



# **FCA Utilities Version 10.6 for Solaris User Manual**

Copyright © 2002-2015 Emulex. All rights reserved worldwide. No part of this document may be reproduced by any means or translated to any electronic medium without the prior written consent of Emulex.

Information furnished by Emulex is believed to be accurate and reliable. However, no responsibility is assumed by Emulex for its use; or for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent, copyright or related rights of Emulex.

Emulex, the Emulex logo, Emulex BladeEngine, Emulex InSpeed, Emulex LightPulse, Emulex OneCommand, Emulex OneConnect, and SLI are registered trademarks, and Emulex Advanced-8, Emulex Connect, Emulex CrossLink, Emulex Engine, Emulex Edge, Emulex ExpressLane, Emulex GreenState, Network Xceleration, Emulex OneCore, Emulex Pilot, Emulex SURF, Emulex Universal Multi-Channel, Emulex vEngine, Emulex Virtual Fabric, Emulex Virtual Network Exceleration, Emulex vPath, Emulex vScale, AutoPilot, AutoPilot Installer, and BlockGuard are trademarks, of Emulex. All other brands or product names referenced herein are trademarks or registered trademarks of their respective companies or organizations.

Emulex provides this manual "as is" without any warranty of any kind, either expressed or implied, including but not limited to the implied warranties of merchantability or fitness for a particular purpose. Emulex may make improvements and changes to the product described in this manual at any time and without any notice. Emulex assumes no responsibility for its use, nor for any infringements of patents or other rights of third parties that may result. Periodic changes are made to information contained herein; although these changes will be incorporated into new editions of this manual, Emulex disclaims any undertaking to give notice of such changes.

Emulex, 3333 Susan Street  
Costa Mesa, CA 92626

# Table of Contents

List of Tables .....	6
<b>1. Introduction .....</b>	<b>7</b>
Supported Drivers .....	7
Abbreviations .....	7
<b>2. Installing and Removing the Utilities.....</b>	<b>9</b>
Supported Operating Systems .....	9
Supported Adapters.....	9
<b>Installing the Utilities for Solaris 10.....</b>	<b>9</b>
Installing the Utilities Using the emlXu_install Script.....	9
Installing the Utilities Manually.....	11
<b>Installing the Utilities for Solaris 11.....</b>	<b>12</b>
Remote Repository Installation .....	12
P5P Archive Installation.....	12
Scripted Installation .....	12
Manual Installation .....	13
<b>Removing the Utilities for Solaris 10.....</b>	<b>13</b>
Removing the Utilities Using the emlXu_remove Script.....	13
Removing the Utilities Manually.....	14
<b>Removing the Utilities for Solaris 11 .....</b>	<b>14</b>
Manual Removal.....	14
Scripted Removal .....	14
<b>Updating the Utilities.....</b>	<b>15</b>
For Solaris 10 .....	15
For Solaris 11 .....	15
<b>3. Using the emlXadm Utility.....</b>	<b>16</b>
<b>Interactive Mode of Operation for emlXadm.....</b>	<b>16</b>
Displaying Available Emulex Adapters .....	16
Selecting an Adapter Port Attached to an SFS or FCT Stack .....	17
Selecting an Adapter Port Attached to a NIC Stack .....	18
Entering emlXadm Commands .....	18
Exiting emlXadm .....	19
<b>CLI Mode of Operation for emlXadm.....</b>	<b>19</b>
Device Path Option in CLI Mode .....	19
Device Path Option for a Single Adapter .....	20

Device Path Option for Multiple Adapters .....	20
Instance Option in CLI Mode .....	21
Using “emlxadm help” for Command Usage in CLI Mode .....	22
<b>Command Descriptions for emlxadm .....</b>	<b>23</b>
boot_code [enable, disable] .....	26
dev_login <wwpn> .....	26
dev_logout <wwpn> .....	26
dev_remove <wwpn> .....	26
diag <test [parameters]> .....	26
diag code <cmd_code> .....	27
download_boot <filename> .....	27
download_fcode <filename> .....	28
download_fw <filename> .....	28
force_dump .....	29
get_boot_rev .....	29
get_dev_list.....	30
get_dump [-h] .....	31
get_dump_size .....	31
get_fcode_rev .....	31
get_fw_rev.....	32
get_hba_attrs.....	32
get_host_attrs.....	33
get_host_params.....	34
get_inst.....	34
get_linkinfo .....	34
get_logi_params <wwpn> .....	35
get_num_devs .....	36
get_path <index> .....	36
get_phy_attrs.....	36
get_port_attrs <index>, <wwn>, all .....	36
get_rnid [wwpn] .....	39
get_state <wwpn> .....	39
get_sym_nname .....	39
get_sym_pname .....	39
get_throttle.....	40
get_topology.....	40
get_vpd.....	40
h .....	41
hba .....	42

link_status <d_id> .....	42
msgbuf [all], <number> [-i interval] .....	43
ns .....	43
p .....	44
parm_get_num .....	45
parm_get <label> .....	45
parm_get_list.....	45
parm_set <label> <value> .....	48
q .....	49
reset_hard .....	49
reset_link <[wwpn] or 0> .....	50
set_sym_nname <“string”> .....	50
set_sym_pname <“string”>.....	50
set_throttle .....	50
<b>4. Using the emlxdrv Utility .....</b>	<b>52</b>
<b>Interactive Mode of Operation for emlxdrv.....</b>	<b>52</b>
Displaying Bindings Between Drivers and Adapter Models.....	53
Entering emlxdrv Commands.....	54
Exiting emlxdrv.....	55
<b>CLI Mode of Operation for emlxdrv.....</b>	<b>55</b>
<b>Command Descriptions for emlxdrv .....</b>	<b>56</b>
clear... .....	56
clear [driver] all .....	57
clear dev [alias] .....	58
clear [driver] emulex.....	58
clear [driver] oracle .....	59
q .....	59
refresh.....	60
set.....	60
set [driver_name] all.....	60
set [driver_name] [alias] .....	61
set [driver_name] emulex .....	62
set [driver_name] oracle .....	62

## List of Tables

<b>Table 3-1</b>	Summary for emlxadm Commands .....	23
<b>Table 4-1</b>	FC Driver Configuration Table Heading Descriptions .....	53
<b>Table 4-2</b>	NIC Driver Configuration Table Heading Descriptions .....	54
<b>Table 4-3</b>	Summary of emlxdrv Commands.....	56

# 1. Introduction

This document provides information for the Emulex<sup>®</sup> emlxadm and emlxdrv Solaris Fibre Channel adapter (FCA) utility programs.

- emlxadm - changes driver parameters through a local interactive or command line interface (CLI) mode. It can also update firmware on non-Oracle branded devices.
- emlxdrv - binds (associates) various Fibre Channel (FC) and network interface card (NIC) drivers to various FC and NIC adapter models, respectively.

## Supported Drivers

Emulex emlxadm and emlxdrv utility programs support the following FC and NIC drivers:

- emlxs - Solaris inbox Fibre Channel/Fibre Channel over Ethernet (FC/FCoE driver)
- elxfc - Emulex distributed FC/FCoE Solaris driver (does not support Oracle-branded devices)
- oce - Solaris inbox NIC driver
- elxnic - Emulex distributed Solaris NIC driver

## Abbreviations

API	application programming interface
CLI	Command line interface
D_ID	destination identifier
ELS	Extended Link Service
FC	Fibre Channel
FCA	Fibre Channel adapter
FCIO	FC input/output
FCoE	Fibre Channel over Ethernet
FCP	Fibre Channel Protocol
FCTL	Fibre Channel transport library
GFC	gigabit Fibre Channel
HBA	host bus adapter
I/O	input/output
IPS	Solaris Image Packaging System
iSCSI	internet Small Computer System Interface
NIC	network interface card (or controller)
PCI	Peripheral Component Interconnect Express

SAN	storage area network
SFS	SAN Foundation Software
VPD	vital product data
WWPN	World Wide Port Name



## 2. Installing and Removing the Utilities

This section details the procedures for installing and removing the FCA utilities.

### Supported Operating Systems

Before installing the utilities, select the appropriate Solaris SFS operating system (see the Emulex website for the latest supported operating systems), and then download the Solaris FCA utilities from the Emulex website.

### Supported Adapters

To determine which adapters are supported by the Solaris SFS FCA drivers (emlxs and elxfc), Solaris Ethernet NIC drivers (oce and elxnic), and the Solaris FCA utilities, see the Emulex website.

## Installing the Utilities for Solaris 10

The emlxadm and emlxdrv utilities are bundled into an emlxu utilities package. Two options are available for installing the emlxu utilities package:

- Using the emlxu\_install script – see “Installing the Utilities Using the emlxu\_install Script” in the following section
- Manually, by using pkgadd – see “Installing the Utilities Manually” on page 11

**Note:** For additional information on installing and removing packages, see the Solaris system administration documentation and the pkgadd(1M) and pkgrm(1M) man pages, which are available on the Oracle website.

### Installing the Utilities Using the emlxu\_install Script

**Note:** Although it is possible to install emlxu onto one or more clients from a server, that procedure is not covered in this document (see the Solaris documentation on the Oracle website for more information).

Before installing the emlxu utilities package, you must install the Solaris 10 Update 9 (or later) with Oracle-recommended patches. Make sure the emlxs or elxfc driver is v2.60k (or later) and the oce driver is v1.10e (or later).

If an earlier version of the emlxu utilities package is installed, in the following procedure, you are prompted to remove it before the script installs the new version.

To install the emlxu utilities package using the emlxu\_install script:

1. Log in as “root”, or “su” to root.
2. Copy the emlxu utilities package from your distribution medium into a directory. The emlxu utilities package is a “tar” file, with a name in the following format:

```
emlxu_kit-<version>-i386.tar
```

3. Change to the directory of the tar file:

```
cd <directory>
```

4. Extract the emlXu\_install script from the tar file:

```
tar xf emlXu_kit-<version>-i386.tar emlXu_install
```

5. Install the emlXu utilities package:

```
emlXu_install
```

If an earlier version of the emlXu utilities package is not found, a message is displayed indicating this, and you can skip to step 7. Otherwise, the script begins removing any earlier version of the emlXu utilities package, and the following message is displayed:

```
<Removing old EMLXemlXu package>
```

6. If an earlier version of the emlXu utilities package is installed, you are prompted to remove it:

```
Do you want to remove this package? [y,n,?,q]
```

Enter "y". The following message is displayed:

```
Removal of <EMLXemlXu> was successful.
```

7. The script expands the new tar file and begins installing the emlXu utilities package. The following message is displayed:

```
<Expanding emlXu_kit-<version>-i386.tar>
```

```
<Adding new package>
```

The package is prepared for installation, and you are prompted to confirm its installation:

```
Do you want to continue with the installation of <EMLXemlXu> [y, n,?]:
```

Enter "y". The installation progress is indicated.

8. Examine the output for any errors or warnings. If the installation is successful, the following message is displayed near the end of the process:

```
Installation of <EMLXemlXu> was successful.
```

The script performs some cleanup and the following messages are displayed:

```
<Cleaning directory>
```

```
<emlXu_install complete>
```

```
<Execute "emlXu_remove" when ready to uninstall>
```

The script copies the emlXu\_remove script into the working directory with the original emlXu utilities package tar file. You can use the emlXu\_remove script later when you want to remove the emlXu utilities from your system. See "Removing the Utilities for Solaris 10" on page 13 for more details. You can also delete the emlXu\_remove script.

The emlXu utilities installation is complete. The emlXu utilities package's programs are located in the /opt/EMLXemlXu/bin directory.

9. You do not have to reboot the system to run a utility program, but you must either enter the program's full path name, or add the package's bin directory (/opt/EMLXemlXu/bin) to the system environment's search path. To use the man

pages provided by the package, you must also add the package's man directory (opt/EMLXemlxu/man) to the system environment's man path.

## Installing the Utilities Manually

**Note:** If an earlier version of the EMLXemlxu utilities package is already installed and you want to install a newer version, you must remove the earlier version manually, as detailed in "Removing the Utilities Manually" on page 14, before installing the newer utilities package manually.

To install the utilities package manually:

1. Log in as "root", or "su" to root.
2. Copy the emlxu utilities package from your distribution medium into a directory. The emlxu utilities package is a "tar" file, with a name in the following format:

```
emlxu_kit-<version>-i386.tar
```

3. Go to the directory of the tar file:

```
cd <directory>
```

4. Extract the emlxu\_install script from the tar file:

```
tar xvf emlxu_kit-<version>-i386.tar
```

5. Install the EMLXemlxu utilities package:

```
pkgadd -d . EMLXemlxu
```

6. The package is prepared for installation, and you are prompted to confirm its installation:

```
Do you want to continue with the installation of <EMLXemlxu> [y,n,?]
```

Enter "y". The installation progress is indicated.

7. Examine the output for any errors or warnings. If the installation is successful, the following message is displayed near the end of the process:

```
Installation of <EMLXemlxu> was successful.
```

The emlxu utilities installation is complete. The utility package's programs are located in the /opt/EMLXemlxu/bin directory.

8. You do not have to reboot the system to run a utility program, but you must either enter the program's full path name or add the package's bin directory (/opt/EMLXemlxu/bin) to the system environment's search path. To use the man pages provided by the package, you must also add the package's man directory (opt/EMLXemlxu/man) to the system environment's man path.

# Installing the Utilities for Solaris 11

## Notes

- Do not install the Emulex Solaris FCA Utility Kit (emlxu) from the p5p bundle or IPS repository on any host that has the OneCommand<sup>®</sup> Manager application installed. Remove the OneCommand Manager kit before installing emlxu using p5p. If you want to run both the OneCommand Manager and emlxu, use the combined installation kit.
- For additional information on installing and removing packages, see the Solaris system administration documentation and the pkgadd(1M) and pkgrm(1M) man pages, which are available on the Oracle website.

## Remote Repository Installation

1. Log in as “root”, or “su” to root.
2. Add the Emulex IPS repository to the publisher list:  

```
$ pkg set-publisher -O http://<repository_url> emulex
```
3. List all available versions of emlxu. For example:  

```
$ pkg list -af emlxu
```

NAME	(PUBLISHER)	VERSION	IFO
emlxu	(emulex)	1.8.4.0-0	---
emlxu	(emulex)	1.8.3.0-0	---
4. By default, the newest version of emlxu that is compatible with the rest of the image will be installed. On the system whose output was displayed in step 3, the following command will install version 1.8.4.0-0:

```
$ pfexec pkg install emlxu
```

To install a specific version of emlxu, append the package version to the package name as follows:

```
$ pfexec pkg install emlxu@1.8.3.0-0
```

In instances where two publishers provide packages of the same name, specify the publisher name as follows:

```
$ pfexec pkg install //emulex/emlxu
```

## P5P Archive Installation

### Scripted Installation

1. Log in as “root”, or “su” to root.
2. Download the p5p tar file from the Emulex website.
3. Untar the archive:

```
$ tar -xvf emlxu_p5p-<version>.tar
```

4. Run the installation script:

```
$ ./emlxu_install
```

## Manual Installation

1. Log in as “root”, or “su” to root.
2. Download the p5p tar file from the Emulex website.
3. Extract the p5p archive from the tar file:  

```
$ tar -xvf eml_xu_p5p-<version>.tar
```
4. Run the following command to install the package:  

```
$ pfexec pkg install -g eml_xu_<version>.p5p eml_xu
```
5. Reboot the system:  

```
$ reboot
```

## Removing the Utilities for Solaris 10

Three options are available for removing the eml\_xu utilities package:

- Using the eml\_xu\_install script - removes any previous versions of the eml\_xu utilities package before installing the latest eml\_xu utilities package. See “Installing the Utilities Using the eml\_xu\_install Script” on page 9.
- Using the eml\_xu\_remove script - removes all eml\_xu files. See “Removing the Utilities Using the eml\_xu\_remove Script” in the following section.
- Manually, by using pkgrm - removes all eml\_xu files. See “Removing the Utilities Manually” on page 14.

## Removing the Utilities Using the eml\_xu\_remove Script

To remove all eml\_xu files using the eml\_xu\_remove script:

1. Log in as “root”, or “su” to root.
2. If you are in the directory of the eml\_xu\_remove script, go to step 4. Otherwise, go to the directory where the original eml\_xu utilities package tar file is located:  

```
cd <directory>
```
3. Extract the eml\_xu\_remove script from the eml\_xu utilities package tar file:  

```
tar xf eml_xu_kit-<version>-i386.tar eml_xu_remove
```
4. Run the eml\_xu\_remove script:  

```
eml_xu_remove
```
5. The eml\_xu\_remove script locates the EMLXeml\_xu package, and the following message is displayed:  

```
<Removing EMLXeml_xu package>
```

If an eml\_xu utilities package is not found, a message is displayed indicating this, and you can skip to step 7. Otherwise, you are prompted to remove the package:

```
Do you want to remove this package? [y,n,?,q]
```

Enter “y”. The following message is displayed:

```
Removal of <EMLXeml_xu> was successful.
```

6. The script performs some cleanup, and the following messages are displayed:  

```
<Removing emlXu scripts>  
<emlXu_remove complete>
```

The utilities package has been removed.
7. If you want to install another version of the emlXu utilities package, follow the instructions provided in one of the following sections:
  - “Installing the Utilities for Solaris 10” on page 9.
  - “Updating the Utilities” on page 15.

## Removing the Utilities Manually

To manually remove the EMLXemlXu utilities package:

1. Log in as “root”, or “su” to root.
2. Run the package removal command:  

```
pkgrm EMLXemlXu
```
3. You are prompted to confirm the package removal:  

```
Do you want to remove this package? [y,n,?,q]
```

Enter “y”. The package is prepared for removal.
4. You are prompted again for confirmation:  

```
Do you want to remove this package? [y,n,?,q]
```

Enter “y”. The following message is displayed:  

```
Removal of <EMLXemlXu> was successful
```

## Removing the Utilities for Solaris 11

### Manual Removal

Run the following command to remove emlXu from the system:

```
$ pkg uninstall emlXu
```

### Scripted Removal

Run the following command to remove emlXu from the system:

```
$ ./emlXu_remove
```

## Updating the Utilities

### For Solaris 10

Two options are available for updating the utilities package:

- Using the `emlxu_install` script - follow the procedure in “Installing the Utilities Using the `emlxu_install` Script” on page 9. In this procedure, if an earlier version of the `emlxu` utilities package is installed, you are prompted to remove it before installing the newer version.
- Manually - first, manually remove the existing EMLXemlxu utilities package as detailed in “Removing the Utilities Manually” on page 14. Then, manually install the newer EMLXemlxu utilities package as detailed in “Installing the Utilities Manually” on page 11.

### For Solaris 11

Two options are available for updating the utilities package:

- Using the remote repository method - run  

```
pkg update emlxu
```
- Using the p5p installation method - follow either the script or the manual procedure in “P5P Archive Installation” on page 12.

## 3. Using the emlxadm Utility

The emlxadm utility changes driver parameters through a local interactive or CLI mode. It can also update firmware on non-Oracle branded devices. The emlxadm utility is intended to be a direct user interface to the FCIO interface provided by the Oracle StorEdge SFS. The FCIO interface provides an Oracle common ioctl interface to the FCTL driver, which manages the FCA drivers for each FC adapter attached to the host system.

The emlxadm utility program can run in two modes:

- Interactive mode (see “Interactive Mode of Operation for emlxadm” in the following section)
- CLI mode (see “CLI Mode of Operation for emlxadm” on page 19)

**Note:** The OneCommand Manager application provides the same functions as emlxadm, and a number of additional ones on multiple systems, through a choice of a graphical user interface and a scriptable command line interface.

To change driver parameters using the OneCommand Manager application, see the *OneCommand Manager Application User Manual* or the *OneCommand Manager Command Line Interface User Manual*.

## Interactive Mode of Operation for emlxadm

To run the emlxadm utility in interactive mode, type “emlxadm” without any command line arguments. For example:

```
# emlxadm
```

### Displaying Available Emulex Adapters

After the emlxadm utility is started, it scans the host system and prepares a list of qualified adapter ports. Qualified adapter ports are devices that are attached to the emlxs, elxfc, oce, or elxnic driver. After each list number, the adapter’s type of stack and type of driver is displayed. For example:

```
Available Emulex HBA's:

1. SFS:emlxs0   : /devices/pci@0,0/pci10de,5d@c/pci10df,e602@0,2/fp@0,0 (CONNECTED)
2. NIC:oce0    : /devices/pci@0,0/pci10de,5d@c/pci10df,e602@0      (CONNECTED)
3. SFS:emlxs1   : /devices/pci@0,0/pci10de,5d@c/pci10df,e602@0,3/fp@0,0 (CONNECTED)
4. NIC:oce1    : /devices/pci@0,0/pci10de,5d@c/pci10df,e602@0,1      (CONNECTED)
5. FCT:emlxs2   : /devices/pci@0,0/pci10de,5d@d/pci10df,f100@0      (CONNECTED)
6. SFS:emlxs3   : /devices/pci@0,0/pci10de,5d@d/pci10df,f100@0,1/fp@0,0 (CONNECTED)
```

```
Enter an HBA number or zero to exit:
```



In this example, six adapter ports are available. For each adapter, the type of stack is indicated. The three types are:

- SFS – the Oracle SFS stack
- NIC – the Oracle networking stack

After the available adapter list is displayed, you are prompted to choose one of the available adapter ports by entering its list number, or you can type “0” or “zero” to exit.

## Selecting an Adapter Port Attached to an SFS or FCT Stack

If you select an adapter port that is attached to an SFS or FCT stack, the emlxadm utility displays a list of available commands. For example, if you enter “1” from the example in “Displaying Available Emulex Adapters” on page 16, the emlxadm utility displays:

```
HBA 1: /devices/pci@0,0/pci10de,5d@pci10df,e602@0,2/fp@0,0
```

```
Available commands:          [FCIO rev2]

get_num_devs                 - Returns the number of FC devices seen by this HBA.
get_dev_list                 - Returns a list of FC devices seen by this HBA.
get_logi_params <wwpn>      - Returns the login parameters for a specified FC device.
get_host_params              - Return the host parameters.
get_sym_pname                 - Returns the symbolic port name of a device.
set_sym_pname <string>      - Sets the symbolic port name for a device.
get_sym_nname                 - Returns the symbolic node name of a device.
set_sym_nname <string>      - Sets the symbolic node name for a device.
dev_login <wwpn>             - Performs an FC login to a device.
dev_logout <wwpn>            - Performs an FC logout to a device.
get_state <wwpn>             - Returns current SFS state of a specified device.
dev_remove <wwpn>           - Remove the FC device from SFS management.
link_status <d_id>           - Request link error status from a specified D_ID.
get_fcode_rev                - Returns the current Fcode revision of the HBA.
download_fcode [filename]    - Download the HBA fcode.
get_fw_rev                   - Returns the current firmware revision of the HBA.
download_fw [filename]       - Download the HBA firmware.
get_boot_rev                 - Returns the current boot revision of the HBA.
get_phy_attrs                - Returns the current PHY attributes for the HBA.
download_boot [filename]     - Download the HBA boot image.
get_dump_size                - Returns the HBA's firmware core dump size.
force_dump                   - Force a firmware core dump on this HBA.
get_dump [-h]                - Saves firmware core dump to a file.
get_topology                 - Returns the current FC network topology.
reset_link [wwpn]            - Resets the link of a specified public loop FC device.
reset_hard                   - Reset the HBA.
diag ...                     - Perform a diagnostic test on the HBA.
ns                            - Performs a complete query of the fabric name server.
parm_get_num                 - Returns the total number of configurable parameters.
parm_get_list                - Returns a list of configurable parameters.
parm_get <label>             - Gets the value of a specified parameter in the driver.
parm_set <label> <val>       - Sets the value of a specified parameter in the driver.
msgbuf [all], <number> [-i interval] - Returns the driver's internal message log.
get_host_attrs               - Returns the host adapter and port attributes.
```

```

get_port_attrs <index>, <wwn>, all - Returns the port attributes.
get_path <index> - Returns the adapter path.
get_vpd - Returns the adapter's Vital Product Data (VPD).
boot_code [enable, disable] - Sets or shows the boot code state in this HBA.
get_rnid [wwpn] - Gets the RNID information for local or specified port.
get_inst - Gets the driver instance.
get_phy_attrs - Returns the current PHY attributes for the HBA. (CNAs only)
set_throttle - Temporarily sets the I/O queue depth for a specified remote
port.
get_throttle - Gets the I/O queue depth for all remote ports.
q - Exits this program.
h - Returns this help screen.
hba - Select another hba.
p - Repeat previous command.

emlxadm>

```

## Selecting an Adapter Port Attached to a NIC Stack

If you select an adapter port that is attached to a NIC stack, the emlxadm utility presents a list of available commands. For example, if you enter “2” from the example in “Displaying Available Emulex Adapters” on page 16, the emlxadm utility displays:

```

HBA 2: /devices/pci@0,0/pci10de,5d@c/pci10df,e602@0 (physical port)

Available commands:      [NIC rev1]

get_hba_attrs - Returns the current control attributes for the HBA.
get_linkinfo - Returns the current link status information for the HBA port.
get_fw_rev - Returns the current firmware revision of the HBA.
download_fw [filename] - Download the HBA firmware.
get_phy_attrs - Returns the current firmware revision of the adapter.
q - Exits this program.
h - Returns this help screen.
hba - Select another HBA.
p - Repeat previous command.

emlxadm>

```

## Entering emlxadm Commands

After the available commands are listed, the “emlxadm>” prompt is displayed. From this point, the utility is prompt-driven. When the prompt is displayed, you can enter one of the commands in the list. For example, you can display the list of available commands at anytime by typing “h” (the help screen) at the prompt:

```
emlxadm> h
```

For some commands, you may have optional or required arguments. If a command requires an argument, but is entered without the argument, a usage statement is returned to indicate that the command requires an argument(s). For example, the get\_state command requires a WWPAN for the target device. Therefore, if you type only “get\_state”:

```
emlxadm> get_state
```

The emlxadm utility returns

```
Usage: get_state <wwpn>
```

Therefore, you must include the <wwpn> argument for the get\_state command to receive a valid response. For example:

```
emlxadm> get_state 21000020371938fa
```

The emlxadm utility can now run the command and display the state:

```
State: PORT_DEVICE_LOGGED_IN
```

## Exiting emlxadm

To exit (quit) the emlxadm utility, type “q” at the prompt:

```
emlxadm> q
```

## CLI Mode of Operation for emlxadm

Two options are available to run emlxadm in a CLI mode:

- Device path option (see the following section)
- Instance option (see page 21)

### Device Path Option in CLI Mode

In this CLI mode option, type “emlxadm”, the device path, followed by a valid command, and its command arguments (if applicable).

#### Syntax

```
emlxadm <device path> [-y] <cmd> [cmd_option(s)]
```

#### Arguments

device path	Specifies the full device name for a single adapter or a pattern string for multiple adapters. If the pattern string matches any part of an adapter device path, the command runs on that adapter.
-y	If the [-y] option is included, the emlxadm utility runs immediately without pausing for a verification from the user to continue. If the [-y] option is absent, the emlxadm utility pauses for a verification from the user before running the command.
cmd	An emlxadm command. See Table 3-1, Summary for emlxadm Commands, on page 23.
cmd_option(s)	Various emlxadm command arguments, if applicable.

## Device Path Option for a Single Adapter

When using the device path option for single adapters, the <device path> parameter must be the full device name for the single adapter.

### Running a Command with User Verification

In this example, the emlxadm utility pauses for verification before running the command. Type "emlxadm", the full device name (/devices/pci@1e,600000/SUNW,emlxs@2/fp@0,0:devctl), the command (get\_state), and its <wwpn> argument (21000020371938fa):

```
# emlxadm /devices/pci@1e,600000/SUNW,emlxs@2/fp@0,0:devctl
get_state 21000020371938fa
```

The elxadm utility returns some status, but pauses for a response before running the command:

```
Found path to 1 HBA port(s).
HBA port: /devices/pci@1e,6000000/SUNW,emlxs@2/fp@0,0:devctl
>Do you wish to continue with this device [y,n,q] ? y
```

After you type "y", the emlxadm utility runs the command and displays the result:

```
State: PORT_DEVICE_LOGGED_IN
#
```

### Running a Command without User Verification (Using [-y])

If you do not want the emlxadm utility to pause for verification before running the command, include the "-y" option after the full device name. For example, if you type "emlxadm", the "-y" option, the full device name, the command, and its argument, the elxadm utility runs the command immediately:

```
# emlxadm /devices/pci@1e,600000/SUNW,emlxs@2/fp@0,0:devctl -y
get_state 21000020371938fa
```

```
Found path to 1 HBA port(s).
HBA port: /devices/pci@1e,600000/SUNW,emlxs@2/fp@0,0:devctl
State: PORT_DEVICE_LOGGED_IN
#
```

## Device Path Option for Multiple Adapters

When using the device path option for multiple adapters, use a pattern string for the <device path> parameter. If the pattern string matches any part of an adapter device path, the command runs on that adapter.

### Running a Command with User Verification

In this example, the emlxadm utility pauses for verification before running the command.

Type “emlxadm”, the pattern string (“SUNW,emlxs@2”), and the command (get\_num\_devs):

```
# emlxadm "SUNW,emlxs@2" get_num_devs
```

The elxadm utility returns some status, but pauses for a response before running the command:

```
Found path to 2 HBA port(s).
HBA port: /devices/pci@1e,600000/SUNW,emlxs@2/fp@0,0:devctl
> Do you wish to continue with this device [y,n,q] ? y
```

After you type “y”, the elxadm utility returns more information, but again pauses for a response before running the command:

```
There are 5 devices reported on this port.
HBA port: /devices/pci@1e,600000/SUNW,emlxs@2,1/fp@0,0:devctl
> Do you wish to continue with this device [y,n,q] ? y
```

After you type “y”, the emlxadm utility runs the command and displays the result:

```
There are 0 devices reported on this port.
#
```

### Running a Command without User Verification (Using [-y])

If you do not want the emlxadm utility to pause for verification before running the command, include the “-y” option after the pattern string. For example, if you type “emlxadm”, the “-y” option, the pattern string, and the command, the elxadm utility runs the command immediately:

```
# emlxadm "SUNW,emlxs@2" -y get_num_devs

Found path to 2 HBA port(s).

HBA port: /devices/pci@1e,600000/SUNW,emlxs@2/fp@0,0:devctl
There are 5 devices reported on this port.

HBA port: /devices/pci@1e,600000/SUNW,emlxs@2,1/fp@0,0:devctl
There are 0 devices reported on this port.
#
```

## Instance Option in CLI Mode

This CLI mode option enables you to use the emlxadm utility as part of a script or another program capable of running system-level calls.

### Syntax

```
emlxadm -i<N,SFS,FCT or all> [-y] <cmd> [cmd_option(s)]
```

## Arguments

N	Indicates a specific emlxs driver instance. For example, N=1 means "emlxs1", N=2 means "emlxs2", and N=2.1 means "emlxs2.1".
SFS	Indicates all emlxs driver instances that are attached to the Oracle SFS interface.
all	Indicates all emlxs driver instances.
-y	If the [-y] option is included, the emlxadm utility runs immediately. It does not pause for verification to continue. If the [-y] option is absent, the emlxadm utility pauses for verification before running the command.
cmd	An emlxadm command. See Table 3-1, Summary for emlxadm Commands, on page 23.
cmd_option(s)	Various emlxadm command arguments, if applicable.

## Using "emlxadm help" for Command Usage in CLI Mode

The emlxadm utility offers help for command usage in CLI mode. To invoke a usage help screen, type "emlxadm help" at the prompt. The CLI mode usage screen is displayed as follows:

```

USAGE:  emlxadm          :Runs utility in interactive mode.
        or
        emlxadm -v
        or
        emlxadm -i<N, SFS, FCT, or all> [-y] <cmd> [cmd_option(s)]
        or
        emlxadm -j<N, SFS, FCT, or all> [-y] <cmd> [cmd_option(s)]
        or
        emlxadm -n<N or all> [-y] <cmd> [cmd_option(s)]
        or
        emlxadm -m<N or all> [-y] <cmd> [cmd_option(s)]
        or
        emlxadm <device_path> [-y] <cmd> [cmd_option(s)]

OPTIONS:
        -v          Display utility version information.
        -i<N>      Executes command on a specific emlxs driver
                   instance. (Example: N=2 for emlxs2 or N=2.1 for emlxs2.1)
        -iSFS      Executes command on all SFS emlxs driver instances.
        -iFCT      Executes command on all FCT emlxs driver instances.
        -iall      Executes command on all emlxs driver instances.
        -j<N>      Executes command on a specific elxyc driver
                   instance. (Example: N=2 for elxyc2 or N=2.1 for elxyc2.1)
        -jSFS      Executes command on all SFS elxyc driver instances.

```

-jFCT	Executes command on all FCT elxfc driver instances.
-jall	Executes command on all elxfc driver instances.
-n<N>	Executes command on a specific oce driver instance. (Example: N=2 for oce2 or N=5 for oce5)
-nall	Executes command on all oce driver instances.
-m<N>	Executes command on a specific elxnic driver instance. (Example: N=2 for elxnic2 or N=5 for elxnic5)
-mall	Executes command on all oce driver instances.
device_path	If a full device path is not specified, then the command will be executed on all device paths containing the specified device_path string.
-y	If multiple devices are found, the utility will ask for verification before executing the command on each device. This option will cause the utility to skip the verification and automatically execute the command on each device.

## Command Descriptions for emlxadm

This section provides a list of commands and descriptions that can be issued with the emlxadm utility. Table 3-1 summarizes this command list, including abbreviated descriptions.

**Table 3-1** Summary for emlxadm Commands

Command Syntax	Description	Page
boot_code [enable, disable]	Sets or shows the boot code state of the current adapter.	26
dev_login <wwpn>	Performs an FC login to an FC device on the network, if not already logged in.	26
dev_logout <wwpn>	Performs an FC logout to an FC device on the network, if not already logged out.	26
dev_remove <wwpn>	Removes the specified FC device from Solaris SFS management.	26
diag...	Performs a diagnostic test on the adapter. Two formats are available: diag <test [parameters]> Performs a diagnostic test on the adapter port specified by an Emulex-specific test and its parameters (if applicable).  diag code <cmd_code> Performs a diagnostic test on the adapter port specified by a diagnostic command code (in hexadecimal). This command provides generic support to issue an adapter-specific diagnostic code to any third-party adapter.	26          27
download_boot <filename>	Downloads the specified boot image file to the adapter.	27

**Table 3-1** Summary for emlxadm Commands (Continued)

Command Syntax	Description	Page
download_fcode <filename>	Downloads the specified FCode image file to the adapter.	28
download_fw <filename>	Downloads the specified firmware image file to the adapter.	28
force_dump	Forces a firmware core dump on the adapter.	29
get_boot_rev	Returns the current boot revision of the adapter.	29
get_dev_list	Returns a list of FC devices currently seen by this adapter port.	30
get_dump [-h]	Saves the firmware core dump to a file.	31
get_dump_size	Returns the adapter's firmware core dump size.	31
get_fcode_rev	Returns the current FCode version of the adapter.	31
get_fw_rev	Returns the current firmware version of the adapter.	32
get_hba_attrs	Returns the current control attributes for the adapter.	32
get_host_attrs	Displays all of the current host adapter API attributes.	33
get_host_params	Returns the FC login parameters of this adapter port.	34
get_inst	Returns driver instance for this adapter port.	34
get_linkinfo	Returns the current link status information for the adapter port.	34
get_logi_params <wwpn>	Returns the FC login common service parameters for a specified FC device on the network.	35
get_num_devs	Returns the number of FC devices currently seen by this adapter port.	28
get_path <index>	Shows the current Solaris device path for a specified adapter port. The total number of ports available can be seen in the "Number of HBA ports" attribute displayed using the get_host_attrs command. The <index> argument is an index into this list.	36
get_phy_attrs	Shows the current PHY module attributes of the adapter. <b>Note:</b> This command applies to CNAs only.	36
get_port_attrs <index>, <wwn>, all	Shows the current adapter API port attributes. All of the ports' attributes can be displayed, or a single port can be specified by <index> or <wwn>. The total number of ports available can be seen in the "Number of Discovered Ports" attribute displayed using the get_host_attrs command. The <index> argument is an index into this list.	36
get_rnid [wwpn]	Returns the request node identification data information for the local or specified port.	39
get_state <wwpn>	Returns the current Solaris SFS state of the specified FC device on the network.	39



**Table 3-1** Summary for emlxadm Commands (Continued)

Command Syntax	Description	Page
get_sym_nname	Returns the symbolic FC node name of the adapter port. <b>Note:</b> This operation is not supported by the Solaris SFS stack.	39
get_sym_pname	Returns the symbolic FC port name of the adapter port. <b>Note:</b> This operation is not supported by the Solaris SFS stack.	39
get_throttle	Returns the I/O queue depth of all remote ports.	40
get_topology	Returns the FC network topology of the adapter port.	40
get_vpd	Shows the current adapter's vital product data.	40
h	Returns the help screen, that is, it lists the available commands.	41
hba	Allows you to select another adapter with which to interface. This prevents you from having to exit and reenter the program.	42
link_status <d_id>	Requests and returns the current link error status from the FC device specified by the D_ID address.	42
msgbuf [all], <number> [-i interval]	This command displays the current driver log, with various options.	43
ns	Performs and returns a complete query of the fabric name server.	43
p	Repeats the last command.	44
parm_get <label>	Retrieves the value of a specified parameter in the driver.	45
parm_get_list	Returns a list of configurable parameters.	45
parm_get_num	Returns the total number of configurable parameters.	45
parm_set <label> <value>	Sets the value of a specified parameter in the driver. Only dynamic parameters can be set.	48
q	Exits (quits) the utility program.	49
reset_hard	Forces the adapter to perform a hardware reset.	49
reset_link <[wwpn] or 0>	If the [wwpn] parameter is specified, this command resets the link of the specified FC device on the network. If "0" (zero) is specified, this command resets the local link.	50
set_sym_nname <"string">	Sets the symbolic FC node name of the adapter to the string provided. <b>Note:</b> This operation is not supported by the Solaris SFS stack.	50
set_sym_pname <"string">	Sets the symbolic FC port name of the adapter to the string provided. <b>Note:</b> This operation is not supported by the Solaris SFS stack.	50

Table 3-1 Summary for emlxadm Commands (Continued)

Command Syntax	Description	Page
set_throttle	Temporarily sets the I/O queue depth for a specified remote port.	50

## boot\_code [enable, disable]

Shows or sets the boot code state of the current adapter.

### Examples

To show the current boot code:

```
emlxadm> boot_code
Boot code: Disabled
```

To enable the boot code:

```
emlxadm> boot_code enable
Boot code: Enabled
```

To disable the boot code:

```
emlxadm> boot_code disable
Boot code: Disabled
```

## dev\_login <wwpn>

Performs an FC login to an FC device on the network, if it is not already logged in.

### Example

```
emlxadm> dev_login 21000020371938fa
Done.
```

## dev\_logout <wwpn>

Performs an FC logout to an FC device on the network, if not already logged out.

### Example

```
emlxadm> dev_logout 21000020371938fa
Done.
```

## dev\_remove <wwpn>

Removes the specified FC device from Solaris SFS management.

## diag <test [parameters]>

Performs the diagnostics function on the adapter port. This command provides support for Emulex-specific tests.

### <test [parameters]>

<code>emlx_biu [pattern]</code>	Performs the bus interface unit test. The [pattern] parameter is a 4-byte hexadecimal pattern to be used for the test (for example, 0xA5A5A5A5).
<code>emlx_echo &lt;did&gt; [pattern]</code>	Performs the echo test to a specified port ID. The [pattern] parameter is a 4-byte hexadecimal pattern to be used for the test (for example, 0xA5A5A5A5).
<code>emlx_post</code>	Performs the power-on self tests.

### Examples

Performs the bus interface unit test:

```
emlxadm> diag emlx_biu
Result: EMLX_DIAG_BIU: Operation successful.
```

Performs the echo test to a <did>=ffffc:

```
emlxadm> diag emlx_echo fffffc
Result: EMLX_DIAG_ECHO: Operation successful.
```

Performs the power-on self tests:

```
emlxadm> diag emlx_post
Result: EMLX_DIAG_POST: Operation successful.
```

### diag code <cmd\_code>

Performs a diagnostic test on the adapter port specified by a diagnostic command code (in hexadecimal format). This command provides generic support to issue an adapter-specific diagnostic code to any third-party adapter.

**Note:** The return status from the adapter is displayed in decimal and hexadecimal format if the diagnostic command code is valid for the adapter. No interpretation of the return status is provided.

### Examples

```
emlxadm> diag code 0x4526
Result: CODE(0x4526): 16 (0x10)
```

### download\_boot <filename>

Downloads the specified boot image file to the adapter.

### Example

```
emlxadm> download_boot TD190A4.PRG
```

```
Image Components: REL type    size=143416
DWC file:          BOOT: version=03845054, 1.90a4
```

```
Current: Boot: 1.90a3
New:      Boot: 1.90a4  143416 (0x23038) bytes
```

```
Are you sure you want to download this image? (y or n): y
Downloading...
Done.
```

## download\_fcode <filename>

Downloads the specified FCode image file to the adapter.

### Example

```
emlxadm> download_fcode LPe12000DC-S.fcode
Image Components: REL type  size=33848
    DWC file:          BOOT: version=03841512, 1.50a2
```

```
Current: Fcode: 1.50a2
New:      Fcode: 1.05e  33848 (0x8438) bytes
```

```
Are you sure you want to download this image? (y or n): y

Downloading...
Result: Operation successful.
Done.
```

## download\_fw <filename>

Downloads the specified firmware image file to the adapter.

**Note:** The Emulex FCA driver does not allow a firmware update to Oracle-branded adapters.

### Example

```
emlxadm> download_fw LPe12000DC-S.fw
Image Components: NOP type
    AWC file:          KERN: version=ff801315, 1.30a5
    DWC file:          SLI2: version=07831914, 1.90a4
    DWC prog:          TEST: version=00f51010, 1.00a0
    DWC prog:          STUB: version=02881914, 1.90a4
    DWC prog:          SLI1: version=06831914, 1.90a4
    DWC prog:          SLI2: version=07831914, 1.90a4
```

```
Current: Firmware: 1.90a4
```

```
New:      Firmware: 1.05e 366712 (0x59878) bytes
```

```
Are you sure you want to download this image? (y or n): y
```

```
Downloading...
```

```
Done.
```

## **force\_dump**

Forces a firmware core dump on the adapter.

### **Example**

```
emlxadm> force_dump
```

```
Done.
```

## **get\_boot\_rev**

Returns the current boot revision of the adapter.

### **Example**

```
emlxadm> get_boot_rev
```

```
Firmware revision: LPe12000DC-S 1.90a3
```

## get\_dev\_list

Returns a list of FC devices currently seen by this adapter port.

### Example

```
emlxadm> get_dev_list
-----
Device 0:
    Dtype: 0
    FC4_type[proto]: 0x00000100, 0x00000000, 0x00000000, 0x00000000,
                    0x00000000, 0x00000000, 0x00000000, 0x00000000
    State: Logged_In
    D_id: 113e1
    LILP: 0
    Hard Addr: e1
    WWPN: 21000020371938fa
    WWNN: 20000020371938fa
-----
Device 1:
    Dtype: 0
    FC4_type[proto]: 0x00000100, 0x00000000, 0x00000000, 0x00000000,
                    0x00000000, 0x00000000, 0x00000000, 0x00000000
    State: Logged_In
    D_id: 113e2
    LILP: 0
    Hard Addr: e2
    WWPN: 21000020371939a2
    WWNN: 20000020371939a2
-----
Device 2:
    Dtype: 0
    FC4_type[proto]: 0x00000100, 0x00000000, 0x00000000, 0x00000000,
                    0x00000000, 0x00000000, 0x00000000, 0x00000000
    State: Logged_In
    D_id: 113e4
    LILP: 0
    Hard Addr: e4
    WWPN: 21000020371938a3
    WWNN: 20000020371938a3
-----
Device 3:
    Dtype: 0
```

```
FC4_type[proto]: 0x00000100, 0x00000000, 0x00000000, 0x00000000,  
                0x00000000, 0x00000000, 0x00000000, 0x00000000  
State: Logged_In  
D_id: 113e8  
LILP: 0  
Hard Addr: e8  
WWPN: 2100002037193670  
WWNN: 2000002037193670
```

## get\_dump [-h]

Saves the firmware core dump to a file.

### Example

Result if a valid dump exists in the driver memory:

```
emlxadm> get_dump -h  
Core size: 6580624 bytes  
files: 2  
TXT file: 13728  
DMP file: 6566876
```

Result if a valid dump does not exist in the driver memory:

```
emlxadm> get_dump -h  
No core file available.
```

## get\_dump\_size

Returns the adapter's firmware core dump size.

### Example

Result if a valid dump exists in the driver memory:

```
emlxadm> get_dump_size  
Size: 6580624 (0x646990) bytes
```

Result if a valid dump does not exist in the driver memory:

```
emlxadm> get_dump_size  
Size: 0 (0x0) bytes
```

## get\_fcode\_rev

Returns the current FCode revision of the adapter.

### Example

```
emlxadm> get_fcode_rev  
FCODE revision: LPe12000-S 1.41a3
```

## get\_fw\_rev

Returns the current firmware version of the adapter.

### Example

```
emlxadm> get_fw_rev  
Firmware revision: LPe12000DC-S 1.90a3
```

## get\_hba\_attrs

Returns the current control attributes for the adapter.

### Example

```
emlxadm> get_hba_attrs  
  
HBA:  
  
Flash ROM Version: SE HBA ATTR VER:0000.0001  
Manufacturer: Emulex Corporation  
Support Modes: TOE,NIC,VM,FCOE_INI,LRO,0  
SEEPROM Version: 2.32  
IOCTL Version: 0x00012345  
EP Fw Version: 0x00897654  
NCSI Version:  
Def Extended Timeout: 0  
Model: OneConnect OCell1102  
Description: BladeEngine 3 10Gb FCoE Initiator  
Serial Number: 0x4254393431383237383100000000000000000000000000000000  
IP Version: IPv4  
Firmware Version: 2.701.374.2  
BIOS Version: 2.701.374.2  
REDBOOT Version: 2.0.38.0  
Driver Version:  
Flash Firmware Version: 2.701.374.2  
Functions Supported: 0  
Max CDB Length: 0  
ASIC Revision: A2  
Generational GUID:  
HBA Port Count: 2  
Multifunction Device: True  
iSCSI Version: 11  
Def Linkdown Timeout: 0  
Physical Port: 0  
Max Domains Supported: 1  
HBA Status: Operational  
Cache Valid: True  
HBA MTU: 8342 8342 0 0 0 0 0 0  
Firmware Post Status: 0xC000
```



```

iSCSI Features: LIST_MODE,0
  PCI Vendor ID: 0x19a2
  PCI Device ID: 0x0700
  PCI SubVendor ID: 0x10df
  PCI SubDevice ID: 0xe602
  PCI Bus Number: 0
  PCI Device Number: 0
  PCI Function Number: 0
  Interface Type: 0
  Unique Identifier: 0
  Net Filters: 8

```

## get\_host\_attrs

Displays all of the current host adapter API attributes.

### Example

```
emlxadm> get_host_attrs
```

```

Host Attributes:
  Manufacturer           = Oracle Microsystems, Inc.
  Serial Number          = BG43918495
  Model                  = LPe12000DC-S
  Model Description      = EMULEX LIGHTPULSE LPe12000DC-S 2GB PCI-X
                        FIBRE CHANNEL ADAPTER
  Node WWN                = 20000000C942097E
  Node Symbolic Name     = none
  Hardware Version       = 1001206d
  Driver Version         = 1.11f.t3 (2006.04.25.11.43)
  Optional ROM Version   = 1.50a9test1
  Firmware Version       = 1.91b5
  Vendor Specific ID     = fc00
  Number of HBA ports    = 1
  Driver Name            = Emulex-S s9-64 v1.11f.t3
  Last Change            = 5
  fp Instance            = e
  Node WWN                = 20000000C942097E
  Port WWN               = 10000000C942097E
  Port Fc Id             = 011700
  Port Type               = Nport
  Port State             = Online
  Port Supported COS     = Class3
  Port Supported FC4 Types = 00000000, 00000000, 00000000, 00000000,
                        00000000, 00000000, 00000000, 00000000,
  Port Active FC4 Types  = 00000120, 00000000, 00000000, 00000000,
                        00000000, 00000000, 00000000, 00000000,
  Port Symbolic Name     = none
  Port Supported Speed   = 1Gb, 2Gb

```

```
Port Speed = 1Gb
Port Max Frame Size = 0x800 bytes
Fabric Name = 0000000000000000
Number of Discovered Ports = 4
```

## get\_host\_params

Returns the FC login parameters of this adapter port.

### Example

```
emlxadm> get_host_params
Host:
    Dtype: 0
FC4_type[proto]: 0x00000120, 0x00000000, 0x00000000, 0x00000000,
                  0x00000000, 0x00000000, 0x00000000, 0x00000000
    State: Online
    Linkspeed: 1Gb
    D_id: 11700
    LILP: 5
    Hard Addr: 0
    WWPN: 10000000c942097e
    WWNN: 20000000c942097e
```

## get\_inst

Returns driver instance for this adapter port.

### Example

```
emlxadm> get_inst
emlxs0
```

## get\_linkinfo

Returns the current link status information for the adapter port.

### Example

```
emlxadm> get_linkinfo

Physical port: 0
MAC Duplex: Full Duplex
MAC Speed: 10 Gbps
MAC Fault: None
Mgmt MAC Duplex: None
Mgmt MAC Speed: None
QOS Link Speed: Disabled
Logical Link Status: Link Up
```

## get\_logi\_params <wwpn>

Returns the FC login common service parameters for a specified FC device on the network.

### Example

```
emlxadm> get_logi_params 21000020371938fa
```

```
Login Parameters:
```

```
00 00 00 00  
20 20 00 00  
88 00 08 00  
00 ff 00 02  
00 00 01 f4  
21 00 00 20  
37 19 38 fa  
20 00 00 20  
37 19 38 fa  
00 00 00 00  
00 00 00 00  
00 00 00 00  
00 00 00 00  
00 00 00 00  
00 00 00 00  
00 00 00 00  
00 00 00 00  
00 00 00 00  
80 00 00 00  
00 00 08 00  
00 ff 00 00  
00 01 00 00  
00 00 00 00  
00 00 00 00  
00 00 00 00  
00 00 00 00  
00 00 00 00  
00 00 00 00  
00 00 00 00  
00 00 00 00  
00 00 00 00
```

## get\_num\_devs

Returns the number of FC devices currently seen by this adapter port.

### Example

```
emlxadm> get_num_devs
There are 4 devices reported on this port.
```

## get\_path <index>

Shows the current Solaris device path for a specified adapter port. The total number of ports available can be seen in the “Number of HBA ports” attribute displayed using the `get_host_attrs` command (page 33). The `<index>` argument is an index into this list.

### Example

```
emlxadm> get_path 0
Adapter: /pci@1e,600000/SUNW,emlxs@2/fp@0,0

emlxadm> get_path 1
Adapter: /pci@1e,600000/SUNW,emlxs@2,1/fp@0,0
```

## get\_phy\_attrs

Shows the current physical layer module attributes of the adapter. This command applies to CNAs only.

### Example

```
emlxadm> get_phy_attrs

PHY Attributes:
  PHY Type: XAUI
  Interface Type: CX4 10 GB
  Flags: 0x00000000
```

## get\_port\_attrs <index>, <wwn>, all

Shows the current adapter API port attributes. All of the ports’ attributes can be displayed, or a single port can be specified by `<index>` or `<wwn>`. The total number of ports available can be seen in the “Number of Discovered Ports” attribute displayed using the `get_host_attrs` command. The `<index>` argument is an index into this list.

### Example

```
emlxadm> get_port_attrs all

Host Port Attributes:
```

```

Last Change                = 5
fp Instance                 = e
Node WWN                   = 20000000C942097E
Port WWN                   = 10000000C942097E
Port Fc Id                 = 011700
Port Type                  = Nport
Port State                 = Online
Port Supported COS         = Class3
Port Supported FC4 Types   = 00000000, 00000000, 00000000, 00000000,
                          00000000, 00000000, 00000000, 00000000
Port Active FC4 Types     = 00000000, 00000000, 00000000, 00000000,
                          00000000, 00000000, 00000000, 00000000
Port Symbolic Name        = none
Port Supported Speed       = 1Gb, 2Gb
Port Speed                 = 1Gb
Port Max Frame Size        = 0x800 bytes
Fabric Name                = 0000000000000000
Number of Discovered Ports = 4

```

Port[0] Attributes:

```

Node WWN                   = 20000020371938FA
Port WWN                   = 21000020371938FA
Port Fc Id                 = 0113e1
Port Type                  = Unknown
Port State                 = Unknown
Port Supported COS         = Class3
Port Supported FC4 Types   = 00000000, 00000000, 00000000, 00000000,
                          00000000, 00000000, 00000000, 00000000
Port Active FC4 Types:    = 00000000, 00000000, 00000000, 00000000,
                          00000000, 00000000, 00000000, 00000000
Port Symbolic Name        = SEAGATE ST39103FC      0004
Port Supported Speed       = Unknown
Port Speed                 = Unknown
Port Max Frame Size        = 0x0 bytes
Fabric Name                = 0000000000000000

```

Port[1] Attributes:

```

Node WWN                   = 20000020371938A2
Port WWN                   = 21000020371938A2
Port Fc Id                 = 0113e2
Port Type                  = Unknown

```

```

Port State = Unknown
Port Supported COS = Class3
Port Supported FC4 Types: = 00000000, 00000000, 00000000, 00000000,
                          00000000, 00000000, 00000000, 00000000
Port Active FC4 Types: = 00000000, 00000000, 00000000, 00000000,
                       00000000, 00000000, 00000000, 00000000
Port Symbolic Name = SEAGATE ST39103FC 0004
Port Supported Speed = Unknown
Port Speed = Unknown
Port Max Frame Size = 0x0 bytes
Fabric Name = 000000000000000000

```

Port[2] Attributes:

```

Node WWN = 20000020371939A3
Port WWN = 21000020371939A3
Port Fc Id = 0113e4
Port Type = Unknown
Port State = Unknown
Port Supported COS = Class3
Port Supported FC4 Types: = 00000000, 00000000, 00000000, 00000000,
                          00000000, 00000000, 00000000, 00000000
Port Active FC4 Types: = 00000000, 00000000, 00000000, 00000000,
                       00000000, 00000000, 00000000, 00000000
Port Symbolic Name = SEAGATE ST39103FC 0004
Port Supported Speed = Unknown
Port Speed = Unknown
Port Max Frame Size = 0x0 bytes
Fabric Name = 000000000000000000

```

Port[3] Attributes:

```

Node WWN = 2000002037193670
Port WWN = 2100002037193670
Port Fc Id = 0113e8
Port Type = Unknown
Port State = Unknown
Port Supported COS = Class3
Port Supported FC4 Types: = 00000000, 00000000, 00000000, 00000000,
                          00000000, 00000000, 00000000, 00000000
Port Active FC4 Types: = 00000000, 00000000, 00000000, 00000000,
                       00000000, 00000000, 00000000, 00000000
Port Symbolic Name = SEAGATE ST39103FC 0004

```

```

Port Supported Speed      = Unknown
Port Speed                = Unknown
Port Max Frame Size      = 0x0 bytes
Fabric Name               = 0000000000000000

```

## get\_rnid [wwpn]

Returns the request node identification data ELS information for the local or specified port.

### Example

```

emlxadm> get_rnid
Offset: 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F  ASCII:
-----
0:      31 30 30 30 30 30 30 30 63 39 34 63 62 64 34 65 10000000c94cbd4e
10:     00 00 00 07 00 00 00 00 00 00 00 00 00 01 00 00 .....
20:     00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 .....
30:     00 00 00 00 .....
Done.

```

## get\_state <wwpn>

Returns the current Solaris SFS state of the specified FC device on the network.

### Example

```

emlxadm> get_state 21000020371938fa

State: PORT_DEVICE_LOGGED_IN

```

## get\_sym\_nname

Returns the symbolic FC node name of the adapter port.

**Note:** This operation is not supported by the Solaris SFS stack.

### Example

```

emlxadm> get_sym_nname
ioctl: FCIO_GET_SYM_NNAME: Operation not supported

```

## get\_sym\_pname

Returns the symbolic FC port name of the adapter port.

**Note:** This operation is not supported by the Solaris SFS stack.

### Example

```

emlxadm> get_sym_pname

```

```
ioctl: FCIO_GET_SYM_PNAME: Operation not supported
```

## get\_throttle

Returns the I/O queue depth of all remote ports. The queue depth represents the maximum concurrent I/Os the driver allows to the remote port at any given time. The default queue depth for an FCP target port is specified by the “target-depth” driver parameter.

### Example

```
emlxadm> get_throttle

_____WWPN: Depth
21000011c6810947: 512
21000011c681065f: 512
21000011c68108c0: 512
21000011c681061d: 512
```

## get\_topology

Returns the FC network topology of the adapter port.

### Example

```
emlxadm> get_topology
Topology: PRIVATE_LOOP
```

## get\_vpd

Displays the current adapter’s vital product data.

### Example

```
emlxadm> get_vpd
Vital Product Data:
  Identifier (ID): FC2G PCI-X LPe12000DC - Oracle
  Part Number (PN): LPe12000DC-S
  Manufacturer (MN): Oracle.
  Serial Number (SN): BG43918495
  Description (V1): EMULEX LIGHTPULSE LPe12000DC-S 2GB PCI-X FIBRE CHANNEL ADAPTER
  Model (V2): LPe12000DC-S
  Program Types (V3): T2:83,88,T3:84,T6:83,T7:83,TB:83,TFF:80
  Port Number (V4): 0
```



## h

Returns the help screen of the available commands.

### Example

This example shows the help screen for an adapter port that is attached to an SFS or FCT stack.

```
emlxadm> h

Available commands:          [FCIO rev2]

get_num_devs                - Returns the number of FC devices seen by this HBA.
get_dev_list                - Returns a list of FC devices seen by this HBA.
get_logi_params <wwpn>     - Returns the login paramters for a specified FC device.
get_host_params             - Return the host parameters.
get_sym_pname               - Returns the symbolic port name of a device.
set_sym_pname <string>     - Sets the symbolic port name for a device.
get_sym_nname               - Returns the symbolic node name of a device.
set_sym_nname <string>     - Sets the symbolic node name for a device.
dev_login <wwpn>           - Performs an FC login to a device.
dev_logout <wwpn>          - Performs an FC logout to a device.
get_state <wwpn>           - Returns current SFS state of a specified device.
dev_remove <wwpn>          - Remove the FC device from SFS management.
link_status <d_id>         - Request link error status from a specified D_ID.
get_fcode_rev               - Returns the current Fcode revision of the HBA.
download_fcode [filename]  - Download the HBA fcode.
get_fw_rev                  - Returns the current firmware revision of the HBA.
download_fw [filename]     - Download the HBA firmware.
get_boot_rev                - Returns the current boot revision of the HBA.
download_boot [filename]   - Download the HBA boot image.
get_dump_size               - Returns the HBA's firmware core dump size.
force_dump                  - Force a firmware core dump on this HBA.
get_dump [-h]               - Saves firmware core dump to a file.
get_topology                - Returns the current FC network topology.
reset_link [wwpn]          - Resets the link of a specified public loop FC device.
reset_hard                  - Reset the HBA.
diag ...                    - Perform a diagnostic test on the HBA.
ns                           - Performs a complete query of the fabric name server.
parm_get_num                - Returns the total number of configurable parameters.
parm_get_list               - Returns a list of configurable parameters.
parm_get <label>            - Gets the value of a specified parameter in the driver.
parm_set <label> <val>     - Sets the value of a specified parameter in the driver.
msgbuf [all], <number> [-i interval] - Returns the driver's internal message log.
get_host_attrs              - Returns the host adapter and port attributes.
get_port_attrs <index>, <wwn>, all - Returns the port attributes.
get_path <index>            - Returns the adapter path.
get_vpd                     - Returns the adapter's Vital Product Data (VPD).
boot_code [enable, disable] - Sets or shows the boot code state in this HBA.
get_rnid [wwpn]             - Gets the RNID information for local or specified port.
get_inst                    - Gets the driver instance.
get_phy_attrs               - Returns the current PHY attributes for the HBA. (CNAs only)
```

```
set_throttle...      - Temporarily sets the I/O queue depth for a specified remote
                      port.
get_throttle         - Gets the I/O queue depth for all remote ports.
q                   - Exits this program.
h                   - Returns this help screen.
hba                 - Select another hba.
p                   - Repeat previous command.

emlxadm>
```

## hba

Selects another adapter with which to interface. This command allows you to connect to another adapter without having to exit and re-enter the program.

### Example

```
emlxadm> hba
```

Available Emulex HBA's:

1. SFS:emlxs0: /devices/pci@7c0/pci@0/pci@1/pci@0,2/SUNW,emlxs@1/fp@0,0 (CONNECTED)
2. FCT:emlxs1: /devices/pci@7c0/pci@0/pci@1/pci@0,2/SUNW,emlxs@1,1 (CONNECTED)

Enter an HBA number or zero to exit:

## link\_status <d\_id>

Requests and returns the current link error status from the FC device specified by the D\_ID address.

### Example

```
emlxadm> link_status e8
```

D\_ID: e8

```
          Link failures: 3 (0x3)
          Loss of sync count: 12 (0xc)
          Loss of signal count: 0 (0x0)
Primitive sequence errors: 0 (0x0)
          Invalid tx words: 17 (0x11)
          Invalid CRC count: 0 (0x0)
```

## msgbuf [all], <number> [-i interval]

This command displays the current driver log, with various options.

### Parameters

- [all] If the [all] parameter is specified, this command displays all of the current driver message log.
- <number> If the <number> parameter is specified, this command displays the last <number> of lines of the current driver message log.
- [-i interval] Using the [-i interval] argument enables the screen to be refreshed every [interval] of seconds. If the [-i interval] argument is not provided, the driver message log is displayed, followed by the "emlxadm>" prompt.

To stop the command from displaying the current driver log, press <Ctrl+c> at the same time.

### Example

In this example, the last 10 lines of the current driver log is displayed.

```
emlxadm> msgbuf 10

155130.01: 1002033:[B.1C35]emlxs0:  DEBUG: 800: ELS sent.  (GA_NXT: did=ffffffc
[00011000,00000000])
155130.02: 1002034:[4.00C9]emlxs0:  DEBUG: 801: ELS comp. (GA_NXT: CT_ACC: Rsn=0 Exp=0
[020113e1,21000020])
155130.02: 1002035:[B.1C35]emlxs0:  DEBUG: 800: ELS sent.  (GA_NXT: did=ffffffc
[000113e1,00000000])
155130.02: 1002036:[4.00C9]emlxs0:  DEBUG: 801: ELS comp. (GA_NXT: CT_ACC: Rsn=0 Exp=0
[020113e2,21000020])
155130.02: 1002037:[B.1C35]emlxs0:  DEBUG: 800: ELS sent.  (GA_NXT: did=ffffffc
[000113e2,00000000])

155130.02: 1002038:[4.00C9]emlxs0:  DEBUG: 801: ELS comp. (GA_NXT: CT_ACC: Rsn=0 Exp=0
[020113e4,21000020])
155130.03: 1002039:[B.1C35]emlxs0:  DEBUG: 800: ELS sent.  (GA_NXT: did=ffffffc
[000113e4,00000000])
155130.03: 1002040:[4.00C9]emlxs0:  DEBUG: 801: ELS comp. (GA_NXT: CT_ACC: Rsn=0 Exp=0
[020113e8,21000020])
155130.03: 1002041:[B.1C35]emlxs0:  DEBUG: 800: ELS sent.  (GA_NXT: did=ffffffc
[000113e8,00000000])

emlxadm>
```

## ns

Performs and returns a complete query of the fabric name server.

### Example

```
emlxadm> ns

Nameserver:
```

```

-----
      TYPE: Lport
      PID: 0113E1
      WWPN: 21000020371938fa
PORT_NAME: (SEAGATE ST39103FC      0004)
      WNNN: 20000020371938fa
NODE_NAME: (null)
      IPA: ffffffffffffffff
      IP_ADDR: 0.0.0.0
      CLASS: Class3
FC4_TYPER: 00000100,00000000,00000000,00000000,00000000,00000000,00000000,00000000
-----
      TYPE: Lport
      PID: 0113E2
      WWPN: 21000020371939a2
PORT_NAME: (SEAGATE ST39103FC      0004)
      WNNN: 20000020371939a2
NODE_NAME: (null)
      IPA: ffffffffffffffff
      IP_ADDR: 0.0.0.0
      CLASS: Class3
FC4_TYPER: 00000100,00000000,00000000,00000000,00000000,00000000,00000000,00000000
-----
      TYPE: Lport
      PID: 0113E4
      WWPN: 21000020371938a3
PORT_NAME: (SEAGATE ST39103FC      0004)
      WNNN: 20000020371938a3
NODE_NAME: (null)
      IPA: ffffffffffffffff
      IP_ADDR: 0.0.0.0
      CLASS: Class3
FC4_TYPER: 00000100,00000000,00000000,00000000,00000000,00000000,00000000,00000000
-----
      TYPE: Lport
      PID: 0113E8
      WWPN: 2100002037193670
PORT_NAME: (SEAGATE ST39103FC      0004)
      WNNN: 2000002037193670
NODE_NAME: (null)
      IPA: ffffffffffffffff
      IP_ADDR: 0.0.0.0
      CLASS: Class3
FC4_TYPER: 00000100,00000000,00000000,00000000,00000000,00000000,00000000,00000000

```

## P

Repeats the last command.

### Example

```
emlxadm> get_num_devs
```

There are 4 devices reported on this port.

```
emlxadm> p
emlxadm> get_num_devs
```

There are 4 devices reported on this port.

## parm\_get\_num

Returns the total number of configurable parameters.

### Example

```
emlxadm> parm_get_num
Result: There are 18 configurable parameters in the driver.
```

## parm\_get <label>

Gets the value of a specified parameter in the driver.

### Example

```
emlxadm> parm_get adisc-support

label: adisc-support
  min: 0
current: 1
  max: 2
default: 1
dynamic: yes
  desc: Sets the Fibre Channel ADISC login support level.
```

## parm\_get\_list

Returns a list of configurable parameters.

### Example

```
emlxadm> parm_get_list

Parameter:
-----
label: console-notices
  min: 0x0
current: 0x0
  max: 0xffffffff
default: 0x0
dynamic: yes
  desc: Verbose mask for notice messages to the console.
```

```
-----  
  label: console-warnings  
    min: 0x0  
current: 0x0  
    max: 0xffffffff  
default: 0x0  
dynamic: yes  
    desc: Verbose mask for warning messages to the console.  
-----  
  label: console-errors  
    min: 0x0  
current: 0x0  
    max: 0xffffffff  
default: 0x0  
dynamic: yes  
    desc: Verbose mask for error messages to the console.  
-----  
  label: log-notice  
    min: 0x0  
current: 0xffffffff  
    max: 0xffffffff  
default: 0xffffffff  
dynamic: yes  
    desc: Verbose mask for notice messages to the messages file.  
-----  
  label: log-warnings  
    min: 0x0  
current: 0xffffffff  
    max: 0xffffffff  
default: 0xffffffff  
dynamic: yes  
    desc: Verbose mask for warning messages to the messages file.  
-----  
  label: log-errors  
    min: 0x0  
current: 0xffffffff  
    max: 0xffffffff  
default: 0xffffffff  
dynamic: yes  
    desc: Verbose mask for error messages to the messages file.  
-----  
  label: num-iocbs  
    min: 128  
current: 1024  
    max: 10240  
default: 1024  
dynamic: no  
    desc: Number of outstanding IOCBs driver can queue to adapter.
```

```
-----  
    label: ub-bufs  
        min: 40  
current: 1000  
        max: 16320  
default: 1000  
dynamic: no  
    desc: Number of unsolicited buffers the driver should allocate.  
-----  
    label: network-on  
        min: 0  
current: 1  
        max: 1  
default: 1  
dynamic: no  
    desc: Enable IP processing.  
-----  
    label: ack0  
        min: 0  
current: 0  
        max: 1  
default: 0  
dynamic: no  
    desc: Enable ACK0 support.  
-----  
    label: topology  
        min: 0  
current: 0  
        max: 6  
default: 0  
dynamic: no  
    desc: Select Fibre Channel topology.  
-----  
    label: link-speed  
        min: 0  
current: 0  
        max: 4  
default: 0  
dynamic: no  
    desc: Select link speed.  
-----  
    label: num-nodes  
        min: 2  
current: 512  
        max: 512  
default: 512  
dynamic: no  
    desc: Number of fibre channel nodes (NPorts) the driver will support.
```

```
-----  
label: cr-delay  
  min: 0  
current: 0  
  max: 63  
default: 0  
dynamic: no  
  desc: A count of milliseconds after which an interrupt response is generated.  
-----  
label: cr-count  
  min: 1  
current: 1  
  max: 255  
default: 1  
dynamic: no  
  desc: A count of I/O completions after which an interrupt response is  
generated.  
-----  
label: assign-alpa  
  min: 0x0  
current: 0x0  
  max: 0xef  
default: 0x0  
dynamic: no  
  desc: Assigns a preferred ALPA to the port. Only used in Loop topology.  
-----  
label: adisc-support  
  min: 0  
current: 1  
  max: 2  
default: 1  
dynamic: yes  
  desc: Sets the Fibre Channel ADISC login support level.  
-----  
label: pm-support  
  min: 0  
current: 1  
  max: 1  
default: 1  
dynamic: no  
  desc: Enables power management support.
```

## **parm\_set <label> <value>**

Sets the value of a specified parameter in the driver. Only dynamic parameters can be set.

**Note:** To make this change permanent, you must edit the `/kernel/drv/emlxs.conf` file.



## Examples

This example sets a dynamic parameter:

```
emlxadm> parm_set adisc-support 2

label: adisc-support
min: 0
current: 2
max: 2
default: 1
dynamic: yes
desc: Sets the Fibre Channel ADISC login support level.
```

This example attempts to set a static parameter (which is not allowed):

```
emlxadm> parm_set network-on 1
emlxadm: EMLX_PARM_SET: Parameter (network-on) is not dynamic and
cannot be changed here.

** To make this change you must edit the /kernel/drv/emlxs.conf or
**
** the /kernel/drv/emlx.conf file(s) and reboot the system.
```

## q

Exits (quits) the utility program.

### Example

```
emlxadm> q
Exiting...
```

## reset\_hard

Forces the adapter to perform a hardware reset.

### Example

```
emlxadm> reset_hard
Done.
```

## reset\_link <[wwpn] or 0>

If the [wwpn] parameter is specified, this command resets the link of the specified FC device on the network. If the specified [wwpn] applies to a remote port, the reset link [wwpn] only works if the remote port is on a public loop. SFS uses the Loop Initialize ELS command to reset the link on a remote port. The LINIT ELS command is valid only if the remote N\_Port is on a public loop.

If "0" (zero) is specified, this command resets the local link.

### Examples

Resets the link of the specified FC device:

```
emlxadm> reset_link 21000020371938fa
Done.
```

Resets the local link:

```
emlxadm> reset_link 0
Done.
```

## set\_sym\_nname <"string">

Sets the symbolic FC node name of the adapter to the string provided.

**Note:** This operation is not supported by the Solaris SFS stack.

### Example

```
emlxadm> set_sym_nname "Emulex Corporation"
ioctl: FCIO_SET_SYM_NNAME: Operation not supported
```

## set\_sym\_pname <"string">

Sets the symbolic FC port name of the adapter to the string provided.

**Note:** This operation is not supported by the Solaris SFS stack.

### Example

```
emlxadm> set_sym_pname "Emulex Corporation"
ioctl: FCIO_SET_SYM_PNAME: Operation not supported
```

## set\_throttle

Temporarily sets the I/O queue <depth> for a specified remote port. The <depth> is the maximum number of concurrent I/Os that the driver can send to the specified remote port. The default queue depth for an FCP target port is specified by the "target-depth" driver parameter.

## Command Options

`set_throttle all <depth>` Sets the <depth> for all ports.  
`set_throttle fcp <depth>` Sets the <depth> for all FCP target ports.  
`set_throttle wwpn <depth>` Sets the <depth> for a specific port.

## Example

This example sets the maximum number of concurrent I/Os to 512 for all remote ports.

```
emlxadm> set_throttle all 512
```

```
_____WWPN: Depth  
21000011c6810947: 512  
21000011c681065f: 512  
21000011c68108c0: 512  
21000011c681061d: 512
```

## 4. Using the emlxdrv Utility

The emlxdrv utility binds (associates) the following FC and NIC drivers to various Emulex FC and NIC adapter models, respectively:

### FC Drivers

- emlxs - Solaris inbox FC/FCoE driver
- elxfc - Emulex-distributed FC/FCoE Solaris driver (does not support Oracle-branded devices)
- lpfc - Legacy Emulex distributed FC SD driver, which does not support Oracle-branded devices. The lpfc driver is available for Solaris 10, but not for Solaris 11.

### NIC Drivers

- elxnic - Emulex-distributed Solaris NIC driver
- oce - Solaris inbox NIC driver

The emlxs and elxfc FC drivers can co-exist on the same host. However, a specific FC adapter model is associated to only one of the FC drivers (emlxs or elxfc) at a time. Likewise, a specific NIC adapter model is associated to only one of the NIC drivers (elxnic or oce) at a time.

### Notes

- The simultaneous use of the lpfc driver and the emlxs or the elxfc driver is not supported. Using the lpfc driver should only be used as a step when migrating complex configurations between drivers.
- If you change the driver binding configuration, the emlxdrv utility requires a system reboot in order for the new configuration to take effect.
- Oracle-branded 16GbFC adapters and the standard models share the same device id; therefore, it is not possible to bind them to two different drivers. Both adapters must be bound to the same driver.
- If an Oracle-branded 16GbFC adapter is detected on the system, the emlxdrv utility will only allow the adapter to bind with the emlxs driver.

The emlxdrv utility program can run in two modes:

- CLI
- Interactive

## Interactive Mode of Operation for emlxdrv

To run the emlxadm utility in interactive mode, type “emlxdrv” without any commands or arguments. For example:

```
# emlxdrv
```

## Displaying Bindings Between Drivers and Adapter Models

The emlxdrv program scans the host system and prepares a driver configuration table consisting of bindings (associations) between the FC and NIC drivers (emlxs, elxfc, lpfc, oce, and elxnic) and a list of Emulex FC and NIC adapter models. After the table is prepared, the utility displays:

- FC driver configuration table
- NIC driver configuration table
- List of available commands
- emlxdrv prompt

For example, after “emlxdrv” is entered, the utility displays the following:

```
FC Driver Alias Pres Boot Oracle emlxs elxfc lpfc Models
elxfc      f100 - - - yes yes yes LPe12000, LPe12002
elxfc      f111 - - - yes yes yes LPe12000, LPe12002
elxfc      f112 - - - yes yes yes LPe12000, LPe12002
elxfc      f0a5 - - - yes yes - 2G Blade Adapter
emxls      fc40 - - yes yes - - LPe12000-S, LPe12002-S
elxfc      714 yes - - yes yes - OCe11101, OCe11102
```

```
NIC Driver Alias Pres Oracle oce elxnic Models
oce         700 - - yes yes OCe11101, OCe11102
elxnic      710 - - yes yes OCe11101, OCe11102
```

### Available Commands

```
set...      - Sets driver bindings to specified devices.
clear...    - Clears driver bindings to specified devices.
refresh...  - Refresh driver bindings to current devices.
q           - Exits this program.
```

emlxdrv>

The definitions of headings for the FC driver configuration table are listed in Table 4-1.

**Table 4-1** FC Driver Configuration Table Heading Descriptions

Heading	Description
Alias	The specific adapter alias associated with a set of Emulex adapter models. Driver bindings can be made only with a specific adapter alias and not with a specific adapter model.

**Table 4-1** FC Driver Configuration Table Heading Descriptions

Heading	Description
Boot	A “yes” indicates that this specific type of adapter is currently providing connectivity to the system’s boot disk.  <b>Note:</b> The emlxdrv utility does not allow you to change the driver binding to an adapter currently providing connectivity to the boot disk. If the driver binding needs to be changed to a boot device, the system must first be configured to boot through an adapter of another type. This procedure is not in the scope of this document.
elxfc	A “yes” indicates the elxfc driver supports this specific type of adapter.
emlxs	A “yes” indicates the emlxs driver supports this specific type of adapter.
FC Driver	The type of FC driver (emlxs, elxfc, lpfc, or “-” for none) that is currently configured to bind or attach to a specific adapter alias.
lpfc	A “yes” indicates the lpfc driver supports this specific type of adapter.
Models	A list of Emulex adapter models that are identified by a common adapter alias. Driver bindings can be made only with a specific adapter alias and not with a specific adapter model.
Oracle	A “yes” indicates that this specific type of adapter is branded and sold directly by Oracle.
Pres	A “yes” indicates that this type of adapter is currently present in the host system. The emlxdrv utility allows you to bind a driver to adapters that are not currently present in the system, but may be present in the future.

The definitions of headings for the NIC driver configuration table are listed in Table 4-2.

**Table 4-2** NIC Driver Configuration Table Heading Descriptions

Heading	Description
Alias	See the “Alias” description in Table 4-1 on page 53.
elxnic	A “yes” indicates the elxnic driver supports this specific type of adapter.
Models	See the “Models” description in Table 4-1 on page 53.
NIC Driver	The type of NIC driver (oce or elxnic) that is currently configured to bind or attach to a specific adapter alias.
oce	A “yes” indicates the oce driver supports this specific type of adapter.
Oracle	See the “Oracle” description in Table 4-1 on page 53.
Pres	See the “Pres” description in Table 4-1 on page 53.

## Entering emlxdrv Commands

After the available commands are listed, the “emlxdrv>” prompt is displayed. From this point, the utility is prompt-driven. When the prompt is displayed, you can enter one of the commands in the list. For example, to refresh the host bindings and main display with the latest information, use the “refresh” command:

```
emlxdrv> refresh
```

The current driver configuration table and the available command list are displayed automatically after each command is issued.

Some commands require a <driver> or <driver\_name> and an <alias> argument. You must specify one of the valid adapter aliases listed in the current driver configuration table. Each alias is shared by multiple adapter models. Driver bindings can be made only with an adapter alias and not with a specific adapter model.

## Exiting emlxdrv

To exit (quit) the emlxdrv utility, type “q” at the prompt:

```
emlxdrv> q
```

## CLI Mode of Operation for emlxdrv

You can run the emlxdrv utility program in CLI mode by typing the name of the program followed by a valid command and any required command arguments. For example:

```
# emlxdrv refresh
```

This mode of operation enables you to use the emlxdrv utility as part of a script or another program capable of running system-level calls.

For example, you can revise the device binding by entering all the information on one line at the operating system prompt as shown below.

```
FC Driver Alias Pres Boot Oracle emlxs elxfc lpfc Models
elxfc      f100 - - - yes yes yes LPe12000, LPe12002
elxfc      f111 - - - yes yes yes LPe12000, LPe12002
elxfc      f112 - - - yes yes yes LPe12000, LPe12002
elxfc      f0a5 - - - yes yes - 2G Blade Adapter
emxls      fc40 - - yes yes - - LPe12000-S, LPe12002-S
elxfc      704 - - - yes yes - OCe11101, OCe11102
elxfc      714 yes - - yes yes - OCe11101, OCe11102
```

```
NIC Driver Alias Pres Oracle oce elxnic Models
oce        700 - - yes yes OCe11101, OCe11102
elxnic     710 - - yes yes OCe11101, OCe11102
```

## Command Descriptions for emlxdrv

**Note:** You can view the list of commands at any time by running the emlxdrv utility in interactive mode (see “Interactive Mode of Operation for emlxdrv” on page 52).

This section provides a list of commands that can be issued with the emlxdrv utility program. Table 4-3 summarizes this command list, including abbreviated descriptions.

**Table 4-3** Summary of emlxdrv Commands

Command	Description	Page
clear...	Clears the bindings from the specified driver(s) to the specified device(s). The clear command has several options:	56
	• clear [driver] all - clears bindings from the specified [driver] to all devices.	57
	• clear dev [alias] - clears bindings from a valid adapter alias to its associated devices.	58
	• clear [driver] emulex - clears bindings from the specified [driver] to all Emulex-branded devices.	58
	• clear [driver] oracle - clears bindings from the specified [driver] to all Oracle-branded devices.	59
	The valid [driver] values are fc, nic, and [driver_name].	
q	Exits (quits) the emlxdrv utility.	59
refresh	Refreshes the host bindings and main display with the latest information.	60
set...	Sets the specific driver (emlxs, elxfc, lpfc, elxnic, or oce) to bind to the specified device(s). The set command has several options:	60
	• set [driver_name] all - sets the [driver_name] to bind to all devices.	60
	• set [driver_name] dev [alias] - sets the [driver_name] to bind to the devices specified by a valid adapter alias.	61
	• set [driver_name] emulex - sets the [driver_name] to bind to all Emulex-branded devices.	62
	• set [driver_name] oracle - sets the [driver_name] to bind to all Oracle-branded devices.	62
	The valid [driver_name] values are emlxs, elxfc, lpfc, elxnic, or oce.	

### clear...

Clears the bindings from the specified driver(s) to the specified device(s). This command has various options as defined in the following subsections.

**Note:** When running a clear command, you may see a “Cannot unload module...” message. This message indicates that you must reboot the system to unbind a driver from that adapter alias. The emlxdrv utility requires a system reboot for the new configuration take effect.



## clear [driver] all

Clears the bindings from the specified [driver] to all devices. The valid [driver] values are fc, nic, and [driver\_name], as defined in the following section.

### Command Options

clear all	Clears bindings from all drivers to all devices. This is the default value for the clear command.
clear fc all	Clears bindings from FC drivers to all devices.
clear nic all	Clears bindings from NIC drivers to all devices.
clear [driver_name] all	Clears bindings from a driver (indicated by its name) to all devices.

### Example

```
emlxadm> clear all

Updating lpfs ...
Cannot unload module: emlxs
Will be unloaded upon reboot.

Updating f800 ...
Cannot unload module: emlxs
Will be unloaded upon reboot.

Updating f900 ...
Cannot unload module: lpfc
Will be unloaded upon reboot.

Updating f980 ...
Cannot unload module: lpfc
Will be unloaded upon reboot.

Updating fa00 ...
Cannot unload module: emlxs
Will be unloaded upon reboot.

Updating fd00 ...
Cannot unload module: emlxs
Will be unloaded upon reboot.

Updating fe00 ...
Cannot unload module: emlxs
Will be unloaded upon reboot.

Done.
```

## clear dev [alias]

Clears the bindings from a valid adapter alias, as listed in one of the driver configuration tables (see the “Alias” column in Table 4-1 on page 53), to its associated devices. Each alias is shared by multiple adapter models.

### Example

```
emlxdrv> clear dev fe00

Updating fe00 ...
Cannot unload module: emlxs
Will be unloaded upon reboot.
Done.
```

## clear [driver] emulex

Clears the bindings from the specified [driver] to all Emulex-branded devices. The valid [driver] values are fc, nic, and [driver\_name], as defined in the following section.

### Command Options

clear emulex	Clears bindings from all drivers to all Emulex-branded devices
clear fc emulex	Clears bindings from FC drivers to all Emulex-branded devices.
clear nic emulex	Clears bindings from all NIC drivers to all Emulex-branded devices.
clear [driver_name] emulex	Clears bindings from a specific driver (indicated by its name) to all Emulex-branded devices.

### Example

```
emlxdrv> clear emulex

Cannot unload module: emlxs
Will be unloaded upon reboot.

Updating fc00 ...
Cannot unload module: emlxs
Will be unloaded upon reboot.

Updating fc10 ...
Cannot unload module: emlxs
Will be unloaded upon reboot.

Updating fc20 ...
Cannot unload module: emlxs
Will be unloaded upon reboot.

Done.
```

## clear [driver] oracle

Clears bindings from the specified [driver] to all Oracle-branded devices. The valid [driver] values are fc, nic, and [driver\_name], as defined in “set...” on page 60.

### Command Options

clear oracle	Clears bindings to all Oracle-branded devices for all drivers.
clear fc oracle	Clears bindings to all Oracle-branded devices for FC drivers.
clear nic oracle	Clears bindings to all Oracle-branded devices for NIC drivers
clear [driver_name] oracle	Clears bindings to all Oracle-branded devices for a specific driver.

### Example

```
emlxdrv> clear oracle

Updating fc00 ...
Cannot unload module: emlxs
Will be unloaded upon reboot.

Updating fc10 ...
Cannot unload module: emlxs
Will be unloaded upon reboot.

Updating fc20 ...
Cannot unload module: emlxs
Will be unloaded upon reboot.

Done.
```

## q

Exits (quits) the emlxdrv utility.

**Note:** If changes were made to the driver bindings, a system reboot is required for the changes to take effect. If NIC changes were made, a system reboot is also required.

### Example

```
emlxdrv> q

Exiting...
```

NOTE: If changes were made, then a system reboot may be required.

## refresh

Refreshes the host bindings and main display with the latest information.

### Example

```
emlxdrv> refresh
```

The following example output is displayed:

FC Driver	Alias	Pres	Boot	Oracle	emlxs	elxfc	lpfc	Models
elxfc	f100	-	-	-	yes	yes	yes	LPe12000, LPe12002
elxfc	f111	-	-	-	yes	yes	yes	LPe12000, LPe12002
elxfc	f112	-	-	-	yes	yes	yes	LPe12000, LPe12002
elxfc	f0a5	-	-	-	yes	yes	-	2G Blade Adapter
emxls	fc40	-	-	yes	yes	-	-	LPe12000-S, LPe12002-S
elxfc	704	-	-	-	yes	yes	-	OCe11101, OCe11102
elxfc	714	yes	-	-	yes	yes	-	OCe11101, OCe11102

NIC Driver	Alias	Pres	Oracle	oce	elxnic	Models
oce	700	-	-	yes	yes	OCe11101, OCe11102
elxnic	710	-	-	yes	yes	OCe11101, OCe11102

#### Available Commands

```
set...      - Sets driver bindings to specified devices.
clear...    - Clears driver bindings to specified devices.
refresh...  - Refresh driver bindings to current devices.
q           - Exits this program.
```

## set...

This command sets the bindings from the specified driver (emlxs, elxfc, lpfc, elxnic, or oce) to the specified device(s). This command has various options as defined in the following subsections.

**Note:** When running a “set...” command, you may see a “Cannot unload module...” message. This message indicates that you must reboot the system to unbind a driver from that adapter alias. The emlxdrv utility requires a system reboot for the new configuration take effect.

### set [driver\_name] all

Sets the specified [driver\_name] to bind to all devices. The valid [driver\_name] values are emlxs, elxfc, lpfc, elxnic, or oce.

### Example

```
emlxdrv> set emlxs all
```

```
Updating lpfs ...
Updating f800 ...
Updating f900 ...
Cannot unload module: lpfc
Will be unloaded upon reboot.
```

```
Updating f980 ...
Cannot unload module: lpfc
Will be unloaded upon reboot.
```

```
Updating fa00 ...
Updating fd00 ...
Updating fe00 ...
Updating fc00 ...
Updating fc10 ...
Updating fc20 ...
Done.
```

### **set [driver\_name] [alias]**

Sets the specified [driver\_name] to bind to the devices specified by a valid adapter alias (as listed in one of the driver configuration tables (see the “Alias” column in Table 4-1 on page 53). Note that each alias is shared by multiple adapter models. Driver bindings can be made only with an adapter alias and not with a specific adapter model. The valid [driver\_name] values are emlxs, elxfc, lpfc, elxnic, or oce.

### **Example**

```
emlxdrv> set emlxs f980

Updating f980 ...
Cannot unload module: lpfc
Will be unloaded upon reboot.

Done.
```

## set [driver\_name] emulex

Sets the specific [driver\_name] to bind to all Emulex-branded devices. The valid [driver\_name] values are emlxs, elxfc, lpfc, elxnic, or oce.

### Example

```
emlxdrv> set lpfc fa00
```

```
Updating fa00 ...  
Cannot unload module: emlxs  
Will be unloaded upon reboot.  
Done.
```

## set [driver\_name] oracle

Sets the specific [driver\_name] to bind to all Oracle-branded devices. The valid [driver\_name] values are emlxs, elxfc, lpfc, elxnic, or oce.

### Example

```
emlxdrv> set emlxs oracle
```

```
Updating fc00 ...  
Updating fc10 ...  
Updating fc20 ...  
Done.
```