


**TOSHIBA**

FILE NO. 050-200511  
(MFR'S VERSION A)

**SERVICE MANUAL**

**COLOR TELEVISION**

**27AF45**  
**27AF45C**



# SERVICING NOTICES ON CHECKING

## 1. KEEP THE NOTICES

As for the places which need special attentions, they are indicated with the labels or seals on the cabinet, chassis and parts. Make sure to keep the indications and notices in the operation manual.

## 2. AVOID AN ELECTRIC SHOCK

There is a high voltage part inside. Avoid an electric shock while the electric current is flowing.

## 3. USE THE DESIGNATED PARTS

The parts in this equipment have the specific characters of incombustibility and withstand voltage for safety. Therefore, the part which is replaced should be used the part which has the same character.

Especially as to the important parts for safety which is indicated in the circuit diagram or the table of parts as a  mark, the designated parts must be used.

## 4. PUT PARTS AND WIRES IN THE ORIGINAL POSITION AFTER ASSEMBLING OR WIRING

There are parts which use the insulation material such as a tube or tape for safety, or which are assembled in the condition that these do not contact with the printed board. The inside wiring is designed not to get closer to the pyrogenic parts and high voltage parts. Therefore, put these parts in the original positions.

## 5. TAKE CARE TO DEAL WITH THE CATHODE-RAY TUBE

In the condition that an explosion-proof cathode-ray tube is set in this equipment, safety is secured against implosion. However, when removing it or serving from backward, it is dangerous to give a shock. Take enough care to deal with it.

## 6. AVOID AN X-RAY

Safety is secured against an X-ray by considering about the cathode-ray tube and the high voltage peripheral circuit, etc.

Therefore, when repairing the high voltage peripheral circuit, use the designated parts and make sure not modify the circuit.

Repairing except indicates causes rising of high voltage, and it emits an X-ray from the cathode-ray tube.

## 7. PERFORM A SAFETY CHECK AFTER SERVICING

Confirm that the screws, parts and wiring which were removed in order to service are put in the original positions, or whether there are the portions which are deteriorated around the serviced places serviced or not. Check the insulation between the antenna terminal or external metal and the AC cord plug blades. And be sure the safety of that.

### (INSULATION CHECK PROCEDURE)

1. Unplug the plug from the AC outlet.
2. Remove the antenna terminal on TV and turn on the TV.
3. Insulation resistance between the cord plug terminals and the eternal exposure metal [Note 2] should be more than 1M ohm by using the 500V insulation resistance meter [Note 1].
4. If the insulation resistance is less than 1M ohm, the inspection repair should be required.

### [Note 1]

If you have not the 500V insulation resistance meter, use a Tester.

### [Note 2]

External exposure metal: Antenna terminal  
Headphone jack

## HOW TO ORDER PARTS

Please include the following informations when you order parts. (Particularly the VERSION LETTER.)

### 1. MODEL NUMBER and VERSION LETTER

The MODEL NUMBER can be found on the back of each product and the VERSION LETTER can be found at the end of the SERIAL NUMBER.

### 2. PART NO. and DESCRIPTION

You can find it in your SERVICE MANUAL.

## IMPORTANT

When you exchange IC and Transistor with a heat sink, apply silicon grease on the contact section of the heat sink. Before applying new silicon grease, remove all the old silicon grease. (Old grease may cause damages to the IC and Transistor.)




Licensed by BBE Sound, Inc. under USP5510752 and 5736897.  
BBE and BBE symbol are registered trademarks of BBE Sound, Inc.

## **ABOUT LEAD FREE SOLDER (PbF)**

### **Distinction of PbF PCB:**

PCBs (manufactured) using lead free solder will have a PbF printing on the PCB.  
(Please refer to figures.)



### **Caution:**

- Pb free solder has a higher melting point than standard solder;  
Typically the melting point is 50°F~70°F(30°C~40°C) higher.  
Please use a soldering iron with temperature control and adjust it to 650°F ± 20°F (350°C ± 10°C).  
In case of using high temperature soldering iron, please be carefull not to heat too long.
- Pb free solder will tend to splash when heated too high (about 1100°F/ 600°C).
- All products with the printed circuit board with PbF printing must be serviced with lead free solder.  
When soldering or unsoldering, completely remove all of the solder from the pins or solder area,  
and be sure to heat the soldering points with the lead free solder until it melts sufficiently.

### **Recommendations**

Recommended lead free solder composition is Sn-3.0Ag-0.5Cu.

# TABLE OF CONTENTS

<b>SERVICING NOTICES ON CHECKING .....</b>	A1-1
<b>HOW TO ORDER PARTS .....</b>	A1-1
<b>IMPORTANT .....</b>	A1-1
<b>ABOUT LEAD FREE SOLDER (PbF).....</b>	A1-2
<b>TABLE OF CONTENTS .....</b>	A2-1
<b>GENERAL SPECIFICATIONS .....</b>	A3-1~A3-10
<b>DISASSEMBLY INSTRUCTIONS</b>	
1. REMOVAL OF ANODE CAP .....	B1-1
2. REMOVAL AND INSTALLATION OF FLAT PACKAGE IC .....	B2-1, B2-2
<b>SERVICE MODE LIST .....</b>	C-1
<b>CONFIRMATION OF HOURS USED .....</b>	C-1
<b>WHEN REPLACING EEPROM (MEMORY) IC .....</b>	C-1
<b>ELECTRICAL ADJUSTMENTS .....</b>	D-1~D-6
<b>BLOCK DIAGRAMS .....</b>	E-1, E-2
<b>PRINTED CIRCUIT BOARDS</b>	
MAIN .....	F-1~F-4
CRT/VM COIL/POWER .....	F-5, F-6
<b>SCHEMATIC DIAGRAMS</b>	
MICON .....	G-1, G-2
CHROMA .....	G-3, G-4
DEFLECTION .....	G-5, G-6
POWER .....	G-7, G-8
SOUND .....	G-9, G-10
TUNER/STEREO .....	G-11, G-12
AV .....	G-13, G-14
COMB FILTER .....	G-15, G-16
CRT/SVM .....	G-17, G-18
SUB POWER .....	G-19, G-20
<b>WAVEFORMS .....</b>	H-1, H-2
<b>MECHANICAL EXPLODED VIEWS .....</b>	I-1, I-2
<b>MECHANICAL REPLACEMENT PARTS LIST .....</b>	J1-1, J1-2
<b>ELECTRICAL REPLACEMENT PARTS LIST .....</b>	J2-1~J2-10

# GENERAL SPECIFICATIONS

G-1	TV System	CRT	CRT Size / Visual Size	27 inch / 676.0mmV
		CRT Type	Flat	
		Deflection	106 degree	
		Magnetic Field	BV/BH	+0.45G/0.18G
		Color System	NTSC	
		Speaker	2 Speaker	
		Position	Front Side	
		Size	1.8 x 3.9 Inch	
		Impedance	8 ohm	
		Sound Output	MAX 10%(Typical)	5.0+5.0 W 4.0+4.0 W
NTSC3.58+4.43 /PAL60Hz		No		
G-2	Tuning System	Broadcasting System	US System M	
		Tuner and Receive CH	System Destination	1Tuner USA(W/ CATV)
			Tuning System	F-Synth
			Input Impedance	VHF/UHF 75 ohm
			CH Coverage	2 - 69, 4A, A-5 - A-1, A - I, J - W, W+1 - W+84
		Intermediate Frequency	Picture(FP) Sound(FS) FP-FS	45.75MHz 41.25MHz 4.50MHz
		Preset CH	No	
		Stereo/Dual TV Sound	Yes	
		Tuner Sound Muting	Yes	
		Power Source	AC DC	120V AC 60Hz
G-3	Power	Power Consumption	at AC	
			Stand by (at AC)	135 W at AC 120 V 60 Hz
			Per Year	3 W at AC 120 V 60 Hz
		Protector	Power Fuse Safety Circuit IC Protector(Micro Fuse)	-- kWh/Year Yes Yes No
G-4	Regulation	Safety Radiation X-Radiation	UL FCC DHHS	
G-5	Temperature	Operation Storage	+50C ~ +40oC -20oC ~ +60oC	
G-6	Operating Humidity	Less than 80% RH		

# GENERAL SPECIFICATIONS

G-7	On Screen Display	Menu	Yes
			Icon
		Picture	Yes
		Contrast	Yes
		Brightness	Yes
		Color	Yes
		Tint	Yes
		Sharpness	Yes
		Sound	Yes
		Bass	Yes
		Treble	Yes
		Balance	Yes
		BBE On/Off	Yes
		Stable Sound On/Off	Yes
		Surround On/Off	Yes
		Set Up	Yes
		TV/CATV	Yes
		Auto CH Memory	Yes
		Add/ Delete	Yes
		Option	Yes
		Language	Yes
		CH Label	Yes
		Favorite CH	Yes
		V-Chip	Yes
		Lock	Yes
		On/Off Timer	Yes
		Color Stream DVD/DTV	Yes
		Control Level	Yes
		Volume	Yes
		Brightness	Yes
		Contrast	Yes
		Color	Yes
		Tint	Yes
		Sharpness	Yes
		Tuning	No
		Bass	Yes
		Treble	Yes
		Balance	Yes
		Back Light	No
		Stereo, Audio Output, SAP	Yes
		Video	Yes
		Color Stream	Yes
		Channel(TV/Cable)	Yes
		CH Label	Yes
		Game Timer	Yes
		Sleep Timer	Yes
		Sound Mute	Yes
		V-chip Rating	Yes
		16: 9	Yes
G-8	OSD Language		English French Spanish
G-9	Clock and Timer	Sleep Timer	Max Time Step
			120 Min 10 Min
		On/Off Timer	Program(On Timer / Off Timer)
		Wake Up Timer	No
		Timer Back-up (at Power Off Mode)	more than -- Min Sec

## GENERAL SPECIFICATIONS

G-10	Remote Control	Unit	RC-GW
		Glow in Dark Remocon	Yes
		Format	Toshiba
		Custom Code	TV:40-BF h
		Power Source	Voltage(D.C) UM size x pcs
		Total Keys	3V UM-4 x 2 pcs <u>50 Keys</u>
		Keys	Power 1 2 3 4 5 6 7 8 9 0 100 CH Up CH Down Volume Up Volume Down TV/Caption/Text CH1/CH2 TV/Video(TV/AV) CH RTN/CH ENT(Quick View) Sleep RE Call(Call) Reset Menu/Enter Mute Exit MTS(Audio Select) Fav.Up Fav.Down 16: 9
		Multi Brand Keys	CH Up(VCR) CH Down(VCR) Pause/Still TV/VCR(VCR) FF Rew Rec Play Stop TV VCR Cable DVD CODE Volume Up(DVD) Volume Down(DVD) DVD CLEAR TOP MENU DVD MENU DISPLAY

# GENERAL SPECIFICATIONS

G-11	Features	Auto Degauss	Yes
		Auto Shut Off	Yes
		Canal+	No
		CATV	Yes
		Anti-theft	No
		Rental	No
		Memory(Last CH)	Yes
		Memory(Last Volume)	Yes
		V-Chip	Yes
		Type	<u>USA,Toshiba Type</u>
		BBE	Yes
		Auto Search	No
		CH Allocation	No
		SAP	Yes
		Just Clock Function	No
		CH Label	Yes
		VM Circuit	Yes
		Full OSD	No
		Premiere	No
		Comb Filter	Yes <u>3 Lines</u>
		Auto CH Memory	Yes
		Hotel Lock	No
		Closed Caption	Yes
		Stable Sound	Yes
		FBT Leak Test Protect	Yes
		CH Lock	Yes
		Video Lock	Yes
		Game Timer (Max Time:120 Min)	Yes
		Energy Star	No
		Favorite CH	Yes
		Surround	Yes
		16:9 Mode	Yes
G-12	Accessories	Owner's Manual	Language W/ Warranty
			English/Spanish Yes
		Remote Control Unit	Yes
		Rod Antenna	No
		Poles	
		Terminal	
		Loop Antenna	No
		Terminal	-
		U/V Mixer	No
		DC Car Cord (Center+)	No
		Guarantee Card	No
		Warning Sheet	No
		Circuit Diagram	No
		Antenna Change Plug	No
		Service Station List	No
		Important Safety Instruction	No
		Dew/AHC Caution Sheet	No
		AC Plug Adapter	No
		Quick Set-up Sheet	No
		Battery	Yes UM-4 x 2
		UM size x pcs	
		OEM Brand	No
		AC Cord	No
		AV Cord (2Pin-1Pin)	No
		Registration Card (NDL Card)	Yes
		PTB Sheet	No
		ESP Card	No
		300 ohm to 75 ohm Antenna Adapter	No

# GENERAL SPECIFICATIONS

G-13	Interface	Switch	Front	Power	Yes
				System Select	No
				Main Power SW	No
				Sub Power	No
				Channel Up	Yes
				Channel Down	Yes
				Volume Up	Yes
				Volume Down	Yes
			Rear	AC/DC	No
				TV/CATV Selector	No
				Degauss	No
				Main Power SW	No
			Indicator	Power	Yes(RED)
				Stand-by	No
				On Timer	No
			Terminals	Front	Video Input = VIDEO3
					RCA
					RCA x 2
				Rear	Other Terminal
					Head Phone
					Video Input(Rear1) = VIDEO1
					RCA
					Video Input(Rear2) = VIDEO2
					RCA
					Audio Input(Rear1) = VIDEO1
					RCA x 2
					Audio Input(Rear2) = VIDEO2
					RCA x 2
					Video Output
					RCA
					Audio Output
					RCA x 2
					Euro Scart
					No
					Color Stream
					RCA x 3
					S Input
					Yes
					Diversity
					No
					Ext Speaker
					No
					DC Jack 12V(Center +)
					No
					VHF/UHF Antenna Input
					F Type
					AC Outlet
					No
G-14	Set Size	Approx.	W x D x H (mm)	<u>740 x 495 x 574.5</u>	
G-15	Weight	Net (Approx.)		<u>40.0 kg ( 88.2lbs)</u>	
		Gross (Approx.)		<u>46.5 kg (102.5lbs)</u>	
G-16	Carton	Master Carton	Content	No	
			Material	---- Sets	
			Dimensions W x D x H(mm)	<u>-- x -- x --</u>	
			Description of Origin	No	
			Gift Box	Yes	
			Material	Double/Brown	
			Dimensions W x D x H(mm)	<u>850 x 620 x 665</u>	
			Design	As per Buyer's	
			Description of Origin	Yes	
			Drop Test	Natural Dropping At 1 Corner / 2 Edges / 4 Surfaces	
			Height (cm)	<u>40 (ORION SPEC:25)</u>	
			Container Stuffing	<u>156 Sets/40' container</u>	
G-17	Cabinet Material	Cabinet	Cabinet Front	PS 94V0 DE CABROM	
			Cabinet Rear	PS 94V0 DE CABROM	
		PCB	Non-Halogen Demand	No	
			Eyelet Demand	Yes	
G-18	Environment	Pb-free Soldering		Yes	
		Parts Specification(Phase3 : based on RoHS)		Yes	

## GENERAL SPECIFICATIONS

G-1	TV System	CRT	CRT Size / Visual Size	27 inch / 676.0mmV
		CRT Type	Flat	
		Deflection	106 degree	
		Magnetic Field	BV/BH	+0.45G/0.18G
		Color System	NTSC	
		Speaker	2 Speaker	
		Position	Front Side	
		Size	1.8 x 3.9 Inch	
		Impedance	8 ohm	
		Sound Output	MAX 10%(Typical)	5.0+5.0 W 4.0+4.0 W
NTSC3.58+4.43 /PAL60Hz				No
G-2	Tuning System	Broadcasting System	US System M	
		Tuner and Receive CH	System Destination	1Tuner USA(W/ CATV)
			Tuning System	F-Synth
			Input Impedance	VHF/UHF 75 ohm
			CH Coverage	2 - 69, 4A, A-5 - A-1, A - I, J - W, W+1 - W+84
		Intermediate Frequency	Picture(FP) Sound(FS) FP-FS	45.75MHz 41.25MHz 4.50MHz
		Preset CH		No
		Stereo/Dual TV Sound		Yes
		Tuner Sound Muting		Yes
G-3	Power	Power Source	AC DC	120V AC 60Hz
		Power Consumption	at AC  Stand by (at AC) Per Year	<u>135 W at AC 120 V 60 Hz</u> <u>3 W at AC 120 V 60 Hz</u> <u>-- kWh/Year</u>
		Protector		Yes Yes No
		Safety Radiation X-Radiation		CSA IC HWC
G-4	Regulation			
G-5	Temperature	Operation Storage		+50C ~ +40oC -20oC ~ +60oC
G-6	Operating Humidity			Less than 80% RH

## GENERAL SPECIFICATIONS

G-7	On Screen Display	Menu	Yes
			Icon
		Picture	Yes
		Contrast	Yes
		Brightness	Yes
		Color	Yes
		Tint	Yes
		Sharpness	Yes
		Sound	Yes
		Bass	Yes
		Treble	Yes
		Balance	Yes
		BBE On/Off	Yes
		Stable Sound On/Off	Yes
		Surround On/Off	Yes
		Set Up	Yes
		TV/CATV	Yes
		Auto CH Memory	Yes
		Add/ Delete	Yes
		Option	Yes
		Language	Yes
		CH Label	Yes
		Favorite CH	Yes
		V-Chip	No
		Lock	Yes
		On/Off Timer	Yes
		Color Stream DVD/DTV	Yes
		Control Level	Yes
		Volume	Yes
		Brightness	Yes
		Contrast	Yes
		Color	Yes
		Tint	Yes
		Sharpness	Yes
		Tuning	No
		Bass	Yes
		Treble	Yes
		Balance	Yes
		Back Light	No
		Stereo, Audio Output, SAP	Yes
		Video	Yes
		Color Stream	Yes
		Channel(TV/Cable)	Yes
		CH Label	Yes
		Game Timer	Yes
		Sleep Timer	Yes
		Sound Mute	Yes
		V-chip Rating	No
		16:9	Yes
G-8	OSD Language		English French Spanish
G-9	Clock and Timer	Sleep Timer	Max Time Step
			120 Min 10 Min
		On/Off Timer	Program(On Timer / Off Timer)
		Wake Up Timer	No
		Timer Back-up (at Power Off Mode)	more than -- Min Sec

## GENERAL SPECIFICATIONS

G-10	Remote Control	Unit	RC-GW
		Glow in Dark Remocon	Yes
		Format	Toshiba
		Custom Code	TV:40-BF h
		Power Source	Voltage(D.C) UM size x pcs
		Total Keys	3V UM-4 x 2 pcs <u>50 Keys</u>
		Keys	Power 1 2 3 4 5 6 7 8 9 0 100 CH Up CH Down Volume Up Volume Down TV/Caption/Text CH1/CH2 TV/Video(TV/AV) CH RTN/CH ENT(Quick View) Sleep RE Call(Call) Reset Menu/Enter Mute Exit MTS(Audio Select) Fav.Up Fav.Down 16: 9
		Multi Brand Keys	CH Up(VCR) CH Down(VCR) Pause/Still TV/VCR(VCR) FF Rew Rec Play Stop TV VCR Cable DVD CODE Volume Up(DVD) Volume Down(DVD) DVD CLEAR TOP MENU DVD MENU DISPLAY

# GENERAL SPECIFICATIONS

G-11	Features	Auto Degauss	Yes
		Auto Shut Off	Yes
		Canal+	No
		CATV	Yes
		Anti-theft	No
		Rental	No
		Memory(Last CH)	Yes
		Memory(Last Volume)	Yes
		V-Chip	No
		Type	
		BBE	Yes
		Auto Search	No
		CH Allocation	No
		SAP	Yes
		Just Clock Function	No
		CH Label	Yes
		VM Circuit	Yes
		Full OSD	No
		Premiere	No
		Comb Filter	Yes <u>3 Lines</u>
		Auto CH Memory	Yes
		Hotel Lock	No
		Closed Caption	Yes
		Stable Sound	Yes
		FBT Leak Test Protect	Yes
		CH Lock	Yes
		Video Lock	Yes
		Game Timer (Max Time:120 Min)	Yes
		Energy Star	No
		Favorite CH	Yes
		Surround	Yes
		16:9 Mode	Yes
G-12	Accessories	Owner's Manual	Language W/ Warranty
			English / French Yes
		Remote Control Unit	Yes
		Rod Antenna	No
		Poles	
		Terminal	
		Loop Antenna	No
		Terminal	-
		U/V Mixer	No
		DC Car Cord (Center+)	No
		Guarantee Card	No
		Warning Sheet	No
		Circuit Diagram	No
		Antenna Change Plug	No
		Service Station List	No
		Important Safety Instruction	No
		Dew/AHC Caution Sheet	No
		AC Plug Adapter	No
		Quick Set-up Sheet	No
		Battery	Yes UM-4 x 2
		UM size x pcs	
		OEM Brand	No
		AC Cord	No
		AV Cord (2Pin-1Pin)	No
		Registration Card (NDL Card)	No
		PTB Sheet	No
		ESP Card	No
		300 ohm to 75 ohm Antenna Adapter	No

# GENERAL SPECIFICATIONS

G-13	Interface	Switch	Front	Power	Yes
				System Select	No
				Main Power SW	No
				Sub Power	No
				Channel Up	Yes
				Channel Down	Yes
				Volume Up	Yes
				Volume Down	Yes
			Rear	AC/DC	No
				TV/CATV Selector	No
				Degauss	No
				Main Power SW	No
			Indicator	Power	Yes(RED)
				Stand-by	No
				On Timer	No
			Terminals	Front	Video Input = VIDEO3
					RCA
					RCA x 2
				Rear	Other Terminal
					Head Phone
					Video Input(Rear1) = VIDEO1
					RCA
					Video Input(Rear2) = VIDEO2
					RCA
					Audio Input(Rear1) = VIDEO1
					RCA x 2
					Audio Input(Rear2) = VIDEO2
					RCA x 2
					Video Output
					RCA
					Audio Output
					RCA x 2
					Euro Scart
					No
					Color Stream
					RCA x 3
					S Input
					Yes
					Diversity
					No
					Ext Speaker
					No
					DC Jack 12V(Center +)
					No
					VHF/UHF Antenna Input
					F Type
					AC Outlet
					No
G-14	Set Size	Approx.	W x D x H (mm)	<u>740 x 495 x 574.5</u>	
G-15	Weight	Net (Approx.)		<u>40.0 kg ( 88.2lbs)</u>	
		Gross (Approx.)		<u>46.5 kg (102.5lbs)</u>	
G-16	Carton	Master Carton	Content	No	
			Material	---- Sets	
			Dimensions W x D x H(mm)	<u>-- x -- x --</u>	
			Description of Origin	No	
			Gift Box	Yes	
			Material	Double/Brown	
			Dimensions W x D x H(mm)	<u>850 x 620 x 665</u>	
			Design	As per Buyer's	
			Description of Origin	Yes	
			Drop Test	Natural Dropping At 1 Corner / 2 Edges / 4 Surfaces	
			Height (cm)	<u>40 (ORION SPEC:25)</u>	
			Container Stuffing	<u>156 Sets/40' container</u>	
G-17	Cabinet Material	Cabinet	Cabinet Front	PS 94V0 DE CABROM	
			Cabinet Rear	PS 94V0 DE CABROM	
		PCB	Non-Halogen Demand	No	
			Eyelet Demand	Yes	
G-18	Environment	Pb-free Soldering		Yes	
		Parts Specification(Phase3 : based on RoHS)		Yes	

# DISASSEMBLY INSTRUCTIONS

## 1. REMOVAL OF ANODE CAP

Read the following **NOTED** items before starting work.

- \* After turning the power off there might still be a potential voltage that is very dangerous. When removing the Anode Cap, make sure to discharge the Anode Cap's potential voltage.
- \* Do not use pliers to loosen or tighten the Anode Cap terminal, this may cause the spring to be damaged.

### REMOVAL

1. Follow the steps as follows to discharge the Anode Cap. **(Refer to Fig. 1-1.)**

Connect one end of an Alligator Clip to the metal part of a flat-blade screwdriver and the other end to ground. While holding the plastic part of the insulated Screwdriver, touch the support of the Anode with the tip of the Screwdriver.

A cracking noise will be heard as the voltage is discharged.




Fig. 1-1

2. Flip up the sides of the Rubber Cap in the direction of the arrow and remove one side of the support. **(Refer to Fig. 1-2.)**




Fig. 1-2

3. After one side is removed, pull in the opposite direction to remove the other.

### NOTE

Take care not to damage the Rubber Cap.

### INSTALLATION

1. Clean the spot where the cap was located with a small amount of alcohol. **(Refer to Fig. 1-3.)**




Fig. 1-3

### NOTE

Confirm that there is no dirt, dust, etc. at the spot where the cap was located.

2. Arrange the wire of the Anode Cap and make sure the wire is not twisted.
3. Turn over the Rubber Cap. **(Refer to Fig. 1-4.)**




Fig. 1-4

4. Insert one end of the Anode Support into the anode button, then the other as shown in **Fig. 1-5.**




Fig. 1-5

5. Confirm that the Support is securely connected.
6. Put on the Rubber Cap without moving any parts.

# DISASSEMBLY INSTRUCTIONS


## 2. REMOVAL AND INSTALLATION OF FLAT PACKAGE IC

### REMOVAL

1. Put Masking Tape (cotton tape) around the Flat Package IC to protect other parts from any damage. (Refer to Fig. 2-1.)

#### NOTE


Masking is carried out on all the parts located within 10 mm distance from IC leads.



2. Heat the IC leads using a blower type IC desoldering machine. (Refer to Fig. 2-2.)

#### NOTE


Do not rotate or move the IC back and forth , until IC can move back and forth easily after desoldering the leads completely.



3. When IC starts moving back and forth easily after desoldering completely, pickup the corner of the IC using a tweezers and remove the IC by moving with the IC desoldering machine. (Refer to Fig. 2-3.)

#### NOTE


Some ICs on the PCB are affixed with glue, so be careful not to break or damage the foil of each IC leads or solder lands under the IC when removing it.



4. Peel off the Masking Tape.
5. Absorb the solder left on the pattern using the Braided Shield Wire. (Refer to Fig. 2-4.)

#### NOTE


Do not move the Braided Shield Wire in the vertical direction towards the IC pattern.




# DISASSEMBLY INSTRUCTIONS

## INSTALLATION

1. Take care of the polarity of new IC and then install the new IC fitting on the printed circuit pattern. Then solder each lead on the diagonal positions of IC temporarily.  
**(Refer to Fig. 2-5.)**




2. Supply the solder from the upper position of IC leads sliding to the lower position of the IC leads.  
**(Refer to Fig. 2-6.)**




3. Absorb the solder left on the lead using the Braided Shield Wire. **(Refer to Fig. 2-7.)**

### NOTE

Do not absorb the solder to excess.



4. When bridge-soldering between terminals and/or the soldering amount are not enough, resolder using a Thin-tip Soldering Iron. **(Refer to Fig. 2-8.)**



5. Finally, confirm the soldering status on four sides of the IC using a magnifying glass. Confirm that no abnormality is found on the soldering position and installation position of the parts around the IC. If some abnormality is found, correct by resoldering.

### NOTE

When the IC leads are bent during soldering and/or repairing, do not repair the bending of leads. If the bending of leads are repaired, the pattern may be damaged. So, always be sure to replace the IC in this case.

## SERVICE MODE LIST

This unit is provided with the following SERVICE MODES so you can repair, examine and adjust easily.  
To enter to the Service Mode, press both set key and remote control key for more than 2 seconds.


Set Key	Remocon Key	Operations
VOL. (-) MIN	0	Releasing of V-CHIP PASSWORD and LOCK PASSWORD.
VOL. (-) MIN	1	Initialization of factory data. NOTE: Do not use this for normal servicing. If you set factory initialization, the memories are reset such as the channel setting, and the POWER ON total hours.
VOL. (-) MIN	6	POWER ON total hours is displayed on the screen. Refer to the "CONFIRMATION OF HOURS USED". Can be checked of the INITIAL DATA of MEMORY IC. Refer to the "WHEN REPLACING EEPROM (MEMORY) IC".
VOL. (-) MIN	9	Display of the Adjustment MENU on the screen. Refer to the "ELECTRICAL ADJUSTMENT" (On-Screen Display Adjustment).

## CONFIRMATION OF HOURS USED

POWER ON total hours can be checked on the screen. Total hours are displayed in 16 system of notation.

**NOTE: If you set factory initialization, the total hours is reset to "0".**

1. Set the VOLUME to minimum.
2. Press both VOL. DOWN button on the set and Channel button **(6)** on the remote control for more than 2 seconds.
3. After the confirmation of using hours, turn off the power.



## WHEN REPLACING EEPROM (MEMORY) IC

If a service repair is undertaken where it has been required to change the MEMORY IC, the following steps should be taken to ensure correct data settings while making reference to TABLE 1.

**NOTE:** No need to set data for after positionINI 1F due to the adjustment value.

INI	+0	+1	+2	+3	+4	+5	+6	+7	+8	+9	+A	+B	+C	+D	+E	+F
00	50	E8	0A	44	5E	B3	24	B7	*1	AC	0B	04	80	80	80	59
10	70	00	00	00	03	00	06	60	3F	0F	0D	E2	A8	21	42	00

*1	INI	USA	CANADA
	08	3D	3C

**Table 1**

1. Enter DATA SET mode by setting VOLUME to minimum.
  2. Press both VOL. DOWN button on the set and Channel button **(6)** on the remote control for more than 2 seconds. ADDRESS and DATA should appear as FIG 1.
  3. ADDRESS is now selected and should "blink". Using the VOL. UP/DOWN button on the remote, step through the ADDRESS until required ADDRESS to be changed is reached.
  4. Press ENTER to select DATA. When DATA is selected, it will "blink".
  5. Again, step through the DATA using VOL. UP/DOWN button until required DATA value has been selected.
  6. Pressing ENTER will take you back to ADDRESS for further selection if necessary.
  7. Repeat steps 3 to 6 until all data has been checked.
  8. When satisfied correct DATA has been entered, turn POWER off (return to STANDBY MODE) to finish DATA input.  
**After the data input, set to the initializing of shipping.**
  9. Turn POWER on.
  10. Press both VOL. DOWN button on the set and Channel button **(1)** on the remote control for more than 2 seconds.
  11. After the finishing of the initializing of shipping, the unit will turn off automatically.
- The unit will now have the correct DATA for the new MEMORY IC.

# ELECTRICAL ADJUSTMENTS

## 1. ADJUSTMENT PROCEDURE

Read and perform these adjustments when repairing the circuits or replacing electrical parts or PCB assemblies.

### CAUTION

- Use an isolation transformer when performing any service on this chassis.
- Before removing the anode cap, discharge electricity because it contains high voltage.
- When removing a PCB or related component, after unfastening or changing a wire, be sure to put the wire back in its original position.
- When you exchange IC and Transistor with a heat sink, apply silicon grease on the contact section of the heat sink. Before applying new silicon grease, remove all the old silicon grease. (Old grease may cause damages to the IC and Transistor.)

Prepare the following measurement tools for electrical adjustments.

1. Oscilloscope
2. Digital Voltmeter
3. Multi-sound Generator
4. Pattern Generator

### On-Screen Display Adjustment

1. In the condition of NO indication on the screen. Press the VOL. DOWN button on the set and the Channel button (9) on the remote control for more than 2 seconds to appear the adjustment mode on the screen as shown in **Fig. 1-1**.




Fig. 1-1

2. Use the Channel UP/DOWN button or Channel button (0-9) on the remote control to select the options shown in **Fig. 1-2**.
3. Press the MENU button on the remote control to end the adjustments.

NO. FUNCTION	NO. FUNCTION
00 OSD H	18 CONTRAST MAX
01 CUT OFF	19 CONTRAST CENT
02 H. VCO	20 CONTRAST MIN
03 H. PHASE	21 COLOR MAX
04 AFC GAIN	22 COLOR CENTER
05 V. SHIFT	23 COLOR MIN
06 H. SIZE	24 TINT
07 V. SIZE	25 SHARPNESS
08 V. LINERITY	26 CB DL
09 VS CORRECTION	27 CR DL
10 R DRIVE	28 CB PED
11 B DRIVE	29 CR PED
12 R BIAS	30 PARABOLA
13 G BIAS	31 CORNER
14 B BIAS	32 TRAPWZIUM
15 BRIGHT MAX	33 LEVEL
16 BRIGHT CENT	34 SEPARATION1
17 BRIGHT MIN	35 SEPARATION2

Fig. 1-2

## 2. BASIC ADJUSTMENTS

### 2-1: CONSTANT VOLTAGE

1. Place the set in AV MODE without signal.
2. Connect the digital voltmeter to the **TP003**.
3. Adjust the **VR502** until the digital voltmeter is  $135 \pm 0.5V$ .

### 2-2: CUT OFF

1. Place the set in Aging Test for more than 15 minutes.
2. Place the set in AV MODE without signal.
3. Using the remote control, set the brightness and contrast to normal position.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button (01) on the remote control to select "CUT OFF".
5. Adjust the **Screen Volume** until a dim raster is obtained.

### 2-3: WHITE BALANCE, WHITE BALANCE CS

NOTE: Adjust after performing CUT OFF adjustment.

1. Place the set in Aging Test for more than 15 minutes.
2. Receive the gray scale pattern from the Pattern Generator with Brust On.
3. Using the remote control, set the brightness and contrast to normal position.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button (12) on the remote control to select "R. BIAS".
5. Press the CH. UP/DOWN button on the remote control to select the "R. BIAS", "G. BIAS", "B. BIAS", "B. DRIVE" or "R. DRIVE".
6. Adjust the VOL. UP/DOWN button on the remote control to whiten the R. BIAS, G. BIAS, B. BIAS, B. DRIVE and R. DRIVE at each step tone sections equally.
7. Perform the above adjustments 5 and 6 until the white color is achieved.
8. Press the TV/VIDEO button on the remote control to set to the CS mode.
9. Receive the gray scale pattern from the Pattern Generator with Brust On.
10. If the picture is too much green. Activate the adjustment mode display of **Fig. 1-1** and press the channel button (28) on the remote control to select "CB PED".
11. Adjust the VOL. UP/DOWN button on the remote control to select the step up.
12. If the picture is too much red. Activate the adjustment mode display of **Fig. 1-1** and press the channel button (29) on the remote control to select "CR PED".
13. Adjust the VOL. UP/DOWN button on the remote control to select the step down.

# ELECTRICAL ADJUSTMENTS

## 2-4: COLOR CENT

1. Receive the color bar pattern. (RF Input)
2. Using the remote control, set the brightness, contrast, color and tint to normal position.
3. Connect the oscilloscope to **TP804**.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(22)** on the remote control to select "COLOR CENT".
5. Adjust the VOLTS RANGE VARIABLE knob of the oscilloscope until the range between white 100% and 0% is set to 4 scales on the screen of the oscilloscope.
6. Press the VOL. UP/DOWN button on the remote control until the red color level is adjusted to  $125 \pm 5\%$  of the white level. (**Refer to Fig. 2-1**)
7. Receive the video color bar pattern. (Audio Video Input)
8. Set to the AV mode. Then perform the above adjustments 2~6.
9. Press the TV/VIDEO button on the remote control to set to the CS mode. Then perform the above adjustments 2~4.
10. Press the VOL. UP/DOWN button on the remote control until the color step No. becomes "70".




Fig. 2-1

## 2-5: TINT

1. Receive the color bar pattern. (RF Input)
2. Using the remote control, set the brightness, contrast, color and tint to normal position.
3. Connect the oscilloscope to **TP806**.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(24)** on the remote control to select "TINT".
5. Press the VOL. UP/DOWN button on the remote control until the section "A" becomes as straight line. (**Refer to Fig. 2-2**)
6. Receive the video color bar pattern. (Audio Video Input)
7. Set to the AV mode. Then perform the above adjustments 2~5.
8. Press the TV/VIDEO button on the remote control to set to the CS mode. Then perform the above adjustments 2~4.
9. Press the VOL. UP/DOWN button on the remote control until the tint step No. becomes "55".




Fig. 2-2

## 2-6: FOCUS

1. Receive the monoscope pattern.
2. Turn the Focus Volume fully counterclockwise once.
3. Adjust the **Focus Volume** until picture is distinct.

## 2-7: VERTICAL POSITION

1. Receive the monoscope pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Adjust the **VR401** until the horizontal line becomes fit to the notch of the shadow mask. (**Refer to Fig. 2-3**)




Fig. 2-3

## 2-8: VERTICAL SIZE

1. Receive the monoscope pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(07)** on the remote control to select "V. SIZE".
4. Press the VOL. UP/DOWN button on the remote control until the SHIFT quantity of the OVER SCAN on upside and downside becomes  $9 \pm 3\%$ .

# ELECTRICAL ADJUSTMENTS

## 2-9: VERTICAL LINEARITY

**NOTE:** Adjust after performing adjustments in section 2-8.  
After the adjustment of Vertical Linearity, reconfirm the Vertical Position and Vertical Size adjustments.

1. Receive the monoscope pattern.
2. Using the remote control, set the brightness, contrast, to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(08)** on the remote control to select "V. LINEARITY".
4. Press the VOL. UP/DOWN button on the remote control until the SHIFT quantity of the OVER SCAN on upside and downside becomes minimum.

## 2-10: HORIZONTAL POSITION


1. Receive the monoscope pattern.
2. Using the remote control, set the brightness, contrast, to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(03)** on the remote control to select "H.PHASE".
4. Press the VOL. UP/DOWN button on the remote control until the SHIFT quantity of the OVER SCAN on right and left becomes minimum.

## 2-11: HORIZONTAL SIZE

1. Receive the monoscope pattern.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(06)** on the remote control to select "H. SIZE".
4. Press the VOL. UP/DOWN button on the remote control adjust the H.SIZE becomes 10~12%.

## 2-12: OSD POSITION

1. Activate the adjustment mode display of **Fig. 1-1**.
2. Press the VOL. UP/DOWN button on the remote control until the difference of A and B becomes minimum. (**Refer to Fig. 2-4**)



## 2-13: BRIGHT CENT

1. Receive the monoscope pattern. (RF Input)
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(16)** on the remote control to select "BRI CENT".
4. Press the VOL. UP/DOWN button on the remote control until the white 10% is starting to be visible.
5. Receive the monoscope pattern. (Audio Video Input)
6. Press the TV/VIDEO button on the remote control to set to the AV mode. Then perform the above adjustments 2~4.
7. Press the TV/VIDEO button on the remote control to set to the CS mode.
8. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(16)** on the remote control to select "BRI CENT".
9. Press the VOL. UP/DOWN button on the remote control until the brightness step No. becomes "90".

## 2-14: CONTRAST MAX

1. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(18)** on the remote control to select "CONT. MAX".
2. Press the VOL. UP/DOWN button on the remote control until the contrast step No. becomes "100".
3. Receive a broadcast and check if the picture is normal.
4. Press the TV/VIDEO button on the remote control to set to the AV mode. Then perform the above adjustments 1~3.
5. Press the TV/VIDEO button on the remote control to set to the CS mode. Then perform the above adjustments 1~3.

## 2-15: PARABOLA/CORNER

1. Receive the cross hatch signal from the Pattern Generator.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(30)** on the remote control to select "PARABOLA".
4. Press the VOL. UP/DOWN button on the remote control until the right and left vertical lines are straight.
5. In the case the right and left vertical lines are not straight, Please Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(31)** on the remote control to select "CORNER".
6. Press the VOL. UP/DOWN button on the remote control until the right and left vertical lines are straight.

## 2-16: TRAPEZIUM

1. Receive the cross hatch signal from the Pattern Generator.
2. Using the remote control, set the brightness and contrast to normal position.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(32)** on the remote control to select "TRAPEZIUM".
4. Press the VOL. UP/DOWN button on the remote control until the both vertical lines of the screen become paralleled.

## ELECTRICAL ADJUSTMENTS

### 2-17: SEPARATION 1, 2

Please do the method (1) or method (2) adjustment.

#### Method (1)

1. Set the multi-sound signal generator for each different L-ch and R-ch frequency (Ex. L-ch=2KHz, R-ch=400Hz) and receive the RF.
2. Connect the oscilloscope to the **Audio Out Jack**.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(34)** on the remote control to select "SEP 1".
4. Press the VOL. UP/DOWN button on the remote control to adjust it until the audio output wave becomes a fine sine wave.
5. Press the CH UP button once the set to "SEP 2" mode. Then perform the above adjustment 4.

#### Method (2)

1. Set the multi-sound signal generator L-ch=1KHz, R-ch =Non input and receive the RF.
2. Connect the oscilloscope to the **Audio Out Jack (R-ch)**.
3. Press the AUDIO SELECT button on the remote control to set to the stereo mode.
4. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(34)** on the remote control to select "SEP 1".
5. Press the VOL. UP/DOWN button on the remote control to adjust it until the R-ch output becomes minimum.
6. Set the multi-sound signal generator L-ch=Non input, R-ch=1KHz and receive the RF.
7. Connect the oscilloscope to the **Audio Out Jack (L-ch)**.
8. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(35)** on the remote control to select "SEP 2".
9. Press the VOL. UP/DOWN button on the remote control to adjust it until the L-ch output becomes minimum. The output difference of the between with Filter and without Filter should be more than 25db for both L and R.

### 2-18: LEVEL

1. Receive the monoscope pattern.
2. Connect the AC voltmeter to **pin 6 of CP101**.
3. Activate the adjustment mode display of **Fig. 1-1** and press the channel button **(33)** on the remote control to select "LEVEL".
4. Press the VOL. UP/DOWN button on the remote control until the AC voltmeter is  $75 \pm 2\text{mV}$ .

### 2-19: Confirmation of Fixed Value (Step No.)

Please check if the fixed values of the each adjustment items are set correctly referring below.

NO.	FUNCTION	RF	AV	CS
02	H.VCO	03	03	03
04	AFC GAIN	06	06	06
05	V.SHIFT	02	02	02
09	VS CORRECTION	36	36	36
15	BRI.MAX	160	160	160
17	BRI.MIN	30	30	30
19	CONT.CENT	64	64	64
20	CONT.MIN	05	05	05
21	COL.MAX	90	90	90
23	COL.MIN	00	00	00
25	SHARPNESS	40	40	40
26	CB DL	00	00	00
27	CR DL	00	00	00

# ELECTRICAL ADJUSTMENTS

## 3. PURITY AND CONVERGENCE ADJUSTMENTS

### NOTE

1. Turn the unit on and let it warm up for at least 30 minutes before performing the following adjustments.
2. Place the CRT surface facing east or west to reduce the terrestrial magnetism.
3. Turn ON the unit and demagnetize with a Degauss Coil.

### 3-1: STATIC CONVERGENCE (ROUGH ADJUSTMENT)

1. Tighten the screw for the magnet. Refer to the adjusted CRT for the position. (**Refer to Fig. 3-1**)  
If the deflection yoke and magnet are in one body, untighten the screw for the body.
2. Receive the green raster pattern from the color bar generator.
3. Slide the deflection yoke until it touches the funnel side of the CRT.
4. Adjust center of screen to green, with red and blue on the sides, using the pair of purity magnets.
5. Switch the color bar generator from the green raster pattern to the crosshatch pattern.
6. Combine red and blue of the 3 color crosshatch pattern on the center of the screen by adjusting the pair of 4 pole magnets.
7. Combine red/blue (magenta) and green by adjusting the pair of 6 pole magnets.
8. Adjust the crosshatch pattern to change to white by repeating steps 6 and 7.

### 3-2: PURITY

### NOTE

Adjust after performing adjustments in section 3-1.

1. Receive the green raster pattern from color bar generator.
2. Adjust the pair of purity magnets to center the color on the screen.  
Adjust the pair of purity magnets so the color at the ends are equally wide.
3. Move the deflection yoke backward (to neck side) slowly, and stop it at the position when the whole screen is green.
4. Confirm red and blue color.
5. Adjust the slant of the deflection yoke while watching the screen, then tighten the fixing screw.




Fig. 3-1

### 3-3: STATIC CONVERGENCE

### NOTE

Adjust after performing adjustments in section 3-2.

1. Receive the crosshatch pattern from the color bar generator.
2. Combine red and blue of the 3 color crosshatch pattern on the center of the screen by adjusting the pair of 4 pole magnets.
3. Combine red/blue (magenta) and green by adjusting the pair of 6 pole magnets.

### 3-4: DYNAMIC CONVERGENCE

### NOTE

Adjust after performing adjustments in section 3-3.

1. Adjust the differences around the screen by moving the deflection yoke upward/downward and right/left. (**Refer to Fig. 3-2-a**)
2. Insert three wedges between the deflection yoke and CRT funnel to fix the deflection yoke. (**Refer to Fig. 3-2-b**)




Fig. 3-2-a






Fig. 3-2-b

## ELECTRICAL ADJUSTMENTS


### 4. ELECTRICAL ADJUSTMENT PARTS LOCATION GUIDE (WIRING CONNECTION)




## BLOCK DIAGRAM



**PRINTED CIRCUIT BOARDS  
MAIN (INSERTED PARTS)  
SOLDER SIDE**




PRINTED CIRCUIT BOARDS  
MAIN (CHIP MOUNTED PARTS)  
SOLDER SIDE




## **PRINTED CIRCUIT BOARDS**


**CRT/VM COIL  
SOLDER SIDE**




**POWER  
SOLDER SIDE**



# MICON SCHEMATIC DIAGRAM (MAIN PCB)



## CHROMA SCHEMATIC DIAGRAM (MAIN PCB)




NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME  
OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.

NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED  
WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST  
WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

**ATTENTION:** LES PIECES REPARÉES PAR UN  ETANT DANGEREUSES AU POINT DE VUE SÉCURITÉ N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.

**CAUTION** SINCE THESE PARTS MARKED BY  ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

# DEFLECTION SCHEMATIC DIAGRAM (MAIN PCB)




NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

NOTE: THE RESISTOR MARKED F IS FUSE RESISTOR.  
THE ALUMI ELECTROLYTIC CAPACITOR MARKED NP IS NON POLAR ONE.


# POWER SCHEMATIC DIAGRAM (MAIN PCB)



# SOUND SCHEMATIC DIAGRAM (MAIN PCB)



# TUNER/STEREO SCHEMATIC DIAGRAM (MAIN PCB)



NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

ATTENTION: LES PIECES REPEREES PAR UN ETANT DANGEREUSES AU POINT DE VUE SECURITE N'UTILISER QUE CELLES DECRISES DANS LA NOMENCLATURE DES PIECES.

CAUTION: SINCE THESE PARTS MARKED BY ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

# AV SCHEMATIC DIAGRAM


(MAIN PCB)



NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME  
OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.


NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED  
WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST  
WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.

# COMB FILTER SCHEMATIC DIAGRAM (MAIN PCB)




## CRT/SVM SCHEMATIC DIAGRAM

(CRT PCB)



(VM COIL PCB)



NOTE: THE DC VOLTAGE AT EACH PART WAS MEASURED  
WITH THE DIGITAL TESTER WHEN THE COLOR BROADCAST  
WAS RECEIVED IN GOOD CONDITION AND PICTURE IS NORMAL.


**NOTE: THIS SCHEMATIC DIAGRAM IS THE LATEST AT THE TIME  
OF PRINTING AND SUBJECT TO CHANGE WITHOUT NOTICE.**

**CAUTION** SINCE THESE PARTS MARKED BY  ARE CRITICAL FOR SAFETY, USE ONES DESCRIBED IN PARTS LIST ONLY.

**ATTENTION:** LES PIECES REPARÉES PAR UN  ETANT DANGEREUSES AU POINT DE VUE SÉCURITÉ N'UTILISER QUE CELLES DÉCRITES DANS LA NOMENCLATURE DES PIÈCES.


◀ R.SIGNAL  
◀ G.SIGNAL  
◀ B.SIGNAL

**SUB POWER SCHEMATIC DIAGRAM**  
**(POWER PCB)**




# WAVEFORMS


## MICON




① 1V 0.1 $\mu$ s/div




⑧ 0.5V 10ms/div




⑬ 1V 20 $\mu$ s/div




② 1V 1 $\mu$ s/div




⑨ 1V 50 $\mu$ s/div




⑭ 2V 20 $\mu$ s/div




③ 1V 50 $\mu$ s/div




⑩ 2V 20 $\mu$ s/div




⑯ 2V 20 $\mu$ s/div



④ 1V 0.1ms/div




⑪ 0.5V 20 $\mu$ s/div




⑯ 2V 5ms/div


## CHROMA



⑦ 1V 20 $\mu$ s/div




⑫ 1V 2 $\mu$ s/div




⑰ 20V 5ms/div

**NOTE:** The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.


## WAVEFORMS




⑯ 10V 10ms/div




⑰ 50V 20μs/div




㉕ 2V 5ms/div



⑲ 20V 20μs/div




⑳ 50V 20μs/div




㉖ 5V 2ms/div


## SOUND




㉐ 2V 20μs/div




㉒ 2V 5ms/div




㉗ 5V 2ms/div



㉑ 200V 50μs/div




㉓ 2V 5ms/div




㉘ 200mV 20μs/div


## CRT/SVM



㉗ 50V 20μs/div




㉔ 2V 5ms/div




㉙ 200mV 20μs/div

**NOTE:** The following waveforms were measured at the point of the corresponding balloon number in the schematic diagram.

## **MECHANICAL EXPLODED VIEW**



## MECHANICAL EXPLODED VIEW (PACKING DIAGRAM)



## MECHANICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description	
101	AE006008	7A701A360A	FRONT CABI ASS'Y	
101A	AE006341	701APJA138	CABINET,FRONT	
101B	AE003015	712APBA005	DOOR	
102	AE006342	A3N120J740K	CABINET,BACK ASS'Y	
103	AE006343	722549A435	SHEET,RATING	
104	AE006344	723000C844	FILM,DECORATION	
105	AD300766	7260000306	SHEET,CAUTION	
106	AE006108	769WSAA009	WASHER,CRT T=1	
107	BZ710660	741WUA0021	SPRING,EARTH	
108	AE005207	761WPA115	HOLDER,SPEAKER	
109	BZ710259	762WPA0011	HOLDER,CRT WIRE	
110	AE003304	735WPA637	BUTTON ASS'Y	
111	AD301616	761WPA0263	HOLDER,JACK	
112	AD300518	801WR00001	DAMPER,SPEAKER	
113	BZ710260	899HV3T000	HOLDER,ANODE WIRE	
114	AE006345	735WPA845	STOPPER,BUTTON	
115	AE003022	723549A026	BADGE,BRAND	
116	AE003302	711WPA100	PLATE,FRONT ASS'Y	
117	AE003023	723549A030	AV LABEL	
118	AE006346	723000C843	SHEET,BAR CODE	
119	AE003028	791AHA0025	FILM BAG	
120	AE006347	792AHAA004	PACKAGE,TOP	
121	AE006348	792AHAA005	PACKAGE,BOTTOM	
122	AE006349	793ACDA187	GIFT BOX	
123	AE006350	795ACAA002	PAD	
124	AE000218	795ACA0010	PAD	378x1114
125	AE006351	A3N120J975	INSTRUCTION BOOK KIT	
126	AE006352	JA4LD200A	POLYBAG,INSTRUCTION(RED CAUTION)	
127	AE006353	J3N11517A	REGISTRASTION CARD	
128	AE006354	J3N12021A	INSTRUCTION BOOK	
201	AE006355	8141J60D5U	SCREW,TAP TITE(P) GW18	6x45
202	AE005398	8162540A6U	SCREW,TAPPING (BO) WASHER 18	
203	AE003528	8110630A0U	SCREW,TAP TITE(P) BRAZIER	3x10
204	AE003524	8109130A0U	SCREW,TAP TITE(B) WH7	3x10
205	AE005917	810963080Q	SCREW,TAP TITE(B) BRAZIER	3x8
206	AE003531	810763080U	SCREW,TAP TITE(S) BRAZIER	3x8
207	AE003529	811063080U	SCREW,TAP TITE(P) BRAZIER	3x8
208	AE003522	8117540B0U	SCREW,TAP TITE(B0) TRUSS	4x20
209	AE005659	810913080U	SCREW,TAP TITE(B) WH7	3x8

# MECHANICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description	
101	AE006008	7A701A360A	FRONT CABI ASS'Y	
101A	AE006341	701APJA138	CABINET,FRONT	
101B	AE003015	712APBA005	DOOR	
102	AE006356	A3N121J740K	CABINET,BACK	
103	AE006357	722549A441	SHEET,RATING	
104	AE006358	723000C856	FILM,DECORATION	
105	AD301425	7240001120	SHEET,CSA	
106	AE006108	769WSAA009	WASHER,CRT T=1	
107	BZ710660	741WUA0021	SPRING,EARTH	
108	AE005207	761WPA115	HOLDER,SPEAKER	
109	BZ710259	762WPA0011	HOLDER,CRT WIRE	
110	AE003304	735WPA637	BUTTON ASS'Y	
111	AD301616	761WPA0263	HOLDER,JACK	
112	AD300518	801WR00001	DAMPER,SPEAKER	
113	BZ710260	899HV3T000	HOLDER,ANODE WIRE	
114	AE006345	735WPA845	STOPPER,BUTTON	
115	AE003022	723549A026	BADGE,BRAND	
116	AE003302	711WPA100	PLATE,FRONT ASS'Y	
117	AE003023	723549A030	AV LABEL	
118	AE006360	723000C855	SHEET,BAR CODE	
119	AE003028	791AHA0025	FILM BAG	
120	AE006347	792AHAA004	PACKAGE, TOP	
121	AE006348	792AHAA005	PACKAGE, BOTTOM	
122	AE006361	793ACDA188	GIFT BOX	
123	AE006350	795ACAA002	PAD	
124	AE000218	795ACA0010	PAD	378x1114
125	AE006362	A3N121J975	INSTRUCTION BOOK KIT	
126	AE006363	JA4LD100A	POLYBAG,INSTRUCTION(RED CAUTION)	
128	AE006364	J3N12121A	INSTRUCTION BOOK	
201	AE006355	8141J60D5U	SCREW,TAP TITE(P) GW18	6x45
202	AE005398	8162540A6U	SCREW,TAPPING (BO) WASHER 18	
203	AE003528	8110630A0U	SCREW,TAP TITE(P) BRAZIER	3x10
204	AE003524	8109I30A0U	SCREW,TAP TITE(B) WH7	3x10
205	AE005917	810963080Q	SCREW,TAP TITE(B) BRAZIER	3x8
206	AE003531	810763080U	SCREW,TAP TITE(S) BRAZIER	3x8
207	AE003529	811063080U	SCREW,TAP TITE(P) BRAZIER	3x8
208	AE003522	8117540B0U	SCREW,TAP TITE(BO) TRUSS	4x20
209	AE005659	8109I3080U	SCREW,TAP TITE(B) WH7	3x8

# ELECTRICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description
<b>RESISTORS</b>			
△ R402	AE006295	R65501680J	R,FUSE
△ R410	BZ210087	R3X18A221J	R,METAL OXIDE
△ R416	BZ210053	R002T22R2J	RC
△ R426	BZ210030	R4X5T4472F	R,METAL
△ R434	AD301972	R5X2CF5R6J	R,CEMENT
△ R436	BZ210023	R4X5T4183F	R,METAL
△ R438	BZ210071	R3X28B4R7J	R,METAL OXIDE
△ R439	BZ210003	R3K181102J	R,METAL OXIDE
△ R441	BZ210231	R4X5T6153F	R,METAL
△ R452	AD301385	R3X18A391J	R,METAL OXIDE
△ R459	AD301595	R65582010J	R,FUSE
△ R500	BZ210080	R0G3K2275K	RC
△ R501	AD301596	R5X2AE010J	R,CEMENT
△ R502	BZ210249	R3X28A331J	R,METAL OXIDE
△ R506	BZ210162	R002T4682J	RC
R507	AE002597	R00202823J	RC
△ R517	BZ210191	R3X28B010J	R,METAL OXIDE
△ R520	BZ210206	R002T2155J	RC
△ R527	BZ210149	R3X18A68J	R,METAL OXIDE
△ R541	AE005735	R63881R22J	R,FUSE
△ R542	BZ210248	R3X181R15J	R,METAL OXIDE
R601	AE006340	R3X1811150J	R,METAL OXIDE
△ R602	AD301975	R3X28B120J	R,METAL OXIDE
△ R649	AD301975	R3X28B120J	R,METAL OXIDE
△ R804	BZ210026	R3X18A153J	R,METAL OXIDE
△ R806	BZ210026	R3X18A153J	R,METAL OXIDE
△ R808	BZ210026	R3X18A153J	R,METAL OXIDE
R832	AE000901	R00202220J	RC
△ R855	AD301019	R65582331J	R,FUSE
△ R881	BZ210087	R3X18A221J	R,METAL OXIDE
R1014	AE006339	R00202821J	RC
<b>CAPACITORS</b>			
C155	AE004040	P6M900105J	CMPL
△ C408	BZ110032	E5EZFR3102M	CE
△ C412	BZ110060	P4N8FJ222H	CMPP
△ C413	AD301977	E0ELF4102M	CE
C418	AE001019	P4J7F3434J	CMPP
△ C420	AD301978	P4N8FJ133H	CMPP
△ C421	AD300048	P3N1F5183J	CPP
C425	BZ110202	C0PLRR713K	CC
△ C426	BZ110225	E5EZFD220M	CE
△ C430	BZ110195	E02LU8220M	CE
C442	AE006084	E736F56R8M	CE
△ C501	AD300067	E02LF4102M	CE
C502	BZ110202	C0PLRR713K	CC
△ C503	BZ110202	C0PLRR713K	CC
△ C504	AD301729	E02LU52R2M	CE
△ C505	BZ110025	P2122B224M	CMP
△ C506	BZ110035	P2122B104M	CMP
C507	AE000417	E51DFC821M	CE
△ C508	BZ110222	CD39E0MH3M	CC
△ C513	AD301026	CD39E0M13M	CC
C514	AD300067	E02LF4102M	CE
△ C517	BZ110213	C03L0R7K3K	CC
△ C519	AD301026	CD39E0M13M	CC
C521	AE006083	E61DFB221M	CE
△ C527	BZ110119	E02LF2222M	CE
△ C535	BZ110202	C0PLRR713K	CC
C808	BZ110226	C0JBB07H3K	CC
C1003	BZ210176	E02LF3222M	CE
C1004	BZ110053	E02LF3102M	CE
C1009	BZ110053	E02LF3102M	CE
<b>DIODES</b>			
D001	BZ410037	D97U03301B	DIODE,ZENER
D104	BZ410006	D1VT001330	DIODE,SILICON
D105	BZ410006	D1VT001330	DIODE,SILICON
D106	BZ410020	D97U05R11B	DIODE,ZENER
D107	BZ410006	D1VT001330	DIODE,SILICON
D108	BZ410006	D1VT001330	DIODE,SILICON
D109	BZ410054	0021721150	LED
D110	BZ410006	D1VT001330	DIODE,SILICON

## ELECTRICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description
<b>DIODES</b>			
D113	BZ410021	D97U05R61B	DIODE,ZENER
D402	BZ410043	D2WT011E10	DIODE,SILICON
D403	BZ410019	D97U03001B	DIODE,ZENER
D404	BZ410020	D97U05R11B	DIODE,ZENER
△D405	BZ410063	D2WTAU02A0	DIODE,SILICON
△D406	BZ410021	D97U05R61B	DIODE,ZENER
△D407	BZ410063	D2WTAU02A0	DIODE,SILICON
D408	AD302110	D2CF0715L0	DIODE,SILICON
D409	AD301980	D2CF2016L0	DIODE,SILICON
D410	BZ410019	D97U03001B	DIODE,ZENER
△D411	BZ410063	D2WTAU02A0	DIODE,SILICON
D414	BZ410043	D2WT011E10	DIODE,SILICON
D415	BZ410043	D2WT011E10	DIODE,SILICON
D416	BZ410006	D1VT001330	DIODE,SILICON
D417	BZ410006	D1VT001330	DIODE,SILICON
D419	BZ410006	D1VT001330	DIODE,SILICON
△D501	BZ410062	D2WTRM11C0	DIODE,SILICON
△D502	BZ410062	D2WTRM11C0	DIODE,SILICON
△D503	BZ410062	D2WTRM11C0	DIODE,SILICON
△D504	BZ410062	D2WTRM11C0	DIODE,SILICON
△D505	AE006082	D28F0PRA60	DIODE,RECTIFIER
△D506	AD300731	D2WXN49370	DIODE,SILICON
D507	BZ410006	D1VT001330	DIODE,SILICON
D508	BZ410064	D97U03R91B	DIODE,ZENER
D509	AD300671	D97U01801B	DIODE,ZENER
△D510	AD301980	D2CF2016L0	DIODE,SILICON
△D511	AD300731	D2WXN49370	DIODE,SILICON
△D512	BZ410010	D28T21DQN9	DIODE,SCHOTTKY
D513	BZ410006	D1VT001330	DIODE,SILICON
D514	BZ410006	D1VT001330	DIODE,SILICON
D516	BZ410006	D1VT001330	DIODE,SILICON
D517	BZ410006	D1VT001330	DIODE,SILICON
D520	BZ410006	D1VT001330	DIODE,SILICON
△D523	AD300671	D97U01801B	DIODE,ZENER
D524	BZ410006	D1VT001330	DIODE,SILICON
D525	AD300671	D97U01801B	DIODE,ZENER
D528	BZ410021	D97U05R61B	DIODE,ZENER
D601	BZ410006	D1VT001330	DIODE,SILICON
D602	BZ410058	D97U08R21B	DIODE,ZENER
D604	AD300070	D97U01201B	DIODE,ZENER
D605	BZ410006	D1VT001330	DIODE,SILICON
D606	BZ410006	D1VT001330	DIODE,SILICON
D607	BZ410006	D1VT001330	DIODE,SILICON
D608	BZ410043	D2WT011E10	DIODE,SILICON
D610	BZ410022	D97U06R81B	DIODE,ZENER
D611	BZ410022	D97U06R81B	DIODE,ZENER
D612	BZ410022	D97U06R81B	DIODE,ZENER
D701	AD300070	D97U01201B	DIODE,ZENER
D702	AD300070	D97U01201B	DIODE,ZENER
D703	AD300070	D97U01201B	DIODE,ZENER
D704	AD300070	D97U01201B	DIODE,ZENER
D705	AD300070	D97U01201B	DIODE,ZENER
D706	AD300070	D97U01201B	DIODE,ZENER
D709	BZ410066	D97U06R21B	DIODE,ZENER
D801	BZ410006	D1VT001330	DIODE,SILICON
D802	BZ410006	D1VT001330	DIODE,SILICON
D803	BZ410006	D1VT001330	DIODE,SILICON
D807	BZ410006	D1VT001330	DIODE,SILICON
D808	BZ410006	D1VT001330	DIODE,SILICON
D809	BZ410006	D1VT001330	DIODE,SILICON
D852	BZ410006	D1VT001330	DIODE,SILICON
D853	BZ410006	D1VT001330	DIODE,SILICON
D854	BZ410006	D1VT001330	DIODE,SILICON
D855	BZ410006	D1VT001330	DIODE,SILICON
D856	BZ410006	D1VT001330	DIODE,SILICON
D857	AE006060	D28T0ERB20	DIODE,RECTIFIER
D858	AE006060	D28T0ERB20	DIODE,RECTIFIER
<b>ICS</b>			
IC101	AE006067	I56F07090B	IC
IC199	AE006335	A3N120J015	INIT DATA
IC301	AE006297	I0QJ021500	IC
OEC7090B BR24L16FJ-WE2 NJM2150AM(TE1)			

# ELECTRICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	ICS	Description
IC302	AD301983	I01FF58910	IC	AN5891SA-E1V
△ IC401	BZ611117	I03TD80410	IC	LA78041
△ IC504	BZ410088	0002E00610	PHOTO COUPLER	LTV-817M-VB
IC601	AE002803	I06FC1283A	IC	M61283FP R70T
IC701	AD301988	I0UF015010	IC	MM1501XNRE
IC702	AD301988	I0UF015010	IC	MM1501XNRE
IC902	BZ611068	I01FF58290	IC	AN5829S-E1V
△ IC1001	AE003081	I0FSP7808B	IC	AN17808B
IC1501	AE003002	I03FE76605	IC	LA76605M-TLM
IC1502	AD301988	I0UF015010	IC	MM1501XNRE
IC1503	AD301988	I0UF015010	IC	MM1501XNRE
<b>TRANSISTORS</b>				
Q101	BZ510109	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK
Q103	BZ510109	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK
Q201	BZ510105	TCAT03209Y	TRANSISTOR,SILICON	KTC3209_Y-AT
Q202	BZ510070	TCAT032034	TRANSISTOR,SILICON	KTC3203_Y-AT
△ Q402	BZ510097	TCAT03227Y	TRANSISTOR,SILICON	KTC3227_Y-AT
Q405	AD302136	TD50026380	TRANSISTOR,SILICON	2SD2638(OEC)
Q408	BZ510073	TAATA12660	TRANSISTOR,SILICON	KTA1266-AT(Y,GR)
Q409	BZ510073	TAATA12660	TRANSISTOR,SILICON	KTA1266-AT(Y,GR)
Q410	BZ510110	TC30041590	TRANSISTOR,SILICON	2SC4159(D,E)
Q411	BZ510109	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK
△ Q502	BZ510098	T220033260	FET	2SK3326(2)
△ Q503	BZ510005	TA3T1371A0	TRANSISTOR,SILICON	2SA1371(D,E)-AE
Q504	BZ510069	TCATC31980	TRANSISTOR,SILICON	KTC3198-AT(Y,GR)
△ Q505	BZ510011	TC3T029090	TRANSISTOR,SILICON	2SC2909(S,T)-AA
△ Q507	BZ510069	TCATC31980	TRANSISTOR,SILICON	KTC3198-AT(Y,GR)
△ Q508	BZ510077	TAAT012714	TRANSISTOR,SILICON	KTA1271_Y-AT
Q509	BZ510069	TCATC31980	TRANSISTOR,SILICON	KTC3198-AT(Y,GR)
△ Q512	BZ510004	TA3T016240	TRANSISTOR,SILICON	2SA1624-AA
△ Q514	BZ510070	TCAT032034	TRANSISTOR,SILICON	KTC3203_Y-AT
Q601	BZ510105	TCAT03209Y	TRANSISTOR,SILICON	KTC3209_Y-AT
Q602	BZ510105	TCAT03209Y	TRANSISTOR,SILICON	KTC3209_Y-AT
Q603	BZ510109	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK
Q604	BZ510105	TCAT03209Y	TRANSISTOR,SILICON	KTC3209_Y-AT
Q605	BZ510109	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK
Q607	BZ510070	TCAT032034	TRANSISTOR,SILICON	KTC3203_Y-AT
Q610	BZ510109	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK
Q611	BZ510105	TCAT03209Y	TRANSISTOR,SILICON	KTC3209_Y-AT
Q613	BZ510109	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK
Q614	BZ510108	TAAA1504SY	TRANSISTOR,SILICON	KTA1504S_Y_RTK
Q709	BZ510108	TAAA1504SY	TRANSISTOR,SILICON	KTA1504S_Y_RTK
Q711	BZ510109	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK
Q712	BZ510109	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK
△ Q801	BZ510091	TC0042170	TRANSISTOR,SILICON	KTC4217(O,Y)
△ Q802	BZ510091	TC0042170	TRANSISTOR,SILICON	KTC4217(O,Y)
△ Q803	BZ510091	TC0042170	TRANSISTOR,SILICON	KTC4217(O,Y)
△ Q810	BZ510100	TCATC3199Y	TRANSISTOR,SILICON	KTC3199_Y-AT
△ Q811	BZ510100	TCATC3199Y	TRANSISTOR,SILICON	KTC3199_Y-AT
△ Q812	BZ510100	TCATC3199Y	TRANSISTOR,SILICON	KTC3199_Y-AT
Q852	BZ510069	TCATC31980	TRANSISTOR,SILICON	KTC3198-AT(Y,GR)
Q853	AD300024	TCUT00752Y	TRANSISTOR,SILICON	2SC752(G)(TM)_Y
Q854	BZ510069	TCATC31980	TRANSISTOR,SILICON	KTC3198-AT(Y,GR)
Q855	BZ510069	TCATC31980	TRANSISTOR,SILICON	KTC3198-AT(Y,GR)
Q856	BZ510069	TCATC31980	TRANSISTOR,SILICON	KTC3198-AT(Y,GR)
Q857	BZ510073	TAATA12660	TRANSISTOR,SILICON	KTA1266-AT(Y,GR)
Q858	AD300029	TAU0018370	TRANSISTOR,SILICON	2SA1837
Q859	AD300025	TCU0047930	TRANSISTOR,SILICON	2SC4793
Q901	BZ510108	TAAA1504SY	TRANSISTOR,SILICON	KTA1504S_Y_RTK
Q902	BZ510108	TAAA1504SY	TRANSISTOR,SILICON	KTA1504S_Y_RTK
Q1001	BZ510068	TNAAJ05003	COMPOUND TRANSISTOR	KRC111SRTK
Q1503	BZ510109	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK
Q1504	BZ510109	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK
Q1507	BZ510109	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK
Q1508	BZ510109	TCAA3875SY	TRANSISTOR,SILICON	KTC3875S_Y_RTK
<b>COILS &amp; TRANSFORMERS</b>				
L301	BZ310041	02167F101J	COIL	100 UH
L401	AD301644	021L75472J	COIL	4.7 MH
L402	BZ310187	022100034A	COIL,LINEARITY	ELH5L4132N
L403	AD301606	02DK000058	COIL,CHOKE	02DK000058
△ L501	AD301124	029T000101	COIL,LINE FILTER	2R2A752F28Y

# ELECTRICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description
<b>COILS &amp; TRANSFORMERS</b>			
△ L503	AE003003	028R270013	COIL,DEGAUSS
L601	AD301990	021LA6330J	COIL
L801	BZ310002	021673101K	COIL
L802	BZ310170	021673151K	COIL
L803	BZ310170	021673151K	COIL
L804	BZ310170	021673151K	COIL
L901	BZ310041	02167F101J	COIL
L1501	BZ310041	02167F101J	COIL
L1502	BZ310039	02167F220J	COIL
L1503	BZ310039	02167F220J	COIL
L1505	AD300613	02167F150J	COIL
L1508	BZ310041	02167F101J	COIL
L1510	AD300613	02167F150J	COIL
L1511	AD300613	02167F150J	COIL
L1512	BZ310183	021LA6220J	COIL
T401	BZ310189	0450190161	TRANS,HORIZONTAL DRIVE
△ T501	AD301355	048140065S	TRANSFORMER,SWITCHING
<b>JACKS</b>			
J701	AE002759	060J431020	RCA JACK
J702	AE006074	063Q700011	JACK
J703	AE002759	060J431020	RCA JACK
J704	AE002761	060J411032	RCA JACK
J705	AE004756	060J401104	RCA JACK
J706	AE004758	060J401106	RCA JACK
J707	AE004757	060J401105	RCA JACK
J708	AE002759	060J431020	RCA JACK
△ J801	AD301936	066F130021	SOCKET,CATHODE RAY,TUBE
△ J1001	AE003431	060J131016	HEADPHONE JACK
<b>SWITCHES</b>			
SW101	BZ612010	0504101T34	SWITCH,TACT
SW102	BZ612010	0504101T34	SWITCH,TACT
SW103	BZ612010	0504101T34	SWITCH,TACT
SW104	BZ612010	0504101T34	SWITCH,TACT
SW105	BZ612010	0504101T34	SWITCH,TACT
<b>VARIABLE RESISTORS</b>			
VR401	BZ210218	V1K63H3BTE	VOLUME,SEMI FIXED
VR502	BZ210101	V1163H4BTC	VOLUME,SEMI FIXED
<b>P.C.BOARD ASSEMBLIES</b>			
PCB010	AE006334	A3N120J010K	PCB ASS'Y
PCB060	AE006336	A3N120J060K	PCB ASS'Y
PCB110	AE006337	A3N120J110K	PCB ASS'Y
PCB240	AE006338	A3N120J240K	PCB ASS'Y
<b>MISCELLANEOUS</b>			
B401	BZ310129	024HT03564	CORE,BEADS
B402	BZ310129	024HT03564	CORE,BEADS
B405	BZ310129	024HT03564	CORE,BEADS
B501	BZ310045	024AT03481	CORE,BEADS
B504	BZ310121	024HT03553	CORE,BEADS
B851	BZ310121	024HT03553	CORE,BEADS
B852	BZ310121	024HT03553	CORE,BEADS
B853	BZ310121	024HT03553	CORE,BEADS
BT001	AE005640	141R004016	BATTERY,MANGAN
BT002	AE005640	141R004016	BATTERY,MANGAN
△ CD501	AE006077	1209615904	CORD,AC BUSH
CD801	BZ614457	06CU253901	CORD,CONNECTOR
CD802	AD302370	06CU275101	CORD,CONNECTOR
CD803	AE003007	06CU83036A	CORD,CONNECTOR
CD851	AD302371	06CU244701	CORD,CONNECTOR
CD852	AD301043	06CU232001	CORD,CONNECTOR
CP101	BZ614102	0694270139	CONNECTOR PCB SIDE
CP201	AE006332	069J130340	CONNECTOR PCB SIDE
△ CP401	AE006075	069X460109	CONNECTOR PCB SIDE
△ CP501	BZ614176	069S320419	CONNECTOR PCB SIDE
△ CP502	BZ614283	069S420110	CONNECTOR PCB SIDE
CP507	BZ614444	069D01001A	CONNECTOR PCB SIDE
CP508	BZ614444	069D01001A	CONNECTOR PCB SIDE
CP803	AD301996	069S330010	CONNECTOR PCB SIDE
CP804	BZ614058	069W010010	CONNECTOR PCB SIDE
CP852	BZ614350	069S230629	CONNECTOR PCB SIDE
CP1001	AD301045	069S140419	CONNECTOR PCB SIDE
CP801A	BZ614276	067U005049	WIRE HOLDER

## ELECTRICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description
<b>MISCELLANEOUS</b>			
CP801B	AD300752	069S250629	CONNECTOR PCB SIDE
CP802A	AD301997	067U007029	WIRE HOLDER
CP802B	BZ614485	069S270629	CONNECTOR PCB SIDE
CP851A	BZ614334	067U004029	WIRE HOLDER
CP851B	AD301998	069S240629	CONNECTOR PCB SIDE
CP852B	BZ614349	067U003029	WIRE HOLDER
EL001	BZ614044	124120301A	EYE LET
EL002	BZ614043	124116281A	EYE LET
△F501	BZ614422	081PC6R305	FUSE
△FB401	AE003213	043227017F	TRANSFORMER,FLYBACK
FH501	AE002634	06710T0009	HOLDER,FUSE
FH502	AE002634	06710T0009	HOLDER,FUSE
OS101	AD301048	0773071001	REMOTE RECEIVER
△RY501	AE006070	0560X20118	RELAY
△SP1001	AE006333	070W546010	SPEAKER
△TH501	BZ410079	DF5EL3R0A0	DEGAUSS ELEMENT
TM101	AE003009	076R0GW020	TRANSMITTER
△TU001	AE006069	0163300018	RF UNIT
△V801	AE003010	098T270904	CRT W/DY
X101	AD302002	100CT8R005	CRYSTAL
X602	BZ613004	100CT3R505	CRYSTAL

RESISTOR

RC..... CARBON RESISTOR

CAPACITORS

CC.....	CERAMIC CAPACITOR
CE.....	ALUMI ELECTROLYTIC CAPACITOR
CP.....	POLYESTER CAPACITOR
CPP.....	POLYPROPYLENE CAPACITOR
CPL.....	PLASTIC CAPACITOR
CMP.....	METAL POLYESTER CAPACITOR
CMPL.....	METAL PLASTIC CAPACITOR
CMPP.....	METAL POLYPROPYLENE CAPACITOR

# ELECTRICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description
<b>RESISTORS</b>			
△ R402	AE006295	R65501680J	R,FUSE
△ R410	BZ210087	R3X18A221J	R,METAL OXIDE
△ R416	BZ210053	R002T22R2J	RC
△ R426	BZ210030	R4X5T4472F	R,METAL
△ R434	AD301972	R5X2CF5R6J	R,CEMENT
△ R436	BZ210023	R4X5T4183F	R,METAL
△ R438	BZ210071	R3X28B4R7J	R,METAL OXIDE
△ R439	BZ210003	R3K181102J	R,METAL OXIDE
△ R441	BZ210231	R4X5T6153F	R,METAL
△ R452	AD301385	R3X18A391J	R,METAL OXIDE
△ R459	AD301595	R65582010J	R,FUSE
△ R500	BZ210080	R0G3K2275K	RC
△ R501	AD301596	R5X2AE010J	R,CEMENT
△ R502	BZ210249	R3X28A331J	R,METAL OXIDE
△ R506	BZ210162	R002T4682J	RC
R507	AE002597	R00202823J	RC
△ R517	BZ210191	R3X28B010J	R,METAL OXIDE
△ R520	BZ210206	R002T2155J	RC
△ R527	BZ210149	R3X18A68J	R,METAL OXIDE
△ R541	AE005735	R63881R22J	R,FUSE
△ R542	BZ210248	R3X181R15J	R,METAL OXIDE
R601	AE006340	R3X181150J	R,METAL OXIDE
△ R602	AD301975	R3X28B120J	R,METAL OXIDE
△ R649	AD301975	R3X28B120J	R,METAL OXIDE
△ R804	BZ210026	R3X18A153J	R,METAL OXIDE
△ R806	BZ210026	R3X18A153J	R,METAL OXIDE
△ R808	BZ210026	R3X18A153J	R,METAL OXIDE
R832	AE000901	R00202220J	RC
△ R855	AD301019	R65582331J	R,FUSE
△ R881	BZ210087	R3X18A221J	R,METAL OXIDE
R1014	AE006339	R00202821J	RC
<b>CAPACITORS</b>			
C155	AE004040	P6M900105J	CMPL
△ C408	BZ110032	E5EZF3102M	CE
△ C412	BZ110060	P4N8FJ22H	CMPP
△ C413	AD301977	E0ELF4102M	CE
C418	AE001019	P4J7F3434J	CMPP
△ C420	AD301978	P4N8FJ133H	CMPP
△ C421	AD300048	P3N1F5183J	CPP
C425	BZ110202	C0PLRR713K	CC
△ C426	BZ110225	E5EZFD220M	CE
△ C430	BZ110195	E02LU8220M	CE
C442	AE006084	E736F56R8M	CE
△ C501	AD300067	E02LF4102M	CE
C502	BZ110202	C0PLRR713K	CC
△ C503	BZ110202	C0PLRR713K	CC
△ C504	AD301729	E02LU52R2M	CE
△ C505	BZ110025	P2122B224M	CMP
△ C506	BZ110035	P2122B104M	CMP
C507	AE000417	E51DFC821M	CE
△ C508	BZ110222	CD39E0MH3M	CC
△ C513	AD301026	CD39E0M13M	CC
C514	AD300067	E02LF4102M	CE
△ C517	BZ110213	C03L0R7K3K	CC
△ C519	AD301026	CD39E0M13M	CC
C521	AE006083	E61DFB221M	CE
△ C527	BZ110119	E02LF2222M	CE
△ C535	BZ110202	C0PLRR713K	CC
C808	BZ110226	C0JBB07H3K	CC
C1003	BZ210176	E02LF3222M	CE
C1004	BZ110053	E02LF3102M	CE
C1009	BZ110053	E02LF3102M	CE
<b>DIODES</b>			
D001	BZ410037	D97U03301B	DIODE,ZENER
D104	BZ410006	D1VT001330	DIODE,SILICON
D105	BZ410006	D1VT001330	DIODE,SILICON
D106	BZ410020	D97U05R11B	DIODE,ZENER
D107	BZ410006	D1VT001330	DIODE,SILICON
D108	BZ410006	D1VT001330	DIODE,SILICON
D109	BZ410054	0021721150	LED
D110	BZ410006	D1VT001330	DIODE,SILICON

# ELECTRICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description
<b>DIODES</b>			
D113	BZ410021	D97U05R61B	DIODE,ZENER
D402	BZ410043	D2WT011E10	DIODE,SILICON
D403	BZ410019	D97U03001B	DIODE,ZENER
D404	BZ410020	D97U05R11B	DIODE,ZENER
△D405	BZ410063	D2WTAU02A0	DIODE,SILICON
△D406	BZ410021	D97U05R61B	DIODE,ZENER
△D407	BZ410063	D2WTAU02A0	DIODE,SILICON
D408	AD302110	D2CF0715L0	DIODE,SILICON
D409	AD301980	D2CF2016L0	DIODE,SILICON
D410	BZ410019	D97U03001B	DIODE,ZENER
△D411	BZ410063	D2WTAU02A0	DIODE,SILICON
D414	BZ410043	D2WT011E10	DIODE,SILICON
D415	BZ410043	D2WT011E10	DIODE,SILICON
D416	BZ410006	D1VT001330	DIODE,SILICON
D417	BZ410006	D1VT001330	DIODE,SILICON
D419	BZ410006	D1VT001330	DIODE,SILICON
△D501	BZ410062	D2WTRM11C0	DIODE,SILICON
△D502	BZ410062	D2WTRM11C0	DIODE,SILICON
△D503	BZ410062	D2WTRM11C0	DIODE,SILICON
△D504	BZ410062	D2WTRM11C0	DIODE,SILICON
△D505	AE006082	D28F0PRA60	DIODE,RECTIFIER
△D506	AD300731	D2WXN49370	DIODE,SILICON
D507	BZ410006	D1VT001330	DIODE,SILICON
D508	BZ410064	D97U03R91B	DIODE,ZENER
D509	AD300671	D97U01801B	DIODE,ZENER
△D510	AD301980	D2CF2016L0	DIODE,SILICON
△D511	AD300731	D2WXN49370	DIODE,SILICON
△D512	BZ410010	D28T21DQN9	DIODE,SCHOTTKY
D513	BZ410006	D1VT001330	DIODE,SILICON
D514	BZ410006	D1VT001330	DIODE,SILICON
D516	BZ410006	D1VT001330	DIODE,SILICON
D517	BZ410006	D1VT001330	DIODE,SILICON
D520	BZ410006	D1VT001330	DIODE,SILICON
△D523	AD300671	D97U01801B	DIODE,ZENER
D524	BZ410006	D1VT001330	DIODE,SILICON
D525	AD300671	D97U01801B	DIODE,ZENER
D528	BZ410021	D97U05R61B	DIODE,ZENER
D601	BZ410006	D1VT001330	DIODE,SILICON
D602	BZ410058	D97U08R21B	DIODE,ZENER
D604	AD300070	D97U01201B	DIODE,ZENER
D605	BZ410006	D1VT001330	DIODE,SILICON
D606	BZ410006	D1VT001330	DIODE,SILICON
D607	BZ410006	D1VT001330	DIODE,SILICON
D608	BZ410043	D2WT011E10	DIODE,SILICON
D610	BZ410022	D97U06R81B	DIODE,ZENER
D611	BZ410022	D97U06R81B	DIODE,ZENER
D612	BZ410022	D97U06R81B	DIODE,ZENER
D701	AD300070	D97U01201B	DIODE,ZENER
D702	AD300070	D97U01201B	DIODE,ZENER
D703	AD300070	D97U01201B	DIODE,ZENER
D704	AD300070	D97U01201B	DIODE,ZENER
D705	AD300070	D97U01201B	DIODE,ZENER
D706	AD300070	D97U01201B	DIODE,ZENER
D709	BZ410066	D97U06R21B	DIODE,ZENER
D801	BZ410006	D1VT001330	DIODE,SILICON
D802	BZ410006	D1VT001330	DIODE,SILICON
D803	BZ410006	D1VT001330	DIODE,SILICON
D807	BZ410006	D1VT001330	DIODE,SILICON
D808	BZ410006	D1VT001330	DIODE,SILICON
D809	BZ410006	D1VT001330	DIODE,SILICON
D852	BZ410006	D1VT001330	DIODE,SILICON
D853	BZ410006	D1VT001330	DIODE,SILICON
D854	BZ410006	D1VT001330	DIODE,SILICON
D855	BZ410006	D1VT001330	DIODE,SILICON
D856	BZ410006	D1VT001330	DIODE,SILICON
D857	AE006060	D28T0ERB20	DIODE,RECTIFIER
D858	AE006060	D28T0ERB20	DIODE,RECTIFIER
<b>ICS</b>			
IC101	AE006067	I56F07090B	IC
IC199	AE007261	A3N121J015	INIT DATA
IC301	AE006297	I0QJ021500	IC
OEC7090B BR24L16FJ-WE2 NJM2150AM(TE1)			

# ELECTRICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description
<b>TRANSISTORS</b>			
IC302	AD301983	I01FF58910	IC
△IC401	BZ611117	I03TD80410	IC
△IC504	BZ410088	0002E00610	PHOTO COUPLER
IC601	AE002803	I06FC1283A	IC
IC701	AD301988	I0UF015010	IC
IC702	AD301988	I0UF015010	IC
IC902	BZ611068	I01FF58290	IC
△IC1001	AE003081	I0FSP7808B	IC
IC1501	AE003002	I03FE76605	IC
IC1502	AD301988	I0UF015010	IC
IC1503	AD301988	I0UF015010	IC
<b>TRANSISTORS</b>			
Q101	BZ510109	TCAA3875SY	TRANSISTOR,SILICON
Q103	BZ510109	TCAA3875SY	TRANSISTOR,SILICON
Q201	BZ510105	TCAT03209Y	TRANSISTOR,SILICON
Q202	BZ510070	TCAT032034	TRANSISTOR,SILICON
△Q402	BZ510097	TCAT03227Y	TRANSISTOR,SILICON
Q405	AD302136	TD50026380	TRANSISTOR,SILICON
Q408	BZ510073	TAATA12660	TRANSISTOR,SILICON
Q409	BZ510073	TAATA12660	TRANSISTOR,SILICON
Q410	BZ510110	TC30041590	TRANSISTOR,SILICON
Q411	BZ510109	TCAA3875SY	TRANSISTOR,SILICON
△Q502	BZ510098	T220033260	FET
△Q503	BZ510005	TA3T1371A0	TRANSISTOR,SILICON
Q504	BZ510069	TCATC31980	TRANSISTOR,SILICON
△Q505	BZ510011	TC3T029090	TRANSISTOR,SILICON
△Q507	BZ510069	TCATC31980	TRANSISTOR,SILICON
△Q508	BZ510077	TAAT012714	TRANSISTOR,SILICON
Q509	BZ510069	TCATC31980	TRANSISTOR,SILICON
△Q512	BZ510004	TA3T016240	TRANSISTOR,SILICON
△Q514	BZ510070	TCAT032034	TRANSISTOR,SILICON
Q601	BZ510105	TCAT03209Y	TRANSISTOR,SILICON
Q602	BZ510105	TCAT03209Y	TRANSISTOR,SILICON
Q603	BZ510109	TCAA3875SY	TRANSISTOR,SILICON
Q604	BZ510105	TCAT03209Y	TRANSISTOR,SILICON
Q605	BZ510109	TCAA3875SY	TRANSISTOR,SILICON
Q607	BZ510070	TCAT032034	TRANSISTOR,SILICON
Q610	BZ510109	TCAA3875SY	TRANSISTOR,SILICON
Q611	BZ510105	TCAT03209Y	TRANSISTOR,SILICON
Q613	BZ510109	TCAA3875SY	TRANSISTOR,SILICON
Q614	BZ510108	TAATA1504SY	TRANSISTOR,SILICON
Q709	BZ510108	TAATA1504SY	TRANSISTOR,SILICON
Q711	BZ510109	TCAA3875SY	TRANSISTOR,SILICON
Q712	BZ510109	TCAA3875SY	TRANSISTOR,SILICON
△Q801	BZ510091	TCA0042170	TRANSISTOR,SILICON
△Q802	BZ510091	TCA0042170	TRANSISTOR,SILICON
△Q803	BZ510091	TCA0042170	TRANSISTOR,SILICON
△Q810	BZ510100	TCATC3199Y	TRANSISTOR,SILICON
△Q811	BZ510100	TCATC3199Y	TRANSISTOR,SILICON
△Q812	BZ510100	TCATC3199Y	TRANSISTOR,SILICON
Q852	BZ510069	TCATC31980	TRANSISTOR,SILICON
Q853	AD300024	TCUT00752Y	TRANSISTOR,SILICON
Q854	BZ510069	TCATC31980	TRANSISTOR,SILICON
Q855	BZ510069	TCATC31980	TRANSISTOR,SILICON
Q856	BZ510069	TCATC31980	TRANSISTOR,SILICON
Q857	BZ510073	TAATA12660	TRANSISTOR,SILICON
Q858	AD300029	TAU0018370	TRANSISTOR,SILICON
Q859	AD300025	TCU0047930	TRANSISTOR,SILICON
Q901	BZ510108	TAATA1504SY	TRANSISTOR,SILICON
Q902	BZ510108	TAATA1504SY	TRANSISTOR,SILICON
Q1001	BZ510068	TNAAJ05003	COMPOUND TRANSISTOR
Q1503	BZ510109	TCAA3875SY	TRANSISTOR,SILICON
Q1504	BZ510109	TCAA3875SY	TRANSISTOR,SILICON
Q1507	BZ510109	TCAA3875SY	TRANSISTOR,SILICON
Q1508	BZ510109	TCAA3875SY	TRANSISTOR,SILICON
<b>COILS &amp; TRANSFORMERS</b>			
L301	BZ310041	02167F101J	COIL
L401	AD301644	021L75472J	COIL
L402	BZ310187	022100034A	COIL,LINEARITY
L403	AD301606	02DK000058	COIL,CHOKE
△L501	AD301124	029T000101	COIL,LINE FILTER

# ELECTRICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description
<b>COILS &amp; TRANSFORMERS</b>			
△L503	AE003003	028R270013	COIL,DEGAUSS
L601	AD301990	021LA6330J	COIL
L801	BZ310002	021673101K	COIL
L802	BZ310170	021673151K	COIL
L803	BZ310170	021673151K	COIL
L804	BZ310170	021673151K	COIL
L901	BZ310041	02167F101J	COIL
L1501	BZ310041	02167F101J	COIL
L1502	BZ310039	02167F220J	COIL
L1503	BZ310039	02167F220J	COIL
L1505	AD300613	02167F150J	COIL
L1508	BZ310041	02167F101J	COIL
L1510	AD300613	02167F150J	COIL
L1511	AD300613	02167F150J	COIL
L1512	BZ310183	021LA6220J	COIL
T401	BZ310189	0450190161	TRANS,HORIZONTAL DRIVE
△T501	AD301355	048140065S	TRANSFORMER,SWITCHING
<b>JACKS</b>			
J701	AE002759	060J431020	RCA JACK
J702	AE006074	063Q700011	JACK
J703	AE002759	060J431020	RCA JACK
J704	AE002761	060J411032	RCA JACK
J705	AE004756	060J401104	RCA JACK
J706	AE004758	060J401106	RCA JACK
J707	AE004757	060J401105	RCA JACK
J708	AE002759	060J431020	RCA JACK
△J801	AD301936	066F130021	SOCKET,CATHODE RAY,TUBE
△J1001	AE003431	060J131016	HEADPHONE JACK
<b>SWITCHES</b>			
SW101	BZ612010	0504101T34	SWITCH,TACT
SW102	BZ612010	0504101T34	SWITCH,TACT
SW103	BZ612010	0504101T34	SWITCH,TACT
SW104	BZ612010	0504101T34	SWITCH,TACT
SW105	BZ612010	0504101T34	SWITCH,TACT
<b>VARIABLE RESISTORS</b>			
VR401	BZ210218	V1K63H3BTE	VOLUME,SEMI FIXED
VR502	BZ210101	V1163H4BTC	VOLUME,SEMI FIXED
<b>P.C.BOARD ASSEMBLIES</b>			
PCB010	AE007262	A3N121J010K	PCB ASS'Y
PCB060	AE006336	A3N120J060K	PCB ASS'Y
PCB110	AE006337	A3N120J110K	PCB ASS'Y
PCB240	AE006338	A3N120J240K	PCB ASS'Y
<b>MISCELLANEOUS</b>			
B401	BZ310129	024HT03564	CORE,BEADS
B402	BZ310129	024HT03564	CORE,BEADS
B405	BZ310129	024HT03564	CORE,BEADS
B501	BZ310045	024AT03481	CORE,BEADS
B504	BZ310121	024HT03553	CORE,BEADS
B851	BZ310121	024HT03553	CORE,BEADS
B852	BZ310121	024HT03553	CORE,BEADS
B853	BZ310121	024HT03553	CORE,BEADS
BT001	AE005640	141R004016	BATTERY,MANGAN
BT002	AE005640	141R004016	BATTERY,MANGAN
△CD501	AE006077	1209615904	CORD,AC BUSH
CD801	BZ614457	06CU253901	CORD,CONNECTOR
CD802	AD302370	06CU275101	CORD,CONNECTOR
CD803	AE003007	06CU83036A	CORD,CONNECTOR
CD851	AD302371	06CU244701	CORD,CONNECTOR
CD852	AD301043	06CU232001	CORD,CONNECTOR
CP101	BZ614102	0694270139	CONNECTOR PCB SIDE
CP201	AE006332	069J130340	CONNECTOR PCB SIDE
△CP401	AE006075	069X460109	CONNECTOR PCB SIDE
△CP501	BZ614176	069S320419	CONNECTOR PCB SIDE
△CP502	BZ614283	069S420110	CONNECTOR PCB SIDE
CP507	BZ614444	069D01001A	CONNECTOR PCB SIDE
CP508	BZ614444	069D01001A	CONNECTOR PCB SIDE
CP803	AD301996	069S330010	CONNECTOR PCB SIDE
CP804	BZ614058	069W010010	CONNECTOR PCB SIDE
CP852	BZ614350	069S230629	CONNECTOR PCB SIDE
CP1001	AD301045	069S140419	CONNECTOR PCB SIDE
CP801A	BZ614276	067U005049	WIRE HOLDER

## ELECTRICAL REPLACEMENT PARTS LIST

Location No.	TSB P/N	Reference No.	Description
CP801B	AD300752	069S250629	CONNECTOR PCB SIDE
CP802A	AD301997	067U007029	WIRE HOLDER
CP802B	BZ614485	069S270629	CONNECTOR PCB SIDE
CP851A	BZ614334	067U004029	WIRE HOLDER
CP851B	AD301998	069S240629	CONNECTOR PCB SIDE
CP852B	BZ614349	067U003029	WIRE HOLDER
EL001	BZ614044	124120301A	EYE LET
EL002	BZ614043	124116281A	EYE LET
△F501	BZ614422	081PC6R305	FUSE
△FB401	AE003213	043227017F	TRANSFORMER,FLYBACK
FH501	AE002634	06710T0009	HOLDER,FUSE
FH502	AE002634	06710T0009	HOLDER,FUSE
OS101	AD301048	0773071001	REMOTE RECEIVER
△RY501	AE006070	0560X20118	RELAY
△SP1001	AE006333	070W546010	SPEAKER
△TH501	BZ410079	DF5EL3R0A0	DEGAUSS ELEMENT
TM101	AE003009	076R0GW020	TRANSMITTER
△TU001	AE006069	0163300018	RF UNIT
△V801	AE003010	098T270904	CRT W/DY
X101	AD302002	100CT8R005	CRYSTAL
X602	BZ613004	100CT3R505	CRYSTAL

**RESISTOR**

RC..... CARBON RESISTOR

**CAPACITORS**

CC.....	CERAMIC CAPACITOR
CE.....	ALUMI ELECTROLYTIC CAPACITOR
CP.....	POLYESTER CAPACITOR
CPP.....	POLYPROPYLENE CAPACITOR
CPL.....	PLASTIC CAPACITOR
CMP.....	METAL POLYESTER CAPACITOR
CMPL.....	METAL PLASTIC CAPACITOR
CMPP.....	METAL POLYPROPYLENE CAPACITOR

**TOSHIBA CORPORATION**

1-1, SHIBAURA 1-CHOME, MINATO-KU, TOKYO 105-8001, JAPAN