

This service manual is same at the TK-280(B51-8454-00) service manual with destination K, K3 and M with the exception of new destination, K2 and K4.



CONTENTS

| | |
|----------------------------------|------------|
| GENERAL | 2 |
| SYSTEM SET-UP | 2 |
| OPERATING FEATURES | 3 |
| REALIGNMENT | 11 |
| CIRCUIT DESCRIPTION | 16 |
| SEMICONDUCTOR DATA | 22 |
| DESCRIPTION OF COMPONENTS | 27 |
| PARTS LIST | 28 |
| EXPLODED VIEW | 34 |
| PACKING | 35 |
| ADJUSTMENT | 36 |
| TERMINAL FUNCTION | 44 |
| PC BOARD VIEWS | |
| DISPLAY UNIT (X54-3210-XX) | 45 |
| TX-RX UNIT (X57-5740-XX) | 51 |
| SCHMATIC DIAGRAM | 57 |
| BLOCK DIAGRAM | 61 |
| LEVEL DIAGRAM | 63 |
| OPTINONS | 64 |
| SPECIFICATIONS | BACK COVER |

Photo is K3 type with KRA-14

CAUTION

When using an external power connector, please use with maximum final module protection of 9V.

GENERAL / SYSTEM SET-UP

INTRODUCTION

SCOPE OF THIS MANUAL

This manual is intended for use by experienced technicians familiar with similar types of commercial grade communications equipment. It contains all required service information for the equipment and is current as of the publication data. Changes which may occur after publication are covered by either Service Bulletins or Manual Revisions. These are issued as required.

ORDERING REPLACEMENT PARTS

When ordering replacement parts or equipment information, the full part identification number should be included. This applies to all parts : components, kits, or chassis. If the part number is not known, include the chassis or kit number of which it is a part, and a sufficient description of the required component for proper identification.

PERSONNEL SAFETY

The following precautions are recommended for personnel safety:

- DO NOT transmit until all RF connectors are verified secure and any open connectors are properly terminated.

- SHUT OFF and DO NOT operate this equipment near electrical blasting caps or in an explosive atmosphere.
- This equipment should be serviced by a qualified technician only.

SERVICE

This radio is designed for easy servicing. Refer to the schematic diagrams, printed circuit board views, and alignment procedures contained within.

NOTE


WE CANNOT guarantee oscillator stability when using channel element manufactured by other than KENWOOD or its authorized agents.

FCC COMPLIANCE AND TYPE NUMBERS

| Type | Type acceptance number | Frequency range | Compliance |
|-------|------------------------|-----------------|-------------------|
| K,K3 | ALH24613110 | 146~174MHz | Parts 22,74,80,90 |
| K2,K4 | ALH24613120 | 136~162MHz | Parts 22,74,80,90 |

| Model & destination | Unit | | X54-3210-XX | | Frequency range | Remarks | QT/DQT | DTMF | Charger | Battery | 16 Keys |
|---------------------|-------------|------|-------------|------|-----------------|-----------------------------------|--------|------|---------|---------|---------|
| | X57-5740-XX | | 0-10 | 0-11 | | | | | | | |
| TK-280 | K, M | 0-10 | | 0-10 | 146~174MHz | IF1 : 44.85MHz LOC : 44.395MHz | ○ | - | OP | OP | - |
| | | 0-11 | | 0-11 | | | | ○ | | | ○ |
| | K3 | 0-10 | | 0-10 | 136~162MHz | | ○ | - | OP | OP | - |
| | | 0-11 | | 0-11 | | | | ○ | | | ○ |

SYSTEM SET-UP



OPERATING FEATURES

⑩ S, A, ◀ B, and C ▶ key (Programmable)

⑪ DTMF keypad (keypad model only)

Press the keys on the telephone keypad to send DTMF tones.

⑫ Universal connector

Connect the external KMC-25 speaker/ microphone (optional) here. Otherwise, keep the supplied cover in place.

* : MONITOR and LAMP are arbitrary names chosen for these buttons. They can be used for any of the auxiliary functions.

2-3. Programmable keys

The FPU (KPG-49D) enables programmable keys to select the following functions.

■ Trunking Format

Auto Tel, AUX(only when Voice Scrambler is not selected), Connect ID, Disconnect ID, Display Character, Emergency (only AUX key), Function, Group Down, Group Up, Home Group, Key Lock, Lamp, Memory (RCL/STO), Memory (RCL), Memory (STO), Monitor A, Monitor B, Monitor C, Monitor D, Redial, RF Power Lo, Scan, Scan Del/Add, Scan Temporary Delete, Scrambler (Only when Voice Scrambler is selected), System Down, System Up, TEL Disconnect and none.

■ Conventional Format

AUX(only when Voice Scrambler is not selected), Channel Down, Channel UP, Connect ID, Disconnect ID, Display Character, Emergency (only AUX key), Function, Group Down, Group Up, Home Channel, Key Lock, Lamp, Memory (RCL/STO), Memory (RCL), Memory (STO), Monitor A, Monitor B, Monitor C, Monitor D, Operator Selectable Tone, Redial, RF Power Lo, Scan, Scan Del/Add, Scrambler (Only when Voice Scrambler is selected), Talk Around and none.

These functions the FPU programs to the function keys are described in the following sections.

1) Auto TEL (Trunking Format)

Automatically connects available repeaters that are connected to telephone circuits when operating as LTR system. The time allocated to search for available repeaters is 60 seconds, after which connection failure occurs, a DTMF tone is output and the function terminates.

If connection to an available circuit is made, only ID 253, EOT or hang-up time-out can terminate the function.

2) AUX

This function can be programmed when the voice scrambler board is not installed.

If this key is pressed, an underscore (“_”) appears at the extreme right of the LCD and AUX port which is inside of the transceiver turns to the active level. If pressed again,

the underscore disappears and the AUX ports turns to the deactive level.

3) Channel up/down (Conventional Format)

When the key is pressed each time, the channel number to be selected is incremented/decremented and repeats if held for one second or longer.

This key works as the voice scrambler code selector in the voice scrambler code select mode.

4) Connect ID

Pressing this key in Conventional mode, automatically sends the preset Connect ID.

5) Disconnect ID

Pressing this key in Conventional mode, automatically sends the preset Disconnect ID.

6) Display character

• Trunking Format

This key switches the LCD display between the system/group number and system/group name.

• Conventional Format

This key switches the LCD display between the group/channel number and group/channel name.

7) Emergency

• Trunking Format

Pressing this key for longer than the programmed “Emergency Key Delay Time” causes the transceiver to enter the emergency mode. The transceiver jumps to the programmed “Emergency System/Group” and transmits for the programmed “Active Time”.

The transceiver disables mic mute while transmitting. After finishing transmission, the transceiver receivers for the programmed “Interval Time”. The transceiver mutes the speaker while receiving. Following the above sequence, the transceiver continues to transmit and receive.

• Conventional Format

Pressing this key for longer than the programmed “Emergency Key Delay Time” causes the transceiver to enter the emergency mode. The transceiver jumps to the programmed “Emergency Group/Channel” and transmits for the programmed “Active Time”.

The transceiver disables mic mute while transmitting. After finishing transmission, the transceiver receivers for the programmed “Interval Time”. The transceiver mutes the speaker while receiving. Following the above sequence, the transceiver continues to transmit and receive.

8) Function

Pressing this key causes the transceiver to display “FCN”. Then, pressing a DTMF key causes the corresponding programmed function to start. This key may be convenient when using many functions with the 12-key keypad (K3, K4 type).

OPERATING FEATURES

9) Group up/down

When the key is pressed each time, the group number to be selected is incremented/decremented and repeats if held for one second or longer. In Conventional format, this key works as the voice scrambler code selector in the voice scrambler code select mode.

10) Home Channel (Conventional Format)

Press this key once, the channel switches to the pre-programmed home channel.

11) Home group (Trunking Format)

Each pressing of the key selects a preset system/group.

12) Key lock

Pressing this key causes the transceiver to accept entry of only the [Function], [Key Lock], [PTT], [Lamp], [Monitor A], [Monitor B], [Monitor C], [Monitor D], and [Emergency] keys. The locked keys also include the tuning control.

13) Lamp

This key illuminates the LCD and keys on the front panel. When the key is pressed, the LED lamp goes on. When it is released, the lamp goes off after about five seconds. If any key is pressed while the LED lamp is on, the lamp is kept on for five seconds.

14) Memory

This key allows DTMF memory data to be recalled; up to 32 memories each with a memory dial of up to 16 digits and an A/N of up to 10 digits per memory.

15) Monitor

Used to release signalling or squelch when operating as a conventional. It is also used to reset option signalling.

16) Operator Selectable Tone (Conventional Format)

This key switches the pre-set decode QT/DQT and encode QT/DQT to OST (Operator Selectable Tone) tone pair. Press this key, the transceiver enters to OST select mode. In this mode, the display shows "OFF" and the operator can select one of the OST tone pair using the tuning control. The display shows "TONE **" and tone pair No. ** is selected.

Press OST key again, the transceiver exits from the OST select mode, and returns to the group/channel mode with the handset indicator (☞) means that the OST tone pair is selected. OST tone pair number or OFF can be memorized for each channel.

16 kinds of tone pair for OST can be programmed by KPG-49D. OST is useful to access the repeater with same radio frequency and different tone (QT/DQT).

17) Redial

Pressing this key when System/Group(trunking format), Group/Channel (Conventional Format) is shown, displays the

previously transmitted DTMF code. Pressing [PTT] at this time, transmits the code that is currently displayed.

18) RF power low

Used to temporarily switch transmission output to low power. Turning the function on enables:

Hi→Low, Low→Low

Key states are backed up, except in the PC mode when they are reset.

19) Scan

Press this key starts scanning. Pressing this key stops scanning.

20) Scan Del/Add

• Trunking Format

Used to select whether system scan routines are used during system scan. Each pressing of the key (to ON) toggles between lockout and lock. The scan routine is started when on lock. The DEL indicator flashes when the system is on lockout.

• Conventional Format

This key switches the currently displayed channel between "Delete" and "Add".

The "Add" channel contained in the scan sequence, and "Delete" channel is not contained. In the scan mode, this key switches the channel delete or add temporarily.

21) Scan temporary delete (Trunking Format)

This key is temporarily deleted a system being scanned. If you press this key when scan is stopped (when a call is being received from another station), the system is temporarily deleted and scanning restarts.

This key operates even when "Scan Type" is set to "List Type System Scan".

22) Scrambler

If a scrambler code (1 to 4) has been set in the FPU, an underscore ("_") appears at the extreme right of the LCD display when scrambler is active. Pressing this key changes ON/OFF of scramble operation.

Holding this key down for 2 seconds sets Scramble Code Select Mode

23) System up/down (Trunking Format)

When the key is pressed each time, the system number to be selected is incremented/decremented and repeats if held for one second or longer.

24) Talk Around (Conventional Format)

Press this key, the transceiver uses the receive frequency and the tone for transmission.

The operator can call the other party directory (without repeater). Press this key again, the talk around function goes off.

OPERATING FEATURES


25) Telephone disconnect (Trunking Format)

Pressing this key ends an RIC connection (disconnects the telephone line).

26) None

Sounds error operation beep, and no action will occur. Use this function when the transceiver is required to be more simple operated.

2-4. Display



① Sub display

Displays the system, channel and group numbers. Also displays various functions, such as TA.

② P (Priority) indicator

The P indicator (**P**) appears when a selected channel is programmed as priority, in conventional operation.

③ MON (Monitor) indicator

The MON indicator appears when the button programmed as MONITOR is pressed.

④ SVC (Service) indicator

This icon is not used on this transceiver.

⑤ SCN (Scan) indicator

The SCN indicator appears when using Scan mode.

⑥ LO indicator

Appears when low power is selected.

⑦ Handset indicator

The handset indicator (☞) appears when the selected group is programmed as telephone IDs. (Trunking Format) In Conventional Format, the handset indicator (☞) appears when the OST tone pair is selected.

⑧ MAIL indicator

This icon is not used on this transceiver.

⑨ Alphanumeric display

• Trunking Format

The twelve-character dot matrix alphanumeric display shows the system and group numbers. You can program system and group names with up to ten characters in place of these numbers. The left display is used as a delete indicator (▶) and the right is used for the selective call (⊘)

or scrambler (⊘) function. The delete/add indicator shows the systems locked out of the scanning sequence. Selective call and scrambler are optional functions that can be programmed.

• Conventional Format

The twelve-character dot matrix alphanumeric display shows the group and channel numbers. You can program group and channel names with up to ten characters in place of these numbers. The left display is used as an add indicator (▼) and the right is used for the selective call (⊘) or scrambler (⊘) function. The add indicator shows the channels unlocked out of the scanning sequence. Selective call and scrambler are optional functions that can be programmed.

3. Scan Operating

3-1. In Case of Trunking Format

1) System scan

System scan can be selected with the “Scan” key by programming the scan feature. When the “Scan” key is pressed and the “SCN” mark appears, scan mode is entered. Scanning starts from the system following the currently displayed system. When a call is received, scanning stops, and the system and group are displayed.

When the system knob or programming key is touched during scanning, the scan stops and the revert system or group can be changed. Scanning resumes one second after the key is released.

System Scan consists of the following 2 types.

• Fix system scan

All the set systems except locked-out ones are scanned. If the DEL/ADD feature is assigned to the programmable key, it can be controlled from the front panel.

• List type system scan

A scan list can be set for each system.

The list to be scanned can be changed by changing the display system

If many system have been set, the scan speed can be increased by narrowing the systems to be scanned with scan lists.

2) System lockout

The system lockout feature is used to lock systems out of the scan sequence, and can be selected by programming in the following two ways:

• Fixed lockout

The system to be locked out is selected by programming. When a locked system is selected, the Delete (▶) indicator appears on the left of the SYSTEM indicator. The revert system is scanned even if it is locked out. If there is a locked system, the Delete (▶) indicator flashes during fixed scanning.

OPERATING FEATURES

- **User selectable lockout**

If the scan lockout feature is programmed to a key, the user can lock systems out of the scan sequence with the key. To lock a system out of the scan sequence, press the key when the system is displayed. The Delete (▶) indicator is displayed on the left of the SYSTEM indicator.

To unlock a system, select the system and press the key. The Delete (▶) indicator disappears to indicate that the system has returned to the scan sequence. The revert system is scanned even if it is locked out. If there a locked system, the Delete (▶) indicator flashes during fixed scanning. If all systems are locked out, the scan stops and only the revert system is received.

3) Drop-out delay time (Scan resume time)

If a call is received during scan, the scan stops. The scan resume time can be programmed as 0 to 300 seconds in one-second increments. The default value is 3 seconds.

4) Dwell time

The dwell time is the time after transmission ends until the scan resumes in scan mode. It can be set 0 to 300 seconds by programming. The default value is 3 seconds.

5) System/Group revert

System/Group revert can be programmed for one of the following;

- **Last called revert**

The system or group changes to the revert system or group when a call is received with the system or group being scanned.

- **Last used revert**

If a system/group call is received during scanning and the PTT button is pressed for transmission and response within the drop out delay time, the system or group is assigned as the new revert system or group.

- **Selected revert**

If the system/group was changed while scanning, the newly selected system/group.

6) Scan message wait

The time for staying with the home repeater that receives a signal during system scan and monitoring data messages can be programmed. If there is no signal from the home repeater, the system is scanned for about 50ms. If there is a signal, three data messages are monitored. Normally, three data messages are monitored for each system, and it can be increased in multiples of three data messages per line to up to eight lines.

If the repeater data message indicates that there is no call, data monitoring is terminated and the home repeater of the next system is scanned.

7) Group scan operation

Group scan can be programmed for each group. In addition to the ID codes of the selected group, the ID codes of the other groups that are permitted for group scan are decoded. (The two fixed ID and block decode codes are always decoded.)

If, during group scanning, a call is received with one of the selectable group ID codes for which group scan is enabled, the group display indicates the group number that the call came in with. That group then becomes the new selected group. Group scan resumes after the specified dropout delay time or dwell time shared by the system scan elapses.

8) In Conventional system.

If QT or DQT is set for the channel, the channels, including signalling, are scanned.

In case of the priority group is set in conventional system, if a group scan (including group scan during a system scan) temporarily stops (receiving) in a group that does not have priority, a look back is performed to the priority group. Look back is performed according to the look back time A and B settings. If a call is received on the priority group, reception immediately switches to the priority group.

3-2. In Case of Conventional Format

1) Scan types

- **Single Group Scan**

You can scan all valid (ADD) channels in the displayed group that can be selected with the group selector.

- **Multiple Group Scan**

You can scan all valid (ADD) channels in the all valid (ADD) group.

2) Scan Start Condition

One or more non-priority channels must be added to all channels that can be scanned. The transceiver must be in normal receive mode (PTT off).

When you activate the key programmed to the scan function, the scan starts. The scan icon "SCN" lights and "-SCAN-" or revert channel (programmable) is indicated on alphanumeric display.

3) Scan Stop Condition

The scan stops temporarily if the following conditions are satisfied.

- ① A carrier is detected, then signalling matches on channels for which receive the signalling is set by the programming software.
- ② A carrier is detected on the channel for which receiving signalling is not set by the programming software or when the monitor (signalling cancel) function is activated.

4) Scan Channel Types

- ① Priority channel is the most important channel for the scan, and always detects a signal during scan and when the scan stops temporarily.

OPERATING FEATURES

- ② Non-priority channels detects a signal during scan. For the channels that can be selected with the group or channel selector when the scan does not occur, adds an indicator “▼” lights.

5) Priority Channel Setting

A priority channel can be set as follows with the programming software (KPG-49D).

- ① Specify a priority channel as a fixed priority channel.
- ② Make a selected channel a priority channel.

6) Scan Type According to the Priority Channel

- ① When no priority channel is set : Only the non-priority channels are scanned.
If a non-priority channel stops temporarily, it stops until there is no signal on the channel.
- ② When priority channel is set : Either priority channel is scanned.
If a non-priority channel stops temporarily, a priority channel signal is detected at certain intervals.
If a priority channel stops temporarily, it stops until there is no signal on the priority channel.

7) Revert Channel

The revert channel is used to transmit during scanning and set by the programming software (KPG-49D).

- ① Priority
The transceiver reverts to the priority channel
- ② Priority with talkback
The transceiver reverts to the priority channel.
If you press PTT during a resume timer (dropout delay time, TX dwell time) or calling, you can transmit on current channel to answer to the call however revert channel is set to priority channel.
After resume time, scan re-starts and transmission channel is return to priority channel.
- ③ Selected channel
The transceiver reverts to the channel before scanning or the channel that you changed during scan.
- ④ Last called channel
The transceiver reverts to the last called channel during the scan.
- ⑤ Last used channel
The transceiver reverts to the last used (transmitted) channel during scan. “Last used” revert channel includes talkback function.
- ⑥ Selected with talkback
The transceiver reverts to the channel before scanning or the channel that you changed during scan.

8) Scan End

When you reactivate the key programmed to the scan function during scan mode, the scan ends.

The scan icon “SCN” and “-SCAN-” or revert channel (programmable) display goes off.

9) Temporarily Delete/Add

It is possible to delete or add channel temporarily during scan. When scan stops on unnecessary channel for example by interference of the other party, activate the delete/add function (for example press the key), then that channel is deleted temporarily and scan re-start immediately.

When you would like to add the deleted channel temporarily to scan sequence, select the desired (deleted) channel during scan, activate the delete/add function (for example press the key) before scan re-start.

That channel is added temporarily to scan sequence. The temporary deleted or added channels are returns to pre-set delete/add, when the transceiver exits from scan mode.

4. Details of Features

4-1. In Case of Trunking Format/Conventional Format

1) Time-out timer

The time-out timer can be programmed in 15 seconds increments from 15 seconds to ten minutes. If the transmitter is keyed continuously for longer than the programmed time, the transmitter is disabled and a warning tone sounds while the PTT button is held down. The alert tone stops when the PTT button is released.

2) Sub LCD

You can use 3-digit the display to display the system number, channel number or group number. It is useful when the main (12-digit) display indicates system, group or channel name or other functions.

3) Selective Call Alert LED

You can select whether or not the LED on the transceiver flashes in an orange color when selective call was occurred.

4) PTT ID

PTT ID provides a DTMF ANI to be sent with every time PTT (connect ID at beginning of transmission, disconnect ID at end of transmission, or both).

You can program PTT ID "on" or "off" for each group channel. The contents of ID are programmed for each transceiver.

The transceiver is capable to have ID. The format is DTMF. The timing that the transceiver sends ID is programmable.

Connect ID : Connect ID is sent on beginning of transmission.

Disconnect ID : Disconnect ID is sent on end of transmission.

Both : Connect ID is sent on beginning of transmission and disconnect ID is sent on end of transmission.

There is also "PTT ID" setting for each channel.

5) Radio password

When the password is set in the transceiver, user can not use the transceiver unless enter the correct password.

This code can be up to 6 digits from 0 to 9 and input with the keypad or selector, and “S” key.

OPERATING FEATURES

6) Battery Warning

This transceiver has battery warning feature. If the low voltage is detected during transmission, the transceiver warns it by flashing red "LED".

Then more low voltage is detected during transmission, the transceiver stops transmission and warns it by flashing red "LED" and beep.

Please notice "standard" for the battery exchange, charging time by flashing red LED and beep.

7) Minimum Volume

The minimum volume is programmable (off (0) to 31). The transceiver remains the minimum volume level however the mechanical volume position is set to zero.

4-2. In Case of Trunking Format

1) Call indicator

The call indicator can be programmed for each group. In trunked system, it can be set to respond to a selectable decode ID or one of two fixed IDs, except block IDs. When a call is received with a selectable decode ID, the call indicator flashes. When a call is received with a fixed ID, the call indicator lights continuously.

On a conventional system, the call indicator can be programmed to light for each QT or DQT code. It keeps flashing while a call is being received. It is turned off by pressing any front panel key.

2) Free system ringback

This feature is available only when a telephone interconnected ID code is selected. If a busy tone sounds when the PTT button is pressed, the transceiver enters this mode automatically.

When the PTT button is released, a beep sounds for 400ms to indicate that the mode has been entered. If the scan is on, it is resumed (the "SCN" mark goes on). When any repeater becomes available, a ringing tone sounds and this mode ends.

The mode is terminated when the system, group, scan, PTT, key is changed.

3) System search

This feature can be programmed to automatically access other programmed systems when the selected system cannot be accessed. If an intercept tone sounds when the PTT button is pressed after setting the mode, the transceiver has entered the mode.

If the group ID is a telephone interconnect ID, the transceiver then attempts to access, in succession, other systems that have a telephone interconnect ID in the revert group location. If the group ID is a dispatch ID, the transceiver attempts to access other systems that have a dispatch ID programmed in the revert group location.

If there is no system to be accessed, an intercept tone sounds, the mode is terminated, and the transceiver returns to the first system. If the access is successful, the mode is terminated, and the searched system becomes the new

selected system (If during scanning, the scan stops).

4) Transpond

This feature can be programmed to turn on and off for each group. If the ID of the group for which transpond is enabled is received, two data messages (transmit ID and turn-off code) are automatically transmitted if the PTT button is not pressed as a response within the time set (0 to 300 seconds in 1-second increments). If the PTT button is pressed within the time, the transpond is not preformed.

5) Transmit inhibit

The transceiver can be programmed with a transmit inhibit block of ID codes. If an ID code within this block is decoded the preset time before the PTT button is pressed, transmission is inhibited. The BUSY indicator lights and a busy tone sounds until the PTT button is released to indicate that transmission is not possible (except clear-to talk mode).

Transmission with the group for which the encode ID is not set is inhibited, and the busy tone is output while the PTT button is held down, regardless of the clear-to -talk setting.

6) Auto TEL

A telephone interconnect call can be made by simply pressing the key by assigning this feature to the key. This feature accesses the TEL channel of the available system automatically.

When the key is pressed, a queue tone is output, and the "AUTO TEL" appears on the alphanumeric display along with a flashing handset indicator (☎) to indicate that this mode has been entered. If the TEL ID is set for the revert system, the TEL channel of that system is accessed. If all TEL channels are busy, an attempt is made to access the TEL channels of another system in which the TEL ID code has been programmed. It is repeated for 60 seconds until the access succeeds. If the access succeeds, a dial tone returns from the repeater. If the key is pressed again when the queue tone is sounding, this mode is canceled.

If the access fails after 60 seconds, a deny tone is output and this mode is terminated. When the talk ends, the revert system/group returns. When the scan mode is effective, the scan resumes. The Auto TEL feature can be programmed to turn on or off for each system.

4-3. In Case of Conventional Format

1) "TOT" Pre-Alert

The transceiver has "TOT" pre-alert timer. This parameter selects the time at which the transceiver generates "TOT" pre-alert tone before "TOT" is expired.

"TOT" will be expired when the selected time passes from a TOT pre-alert tone.

2) "TOT" Re-Key Time

The transceiver has "TOT" re-key timer. This timer is the time you can not transmit after "TOT" exceeded. After "TOT" re-key time expired you can transmit again.

OPERATING FEATURES

3) "TOT" Reset Time

The transceiver has "TOT" reset timer. This timer is the minimum wait time allowed during a transmission that will reset the "TOT" count.

"TOT" reset time causes the "TOT" to continue even after PTT is released unless the "TOT" reset timer has expired.

4) OST (Operator Selectable Tone)

The transceiver is capable to have "OST" function and 16 tone pair (QT/DQT) with max 10-digit name for each tone pair.

- **"OST" Back Up**

The transceiver is programmable the selected "OST" code is memorized or not. If you set to Disable (no memorized), the "OST" function always starts at "off".

- **Direct "OST"**

It is possible to call "OST" number directory using keypad. In this case, keypad is used for "OST", then "Auto PTT" "Store & Send" functions by keypad are not usable.

5) Clear to Transpond

The transceiver waits the transpond of 2-Tone/DTMF if channel is busy until channel open. This feature prevents the interference to other party.

6) Battery Save

This is the automatic battery saver during a standby mode operation. The receiver circuit is repeated on and off to conserve the battery life.

5. Option Signalling (DTMF/2 tone)

Built-in DTMF decoder is available for option signalling.
Built-in 2-Tone decoder is available for option signalling.

It is possible to use individual call, group call, DBD (Dead Beat Disable). **Note** : DBD is only DTMF.

Preset operation is triggered when matches with Option Signaling

When Option Signaling matches on a Group Channel where set to Yes, the Option Signaling display flashes and Option Signaling is canceled. Settings after this will cause "Transpond" or "Alert" to sound.

Setting the Selective Call Alert LED will make an orange LED start flashing.

Mute or Unmute is triggered by the ID/QT/DQT/Carrier when option signaling is a match (when Option Signal is deactivated by a transmission).

AND/OR

Option Signaling match conditions can be selected with AND/OR logic.

| | Alert/Transpond | AF Mute Open |
|-----|--|---|
| AND | Triggers at match with QT/DQT/ID+DTMF(2tone);Both | Triggers at match with QT/DQT/ID+DTMF(2tone);Both |
| OR | LTR Format→ Triggers at match with QT/DQT/ID+DTMF :Both Conventional Format → Triggers only for match with DTMF (2tone) : Opt | Triggers only for match with QT/DQT/ID;Signaling |

Even if set for OR, AF mute cannot be canceled just by a match with DTMF.

In conventional channels not set with QT/DQT, signaling is a match just by receiving the carrier.

Auto Reset

When Option Signaling matches on a Group channel where set to Yes, Option Signaling is canceled when it matches a group channel set to Yes.

After Option Signaling is a match, Option Signaling can automatically set to Reset after a specified time.

Dead Beat Disable

When the D.B.D (Dead Beat Disable) code is a match, a preset operation is performed.

When D.B.D matches on all group channels regardless of whether Option Signaling = Yes/No, then TX Inhibit or TX RX Inhibit is activated by settings performed afterwards. D.B.D is canceled when the D.B.D. code + "#" is received.

Transpond is always activated when the D.B.D code is a match. Alert is not output. An Option Signaling match is not displayed.

6. Audible user feedback tones

The transceiver outputs various combinations of tones to notify the user of the transceiver operating state. The main tones are listed below

The high tone is 1477Hz, the mid tone is 941Hz, and the low tone is 770Hz.

- **Power on tone**

This tone is output when the transceiver is turned on. (The high tone is output for 500ms.)

- **Alert tone**

This tone is output when the transceiver is TX inhibition for TOT, battery warning and PLL unlocked. It is output until the PTT button is released. (The 697Hz tone is output.)

- **Busy Tone**

In trunked mode (of trunking format) the busy tone informs the user when the repeater cannot be used (System busy or TX inhibit status).

In conventional mode (of conventional format), this informs the user of a Busy Channel Lockout.

OPERATING FEATURES/REALIGNMENT

- **Group Call Tone**

The group call tone informs the user of a group call in DTMF/2Tone Option Signaling. This tone repeats 7 times.

| | | |
|-------|------|-------|
| 770Hz | | 770Hz |
| 30ms | 30ms | 30ms |

- **Individual Tone**

Individual tone is issued on receiving selective call by DTMF/2 Tone Option Signaling.

| | | | | |
|--------|-------|--------|-------|--------|
| 2000Hz | | 2000Hz | | 2000Hz |
| 100ms | 100ms | 100ms | 100ms | 100ms |

- **Intercept tone (Trunking Format)**

This tone indicates that the transceiver is out of range. It indicates that the PTT button is pressed, and transmission has started, but the repeater cannot be connected and talking is not possible. It is output until the PTT button is released. (The mid tone and low tone are output alternately in 200ms intervals.)

- **Delay tone (Trunking Format)**

This tone is output when the PTT button is pressed and the repeater is accessed three times or more to indicate connection with the repeater is delayed. This tone is the same as the busy tone. (It is not output of CLEAT TO TALK has been set to YES.)

- **Proceed tone (Trunking Format)**

This tone is output when the PTT button is pressed, transmission starts, and the repeater is connected to indicate that the user can talk if the Clear-to-talk function has been set. (The high tone is output for 100ms.)

- **Queue tone (Trunking Format)**

This tone is output until the Auto TEL function is set and the TEL channel is accepted successfully. (The mid tone on for 50ms, off for 50ms, and on for 50ms in 1 second intervals.)

- **Deny tone (Trunking Format)**

This tone is output if the Auto TEL function is set, the queue tone is output, but the TEL channel cannot be accessed within 60 seconds. It is similar to the intercept tone. (The mid tone and low tone are output alternately in 150ms intervals.)

- **Free system ringback mode tone, system search mode tone (Trunking Format)**

This tone indicates that the transceiver is free system ringback mode or system search mode. (The low tone is output for 400ms.)

- **Ring tone (Trunking Format)**

This tone indicates that the transceiver can use the repeater in free system ringback mode. (The mid tone and no tone are output eight cycles alternately in 50ms intervals.)

- **Pre Alert tone (Conventional Format)**


Informs user when nearing transmit inhibit (transmit cutoff) time due to TOT.

The Pre Alert Tone is issued from the time set for TOT Pre Alert until the TOT triggers.

| | | | | |
|--------|------|--------|------|--------|
| 1633Hz | | 1633Hz | | 1633Hz |
| 50ms | 50ms | 50ms | 50ms | 50ms |

REALIGNMENT

1. Modes



| Mode | Function |
|---|--|
| User mode | For normal use. |
| Panel test mode | Used by the dealer to check the fundamental characteristics. |
| Panel tuning mode | Used by the dealer to tune the radio. |
| PC mode | Used for communication between the radio and PC (IBM compatible). |
| Data programming mode | Used to read and write frequency data and other features to and from the radio. |
| PC test mode | Used to check the radio using the PC. This feature is included in the FPU. See panel tuning. |
| Firmware programming mode | Used when changing the main program of the flash memory. |
| Clone mode | Used to transfer programming data from one radio to another. |
| Self programming mode (Conventional Format) | Frequency, signalling and features write to the radio. |

REALIGNMENT

2. How to Enter Each Mode

| Mode | Operation |
|--|----------------------------------|
| User mode | Power ON |
| Panel test mode | [A]+Power ON (Two seconds) |
| PC mode | Received commands from PC |
| Panel tuning mode | [Panel test mode]+[S] |
| Firmware programming mode | [S]+Power ON (Two seconds) |
| Clone mode | [C]+Power ON (Two seconds) |
| Self programming mode (Conventional Format) | [LAMP]+Power ON (Two seconds) |

3. Panel Test Mode

Setting method refer to ADJUSTMENT.

4. Panel Tuning Mode

Setting method refer to ADJUSTMENT.

5.PC Mode

5-1. Preface

The TK-280 transceiver is programmed by using a personal computer, programming interface (KPG-36) and programming software (KPG-49D).

The programming software can be used with an IBM PC or compatible. Figure 1 shows the setup of an IBM PC for programming.

5-2. Connection procedure

1. Connect the TK-280 to the personal computer with the interface cable.
2. When the POWER switch on, user mode can be entered immediately. When PC sends command the radio enter PC mode, and "PROGRAM" is displayed on the LCD. When data transmitting from transceiver, the red LED is blinking. When data receiving to transceiver, the green LED is blinking.

Notes:

- The data stored in the personal computer must match model type, when it is written into the flash memory.
- Change the TK-280 to PC mode, then attach the interface cable.

5-3. KPG-36 description

(PC programming interface cable: Option)

The KPG-36 is required to interface the TK-280 to the computer. It has a circuit in its D-subconnector (25-pin) case that converts the RS-232C logic level to the TTL level.

The KPG-36 connects the universal connector of the TK-280 to the computers RS-232C serial port.

5-4. Programming software description

The KPG-49D programming disk is supplied in 3-1/2" disk format. The software on this disk allows a user to program TK-280 radios via programming interface cable (KPG-36).

5-5. Programming with IBM PC

If data is transferred to the transceiver from an IBM PC with the KPG-49D, the destination data (basic radio information) for each set can be modified. Normally, it is not necessary to modify the destination data because their values are determined automatically when the frequency range (frequency type) is set.

The values should be modified only if necessary. Data can be programmed into the flash memory in RS-232C format via the universal connector.

KPG-49D instruction manual parts No. : B62-1096-XX




Fig. 1

6. Firmware Programming Mode

6-1. Preface

Flash memory is mounted on the TK-280. This allows the TK-280 to be upgraded when new features are released in the future. (For details on how to obtain the firmware, contact Customer Service.)

6-2. Connection procedure

Connect the TK-280 to the personal computer (IBM PC or compatible) with the interface cable (KPG-36). (Connection is the same as in the PC Mode.)

6-3. Programming

1. Start up the programming software (KPG-49D), select "firmware program" in the "Program" item, and press the Return key on the personal computer. This starts up the firmware programmer.
2. The top screen is displayed. Press any key to advance to the next screen.
3. Set the communications speed (normally, 57600 bps) and communications port in the Setup item.
4. Set the firmware to be updated by File select (=F1).
5. Turn the TK-280 power ON with the [S] switch held down. Hold the switch down for two seconds until the display changes to "PROG 57600". When "PROG 57600" appears, release your finger from the switch.
6. Check the connection between the TK-280 and the personal computer, and make sure that the TK-280 is in the Program mode.
7. Press F10 on the personal computer. A window opens on the display to indicate progress of writing. When the TK-

REALIGNMENT

280 starts to receive data. the [P] icon is blinking.

- If writing ends successfully. the LED on the TK-280 lights and the checksum is displayed.
- If you want to continue programming other TK-280 s, repeat steps 5 to 8.

Notes:

- To start the Firmware Programmer from KPG-49D, the Fpro path must be set up by KPG-49D Setup.
- This mode cannot be entered if the Firmware Programming mode is set to Disable in the Programming software (KPG-49D).
- When programming the firmware, it is recommend to copy the data from the floppy disk to your hard disk before update the radio firmware.
Directry copying from the floppy disk to the radio may not work because the access speed is too slow.

6-4. Function

- If you press the [MON] switch (top of left side) while "PROG 57600" is displayed, the checksum is displayed. If you press the [MON] switch again while the checksum is displayed, "PROG 57600" is redisplayed.
- If you press the [LAMP] switch (bottom of left side) while "PROG 57600" is displayed, the display changes to "PROG 19200" to indicate that the write speed is low speed (19200 bps). If you press the [LAMP] switch again while "PROG 19200" is displayed, the display changes to "PROG 38400", and the write speed becomes the middle-speed mode (38400 bps). If you press the [LAMP] switch again while "PROG 38400" is displayed, the display returns to "PROG 57600".

Note:

Normally, write in the high-speed mode.

7. Clone Mode

Programming data can be transferred from one radio to another by connecting them via their external universal connectors. The operation is as follows (the transmit radio is the master and the receive radio is a slave).

- Turn the master TK-280 power ON with the [C] key held down. If the password is set to the TK-280, the TK-280 displays "CLONE LOCK". If the password is not set, the TK-280 displays "CLONE MODE".
- When "CLONE LOCK" is displayed, only the knob (encoder) and [S], and [0] to [9] keys can be accepted. When you enter the correct password, and "CLONE MODE" is displayed, the TK-280 can be used as the cloning master. The following describes how to enter the password.
- How to enter the password with the keypad;
If you press a key while "CLONE LOCK" is displayed. the number that was pressed is displayed on the TK-280. Each press of the key shifts the display in order to the left. When

you enter the password and press the [S] key, "CLONE MODE" is displayed if the entered password is correct. If the password is incorrect, "CLONE LOCK" is redisplayed. How to enter the password with the encoder;
If the encoder is rotated while "CLONE LOCK" is displayed, numbers (0 to 9) are displayed flashing. When you press the [S] key, the currently selected number is determined. If you press the [S] key after entering the password in this procedure, "CLONE MODE" is displayed if the entered password is correct. If the password is incorrect, "CLONE LOCK" is redisplayed.

- Power on the slave TK-280.
- Connect the cloning cable (No. E30-3325-05) to the universal connectors on the master and slave.
- Press the [S] key on the master while the master displays "CLONE MODE". The data of the master is sent to the slave. While the slave is receiving the data, "PROGRAM" is displayed. When cloning of data is completed, the master displays "END", and the slave automatically operates in the User mode. The slave can then be operated by the same program as the master.
- The other slave can be continuously cloned. When the [S] key on the master is pressed while the master displays "END", the master displays "CLONE MODE". Carry out the operation in step 4 to 6.

Note:

Only the same models can be cloned together.




Fig. 2

8. Self Programming Mode

Write mode for frequency data and signalling etc. Mainly used by the person maintaining the user equipment.

8-1. Enter to the self programming mode

Delete R134 (SELF, Figure 3) in the TX-RX unit and turn the power switch on while pressing the [LAMP] key. When enter the self programming mode, "SELF PROG" is displayed.

Note :

This mode (self programming mode) cannot be set when it has been disabled with the FPU.

REALIGNMENT




Fig. 3

8-2. Channel Setting Mode

This is a mode for making channel settings with the panel keys without using the FPU.

Pressing [MON] when [SELF PROG] is displayed, sets Channel Setting Mode.

Select an item set with [C] and change the selection with the encoder.


The data displayed with [B] is stored in the memory and then proceeds to the next item. Pressing [C] proceeds to the next item without storing it in the memory.

Press [MON] to set the display to [SELF PROG] and return to reset (default) status.

Items set in Channel Setting Mode are as follows.

| Function settings | Display | Remarks |
|----------------------|-----------|---|
| Channel select | CH or GRP | |
| RX Frequency | RXF | [LAMP] : Freq. On/Off switching [A] : 2.5kHz/5kHz/6.25kHz/7.5kHz/1MHz step switching |
| RX Signalling | RXS | [LAMP] : OFF/QT/DQT switching [A] : 1 step/Standard switching [S] : DQT Normal/Invert switching |
| TX Frequency | TXF | Key operation same as RX Frequencies |
| TX Signalling | TXS | Key operation same as RX Signalling |
| Scan Del/Add | SCN | Delete/Add |
| Busy Channel Lockout | BSY | YES/NO |
| RF Power | PWR | HIGH/LOW |
| Beat Shift | SFT | YES/NO |
| Wide/Narrow | W/N | Wide/Narrow |

• Flow Chart



REALIGNMENT

8-3. Function Setting Mode

This is a mode for using the panel keys to make function settings without using the FPU, that operate on all channels.

Pressing the [LAMP] when [SELF PROG] is displayed, sets the Function Setting Mode.


Select an item set with [C] and change the selection with the encoder.

Press [LAMP] to display [SELF PROG] and return to reset (default) status.

Items set in Function Set Mode are as follows.

| Function settings | Display | Remarks |
|-------------------|---------|--|
| [A] | A | Key Function |
| [B] | B | Key Function |
| [C] | C | Key Function |
| [LAMP] | LAMP | Key Function |
| [S] | S | Key Function |
| [MON] | MON | Key Function |
| [AUX] | AUX | Key Function |
| [KNOB] | KNB | Knob Function |
| T.O.T | TOT | ON/OFF at T.O.T all settings ON:TOT[60s]/Pre-Alert[10s]/ Rekey Time[5s]/Reset Time[5s] OFF:TOT[600s]/Pre-Alert[Off]/ Rekey Time[Off]/Reset Time[Off] |
| Beep | BEP | ON/OFF at BEEP all settings ON:Power On Tone[On]/ Control Tone[On]/Warning Tone[On] OFF:Power ON Tone[Off]/ Control Tone[Off]/ Watning Tone[Off] |
| Battery Save | BAT | OFF/SHORT/MEDIUM/LOG |

• Flow Chart



8-4. Memory Reset Mode

This mode is used to clear data for functions that can be set in Self Programming Mode or to return to reset values (default).

Pressing [S] when [SELF PROG] is shown, sets the display to [CLEAR NO?].

Turning the encoder alternately switches the display between [CLEAR NO?] ←→ [CLEAR YES?].

Pressing [S] when [CLEAR YES?] is shown, clears the data and sets the display to [ALL CLEAR].

Pressing [S] again, returns the display to [SELF PROG].

Pressing [S] when [CLEAR NO?] is shown, returns the display to [SELF PROG] without resetting the data.

CIRCUIT DESCRIPTION

1. Overview

This transceiver is VHF/FM portable transceiver designed to operate in the frequency range of 146 to 174MHz (K, K3, M) and 136 to 162MHz (K2, K4).

2. Circuit Configuration by Frequency

The receiver is a double-conversion superheterodyne with a first intermediate frequency (IF) of 44.85MHz and a second IF of 455kHz. Incoming signals from the antenna are mixed with the local signal from the PLL to produce the first IF of 44.85MHz.

This is then mixed with the 44.395MHz second local oscillator output to produce the 455kHz second IF. This is detected to give the demodulated signal.

The transmit signal frequency is generated by the PLL VCO, and modulated by the signal from the microphone. It is then amplified and sent to the antenna.




Fig. 1 Frequency configuration

3. Receiver System

3-1. RF unit

An incoming RF signal from the antenna terminal is passed through the antenna switch (D12, D14, and D22 are off) and then the bandpass filter (L43,44,46,47,48). The bandpass filter is adjusted by a variable capacitor. The input voltage to the variable capacitor is regulated by the voltage output from the

D/A converter (IC8). The signal is amplified by RF amplifier (Q24), and passed through the bandpass filter (L31,33) and band-eliminate filter (L27,29) to remove the spurious signal again. The resulting signal is applied to the first mixer (IC18), where it is mixed with the first local oscillator signal output from the frequency synthesizer to produce the first IF (44.85MHz). The 1st mixer uses the GaAs IC.

3-2. IF unit

The first IF signal is passed through a four-pole monolithic crystal filter (XF1) to remove an adjacent channel signal. The filtered first IF signal is amplified by the first IF amplifier (Q12) and then applied to the IF system IC (IC12). The IF system IC provides a second mixer, second local oscillator, limiting amplifier, quadrature detector and RSSI (Received Signal Strength Indicator). The second mixer mixes the first IF signal with the 44.395MHz of second local oscillator output (crystal unit X2) and produces the second IF signal of 455kHz.

The second IF signal is passed through the ceramic filter (CF1; Wide, CF2 ; Narrow) to more remove the adjacent channel signal. The filtered second IF signal is amplified by the limiting amplifier and demodulated by the quadrature detector with ceramic discriminator (CD1). The demodulated signal is routed to the audio circuit.

3-3. Wide/Narrow changeover circuit

Narrow and Wide settings can be made for each channel by switching the ceramic filters CF1 (Wide), CF2 (Narrow).

The WIDE (high level) and NARROW (low level) data is output from IC19 (microcomputer) pin 99.

When a WIDE (high level) data is received, Q6 turn off and Q7 turn on. When a NARROW (low level) data is received, Q6 turn on and Q7 turn off. D5, D7 are switched to ceramic filters when a high/low level data is received.

Q9 turns on/off with the Wide/Narrow data and the IC12 detector output level is changed to maintain a constant output level during wide or narrow signals.




Fig. 2 Receiver section

CIRCUIT DESCRIPTION




Fig. 3 Wide/Narrow changeover circuit

3-4. Audio amplifier circuit

The demodulated signal from IC12 goes through the mute switch (Q15) and is amplified by IC4 (2/2), high-pass filtered, low-pass filtered, high-pass filtered, band-eliminate filtered, and de-emphasized by IC13.

The signal then goes through an AF amplifier IC7 (2/2), an electronic volume control (IC8), and an AF switch (Q310 is on), and is routed to audio power amplifier (IC300), where it is amplified and output to the internal speaker.

The audio mute signal (AM) from the shift register becomes Low in the standby and Q304, Q305 which are power supply circuit for IC300 turn off. Also, IC13 is set to the power down mode according to data from microprocessor, and the AF signal is muted. When the audio is output, AM becomes High to turn Q304, Q305 ON, and voltage is supplied to power terminal VP of IC300. Also, IC13 is canceled out of the power down mode.

The speaker is switched by the logic of speaker switching terminal SSW on the universal connector. When SP-MIC is not attached, the logic of SSW becomes High and SW (Q310) is turned ON, and the AF signal is input to both amplifiers of IC300.

When SP-MIC is attached, SSW is connected to GND at inside of SP-MIC. For this reason, Q310 is turned OFF, and the AF signal is input only to amplifier for EXT SP of IC300.

Change of INT/EXT SP refer to Fig. 4.

| AM | SSW | VC1 | VC2 | SP |
|----|-----|-----|-----|------|
| H | H | H | L | INT |
| H | L | L | H | EXT |
| L | H | L | L | MUTE |
| L | L | L | L | MUTE |




Fig. 4 Audio amplifier circuit

3-5. Squelch circuit

The output from IC12 enters FM IC again, then passed through a band-pass filter. The noise component output from IC12 is amplified by Q4 and rectified by D4 to produce a DC voltage corresponding to the noise level. The DC voltage is sent to the analog port of the CPU (IC19). And IC12 outputs a DC voltage (RSSI) corresponding to the input of the IF amplifier. The CPU reads the RSSI signal via pin 93.

IC19 determines whether to output sounds from the speaker by comparing the input voltage of pin 91 and pin 93 with the preset value.




Fig. 5 Squelch circuit




Fig. 6 Squelch and RSSI voltage vs ANT input level

4. Transmitter System

4-1. Microphone amplifier

The signal from the internal microphone goes through the mute switch (Q300).

When the SP-MIC is not attached, the microphone switching terminal (MSW) on the universal connector becomes High, and mute switch (Q300) is turned ON. When the SP-MIC is

CIRCUIT DESCRIPTION

attached, MSW is connected to GND at inside of SP-MIC. For this reason, Q300 is turned OFF, the internal microphone is muted, and only the input of the external microphone is supplied to the microphone amplifier of the TX-RX unit.

The signal from microphone passes through the limiter circuit in D8, and Mic mute switch (Q17 is off in TX) and through the high-pass filter, the ALC circuit, the low-pass filter, the high-pass filter, and pre-emphasis/IDC circuit in IC13. When encoding DTMF, mute switch (Q13) is turned OFF for muting the microphone input signal.

The signal passes through the D/A converter (IC8) for the maximum deviation adjustment, and enters the summing amplifier consisting of IC7 (1/2), and is mixed with the low speed data from the CPU (IC19) and 9600bps DATA from Optional Board Terminal.

The output signal from the summing amplifier passes through the D/A converter (IC8) again and goes to the VCO modulation input.

The other output signal from the summing amplifier passes through the D/A converter (IC8) again for the BAL adjustment, and the buffer amplifier (IC1 : 2/2), and goes to the VCXO modulation input.




Fig. 7 Microphone amplifier

4-2. Drive and Final amplifier

The signal from the T/R switch (D9 is on) is amplified by drive amplifier (Q20) to 30mW.

The output of the drive amplifier is amplified by the RF power amplifier (IC100) to 5.0W (1W when the power is low). The RF power amplifier consists of two stages MOS FET transistor. The output of the RF power amplifier is then passed through the harmonic filter (LPF) and antenna switch (D12 is on) and applied to the antenna terminal.




Fig. 8 Drive and final amplifier and APC circuit

4-3. APC circuit

The APC circuit always monitors the current flowing through the RF power amplifier (IC100) and keeps a constant current. The voltage drop at R244, R246 and R248 is caused by the current flowing through the RF power amplifier and this voltage is applied to the differential amplifier (IC23 1/2).

IC23(2/2) compares the output voltage of IC23(1/2) with the reference voltage from IC8, and the output of IC23(2/2) controls the VGG of the RF power amplifier to make the both voltages to same voltage.

The change of power high/low is carried out by the change of the reference voltage. Q22,23 and 25 are turned on in transmit and the APC circuit is active.

5. Frequency Synthesizer Unit

5-1. Frequency synthesizer

The frequency synthesizer consists of the VCXO (X1), VCO (A1), PLL IC(IC14) and buffer amplifiers.

The VCXO generates 16.8MHz. The frequency stability is 1.5ppm within the temperature range of -30 to +60°C. The frequency tuning and modulation of the VCXO are done to apply a voltage to pin 1 of the VCXO. The output of the VCXO is applied to pin 8 of the PLL IC.

The TK-280's VCO consists of 2VCO and covers a dual range of the 190.85~218.85MHz (K,K3,M), 186.85~206.85MHz (K2,K4) and the 146~174MHz (K,K3,M), 136~162MHz (K2,K4). The VCO generates 190.85~218.85MHz (K,K3,M), 186.85~206.85MHz (K2,K4) for providing to the first local signal in receive. In TX, the pin 3 of the VCO goes low and the VCO generates 146~174MHz (K,K3,M), 136~162MHz (K2,K4).

The output of the VCO is amplified by the buffer amplifier (Q16) and routed to the pin 5 of the PLL IC. Also the output of the VCO is amplified by the buffer amplifier (Q18) and routed to the next stage according to T/R switch (D9, D23).

The PLL IC consists of a prescaler, fractional divider, reference divider, phase comparator, charge pump. This PLL IC is fractional-N type synthesizer and performs in the 40, 50 or 60kHz reference signal which is eighth of the channel step (5, 6.25 or 7.5kHz). The input signal from the pins 5 and 8 of the PLL IC is divided down to the 40, 50 or 60kHz and compared at phase comparator. The pulsed output signal of the phase comparator is applied to the charge pump and transformed into DC signal in the loop filter (LPF). The DC signal is applied to the pin 1 of the VCO and locked to keep the VCO frequency constant.

PLL data is output from DT (pin 75). CP (pin 19) and EP (pin 47) of the microprocessor (IC19). The data are input to the PLL IC when the channel is changed or when transmission is changed to reception and vice versa. A PLL lock condition is always monitored by the pin 31 (UL) of the microprocessor. When the PLL is unlocked, the UL goes low.

CIRCUIT DESCRIPTION




Fig. 9 PLL block diagram

6. Control Circuit

The control circuit consists of microprocessor (IC19) and its peripheral circuits. It controls the TX-RX unit and transfers data to and from the display unit. IC19 mainly performs the following;

- 1) Switching between transmission and reception by PTT signal input.
- 2) Reading system, group, frequency, and program data from the memory circuit.
- 3) Sending frequency program data to the PLL.
- 4) Controlling squelch on/off by the DC voltage from the squelch circuit.
- 5) Controlling the audio mute circuit by decode data input.
- 6) Transmitting tone and encode data.

6-1. Memory circuit

Memory circuit consists of the CPU (IC19) and a flash memory (IC17), a flash memory has a capacity of 2M bits that contains the transceiver control program for the CPU and data such as transceiver channels and operating features.

This program can be easily written from an external devices. Data. such as operating status, are programmed into the EEPROM (IC20).

• Flash Memory

Note : The flash memory holds data such as written with the FPU (KPG-49D), firmware program (User mode, Test mode, Tuning mode, etc.) This data must be rewritten when replacing the flash memory.

• EEPROM

Note : The EEPROM stores tuning data (Deviation, Squelch, etc.).

Realign the transceiver after replacing the EEPROM.




Fig. 10 Memory circuit

6-2. Low battery warning

The battery voltage is monitored by the microprocessor (IC19). When the battery voltage falls below the voltage set by the Low Battery Warning adjustment, the red LED flashes to notify the operator that it is time to replace the battery. If the battery voltage falls even more (approx. 5.8V), a beep sounds and transmission is stopped.

| Low battery warning | Battery condition |
|--|---|
| The red LED flashes during transmission | The battery voltage is low but the transceiver is still usable. |
| The red LED flashes and continuous beep sounds while PTT pressed | The battery voltage is low and the transceiver is not usable to make calls. |

6-3. Key input

If the clock is supplied to CLK terminal when the RES terminal (CPU pin 78) of the decade counter (IC301) is set to Low, Q0 to Q7 become High sequentially. Normally, KI1 and KI2 are Low (pulled down). When any key is pressed. KI1 or KI2 become High. The CPU detects which key is pressed, according to the voltage of KI1 and KI2 and clock timing.




Fig. 11 Key input




Fig. 12 Decade counter timing chart

CIRCUIT DESCRIPTION

7. Signalling Circuit

7-1. Encode

- **Low-speed data (QT,DQT,LTR)**

Low-speed data is output from pin 1 of the CPU. The signal passes through a low-pass CR filter, and goes to the summing amplifier (IC7 1/2). The signal is mixed with the audio signal and goes to the VCO (A1) and VCXO (X1) modulation input after passing through the D/A converter (IC8) for BAL adjustment.

- **High-speed data (DTMF)**

High-speed data is output from pin 2 of the CPU. The signal passes through a low-pass filter consisting of IC10, and provides a TX DTMF tone and a RX DTMF tone. TX DTMF deviation making an adjustment by microprocessor is passed through the D/A converter (IC8) and then applied to the audio processor (IC13).

The signal is mixed with the audio signal and goes to the VCO and VCXO. The RX DTMF tone is passed a summing amplifier (IC7 2/2). The D/A converter (IC8) for audio control, audio power amplifier and then to the speaker.

- **MSK (ESN)**

ESN utilizes 1200bps MSK signal. MSK signal is output from pin 6 of IC13. The signal passes through the D/A converter (IC8) for the MSK deviation adjustment. and is routed to the VCO. When encoding MSK, the microphone input signal is muted.




Fig. 13 Encode

7-2. Decode

- **Low-speed data (QT,DQT,LTR)**

The demodulated signal from the IF IC (IC12) is amplified by IC4 (2/2) and passes through a low-pass filter (IC11) to remove audio components. The signal is input to pin 95 of the CPU.

The CPU digitizes this signal, performs processing such as DC restoration, and decodes the signal.

- **High-speed data (DTMF)**

The DTMF input signal from the IF IC (IC12) is amplified by IC4 (2/2) and goes to IC16, the DTMF decoder. The decoded information is then processed by the CPU. During transmission and standby, the DTMF IC is set to the power down mode when the PD terminal is High. When the line is busy, the PD terminal becomes Low, the power down mode is canceled and decoding is carried out.

- **High-speed data (2 tone)**

The demodulated signal from the IF IC (IC12) is amplified by IC4 (2/2) and passes through an audio processor (IC13) and band-pass filter (IC2) to remove a low-speed data. The CPU digitizes this signal, performs processing such as DC restoration, and decodes the signal.

- **MSK (ESN)**

The MSK input signal from the IF IC is amplified by IC4 (1/2) and goes to pin 5 of IC13. The signal is demodulated by MSK demodulator in IC13. The demodulated data goes to the CPU for processing.




Fig. 14 Decode

CIRCUIT DESCRIPTION

8. Power Supply Circuit

Battery +B is supplied via a 3A fuse from the battery terminal connected to the TX-RX unit. After passing through the power switch, power supply (SB) is applied to the three AVR's. IC5 supplies 5V (5M) to the control circuit, and IC9 supplies 5V (5C) to common circuits. IC6 supplies to the TX circuit, the RX circuit and common circuits of needless save mode. During transmission, 5TC becomes Low and Q3 is turned ON to supply 5V (5T) to the TX circuit. During reception, 5RC becomes Low and Q2 is turned ON to supply 5V (5R) to the RX Circuit.




Fig. 15 Power supply circuit

9. Optional Board Terminal

Terminals for mounting the option board are provided at the bottom edge of the TX-RX unit. The table below shows the correspondence between the board and terminals. R37, R69, R249, R258, R259, R304, R305 may have to be removed depending on the type of option board being used.

| Name | Function |
|------------|--|
| SB | Battery (7.5V) |
| GND | Ground |
| TXD | Serial data |
| RXD | Serial data |
| SQ | Busy: high |
| LOK | Link acquired : low (TX mode) |
| DI/ANI | Modulation (ANI) input |
| DEO | Detect output |
| TXAI/MUTE | Modulation output from board or mic mute: low |
| TXAO | Modulation input to board |
| RXAI | Received signal input to board |
| RXAO | Received signal output from board |
| D1 | Binary 1 |
| D2 | Binary 2 |
| OPT | Scramble, Emergency:low |
| PTTIN | PTT switch signal input to board (TX:low) |
| 5CNS | Battery (5V) |
| DI9 | 9600 bps data output |
| RXEMAO | Received signal output from board (after de-emphasis) |
| RXEMAI | Received signal input to board (after de-emphasis) |
| PTTOUT | PTT switch signal output from board (TX:low) |
| MONI | Busy:low |
| LAMP | Busy:low |
| AAC | Audio Amp Control signal output from board (Busy:high) |
| Audio Beep | Beep signal output from board. |
| AUX TXD | Serial data |
| AUX RXD | Serial data |

Table 1 Terminal name and function

SEMICONDUCTOR DATA

Microprocessor : 30612M4A-407GP (TX-RX UNIT : IC19)

■ Pin function

| Pin No. | Port Name | I/O | Function |
|---------|-----------|-----|---|
| 1 | LSDOUT | O | Low speed data output. |
| 2 | HSDOUT | O | High speed data output. |
| 3 | HSDIN | I | High speed data input. |
| 4 | DTMSTD | I | DTMF decode IC data detect input. |
| 5 | SELF | I | Self programming mode input. |
| 6 | BYTE | I | +5V. |
| 7 | CNVSS | I | GND. |
| 8 | SFTOE | O | Shift register output enable. |
| 9 | LCDCS | O | LCD driver chip select output. |
| 10 | RESET | I | Microcomputer reset input. |
| 11 | XOUT | - | 9.8304MHz (System clock). |
| 12 | VSS | - | GND. |
| 13 | XIN | - | 9.8304MHz (System clock). |
| 14 | VCC | - | +5V |
| 15 | AUX | I | AUX switch input. |
| 16 | AFTRD | I | MSK modulation data output timing pulse input. |
| 17 | AFRTM | I | MSK demodulation data input timing pulse input. |
| 18 | EN2 | I | Encoder pulse input 2. |
| 19 | PLLCLK | O | PLL IC clock output. |
| 20 | BEEP | O | Beep data output. |
| 21 | AFRDT | I | MSK demodulation data input. |
| 22 | AFREG1 | O | AF IC register switching data output 1. |
| 23 | AFREG2 | O | AF IC register switching data output 2. |
| 24 | EEPDAT | O | EEPROM data output. |
| 25 | DACSTB | O | D/A converter IC data strobe output. |
| 26 | AFCLR | O | MSK flame reset output. |
| 27 | SAVE | O | Battery save output. |
| 28 | LAMP | I | LAMP switch input. |
| 29 | AUXTXD | O | External Serial interface output. |
| 30 | AUXRXD | I | External Serial interface input. |
| 31 | PLLUL | I | PLL unlock detect input. |
| 32 | AFMSKE | O | MSK modulation enable (Enable active "H"). |
| 33 | TXD | O | Serial interface output (ex. PC). |
| 34 | RXD | I | Serial interface input (ex. PC). |
| 35 | AFDAT | O | MSK data output. |
| 36 | PTT | I | PTT switch input. |
| 37 | RDY | - | Not used. |
| 38 | ALE | - | Not used. |
| 39 | HOLD | - | Not used. |
| 40 | HLDA | - | Not used. |
| 41 | BLCK | - | Not used. |
| 42 | RD | - | Flash memory RD bus. |
| 43 | BHE | - | Not used. |
| 44 | WR | - | Flash memory WR bus. |
| 45 | DTMCLK | O | DTMF decode IC clock output. |
| 46 | CNTCLK | O | Common clock output. |
| 47 | PLLSTB | O | PLL IC data strobe output. |
| 48 | CS0 | O | Flash memory chip enable. |
| 49 | A19 | - | Not used. |
| 50-59 | A9~A18 | - | Flash memory address bus. |
| 60 | VCC | - | +5V |
| 61 | A8 | - | Flash memory address bus. |

| Pin No. | Port Name | I/O | Function |
|---------|-----------|-----|--|
| 62 | VSS | - | GND. |
| 63-70 | A0~A7 | - | Flash memory address bus. |
| 71 | MONI | I | Monitor switch input. |
| 72 | EN4 | I | Encoder pulse input 4. |
| 73 | EN3 | I | Encoder pulse input 3. |
| 74 | EN1 | I | Encoder pulse input 1. |
| 75 | MINDAT | O | Common data output. |
| 76 | KEY2 | I | Key scan input 2. |
| 77 | KEY1 | I | Key scan input 1. |
| 78 | RESET | O | Key scan IC reset output.. |
| 79-86 | D0~D7 | - | Flash memory data bus. |
| 87 | DTMDAT | I | DTMF decode IC data input. |
| 88 | PF | I | PF switch input. |
| 89 | VOL | I | Volume level input. |
| 90 | BATT | I | Battery voltage input. |
| 91 | ANLSQL | I | Squelch level input. |
| 92 | TEMP | I | Thermistor input. |
| 93 | RSSI | I | Received signal strength indicator input (RSSI). |
| 94 | AVSS | - | GND. |
| 95 | LSDIN | I | Low speed data input. |
| 96 | VREF | - | +5V |
| 97 | AVCC | - | +5V |
| 98 | SFTSTB1 | O | Shift register data strobe output. |
| 99 | W/N | O | Wide/Narrow switching output. |
| 100 | AFSTB | O | AF IC data strobe output. |

Shift register 1 : BU4094BCFV (TX-RX UNIT : IC21)

■ Pin function

| Pin No. | Port | Port Name | Function |
|---------|------|-----------|--|
| 4 | Q1 | LEDR | Red LED. H:ON, L:OFF |
| 5 | Q2 | LEDG | Green LED. H:ON, L:OFF |
| 6 | Q3 | KEYBLT | Key back light. H:ON, L:OFF |
| 7 | Q4 | MMUTE | Mic mute. H:Unmute, L:Mute |
| 14 | Q5 | 5RC | RX power control. H:TX, L:RX |
| 13 | Q6 | 5TC | TX power control. H:RX, L:TX |
| 12 | Q7 | BSHIFT | Beat shift. H:ON, L:OFF |
| 11 | Q8 | DTMPD | DTMF decode IC power down. H:Power Down, L:Busy |

Shift register 2 : BU4094BCFV (TX-RX UNIT : IC22)


■ Pin function

| Pin No. | Port | Port Name | Function |
|---------|------|-----------|--|
| 4 | Q1 | AM1 | Audio mute 1. H:Unmute, L:Mute |
| 5 | Q2 | LOK | Link complete. (Programmable active H/L) |
| 6 | Q3 | T/R | TX/RX switching. H:RX, L:TX |
| 7 | Q4 | DM | Dead mute. H:RX, L:TX |
| 14 | Q5 | OPT | Option board control. H:ON, L:OFF Auxiliary. (Programable active H/L) |
| 13 | Q6 | CODE1 | Option board data 1. H:ON, L:OFF |
| 12 | Q7 | CODE2 | Option board data 2. H:ON, L:OFF |
| 11 | Q8 | SQ | External squelch. (Programmable active H/L) |

SEMICONDUCTOR DATA

Audio Processor : TC35453F (TX-RX Unit IC13)

■ Block diagram



■ Pin function


| Pin No. | Port Name | I/O | Function |
|---------|-----------|-----|---|
| 1 | RXFO | O | RX audio filter output. |
| 2 | RXGS | O | RX audio signal level setting amplifier output. |
| 3 | RXIN | I | RX audio signal level setting amplifier input. |
| 4 | MSKGS | O | MSK RX level setting amplifier output. |
| 5 | MSKIN | I | MSK RX level setting amplifier input. |
| 6 | TXOUT | O | TX signal output. |
| 7 | IDCGS | O | IDC input level setting amplifier output. |
| 8 | IDCIN | I | IDC input level setting amplifier input. |
| 9 | TXFO | O | TX audio filter circuit output. |
| 10 | AGND | - | Analog reference voltage stabilization. |
| 11 | CST | I/O | Compressor stabilization. |
| 12 | MICIN | I | Microphone amplifier input. |
| 13 | MICGS | O | Microphone amplifier output. |
| 14 | CALC | I/O | ALC Circuit response time setting. |
| 15 | ALCO | O | ALC circuit output. |
| 16 | CMPIN | I | Compressor input. |
| 17 | CCHG | I/O | Compressor response time setting. |
| 18 | CMPO | O | Compressor output. |
| 19 | TXFI | I | TX audio filter input. |
| 20 | VDDA | - | Analog power supply. |
| 21 | VDDD | - | Digital power supply. |
| 22 | STB | I | Data strobe pulse input / system reset input 1. |
| 23 | DIN | I | Data input. |

| Pin No. | Port Name | I/O | Function |
|---------|-----------|-----|---|
| 24 | DCK | I | Data synchronized clock input. |
| 25 | REGS1 | I | Internal register select input 1. |
| 26 | REGS2 | I | Internal register select input 2. |
| 27 | XOUT | O | Oscillation circuit output. |
| 28 | XIN | I | Oscillation circuit input. |
| 29 | MSKE | I | MSK modulation enable input. |
| 30 | TRD | O | MSK modulation data latch timing output. |
| 31 | RTM | O | MSK RX synchronized clock output. |
| 32 | RDT | O | MSK RX data output. |
| 33 | FCLR | I | Flame detect circuit reset input 1 System reset input 2. |
| 34 | VSSD | - | Digital ground. |
| 35 | VSSA | - | Analog ground. |
| 36 | MSKST | I/O | MSK modem demodulation circuit stabilization. |
| 37 | PWROP | O | Speaker operation positive output. |
| 38 | PWRON | O | Speaker operation negative output. |
| 39 | PWRGS | O | RX output level setting amplifier output. |
| 40 | PWRIN | I | RX output level setting amplifier input. |
| 41 | EXPO | O | Expander output. |
| 42 | ECHG | I/O | Expander response time setting. |
| 43 | EXPGS | O | Expander input level setting amplifier output. |
| 44 | EXPIN | I | Expander input level setting amplifier input. |

SEMICONDUCTOR DATA

D/A Converter : M62364FP (TX-RX Unit IC8)

■ Block diagram



■ Pin function


| Pin No. | Pin code | I/O | Function |
|---------|-----------------|-----|--|
| 1 | VI1 | I | D/A converter input. |
| 2,3 | VO1,VO2 | O | 8-bit resolution D/A. |
| 4 | VI2 | I | D/A Converter input. |
| 5 | V _{DD} | - | Power supply. |
| 6 | LD | I | When the LD is at the low level, the clock input reception mode is entered. and data can be uptaken by the 12-bit shift register. Then at the threshold rising from low to high, the 12-bit shift register value is loaded to the D/A output register. |
| 7 | CLK | I | Shift clock input. With the rise of the shift clock, the input signal from the DI is input to the 12-bit shift register. |
| 8 | DI | I | Serial data input. Input serial data 12 bits long. |
| 9 | VI3 | I | D/A converter input. |

| Pin No. | Pin code | I/O | Function |
|---------|------------------|-----|---|
| 10,11 | VO3,VO4 | O | 8-bit resolution D/A. |
| 12,13 | VI4,VI5 | I | D/A converter input. |
| 14,15 | VO5,VO6 | O | 8-bit resolution D/A. |
| 16 | VI6 | I | D/A converter input. |
| 17 | DO | O | 12-bit shift register MSB bit data is output. |
| 18 | V _{REF} | - | Terminal for determining the D/A Conversion reference point level. $V_o = (V_{IN} - V_{DAREF}) \times n/256 + V_{DAREF}$ |
| 19 | RESET | - | When a low level signal is input to the RESET terminal, all the D/A output register value become low. |
| 20 | GND | - | GND. |
| 21 | VI7 | I | D/A converter input. |
| 22,23 | VO7,VO8 | O | 8-bit resolution D/A. |
| 24 | VI8 | I | D/A converter input. |

SEMICONDUCTOR DATA

PLL System : SA7025DK (TX-RX Unit IC14)


■ Block diagram



Audio Power Amplifier : TDA7053AT

(Display Unit IC300)

■ Block diagram



■ Pin description

| Pin No. | Symbol | Description |
|---------|--------|---|
| 1 | CLOCK | Serial clock input. |
| 2 | DATA | Serial data input. |
| 3 | STROBE | Serial strobe input. |
| 4 | VSS | Digital ground. |
| 5 | RFIN | Prescaler positive input. |
| 6 | RFIN | Prescaler negative input. |
| 7 | VCCP | Prescaler positive Supply voltage. This pin supplies power to the prescaler and RF input buffer. |
| 8 | REFIN | Reference divider input. |
| 9 | RA | Auxiliary current setting; resistor to VSSA. |
| 10 | AUXIN | Auxiliary divider input. |
| 11 | PHA | Auxiliary phase detector output. |
| 12 | VSSA | analog ground. |
| 13 | PHI | Integral phase detector output. |
| 14 | PHP | Proportional phase detector output. |
| 15 | VDDA | Analog supply voltage. This pin supplies power to the charge pumps, Auxiliary prescaler, Auxiliary and Reference buffers. |
| 16 | RN | Main current setting; resistor to VSSA. |
| 17 | RF | Fractional compensation current setting; resistor to VSSA. |
| 18 | LOCK | Lock detector output. |
| 19 | TEST | Test pin; connect to VDD. |
| 20 | VDD | Digital supply voltage. This pin supplies power to the CMOS digital part of the device. |

■ Pin description


| Pin No. | Symbol | Description |
|---------|--------|--------------------------|
| 1 | NC | Not connected. |
| 2 | VC1 | DC volume control 1. |
| 3 | NC | Not connected. |
| 4 | VI(1) | Voltage input 1. |
| 5 | VP | Positive Supply voltage. |
| 6 | VI(2) | Voltage input 2. |
| 7 | SGND | Signal ground. |
| 8 | VC2 | DC volume control 2. |
| 9 | OUT2+ | Positive output 2. |
| 10 | PGND2 | Power ground 2. |
| 11 | NC | Not connected. |
| 12 | OUT2- | Negative output 2. |
| 13 | OUT1- | Negative output 1. |
| 14 | PGND1 | Power ground 1. |
| 15 | NC | Not connected. |
| 16 | OUT1+ | Positive output 1. |

SEMICONDUCTOR DATA

Voltage Detector : RN5VL42C

(TX-RX Unit IC3)

■ Block diagram (CMOS output)




■ Pin function

| Pin No. | Pin code | Function |
|---------|----------|---------------|
| 1 | OUT | Output. |
| 2 | VDD | Power supply. |
| 3 | GND | Ground. |


Counter : MC74HC4017F (Display Unit IC301)

■ Logic circuit



VCO System : X58-4580-XX (SUB Unit : A1)

■ Circuit diagram



• Input

CLOCK (pin No.14) - Clock Input

The rising edge of this clock advances the count.

• Controller Input

RESET (pin No.15) - Asynchronous Reset Input

When this pin is High, the counter is initialized. and Q0 and CARRY OUT output become High. At this time, Q1 to Q9 become Low.

CLOCK ENABLE (Pin No.13) - Clock Enable Input (Low active)

The count operation is forbidden when this pin is High. When it is Low, the normal count is carried out. When the clock input (pin No.14) is used as enable (High active), this input can be used for the count as the rising clock.

• Output

Q0 to Q9 (pins 3,2,4,7,10,1,5,6,9,11) - Decoded Decade Counter Output

These outputs become High only during a single clock cycle.

CARRY OUT (pin No.12) - Cascade Output Pin

This output is used as the cascade output, or as the $\div 10$ output during the 50% duty cycle. When the count reaches "5", this output becomes Low. When the count reaches "0" or is reset, this output becomes High. When counters are cascade-connected, this output sends the rise signal to clock input of the next counter.

DESCRIPTION OF COMPONENTS

DISPLAY UNIT (X54-3180-XX)

| Ref. No. | Use/Function | Operation/Condition |
|----------|--------------|---|
| IC300 | IC | Audio power amplifier |
| IC301 | IC | Counter /Key scan |
| Q300 | FET | DC switch / INT MIC on/off |
| Q301 | FET | DC switch |
| Q302 | Transistor | DC switch / LED (Red) driver |
| Q303 | Transistor | DC switch / LED (Green) driver |
| Q304 | Transistor | DC switch |
| Q305 | Transistor | Current driver / Audio amp AVR |
| Q306 | Transistor | DC switch |
| Q307 | Transistor | Current driver / LCD back light LED AVR |
| Q308 | FET | DC switch / SP INT/EXT |
| Q309 | Transistor | Temperature compensation |
| Q310 | FET | Mute switch |
| D300 | Zener diode | Surge absorption |
| D301 | LED | LED / Red, Green |
| D302 | Diode | Quick discharge /AF mute |
| D303 | Zener diode | Voltage reference |
| D304 | Diode | Voltage reference |
| D305~310 | LED | LCD back light |
| D315~318 | Diode | Reverse current prevention |
| D319~321 | Zener diode | Surge absorption |

TX-RX UNIT (X57-5740-XX)

| Ref. No. | Use/Function | Operation/Condition |
|----------|--------------|--|
| IC1,2 | IC | Buffer amplifier |
| IC3 | IC | Voltage detector / Reset |
| IC4 | IC | Buffer amplifier |
| IC5 | IC | Voltage regulator / 5M |
| IC6 | IC | Voltage regulator / 5V |
| IC7 | IC | Buffer amplifier |
| IC8 | IC | D/A converter (Adjustment) |
| IC9 | IC | Voltage regulator / 5C |
| IC10 | IC | Active filter / For HSDout |
| IC11 | IC | Active filter / For LSDin |
| IC12 | IC | FM IF system |
| IC13 | IC | Audio processor |
| IC14 | IC | PLL system |
| IC16 | IC | DTMF decoder |
| IC17 | IC | Flash memory |
| IC18 | IC | Active DBM |
| IC19 | IC | Microprocessor |
| IC20 | IC | EEPROM |
| IC21,22 | IC | Shift register / Output expander |
| IC23 | IC | Comparator (APC) |
| IC24 | IC | Analog switch |
| Q1 | Transistor | Switch |
| Q2 | FET | DC switch / 5R |
| Q3 | Transistor | DC switch / 5T |
| Q4 | Transistor | Noise amplifier / Squelch |
| Q5 | FET | DC switch / Save |
| Q6 | Transistor | 2 nd IF W/N switch sets to on when Narrow |
| Q7 | Transistor | 2 nd IF W/N switch sets to on when Wide |

| Ref. No. | Use/Function | Operation/Condition |
|----------|--------------|--|
| Q8 | Transistor | Ripple filter |
| Q9 | Transistor | DC switch / W/N audio amplitude adjust |
| Q10 | Transistor | AF mute switch |
| Q11 | FET | Mute switch |
| Q12 | Transistor | IF amplifier |
| Q13 | FET | Mute switch / MIC line mute |
| Q14 | FET | DC switch |
| Q15 | FET | DET mute |
| Q16 | Transistor | PLL IC fin amplifier |
| Q17 | FET | Mute switch / MIC line mute |
| Q18 | Transistor | Buffer amplifier |
| Q19 | Transistor | Clock frequency shift |
| Q20 | Transistor | RF amplifier / TX driver |
| Q21 | FET | DC switch |
| Q22 | Transistor | DC switch |
| Q23 | FET | DC switch |
| Q24 | FET | RF amplifier |
| Q25 | Transistor | DC switch |
| D1 | Diode | Reverse protection |
| D2 | Diode | Overload protection |
| D3 | Diode | Reverse current protection |
| D4 | Diode | Noise detection |
| D5 | Diode | RF switch (2 nd IF wide/narrow) |
| D6 | Diode | Current steering |
| D7 | Diode | RF switch (2 nd IF wide/narrow) |
| D8 | Diode | Voltage clamp |
| D9 | Diode | TX/RX switch |
| D10 | Diode | Overload protection |
| D12,14 | Diode | ANT switch |
| D15 | Diode | Overload protection |
| D16,17 | Diode | Varactor tuning |
| D18,19 | Diode | Surge absorption |
| D20,21 | Diode | Varactor tuning |
| D22 | Diode | ANT switch |
| D23 | Diode | TX/RX switch |
| D24 | Diode | Voltage drop |

SUB UNIT (X58-4580-XX)

| Ref. No. | Use/Function | Operation/Condition |
|----------|--------------|---------------------|
| Q1 | FET | DC switch |
| Q2,3 | FET | VCO oscillation |
| Q4 | Transistor | DC switch |
| Q5 | Transistor | RF Buffer amplifier |
| D1-D8 | Diode | Frequency control |
| D9 | Diode | TX modulation |

PARTS LIST

* New Parts. Δ indicates safety critical components.
 Parts without **Parts No.** are not supplied.
 Les articles non mentionnés dans le **Parts No.** ne sont pas fournis.
 Teile ohne **Parts No.** werden nicht geliefert.

L: Scandinavia K: USA P: Canada
 Y: PX (Far East, Hawaii) T: England E: Europe
 Y: AAFES (Europe) X: Australia M: Other Areas

TK-280

| Ref. No. | Address | New parts | Parts No. | Description | Destination | Ref. No. | Address | New parts | Parts No. | Description | Destination |
|-------------------------|---------|-----------|-------------|-------------------------------|-------------|--|---------|-----------|---------------|---------------------------------|-------------|
| TK-280 (Y50-487) | | | | | | | | | | | |
| 1 | 1A | | A02-2054-53 | CABINET ASSY(4 KEYS) | K,K2,M | 50 | 2B | | S70-0414-05 | TACT SWITCH (AUX SW) | |
| 1 | 1A | | A02-2055-53 | CABINET ASSY(16 KEYS) | K3,K4 | SP | 1B | | T07-0347-05 | SPEAKER | |
| 2 | 3B | | A62-0535-04 | PANEL ASSY | | ANT | 2D | | T90-0679-05 | HELICAL ANTENNA ACSY | M |
| 3 | 2C | | B09-0363-03 | CAP (SP/MIC) ACSY | | MIC300 | 2A | | T91-0579-05 | MIC ELEMENT | |
| 4 | 2A | | B38-0810-05 | LCD ASSY | | IC100 | 2B | | M68731HM | IC (POWER MODULE) | K,K3,M |
| 5 | 1B | | B43-1106-14 | BADGE (KENWOOD) | | IC100 | 2B | * | M68776 | IC (POWER MODULE) | K2,K4 |
| 6 | 1C | | B46-0470-00 | WARRANTY CARD ACSY | K,K2,K3,K4 | 51 | 3B | | W02-1814-05 | ENCODER | |
| 7 | 1C | | B62-0967-00 | INSTRUCTION MANUAL ACSY | K,K2,K3,K4 | DISPLAY UNIT (X54-3210-XX) -10:K,K2,M -11:K3,K4 | | | | | |
| 7 | 1C | | B62-0988-00 | INSTRUCTION MANUAL ACSY | M | C301 | | | CC73GCH1H470J | CHIP C 47PF J | |
| 8 | 3B | * | B72-1445-14 | MODEL NAME PLATE | K,K3,M | C302 | | | C92-0560-05 | CHIP-TAN 10UF 6.3WV | |
| 8 | 3B | * | B72-1446-04 | MODEL NAME PLATE | K2,K4 | C304 | | | CK73FB1C474K | CHIP C 0.47UF K | |
| 9 | 3B | | E04-0416-05 | RF COAXIAL RECEPTACLE(SMA) | | C305 | | | CC73GCH1H101J | CHIP C 100PF J | |
| 10 | 3A | | E23-1048-05 | TERMINAL (BATT-) | | C307 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| 11 | 3B | | E23-1101-05 | TERMINAL (BATT+) | | C308 | | | CC73GCH1H101J | CHIP C 100PF J | |
| 12 | 2B | | E23-1104-04 | TERMINAL (ANT) | | C309 | | | CK73FB1C474K | CHIP C 0.47UF K | |
| 13 | 2B | | E37-0672-05 | FLAT CABLE | | C310 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| 14 | 3A | | E37-0673-05 | LEAD WIRE WITH CONNECTOR(PTT) | | C311 | | | CC73GCH1H470J | CHIP C 47PF J | |
| 15 | 1A | | E37-0674-05 | LEAD WIRE WITH CONNECTOR(SP) | | C312 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| 16 | 3B | | E58-0440-05 | SQUARE SOCKET (SP/MIC) | | C313 | | | C92-0628-05 | CHIP-TAN 10UF 10WV | |
| 17 | 2A | * | F10-2310-03 | SHIELDING PLATE(LCD) | | C314 | | | C92-0647-05 | TAN C 3.3UF 4WV | |
| 18 | 3B | | F10-2255-04 | SHIELDING PLATE(P-MODULE) | | C315 | | | CC73GCH1H101J | CHIP C 100PF J | |
| 19 | 2B | | F10-2271-03 | SHIELDING CASE (FRONT END) | | C316,317 | | | CC73GCH1H470J | CHIP C 47PF J | |
| 20 | 2B | | F10-2272-03 | SHIELDING CASE (DBM) | | C318 | | | CC73GCH1H101J | CHIP C 100PF J | |
| 21 | 2A | * | F10-2274-13 | SHIELDING CASE (VCO-OUT) | | C321-333 | | | CC73GCH1H470J | CHIP C 47PF J | |
| 22 | 2A | | F20-3303-04 | INSULATING SHEET(MIC/GND) | | C335-339 | | | CC73GCH1H470J | CHIP C 47PF J | |
| 23 | 1A | | G01-0881-04 | COIL SPRING | | C340 | | | CK73GB1E153K | CHIP C 0.015UF K | |
| 24 | 1B | | G09-0418-05 | KNOB SPRING (VOL,ENC) | | C341-344 | | | CC73GCH1H470J | CHIP C 47PF J | |
| 25 | 1B | | G10-0799-04 | FIBROUS SHEET (SP) | | CN300 | | | E40-5891-05 | FLAT CABLE CONNECTOR(24P-TX-RX) | |
| 27 | 3A | | G11-2544-04 | SHEET (CHASSIS) | | CN301 | | | E40-5892-05 | FLAT CABLE CONNECTOR(14P) | |
| 29 | 3A | * | G11-2590-04 | SHEET (PTT) | | CN302 | | | E40-5862-05 | PIN ASSY SOCKET (SP) | |
| 31 | 3B | | G53-0811-03 | PACKING (TOP) | | CN303 | | | E40-5887-05 | PIN ASSY (PTT) | |
| 32 | 3A | | G53-0814-04 | PACKING (BATT+) | | CN304 | | | E40-5823-05 | FLAT CABLE CONNECTOR(LCD) | |
| 33 | 1B | | G53-0840-02 | PACKING (4 KEYS) | K,K2,M | L300,301 | | | L92-0141-05 | FERRITE CHIP | |
| 34 | 1B | | G53-0841-02 | PACKING (16 KEYS) | K3,K4 | L302,303 | | | L92-0138-05 | FERRITE CHIP | |
| 35 | 2D | | H12-3014-02 | PACKING FIXTURE | | L304,305 | | | L92-0141-05 | FERRITE CHIP | |
| 36 | 1D | | H13-1072-04 | CARTON BOARD | | L306,307 | | | L92-0138-05 | FERRITE CHIP | |
| 37 | 3D | | H52-1225-02 | ITEM CARTON CASE | | L308,309 | | | L92-0141-05 | FERRITE CHIP | |
| 38 | 1A | | J19-1572-04 | HOLDER | | CP300,30 | | | R90-0723-05 | MULTI-COMP 47K X2 | |
| 39 | 2A | | J21-8366-03 | HARDWARE FIXTURE(P-MODULE) | | CP302 | | | R90-0724-05 | MULTI-COMP 1K X4 | K3,K4 |
| 40 | 2C | | J29-0618-15 | HOOK ACSY | | CP303 | | | R90-0724-05 | MULTI-COMP 1K X4 | |
| 41 | 3B | | J82-0045-05 | FPC (VOL,ENC) | | R300 | | | RK73GB1J103J | CHIP R 10K J 1/16W | |
| 42 | 3B | * | J82-0066-05 | FPC (SQUARE SOCKET) | | R301 | | | RK73FB2A101J | CHIP R 100 J 1/10W | |
| 43 | 1A | | K29-5157-03 | KNOB (PTT etc) | | R302 | | | RK73GB1J470J | CHIP R 47 J 1/16W | |
| 44 | 1A | | K29-5158-03 | KEY TOP (PTT etc) | | R303 | | | RK73GB1J471J | CHIP R 470 J 1/16W | |
| 45 | 1A | | K29-5165-03 | LEVER KNOB | | R304 | | | RK73GB1J182J | CHIP R 1.8K J 1/16W | |
| 46 | 1B | | K29-5231-03 | KNOB (VOL) | | R305 | | | RK73GB1J104J | CHIP R 100K J 1/16W | |
| 47 | 1B | | K29-5232-03 | KNOB (ENC) | | R306 | | | R92-1252-05 | CHIP R 0 OHM | |
| A | 3B | | N14-0569-04 | CIRCULAR NUT (VOL,ENC) | | R307 | | | RK73GB1J821J | CHIP R 820 J 1/16W | |
| B | 3B | | N30-2604-46 | PAN HEAD MACHINE SCREW(ANT) | | R308 | | | RK73GB1J153J | CHIP R 15K J 1/16W | |
| C | 3A | | N30-2610-46 | PAN HEAD MACHINE SCREW(CASE) | | R309 | | | R92-1252-05 | CHIP R 0 OHM | |
| D | 2B | | N67-2606-46 | PAN HEAD SEMS SCREW(P-MODULE) | | R310 | | | RK73GB1J331J | CHIP R 330 J 1/16W | |
| E | 2A | | N83-2005-46 | PAN HEAD TAPTITE SCREW(UNIT) | | R311 | | | RK73GB1J102J | CHIP R 1.0K J 1/16W | |
| 48 | 2C | | N99-2004-05 | SCREW SET ACSY | | R312 | | | RK73GB1J104J | CHIP R 100K J 1/16W | |
| 49 | 3B | | R31-0617-05 | VARIABLE R (POWER SW/VOL) | | R313, 314 | | | RK73GB1J102J | CHIP R 1.0K J 1/16W | |
| | | | | | | R315 | | | RK73GB1J104J | CHIP R 100K J 1/16W | |
| | | | | | | R316 | | | RK73GB1J473J | CHIP R 47K J 1/16W | |
| | | | | | | R317 | | | RK73GB1J472J | CHIP R 4.7K J 1/16W | |

PARTS LIST

DISPLAY UNIT (X54-3210-XX)
TX-RX UNIT (X57-5740-XX)

| Ref. No. | Address | New parts | Parts No. | Description | Destination | Ref. No. | Address | New parts | Parts No. | Description | Destination |
|--|---------|-----------|---------------|----------------------|-------------|----------|---------|-----------|---------------|------------------|-------------|
| R318 | | | RK73GB1J104J | CHIP R 100K J 1/16W | | C31 | | | CK73FB1A105K | CHIP C 1.0UF K | |
| R319 | | | RK73GB1J820J | CHIP R 82 J 1/16W | | C32 , 33 | | | CK73GB1H102K | CHIP C 1000PF K | |
| R320, 321 | | | RK73GB1J820J | CHIP R 82 J 1/16W | K3,K4 | C34 | | | CK73GB1E103K | CHIP C 0.010UF K | |
| R324 | | | RK73GB1J102J | CHIP R 1.0K J 1/16W | | C35 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| R325 | | | RK73GB1J102J | CHIP R 1.0K J 1/16W | K3,K4 | C36 , 37 | | | CK73GB1H102K | CHIP C 1000PF K | |
| R326 | | | RK73GB1J124J | CHIP R 120K J 1/16W | | C38 , 39 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| R327 | | | RK73GB1J563J | CHIP R 56K J 1/16W | | C40 | | | C92-0713-05 | TAN C 10UF 6.3WV | |
| R328 | | | RK73GB1J124J | CHIP R 120K J 1/16W | | C41 | | | CK73GB1H102K | CHIP C 1000PF K | |
| R331 | | | RK73GB1J103J | CHIP R 10K J 1/16W | | C42 | | | CK73GB1C333K | CHIP C 0.033UF K | |
| R332 | | | RK73GB1J272J | CHIP R 2.7K J 1/16W | | C43 | | | CK73GB1H102K | CHIP C 1000PF K | |
| R333 | | | RK73GB1J103J | CHIP R 10K J 1/16W | | C45 | | | CC73GCH1H121J | CHIP C 120PF J | |
| R336 | | | R92-1252-05 | CHIP R 0 OHM | | C46 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| R337 | | | RK73GB1J472J | CHIP R 4.7K J 1/16W | | C47 | | | CK73GB1H102K | CHIP C 1000PF K | |
| R338-341 | | | RK73GB1J101J | CHIP R 100 J 1/16W | | C48 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| S301-303 | | | S70-0457-05 | TACT SWITCH(PTT) | | C49 | | | CC73GCH1H100D | CHIP C 10PF D | |
| D300 | | | NNCD6.8G | ZENER DIODE | | C50 | | | CK73GB1E103K | CHIP C 0.010UF K | |
| D301 | | | B30-2019-05 | LED(RE/GR) | | C51 | | | CC73GCH1H271J | CHIP C 270PF J | |
| D302 | | | 1SS373 | DIODE | | C52 | | | CK73GB1H102K | CHIP C 1000PF K | |
| D303 | | | 015AZ2.4-X | ZENER DIODE | | C53 | | | CK73GB1E103K | CHIP C 0.010UF K | |
| D304 | | | MA2S111 | DIODE | | C54 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| D305,306 | | | B30-2171-05 | LED(1608/D/8) | | C55 | | | C92-0662-05 | TAN C 15UF 6.3WV | |
| D307-310 | | | B30-2171-05 | LED(1608/D/8) | K3,K4 | C56 | | | CK73GB1H472K | CHIP C 4700PF K | |
| D315 | | | IMN10 | DIODE | K3,K4 | C57 | | | CK73GB1H102K | CHIP C 1000PF K | |
| D316 | | | MA2S111 | DIODE | K3,K4 | C58 | | | CK73GB1H222K | CHIP C 2200PF K | |
| D317 | | | MA2S111 | DIODE | | C59 | | | CK73GB1C273K | CHIP C 0.027UF K | |
| D318 | | | IMN10 | DIODE | | C60 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| D319-321 | | | 015AZ6.8 | ZENER DIODE | | C61 | | | CK73GB1E123K | CHIP C 0.012UF K | |
| IC300 | | | TDA7053AT | IC(AUDIO AMP) | | C62 | | | CK73GB1H122J | CHIP C 1200PF J | |
| IC301 | | | MC74HC4017F | IC(GATE CMOS) | | C63 | | | CK73GB1H102K | CHIP C 1000PF K | |
| Q300 | | | 2SJ243 | FET | | C64 ,65 | | | CC73GCH1H680J | CHIP C 68PF J | |
| Q301 | | | UPA672T | FET | | C66 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| Q302-304 | | | 2SC4617(S) | TRANSISTOR | | C67 ,68 | | | CK73GB1E103K | CHIP C 0.010UF K | |
| Q305 | | | 2SB798(DL,DK) | TRANSISTOR | | C69 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| Q306 | | | 2SC4617(S) | TRANSISTOR | | C70 | | | CC73GCH1H220J | CHIP C 22PF J | |
| Q307 | | | 2SB1132(Q,R) | TRANSISTOR | | C71 | | | CK73GB1C683K | CHIP C 0.068UF K | |
| Q308 | | | UPA672T | FET | | C72 | | | CC73GCH1H100D | CHIP C 10PF D | |
| Q309 | | | 2SC4617(S) | TRANSISTOR | | C73 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| Q310 | | | 2SK1824 | FET | | C74 | | | CK73GB1E103K | CHIP C 0.010UF K | |
| TH300 | | | TN10-3S154JT | THERMISTOR | | C75 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| | | | | | | C76 | | | C92-0662-05 | TAN C 15UF 6.3WV | |
| TX-RX UNIT (X57-5740-XX) -10:K,K3,M -11:K2,K4 | | | | | | | | | | | |
| C1 | | | CK73GB1H102K | CHIP C 1000PF K | | C77 | | | CK73GB1H562J | CHIP C 5600PF J | |
| C2 ,3 | | | CK73GB1E103K | CHIP C 0.010UF K | | C78 | | | C92-0713-05 | TAN C 10UF 6.3WV | |
| C4 -6 | | | CK73GB1H102K | CHIP C 1000PF K | | C79 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| C7 | | | CK73GB1C104K | CHIP C 0.10UF K | | C80 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C8 ,9 | | | CK73GB1E103K | CHIP C 0.010UF K | | C81 | | | CK73GB1C333K | CHIP C 0.033UF K | |
| C10 | | | CK73GB1H102K | CHIP C 1000PF K | | C82 | | | CC73GCH1H101J | CHIP C 100PF J | |
| C11 | | | CK73GB1E103K | CHIP C 0.010UF K | | C83 | | | CK73GB1H562J | CHIP C 5600PF J | |
| C12 | | | CC73GCH1H101J | CHIP C 100PF J | | C84 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C13 | | | C92-0628-05 | CHIP-TAN 10UF 10WV | | C85 | | | CK73GB1H562J | CHIP C 5600PF J | |
| C14 | | | C92-0592-05 | CHIP-TAN 4.7UF 6.3WV | | C86 | | | CK73GB1C333K | CHIP C 0.033UF K | |
| C15 | | | CK73GB1H102K | CHIP C 1000PF K | | C87 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| C16 | | | C92-0628-05 | CHIP-TAN 10UF 10WV | | C88 | | | CC73GCH1H820J | CHIP C 82PF J | |
| C17 | | | CK73FB1C334K | CHIP C 0.33UF K | | C90 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C18 | | | C92-0628-05 | CHIP-TAN 10UF 10WV | | C91 | | | C92-0662-05 | TAN C 15UF 6.3WV | |
| C19 | | | C92-0592-05 | CHIP-TAN 4.7UF 6.3WV | | C92 | | | CK73GB1H272J | CHIP C 2700PF J | |
| C20 | | | CK73GB1C104K | CHIP C 0.10UF K | | C93 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| C21 | | | CK73GB1H331K | CHIP C 330PF K | | C94 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C22 | | | C92-0592-05 | CHIP-TAN 4.7UF 6.3WV | | C95 | | | CC73GCH1H330J | CHIP C 33PF J | |
| C23 -25 | | | CK73GB1H102K | CHIP C 1000PF K | | C96 | | | CC73GCH1H030C | CHIP C 3.0PF C | |
| C26 | | | CK73GB1E223K | CHIP C 0.022UF K | | C97 ,98 | | | CK73GB1H272J | CHIP C 2700PF J | |
| C27 -29 | | | CK73GB1H102K | CHIP C 1000PF K | | C101 | | | CK73GB1C104K | CHIP C 0.10UF K | |
| C30 | | | CK73GB1C104K | CHIP C 0.10UF K | | C102 | | | CC73GCH1H151J | CHIP C 150PF J | |
| | | | | | | C103 | | | CK73GB1H152J | CHIP C 1500PF J | |

PARTS LIST

TX-RX UNIT (X57-5740-XX)

| Ref. No. | Address | New parts | Parts No. | Description | Destination | Ref. No. | Address | New parts | Parts No. | Description | Destination |
|----------|---------|-----------|---------------|----------------------|-------------|----------|---------|-----------|---------------|---------------------|-------------|
| C104 | | | CK73GB1H102K | CHIP C 1000PF K | | C187 | | | CC73GCH1H270J | CHIP C 27PF J | |
| C105 | | | CK73GB1E103K | CHIP C 0.010UF K | | C189 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C106 | | | CC73GCH1H030C | CHIP C 3.0PF C | | C190 | | | CC73GB1H102K | CHIP C 1000PF K | K,K3,M |
| C107 | | | C92-0635-05 | TAN C 10UF 6.3WV | | C190 | | | CK73GC1H101J | CHIP C 100PF J | K2,K4 |
| C108 | | | C92-0714-05 | TAN C 4.7UF 6.3WV | | C191 | | | CK73HB1C103K | CHIP C 0.010UF K | |
| C109 | | | CK73GB1C104K | CHIP C 0.10UF K | | C192 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C110 | | | CK73GB1H102K | CHIP C 1000PF K | | C193 | | | CK73GB1H102K | CHIP C 1000PF K | K,K3,M |
| C111 | | | C92-0713-05 | TAN C 10UF 6.3WV | | C193 | | | CC73GCH1H101J | CHIP C 100PF J | K2,K4 |
| C112 | | | CK73GB1H102K | CHIP C 1000PF K | | C194 | | | CC73GCH1H390J | CHIP C 39PF J | K,K3,M |
| C113 | | | CK73GB1C104K | CHIP C 0.10UF K | | C194 | | | CC73GCH1H070B | CHIP C 7PF B | K2,K4 |
| C116,117 | | | CK73GB1C104K | CHIP C 0.10UF K | | C195 | | | CC73GCH1H220J | CHIP C 22PF J | K,K3,M |
| C119 | | | CK73GB1C473K | CHIP C 0.047UF K | | C195 | | | CC73GCH1H270J | CHIP C 27PF J | K2,K4 |
| C120,121 | | | CK73GB1C104K | CHIP C 0.10UF K | | C196 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C122 | | | CK73GB1E103K | CHIP C 0.010UF K | | C197 | | | CC73GCH1H150J | CHIP C 15PF J | K,K3,M |
| C123,124 | | | CK73GB1C104K | CHIP C 0.10UF K | | C197 | | | CC73GCH1H220J | CHIP C 22PF J | K2,K4 |
| C125 | | | C92-0657-05 | TAN C 2.2UF 20WV | | C198 | | | CK73FB1C474K | CHIP C 0.47UF K | |
| C126 | | | C92-0592-05 | CHIP-TAN 4.7UF 6.3WV | | C199 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C127 | | | CK73GB1C104K | CHIP C 0.10UF K | | C200 | | | C92-0565-05 | CHIP-TAN 6.8UF 10WV | |
| C128 | | | CK73GB1H562J | CHIP C 5600PF J | | C201 | | | CC73GCH1H270J | CHIP C 27PF J | |
| C129 | | | CK73GB1H102K | CHIP C 1000PF K | | C202 | | | CC73GCH1H180J | CHIP C 18PF J | K,K3,M |
| C130 | | | CK73GB1H562J | CHIP C 5600PF J | | C203 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C132 | | | CC73GCH1H220J | CHIP C 22PF J | | C204 | | | CC73GCH1H330J | CHIP C 33PF J | K,K3,M |
| C133 | | | CK73GB1E153K | CHIP C 0.015UF K | | C204 | | | CC73GCH1H300J | CHIP C 30PF J | K2,K4 |
| C134 | | | CK73GB1E103K | CHIP C 0.010UF K | | C205 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C135 | | | CK73GB1C333K | CHIP C 0.033UF K | | C206 | | | CC73GCH1H270J | CHIP C 27PF J | |
| C136 | | | CK73GB1E103K | CHIP C 0.010UF K | | C207 | | | CC73GCH1H050B | CHIP C 5.0PF B | |
| C137 | | | CC73GCH1H100D | CHIP C 10PF D | | C208 | | | CK73GB1E103K | CHIP C 0.010UF K | |
| C138 | | | CK73GB1H102K | CHIP C 1000PF K | | C209 | | | CC73GCH1H020B | CHIP C 2.0PF B | K,K3,M |
| C139 | | | CC73GCH1H220J | CHIP C 22PF J | | C209 | | | CC73GCH1H120J | CHIP C 12PF J | K2,K4 |
| C140 | | | C92-0592-05 | CHIP-TAN 4.7UF 6.3WV | | C210,211 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C141 | | | CK73GB1H102K | CHIP C 1000PF K | | C212 | | | CC73GCH1H270J | CHIP C 27PF J | K,K3,M |
| C142 | | | CC73GCH1H150J | CHIP C 15PF J | | C212 | | | CC73GCH1H220J | CHIP C 22PF J | K2,K4 |
| C143 | | | C92-0714-05 | TAN C 4.7UF 6.3WV | | C213 | | | CK73FB1C474K | CHIP C 0.47UF K | |
| C144 | | | CK73FB1H563K | CHIP C 0.056UF K | | C214 | | | CC73GCH1H330J | CHIP C 33PF J | |
| C146 | | | CK73HB1H102K | CHIP C 1000PF K | | C215 | | | CC73GCH1H101J | CHIP C 100PF J | |
| C148 | | | CK73GB1H102K | CHIP C 1000PF K | | C216 | | | CC73GCH1H330J | CHIP C 33PF J | K,K3,M |
| C149 | | | CC73GCH1H060D | CHIP C 6.0PF D | | C216 | | | CC73GCH1H560J | CHIP C 56PF J | K2,K4 |
| C153 | | | CK73GB1C104K | CHIP C 0.10UF K | | C217 | | | CC73GCH1H680J | CHIP C 68PF J | K,K3,M |
| C154 | | | CK73GB1H102K | CHIP C 1000PF K | | C217 | | | CC73GCH1H560J | CHIP C 56PF J | K2,K4 |
| C157 | | | CK73GB1H102K | CHIP C 1000PF K | | C218 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C158 | | | CK73HB1C103K | CHIP C 0.010UF K | | C219 | | | CC73GCH1H120J | CHIP C 12PF J | |
| C159 | | | CK73GB1C104K | CHIP C 0.10UF K | | C220 | | | CC73GCH1H101J | CHIP C 100PF J | |
| C160 | | | CC73GCH1H100D | CHIP C 10PF D | | C221 | | | CC73GCH1H220J | CHIP C 22PF J | K,K3,M |
| C162 | | | CK73GB1C104K | CHIP C 0.10UF K | | C221 | | | CC73GCH1H100D | CHIP C 10PF D | K2,K4 |
| C164 | | | CK73GB1E103K | CHIP C 0.010UF K | | C222 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C165 | | | CC73GCH1H050C | CHIP C 5.0PF C | | C223 | | | CC73GCH1H270J | CHIP C 27PF J | |
| C166 | | | CK73HB1C103K | CHIP C 0.010UF K | | C224-226 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C167 | | | CC73GCH1H150J | CHIP C 15PF J | | C227 | | | CC73GCH1H150J | CHIP C 15PF J | |
| C168 | | | CC73GCH1H220J | CHIP C 22PF J | | C228 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C169 | | | CC73GCH1H1R5B | CHIP C 1.5PF B | | C229 | | | CC73GCH1H470J | CHIP C 47PF J | |
| C170 | | | CK73GB1E103K | CHIP C 0.010UF K | | C230 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C171 | | | CK73HB1C103K | CHIP C 0.010UF K | | C231 | | | CC73GCH1H270J | CHIP C 27PF J | K2,K4 |
| C172 | | | CC73GCH1H120J | CHIP C 12PF J | | C233 | | | CC73GCH1H090D | CHIP C 9.0PF D | |
| C175 | | | CK73GB1C104K | CHIP C 0.10UF K | | C234 | | | CC73GCH1H470J | CHIP C 47PF J | |
| C176 | | | CK73GB1H472K | CHIP C 4700PF K | | C235 | | | CK73GB1E103K | CHIP C 0.010UF K | |
| C177,178 | | | CK73GB1H102K | CHIP C 1000PF K | | C236 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C179 | | | CK73GB1H471K | CHIP C 470PF K | | C237 | | | CC73GCH1H100D | CHIP C 10PF D | |
| C180,181 | | | CK73GB1H102K | CHIP C 1000PF K | | C238,239 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C182 | | | CK73GB1E103K | CHIP C 0.010UF K | | C241 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C183 | | | CC73GCH1H100D | CHIP C 10PF D | | C242 | | | CC73GCH1H270J | CHIP C 27PF J | |
| C184 | | | CC73GCH1H270J | CHIP C 27PF J | | C243 | | | CK73GB1H102K | CHIP C 1000PF K | |
| C186 | | | CK73GB1H102K | CHIP C 1000PF K | | C244 | | | CC73GCH1H100D | CHIP C 10PF D | |

PARTS LIST

TX-RX UNIT (X57-5740-XX)

| Ref. No. | Address | New parts | Parts No. | Description | Destination | Ref. No. | Address | New parts | Parts No. | Description | Destination |
|----------|---------|-----------|---------------|-------------------------------|-------------|----------|---------|-----------|--------------|--------------------------------|-------------|
| C245 | | | CK73GB1H102K | CHIP C 1000PF K | | L38 | | | L40-3371-36 | SMALL FIXED INDUCTOR(33NH/8) | |
| C246 | | | CC73GCH1H130J | CHIP C 13PF J | | L39 | | | L34-4568-05 | AIR-CORE COIL(8T) | |
| C247 | | | CC73GCH1H040B | CHIP C 4.0PF B | | L40 | | | L40-1888-67 | SMALL FIXED INDUCTOR(180NH/8) | |
| C248 | | | CC73GCH1H330J | CHIP C 33PF J | | L41 | | | L34-4568-05 | AIR-CORE COIL(8T) | |
| C249 | | | CK73GB1H102K | CHIP C 1000PF K | | L43, 44 | | | L34-4568-05 | AIR-CORE COIL(8T) | |
| C251 | | | CC73GCH1H331J | CHIP C 330PF J | | L45 | | | L40-1092-81 | SMALL FIXED INDUCTOR | |
| C252 | | | CK73GB1H102K | CHIP C 1000PF K | K,K3,M | L46 | | | L40-2288-67 | SMALL FIXED INDUCTOR(220NH/8) | |
| C252 | | | CC73GCH1H101J | CHIP C 100PF J | K2,K4 | L47, 48 | | | L34-4568-05 | AIR-CORE COIL(8T) | |
| C253 | | | CK73GB1H102K | CHIP C 1000PF K | | L49 | | | L92-0138-05 | FERRITE CHIP | |
| C255 | | | CK73GB1H102K | CHIP C 1000PF K | | L51 | | | L40-2288-67 | SMALL FIXED INDUCTOR(220NH/8) | |
| C256,257 | | | CK73HB1C103K | CHIP C 0.010UF K | | X1 | | | L77-1778-05 | TCXO (16.8MHZ/4P/16) | |
| C259 | | | CK73GB1E103K | CHIP C 0.010UF K | | X2 | | | L77-1760-05 | CRYSTAL RESONATOR(44.395MHZ) | |
| C260 | | | CC73GCH1H180J | CHIP C 18PF J | | X3 | | | L77-1708-05 | CRYSTAL RESONATOR(3.579545MHZ) | |
| C261 | | | CK73GB1E103K | CHIP C 0.010UF K | | X4 | | | L78-0462-05 | RESONATOR(9.8304M/8*2.5) | |
| C263 | | | CC73GCH1H0R5B | CHIP C 0.5PF B | | XF1 | | | L71-0530-05 | MCF (44.85MHZ/6P/1) | |
| C264 | | | CC73GCH1H180J | CHIP C 18PF J | K2,K4 | CP1 | | | R90-0724-05 | MULTI-COMP 1K X4 | |
| C265 | | | CK73GB1C104K | CHIP C 0.10UF K | | CP2 | | | R90-0718-05 | MULTI-COMP 4.7K X4 | |
| C266 | | | CC73GCH1H181J | CHIP C 180PF J | | CP4, 5 | | | R90-0743-05 | MULTIPLE RESISTOR 47K X2 | |
| C267 | | | CC73GCH1H680J | CHIP C 68PF J | | CP6 -21 | | | R90-0741-05 | MULTIPLE RESISTOR 1K X2 | |
| C268 | | | CK73GB1C104K | CHIP C 0.10UF K | | CP22-24 | | | R90-0743-05 | MULTIPLE RESISTOR 47K X2 | |
| CN1 | | | E40-5823-05 | FLAT CABLE CONNECTOR | | R1 | | | RK73GB1J103J | CHIP R 10K J 1/16W | |
| CN2 | | | E40-9517-05 | PIN ASSY SOCKET (4P) | | R2 | | | RK73GB1J473J | CHIP R 47K J 1/16W | |
| CN3 | | | E40-5890-05 | FLAT CABLE CONNECTOR(24P) | | R3 | | | RK73GB1J104J | CHIP R 100K J 1/16W | |
| CN4 | | | E23-0342-05 | TEST TERMINAL (2P) | | R4 | | | RK73GB1J154J | CHIP R 150K J 1/16W | |
| CN5 -12 | | | E23-1081-05 | TERMINAL | | R5 | | | RK73GB1J103J | CHIP R 10K J 1/16W | |
| F1 | | | F53-0130-05 | FUSE (3A) | | R6, 7 | | | RK73GB1J104J | CHIP R 100K J 1/16W | |
| CD1 | | | L79-1072-05 | TUNING COIL | | R8 | | | RK73GB1J472J | CHIP R 4.7K J 1/16W | |
| CF1 | | | L72-0962-05 | CERAMIC FILTER(455KHz) | | R9 | | | RK73GB1J474J | CHIP R 470K J 1/16W | |
| CF2 | | | L72-0963-05 | CERAMIC FILTER(455KHz) | | R10 | | | RK73GB1J472J | CHIP R 4.7K J 1/16W | |
| L1 | | | L92-0149-05 | FERRITE CHIP | | R11 | | | RK73GB1J104J | CHIP R 100K J 1/16W | |
| L2 | | | L92-0138-05 | FERRITE CHIP | | R12 | | | RK73GB1J184J | CHIP R 180K J 1/16W | |
| L3 | | | L40-4791-37 | SMALL FIXED INDUCTOR(4.7UH) | | R13 | | | RK73GB1J563J | CHIP R 56K J 1/16W | |
| L4 | | | L40-1091-37 | SMALL FIXED INDUCTOR(1.0UH) | | R14 | | | RK73GB1J223J | CHIP R 22K J 1/16W | |
| L5, 6 | | | L92-0138-05 | FERRITE CHIP | | R15 | | | RK73GB1J104J | CHIP R 100K J 1/16W | |
| L8 | | | L92-0138-05 | FERRITE CHIP | | R16, 17 | | | RK73GB1J473J | CHIP R 47K J 1/16W | |
| L9 | | | L40-2771-36 | SMALL FIXED INDUCTOR(27NH/8) | | R18 | | | RK73GB1J154J | CHIP R 150K J 1/16W | |
| L10 | | | L40-6871-36 | SMALL FIXED INDUCTOR(68NH) | | R19, 20 | | | RK73GB1J104J | CHIP R 100K J 1/16W | |
| L11, 12 | | | L92-0138-05 | FERRITE CHIP | | R21 | | | RK73GB1J393J | CHIP R 39K J 1/16W | |
| L14 | | | L40-1081-36 | SMALL FIXED INDUCTOR(100NH) | | R22, 23 | | | RK73GB1J823J | CHIP R 82K J 1/16W | |
| L15 | | | L40-3371-36 | SMALL FIXED INDUCTOR(33NH/8) | | R24 | | | RK73GB1J473J | CHIP R 47K J 1/16W | |
| L17 | | | L40-4771-36 | SMALL FIXED INDUCTOR(47NH) | | R25 | | | RK73GB1J472J | CHIP R 4.7K J 1/16W | |
| L18 | | | L39-1272-05 | TOROIDAL COIL | | R26 | | | RK73GB1J473J | CHIP R 47K J 1/16W | |
| L19 | | | L92-0138-05 | FERRITE CHIP | | R27 | | | RK73GB1J332J | CHIP R 3.3K J 1/16W | |
| L20 | | | L40-1081-36 | SMALL FIXED INDUCTOR(100NH) | | R28 | | | RK73GB1J474J | CHIP R 470K J 1/16W | |
| L21, 22 | | | L39-1272-05 | TOROIDAL COIL | | R29 | | | RK73GB1J184J | CHIP R 180K J 1/16W | |
| L23 | | | L40-8271-36 | SMALL FIXED INDUCTOR(82NH) | K2,K4 | R30 | | | RK73GB1J334J | CHIP R 330K J 1/16W | |
| L24 | | | L92-0138-05 | FERRITE CHIP | | R31 | | | RK73GB1J102J | CHIP R 1.0K J 1/16W | |
| L25 | | | L40-1081-36 | SMALL FIXED INDUCTOR(100NH) | | R32 | | | RK73GB1J104J | CHIP R 100K J 1/16W | |
| L26 | | | L92-0138-05 | FERRITE CHIP | | R33 | | | RK73GB1J184J | CHIP R 180K J 1/16W | |
| L27 | | | L40-8278-67 | SMALL FIXED INDUCTOR(82NH/8) | | R34 | | | RK73GB1J683J | CHIP R 68K J 1/16W | |
| L28 | | | L92-0138-05 | FERRITE CHIP | | R35 | | | RK73GB1J220J | CHIP R 22 J 1/16W | |
| L29 | | | L40-6875-54 | SMALL FIXED INDUCTOR(68NH) | | R36 | | | RK73GB1J154J | CHIP R 150K J 1/16W | |
| L30 | | | L92-0149-05 | FERRITE CHIP | | R37 | | | R92-1252-05 | CHIP R 0 OHM | |
| L31 | | | L40-1878-67 | SMALL FIXED INDUCTOR(18NH/8) | K,K3,M | R38 | | | RK73GB1J101J | CHIP R 100 J 1/16W | |
| L31 | | | L40-1278-67 | SMALL FIXED INDUCTOR(12NH/8) | K2,K4 | R39 | | | RK73GB1J472J | CHIP R 4.7K J 1/16W | |
| L32 | | | L34-4564-05 | AIR-CORE COIL(4T) | | R40, 41 | | | RK73GB1J334J | CHIP R 330K J 1/16W | |
| L33 | | | L40-1878-67 | SMALL FIXED INDUCTOR(18NH/8) | | R42, 43 | | | RK73GB1J223J | CHIP R 22K J 1/16W | |
| L34 | | | L40-1095-34 | SMALL FIXED INDUCTOR(1UH/8) | | R44 | | | RK73GB1J473J | CHIP R 47K J 1/16W | |
| L35 | | | L40-1088-67 | SMALL FIXED INDUCTOR(100NH/8) | K,K3,M | R45 | | | RK73GB1J472J | CHIP R 4.7K J 1/16W | |
| L35 | | | L40-1288-67 | SMALL FIXED INDUCTOR(120NH/8) | K2,K4 | R46, 47 | | | RK73GB1J223J | CHIP R 22K J 1/16W | |
| L36 | | | L40-3978-67 | SMALL FIXED INDUCTOR(39NH/8) | | R48 | | | R92-1252-05 | CHIP R 0 OHM | |
| L37 | | | L34-4568-05 | AIR-CORE COIL(8T) | | R49 | | | RK73GB1J223J | CHIP R 22K J 1/16W | |

PARTS LIST

TX-RX UNIT (X57-5740-XX)


| Ref. No. | Address | New parts | Parts No. | Description | Destination | Ref. No. | Address | New parts | Parts No. | Description | Destination |
|----------|---------|-----------|--------------|---------------------|-------------|----------|---------|-----------|--------------|---------------------|-------------|
| R50 | | | RN73GH1J913D | CHIP R 91K D 1/16W | | R123 | | | RK73GB1J183J | CHIP R 18K J 1/16W | |
| R51 | | | RN73GH1J683D | CHIP R 68K D 1/16W | | R124 | | | R92-1252-05 | CHIP R 0 OHM | |
| R52 | | | RN73GH1J913D | CHIP R 91K D 1/16W | | R127 | | | RK73GB1J103J | CHIP R 10K J 1/16W | |
| R53 | | | RK73GB1J473J | CHIP R 47K J 1/16W | | R129 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| R54 | | | RK73GB1J123J | CHIP R 12K J 1/16W | | R132,133 | | | R92-1368-05 | CHIP R 0 OHM | |
| R55 | | | RN73GH1J333D | CHIP R 33K D 1/16W | | R134 | | | R92-1252-05 | CHIP R 0 OHM | |
| R56 | | | RK73GB1J472J | CHIP R 4.7K J 1/16W | | R136 | | | RK73GB1J103J | CHIP R 10K J 1/16W | |
| R57 | | | RK73GB1J183J | CHIP R 18K J 1/16W | | R137 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R58 | | | RK73GB1J184J | CHIP R 180K J 1/16W | | R138 | | | R92-1252-05 | CHIP R 0 OHM | |
| R59 | | | RK73GB1J564J | CHIP R 560K J 1/16W | | R139,140 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R60 | | | RK73GB1J123J | CHIP R 12K J 1/16W | | R143-151 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R61 | | | RK73GB1J103J | CHIP R 10K J 1/16W | | R155 | | | RK73GB1J102J | CHIP R 1.0K J 1/16W | |
| R62 | | | RN73GH1J913D | CHIP R 91K D 1/16W | | R159 | | | RK73GB1J154J | CHIP R 150K J 1/16W | |
| R63 | | | RK73GB1J474J | CHIP R 470K J 1/16W | | R161 | | | R92-1252-05 | CHIP R 0 OHM | |
| R64 | | | RK73GB1J184J | CHIP R 180K J 1/16W | | R162 | | | RK73GB1J103J | CHIP R 10K J 1/16W | |
| R65 | | | RK73GB1J103J | CHIP R 10K J 1/16W | | R163 | | | RK73HB1J103J | CHIP R 10K J 1/16W | |
| R66 | | | R92-1252-05 | CHIP R 0 OHM | | R166 | | | RK73GB1J223J | CHIP R 22K J 1/16W | |
| R67 | | | RN73GH1J274D | CHIP R 270K D 1/16W | | R167,168 | | | R92-1252-05 | CHIP R 0 OHM | |
| R68 | | | RK73GB1J223J | CHIP R 22K J 1/16W | | R177 | | | RK73GB1J101J | CHIP R 100 J 1/16W | |
| R69 | | | R92-1252-05 | CHIP R 0 OHM | | R180 | | | RK73GB1J473J | CHIP R 47K J 1/16W | |
| R70 | | | RN73GH1J682D | CHIP R 6.8K D 1/16W | | R184 | | | RK73GB1J102J | CHIP R 1.0K J 1/16W | |
| R71 | | | RK73GB1J183J | CHIP R 18K J 1/16W | | R185 | | | RK73GB1J470J | CHIP R 47 J 1/16W | |
| R72 | | | RK73GB1J155J | CHIP R 1.5M J 1/16W | | R189 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R73 | | | RK73GB1J471J | CHIP R 470 J 1/16W | | R190 | | | RK73GB1J472J | CHIP R 4.7K J 1/16W | |
| R74 | | | RK73GB1J183J | CHIP R 18K J 1/16W | | R192 | | | RK73GB1J122J | CHIP R 1.2K J 1/16W | |
| R75 | | | RN73GH1J683D | CHIP R 68K D 1/16W | | R195 | | | RK73GB1J222J | CHIP R 2.2K J 1/16W | |
| R76 | | | RK73GB1J474J | CHIP R 470K J 1/16W | | R199 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R78 | | | RN73GH1J682D | CHIP R 6.8K D 1/16W | | R202 | | | RK73GB1J271J | CHIP R 270 J 1/16W | |
| R79 | | | RK73GB1J101J | CHIP R 100 J 1/16W | | R217 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| R80 | | | RK73GB1J152J | CHIP R 1.5K J 1/16W | | R218 | | | RK73GB1J220J | CHIP R 22 J 1/16W | K,K3,M |
| R81 | | | RK73GB1J220J | CHIP R 22 J 1/16W | | R218 | | | RK73GB1J820J | CHIP R 82 J 1/16W | K2,K4 |
| R83 | | | RK73GB1J184J | CHIP R 180K J 1/16W | | R220 | | | RK73HB1J102J | CHIP R 1.0K J 1/16W | |
| R84 | | | R92-1252-05 | CHIP R 0 OHM | | R221 | | | RK73GB1J221J | CHIP R 220 J 1/16W | K,K3,M |
| R85 | | | RK73GB1J103J | CHIP R 10K J 1/16W | | R239 | | | R92-1252-05 | CHIP R 0 OHM | |
| R86 | | | RK73GB1J223J | CHIP R 22K J 1/16W | | R240 | | | RK73GB1J331J | CHIP R 330 J 1/16W | |
| R89 | | | RK73GB1J102J | CHIP R 1.0K J 1/16W | | R243 | | | RK73GB1J220J | CHIP R 22 J 1/16W | K,K3,M |
| R90 | | | RK73GB1J153J | CHIP R 15K J 1/16W | | R244 | | | RK73EB2ER39K | CHIP R 0.39 K 1/4W | |
| R91 | | | RK73GB1J473J | CHIP R 47K J 1/16W | | R246 | | | RK73EB2ER39K | CHIP R 0.39 K 1/4W | |
| R93 | | | RK73HB1J682J | CHIP R 6.8K J 1/16W | | R247 | | | R92-1252-05 | CHIP R 0 OHM | |
| R94 | | | RK73HB1J563J | CHIP R 56K J 1/16W | | R248 | | | RK73EB2ER39K | CHIP R 0.39 K 1/4W | |
| R95 | | | RK73GB1J394J | CHIP R 390K J 1/16W | | R249 | | | R92-1252-05 | CHIP R 0 OHM | |
| R96 | | | RK73GB1J122J | CHIP R 1.2K J 1/16W | K,K3,M | R250-252 | | | RN73GH1J154D | CHIP R 150K D 1/16W | |
| R96 | | | RK73GB1J821J | CHIP R 820 J 1/16W | K2,K4 | R253 | | | RK73GB1J221J | CHIP R 220 J 1/16W | |
| R97 | | | RK73GB1J151J | CHIP R 150 J 1/16W | | R254-256 | | | RN73GH1J154D | CHIP R 150K D 1/16W | |
| R99 | | | RK73GB1J104J | CHIP R 100K J 1/16W | | R257 | | | RK73GB1J221J | CHIP R 220 J 1/16W | |
| R100 | | | R92-1252-05 | CHIP R 0 OHM | | R258,259 | | | R92-1252-05 | CHIP R 0 OHM | |
| R101 | | | RK73GB1J560J | CHIP R 56 J 1/16W | | R260 | | | RK73GB1J103J | CHIP R 10K J 1/16W | |
| R102 | | | RK73GB1J333J | CHIP R 33K J 1/16W | | R261 | | | RK73GB1J470J | CHIP R 47 J 1/16W | |
| R104 | | | RK73GB1J102J | CHIP R 1.0K J 1/16W | | R262,263 | | | RK73GB1J104J | CHIP R 100K J 1/16W | |
| R106 | | | RK73GB1J470J | CHIP R 47 J 1/16W | | R264 | | | RK73GB1J680J | CHIP R 68 J 1/16W | |
| R107 | | | RK73GB1J473J | CHIP R 47K J 1/16W | | R265 | | | RK73GB1J473J | CHIP R 47K J 1/16W | |
| R109 | | | R92-1252-05 | CHIP R 0 OHM | | R266 | | | RK73GB1J683J | CHIP R 68K J 1/16W | |
| R110 | | | RK73GB1J220J | CHIP R 22 J 1/16W | | R267 | | | R92-1252-05 | CHIP R 0 OHM | |
| R112 | | | R92-1252-05 | CHIP R 0 OHM | | R268 | | | RK73GB1J105J | CHIP R 1.0M J 1/16W | |
| R114 | | | RK73GB1J223J | CHIP R 22K J 1/16W | | R269,270 | | | RK73GB1J473J | CHIP R 47K J 1/16W | |
| R115 | | | RK73GB1J184J | CHIP R 180K J 1/16W | | R271 | | | R92-1252-05 | CHIP R 0 OHM | |
| R116 | | | RK73GB1J103J | CHIP R 10K J 1/16W | | R272 | | | RK73GB1J222J | CHIP R 2.2K J 1/16W | |
| R118 | | | RK73GB1J331J | CHIP R 330 J 1/16W | | R273 | | | RK73GB1J103J | CHIP R 10K J 1/16W | |
| R119 | | | RK73GB1J101J | CHIP R 100 J 1/16W | | R274 | | | RK73GB1J470J | CHIP R 47 J 1/16W | |
| R120 | | | RK73GB1J224J | CHIP R 220K J 1/16W | | R276 | | | RK73GB1J103J | CHIP R 10K J 1/16W | |
| R121 | | | RK73GB1J222J | CHIP R 2.2K J 1/16W | | R281 | | | RK73GB1J331J | CHIP R 330 J 1/16W | |
| R122 | | | RK73GB1J331J | CHIP R 330 J 1/16W | | R282,283 | | | RK73GB1J472J | CHIP R 4.7K J 1/16W | |

PARTS LIST


TX-RX UNIT (X57-5740-XX)
SUB UNIT (X58-4580-10)

| Ref. No. | Address | New parts | Parts No. | Description | Destination | Ref. No. | Address | New parts | Parts No. | Description | Destination |
|----------|---------|-----------|----------------|-------------------------------|-------------|---|---------|-----------|---------------|------------------------------|-------------|
| R284 | | | R92-1252-05 | CHIP R 0 OHM | | Q13 -15 | | | 2SK1824 | FET | |
| R294 | | | RK73GB1J221J | CHIP R 220 J 1/16W | | Q16 | | | 2SC5108(Y) | TRANSISTOR | |
| R295 | | | R92-1252-05 | CHIP R 0 OHM | | Q17 | | | 2SK1824 | FET | |
| R296,297 | | | RK73HB1J473J | CHIP R 47K J 1/16W | | Q18 | | | 2SC5108(Y) | TRANSISTOR | |
| R298-300 | | | R92-1252-05 | CHIP R 0 OHM | | Q19 | | | 2SC4619 | TRANSISTOR | |
| R303-305 | | | R92-1252-05 | CHIP R 0 OHM | | Q20 | | | 2SC4988 | TRANSISTOR | |
| R306 | | | RK73HB1J474J | CHIP R 470K J 1/16W | | Q21 | | | 2SK1824 | FET | |
| R307 | | | RK73GB1J272J | CHIP R 2.7K J 1/16W | | Q22 | | | DTC114EE | DIGITAL TRANSISTOR | |
| R308 | | | RK73GB1J684J | CHIP R 680K J 1/16W | | Q23 | | | 2SK1824 | FET | |
| R309 | | | RK73GB1J221J | CHIP R 220 J 1/16W | K,K3,M | Q24 | | | 3SK239A | FET | |
| R310 | | | RK73GB1J221J | CHIP R 220 J 1/16W | K2,K4 | Q25 | | | DTA144EE | DIGITAL TRANSISTOR | |
| D1 | | | 1SR154-400 | DIODE | | TH1 | | | 157-302-65801 | THERMISTOR | |
| D2 ,3 | | | MA2S111 | DIODE | | A1 | | | X58-4580-10 | SUB UNIT | K,K3,M |
| D4 | | | RB706F-40 | DIODE | | A1 | | * | X58-4580-11 | SUB UNIT | K2,K4 |
| D5 | | | DAN222 | DIODE | | A1:SUB UNIT (VCO) X58-4580-XX The A1 is replaceable as a unit assembly so individual parts are not kept in stock. | | | | | |
| D6 | | | MA2S111 | DIODE | | C1 | | | CK73HB1C103K | CHIP C 0.010UF K | |
| D7 | | | DAN222 | DIODE | | C2 | | * | CC73HCH1H100B | CHIP C 10PF B | |
| D8 | | | RB706F-40 | DIODE | | C3 | | | CK73HB1H102K | CHIP C 1000PF K | |
| D9 | | | MA2S077 | DIODE | | C4 | | | CC73HCH1H101J | CHIP C 100PF J | |
| D10 | | | HZU5ALL | DIODE | | C5 | | | CC73HCH1H470J | CHIP C 47PF J | |
| D12 | | | HVU131 | DIODE | | C6 | | | CC73HCH1H120J | CHIP C 12PF J | |
| D14 | | | MA2S077 | DIODE | | C7 | | | CK73HB1C103K | CHIP C 0.010UF K | |
| D15 | | | HSM88AS | DIODE | | C9 | | | CC73HCH1H0R5B | CHIP C 0.5PF B | |
| D16 ,17 | | | HVC200A | VARIABLE CAPACITANCE DIODE | | C10 | | | CK73HB1H102K | CHIP C 1000PF K | |
| D18 ,19 | | | DA221 | DIODE | | C11 | | * | CC73HCH1H070B | CHIP C 7.0PF B | |
| D20 | | | HVC200A | VARIABLE CAPACITANCE DIODE | | C12 | | * | CC73HCH1H090B | CHIP C 9.0PF B | |
| D21 | | | HVC200A | VARIABLE CAPACITANCE DIODE | K,K3,M | C13 | | * | CC73HCH1H070B | CHIP C 7.0PF B | |
| D22 ,23 | | | MA2S077 | DIODE | | C14 | | | CC73HCH1H120J | CHIP C 12PF J | |
| D24 | | | 1SS373 | DIODE | | C15 | | | CC73HCH1H0R5B | CHIP C 0.5PF B | |
| IC1 | | | TA75W01FU | IC(OP AMP X2) | | C16 | | | C92-0606-05 | CHIP-TAN 4.7UF 10WV | |
| IC2 | | | TC75W51FU | IC(OP AMP X2) | | C17 | | | CC73HCH1H0R5B | CHIP C 0.5PF B | |
| IC3 | | | RN5VL42C | IC(REGULATOR) | | C18 | | | CK73HB1C103K | CHIP C 0.010UF K | |
| IC4 | | | TC75W51FU | IC(OP AMP X2) | | C19 | | | CK73HB1H102K | CHIP C 1000PF K | |
| IC5 | | | S-81350HG-KD | IC(VOLTAGE REGULATOR) | | C20 | | | CC73HCH1H150J | CHIP C 15PF J | |
| IC6 | | | NJU7201U50 | IC(VOLTAGE REGULATOR) | | C21 | | | CK73HB1C103K | CHIP C 0.010UF K | |
| IC7 | | | TC75W51FU | IC(OP AMP X2) | | TC1 ,2 | | | C05-0384-05 | CERAMIC TRIMMER CAP(10P/8) | |
| IC8 | | | M62364FP | IC(D/A CONVERTER) | | CN1 ,2 | | | E40-5622-05 | PIN ASSY | |
| IC9 | | | TK11250BM | IC(VOLTAGE REGULATOR) | | L1 | | | L40-3391-37 | SMALL FIXED INDUCTOR(3.3UH) | |
| IC10 | | | TA75S01F | IC(OP AMP) | | L2 | | | L40-4791-37 | SMALL FIXED INDUCTOR(4.7UH) | |
| IC11 | | | TA75W01FU | IC(OP AMP X2) | | L3 ,4 | | | L40-2291-37 | SMALL FIXED INDUCTOR(2.2UH) | |
| IC12 | | | TA31136FN | IC(FM IF DETECTOR) | | L5 | | * | L34-4577-05 | AIR-CORE COIL(9T) | |
| IC13 | | | TC35453F | IC(AUDIO PROCESSOR) | | L6 | | * | L34-4575-05 | AIR-CORE COIL(7T) | |
| IC14 | | | SA7025DK | IC(PLL SYSTEM) | | L7 | | | L92-0138-05 | FERRITE CHIP | |
| IC16 | | | LC73872M | IC(DTMF RECEIVER) | | L8 | | | L40-8275-44 | SMALL FIXED INDUCTOR(82.0NH) | |
| IC17 | | | AT29C020-90TI | IC | | R1 | | | RK73HB1J334J | CHIP R 330K J 1/16W | |
| IC18 | | | GN2011(Q) | IC | | R2 | | | RK73HB1J473J | CHIP R 47K J 1/16W | |
| IC19 | | | 30612M4A-407GP | IC(CPU) | | R3 | | | RK73HB1J274J | CHIP R 270K J 1/16W | |
| IC20 | | | AT2408N10SI2.5 | IC(8kbit SERIAL EEPROM) | | R4 | | | RK73HB1J104J | CHIP R 100K J 1/16W | |
| IC21,22 | | | BU4094BCFV | IC(8bit SHIFT/STORE REGISTER) | | R5 ,6 | | | RK73HB1J391J | CHIP R 390 J 1/16W | |
| IC23 | | | NJM2904V | IC(APC) | | R7 | | | RK73HB1J334J | CHIP R 330K J 1/16W | |
| IC24 | | | TC7S66FU | IC(ANALOG SWITCH) | | R8 | | | RK73HB1J470J | CHIP R 47 J 1/16W | |
| Q1 | | | DTC144EE | DIGITAL TRANSISTOR | | D1 -8 | | | HVC350B | VARIABLE CAPACITANCE DIODE | |
| Q2 | | | 2SJ243 | FET | | D9 | | | HVC351 | VARIABLE CAPACITANCE DIODE | |
| Q3 | | | 2SA1745(6,7) | TRANSISTOR | | Q1 | | | 2SJ243 | FET | |
| Q4 | | | 2SC4617(S) | TRANSISTOR | | Q2 ,3 | | | 2SK508NV(K52) | FET | |
| Q5 | | | 2SJ243 | FET | | Q4 | | | UMC4 | TRANSISTOR | |
| Q6 | | | DTA144EE | DIGITAL TRANSISTOR | | Q5 | | | 2SC5108(Y) | TRANSISTOR | |
| Q7 | | | DTC144EE | DIGITAL TRANSISTOR | | | | | | | |
| Q8 | | | 2SC4617(S) | TRANSISTOR | | | | | | | |
| Q9 ,10 | | | DTC144EE | DIGITAL TRANSISTOR | | | | | | | |
| Q11 | | | 2SK1824 | FET | | | | | | | |
| Q12 | | | 2SC5108(Y) | TRANSISTOR | | | | | | | |

EXPLODED VIEW



PACKING



ADJUSTMENT

Test Equipment Required for Alignment

| Test Equipment | Major Specifications | |
|---------------------------------------|---|--|
| 1. Standard Signal Generator (SSG) | Frequency Range Modulation Output | 136 to 174MHz Frequency modulation and external modulation. -127dBm/0.1μV to greater than -47dBm/1mV |
| 2. Power Meter | Input Impedance Operation Frequency Measurement Range | 50Ω. 136 to 174MHz or more. Vicinity of 10W |
| 3. Deviation Meter | Frequency Range | 136 to 174MHz. |
| 4. Digital Volt Meter (DVM) | Measuring Range Input Impedance | 10mV to 10V DC High input impedance for minimum circuit loading. |
| 5. Oscilloscope | | DC through 30MHz. |
| 6. High Sensitivity Frequency Counter | Frequency Range Frequency Stability | 10Hz to 1000MHz. 0.2ppm or less. |
| 7. Ammeter | | 5A. |
| 8. AF Volt Meter (AF VTVM) | Frequency Range Voltage Range | 50Hz to 10kHz. 1mV to 10V. |
| 9. Audio Generator (AG) | Frequency Range Output | 50Hz to 5kHz or more. 0 to 1V. |
| 10. Distortion Meter | Capability Input Level | 3% or less at 1kHz. 50mV to 10Vrms. |
| 11. 16Ω Dummy Load | | Approx. 16Ω, 3W. |
| 12. Regulated Power Supply | | 5V to 10V, approx. 5A Useful if ammeter equipped. |

■ The following parts are required for adjustment

1. Antenna connector adapter

The antenna connector of this radio uses an SMA terminal. Use an antenna connector adapter [SMA(f) – BNC(f) or SMA(f) – N(f)] for adjustment. (The adapter is not provided as an option, so buy a commercially-available one.)

Note

When the antenna connector adapter touches the knob, draw out the knob to mount the connector.

2. Universal connector


Use the interface cable (KPG-36) for PC tuning or the lead wire with plug (E30-3287-18) and screw (N08-0535-08) for panel tuning. Connect the plug to the universal connector of the radio and tighten the screw.

The lead wire with plug (E30-3287-18) and screw (N08-0535-08) terminals are as follows. Numbers are universal connector terminal numbers.

Caution



1. When connecting the plug to the universal connector of the radio, a short circuit may occur. To prevent this, be sure to turn the radio POWER switch off.
2. Since the RX AF output is a BTL output, there is a DC component. Isolate this with a capacitor or transformer as shown in the figure.
3. Do not connect an instrument between red or black and GND.

• Universal connector



ADJUSTMENT



• Panel tuning



• PC tuning

Connect the wires to the PCB in the connector case of interface cable.


For output the wires out of the connector case, need to process the connector case.



Repair Jig (Chassis)


Use jig (part No.: A10-1383-14) for repairing the TK-280.

The jig facilitates the voltage check and protects the module when the voltage on the flow side of the TX-RX unit is checked during repairs.




How to Remove the Flat Cable

1. Gently draw out both sides of the connector lever uniformly in the direction of the arrow with tweezers. (CN300, CN301)



2. Gently rise up the connector lever in the direction of the arrow with a fine regular screwdriver or tweezers. (CN1, CN3, CN304)



ADJUSTMENT

Test Mode

■ Test mode operating features

This transceiver has a test mode. **To enter test mode, press [A] key and turn power on. Hold [A] key until test channel No. and test signalling No. appears on LCD.** Test mode can be inhibited by programming. To exit test mode, switch the power on again. The following functions are available in test mode.

• Controls

| Controls | "FCN" appears | "FCN" not appears |
|-------------------------|--|--|
| [PTT] | Used when making a transmission. | Used when making a transmission. |
| [AUX] | Unused | Unused |
| [MON] | Monitor ON and OFF. | Monitor ON and OFF. |
| [LAMP] | Lights the lamp for five seconds. Lighting is extended for a further five seconds by pressing any key while the lamp is lit. | Changes wide and narrow. |
| [S] | Sets to the Tuning mode. | Sets to the Tuning mode. |
| [A] | Function OFF | Function ON. |
| [B] | Compander function ON and OFF. | RF power HIGH and LOW. |
| [C] | Best shift ON and OFF. | Changes signalling. |
| [O] to [9], and [#],[*] | Used as the DTMF keypad. If a key is pressed during transmission, the DTMF corresponding to the key that was pressed is sent. (keypad model) | Used as the DTMF keypad. If a key is pressed during transmission, the DTMF corresponding to the key that was pressed is sent. (keypad model) |
| [ENCODER] | Changes channel. | Changes channel. |

Note: If a [S],[A],[B],[C] key is pressed during transmission, the DTMF corresponding to the key that was pressed is sent.

• LCD indicator

| | |
|---|-------------------------|
| "SCN" | Unused |
| "  | Lights at Compander ON. |
| "LO" | Lights at RF Power Low. |
| "P" | Unused |
| "MON" | Lights at monitor ON. |
| "SVC" | Unused |
| "  | Unused |

• LED indicator

| | |
|-----------|--|
| Red LED | Lights during transmission. Blinks at the low battery voltage warning. |
| Green LED | Lights when there is a carrier. |

• Sub LCD indicator

| | |
|-------|-------------------------|
| "FCN" | appears at Function ON. |
| "n" | appears at Narrow ON. |

■ Frequency and signalling

The set has been adjusted for the frequencies shown in the following table. When required, re-adjust them following the adjustment procedure to obtain the frequencies you want in actual operation.

Frequency (MHz)

| Channel No. | VHF-F1 K, K3, M | |
|-------------|-----------------|-----------|
| | RX | TX |
| 1 | 160.05000 | 160.10000 |
| 2 | 146.05000 | 146.10000 |
| 3 | 173.95000 | 173.90000 |
| 4 | 160.00000 | 160.00000 |
| 5 | 160.20000 | 160.20000 |
| 6 | 160.40000 | 160.40000 |
| 7~16 | — | — |

| Channel No. | VHF-F2 K2, K4 | |
|-------------|---------------|-----------|
| | RX | TX |
| 1 | 149.05000 | 149.10000 |
| 2 | 136.05000 | 136.10000 |
| 3 | 161.95000 | 161.90000 |
| 4 | 149.00000 | 149.00000 |
| 5 | 149.20000 | 149.20000 |
| 6 | 149.40000 | 149.40000 |
| 7~16 | — | — |

Signalling

| Signalling No. | RX | TX |
|----------------|----------------------|--------------------|
| 1 | None | None |
| 2 | None | 100Hz square |
| 3 | LTR data | LTR data |
| 4 | QT 67.0Hz | QT 67.0Hz |
| 5 | QT 151.4Hz | QT 151.4Hz |
| 6 | QT 210.7Hz | QT 210.7Hz |
| 7 | QT 250.3Hz | QT 250.3Hz |
| 8 | DQT D023N | DQT D023N |
| 9 | DQT D754I | DQT D754I |
| 10 | DTMF DEC, (159D) | DTMF ENC, (159D) |
| 11 | None | DTMF tone 9 |
| 12 | 2 tone 321.7/928.1Hz | None |
| 13 | Single tone 1200Hz | Single tone 1200Hz |
| 14 | None | MSK |
| 15 | MSK code | MSK code |

• Preparations for tuning the transceiver

Before attempting to tune the transceiver, connect the unit to a suitable power supply.

When ever the transmitter is turned, the unit must be connected to a suitable dummy load (i.e. power meter).

The speaker output connector must be terminated with a 16Ω dummy load and connected to an AC voltmeter and an audio distortion meter or a SINAD measurement meter at all times during tuning.


• Transceiver tuning

(To place transceiver in tuning mode)

Channel appears on LCD. Set channel according to tuning requirements.

ADJUSTMENT

LCD display (Test mode)



Press [S], now in tuning mode. Use [◀ B] button to write tuning data through tuning modes, and channel selector knob to adjust tuning requirements (1 to 256 appears on LCD).

Use [C ▶] button to select the adjustment item through tuning modes. Use [A] button to adjust 3 or 5 point tuning, and use [LAMP] button to switch between Wide/Narrow.

LCD display (Tuning mode)




Panel Tuning Mode

| TEST Ch | VHF-F1 K,K3,M | |
|---------|--------------------|--------------------|
| | RX frequency (MHz) | TX frequency (MHz) |
| L | 146.05000 | 146.10000 |
| L2 | 153.05000 | 153.10000 |
| C | 160.05000 | 160.10000 |
| H2 | 167.05000 | 167.10000 |
| H | 173.95000 | 173.90000 |

| TEST Ch | VHF-F2 K2,K4 | |
|---------|--------------------|--------------------|
| | RX frequency (MHz) | TX frequency (MHz) |
| L | 136.05000 | 136.10000 |
| L2 | 142.55000 | 142.60000 |
| C | 149.05000 | 149.10000 |
| H2 | 155.55000 | 155.60000 |
| H | 161.95000 | 161.90000 |

Tuning mode



ADJUSTMENT

Common Section

| Item | Condition | Measurement | | | Adjustment | | | Specifications/ Remark |
|---------------------|---|--------------------|----------------|------------------|------------|-------|--------|---------------------------|
| | | Test equipment | Unit | Terminal | Unit | Parts | Method | |
| 1. Setting | 1) BATT terminal voltage:7.5V 2) SSG Standard modulation [Wide] MOD:1kHz, DEV:3kHz [Narrow] MOD:1kHz, DEV:1.5kHz | | | | | | | |
| 2. VCO lock voltage | [Panel Test Mode] | | | | | | | |
| RX | 1) CH-Sig:2-1 | Power meter DVM | Panel TX-RX | ANT CV (CN14) | | | Check | 0.8V or more |
| | 2) CH-Sig:3-1 | | | | | | | 4.4V or less |
| TX | 3) CH-Sig:2-1 PTT:ON | | | | | | | 0.8V or more |
| | 4) CH-Sig:3-1 PTT:ON | | | | | | | 4.4V or less |

Transmitter Section [Panel Tuning Mode except when Panel TEST Mode is specified.]

| Item | Condition | Measurement | | | Adjustment | | | Specifications/ Remark |
|-----------------------|---|-------------------------|-------|----------|------------|--------------|--|---|
| | | Test equipment | Unit | Terminal | Unit | Parts | Method | |
| 1. Frequency Adjust | 1) Adj item [FREQ] Adjust [***] PTT:ON | Power meter Am meter | Panel | ANT | Panel | Encoder knob | Center frequency ± 100Hz (Note:) After replacing the VCXO (X1), align using KPG-49D. | |
| 2. Max Power Check | 1) Adj item [HPOW] Adjust [256] 2) Adj item [L HPOW] → [L2 HPOW] → [C HPOW] → [H2 HPOW] → [H HPOW] Adjust [256] PTT:ON | | | | | | Check | 5.3W or more |
| 3. Hight Power Adjust | 1) Adj item [HPOW] Adjust [***] 2) Adj item [L HPOW] → [L2 HPOW] → [C HPOW] → [H2 HPOW] → [H HPOW] Adjust [***] PTT:ON | | | | | Encoder knob | K, K3, M : 5.0W K2, K4 : 4.8W | ±0.1W 2.2A or less |
| 4. Hight Power Check | [Panel Test Mode] 1) CH-Sig:1-1 PTT:ON 2) CH-Sig:2-1 PTT:ON 3) CH-Sig:3-1 PTT:ON | | | | | | Check | K, K3, M : 4.8~5.2W K2, K4 : 4.6~5.0W 2.3A or lessZ |
| 5. Low Power Adjust | 1) Adj item [LPOW] Adjust [***] 2) Adj item [L LPOW] → [L2 LPOW] → [C LPOW] → [H2 LPOW] → [H LPOW] Adjust [***] PTT:ON | | | | | | 0.8W | ±0.1W 1.0A or less |
| 6. Low Power Check | [Panel Test Mode] 1) CH-Sig:1-1 Set low power (Push [B]) PTT:ON 2) CH-Sig:2-1 PTT:ON 3) CH-Sig:3-1 PTT:ON | | | | | | Check | 0.5~1.5W 1.2A or less |

ADJUSTMENT

[Panel Tuning Mode except when Panel TEST Mode is specified.]

| Item | Condition | Measurement | | | Adjustment | | | Specifications/ Remark |
|--|--|---|-------|-------------------------------|------------|-----------------|---|---|
| | | Test equipment | Unit | Terminal | Unit | Parts | Method | |
| 7. Max DEV Adjust [Wide] | 1) Adj item [MAX] Adjust [***] AG:1kHz / 150mV Dev meter filter LPF:15kHz HPF:OFF | Power meter Dev meter Oscilloscope AG AF VTVM | Panel | ANT universal connector | Panel | Encoder knob | 3.8kHz (According to the larger +,-) | ±50Hz |
| | 2) Adj item [L MAX] → [C MAX] → [H MAX] Adjust [***] PTT:ON | | | | | | | |
| [Narrow] | 1) Adj item [n MAX] Adjust [***] PTT:ON | | | | | | 1.75kHz (According to the larger+,-) | |
| 8. MIC Sensitivity Check | [Panel Test Mode] 1) CH-Sig:1-1 AG:1kHz / 15mV LPF:15kHz PTT:ON | | | | | | Check | 2.2~3.0kHz |
| 9. DQT Balance Adjust [Wide] | 1) Adj item [BAL] Adjust [***] LPF:3kHz HPF:OFF | Power meter Dev meter Oscilloscope AG AF VTVM | Panel | ANT universal connector | Panel | Encoder knob | Make the demodulation waves into square waves. |  |
| | 2) Adj item [L BAL] → [C BAL] → [H BAL] Adjust [***] PTT:ON | | | | | | | |
| [Narrow] | 3) Adj item [n BAL] Adjust [***] PTT:ON | | | | | | | |
| 10.QT Deviation Adjust [Wide] | 1) Adj item [FQT] Adjust [***] LPF:3kHz HPF:OFF | | | | | | Wide:0.75kHz Narrow:0.35kHz | ±50Hz |
| | 2) Adj item [L FQT] → [C FQT] → [H FQT] Adjust [***] PTT:ON | | | | | | | |
| [Narrow] | 3) Adj item [n FQT] Adjust [***] PTT:ON | | | | | | | |
| 11.DQT Devition Adjust [Wide] | 1) Adj item [FDQT] Adjust [***] LPF:3kHz HPF:OFF | | | | | | | |
| | 2) Adj item [L FDQT] → [C FDQT] → [H FDQT] Adjust [***] PTT:ON | | | | | | | |
| [Narrow] | 3) Adj item [n FDQT] Adjust [***] PTT:ON | | | | | | | |

ADJUSTMENT

[Panel Tuning Mode except when Panel TEST Mode is specified.]


| Item | Condition | Measurement | | | Adjustment | | | Specifications/ Remark |
|--|---|---|-------|-------------------------------|------------|-----------------|--|-------------------------------|
| | | Test equipment | Unit | Terminal | Unit | Parts | Method | |
| 12.LTR Deviation Adjust [Wide] | 1) Adj item [FLTR] Adjust [***] LPF:3kHz HPF:OFF | Power meter Dev meter Oscilloscope AG AF VTVM | Panel | ANT universal connector | Panel | Encoder knob | 1.0kHz | ±0.1kHz |
| | 2) Adj item [L FLTR] → [C FLTR] → [H FLTR] Adjust [***] PTT:ON | | | | | | 0.75kHz | |
| [Narrow] | 3) Adj item [n FLTR] Adjust [***] PTT:ON | | | | | | ±50Hz | |
| 13.DTMF Deviation Adjust [Wide] | 1) Adj item [DTMF] Adjust [***] LPF:15kHz HPF:OFF PTT:ON | | | | | | Wide:2.5kHz Narrow:1.25kHz | ±0.1kHz |
| | [Narrow] | 2) Adj item [n DTMF] Adjust [***] PTT:ON | | | | | | |
| 14.MSK Deviation Adjust [Wide] | 1) Adj item [FMSK] Adjust [***] LPF:15kHz HPF:OFF PTT:ON | | | | | | | |
| | [Narrow] | 2) Adj item [n FMSK] Adjust [***] PTT:ON | | | | | | |
| 15.TONE Deviation Adjust [Wide] | 1) Adj item [TONE] Adjust [***] LPF:15kHz HPF:OFF PTT:ON | | | | | | | |
| | [Narrow] | 2) Adj item [n TONE] Adjust [***] PTT:ON | | | | | | |
| 16.BATT Detection Writing | 1) Adj item [BATT] Adjust [***] PTT:ON | Power meter DVM | Panel | ANT BATT terminal | Panel | Encoder knob | After pressing the PTT switch, confirm that one predeter- mined numeric in the range 1 to 256 appears and then press [B] key. That numeric will be stored in memory. | BATT terminal voltage:6.2V |
| 17.BATT Detection Check | [Panel Test Mode] 1) CH-Sig:1-1 BATT terminal voltage:6.5V PTT:ON | | | | | | Check | No blinking of LED |
| | 2) BATT terminal voltage:5.7V PTT:ON | | | | | | | Blinking of LED |

ADJUSTMENT

Receiver Section [Panel Tuning Mode except when Panel TEST Mode is specified.]

| Item | Condition | Measurement | | | Adjustment | | | Specifications/ Remark |
|--------------------------|--|------------------------------------|-------|-----------------------------------|------------|-----------------|---|--|
| | | Test equipment | Unit | Terminal | Unit | Parts | Method | |
| 1. Sensitivity Adjust | 1) Adj item [SENS] Adjust [***] 2) Adj item [L SENS] → [C SENS] → [H SENS] Adjust [***] SSG OUT:-118dBm MOD:1kHz / ±3kHz | SSG AF VTVM Oscilloscope | Panel | ANT Universal Connector | Panel | Encoder knob | Adjust for maximam SINAD. | 14dB SINAD or more. |
| 2. Sensitivity Check | [Panel Test Mode] 1) CH-Sig:1-1 SSG OUT Wide:-118dBm (MOD:1kHz / ±3kHz) Narrow:-117dBm (MOD:1kHz / ±1.5kHz) | | | | | | Check | 12dB SINAD or more |
| 3. Squelch Adjust | 1) Adj item [SQL] Adjust [***] SSG OUT: 12dB SINAD level 2) Adj item [n SQL] Adjust [***] 12dB SINAD level | | | | | Encoder knob | Adjust to point of opening squelch. | |
| 4. Squelch Check | [Panel Test Mode] 1) CH-Sig:1-1 SSG OUT: 12dB SINAD level 2) SSG OUT:OFF | | | | | | Check | Squelch must be opened. Squelch must be closed. |

Adjustment points
TX-RX unit (X57-5740)
component side view



TERMINAL FUNCTION



| CN No. | Pin No. | Name | I/O | Function |
|---|---------|------|-----|---|
| TX-RX UNIT (X57-5740-XX): TX-RX section | | | | |
| CN1 | 1 | B | O | Power input after passing through the fuse. |
| | 2 | B | O | Power input after passing through the fuse. |
| | 3 | SB | I | Power output after power switch. |
| | 4 | SB | I | Power output after power switch. |
| | 5 | 5M | O | 5V. |
| | 6 | VOL | I | Volume level input for audio control. |
| | 7 | E | - | GND |
| | 8 | EN2 | I | Encoder pulse input. |
| | 9 | E | - | GND |
| | 10 | EN1 | I | Encoder pulse input. |
| CN2 for X54- SW section | 1 | MON | I | Normally; 5V. MON when connected GND. |
| | 2 | LAMP | I | Normally; 5V. LAMP when connected GND. |
| | 3 | PTT | I | Normally; 5V. transmit when connected GND. |
| | 4 | GND | - | GND |
| CN3 for X54- Display unit | 1 | AF | O | Audio output. |
| | 2 | AFE | - | Audio GND. |
| | 3 | NC | - | Not use. |
| | 4 | PF | I | External PF signal input. |
| | 5 | CK | O | Clock data output. |
| | 6 | RXD | I | Serial control signal input. |
| | 7 | TXD | O | Serial control signal output. |
| | 8 | DT | O | Data output for LCD driver/decade counter. |
| | 9 | KRS | O | Key scan IC reset output. |
| | 10 | KI1 | I | KEY input |
| | 11 | KI2 | I | KEY input |
| | 12 | GND | - | GND |
| | 13 | 5M | O | 5V. |
| | 14 | AM | O | Audio mute signal output. Mute: "L". Unmute: "H" |
| | 15 | CS | O | LCD driver chip select output. |
| | 16 | NC | - | Not use. |
| | 17 | PTT | I | PTT signal input. |
| | 18 | AUX | I | AUX key input. |
| | 19 | LR | O | TX LED control. Normally: 0V, lighting: 5V. |
| | 20 | LG | O | RX LED control. Normally: 0V, lighting: 5V. |
| | 21 | LBL | O | Backlight LED control. Normally: 0V, lighting: 5V. |
| | 22 | ME | - | MIC GND. |
| | 23 | MIC | I | MIC signal input. |
| | 24 | SB | O | Power output after power switch. |
| DISPLAY UNIT (X54-3210-XX A/2) : DISPLAY section | | | | |
| CN300 for X57- TX-RX unit | 1 | SB | I | Power input after power switch. |
| | 2 | MIC | O | MIC signal output. |
| | 3 | ME | - | MIC GND. |
| | 4 | LBL | I | Backlight LED control. Normally: 0V, lighting: 5V. |
| | 5 | LG | I | RX LED control. Normally: 0V, lighting: 5V. |
| | 6 | LR | I | TX LED control. Normally: 0V, lighting: 5V. |
| | 7 | AUX | O | AUX key output. |

| CN No. | Pin No. | Name | I/O | Function | |
|--|---------|--------|-----|--|------------------------------------|
| | 8 | PTT | O | PTT signal output. | |
| | 9 | NC | - | Not use. | |
| | 10 | CS | I | LCD driver chip select input. | |
| | 11 | AM | I | Audio mute signal input. Mute: "L", Unmute: "H" | |
| | 12 | 5M | I | 5V. | |
| | 13 | GND | - | GND | |
| | 14 | KI2 | O | KEY output | |
| | 15 | KI1 | O | KEY output | |
| | 16 | KRS | I | Key scan IC reset input | |
| | 17 | DT | I | Data input for LCD driver/decade counter. | |
| | 18 | TXD | I | Serial control signal input. | |
| | 19 | RXD | O | Serial control signal output. | |
| | 20 | CK | I | Clock data input. | |
| | 21 | PF | O | External PF signal output. | |
| | 22 | NC | - | Not use. | |
| | 23 | AFE | - | Audio GND. | |
| | 24 | AF | I | Audio input. | |
| | CN301 | 1 | SSW | I | EXT/INT speaker switch input. |
| | | 2 | SP+ | O | BTL output + for external speaker. |
| | | 3 | SP- | O | BTL output - for external speaker. |
| | | 4 | MSW | I | EXT/INT MIC switch input. |
| | | 5 | EMC | I | External microphone input. |
| | | 6 | ME | - | External microphone ground. |
| | | 7 | PTT | I | External PTT input. |
| 8 | | PF | I | Programmable function key input. | |
| 9 | | NC | - | Not use. | |
| 10 | | E | - | GND | |
| 11 | | 5M | O | 5V output | |
| 12 | | TXD | O | Serial data output. | |
| 13 | | RXD | I | Serial data input. | |
| 14 | | NC (E) | - | Not use (GND) | |
| CN302 | 1 | SP | O | Output for internal speaker. | |
| | 2 | E | - | GND | |
| CN304 | 1 | NC | - | Not use. | |
| | 2 | LEDK | I | Backlight LED control. | |
| | 3 | LEDA | O | Backlight LED control. | |
| | 4 | VCI | O | LCD power supply. | |
| | 5 | SOD | O | Serial data output for LCD driver. | |
| | 6 | SID | I | Serial data input for LCD driver. | |
| | 7 | SCLK | O | Clock data output for LCD driver. | |
| | 8 | CS | O | LCD driver chip select output. | |
| | 9 | Vcc | O | 5V | |
| | 10 | GND | - | GND | |
| DISPLAY UNIT (X54-3210-XX B/2) : SW section | | | | | |
| CN303 For X57- TX-RX unit | 1 | MON | O | Normally; 5V.,MON when connected GND. | |
| | 2 | LAMP | O | Normally; 5V, LAMP when connected GND. | |
| | 3 | PTT | O | Normally; 5V, transmit when connected GND. | |
| | 4 | GND | - | GND | |

DISPLAY UNIT (X54-3210-XX) (-10) : K, K2, M (-11) : K3, K4 Component Side View

DISPLAY UNIT (X54-3210-XX)









| Ref. No. | Address |
|----------|---------|
| D301 | 9C |
| D305 | 8L |
| D306 | 6L |
| D307 | 8N |
| D308 | 6N |
| D309 | 8Q |
| D310 | 6Q |



DISPLAY UNIT (X54-3210-XX) (-10) : K, K2, M (-11) : K3, K4 Component Side + Foil Side View


DISPLAY UNIT (X54-3210-XX)

| Ref. No. | Address |
|----------|---------|
| D300 | 6H |
| D301 | 9C |
| D302 | 8M |
| D303 | 8L |
| D304 | 9L |
| D305 | 8L |
| D306 | 6L |
| D307 | 8N |
| D308 | 6N |
| D309 | 8Q |
| D310 | 6Q |
| D315 | 8N |
| D316 | 8M |
| D317 | 8N |
| D318 | 8N |
| D319 | 5I |
| D320 | 6L |
| IC300 | 7L |
| IC301 | 7N |
| Q300 | 5F |
| Q301 | 5L |
| Q302 | 10D |
| Q303 | 9D |
| Q304 | 9M |
| Q305 | 8L |
| Q306 | 10L |
| Q307 | 10M |
| Q308 | 9M |
| Q309 | 9K |



TK-280 PC BOARD VIEW

TX-RX UNIT (X57-5740-XX) (-10) : K, K3, M (-11) : K2, K4 Component Side View



TX-RX UNIT (X57-5740-XX)

| Ref. No. | Address |
|----------|---------|
| D2 | 8P |
| D5 | 7I |
| D7 | 8I |
| D10 | 5L |
| D12 | 4P |
| D14 | 4P |
| D15 | 5P |
| D16 | 6O |
| D17 | 6N |
| D18 | 9G |
| D19 | 8F |
| D20 | 6N |
| D21 | 5N |
| D22 | 4Q |
| D24 | 8Q |
| IC1 | 4G |
| IC2 | 5H |
| IC3 | 8P |
| IC4 | 6I |
| IC5 | 8Q |
| IC7 | 7F |
| IC8 | 5G |
| IC11 | 7H |
| IC18 | 7N |
| Q5 | 7P |
| Q6 | 8I |
| Q7 | 7I |
| Q9 | 5I |
| Q13 | 5F |
| Q14 | 5F |
| Q15 | 6I |

DTA144EE
DTC144EE




2SJ243
2SK1824




S-81350HG-KD




M62364FP




TA75W01FU
TC75W51FU



RN5VL42C



GN2011



Component side


- Pattern 1
- Pattern 2
- Pattern 3
- Pattern 4
- Pattern 5
- Pattern 6



Foil side

TK-280 PC BOARD VIEW

TX-RX UNIT (X57-5740-XX) (-10) : K, K3, M (-11) : K2, K4 Component Side + Foil Side View



TX-RX UNIT (X57-5740-XX)

| Ref. No. | Address |
|----------|---------|
| D1 | 6H |
| D2 | 8P |
| D3 | 7G |
| D4 | 7I |
| D5 | 7I |
| D6 | 6J |
| D7 | 8I |
| D8 | 8F |
| D9 | 6L |
| D10 | 5L |
| D12 | 4P |
| D14 | 4P |
| D15 | 5P |
| D16 | 6O |
| D17 | 6N |
| D18 | 9G |
| D19 | 8F |
| D20 | 6N |
| D21 | 5N |
| D22 | 4Q |
| D23 | 6L |
| D24 | 8Q |
| IC1 | 4G |
| IC2 | 5H |
| IC3 | 8P |
| IC4 | 6I |
| IC5 | 8Q |
| IC6 | 6P |
| IC7 | 7F |
| IC8 | 5G |
| IC9 | 6P |
| IC10 | 6F |
| IC11 | 7H |
| IC12 | 8J |
| IC13 | 6F |
| IC14 | 6I |
| IC16 | 6G |
| IC18 | 7N |
| IC19 | 7C |
| IC20 | 3C |
| IC21 | 6D |
| IC22 | 3C |
| IC23 | 5N |
| IC24 | 4G |
| Q1 | 5O |
| Q2 | 5O |
| Q3 | 6P |
| Q4 | 7I |
| Q5 | 7P |
| Q6 | 8I |
| Q7 | 7I |
| Q8 | 5J |
| Q9 | 5I |
| Q10 | 7F |
| Q11 | 7K |
| Q12 | 9K |
| Q13 | 5F |
| Q14 | 5F |
| Q15 | 6I |
| Q16 | 6J |
| Q17 | 6F |
| Q19 | 6C |
| Q20 | 5M |
| Q21 | 5M |
| Q22 | 5N |
| Q23 | 5M |
| Q24 | 8O |
| Q25 | 5N |

DTA144EE
DTC114EE
DTC144EE
2SA1745
2SC4617
2SC4619
2SC5108

2SJ243
2SK1824

TK11250BM

TC35453F


BU4094BCFV

TA75W01FU
TC75W51FU















GN2011

⌘ Connect 1 and 6.


Component side



Foil side



LEVEL DIAGRAM



To make measurements in the AF section, connect the AC level meter. (ANT input : -53dBm, 1kHz FM, 3kHz DEV(WIDE).)

In the RF section, use a 1000pF coupling capacitor. (The display shows the SSG input value required to obtain 12dB SINAD.)

AG is set to the MIC input becomes 3kHz DEV. at 1kHz MOD (WIDE).


To make measurements in the AF section, connect the AC level meter.

In the RF section, use a 1000pF coupling capacitor.

TK-280

KNB-16A/17A (Ni-Cd BATTERY) / KPG-36 (PROGRAMMING INTERFACE CABLE) / KSC-19 (CHARGER) / KRA-14 (HELICAL ANTENNA)

KNB-16A
External View




KNB-17A
External View




KPG-36 External View



KNB-16A
Circuit Diagram



KNB-17A
Circuit Diagram



KSC-19 External View



KNB-16A Specifications

| | |
|-------------------------------|-------------------------|
| Voltage | 7.2V (1.2V x 6) |
| Charging current | 1100mAh |
| Dimensions (mm) | 58 W x 110.8 H x 17.2 D |
| (Projections included) | |
| Charger and charging time | |
| KSC-19 (Normal Charger) | Approx. 8 hours |
| KSC-20 (Rapid Charger) | Approx. 1 hour |
| Weight | 180g |

KSC-19 Charging

| | |
|------------------------|-----------------|
| KNB-16A | |
| Voltage | 7.2V |
| Battery capacity | 1100mAh |
| Charging time | Approx. 8 hours |
| KNB-17A | |
| Voltage | 7.2V |
| Battery capacity | 1500mAh |
| Charging time | Approx. 8 hours |

KNB-17A Specifications

| | |
|-------------------------------|---------------------------|
| Voltage | 7.2V (1.2V x 6) |
| Charging current | 1500mAh |
| Dimensions (mm) | 58.0 W x 110.8 H x 20.0 D |
| (Projections included) | |
| Charger and charging time | |
| KSC-19 (Normal Charger) | Approx. 8 hours |
| KSC-20 (Rapid Charger) | Approx. 1.3 hour |
| Weight | 220g |

KRA-14 External View




KMC-25 (SPEAKER MICROPHONE)

External View



Circuit Diagram



Specifications

- Microphone
 - Impedance 2k Ω
 - Sensitivity -65dB \pm 4.0dB at 1kHz
- Speaker
 - Impedance 16 Ω
 - Input 0.5W
 - Maximum input 1.5W
- Dimensions 62W x 81 H x 29 D (mm)
- Weight (With plug cord) Approx. 0.17kg

TK-280

SPECIFICATION

General

| | |
|--------------------------------------|---|
| Frequency Range | |
| RX, TX..... | K, K3, M : 146 to 174MHz K2, K4 : 136 to 162MHz |
| Systems | Maximum 32 |
| Groups | Maximum 250 (Case of 1 system) |
| Channels | LTR Model : Maximum 600 Conventional Model :Maximum 250 |
| Channel Spacing (Wide/Narrow)..... | 25kHz, 30kHz/12.5kHz, 15kHz |
| Channel Step Frequency | 2.5, 5.0, 6.25, 7.5kHz |
| Battery Voltage | DC 7.5V \pm 20% |
| Battery Life | More than 8 hours at 5-5-90 duty cycle with KNB-16A battery More than 10 hours at 5-5-90 duty cycle with KNB-17A battery |
| Temperature Range | -30°C to +60°C (-22°F to + 140°F) |
| Dimension and Weight | |
| With KNB-16A (1100mAh battery) | 5.33" (135mm) H x 2.29" (58mm) W x 1.34" (34mm) D 1.01lbs (460g) |

Receiver (Measurements made per EIA-RS 316B)

| | |
|-------------------------------------|--|
| RF Input Impedance | 50 Ω |
| Sensitivity | |
| 12dB SINAD | 0.25 μ V |
| Selectivity (Wide/Narrow)..... | 70dB/65dB |
| Intermodulation (Wide/Narrow) | 70dB/65dB |
| Spurious (Except for IF 1/2) | 70dB |
| Frequency Stability | \pm 0.00025% (-30°C to +60°C) |
| Channel Spread | 28MHz : K, K3, M 26MHz : K2, K4 |
| Audio Power Output | 500mW at 16 Ω less than 5% distortion |

Transmitter (Measurements made per EIA-RS 316B)

| | |
|--------------------------------------|------------------------------------|
| RF Power Output | |
| Hi | 5W |
| Low | 1W |
| RF Output Impedance..... | 50 Ω |
| Spurious | -70dB |
| Modulation (Wide/Narrow) | 16K0F3E/11K0F3E |
| FM Noise (Wide/Narrow)..... | -45dB/-40dB |
| Audio Distortion (Wide/Narrow) | Less than 3%/5% |
| Frequency Stability | \pm 0.00025% (-30°C to +60°C) |
| Channel Spread | 28MHz : K, K3, M 26MHz : K2, K4 |

KENWOOD CORPORATION

14-6, Dogenzaka 1-chome, Shibuya-ku, Tokyo 150-8501, Japan

KENWOOD SERVICE CORPORATION

P.O. BOX 22745, 2201 East Dominguez Street, Long Beach, CA 90801-5745, U.S.A.

KENWOOD ELECTRONICS LATIN AMERICA S.A.

P.O. BOX 55-2791 Piso 6 Plaza Chase Cl, 47 y Aquilino de la Guardia Panama, Republic of Panama

KENWOOD ELECTRONICS CANADA INC.

6070 Kestrel Road, Mississauga, Ontario, Canada L5T 1S8

KENWOOD ELECTRONICS DEUTSCHLAND GMBH

Rembrücker Str. 15, 63150 Heusenstamm, Germany

KENWOOD ELECTRONICS BELGIUM N.V.

Mechelsesteenweg 418 B-1930 Zaventem, Belgium

KENWOOD ELECTRONICS FRANCE S.A.

13, Boulevard Ney, 75018 Paris, France

KENWOOD ELECTRONICS U.K. LIMITED

KENWOOD House, Dwight Road, Watford, Herst., WD1 8EB United Kingdom

KENWOOD ELECTRONICS EUROPE B.V.

Amsterdamseweg 37, 1422 AC Uithoorn, The Netherlands

KENWOOD ELECTRONICS ITALIA S.p.A.

Via G. Sirtori, 7/9 20129 Milano, Italy

KENWOOD IBERICA S.A.

Bolivia, 239-08020 Barcelona, Spain

KENWOOD ELECTRONICS AUSTRALIA PTY. LTD.

(A.C.N. 001 499 074)

P.O. Box 504, 8 Figtree Drive, Australia Centre, Homebush, N.S.W. 2140, Australia

KENWOOD & LEE ELECTRONICS, LTD.

Unit 3712-3724, Level 37, Tower one Metroplaza, 223 Hing Fong Road, Kwai Fong, N.T., Hong Kong

KENWOOD ELECTRONICS TECHNOLOGIES(S) PTE LTD.

Sales Marketing Division
1 Ang Mo Kio Street 63, Singapore 569110