

Hotpoint Service and Spares

FOR SERVICE: If you have a problem with your appliance ring your local Service Office.
 FOR SPARES and ACCESSORIES: To purchase spares and accessories send your Accessories Order Form to your Spares Centre. If the accessory or spare part you want is not on the form, contact your Spares Centre for prices and availability.
 Please address all correspondence to Hotpoint Spares Centre or Hotpoint Service Office as applicable.

Service Offices and Spares Centres are open between 8.00am-5.00pm Monday to Friday, except on Public Holidays. 8.30am-12.30pm on Saturdays.


- EAST**
- ESSEX: Industrial Buildings, Beehive Lane, Chelmsford, CM2 9TE
Post Codes RM & IG Tel: (0245) 492433
Remainder of Essex Tel: (0245) 265331
Celia Road, PE2 9JB Tel: (0733) 64741
Spares Administration Dept. Tel: (0733) 556520
- LONDON**
- WEMBLEY: 68 East Lane, HA9 7PQ Tel: 081-904 4399
S. Herts and Middlesex Tel: 081-908 4722
Post Codes N, NW, E, EC Tel: 081-908 4722
Post Codes W, WC, SE, SW Tel: 081-908 2511
Tel: 081-904 0201
- MIDLANDS**
- BIRMINGHAM: Westgate, Aldridge, W Midlands, WS9 8UX
Post Codes B Tel: (0922) 743374
All other Post Codes Tel: (0922) 743376
Tel: (0922) 743377
 - NOTTINGHAM: Ashing Street, NG2 3JB For Spares Tel: (0602) 860387
For Service Tel: (0602) 862431/864322 For Spares Tel: (0782) 174511
West Ave, Nelson Estate, Talke, ST7 1TN Tel: (0782) 174511
 - STOKE: West Ave, Nelson Estate, Talke, ST7 1TN Tel: (0782) 174511
- NORTH EAST**
- WASHINGTON: 8 Beale House, Tower Road, Gower Est., District 11, NE37 2SH
Tel: 091-417 3500/419 3535
Sandbeck Lane, LS22 4TW
Tel: (0937) 581261/581444 For Spares Tel: (0937) 581221
- NORTH WEST**
- KENDAL: Mumford House, 26 Highgate, LA9 4SX Tel: (0539) 724483
44/46 Station Road, Heaton Mersey, Stockport, SK4 3DT
Manchester North Tel: 061-432 0513
Manchester South Tel: 061-442 8677
 - NETHERTON: 7 Bridle Way, Mersyside Tel: 051-525 2342/2524 2339
- SCOTLAND**
- ABERDEEN: Holbeck House, 68 Carden Place, AB1 1UL Tel: (0224) 642283
35 West Bowling Green Street, Leith, EH6 5NX Tel: 031-554 1431
West Lodge Road, Blythswood Estate, PA4 9EN
Tel: 041-886 6241 For Spares Tel: 041-886 5611
- SOUTH**
- KENT: Larkfield Trading Est, New Hythe Lane, Larkfield, ME20 6SW
CT, DA, ME & TN Kent Post Codes Tel: (0622) 716571
CR, KT, RH, SM, Surrey & BR Kent Post Codes (0622) 790707
GU Post Codes in Surrey Tel: Southampton (0703) 667374
Tel: (0622) 716551
 - SOUTHAMPTON: Unit H, S. Hampshire Ind Park, Salisbury Rd, Totton, SO4 3SA
Tel: (0703) 861981/867374 For Spares Tel: (0703) 867393
For Service 1 Kingswood, North St, Haislham, BN27 1DQ Tel: (0323) 842733
69 Mulvey Plain, PL4 6JH Tel: (0752) 262631
- WALES**
- NORTH: Conwy Rd, Llandudno Junction, LL31 9RE Tel: (0492) 573536
18 Western Ave, Bridgend Ind. Estate, Bridgend, CF31 3SL
Post Codes CF, SA & SY23-25 Tel: (0656) 664121
Post Codes BS, GL (not 55), HR, SY15-18, LD1-8, NP Tel: (0656) 655554
Tel: (0656) 766111

In accordance with its policy of progressive product design, the Company reserves the right to alter specifications. Hotpoint Ltd, Peterborough, PE2 9JB, England 225/2634/96

HOTPOINT HANDBOOK

FROST FREE FREEZER

MODEL 8792



<p>IRELAND</p> <ul style="list-style-type: none"> NORTHERN: 256 Ormeau Road, Belfast, BT7 2FZ Tel: (0232) 647111 49 Always Ind. Estate, Dublin 17 Tel: Dublin 426088 Tel: Dublin 426836 EIRE: For Service For Spares 	<p>■ Service Office and Spares Centre ● Service Office only</p>
<p>CHANNEL ISLANDS — Service provided by Agents. Normal Guarantees apply and all Service Schemes are available</p> <p>JERSEY: 19 Don Street, St. Helier Tel: (0534) 21625 Clos D'Ormes, Pontiac St. Clements, Tel: (0534) 54808</p> <p>GUERNSEY & SARK: Valpys Stores, Grande Rue, St. Martins. Guernsey Tel: (0481) 38422 Barras Lane, Vale Tel: (0481) 51610 32 High Street, Tel: (0481) 822686</p>	
<p>ISLE OF MAN — Service provided by Agents. Normal Guarantees apply and all Service Schemes are available</p> <p>from 5 Drumgould St., Douglas, Tel: (0524) 673233</p> <p>or Tromode Works Crombourne Village, Douglas, Tel: (0524) 676066</p> <p>or 17 Ridgeway Street, Douglas Tel: (0524) 25811/25846</p>	
<p>SHETLAND, ORKNEY & WESTERN ISLES — Service provided by Agents. Normal Guarantees apply, but Service Schemes are NOT available.</p> <p>SHETLAND: Fort Road, Lerwick Tel: (0595) 2557</p> <p>ORKNEYS: Halstone Ind. Estate, Kirkwall, Tel: (0856) 5457</p> <p>WESTERN ISLES: 27 Bayhead Street Stornoway, Isle of Lewis Tel: (0851) 3387</p> <p>OTHER ISLANDS: Local Hydro Electric Shops EXCEPT ARRAN, BUTE & SKYE — Which are covered by Hotpoint.</p>	

Your new Hotpoint Freezer

Using your new freezer is very simple. Nevertheless, for your own safety and to get the best results it is important that you read right through this handbook **before** using your freezer for the first time. Also do not load your freezer immediately it is switched on, but wait until the correct storage temperature has been reached (see page 9).

ELECTRICAL REQUIREMENTS

We recommend that this appliance is connected to the mains supply via a suitable switched socket in a readily accessible position. All Hotpoint appliances come complete with a fitted plug. The plug on your freezer has a 13A fuse. If the plug does not fit your sockets, a new plug can be fitted. Cut off the old plug and throw it away, do not insert it into a socket elsewhere in the house as this could cause a shock hazard.


WARNING: THIS APPLIANCE MUST BE EARTHED.

IMPORTANT: Fitting a Different Plug:

The wires in the mains lead are coloured in accordance with the following code:

Green and Yellow	– Earth
Blue	– Neutral
Brown	– Live

If you fit your own plug the colours of these wires may not correspond with the identifying marks on the plug terminals. This is what you have to do:

1. Connect the green and yellow (Earth) wire to the terminal in the plug marked 'E' or with the symbol , or coloured green or green and yellow.
2. Connect the blue (Neutral) wire to the terminal in the plug marked 'N' or coloured black.

3. Connect the brown (Live) wire to the terminal marked 'L' or coloured red. With alternative plugs a 5A fuse must be fitted either in the plug or adaptor or in the main fuse box. In the event of replacing a fuse in the plug supplied, a 13A ASTA approved fuse to BS1362 must be fitted. If the plug is the moulded on type the fuse cover must be refitted when changing the fuse. In the event of losing the fuse cover the plug must **not** be used until a replacement fuse cover has been obtained and fitted. A new fuse cover can be obtained from your nearest Hotpoint Spares Centre or local Electricity Company. The colour of the correct replacement fuse cover is that of the coloured marks or insert in the base of the plug.

Mains Lead Replacement

If the mains lead on this appliance needs replacing at any time, it must be replaced by a special lead which is obtainable from your nearest Hotpoint Service Office (see back page). A charge will be made for the replacement of the mains lead if you have damaged the lead or require a longer lead.

WARNING: HOW TO AVOID ACCIDENTS TO CHILDREN. WHEN DISCARDING AN OLD FRIDGE OR FREEZER BE CERTAIN TO MAKE THE LOCK UNUSABLE. IF POSSIBLE, REMOVE THE DOORS AND DISCARD SEPARATELY.

DO NOT ATTEMPT TO STAND ON TOP OF YOUR APPLIANCE. IT IS NOT DESIGNED FOR SUCH USE AND YOU COULD INJURE YOURSELF OR DAMAGE THE APPLIANCE BY SUCH ABUSE. CHILDREN SHOULD NOT BE ALLOWED TO PLAY WITH THE APPLIANCE OR TAMPER WITH THE CONTROLS.

Contents

THIS BOOK COVERS MODEL 8792

	Page
Get to know your Freezer	4
Installing your Freezer	5-8
Where to put your freezer	
Decor panel trim kits	
Repositioning the door hinge	
Installing next to a Fridge or Larder Fridge	
Getting your Freezer ready for use	9
Starting and Running In	
The Controls	10
The Lights – what they mean	
Fast Freeze Switch	
Economy Switch	
Storing Food	11-12
Storing already frozen food	
Freezing fresh foods – maximum freezing loads and how to freeze them	
Do's and Don'ts	
Caring for your Freezer	13-15
Cleaning	
Table Top	
Going Away	
If your Freezer won't work	15
Hotpoint Service Cover	16
Hotpoint Service Offices and Spares Centres	Back Page


Retention of the Instruction Book

This Instruction Book must be kept handy for reference as it contains important details on the safe and proper use of the appliance.

If you sell or pass the appliance to someone else, or move house and leave it behind, make sure this Book is also provided so the new owner can become familiar with the appliance and safety warnings.

If the Book is lost or damaged a copy may be obtained from Hotpoint Ltd, Celta Road, Peterborough, PE2 9JB.

Get to know your Freezer



Model 8792

Hotpoint Service Cover

Satisfaction Guaranteed or Your Money Back

Hotpoint gives you a unique 'Satisfaction Guaranteed' promise – valid for ninety days after you have purchased your Hotpoint product. If there is a problem with your Hotpoint appliance just call your Hotpoint Service Office. If necessary we will arrange for an engineer to call. If the problem is not resolved by us under this Guarantee, Hotpoint will replace your appliance or, if you prefer, give you your money back. This Guarantee is additional and subject to the terms of Hotpoint's Five Year Parts Guarantee.

Hotpoint's Free Five Year Guarantee

From the moment your appliance is delivered, Hotpoint guarantees it for **FIVE YEARS**.

- In the Five Years all replacement parts are **FREE** provided they are fitted by our own Service Engineer. During the first year our Engineer's time and labour is also free.
- After the first year we will charge for our Engineer's time and labour. We do, however, operate a range of Service Plans (see opposite) which for an annual payment enables you to cover any repair costs which may be necessary
- All of our service repairs are guaranteed for twelve months in respect of our labour and any parts fitted.
- The appliance must be used in the United Kingdom and must not be tampered with or taken apart by anyone other than our own Service Engineer.
- You may, however, buy parts which can be safely fitted without specialist knowledge or equipment. The correct fitting of such parts, provided they are genuine Hotpoint spares, will not affect your Guarantee. Parts are available from our main Hotpoint Spares Centres.
- Our Guarantee does not cover the cost of any repair which is needed because of power cuts, accidents or misuse. Nor does it cover the cost of any visit to advise you on the use of the appliance except for our Free Installation Check for Automatic Washing Machines and Dishwashers. Please read the instruction book thoroughly.
- If at any time during the Guarantee period we are unable to repair your appliance, we will refund any repair costs paid to us in the previous twelve months. We will also offer you a new appliance at a reduced charge instead of a repair.
- Our Guarantee is in addition to and does not affect your legal rights.
- Should you need independent advice on your consumer rights, help is available from your Consumer Advice Centre, Law Centre, Trading Standards Department and Citizens Advice Bureau.

- All Hotpoint servicing is done by our own Service Organisation located throughout the United Kingdom and Southern Ireland. It will be happy to deal with any problems.

Hotpoint's Service Care

Whether you have just one or a number of Hotpoint appliances in your kitchen, Hotpoint has a range of Service Schemes to give you complete peace of mind.

Service Cover

A single payment covers you for all repairs during the period of cover, which can be from 1 to 4 years. There is also an option of Service Cover with Maintenance at an additional cost. This includes an annual Electrical and Safety check and replacement of any parts as necessary. For 1 year contracts this takes place towards the end of the contract period.

Kitchen Cover

An annual payment covers you for all repairs for all your Hotpoint appliances which are less than 10 years old. It also covers the cost of loss of food up to £250 in our refrigeration and freezer products. There is also the option of Kitchen Cover with Maintenance at an additional cost. Any additional Hotpoint appliances purchased after you have joined Hotpoint Kitchen Cover will automatically be included during the annual period of cover without further charge.

Appliance Registration

To ensure that you have the opportunity to benefit from any of the above Service Schemes you should complete and return immediately the Appliance Registration Form supplied with your appliance. Full details and costs of our Service Schemes together with an application form will be sent to you at the end of the first year of the guarantee.

Annual Safety/Maintenance Checks

Hotpoint strongly recommends that all its appliances are regularly checked for electrical and mechanical safety whether or not they are covered by a Service Plan.

Proof of Purchase

For future reference please attach your purchase receipt to this booklet and keep it in a safe place.

Spares and Accessories

Spares and accessories can be ordered from your local Hotpoint Spares Centre (listed on the back page), using the order form enclosed.

NOTE: Our Engineer will use every effort to avoid damage to floor coverings and adjacent units when carrying out repairs/service work but in locations where the Engineer advises you that it will be impossible to move the appliance without risk of damage, he will only proceed with your approval that no liability is accepted.


Installing your Freezer

Where to put your freezer

Your freezer should be placed where it is easy to use, alongside or beneath a work surface is often a good position. Avoid putting it near anything which gives off heat, a cooker or radiator for example. In such a position your freezer will have to work harder and will cost more to run, and may also be damaged by the heat.

Once you have decided on the most suitable place, make sure that there is adequate air circulation at the back of the freezer.

Just push the freezer back until the grille is against the wall.



if placed underneath a work surface, adequate ventilation **must** be provided to maintain operating efficiency. Make sure there is a gap of 30mm (1 1/4in) between the top of the freezer and the underside of the work surface. If there is not enough clearance available then ventilation must be provided by fitting an air grille. To increase efficiency and reduce the running cost of your appliance we recommend the fitting of an air grille at the rear of the work surface. This grille, Part No. 8040 is available from your retailer or nearest Hotpoint Spares Centre using the Accessories Order form supplied with your freezer. Finally, make sure your freezer is standing correctly by carefully adjusting the two front feet by turning them clockwise or anti-clockwise, until all four feet are in firm contact with the floor. Correct adjustment avoids excessive vibration and noise.



A Wheel Kit, Part No. 8031, for fitting to the back of your freezer is available from your retailer or nearest Hotpoint Spares Centre using the Accessories Order Form supplied.

WARNING: YOU SHOULD NOT STACK YOUR FREEZER WITH ANY OTHER APPLIANCE.

Installing next to a Fridge or Larder Fridge

This can be done in one of two ways – either free standing or linked.

Free standing: Just slide in next to the Fridge, but leave a gap of 50mm (2in) between the two appliances to avoid a build up of condensation. Make sure both appliances stand correctly (see page 5).

Linking: Your Hotpoint Freezer can be joined with the appropriate Larder Fridge to make them look like one unit.

To join Model 8792 with Model 8112/8232 requires linking kit Part No. 8010 (Brown) or Part No. 8011 (White).

These are available from your retailer or nearest Hotpoint Spares Centre (see back page) using the Accessories Order Form supplied with your Freezer.

The kit comes complete with wheels so that the unit can be easily moved. The widths of the linked appliances are as follows:

8112 and 8792 – 1053mm (41.5in)
8232 and 8792 – 1108mm (43.6in).

Note: To ensure that the doors function properly you will need to change the left hand appliance so that its door hinges on the left hand side (see pages 7 and 8). Also make sure that the two appliances stand correctly and firmly (see page 5).

If your Freezer won't work . . . don't panic

Just run through these quick checks before calling your nearest Hotpoint Service Office.

1. Check that the plug is firmly in the socket outlet and that the power supply is on.
2. Check the power supply to the socket outlet by plugging in another appliance.
3. If the other appliance works, check the fuse in the freezer's plug.
4. If you have changed the plug, check the wiring (see page 2).
5. If there is excessive noise or vibration, check that all four feet are firmly in contact with the ground (see page 5).
6. If water droplets appear on the outside of the cabinet, check that you have the Economy switch set on 'H' (see page 10).
7. You may find the freezer difficult to open just after you have used it. This is due to a pressure difference which will soon equalise. Wait a few minutes then open the door.

If, after following all these instructions, you are still having problems, contact your nearest Hotpoint Service Office (or local importer if outside the United Kingdom). The telephone number is shown on the back page.

When you contact us we need to know:

1. Your name, address and post code.
2. Your telephone number.
3. Clear and concise details of the fault.

4. The model number (8792), serial number (found on the label on the underside of the front top of the appliance), and colour.
5. When it was purchased. Please put the date here

6. If you have subscribed to the Hotpoint Service Cover Plan. Make sure you have all these details before you call.

Spare Parts

Please remember your new appliance is a complex piece of equipment.

'DIY' repairs or unqualified and untrained service people may put you in danger, could damage the appliance and might mean you lose cover under Hotpoint's Parts Guarantee.

If you do experience a problem with the appliance don't take risks; call in Hotpoint's own Service Engineer. The address and telephone number of your nearest Hotpoint Service Office is in your local telephone directory.

Our spare parts are designed exclusively to fit only Hotpoint appliances. Do not use them for any other purpose as you may create a safety hazard.

Caring for your Freezer (cont)

Never use any household cleaner or detergent, abrasive powders or wax polish. These not only damage the surfaces, but also leave a smell in the freezer. **Before** you refill the freezer ensure it is thoroughly dry.

Cleaning the exterior of your freezer

Clean the outside of your freezer, **but not the door seal and handle**, with a damp cloth, using a small amount of detergent, followed by a wipe down with a clean cloth. **Do not** use an abrasive powder. **The rubber door seal and handle must be cleaned with soap and water only as detergent will damage it.**

Finally, the compressor and condenser at the back of the freezer can be carefully cleaned. Use a brush or vacuum cleaner to remove any dust. **Always** check that the freezer is disconnected from the mains electricity supply **before** doing this.

Remember to re-connect the mains plug and switch on after cleaning your freezer.

Table top

This is designed to serve as an extra work surface, but be careful with it. **Do not** drop/place heavy objects on it or sit on it.

Going away

If you expect to be away for any length of time and don't want to use your freezer, switch off at the socket outlet and pull out the plug. Remove **all** food and follow the defrosting instructions (see page 13). After defrosting dry out the interior. **Always** leave the door ajar to prevent the accumulation of odours.

Fitting decor panels to match your kitchen units

For that fully co-ordinated kitchen look it is possible to fit a matching decor panel to your freezer. A special trim kit is available from Hotpoint that attaches to the edges of the appliance door and enables a decor panel, up to 4mm ($\frac{1}{16}$ in) thick, to be fitted. Decor panels are available from most kitchen suppliers.

Your freezer requires trim kit Part No. 8001 (Brown) or Part No. 8004 (White).

These are available from your retailer or nearest Hotpoint Spares Centre (see back page) using the Accessories Order Form supplied with your freezer.

Repositioning the door hinge


Just follow the step by step instructions below:

Tools required: A 7mm/8mm A/F Spanner or a No. 2 Pozidriv.


1. Take out all the loose fittings from inside the freezer.
2. **Carefully** lay the freezer on its back (you may need assistance for this). **Take care to avoid damage to the pipework by keeping it off the floor or by laying it on some protective material (eg. its original packaging).**
3. Unscrew and remove the two front feet (**A**).
4. Remove the bottom hinge (**C**) by unscrewing the two screws (**D**). Make sure that if any packing washers (**E**) are fitted they are left on the hinge pin.

5. Remove the bottom screws (**F**), washers and plate (**G**) and fit them on the opposite side of the cabinet, making sure the hole in the cabinet for the foot is not covered over.
6. Remove the door gently pulling it downwards until clear of the top hinge.
7. Remove the top hinge (**H**) by unscrewing the two screws (**J**) – replace the screws (**J**). Make sure the screw heads do not protrude below the recess.
8. Remove two screws (**L**) in the opposite recess and use them to fit the top hinge (**H**) in the recess.
9. Before re-fitting the door, the plug (**M**) and the top and bottom hinge bushes (**N**) must be swapped over. Prise them out of their location, taking care not to mark the adjacent surfaces. Reposition them on the opposite side of the door.
10. Reposition the door handle insert (**P**) on the opposite side of the door. To do this, remove the four screws (**R**), lift up and swap over the insert. Refit the four screws.
11. Refit the door by laying it on the cabinet and, sliding it upwards, locate the top hinge bush on the top hinge pin (**E**).
12. With all the packing washers that may have been originally fitted retained on the pin, fit the bottom hinge pin (**C**) into the hinge bush (**N**). Adjust as necessary so the door fits evenly.

- The bottom hinge can now be secured to the cabinet using the two screws **(D)**.
- Replace both adjustable front feet **(A)** setting them at approximately 25mm (1in) from the bottom of the cabinet.
- Carefully stand the freezer up (you may need assistance for this) and put it where you have decided to locate it. Ensure it is standing correctly by adjusting



- the two front feet until all four feet are in firm contact with the floor.
- Check the door opens and closes easily. **Ensure the door seal does not bind on the hinge side and that there are no gaps allowing air into the cabinet.** Adjust the bottom hinges if necessary.
- Finally put back all the loose fittings inside the freezer.



Caring for your Freezer

Defrosting

The freezer is designed to be frost free – defrosting is carried out automatically.


The appliance interior is cooled by air flow through the vent situated at the top rear of the freezer.

The frost is absorbed and excess moisture is collected into a small container from where it evaporates. It is recommended that your freezer is cleaned periodically, how often depends on usage.

Cleaning your freezer

Just follow these steps:

- Switch off and pull out the mains plug.**
- Remove any frozen food. Wrap it in several layers of newspaper or a blanket, remove the empty baskets and use them to store the wrapped food – put them in a cool place.
- Remove the compartment doors. This is done by opening the compartment door 45 degrees and gently lifting and pushing the **left hand** corner so that the pin comes up and out of the special hinge. The door can then be removed from the right hand hinge by pulling the door to the left. To replace door after cleaning: ensure the upper door pins are positioned in front of the hinges. Fit the right hand, bottom door pin into the bottom slot in the right hand hinge. Then pull the left hand bottom pin through the back slot in the left hand hinge. Press down on the left top corner of the door so that the pin goes fully home in the hinge.



- Wipe out the inside with a clean cloth wrung out in either a solution of 1 teaspoonful of bicarbonate of soda to one pint of water **or** Milton diluted to the manufacturer's instructions. The complete interior including the door and all removable parts, should be washed.
- Dry the interior thoroughly with a clean cloth before replacing the basket, shelf and contents.

Do's and Don'ts

- Do:--** Always choose high quality fresh food and be sure it is thoroughly clean before you freeze it.
- Do:--** Prepare fresh food for freezing in small portions to ensure rapid freezing.
- Do:--** Remember lean foods last longer than fat foods and salt will reduce storage life.
- Do:--** Wrap all foods in aluminium foil or freezer quality polythene bags and make sure any air is excluded. Keep the door shut when freezing fresh foods.
- Do:--** Separate food in different baskets for easy identification.
- Do:--** Wrap frozen food when you buy it and put it into the freezer as soon as possible.
- Do:--** Store commercially frozen food in accordance with the instructions given on the packets that you buy.
- Do:--** Ice cream should be removed from the freezer 15-30 minutes before serving.

- Don't:--** Exceed the maximum freezing loads when freezing fresh food (see page, 11).
- Don't:--** Put hot food into the freezer. Let it cool down first.
- Don't:--** Leave the door open for long periods as this will make the freezer more costly to run.
- Don't:--** Put liquid-filled bottles or sealed cans containing carbonated liquids (fizzy drinks, etc) into the freezer as they may burst.
- Don't:--** Try to keep frozen food which has thawed; it should be eaten within 24 hours or cooked and refrozen.
- Don't:--** Give children lollipops and water ices direct from the freezer. The low temperature may cause 'freezer burns' on their lips.
- Don't:--** Store poisonous or dangerous substances in the freezer. Your freezer has been designed for the storage of edible foodstuffs only.

Getting your Freezer ready for use

If you are going to freeze fresh food, you must press **★ (ON)** on the Fast Freeze switch. The amber light will come on and you must **wait at least 24 hours** before putting in your fresh food to be frozen. Do not put more than 5½ kg (12lb) of fresh food to be frozen into the Fast Freeze compartment (Lower compartment).

Running-in the compressor

The liquid and gases sealed within the refrigeration system may give rise to noise, whether the compressor is running or not. This is quite normal. Your freezer is operated by a compressor which switches on and off in order to maintain the freezer's temperature. The compressor is a precision piece of machinery like a car engine, and requires a running-in period of up to 2 months. During this time the compressor has to work a little harder and this may result in more noise than usual.

NOTE: Your freezer is designed only for domestic purposes: for the freezing of fresh food and storage of frozen food.

Before using your freezer for the first time the interior, including the door, and all removable parts should be wiped out. Use a damp cloth wrung out in either a solution of one teaspoonful of bicarbonate of soda to one pint of water or Milton diluted according to the manufacturer's instructions.

WARNING: NEVER USE ANY HOUSEHOLD CLEANER OR DETERGENT, ABRASIVE POWDERS OR WAX POLISH. THESE NOT ONLY DAMAGE THE SURFACES, THEY ALSO LEAVE A SMELL IN THE FREEZER.

Final check

Before you start using the freezer, check that

1. It is thoroughly dry inside.
2. Air can circulate freely, at the rear.
3. The feet have been adjusted, ie. all four are firmly on the ground.

Starting

Insert the plug into the wall socket and switch on the electricity supply. The green (mains) and red (temperature warning) lights will come on together and your freezer will start working. You will hear a noise as the compressor starts up. If you are going to store already frozen food, open the freezer door and check that the Fast Freeze switch is at **'O'** (Off). The red light will go out when the freezer has reached the correct temperature. Then you can put in your already frozen food.

The Controls

Controlling the Temperature

Your freezer is fitted with a factory set thermostat control which does not require any adjustment.

In the summer months, or in conditions giving high temperatures around the freezer, the compressor has to work harder and run for longer periods. This is quite normal.

Conversely, during cold weather the compressor will run for much shorter periods.

A fridge/freezer thermometer, Part No. 8058 is available to ensure that you maintain your appliance at the correct temperature. This can be ordered from your local Hotpoint Spares Centre (see back page) using the order form enclosed.

WARNING: DO NOT USE MERCURY FILLED THERMOMETER.

Green Mains Light

Comes on and stays on as long as the electricity supply is not interrupted.

Red Temperature Warning Light

The red temperature warning light may come on for a short period (up to 30 minutes) during the automatic defrost. The light also comes on when the temperature inside the freezer rises above the correct storage temperature. If it comes on for a short period when you open the door to load or unload food, storage times will not be affected. However, if the red light stays on this indicates that something is wrong. First check that the door has not been accidentally left open. If this is not the case, call your nearest Hotpoint

Service Office (see back page). If the delay is likely to be longer than 10 hours then the food should either be defrosted and eaten immediately; defrosted, cooked and then refrozen or transferred to another freezer.

Fast Freeze Switch and Amber Fast Freeze Light

Press '★' (ON position) when freezing fresh food and the amber light will come on (see Freezing Fresh Foods, page 11).

Economy Switch

Your freezer incorporates a low energy heater to reduce condensation on the cabinet sides. Press 'E' (Economy position) for normal conditions.

If the room is cold or humid or if freezing fresh food, water droplets may form on the outside of the freezer. When this happens press 'H' (Humid position). The low energy heater will operate continuously and the water droplets will disappear. When conditions return to normal, reset the switch to 'E' and the heater will operate intermittently.

Note: The outside front edges of the freezer may feel warm. This is normal.

Storing Food

Storing food in your freezer

Your freezer carries the **★** symbol which indicates that it is suitable for the long-term storage of commercially frozen foods and also can be used to freeze and store fresh food.

It will store up to 26kg (58lb) of frozen food. These figures are based on an average density of 0.32kg of mixed food per litre of net storage volume (20lb per cubic foot). In the case of meat it will take appreciably more. Generally speaking long-term storage means up to 3 months, but this will vary with the nature of the packaged food, so always follow the manufacturer's recommended storage time given on the packet. For storing home frozen fresh food refer to the pictorial guide on the door liner.

If there is a power failure do not open the door.

Frozen food should not be affected if the failure lasts for less than 10 hours. If the failure is longer, then the food should be checked and either eaten immediately or cooked and then refrozen.

Do not line the shelf or baskets with paper plastic or foil. The vent at the top rear of the top compartment must not be covered inadvertently when loading the compartment.

Do not pack items tightly together. Whenever possible leave space between items. Evenly distribute the frozen food packages throughout all compartments. This allows improved air circulation and easy access to the items stored.

Freezing Fresh Foods Maximum Freezing Loads

You can freeze up to 5½kg (12lb) of fresh or cooked food in any 24 hours.

1. Transfer any frozen food from the lower Fast Freeze compartment to the storage baskets or upper storage compartment.
2. Press '★' (ON position) on the Fast Freeze switch. The amber Fast Freeze light will come on. If the freezer has not been in use it will be necessary to set the Fast Freeze switch to '★' at least 24 hours before putting in the fresh food.
3. Press 'H' on the Economy switch to avoid condensation on the outside of the freezer compartment.
4. Allow 24 hours before placing the maximum 5½kg (12lb) of fresh food in the lower fast freeze basket. Allow proportionally less time for smaller quantities.
5. Leave the switches on for 24 hours then reset the Fast Freeze switch to 'O' and the Economy switch to 'E'.