





Welcome


Welcome to the world of Motorola digital wireless communications! We are pleased that you have chosen the Motorola T190 wireless phone.





Personal Communications Sector
600 North U.S. Highway 45
Libertyville, Illinois 60048
1-800-331-6456 (United States)
1-888-390-6456 (TTY/TDD United States)
1-800-461-4575 (Canada)
www.motorola.com (United States)
www.motorola.ca (Canada)


MOTOROLA, the Stylized M Logo and all other trademarks indicated as such herein are trademarks of Motorola, Inc. © Reg. U.S. Pat. & Tm. Off. All other product or service names are the property of their respective owners.
© 2001 Motorola, Inc. All rights reserved. Printed in the U.S.A.



Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.



Manual number:
Cover number:






Contents

Welcome	1
Safety and General Information	5
Touring Your Phone	13
Appearance	13
Idle Mode Display	15
Keys	16
Getting Started	20
Your SIM Card	20
Battery Use	21
Using Your Phone	24
Turning on the Phone	24
Making a Phone Call	24
Ending a Call	25
Answering a Call	25
Turning Off the Phone	25
One-touch Dialing	26
Listening to a Voicemail	26
Making an International Call	26
Making an Emergency Call	27
Dialing an Extension Number	27
Last Missed, Dialed, and Received Calls	27
Making an Abbreviated Call	28
Phone Book Directory Shortcut	28
Messages Menu Shortcut	29
Adding Phone Book Entries in Idle Mode	29
Incoming Call Waiting	30
Holding a Call	30
Call Options Menu	31





Adjusting the Earpiece Volume	33
Initiating Keypad Lock	33
Input Mode Menu	34
Selecting an Input Mode	34
Quick Access	43
Quick Access Menu	43
Using the Quick Access Menu	43
Menus	44
Using Menus	44
Phone Book (1)	46
Messages (2)	55
Call Services (3)	66
Phone Setting (4)	72
Network (5)	75
Security (6)	76
Audio Setting (7)	79
Tools (8)	86
Menu Structure Map	95
Care and Maintenance	96
Problems and Solutions	97





Safety and General Information

IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION.
READ THIS INFORMATION BEFORE USING YOUR PHONE.





RF Operational Characteristics

Your phone contains a transmitter and receiver. When it is ON, it receives and transmits radio frequency range of 900 MHz to 1800 MHz and employs digital modulation techniques. When you communicate with your phone, the system handling your call controls the power level at which your phone transmits. The output power level typically may vary over a range from 1mW to 2 Watts.

Exposure to Radio Frequency Energy

Your Motorola phone is designed to comply with the following national and international standards and guidelines regarding exposure of human beings to radio frequency electromagnetic energy:

- United States Federal Communications Commission, Code of Federal Regulations; 47 CFR part 2 sub-part J
- American National Standards Institute (ANSI) / Institute of Electrical and Electronic Engineers (IEEE) C95. 1-1992
- Institute of Electrical and Electronic Engineers (IEEE) C95.1-1999 Edition
- National Council on Radiation Protection and Measurements (NCRP) of the United States, Report 86, 1986
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998
- Ministry of Health (Canada) Safety Code 6. Limits of Human Exposure to Radiofrequency Electromagnetic Fields in the Frequency Range from 3 kHz to 300 GHz, 1999





- Australian Communications Authority Radiocommunications (Electromagnetic Radiation - Human Exposure) Standard 1999 (applicable to wireless phones only)

To assure optimal phone performance and make sure human exposure to radio frequency electromagnetic energy is within the guidelines set forth in the above standards, always adhere to the following procedures:

Portable Phone Operation and EME Exposure

Antenna Care

Use only the supplied or an approved replacement antenna.

Unauthorized antennas, modifications, or attachments could damage the phone and may violate FCC regulations.



DO NOT hold the antenna when the phone is "IN USE". Holding the antenna affects call quality and may cause the phone to operate at a higher power level than needed.

Phone Operation

When placing or receiving a phone call, hold your phone as you would a wireline telephone. **Speak directly into the microphone.**

Body-worn Operation

To maintain compliance with FCC/Health Canada RF exposure guidelines, if you wear a phone on your body when transmitting, always place the phone in a **Motorola supplied or approved clip, holder, holster, case, or body harness for this product.** Use of non-Motorola-approved accessories may exceed FCC/Health Canada RF exposure guidelines. **If you do not use a body-worn accessory, and are not using the phone held in the normal use position at the ear, ensure the phone and its antenna are at least one inch (2.5 cm) from your body when transmitting.**





Data Operation

When using any data feature of the phone, with or without an accessory cable, position the phone **and its antenna at least one inch (2.5 cm) from the body.**

Approved Accessories

For a list of approved Motorola accessories visit our website at www.motorola.com.

Electromagnetic Interference/ Compatibility

Note: Nearly every electronic device is susceptible to electromagnetic interference (EMI) if inadequately shielded, designed or otherwise configured for electromagnetic compatibility.

Facilities

To avoid electromagnetic interference and/or compatibility conflicts, turn off your phone in any facility where posted notices instruct you to do so. Hospitals or health care facilities may be using equipment that is sensitive to external RF energy.

Aircraft



When instructed to do so, turn off your phone when on board an aircraft. Any use of a phone must be in accordance with applicable regulations per airline crew instructions.

Medical Devices

Pacemakers

The Advanced Medical Technology Association recommends that a minimum separation of 6 inches (15 centimeters) be maintained between a handheld wireless phone and a pacemaker. These recommendations are consistent with the independent research by, and recommendations of, the United States Food and Drug Administration.

Persons with pacemakers should:





- ALWAYS keep the phone more than six inches (15 centimeters) from their pacemaker when the phone is turned ON.
- not carry the phone in the breast pocket.
- use the ear opposite the pacemaker to minimize the potential for interference.
- turn the phone OFF immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.




Safety and General

Use While Driving

Check the laws and regulations on the use of phones in the area where you drive. Always obey them.

When using your phone while driving, please:

- Give full attention to driving and to the road.
- Use hands-free operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.





Operational Warnings

For Vehicles with an Air Bag


Do not place a portable phone in the area over an air bag or in the air bag deployment area. Air bags inflate with great force. If a portable phone is placed in the air bag deployment area and the air bag inflates, the phone may be propelled with great force and cause serious injury to occupants of the vehicle.

Potentially Explosive Atmospheres

Turn off your phone prior to entering any area with a potentially explosive atmosphere, unless it is a phone type especially qualified for use in such areas as "Intrinsically Safe." Do not remove, install, or charge batteries in such areas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.




Note: The areas with potentially explosive atmospheres referred to above include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust or metal powders, and any other area where you would normally be advised to turn off your vehicle engine. Areas with potentially explosive atmospheres are often but not always posted.



Blasting Caps and Areas

To avoid possible interference with blasting operations, turn off your phone when you are near electrical blasting caps, in a blasting area, or in areas posted: "Turn off two-way radio." Obey all signs and instructions.






Operational Cautions

Antennas

Do not use any portable phone that has a damaged antenna. If a damaged antenna comes into contact with your skin, a minor burn can result.

Batteries

All batteries can cause property damage and/or bodily injury such as burns if a conductive material such as jewelry, keys, or beaded chains touch exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects.





European Union Directives Conformance Statement



Hereby, Motorola declares that this product is in compliance with


- The essential requirements and other relevant provisions of Directive 1999/5/EC
- All other relevant EU Directives

IMEI: 350034/40/394721/9

CE0168


Type: MC2-41H14





Product Approval Number



The above gives an example of a typical Product Approval Number.

You can view your product's Declaration of Conformity (DoC) to Directive 1999/5/EC (to R&TTE Directive) at www.motorola.com/rtte. To find your DoC, enter the product Approval Number from your product's label in the "Search" bar on the web site.











Touring Your Phone

Appearance




*For information on how to use each key, see "Function Keys" on page 16.






*For connection to the optional handsfree headset.



Idle Mode Display



Idle Display Icons

Icons are frequently shown on the idle display:

Icon	Function	Descriptions
	Signal Strength	Signal strength of your designated network. The more bars displayed, the stronger the signal.
	Short message	Receiving a short text message or having unread messages (see page 55).
	Voice mail waiting	You have a new voice mail (see page 64)
	Call divert	All incoming calls are diverted to a designated number (see page 68).
	Line in use	The current line in use (see page 71).




Icon	Function	Descriptions
	Vibration only	Your phone only vibrates without ringing when a call comes in. (See page 80).
	Battery	Battery power level, the more the bars, the more the battery power. Four bars: full. No bars: Recharging immediately. The icon scrolls during charging until the battery is full.
	Key lock	Key lock is activated (see page 33 and 73).
	Roaming	When your phone is not used on your home network, this icon will appear.



Keys






Function Keys





In this user guide, *long press* means "pressing and holding a key for about 2 seconds," while *press* means "pressing and releasing a key immediately."














This listing does not include all operations of each key. Refer to related sections of this manual for other key commands.

Keys	Commands and functions
	<p>Power On/Off key</p> <ul style="list-style-type: none"> • Long press to switch your phone on/off. • Press to end or cancel a call. • Press to return to the previous menu.
	<p>Send/Answer key</p> <ul style="list-style-type: none"> • Press to send or answer a call. • In idle mode, long press to redial the last call number. • In idle, press to display last dialed / missed / received numbers. • Press to select or activate an option.
	<p>Menu key</p> <ul style="list-style-type: none"> • Accessing the main menu from idle. • During a call, press to access the Call Options menu. • During input, press to access the input mode menu.
	<p>Right soft key</p> <p>Executes the command shown at the bottom right of the display:</p> <ul style="list-style-type: none"> • In menus, press to select or activate an option (as SEL/OK/OPTION shows). • In idle, press to access the Messages menu. (as  shows). • Confirms entered digits/text during input (as OK shows).





Keys	Commands and functions
	<p>Left soft key Executes the command shown at the bottom left of the display:</p> <ul style="list-style-type: none"> • In menus, press to abort a selection/operation and return to the previous menu or screen (as QUIT/EXIT shows). • In idle mode, press to access the Phone Book directory (as CB shows). • During input, press to clear one digit/character; long press to clear all digits/characters (as DEL shows).
	<p>Scroll key</p> <ul style="list-style-type: none"> • Scrolling the menus and options. • Adjusting volume during a call. • In idle mode, press to access Quick Access menu. • In idle mode, long press to access Phone Book directory • During input, press once to move cursor to the next/last insertion point; long press to move the cursor continuously.
	<p>Voicemail key</p> <ul style="list-style-type: none"> • In idle, long press to dial the voice mail box number.
	<p>Lock key</p> <ul style="list-style-type: none"> • In idle, long press to lock the keypad.
	<p>Number key</p> <ul style="list-style-type: none"> • In idle, long press to dial any of the first 9 phone numbers saved in the Phone Book. • In menus, press to access a corresponding option directly.









Alphanumeric Keys

Following is a list of the alphanumeric keys and their corresponding characters and symbols in input.

Key	Lower case
	, . : 1 % ! ? ; " ' < > () @ &
	A B C 2 Å Ä å ä à ç æ ß
	D E F 3 é è E F Æ \$
	G H I 4 ì i ç ø
	J K L 5 Δ _ Φ Γ Λ Ω
	M N O 6 Ñ ñ Ò ö O ø
	P Q R S 7 ¥ §
	T U V 8 ü Ü ù
	W X Y Z 9 Π ψ Σ Θ Ξ
	0 (Space)
	+ - * / =
	# P





Getting Started



Your SIM Card

To successfully use your phone, you must insert a SIM card (Subscriber Identification Module) supplied by your network operator. The SIM card contains your subscription number and your phone number as well as a memory in which you can store phone numbers, messages, etc.

Inserting Your SIM card

Note: Scratches can easily damage the metal contacts of the SIM card. Pay special attention to the SIM card when you handle and insert.


- Locate the SIM card slot on back of your phone. Place the entire SIM card into the slot, with the metal contacts of the SIM card facing down and its cut corner on the upper left.
- Slide the SIM card latch over onto the card.





Removing Your SIM Card

Push the battery latch back, slide the SIM card latch backwards, then pick up the card from the slot.




Battery Use

Caution: Do not remove the battery when your phone is on—you may lose all your personal settings stored either in your SIM card or phone memory.



Fitting the Battery


Place the battery onto the back of the handset with the battery's contacts facing down in alignment with the contacts on the battery compartment, push the battery forward against the top of the compartment and press it down till it clicks into the compartment.





Removing the Battery


Push the battery latch back. The battery will rise automatically. Lift the battery up from the bottom end.



Charging the Battery

Insert the travel charger connector into the charger port at the bottom left of the phone.

Charger connector





Charger port




Pull out the charger connector when charging is done.

Tip: It takes 24 hours for the travel charger to fully charge a new battery. Recharging takes approximately 160 minutes each time.






Tip: During charging,  on the LCD will blink until the battery is fully charged. When the battery is low, you will hear a warning tone and **Battery Low** will appear on the LCD. When the battery is running out of power,  will appear to remind you to recharge immediately. Then your phone will power off automatically.








Using Your Phone

Turning on the Phone


Long press  to turn your phone on.



Making a Phone Call

1. Enter your PIN. If you type a wrong number while entering your PIN, delete the wrong number by pressing  (DEL). When done, press  (OK) or  to confirm.



Tip: *PIN* (Personal Identification Number) is a password provided by your network operator. With your PIN, you can use your SIM card and access the services offered by your operator.

Note: If you enter a wrong PIN three times in a row, your SIM card will be blocked. To unblock the SIM card, you need to enter the PUK (Personal Unblocking Key) of the card. Please call the operator, and ask for PUK.

Once your PIN is accepted, the phone will start searching for your designated network automatically, as  indicates. This may take a few seconds. When receiving network signals successfully, the phone beeps twice with its LCD display showing the network you connect to and then goes into idle mode.

2. Now you can dial a desired number using the keys on the keypad. Press  (DEL) to delete wrong digits. Press  to send your call.

Note: When network service is not available, no signal level will be displayed on the screen.





Note: When connected to a network you do not have access to, the signal strength will still show on the screen. You can only make an emergency call.

Note: During a call, you can use the call options described on page 31.

Ending a Call

When you finish a phone call, press or (EXIT) to end the call and return to idle mode. Also press or (EXIT) if you want to drop a call after dialing.

Answering a Call


When your phone rings or vibrates, the screen will display the name or the phone number of the caller (Network support dependent). The name displayed depends on the data in the Phone Book. Press (OK) or to answer a call. You can also answer incoming calls by pressing any key.*

If you want to reject a call, press or (EXIT).

* To change the answering mode, you must go to **Profiles** under the **Audio Setting** menu. See page 82 for details.

Turning Off the Phone

Long press to turn your phone off.





One-touch Dialing

There are two ways of doing one-touch dialing while in idle mode:

- Long press . The last number you dialed will be dialed again automatically.
- You can dial any of the first 9 phone numbers saved in the Phone Book by long pressing its phone book location number. If the number is saved in the Phone Book at location 5, for example, long press to make the call.


Listening to a Voicemail

In idle mode, long press to call your operator's voice mail center and listen to the voice mail left by a caller. You can also go to **Voice Mail** under the **Message** menu to make a voicemail call. See more details on page 64.*

** Voicemail feature is network support and subscription dependent.*

Making an International Call

1. Enter the outgoing international code, or long press until "+" is displayed.
2. Enter the recipient's national code, area code and phone number.
3. Send out your call by pressing .





Making an Emergency Call

Enter 112 (the international emergency number) and press . This emergency call can be made without a SIM card inserted, so long as you are within the coverage of the type of network used by your phone.

Dialing an Extension Number

After you enter the telephone number, long press for a second and **P** will display on the screen. Enter the extension number, and press to make the call.


Last Missed, Dialed, and Received Calls

There are two scenarios in which you can review the most recently missed, answered and dialed phone numbers as well as the time and date information associated with the calls:

- If incoming calls were not answered, your phone displays a message of missed calls along with the number of call times. Press (SEL) or twice. The most recently missed call is displayed first. Then use to display the missed call you want.
- In idle mode, press to access a list of missed, dialed and received calls. The most recent is displayed first. Press to scroll to the phone number you want.

When the phone number of a missed/dialed/received call appears on the screen, you can do the following:

- Press (SEL) or to redial the phone number.





- To store the phone number in your phone book, long press . Follow the prompts to enter the name and confirm the phone number. Then specify a caller group and location number and press (OK) or to save.

Note: The phone number saved this way is stored in you SIM card memory. To save a phone number in the phone memory, go to "Add Entry to Phone (1-4)" on page 49.

Note: For details on the caller group, see "Caller Group (1-6)" on page 50.

Making an Abbreviated Call

Type a location number of a desired phone book record and press . Then press (OK) or to dial the displayed number. You can also press to scroll phonebook numbers until the one you want appears.




Phone Book Directory Shortcut

1. As on the idle screen indicates, press to access the Phone Book directory.

or

In idle mode, long press to access the Phone Book directory.

2. Press to browse the entries (listed in alphabetical order). appears at the top left of the screen if the record you display is stored in the SIM card memory, while shows up if the record is stored in the phone memory.





You can also find an entry by typing the first letter of its name. For example, to find a name that starts with "K", enter K and press (OK) or . The names starting with "K" will appear first. Scroll the names until you find the one you want.

3. When the desired phone number appears:

Press (SEL) or to dial the number.

or

Long press to edit the phone number record. You can edit the record in the same way you save a phone number in the phone book.

Messages Menu Shortcut


As on the idle screen shows, press to enter the Messages menu. For details on the Messages menu, see page 55.

Adding Phone Book Entries in Idle Mode

Enter a phone number and press (SAVE) or long press . Follow the prompts to enter the name and confirm phone number, specify a caller group* and location number for the record, and press (OK) or to save*.

** For details on the caller group, see "Caller Group (1-6)" on page 50.*

Note: The phone number saved this way is stored in you SIM card memory. To save a phone number in the phone memory, go to "Add Entry to Phone (1-4)" on page 49.





Incoming Call Waiting

If another call comes in while you are on the phone, you can:

- Press **(END CALL)** and **(CALL WAITING)** to reject the waiting call.
- Press **(END CALL)** and **(CALL WAITING)** to end the active call and connect the waiting call.
- Press **(2WAY)** and **(CALL WAITING)** to hold the active call and connect to the waiting call.

** Network and subscription dependent.*

Holding a Call




When you are on a phone call and wish to dial another number, you can place the current call on hold by pressing **(OPTION)** or **(CALL WAITING)**. After a call is put on hold, **[1]** will appear on the screen, and when the second call is connected, **[1]** will pop up.

When you have an active call and a call that is on hold, you can press **(CALL WAITING)** to switch calls.

When an active call ends, the call on hold will resume. You can also make a call on hold active again by pressing **(CALL WAITING)** if you have only a held call.

Note: This hold-call feature is network and subscription dependent.

Note: The figure next to **[] / []** (in the example above it is "1") indicates the number of held/active calls.





Call Options Menu

When you are on a phone call, press to access the Call Options menu listed below. Use to scroll and press (SEL) or to access a selected option; press (QUIT) or to leave a selected option.

Note: Options marked "*" are network and subscription dependent.

***SIM Menu**

Access the SIM Tool Kit menu.

Mute

Mute the microphone so the person you are speaking with cannot hear your voice. appears when this mode is on.

***Messages**

You can read, write and send messages with this function. For details on the Messages menu see page 55.




Conference

The Conference menu has the following options:

Note: The maximum number of parties allowed during a conference (multi-party) call varies, depending on the network you choose.

*** End Call**

During a multi-party call, you can end the call on one of the parties by selecting this function.





*** Swap**

This function is available when you have both active and held calls. **Swap** transfers the active call to hold and vice versa, so that you may converse with the other party.

*** Hold**

This function allows you to put a currently active call on hold, so that you can initiate a new call.

*** Unhold**

Once you end the new call while holding an old call, the old call can be made active again by selecting this function.

*** Join Call**

This function allows you to make a conference call.

*** Private**


Talk privately with one participant during a conference call.

*** Transfer**

This function allows you to end your own call and connect the active and held calls, so the callers of the active and held calls can speak with each other alone.

Phone Book

You can access the Phone Book menu by selecting this item.





Call List


View dialed, received, and missed calls. When the desired phone number appears, press or (SEL) to call, save, or delete the number.

Adjusting the Earpiece Volume

When speaking on the phone, press to adjust the volume.

Initiating Keypad Lock

In idle, long press to activate the keypad lock. When the lock is enabled, will appear at the bottom of the idle mode screen. To deactivate the lock, press (Un**lock**) or , then press . You can also activate the keypad lock in the menu option **Key Lock**. See page 73.





Input Mode Menu


Your phone provides several input methods when you wish to:

- write short messages
- enter names or numbers in the phone book

** For details on these features, see related sections of this user guide.*

Message editor display

Character count information




Cursor

Input mode indicator

Phonebook editor display

Prompt for current input



Text area


Press to delete characters.

Press for input menu.

Press to confirm.

Selecting an Input Mode

On the editor screen, press or long press to access the input mode menu. Scroll the menu with and press or to select, or press a corresponding number key directly to choose from the following input modes:





Note: The factory default for the input mode is **ABC Input (ABCD)**. However, you can set the default yourself. See "Input Mode (4-5)" on page 74. The default input mode you set appears automatically with the editor screen.


Note: The input mode menu may vary from market to market.

Smart Input (iTAP)


The **Smart Input** system (or *iTAP*, as shown on the editor screen) analyzes letters as they are being typed to come up with the right words, making text entry quick and easy. **Smart Input (iTAP)** is an efficient alternative to the traditional multi-tapping input, which requires you to press a key several times for an appropriate letter.

Features of Smart Input (iTAP)

- One key press per letter. No multi-pressing for entering letters.
- Comprehensive word database including common names.
- Widely used punctuation and symbols included.



Smart Input (iTAP) Keypad Mapping



Tips for Using Smart Input (iTAP)

To enter words:

- Type a word by pressing a corresponding alphanumeric key only once for each letter, without having to consider the order of the alphabets indicated on the keys. The word you type will appear outside the text frame before you confirm it OK.
- To switch between upper case and lower case, press . Press (DEL) once to delete a wrong letter; long press to delete an entire word.
- The word changes as you type letters. Disregard what is on the screen until you type an entire word.




- If the word displayed is not the one you want after typing it completely, press for the next word candidate. You can also press for the next/previous candidate. When the desired one appears, press (OK) or to put it inside the text frame, then a space will appear automatically between the word and the cursor. So you can type the next word directly without having to leave a space for it.
- After you enter a word in the text area, you can press once to move the cursor to the insertion point of the next/last character; long press to move the cursor continuously.
- In the text area, press (DEL) once to clear one character; long press to clear all text.

To enter punctuation and symbols:

- You can long press to display a bar of available punctuation and symbols at the bottom of the screen. Press to scroll the symbols one by one; long press to scroll page by page. Press (OK) or to enter a highlighted symbol, or press a corresponding number key for a desired symbol directly (~), from left to right).
- Press (QUIT) or to exit the punctuation & symbol bar.


Demo of Smart input (iTAP)

To enter **COME HOME** on the message editor screen:




1. Press (MENU) to access the input mode menu. Select **Smart Input** and press (SEL) or .







2. Press **0** → **2** for the upper case C. Then press **0** → **6** → **6** → **3** for lower case o, M, and e.




3. Press **OK** or **↵** to enter **Come** into the text frame.



4. Press **4** → **6** → **6** → **3** for **home**.



5. **good** isn't the word you want, so press **#** or **⏏** for the next candidate **home**.



6. Press **OK** or **↵** to put **home** inside the text frame.

ABC Input



ABC Input is the factory default input mode that appears automatically with the editor screen.

If **Smart Input** (ITAP) doesn't provide the word you want, you also can press **MENU** or long press **↵** for the input menu and select **ABC Input**.





Please see "Alphanumeric Keys" on page 19 for the listing of the alphabets and symbols represented by each key in ABC Input.




Tips for Using ABC Input




- Follow the order of the alphabets shown on each key to enter data.
- Press once for the first letter shown on a particular key, twice for the second letter, and so on and so on.
- Long press a corresponding key to shift among upper case, lower case and number.
- When you have entered a letter and want to enter the next one, you can wait for about two seconds until the cursor moves to the position of the next letter, or simply press a key immediately to enter it.
- If you type a wrong letter or number, you can move the cursor to it by pressing , then press  to erase it.



For example, to enter **Love**:

1. Press  three times for **L**.
2. Long press  to change to lower case and press the same key twice for **o**.
3. Press  three times for **v**.
4. Press  twice for **e**.



123 Input

This input mode allows you to enter numbers using the alphanumeric keys  - . To enter punctuation, long press  to display the punctuation and select.





Insert Symbol

Displays the bar of punctuation and symbols. Use to scroll the bar (long press to scroll page by page) and when the desired symbol is highlighted, press (OK) or . You can also press a corresponding number key (-) for a desired symbol.

Select Icon

You can insert an animated icon into a text message you'd like to send by selecting this input mode.




When the icon list appears, use to scroll to the animated icon you want, then press (SEL) or to put the icon in your message text. The icon you inserted is encoded in the form of three specific symbols. When done, press (OK) or .

Note: For concatenated SMS, you must enter the icon before the 160th character.

- To view the actual icon along with the message text, you must go to **Preview**. Please see related sections under the main menu option **Messages (2)** (p. 55) in chapter 7.
- To exit from the icon list without choosing an icon, press (QUIT) or .
- To delete the icon from the message text, simply press to erase the symbols that represent the icon.

Note: **Select Icon** is only available for message editing.

Note: Each message allows only one icon. The **Select Icon** option will not appear in the input mode menu if you already attached an icon to the message.





Note: You can also send an icon message by selecting **Icon Message** in the **Messages** menu. See page 61.

Note: Icon message feature must be supported by your network operator and by the recipient's phone.

Insert Quick Msg

Quick Msg is a list that allows you to compose messages and notes by making use of the sentences already stored in the phone.

In the menu option **Select Quick Msg**, you can customize the Quick Msg list by adding the sentences you wrote to the list. See page 61 for details.

Quick Msg Listing

The following is the entries of the default Quick Msg list:

No.	Phrases and sentences
6	I'm busy now, will call you later
7	Happy Birthday
8	Please call my mobile number
9	Please call office
10	I'm not coming home for dinner
11	I'm on my way, please wait
12	I love you
13	I'm sorry
14	Please call home
15	Merry Christmas
16	Happy New Year





No.	Phrases and sentences
17	Have a safe trip
18	Get well soon
19	Thank you
20	I arrived safely
21	Don't leave until I get there
22	Meet me at [time] [place]
23	I will be there in [xx] minutes
24	I'll be leaving at
25	Wish you success

Note: The default Quick Msg list may vary from market to market.

Note: The first 5 blank entries in the list are reserved for you to store the sentences you wrote. Please see **Select Quick Msg** on page 61.

Note: **Insert Quick Msg** is not available in Phone Book.



Using Quick Msg sentences

Scroll with and press (SEL) or to enter a desired sentence, or press a corresponding number key to select (-). As soon as the sentence is entered, the screen automatically returns to Smart Input (iTAP). You can now modify the sentence into the message you want. If you wish to use the other input modes, press .

Select Dictionary

Select a dictionary database for the language that is currently used in iTAP mode. The default language is English.*

* The dictionary may vary from market to market.





Quick Access

Quick Access is a ready menu of 9 regularly used features. It provides you with an efficient means to access these features directly and minimizes the number of steps required for accessing via the main menu.

Note: The default Quick Access menu may vary from market to market.

Quick Access Menu






In idle mode, press  to display the Quick Access menu.

Note: You can personalize the Quick Access menu as needed by selecting what features you want available in this menu. For information on the available Quick Access menu items and how to configure your Quick Access menu, see "Quick Access (8-6)" on page 91.

Note: The SIM Menu option is a network support and subscription dependent feature.

Note: For details on each menu option, please refer to related sections of this user guide.

Using the Quick Access Menu

Press  to scroll through the menu and press  (SEL) or  to access an option. You can also press a corresponding number key to get to a desired function directly. To exit from a Quick Access option or operation, press  (QUIT) or .




Menus

Your phone's menus cover a variety of features. The main menu consists of 8 animated images, that represent specific options with related submenus.

Using Menus

Normal Access to an Option

For example, if you want to change the language setting:






Press (QUIT or EXIT) or to return to the previous menu.

Shortcut Access

In the main menu, type a corresponding function code listed behind each option in the following sections. By means of the shortcut access you can quickly reach a desired function.

For example, if you want to change the language setting (the function code for the language setting is 4-4):





Phone Book (1)

The Phone Book menu allows you to view the phone book directory you create and add and delete entries. In this menu you can choose from the following:

Last Number (1-1)

Missed (1-1-1)

Displays the last missed calls.*

* Network/Subscription dependent.





Press  to browse the calls. Then press  (SEL) or  to choose from the following:

Call

Calls back.


Save

Saves the number into the SIM card memory's phone book:

1. Enter the name and confirm the telephone number and press  (OK) or .
2. Add the phone book record to a preferred caller group list, and press  (SEL) or .

Tip: A caller group has its specific settings, i.e., ring tone, etc. When a member of a particular caller group phones you or sends you a text message, your phone will make that group's ring tone so you can tell immediately which group the caller belongs to before you answer the call.



Note: Each name in the phonebook can belong to only one caller group.





Note: For information on customizing the settings of each caller group, see "Caller Group (1-6)" on page 50.

Note: To activate/deactivate the Caller Group function, go to "Caller Group (7-5)" on page 83.

Your phone will assign a location number for this record. Press  (OK) or  to confirm.

Delete

Deletes the number.

Received (1-1-2)

Displays the last received calls.*

* *Network/Subscription dependent.*

You can use this option the same way as **Missed** (1-1-1).

Dialed (1-1-3)


Displays the last dialed calls.*

* *Network/Subscription dependent.*

You can use this option the same way as **Missed** (1-1-1).

Delete All (1-1-4)

Deletes all records of missed, received, or sent calls.





Find Record (1-2)

Follow the prompt to enter the name. When done, press (OK) or . The corresponding location, telephone number and name will appear on the screen. You can also find a Phone Book record by typing the first letter of its name. For example, if the name starts with "K", enter K and press (OK) or . The names starting with "K" will appear on the screen. Scroll through the names until the one you want appears on the screen.

Now you can press (SEL) or to choose from the options below:

Call

Dials the number.

Edit

You can edit the record here. Modify the name, number and select a caller group for the number.

Delete

Deletes the record.



Copy

Copies the record to another location. Choose to move the record to the SIM or phone memory, enter the location number, and press (OK) or .

Add Entry to SIM (1-3)

You can store phone book records in your SIM card memory:

1. Enter the name and phone number and press (OK) or .





2. Add the phonebook name to a preferred caller group list, and press (SEL) or .

3. Your phone will assign a location number for this record. Press (OK) or to confirm.

Tip: When you enter a new phone number, use the international number format: Long press to display + and enter the corresponding country code and the phone number. By doing so, you do not have to change the records when you are roaming in other countries.

Add Entry to Phone (1-4)

You can store phone book records in the phone memory by selecting this option. The steps are the same as described in "Add Entry to SIM."



Delete (1-5)

You can erase phonebook records that are no longer needed:



By Name (1-5-1)

Deletes records by name.

Enter the name of the record and press (OK) or . The record will display on the screen. Press (SEL) or to delete.

Delete All In SIM (1-5-2)

Deletes all phone book records stored in the SIM card memory. You will be prompted to enter the phone code before you delete all records. Enter the phone code and press (OK) or to delete.





Delete All In Phone (1-5-3)

Deletes all records stored in the phone memory. Steps are the same as described in "Delete All In SIM."

Caller Group (1-6)

You have 5 caller groups to choose from (**Default Group** and **Group 1-4**). You can add any phone book records to a particular caller group and define such settings as ring tones, etc., for incoming calls from a specific group.



Tip: Settings for **Default Group** are also applied to incoming calls not assigned to a caller group.

Tip: To activate/deactivate the Caller Group function, go to "Caller Group (7-5)" on page 83.

Settings for **Default Group** and **Group** are as follows:



View List

View the phone book names stored in this group.

- If no records were added, **No Matching Record** will appear.
- If this group already has records in it, you can scroll the records and when the desired one appears, press  (**SEL**) or  to choose to dial the number (**Call**) or move this record to another caller group (**Edit**).

Rename

Change the title of this group. (not available in **Default Group**).





Vibracall

Set the vibration mode for this group:

Off

Turn the vibration mode off.

Vibrate and Ring

The handset rings and vibrates simultaneously when there is an incoming call from this group.

Vibrate Only

The handset vibrates without ringing when a call comes in from this group.

Vibrate Then Ring

When a call comes in from this group, the handset vibrates five times first before it rings.



Ring Type

Define a ring tone for this group. Your phone will ring in the tone you choose when there is an incoming call from this group.


SMS Alert

Specify an alert tone for short messages from this group.

Service Number (1-7)

Under this option you can view and call the service phone numbers provided by your network operator.* These numbers are stored and locked by your operator in your SIM card.

** Network/SIM card dependent.*





Own Number (1-8)

Sets or displays the record of your current SIM card number.

- If no own number records are saved in the memory, your phone displays **No Records Add Record?**. Press (OK) or and enter your name and phone number, then specify a location for this number (1 or 2).
- If you have already entered your own number data, press (OK) or and choose to add a new record, edit or delete the current record.

Status (1-9)

This menu option allows you to view the numbers of free and occupied phonebook entries. The phone memory can store up to 100 phonebook records, while the number of available entries in the SIM memory varies, depending on the network service you subscribe to.

The screen will show the numbers of available and occupied entries in the SIM card. You can press to view the numbers of free and occupied entries in the phone memory.



Copy Record (1-10)


This function allows you to copy or move phonebook records between the SIM and phone memories.

SIM->Phone (1-10-1)



Copy or move phonebook records from the SIM into the phone memory.



Single (1-10-1-1)

Copy or move a single phonebook record from the SIM memory into the phone memory.







Keep Original (1-10-1-1-1). Copy a single record from the SIM memory and paste it into the phone memory, while the original record is still kept in the SIM memory. Scroll through the records stored in the SIM memory. When the desired one appears, press  (OK) or  and the record will be copied into the phone memory.

Delete Original (1-10-1-1-2). Remove a single record from the SIM memory and store it in the phone memory. Scroll through the records stored in the SIM memory. When the desired one appears, press  (OK) or  and the record will be moved into the phone memory.

All (1-10-1-2)

Copy or move all records from the SIM card into the phone memory.

Keep Original (1-10-1-2-1). Copy all of the records from the SIM memory into the phone memory, while the original records remain in the SIM memory. After entering this option, the screen will show the total number of the records and ask if you want to copy all the records. Press  (OK) or  and all the records will be copied into the phone memory.

Delete Original (1-10-1-2-2). Remove all the records from the SIM and paste them into the phone memory.



Phone->SIM (1-10-2)



Single (1-10-2-1)

Copy or move a single phonebook record from the phone memory into the SIM memory.







Keep original (1-10-2-1-1). Copy a single record from the phone memory and paste it into the SIM memory, while the original record is still kept in the phone memory. Scroll through the records stored in the phone memory. When the desired one appears, press  (OK) or  and the record will be copied into the SIM memory.



Delete Original (1-10-2-1-2). Remove a single record from the phone memory and store it in the SIM memory. Scroll through the records stored in the phone memory. When the desired one appears, press  (OK) or  and the record will be moved into the SIM memory.

All (1-10-2-2)

Copy or move all records from the phone memory into the SIM card.

Keep original (1-10-2-2-1). Copy all of the records from the phone memory into the SIM memory, while the original records remain in the phone memory. After entering this option, the screen will show the total number of the records and ask if you want to copy all the records. Press  (OK) or  and all the records will be copied into the SIM memory.

Delete Original (1-10-2-2-2). Remove all the original records from the phone memory and paste them into the SIM.
















Messages (2)



The following options are network and subscription dependent.

Inbox (2-1)

If a new message is received by the phone, a tone is sounded, and the prompt **Read?** pops up with . ( also appears on the upper left of the idle screen). Press  (OK) or  to display the message record directly, or enter this menu option to do so. Then you will see the record of the last received message showing its delivery time, date and phone number or caller ID (provided stored in the phone book). Press  (SEL) or  to read the message. If you have two or more new messages, press  to browse the message records and press  (SEL) or  to read.


After reading a message, press  (OPTION) or  for the following options:

Reply

Reply to the message. When you are finished with a reply message, press  (OK) or  to choose from the following options:

Single Recipient

Send the reply message to one recipient. When the recipient's phone number appears, press  (OK) or  to send the message directly.





Multiple Recipients

By Entry. You can send the message to recipients you select from your phone book entries. Scroll the entries and press (SEL) to select the recipients. You can also press (CANCEL) to deselect a recipient. The maximum number of recipients that you can select is 10. When done, press to show the list of the selected recipients. Press (CHANGE) if you want to change the list. (You change the list in the same way as you select/deselect a recipient.) Finally, press to send the message to the selected recipients.

By Group. You can send the message to the members you select from a particular caller group. Choose a preferred group and select recipients in the same way you select by entry from the phone book.

Select Icon*

Insert an animated icon into the message. This option works the same way as **Select Icon** in the input mode menu. See "Select Icon" on page 40 for details on the **Select Icon** feature.




** The **Select Icon** option will not appear if you already have an icon attached to the message.*

Preview

View the modified message. If the message comes along with an animated icon, the icon will pop up on the screen first, then you can press to display the text message.

Save

Enter a phone number and press (OK) or to save the message to Outbox.





Delete

Deletes the message. When done, **Deleted Read Next?** will display on the screen. If you want to read the next message, press (OK) or . If you want to exit, press (QUIT) or .

Start Chat

This option allows you to initiate a chat session by replying to a received message in Inbox. You will be prompted to enter your nickname and a chat message. When done, press (OK) or to initiate the chat session. For more information, see "SMS Chat (2-3)" on page 59.

Call Back

Dials the number shown on the record of the received message.


Edit

You can edit the received message. When done, press (OK) or to choose from the following options:

Single Recipient






You can send the message to one recipient in two ways:

- Enter the recipient's phone number as you are prompted to do so and press (OK) or to send the message directly.
- If you want to select a number from the Phone Book when you are prompted to enter the phone number, you can press (SEL) or and enter the recipient's name saved in the Phone Book. When the desired phone number appears, press (OK) or to send the message. You can also press or twice to select a phone number directly from the Phone Book without having to enter the name first.





Multiple Recipients

By Entry. You can send the message to the recipients you choose from your phone book entries. Scroll the entries and press  (SEL) to select the recipients to whom you want to send message. You can also press  (CANCEL) to deselect a recipient. When done, press  to show the list of the selected recipients. Press  (CHANGE) if you want to change the list. (You change the list in the same way as you select/deselect a recipient.) Finally, press  to send your message to the selected recipients.

By Group. You can send the message to the members you select from a particular caller group. Choose a preferred group and select recipients in the same way you select by entry from the phone book.


Select Icon*

Insert an animated icon into the message. This option works the same way as **Select Icon** in the input mode menu. See "Select Icon" on page 40 for details.



Note: For concatenated SMS, you must enter the icon before the 160th character.


** The **Select Icon** option will not appear if you already have an icon attached to the message.*

Preview

View the modified message. If the message comes along with an animated icon, the icon will pop up on the screen first, then you can press  to display the text message.

Save

Enter a phone number and press  (OK) or  to save the message to Outbox.








Send



Forwards the received message to one or more recipients. You can do this the same way as described on page 57.

Use Number

Displays and uses the phone number of the message.

If a message has more than one number, you can use  to scroll the numbers. When the desired one appears, press  (SEL) or  to choose from the following:

Save



Saves the phone number in the Phone Book. Enter the name and confirm the phone number. Then specify a caller group and location number for the phone number. Press  (OK) or  to save the number.

Call

Press  (SEL) or  to dial the number.

New Message (2-2)


This function allows you to write short messages.

Write down the message you want. When done, press  (OK) or  to choose to send or save the message.

This option has the same submenu as **Edit in Inbox (2-1)**.

SMS Chat (2-3)

Note: This feature is network support and subscription dependent.






You can engage in a peer-to-peer chat session by writing short messages to the other mobile phone user. There are three ways of initiating a chat session:

1. You can select a previously received message in **Inbox (2-1)** and choose **Start Chat** to set up a chat session. See "Start Chat" on page 57.
2. When someone invites you to a chat by sending you a chat message, or when she/he accepts your chat invitation by replying to your chat message, the chat prompt will pop up showing her/his name followed by a message. Then you can choose to join the chat or reject the chat by pressing a corresponding soft key.
3. If you come to this SMS Chat menu to open a chat session, select **Start Chat (2-3-1)**:



- First enter a nickname you'd like to use during a chat. Then write down the message you wish to send and press (OK) or . Finally enter the phone number of the person you want to chat with and press (OK) or to send the message to invite the recipient to a chat.
- When you have sent a chat message, the message is displayed on the screen as **nickname :>message**. Then you can continue the chat by sending another message.
- If you want to leave the chat session screen, press (QUIT). Then you can enter this SMS Chat menu again and choose **Resume Chat** to go on with a chat session, or choose **End Chat** to terminate a chat session.
- When you are interrupted by an incoming call during a chat session:





- You can press to answer the call. Upon ending the call, the screen returns to idle. Then you may resume the chat session by selecting **Resume Chat** from the **SMS Chat** menu.
- You can press to reject the incoming call and continue the chat by selecting **Resume Chat** from the **SMS Chat** menu.
- You can choose **History** from the **SMS Chat** menu and view a chat log recording the chat conversions. You can also erase the log data by choosing **Erase History**.

Icon Message (2-4)

In this option, you can first select an icon you like, then write down a text message you'd like to send with the icon. When done, choose to send or save the message. This option has the same submenu as **Edit** in **Inbox (2-1)**.

Note: For concatenated SMS, you must enter the icon before the 160th character.

Select Quick Msg (2-5)

This function allows you to personalize the Quick Msg list by writing and storing your own sentences. You can also use the sentences already stored in this list to edit a message.

To Write and Store Your Quick Msg Sentences

In the Quick Msg list, pick one out of the first five empty entries and select **Edit** to start writing your own sentences. When done, press (OK) or to save the sentence. The screen will return to the Quick Msg list showing the sentence stored in the selected entry.





To Access a Quick Msg Sentence You Wrote

In the Quick Msg list, scroll to a desired sentence you wrote and press (SEL) or , or press a corresponding number key to select. The following will appear:

View

Displays the entire sentence. Then you can modify the sentence into the message you want. When finished, press (OK) or to choose to send or save the message. This option has the same submenu as **Edit** in **Inbox (2-1)**.

Send

You can send the message to one or more recipients. You can do this the same way as described on page 57.

Edit




Modify the sentence. When finished, press (OK) or to save the modified sentence to its Quick Msg entry.

Delete

Deletes the sentence. When done, the entry where the sentence was previously stored will become blank.

To Access a Preset Quick Msg Sentence

In the Quick Msg list, scroll to a preset sentence you want and press (SEL) or , or press a number key to select from sentences 6-9. Then choose **View** or **Send**. Operations are the same as described above.





Outbox (2-6)

You can use this function to read the messages you saved. After entering this option, you will see the record of the last saved message showing its phone number and record number. Scroll the records until the one you want appears on the screen. Then press (SEL) or to view the message. When finished, press (OPTION) or to choose from the following:

Delete

Deletes the selected message.

When done, "Deleted Read Next?" will pop up. If you want to read the next message, press (OK) or . If you want to exit, press (QUIT) or .

Edit

Operation and submenu are the same as those of **Edit** in **Inbox (2-1)**.


Send

Sends the message to one or more recipients. You can do this the same way as described on page 57.

Use Number

Displays and uses the phone number of the message.

Operations and submenu are the same as those of **Use Number** in **Inbox (2-1)**, see "Use Number" on page 59.





Voice Mail (2-7)

You can call the voice mailbox provided by your operator and listen to the voice mail left by a caller.

Once your voicemail box receives a message, the voicemail waiting icon pops up at the center of the screen. Press or to return to idle, and you will find on the screen indicating a voice mail is waiting at line 1. (will show up if line 2 is in use).* Then you can long press to dial the voice mailbox number directly, or enter this menu option to do so.

** 1All voice mail icons are network support dependent. For how to designate the line in use, please see "Line in Use (3-5)" on page 71.*

Call (2-7-1)

Dial the voice mailbox number to listen to the voice mail.

Edit (2-7-2)



You can modify your voice mailbox number. Enter the voice mailbox number provided by your operator and press (OK) or .

Broadcast (2-8)

You can receive cell broadcast offered by your network operator, and choose preferred topics and languages.

Receive (2-8-1)



Choose whether or not to receive the cell broadcast provided by your operator.







Topics (2-8-2)

Display the topics of the broadcast message.

After entering this item, "No Topics Add Topic?" will appear if no topics have been saved before. Press  (OK) or  and enter the topic you want. If you have entered a topic before, it will appear on the screen when you select this item. You can then choose to add a new topic, edit or delete the saved one.

Language (2-8-3)



Display broadcast messages only in the languages you select. Scroll the languages and press  (SEL) or  to select.

Settings (2-9)

This menu includes several options to adjust the message settings:


Route Center (2-9-1)

This option stores the phone number of the message center. The message you send is transmitted via this message center to the recipient.

Enter the message center number provided by your operator and press  (OK) or  to save the number.

Valid Period (2-9-2)

You can select the length of time that your text messages are stored at the message center while the message center attempts to deliver them.





Reply Path (2-9-3)

You can ask the network to set the route of the reply message via your own message center. If you set this function on and send a message to someone and the person replies, the reply message will follow the path of the previous message that you sent.

Notification (2-9-4)

If you activate this function, your network operator will send you a delivery report.


Format (2-9-5)

You can ask the network to convert your text message into different formats. Select from the following formats: Text, Paging, and Voice.



Delete All (2-10)

Deletes all the messages.



Call Services (3)

Call Services provide several options to manage your calls.


Tip: Functions under this menu are network support and subscription dependent.

Call Records (3-1)

This menu contains records of call cost and duration.

Time (3-1-1)

This function records the information of call duration.





Last Call (3-1-1-1)

Shows duration of the last call in hours, minutes & seconds.

All Calls (3-1-1-2)

Shows the total duration of all types of calls.

Outgoing Calls (3-1-1-3)

Shows the total duration of all outgoing calls.

Incoming Calls (3-1-1-4)

Shows the total duration of all incoming calls.

Clear Time (3-1-1-5)

Clear all duration data.

Cost (3-1-2)

This function records the information of call cost.

Last Call (3-1-2-1)

Shows the cost of the last call.*

** Network support dependent.*

All Calls (3-1-2-2)

Shows the total cost of all calls.*


** Network support dependent.*

Clear Cost (3-1-2-3)

Clears all cost data.*

** PIN 2 is required.*

Tip: PIN2 is a second set of PIN that is used mainly to control limited services such as call cost limitation and fixed dialing numbers.





Tip: If entered incorrectly three times in a row, PIN2 will be locked up. To unblock PIN2, you need to enter the PUK2 code. Please call the operator, and ask for PUK2.

Call Rate (3-1-3)

Cost Limit (3-1-3-1)

You can set a limit to the total call cost. Your phone cannot be used to make a pay call if call cost goes beyond that limit. When this function is activated, the remaining cost will appear on the screen.

On: Enable the cost limit function.*

* PIN2 is required.

Off: Disable this function.

Currency (3-1-3-2)

Allows you to enter a preferred currency base for calculating the cost of your calls.*

* PIN2 is required.

Charge Unit (3-1-3-3)

Allows you to enter the unit price for calculating the cost.*




* PIN2 is required.

Call Divert (3-2)

You can choose from the following call divert modes as needed.






Divert Voice (3-2-1)

Divert incoming voice calls to a designated phone number.





Activate

Enables the Divert Voice mode. Enter the number to divert to and press  (OK) or . When this mode is on,  or  will appear, depending on which line you divert.  will appear if you divert both line1 and line2.*

* For how to designate the line in use, see page 71.

Cancel: Disables this function.

Status: Shows the status of this function.

When Busy (3-2-2)

Incoming calls are sent to a designated number when your phone is busy. Settings are the same as those for **Divert Voice (3-2-1)**.

If No Reply (3-2-3)

When an incoming call is not answered, it will be sent to a designated phone number. Settings are the same as those for **Divert Voice**.

Unreachable (3-2-4)

When the phone is off or located outside the network service area, incoming calls will be sent to a designated number. Settings are the same as those for **Divert Voice**.



Divert Cond. (3-2-5)

Diverts all incoming calls to a designated number when your phone is busy, unreachable or there is no reply from your phone.

Choose to enable/disable this function.

Cancel All (3-2-6)

Cancels all call divert settings.





Call Barring (3-3)

You can set up limitations to restrict outgoing or incoming calls.

All Outgoing (3-3-1)

Bars all outgoing calls. Options are as follows:

Activate

Enter the password provided by your network operator and press (OK) or to enable this function.

Cancel

Enter the password provided by your network operator and press (OK) to disable the function.

Status: Show the status of this function.



Int'l Out (3-3-2)

Bars all outgoing international calls. Settings are the same as those for **All Outgoing (3-3-1)**.



Int Exc Home (3-3-3)

Bars outgoing international calls except calls that are connected to home country. Settings are the same as those for **All Outgoing**.

All Incoming (3-3-4)

Bars all incoming calls. Settings are the same as those for **All Outgoing**.

In When Roam (3-3-5)

Bars incoming calls when roaming (when you are traveling abroad). Settings are the same as those for **All Outgoing**.





Cancel All (3-3-6)

Cancels all call barring settings. Enter the password provided by your network operator and press  (OK) or .

Change Code (3-3-7)

Change the password for the Call Barring feature.

Call Waiting (3-4)

When you are on another call and an incoming call is directed to your phone, an incoming call number and a call-waiting message will appear to remind you. Choose to activate, cancel or check the status of this function.

Line in Use (3-5)

This function allows you to use two different telephone numbers for one single phone. You can designate the number used to make a call and use both of these numbers simultaneously to receive calls without having to use two phones to do so.

Choose **Line** or **Line 2**. The icon of the line you selected will appear on the idle screen.*


** Network support dependent.*

Show Number (3-6)

You can decide whether or not to show your number on the recipient's phone when you make a call:

Preset (3-6-1)

Whether the recipient's phone will display your number depends on the default setting on the network side.





On (3-6-2)

The recipient's phone will show your number when you send a call.

Off (3-6-3)

Your phone number will not appear on the recipient's phone.

Phone Setting (4)

This menu allows you to program the phone's various settings as needed.

ScreenSaver (4-1)

This menu allows you to display the default animation stored in the phone memory.


Off (4-1-1)

Deactivate the screensaver function. The LCD screen will display phone and network information in idle mode. No animation will appear if you select this option.

Animation 1 (4-1-2)

Display the handset's default animation 1.

The screensaver you select will be displayed on the idle screen if no incoming call is received and you leave the keypad untouched for about 20-30 seconds. The screensaver will disappear temporarily if there is an incoming call received by the phone or when you touch any key on the keypad.





Animation 2 (4-1-3)

Display the handset's default animation 2. Scenarios are the same as described in "Animation 1."

Set Time & Date (4-2)

Sets current date and time to be displayed on the idle screen. To set the date, use number keys to enter year, month and day, then press (OK) or to confirm. To set current time (24 hr format), use to enter the hour, then press and enter the minute the same way. You can also use number keys to type the exact time directly. If you want to clear digits, press (DEL).

Key Lock (4-3)

You can activate the keypad lock to prevent unintentional key-in actions, say, when you put your phone in a bag. In idle, you can also long press to activate the lock. When the lock is enabled, will appear at the bottom of the idle mode screen. You still can answer phone calls by pressing . To unlock, press (Un1ock) or , then press .

Auto KeyLock (4-3-1)


The key lock will be activated approximately 30 seconds after you set this mode on.

Lock now (4-3-2)

Activate the key lock immediately.

Off (4-3-3)

Disable the function.





Language (4-4)

You can select the language used to display information.

Tip: The language you choose will be stored in your SIM card memory. Accordingly, the language setting may change if you insert a different SIM card.

Tip: If you want to use the default language setting locked in the phone memory, select **Automatic (4-4-1)**.

Input Mode (4-5)

You can set the default input mode that comes along with the editor screen.



Time Alert (4-6)

Your phone will beep every minute during a call. Select On or Off.






Auto Redial (4-7)

If you make a call that is not answered, your phone will redial the number continuously. Your phone will redial up to 10 times before the call is answered. Choose to turn this function on or off.



Back Light (4-8)

Adjusts the duration of the LCD backlight. The backlight will be turned on the moment the phone receives calls, messages, etc., or when you touch any key on the keypad. Select a desired time period or choose to turn the backlight off.





Restore (4-9)

Reset all settings to default. Enter the phone code (the default phone code is 1234) and press  (OK) or  twice to confirm.

Network (5)

When turning on your mobile phone, the phone automatically connects to the designated network operator. This menu allows you to select an appropriate network operator and system as needed.*

** Network and subscription dependent.*

Automatic (5-1)


The phone will perform another network operator search after this function is selected.

Manual (5-2)

The phone lists the available network operators for you to choose from.

Band (5-3)

Choose the frequency band for the GSM radio standard as needed. If you select **Automatic**, your phone will detect the network environment and select an appropriate network system automatically. You can also connect your phone to a GSM 900 or GSM 1800 network by choosing **900 MHz** or **1800 MHz**.





Security (6)

This menu ensures the security of your phone by setting PIN check, phone code, SIM lock etc., as well as limitations on particular outgoing and incoming phone calls.

Code Status (6-1)

PIN code (6-1-1)

Activate/Deactivate the PIN code.

Select **On** or **Off**. When you change the PIN code status, you will be prompted to enter PIN.







Phone Code (6-1-2)




Activate/Deactivate the phone code. The phone code helps prevent unauthorized use of your phone. When this function is on, you must enter your phone code every time you power on your phone (there is no limitation on the number of wrong attempts when you enter the phone code).

Select **On** or **Off**. When changing the phone code status, you must enter your phone code. (The default phone code is 1234).

Change Code (6-2)

PIN Code (6-2-1)

You can change your PIN. You need to activate your PIN as described in 6-1-1 before changing your PIN. First, enter the original PIN and press  (OK) or . Then enter the new PIN and press  (OK) or . Enter the new PIN again and press  (OK) or  to confirm.





PIN2 Code (6-2-2)

You can change PIN 2 code the same way you change your PIN.*

** When you enter a wrong PIN2 code three times in a row, you need to enter the PUK2 code to unblock PIN2, if so provided by your operator.*

Phone Code (6-2-3)

You can change your phone code in the same way you change your PIN.

Network Code (6-2-4)

You can change the network password in the same way you change your PIN.

Fixed Dial (6-3)

You can set limitations on the numbers you can call.

Note: You must get PIN2 before you can use this feature.

Note: If you enter a wrong PIN2 code three times in a row, you need to enter the PUK2 code to unblock PIN2, if so provided by your operator.

View (6-3-1)


You can view the fixed-dial numbers you set.

Set Status (6-3-2)

Enables/disables this feature. You will be prompted to enter PIN2 when you activate this feature.

Modify (6-3-3)

You need to enter PIN2 before you can add, edit and delete the records of your fixed-dial numbers.





SIM Lock (6-4)

This function prevents unauthorized use of the phone with unknown SIM cards.


When you set this function on, if the SIM card in your phone is not the one used to enable this function, you will be prompted to enter the unlock code when you power on your phone. If you enter the correct unlock code, the phone recognizes the SIM card automatically. The next time you power on your phone with this newly recognized SIM card, you will not be prompted to enter the unlock code. However, if you enter an incorrect unlock code, the phone displays **Insert Correct SIM** and functions as if the SIM cards were not inserted.* Your phone can recognize up to 3 different SIM cards.

** There is no limitation on the number of wrong attempts when you enter the SIM lock code.*






Set Status (6-4-1)

Enables/disables the SIM lock. You need to enter the unlock code first before you change the SIM lock status (The default unlock code is 00000000).



Change Code (6-4-2)

Change the unlock code. You will be prompted to enter the original unlock code first. Enter the original unlock code and new unlock code twice and press  (OK) or . The length of the code may vary from 1 to 8 digits, depending on your setting.







Audio Setting (7)

You can adjust the audio settings of your phone here.

Ring Type (7-1)

Select a ring tone from a variety of melodies. The ring tone you set in this option will be used for the currently active profile (see **Profiles 7-4** on page 80). Scroll the list of the available ring tones and listen to a highlighted melody. Then press  (SEL) or  to confirm your choice.

Vibracall (7-2)

Select a desired vibration mode from the following options. The vibration mode you set here will be used for the currently active profile (see **Profiles 7-4** on page 80).

Off

Turn the vibration mode off.

Vibrate and Ring



The handset rings and vibrates simultaneously when a call comes in.

Vibrate Only

The handset vibrates without ringing when a call comes in.

Vibrate then Ring

When a call comes in, the handset vibrates five times first before it rings.





SMS Alert (7-3)

Select an alert tone for incoming short messages. Your phone will make the tone you set when a short message has been received. The alert tone you set in this option will be used for the currently active profile (see "Profiles 7-4").

Profiles (7-4)

This feature allows you to customize such audio settings as ring tones, vibration, ring volume, etc. to suit a variety of occasions. When you are in this menu, you will see a list of profiles. You can customize the settings of each profile and activate one of these profiles for a special event or situation.

General (7-4-1)

Activate (7-4-1-1)

Activates settings of the General profile.




Customize (7-4-1-2)

This menu allows you to customize the following as needed:


The settings you set in the **Caller Group (1-6)** have priority over the following **Profile** settings (see "Caller Group (1-6)" on page 50). Accordingly, **Vibracall**, **Ring Type** and **SMS Alert** you set here are applied only when the **Caller Group** feature is deactivated.

Vibracall. Sets the vibration mode:

- **Off:** Turn the vibration mode off.
- **Vibrate and Ring:** The handset rings and vibrates simultaneously when a call comes in.







• **Vibrate Only:** The handset vibrates without ringing when a call comes in.  appears at the top of the idle screen when you select this mode.*





* However,  will not appear if **Caller Group** feature is on, unless you select **Vibrate Only** for all caller groups.

• **Vibrate then Ring:** When a call comes in, the handset vibrates five times first before it rings.

- **Ring Type**

Select a ringing mode from a variety of melodies. Scroll the options and listen to the highlighted melody. Then press  (SEL) or  to confirm your choice.

- **Ring Volume**




You can adjust the ring volume level . A total of five levels are available. Press  to change the ring volume level and press  (SEL) or  to confirm.

- **SMS Alert**

Select the alert tone for incoming short messages. Your phone will make the tone you set when a short message has been received.

- **Keypad Tone**

This setting determines whether keypad tones will be sounded. Choose On or Off.






- Answer By

2 modes are available for you to answer incoming calls:

Any Key: The incoming calls can be answered by pressing any key.

Send Key: The calls can be answered by pressing .

Connect Beep

This function allows your phone to beep, vibrate or flash backlight when the recipient answers your call.

Silent (7-4-2)


Settings are predefined for occasions where silence is required (e.g., vibration on, ringer mode off, keypad tone off, etc.). You can adjust the settings in the same way you adjust **General (7-4-1)**.

Meeting (7-4-3)

Settings are predefined for the circumstances of a meeting. (e.g., vibration on, ringer mode off, etc.). You can adjust the settings in the same way you adjust **General**.

Outdoors (7-4-4)

Settings are predefined for outdoor activities (e.g., ringer volume high). You can adjust the settings the same way you adjust **General**.





Headset (7-4-5)

Settings are predefined for the occasions when the handsfree kit is connected to your handset. You can adjust the settings the same way you adjust **General**.

Personal (7-4-6)

Options are the same as under **General**. Adjust the settings in the same way you adjust **General**.



Caller Group (7-5)

Activates/deactivates the Caller Group feature.

Edit Melody (7-6)


This function allows you to compose 2 ring melodies of your own using the available musical notes stored in your phone memory.



Select an empty ring and the following scale will pop up:



Composing a Melody

To set the note length: Press a corresponding number key (0-9) to place the musical note of a desired length on the scale (see the table below).





To set the pitch of a note-c, d, e, f, g, a, b and the octave:

When the note of a particular length appears, press the same corresponding number key (1-5) several times to move the note up and down on the scale.






- Press (#) to add # (not available for e, b).
- Press (left arrow) to move the cursor between notes.
- Press (right arrow) to delete a note; long press (right arrow) to delete all notes.

Tip: The maximum duration of a score is 24 seconds. No further note entry will be allowed once this limit is reached.

Keypad Mapping

The table below illustrates how to enter the musical notes of different length and symbols using their corresponding keys:

Key	Note length	Note symbol	Note Symbol (inverted)
1	1/32		
2	1/16		
3	1/8		
4	3/16		
5	1/4		





Key	Note length	Note symbol	Note Symbol (inverted)
	3/8	↓	↑
	1/2	↓	↑
	3/4	↓	↓
	1	○	○
	Rest	Press the same key repeatedly to produce the desired rest note.	
	Sharp	#	#

Note: The Flat (b) is not available, and has no function.

Settings

When you finish the score of a melody, press or to choose from the following:

Play



Play the melody you just composed.

Save Tone

Save the melody as an option of **Ring Type** in **Profiles** and **Caller Group** settings.

Edit

Edit the score of the melody.





Rename

Change the name of the melody.*

** You must save the melody before you change its name.*

Timebeat

Adjust the time beat to the rhythm you want.*

** You must save the melody before you change its time beat.*

Delete

Delete the melody.

Send Melody

Send the melody to someone in the same way that you send a text message.*

** You must save the melody before you can send it.*




Tools (8)

This submenu provides features to better your wireless life.

SIM Menu (8-1)

Your network operator provides this feature. Depending on your SIM card and the services provided, there will be several extra options under this option. However, if your network operator does not offer these services, this item will not be displayed on the screen. For details, please contact your operator.





Games (8-2)

Snake (8-2-1)

Make the snake grow longer by feeding it with as many goodies as possible. Use **(Z)** (up), **(X)** (down), **(M)** (right) and **(C)** (left), or **(V)** (clockwise/▲ counterclockwise) to direct the snake to a goody. The longer the snake, the higher the score. You are not allowed to stop the snake or make it go backwards. When the snake hits its own tail or eggs, or the surrounding frame, a game is over. Then the screen will show your score.

After you select this game, you will see the following:

Continue

Resume a paused game. This item appears only when a game has been temporarily halted.

New Game

Start a new game. If you want to exit the game before it is over (to halt a game), press **(E)**. To resume a halted game, please go to **Continue**.

Last View

Show the result of the last game you play.

Level


Set the difficulty level of the game.

Top Score

Show the top score of a game ever played.

Instructions

Read the instructions for the game.





Tetris (8-2-2)

Tetris is a deceptively simple, completely addictive electronic puzzle game. The object of the game is to position the falling shapes, called "Tetraminoes," across the bottom of a rectangular pit. Tetraminoes are shapes created from 4 blocks joined together into 7 different patterns. The Tetraminoes must be rotated as they fall and positioned across the bottom leaving no open spaces. When an entire horizontal line fills with blocks, the line clears from the screen. If lines are not completely filled with blocks, they will not clear from the screen, and the Tetraminoes will continue to stack up higher and higher. If the stack of Tetraminoes reaches the top, the game is over!

Use the following keys to move a falling piece:

- or rotates a falling Tetramino.
- , , and move a falling tetramino to the right or to the left.
- drops down a tetramino (if you don't want to wait for it to reach the bottom).


The menu options in this game are the same as those in **Snake**.

Box World (8-2-3)

In this puzzle game your job is to get rid of all the boxes. This is done by pushing each of them onto a fixed black object. When you finish pushing all boxes onto the black objects, you pass the boxworld of the current level, and you can proceed with a new game of the next level.

Use the following keys to play this game:

- Move the pusher using (up), (down), (right), (left), or (up and down).





- Press to undo one move. Press to play the game all over again.
- Press to read the current status about this game, which includes:
 - The number of the user's moves in this game.
 - The least moves taken in a previous game.

The menu options in this game are exactly the same as those in **Snake** except that there is no **Top Score**.

Set Alarm (8-3)

Set the alarm clock:

Daily (8-3-1)

Sets the alarm to go off daily when the alarm time is reached, even if the handset is powered off. To set current time, use to enter the hour, then press and enter the minute the same way. You can also press number keys to enter time. If you want to clear numbers, press (DEL).

Once (8-3-2)




Sets the alarm to go off only once.

Off (8-3-3)

Turn off the alarm clock.

Calculator (8-4)

You can use your phone as a handy calculator. You can also use this feature to convert currency values.






Using the Calculator Feature

In this option, a cursor will appear at the upper left of the screen. Follow the chart below to enter numbers and arithmetic symbols.

Key	Number/ Function	Key	Number/Function
	1		9
	2		0
	3		+ - * /
	4		. ()
	5		Clear number/back to previous screen
	6		Display result
	7		Move the cursor
	8		abort operation/exit calculator






For example, to calculate the following formula:

$$123 \times (456 + 34) \div 4 - 2$$

Press (3 times) (twice) (3 times) (4 times) (twice) .

Press and select **Equals** to display the result.






Converting Currency Values

1. When the calculator screen appears, press . Select **Exchange Rate** and press (SEL) or . Choose **Local to Foreign** or **Foreign to Local** to set the exchange rate. If you set **Local to Foreign** as "2", for example, the rate in **Foreign to Local** will become "0.5" automatically, and vice versa.
2. When the rate is set, press (OK) or to return to the calculator screen. Enter the sum you want to convert and press . Then choose **To Local** or **To Foreign** to see the converted figure. According to the rate above, for example, if you enter "20" and choose **To Local**, the outcome will be $20 \times 0.5 = 10$. If you choose **To Foreign**, the outcome will be $20 \times 2 = 40$.

Tip: To exit from the calculator or currency converter feature, press .






Hour Minder (8-5)

Set the hour minder. After you activate this feature, the phone beeps once an hour like a digital watch.

Quick Access (8-6)




In this option, the screen will display a configuration list of 25 features as options for you to add to the Quick Access menu discussed in chapter 5. With this configuration list, you can create a Quick Access menu of your own by choosing which features you want readily available.





Below is the configuration menu:

Option	Functionality
Add Entry to SIM	Add new phone book entries to the SIM card memory.
New Message	Write a new message.
Missed Calls	View and send/save/delete last missed calls.
Profiles	Enable/Disable settings of a selected profile.
Set Alarm	Set the alarm function.
SIM Menu	Access the SIM tool kit menu provided by your operator (network support and subscription dependent).
Inbox	Read messages stored in Inbox.
Vibrate On/Off	Set the vibration mode.
Divert Call On/Off	Activate/ cancel/check the Divert Voice function.
Quick Msgs	Access the listing of Quick Msgs to send a message.
Ring Volume	Adjust ring volume.
Last Call Timer	Display the duration of the last call.
Outbox	Access the outgoing SMS message list.
Switch Line 1/2	Switch between Line 1 and Line 2.
Last Number Dialed	Display and call/save/delete last dialed numbers.
Last Call Cost	Display the charge for the last dialed call.





Option	Functionality
Last Calls Received	Display and call/save/delete the numbers of last calls received.
Find By Name	Find a number by name in the phone book.
Add Entry to Phone	Add new phone book entries to the phone memory.
Voice Mail	Dial the voice mailbox number directly.
Phone Mute On/Off	Mute and un-mute the microphone.
Change Band	Select the band to connect to (network dependent).
Calculator	Use the calculator feature.
SMS Chat	Access the SMS Chat menu.
Games	Access the Games menu




Customize the Quick Access Menu

Scroll to the configuration menu and press (SEL) or to select a highlighted item, or press a corresponding key to select from item 1-9 directly. Then you will be prompted to specify a location in the Quick Access menu for the selected item. Enter a location number (1-9) and press (OK) or . **Settings Saved** will appear indicating that the selected item has been successfully added to the Quick Access menu.

Tip: The Quick Access menu always has exactly nine options.

Tip: Items that are already listed in the **Quick Access** menu will be marked by a location number.






Tip: You can replace any of the nine **Quick Access** options with a different preset item listed in the configuration menu.


Tip: A preset item can be assigned to more than one location in the **Quick Access** menu.

Tip: You can press a corresponding number key to select any of the first 9 preset items in the configuration menu.





Menu Structure Map







Care and Maintenance

Notice the following to ensure the proper usage and the life of your mobile phone:

- Keep your mobile phone and its accessories out of small children's reach.
- Keep your phone dry. Use your phone at a normal temperature. Temperature higher than 55°C or lower than -20°C (higher than 131°F or lower than -4°F) may cause damage to your phone.
- Do not use or store your phone in dusty or dirty areas if possible.
- Do not disassemble the phone.
- Do not use harsh detergents to clean the phone.
- If your mobile phone or its accessory is not working properly, contact your dealer immediately.
- Use only genuine batteries, battery chargers and accessories to ensure the proper function of your phone and battery life. Any malfunction or damage caused by the use of any third-party accessories will void the product warranty.
- Keep battery contacts and the charger port at the bottom of your phone from direct contact with conductive objects. Otherwise it may cause a short circuit and result in danger.








Problems and Solutions

If you encounter any problems using your mobile phone, please refer to the following table. If the problem persists, please contact your dealer.

Problem	Possible cause	Solution
Poor signal reception	• You are using your mobile phone in a location (e.g. in the basement or building) where signal is weak.	Move to a location where signal can be received properly.
	• You are using your mobile phone in a call-crammed time (e.g., the rush hour).	Avoid using your mobile phone in such time, or try later.
	• You are too far from the base station of your network operator.	You can ask your network operator for a service range map.
Echo or noise	• The network trunk quality of your network operator.	Hang up the phone and dial again. You can be switched to a better-quality network trunk or line.
	• Poor local telephone line quality.	
The standby time becomes short	• The standby time depends on the system settings of your network operator.	if you are in a location where the signal is weak, turn your phone off for the time being.
	• The battery needs to be replaced.	Use a new battery.
	• If the phone cannot get connected to a network, it will continue searching for the signal from the base station, which consumes battery capacity.	Change your location or turn off your phone temporarily.
Unable to power on	• Battery has run out.	Recharge the battery if necessary.



Problem	Possible cause	Solution
SIM card error	• SIM card is out of order.	Send it to your network operator for test.
	• SIM card is not inserted properly.	Insert SIM card correctly.
	• SIM card contacts are dirty.	Clean the SIM card contacts using a soft, dry cloth.
Unable to connect to the network	• SIM card is invalid.	Contact your network operator.
	• You are away from the GSM service area.	Check the service area with your network operator.
	• Poor signal.	Move to another place where signal can be received properly.
Unable to send a message	• Your network service provider doesn't support this service.	Contact your network operator.
Unable to make a call	• You have activated fixed dial function.	Cancel fixed dial function.
Wrong PIN	• You have entered a wrong PIN three times in a row.	Contact your network operator, or use the PUK code of the SIM card if provided by your network operator.
Unable to charge the battery	• The battery or charger is out of order.	Contact your dealer.
	• The phone temperature goes under 5°C or above 40°C.	Change the charging environment.
	• Poor connection.	Check if all connectors are connected properly.
Unable to input data into the Phone Book	• The Phone Book memory is full.	Delete some data from the Phone Book.



Problem	Possible cause	Solution
Unable to choose certain functions	<ul style="list-style-type: none">Your network operator doesn't support these functions, or you do not subscribe to them.	Contact your network operator.
Battery appears not to be fully charged after overnight charging.	<ul style="list-style-type: none">Battery may have discharged after fully charging due to normal phone operation while turned on.	Plug charger into phone again to reach full charge.
Phone does not immediately turn on after plugging in charger after extended period of non-use.	<ul style="list-style-type: none">It may be necessary to charge for up to 30 minutes to recharge the battery enough to turn the phone on.	Charge battery as long as needed until phone turns on.

