




MOTOROLA

START HERE >

Welcome

Welcome to the world of Motorola digital wireless communications! We are pleased that you have chosen the Motorola T722i GSM wireless phone.



Personal Communications Sector
600 North U.S. Highway 45
Libertyville, Illinois 60048

1-800-331-6456 (United States)

1-888-390-6456 (TTY/TDD United States)

1-800-461-4575 (Canada)

www.motorola.com (United States)

www.motorola.ca (Canada)

MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. TrueSync, Sidekick, Starfish and the Stylized Starfish Logo are registered trademarks of Starfish Software, Inc., a wholly owned independent subsidiary of Motorola, Inc. Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries. All other product or service names are the property of their respective owners.

© Motorola, Inc. 2002, 2003.

Software Copyright Notice

The Motorola products described in this manual may include copyrighted Motorola and third-party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third-party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of the Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third-party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Manual number: 6809459A12-O

Cover number: 8988485L61-O

Contents

Safety and General Information	6
Getting Started	12
What's in the Box?	12
About This Guide	12
Installing the SIM Card	13
Installing the Battery	14
Charging the Battery	16
Battery Use	16
Changing the Convertible Covers	18
Attaching the Camera	19
Turning Your Phone On	20
Adjusting Volume	20
Making a Call	21
Answering a Call	21
Changing the Call Alert	22
Viewing Your Phone Number	22
Learning to Use Your Phone	23
Using the Display	23
Using the 4-Way Navigation Key	26
Using Menus	28
Entering Text	33
Using the Status Light	41
Using the External Display	42
Locking and Unlocking Your Phone	42
Changing a Code, PIN, or Password	43
If You Forget a Code, PIN, or Password	44
Taking Photos and Sending Picture Messages	45

Setting Up Your Phone	49
Storing Your Name and Phone Number	49
Setting the Time and Date	49
Setting a Ring Style	49
Setting Answer Options	50
Setting a Wallpaper Image	51
Setting a Screen Saver Image	52
Zooming In and Out	53
Setting Display Contrast	53
Setting Display Color	53
Adjusting the Backlight	54
Conserving Battery Power	54
Calling Features	55
Changing the Active Line	55
Redialing a Number	55
Using Automatic Redial	56
Using Caller ID	56
Canceling an Incoming Call	57
Turning Off a Call Alert	58
Calling an Emergency Number	58
Dialing International Numbers	58
Viewing Recent Calls	59
Returning an Unanswered Call	60
Using the Notepad	61
Attaching a Number	62
Calling With Speed Dial	62
Calling With 1-Touch Dial	62
Using Voicemail	63
Using Call Waiting	64
Putting a Call On Hold	65
Transferring a Call	65

Phone Features	67
Main Menu	67
Feature Quick Reference	69
Specific Absorption Rate Data	81
Additional Health and Safety Information	83
Warranty	91
Product Registration	96
Export Law Assurances	96
RF Energy Interference	96
Index	97
Wireless Phone Safety Tips	107

Safety and General Information

IMPORTANT INFORMATION ON SAFE AND EFFICIENT OPERATION.
READ THIS INFORMATION BEFORE USING YOUR PHONE.

The information provided in this document supersedes the general safety information in user guides published prior to December 1, 2002.

Exposure To Radio Frequency (RF) Energy

Your phone contains a transmitter and a receiver. When it is ON, it receives and transmits RF energy. When you communicate with your phone, the system handling your call controls the power level at which your phone transmits.

Your Motorola phone is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

Operational Precautions

To assure optimal phone performance and make sure human exposure to RF energy is within the guidelines set forth in the relevant standards, always adhere to the following procedures.

External Antenna Care

Use only the supplied or Motorola-approved replacement antenna. Unauthorized antennas, modifications, or attachments could damage the phone.

Do NOT hold the external antenna when the phone is IN USE. Holding the external antenna affects call quality and may cause the phone to operate at a higher power level than needed. In addition, use of unauthorized antennas may result in non-compliance with the local regulatory requirements in your country.

Phone Operation

When placing or receiving a phone call, hold your phone as you would a wireline telephone.

Body-Worn Operation

To maintain compliance with RF energy exposure guidelines, if you wear a phone on your body when transmitting, always place the phone in a Motorola-supplied or approved clip, holder, holster, case, or body harness for this phone, if available. Use of accessories not approved by Motorola may exceed RF energy exposure guidelines. If you do not use one of the body-worn accessories approved or supplied by Motorola, and are not using the phone held in the normal use position, ensure the phone and its antenna are at least 1 inch (2.5 centimeters) from your body when transmitting.

Data Operation

When using any data feature of the phone, with or without an accessory cable, position the phone and its antenna at least 1 inch (2.5 centimeters) from your body.

Approved Accessories

Use of accessories not approved by Motorola, including but not limited to batteries and antenna, may cause your phone to exceed RF energy exposure guidelines. For a list of approved Motorola accessories, visit our website at www.Motorola.com.

RF Energy Interference/Compatibility

Note: Nearly every electronic device is susceptible to RF energy interference from external sources if inadequately shielded, designed, or otherwise configured for RF energy compatibility. In some circumstances your phone may cause interference.

Facilities

Turn off your phone in any facility where posted notices instruct you to do so. These facilities may include hospitals or health care facilities that may be using equipment that is sensitive to external RF energy.

Aircraft

When instructed to do so, turn off your phone when on board an aircraft. Any use of a phone must be in accordance with applicable regulations per airline crew instructions.

Medical Devices

Pacemakers

Pacemaker manufacturers recommend that a minimum separation of 6 inches (15 centimeters) be maintained between a handheld wireless phone and a pacemaker.

Persons with pacemakers should:

- ALWAYS keep the phone more than 6 inches (15 centimeters) from your pacemaker when the phone is turned ON.
- NOT carry the phone in the breast pocket.
- Use the ear opposite the pacemaker to minimize the potential for interference.
- Turn OFF the phone immediately if you have any reason to suspect that interference is taking place.

Hearing Aids

Some digital wireless phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer to discuss alternatives.

Other Medical Devices

If you use any other personal medical device, consult the manufacturer of your device to determine if it is adequately shielded from RF energy. Your physician may be able to assist you in obtaining this information.

Use While Driving

Check the laws and regulations on the use of phones in the area where you drive. Always obey them.

When using your phone while driving, please:

- Give full attention to driving and to the road.
- Use hands-free operation, if available.
- Pull off the road and park before making or answering a call if driving conditions so require.

Responsible driving best practices may be found in the “Wireless Phone Safety Tips” at the end of this manual and at the Motorola website:

www.Motorola.com/callsmart.

Operational Warnings

For Vehicles With an Air Bag

Do not place a phone in the area over an air bag or in the air bag deployment area. Air bags inflate with great force. If a phone is placed in the air bag deployment area and the air bag inflates, the phone may be propelled with great force and cause serious injury to occupants of the vehicle.

Potentially Explosive Atmospheres

Turn off your phone prior to entering any area with a potentially explosive atmosphere, unless it is a phone type especially qualified for use in such areas and certified as “Intrinsically Safe.” Do not remove, install, or charge batteries in such areas. Sparks in a potentially explosive atmosphere can cause an explosion or fire resulting in bodily injury or even death.

Note: The areas with potentially explosive atmospheres referred to above include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, areas where the air contains chemicals or particles, such as grain, dust, or metal powders. Areas with potentially explosive atmospheres are often but not always posted.

Blasting Caps and Areas

To avoid possible interference with blasting operations, turn OFF your phone when you are near electrical blasting caps, in a blasting area, or in

areas posted “Turn off electronic devices.” Obey all signs and instructions.

Batteries

Batteries can cause property damage and/or bodily injury such as burns if a conductive material such as jewelry, keys, or beaded chains touch exposed terminals. The conductive material may complete an electrical circuit (short circuit) and become quite hot. Exercise care in handling any charged battery, particularly when placing it inside a pocket, purse, or other container with metal objects. **Use only Motorola original batteries and chargers.**

Your battery or phone may contain symbols, defined as follows:

Symbol	Definition
	Important safety information will follow.
	Your battery or phone should not be disposed of in a fire.
	Your battery or phone may require recycling in accordance with local laws. Contact your local regulatory authorities for more information.
	Your battery or phone should not be thrown in the trash.
	Your phone contains an internal lithium ion battery.

Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to blinking lights, such as when watching television or playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your doctor before

playing video games on your phone or enabling a blinking-lights feature on your phone. (The blinking-light feature is not available on all products.)

Parents should monitor their children's use of video game or other features that incorporate blinking lights on the phones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation.

To limit the likelihood of such symptoms, please take the following safety precautions:

- Do not play or use a blinking-lights feature if you are tired or need sleep.
- Take a minimum of a 15-minute break hourly.
- Play in a room in which all lights are on.
- Play at the farthest distance possible from the screen.

Repetitive Motion Injuries

When you play games on your phone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow these instructions to avoid problems such as tendonitis, carpal tunnel syndrome, or other musculoskeletal disorders:

- Take a minimum 15-minute break every hour of game playing.
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again.
- If you continue to have sore hands, wrists, or arms during or after play, stop playing and see a doctor.

Getting Started



What's in the Box?

Your digital wireless phone typically comes equipped with a battery and a charger. You can purchase other accessory items, such as an attachable camera, to customize your phone for maximum performance and portability.

To purchase Motorola Original™ accessories, contact the Motorola Customer Call Center at 1-800-331-6456 in the United States or 1-800-461-4575 in Canada.

About This Guide

This guide introduces you to your Motorola wireless phone.

Note: A *More Here* reference guide for your phone is also available that describes your phone's features in more detail.

To obtain the *More Here* guide for your phone, or another copy of this guide, see the Motorola Web site at:

<http://motorola.com/consumer/manuals> (U.S.A.)

<http://motorola.ca/consumer> (Canada)

or contact the Motorola Customer Call Center at 1-800-331-6456 in the United States or 1-800-461-4575 in Canada.

Optional Features



This label identifies an optional network, SIM card, or subscription-dependent feature that may not be offered by all service providers in all geographical areas. Contact your service provider for more information.



Optional Accessories



This label identifies a feature that requires an optional Motorola Original™ accessory.


Installing the SIM Card

Your SIM (Subscriber Identity Module) card contains your phone number, service details, and phonebook/message memory.

Caution: Do not bend or scratch your SIM card. Avoid exposing your SIM card to static electricity, water, or dirt.


Action

- 1 If necessary, slide down the battery door release latch and lift the door off of the phone.




Action


- 2 Slide the SIM card latch up.



- 3 Insert the SIM card into the SIM card tray with the notch in the lower left corner and the gold plate facing down.



- 4 Slide the SIM card latch down to lock the SIM card in place.



Installing the Battery

You must install and charge the battery to use your phone.




Your phone is designed to be used only with Motorola Original batteries and accessories. We


recommend that you store batteries in their protective cases when not in use.

Action


- 1 Remove the battery from its protective clear plastic case.
- 2 If necessary, slide down the battery door release latch and lift the door off of the phone.



- 3 Insert the battery, printed arrow first, **under the tab** at the top of the battery compartment and push down.



- 4 Insert the teeth at the bottom of the battery door into the slot at the base of the phone, then push the door down. Slide the release latch up to lock the door in place.




Charging the Battery

New batteries are shipped partially charged. Before you can use your phone, you need to install and charge the battery as described below. Some batteries perform best after several full charge/discharge cycles.

Action

- 1 Plug the travel charger into your phone with the release tab facing up.



- 2 Plug the other end of the travel charger into the appropriate electrical outlet.
- 3 When your phone indicates that the battery is fully charged (**Charge Complete**), press the release tab and remove the travel charger.

Note: When you charge the battery, the battery level indicator in the upper right corner of the display shows how much of the charging process is complete. At least 1 segment of the battery level indicator must be visible to ensure full phone functionality while charging.

Battery Use

Battery performance depends on many factors, including your wireless carrier's network configuration; signal



strength; the temperature at which you operate your phone; the features and/or settings you select and use; items attached to the phone's accessory connector port; and your voice, data, and other application usage patterns.

Caution: To prevent injuries or burns, do not allow metal objects to contact or short-circuit the battery terminals.

To maximize your battery's performance:

- Always use Motorola Original™ batteries and battery chargers. The phone warranty does not cover damage caused from using non-Motorola batteries and/or battery chargers.
- New batteries or batteries that have been stored for long periods of time may require a longer charge time.
- Maintain the battery at or near room temperature when charging.
- Do not expose batteries to temperatures below -10°C (14°F) or above 45°C (113°F). Always take your phone with you when you leave your vehicle.
- When you do not intend to use a battery for a while, store it uncharged in a cool, dark, dry place, such as a refrigerator.
- Over extended periods of time, batteries gradually wear down and require longer charging times. This is normal. If you charge your battery regularly and notice a decrease in talk time or an increase in charging time, then it is probably time to purchase a new battery.





The rechargeable batteries that power this product must be disposed of properly and may need to be recycled. Refer to your battery's label for battery type. Contact your local recycling center for proper disposal methods. Never dispose of batteries in a fire because they may explode.



Changing the Convertible Covers




You can change the flip cover and battery cover on your phone to personalize its appearance. Matching front and back cover sets are available in a variety of colors and designs.

Your phone is designed to be used only with Motorola Original accessories. See your Motorola retailer for these convertible covers.

Remove a Flip Cover

Action

Insert your fingertip or fingernail into the slot at the base of the flip cover, then *firmly* pull up and lift the cover off the phone



Notes:


- Do not use tools to remove a flip cover. Using tools to remove a flip cover will damage the cosmetic appearance of the phone.
- The flip cover is attached tightly to the phone, and considerable force is required to remove it.



Attach a Flip Cover

Action

Insert the tabs at the bottom of the cover into the slots at the base of the phone, then push the cover down and snap it into place.




Attaching the Camera



Insert the optional Motorola Original™ Digital Camera into the accessory connector port

at the bottom of your phone as shown.


For instructions on how to take and send photos, see page 45.



Turning Your Phone On

Action

- 1 Open your phone
- 2 Press and hold  to turn on the phone



- 3 If necessary, enter your SIM card PIN code and press **OK** () to unlock the SIM card

Caution: If you enter an incorrect PIN code 3 times in a row, your SIM card is disabled and your phone displays **SIM Blocked**.


- 4 If necessary, enter your 4-digit unlock code and press **OK** () to unlock the phone

The unlock code is originally set to 1234. Your service provider may change this number before you receive your phone.

Adjusting Volume

Press the up and down volume keys to:

- increase and decrease earpiece volume during a call
- increase and decrease the ringer volume setting when the idle display is visible (flip must be open)



Tip: At the lowest volume setting, press the down volume key once to switch to vibrate alert. Press it again to switch to silent alert. Press the up volume key to cycle back to vibrate alert, then ring alert.

- turn off an incoming call alert



Making a Call

Press	To
1 keypad keys	dial the phone number
	Tip: If you make a mistake, press DELETE (⏏) to delete the last digit, or press and hold DELETE (⏏) to clear all digits.
2 	make the call
3 	end the call and “hang up” the phone when you are finished

Note: You must dial the phone number from the idle display. See page 23.

Answering a Call

When you receive a call, your phone rings and/or vibrates and displays an incoming call message.

Press	To
1  or ANSWER (⏏)	answer the call
2 	end the call and “hang up” the phone when you are finished


Tip: When the phone flip is active, simply open the phone to answer the call. (To activate, press  > **Settings** > **In-Call Setup** > **Answer Options** > **Open to Answer**)

Note: If the phone is locked, you must unlock it to answer the call.



Changing the Call Alert

With the phone flip open, press the down volume key to switch the alert for incoming calls and other events to vibrate alert, then silent alert. Press the up volume key to reset ring alert.



Viewing Your Phone Number

To view your phone number from the idle display, press  .

While you are on a call, press  > **My Tel. Numbers**.


Note: Your phone number must be stored on your SIM card to use this feature. To store your phone number on the SIM card, see page 49. If you do not know your phone number, contact your service provider.

Learning to Use Your Phone

See page 1 for a basic phone diagram.

Using the Display

The *idle display* (shown below) is the standard display you see when you are *not* on a call or using the menu. You must be in the idle display to dial a phone number.




The ☰ (menu) indicator in the bottom center of the display indicates you can press the menu key (☰) to go to the main menu to see more features.



Labels at the bottom corners of the display show the current soft key functions. Press the left soft key (☐) or right soft key (☐) to perform the function indicated by the left or right soft key label.

At the top of the display are a number of status indicators:



1 Signal Strength Indicator Vertical bars show the strength of the network connection. You cannot make or receive calls when the  (no signal) indicator is displayed.



2 GPRS Indicator Shows that your phone is using a high-speed GPRS network connection. Other indicators can include:

 = GPRS PDP context active

 = GPRS packet data available

③ In Use Indicator Shows that a call is in progress. Other indicators can include:

 = secure CSD call

 = unsecure CSD call

 = secure packet data transfer

 = unsecure packet data transfer

 = secure application connection

 = unsecure application connection



④ Roam Indicator Shows that your phone is seeking or using another network system outside your home network. On text entry screens, shows text entry status information:

 = symbol mode

1 = numeric mode

A = caps lock on

a = normal text entry



⑤ Active Line Indicator Shows the current active phone line:

1 = line 1

2 = line 2



⑥ Text Entry Mode Indicator Appears when you are in a text entry screen, to show the current active text entry mode:

 = tap method

 = iTAP mode

⑦ Battery Level Indicator Vertical bars show the battery charge level. Recharge the battery when you see **Low Battery** and hear the low battery alert.



⑧ Ring Style Indicator Shows the ring style setting.

 = loud ring

 = soft ring

 = vibrate

 = vibrate and ring

 = silent



⑨ Message Waiting Indicator Appears when you receive a text or email message. Other indicators can include:

 = voicemail message

 = voicemail and text message

 = active chat session

 = limited character count (text entry screen)


Using the 4-Way Navigation Key

Use the 4-way navigation


key () like a joystick to navigate the menu system, change feature settings, and play games.

Tip: Down and up are your primary movements within menus. Move left and right to change feature settings, navigate the datebook, and edit text.

4-way
navigation
key



From the idle display, press  to temporarily show 4 menu feature icons:




You can press  left, right, up, or down to select one of the menu feature icons when they are visible in the idle display. After five seconds, the menu feature icons disappear to give a better view of the wallpaper image.



Using Menus

From the idle display, press  to go to the main menu.



Press  to highlight a menu feature icon in the main menu. Select **More** () to see additional menu features. The following icons represent features that may appear in

the main menu, depending on your service provider and service subscription options.

Menu Icon	Feature	Menu Icon	Feature
	Media Center		Games & Apps
	Picture Msgs		Shortcuts
	Calculator		Settings
	Chat		Web Access
	More		Services
	Web Sessions		Phonebook
	Messages		Datebook
	Recent Calls		Ring Styles

Tip: You can set your phone to display the main menu as a text-based list rather than graphic icons. See page 72.

Selecting a Menu Feature

This guide shows you how to select a menu feature as follows, starting from the idle display:

Find the Feature


 > More > Phonebook

This example shows that from the idle display, you must press , scroll to and select **More** () from the main menu, then scroll to and select **Phonebook**. Use  to scroll, and the left/right soft keys to select the functions listed in the bottom left and right corners of the display.



Selecting a Feature Option


Some features require you to select an item from a list:



- Press (⬆️) to scroll up or down to highlight the item you want.
- In a numbered list, press a number key to highlight the item.
- In an alphabetized list, press a key multiple times to cycle through the letters on the key and highlight the closest matching list item.

Entering Feature Information

Some features require you to enter information:




Press **CANCEL** (⏏) to exit without making changes. **DONE** (⏏) appears when you enter or edit information.


- Enter numbers or text with the keypad.
- When an item has a list of possible values, press [Up/Down Arrow] to the left or right to scroll through and select a value.
- When an item has a list of possible numeric values, press a number key to set the value.
- If you enter or edit information and do not want to save your changes, press [Cancel Key] to exit without saving.



The message center lets you compose and send text messages. A *flashing cursor* shows where text will appear:



When you enter text using the standard tap method (see page 33), the flashing cursor changes to a *block cursor*, and the soft key functions change:



Entering Text

Multiple text entry methods make it easy for you to enter names, numbers, and messages on your phone.

Choosing a Text Mode

Most text entry screens let you enter letters, numbers, and/or symbols as required. Press  (or  > **Entry Method**) from a text entry screen to select a text mode:

- iTAP** Let the phone predict each word as you enter it. See page 36.
- Tap Method** Enter letters, numbers, and symbols by pressing a key one or more times. See following section.
- Numeric** Enter numbers only.
- Symbol** Enter symbols only. See page 40.
- Browse** Browse your phonebook or recent call lists to select a name or number.

Note: The text mode you select remains active until you change it by selecting another mode.

Using Tap Method

This is the standard mode for entering text on your phone.




Press  > **Entry Method** from any text entry screen and select the **Tap Method** menu option.

	Press	To
1	A number key one or more times	select a letter, number, or symbol shown in the “Character Chart” on page 36
2	Number keys	enter the remaining characters
3	OK ()	store the text when you are finished

General Text Entry Rules

Press a number key repeatedly to cycle through its characters. See the “Character Chart” on page 36.



- If you do not press a key for 2 seconds, the character in the block cursor is accepted, and the cursor moves to the next position.
- The first character of every sentence is capitalized. (Press  down to force the character to lowercase while it is highlighted by the block cursor.)



Character Chart

Use this chart as a guide for entering characters with the tap method.

1...☎	space . 1 ? ! , @ _ & ~ : ; " - () ' ` ¡ ¨ % £ \$ ¥ ¤ €
2 ABC	a b c 2 ä å á à â ã α ó β ç
3 DEF	d e f 3 δ ë é è ê ε é φ
4 GHI	g h i 4 ï í î γ η ή ι í
5 JKL	j k l 5 κ λ
6 MNO	m n o 6 ñ ö ø ó ò ô õ μ ν ω ώ
7 PQRS	p q r s 7 π β σ
8 TUV	t u v 8 θ ü ú ù û τ
9 WXYZ	w x y z 9 ξ ψ
0+*	+ - 0 x * / \ [] = > < # §

Note: This chart may not reflect the exact character set available on your phone.

Use iTAP™ Software Predictive Text Entry Method

iTAP™ software is a predictive text entry method that lets you enter a word using a single keypress per letter.

Press  > **Entry Method** from any text entry screen and select the **iTAP** menu option.

Note: You can switch languages within a message in iTAP text mode. Press  > **Entry Method** to select the language you want to use.

Entering Words

Action

- 1 Press a number key one time to enter the first letter of the word

The letters associated with the key are shown at the bottom of the display.

- 2 Press number keys (one per letter) to enter the rest of the word


Alternative words and letter combinations are shown at the bottom of the display. The word choices are updated with each keypress.

- 3 Press  to highlight the word you want

- 4 Press **SELECT** () to enter the word at the flashing cursor location

A space is automatically inserted after the word.

For example, to spell the word “art,” press    .
The display shows:



Entering Novel Words

You may enter a word that the iTAP software does not recognize. If the word is not displayed:

Action

- 1 Press **DELETE** (⏏) one or more times to delete letters until you see a letter combination that matches the start of the word
- 2 Press ⬅️ or ➡️ left or right to highlight the letter or letter combination
- 3 Press **SELECT** (⏏), then press ⬅️ to the left to shift the text entry cursor to the left and “lock” the selected word portion
- 4 Continue to enter letters and highlight letter combinations to spell the word

 Your phone stores the unrecognized word, and includes it in the list of alternative word choices the next time you enter it. When memory space for storing unrecognized words is filled, your phone deletes the oldest words as new words are added.

Entering Punctuation

Press

⋮ or 0+

To

enter punctuation or other characters as shown in the “Character Chart” on page 36

Using Capitalization

The first word of a sentence is automatically capitalized, with following words in lowercase.

Press	To
 up or down	change the words to initial character capitalized, all uppercase characters, or all lowercase characters

Entering Numbers

Action
1 Enter the first digit and then highlight it to put the iTAP software in number entry mode
2 Press number keys to add digits to the number
3 Press SELECT () to enter the number at the flashing cursor location

Deleting Letters and Words

Place the cursor to the right of the text you want to delete, and then do the following:

Action
Press DELETE () to delete 1 letter at a time
Hold DELETE () to delete the entire message



Using Symbol Mode

Your phone provides an alternate way to enter symbol characters in a message. Press  > **Entry Method** from any text entry screen and select the **Symbol** menu option.

Action

- 1 Press a number key one time to display its symbol options at the bottom of the display
See the "Symbol Chart" on page 40.
- 2 Press , or press the number key multiple times, to highlight the symbol you want
- 3 Press **SELECT** () to enter the symbol at the flashing cursor location

Symbol Chart


Use this chart as a guide for entering characters in symbol mode.

	space . ? ! , @ _ & ~ : ; " - () ' ¿ ¡ % £ \$ ¥ ¤ €
	@ _ \
	/ : ;
	" & '
	() [] { }
	¿ ¡ ~
	< > =
	\$ £ ¥ ¤ €

9WXYZ	# % *
0+	+ - x * / = > < # §

Using the Status Light

The status light shows when you have an incoming call or message, or when your phone is *roaming* (using a non-home system).



Indication	State
alternating red/green	incoming call
flashing green	in service, home system
flashing yellow	roaming, non-home system
flashing red	no service

You can turn off the status light to extend battery life and increase your phone's *standby time*, the length of time that your phone's battery retains power when the phone is turned on but is not in use.

To turn the status light on or off:

Find the Feature

- > Settings
- > Initial Setup
- > Status Light



Using the External Display

When the flip is closed, the external display shows time, date, and phone status information. It also displays messages to notify you of incoming calls and other events. See pages 24–26 for descriptions of the status indicators that may appear in the external display.

Locking and Unlocking Your Phone



You can lock your phone manually or set the phone to lock automatically whenever you turn it off.

To use a locked phone, you must enter the unlock code. A locked phone still rings or vibrates for incoming calls or messages, **but you must unlock it to answer.**

You can make emergency calls on your phone even when it is locked. For more information, see page 58.

Locking Your Phone Manually

Find the Feature

 > Settings > Security
> Phone Lock
> Lock Now

	Press	To
1	keypad keys	enter your unlock code
2	OK ()	lock the phone

Unlocking Your Phone

Tip: Your phone's unlock code is originally set to 1234 at the factory. Many service providers reset the unlock code to the last 4 digits of your phone number.

At the **Enter UnLock Code** prompt:

	Press	To
1	keypad keys	enter your unlock code
2	OK (⏏)	unlock your phone

Setting Your Phone to Lock Automatically

You can set your phone to lock every time you turn it off:

Find the Feature

☰ > Settings > Security
> Phone Lock
> Automatic Lock > On

	Press	To
1	keypad keys	enter your unlock code
2	OK (⏏)	activate automatic lock

Changing a Code, PIN, or Password

Your phone's 4-digit unlock code is originally set to 1234, and the 6-digit security code is originally set to 000000 at the factory. Your service provider may reset these numbers before you receive your phone.



If your service provider has *not* reset these numbers, we recommend that you change them to prevent other users from accessing your personal information. The unlock code must contain 4 digits, and the security code must contain 6 digits.

You can also reset your SIM card PIN code, PIN2 code, and/or call barring password if necessary.

To change a code or password:

Find the Feature

 > Settings > Security
> New Passwords

If You Forget a Code, PIN, or Password

If you forget your security code, SIM card PIN code, PIN2 code, or call barring password, contact your service provider.

If you forget your unlock code, try entering 1234 or the last 4 digits of your phone number. If that does not work, do the following at the **Enter UnLock Code** prompt:

Press	To
1 	go to the unlock code bypass screen
2 keypad keys	enter your security code
3 OK ()	submit your security code

Taking Photos and Sending Picture Messages



You can take photos with your phone using the optional Motorola Original™ Digital Camera accessory, and use them as wallpaper or screen saver images.



You can also send your camera photos to others as *Multimedia Messaging Service* (MMS) picture messages.

Taking Photos

Attach the camera as described on page 19 and follow these steps:

Find the Feature

 > **Picture Msgs**
> **Camera**

The image in the camera's viewfinder appears on your phone's display.

Note: Viewfinder and captured images are scaled to fit your phone's display. The image will have greater resolution when viewed on a PC.



Point the viewfinder at the photo subject and do the following:

	Press	To
1	CAPTURE (⏏)	freeze the image in the display
2	KEEP (⏏)	save the photo as a JPG file on your phone
	or	
	DISCARD (⏏)	delete the photo and return to viewfinder mode
		If you save the photo, continue to step 3
3	SEND (⏏)	open a new MMS picture message with the photo attached
	or	
	BACK (⏏)	return to viewfinder mode



Using Photos

Find the Feature

☰ > **Picture Msgs**
> **Photo Album**

	Press	To
1	⬆	scroll to the photo you want

Press	To
2 SELECT (⏏)	view the photo
3 SEND (⏏)	open a new MMS picture message with the photo attached



or

 open the **Photo Album Menu** to perform other procedures

The **Photo Album Menu** can include the following options:

Option	Description
Send	Open a new MMS picture message with the photo attached.
Info	View photo information.
Rename	Rename the photo.
Delete Photo	Delete the photo.
Delete All	Delete all stored photos.
Set as Wallpaper	Set the photo as your phone's wallpaper image.
Set as Screen Saver	Set the photo as your phone's screen saver image.



Viewing a Photo Slideshow

Find the Feature

☰ > Picture Msgs
> Slideshow

Your phone cycles through all stored photos, briefly displaying each.



Press	To
BACK (⏪)	return to the previous photo
NEXT (⏩)	skip to the next photo
RESTART (⏮)	restart the slideshow (only appears when slideshow is finished)

Setting Photo Capture Size

You can set your phone to capture images at normal size (320 x 240 pixels, QVGA) or small size (160 x 112 pixels, approximate QQVGA). The default setting is normal size.

Note: Viewfinder and captured images are scaled to fit your phone's display. The image will have greater resolution when viewed on a PC.

Find the Feature

☰ > Picture Msgs
> Settings
> Photo Size > size

Setting Up Your Phone

Storing Your Name and Phone Number



To store or edit user name and phone number information on your SIM card:

Find the Feature

- > Settings
- > Phone Status
- > My Tel. Numbers

If you do not know your phone number, contact your service provider. To view your phone number from the idle display or during a call, see page 22.

Setting the Time and Date

You must set the time and date to use the datebook.

Find the Feature

- > Settings
- > Initial Setup
- > Time and Date

Setting a Ring Style

Your phone rings or vibrates to notify you of an incoming call or other event. This ring or vibration is called an *alert*.



You can select one of 5 different ring styles:

 = loud ring

 = soft ring

 = vibrate

 = vibrate and ring

 = silent

The ring style indicator in the display shows the current ring style (see page 24).

To set a ring style:

Find the Feature

 > **More > Ring Styles
> Style**

Press	To
1 	scroll to the ring style
2 SELECT ()	select the ring style

Each ring style contains settings for specific event alerts, ringer ID, and ringer and keypad volume. To change these settings, press  > **More > Ring Styles > Style Detail**.

Setting Answer Options

You can use different methods to answer an incoming call.

Find the Feature

 > **Settings
> In-Call Setup
> Answer Options**

The **Answer Options** menu includes:

Multi-Key

answer by pressing any key

Open to Answer

answer by opening the flip

Setting a Wallpaper Image

You can set a picture or animation as a wallpaper (background) image in your phone's idle display.

Find the Feature

- > Settings
- > Personalize
- > Wallpaper

Press	To
1 	scroll to Picture
2 CHANGE ()	open the picture viewer
3  up or down	scroll to a picture/animation Scroll to (None) to turn off the wallpaper image.
4 SELECT ()	select the image
5 	scroll to Layout
6 CHANGE ()	adjust the image layout
7 	scroll to Center or Tile Center places the image in the center of the display and, if necessary, shrinks the image to fill the display. Tile fills the display with adjacent copies of the image
8 SELECT ()	confirm the layout setting
9 DONE ()	save wallpaper settings

You can also take photos with your phone using the optional Motorola Original™ Digital Camera accessory,



and set one of your photos as a wallpaper image. To set a photo as a wallpaper image, see page 45.

Setting a Screen Saver Image

You can set a picture or animation as a screen saver image.

The screen saver image is displayed when the flip is open and no activity is detected for a period of time. The image is shrunk to fill the display, if necessary. An animation repeats for 1 minute, then the first frame of the animation is displayed.

Tip: Turn off the screen saver to extend battery life.

Find the Feature

 > **Settings**
> **Personalize**
> **Screen Saver**



Press	To
1 	scroll to Picture
2 CHANGE ()	open the picture viewer
3  up or down	scroll to a picture/animation Scroll to (None) to turn off the screen saver image.
4 SELECT ()	select the image
5 	scroll to Delay
6 CHANGE ()	set the delay interval
7 	scroll to the inactivity interval that triggers the screen saver

Adjusting the Backlight

You can set the amount of time that the display and keypad backlights remain on, or turn off backlights to extend battery life.

Find the Feature

-  > **Settings**
- > **Initial Setup**
- > **Backlight**

Conserving Battery Power

Some networks and phones include a battery save setting to extend battery life. When this feature is activated, your phone automatically turns off the keypad backlight when it detects that enough ambient light is available.

Find the Feature

-  > **Settings**
- > **Initial Setup**
- > **Battery Save**



Calling Features

For basic instructions on how to make and answer calls, see page 21.

Changing the Active Line



Change the active phone line to make and receive calls from your other phone number.

Note: This feature is available only for dual-line enabled SIM cards.

Find the Feature

- > Settings
- > Phone Status
- > Active Line

The active line indicator in the display shows the current active phone line. See page 24.

Redialing a Number

	Press	To
1		view the dialed calls list
2		scroll to the entry you want to call
3		redial the number



Using Automatic Redial



When you receive a busy signal, your phone displays **Call Failed**.

With automatic redial, your phone automatically redials the number. When the call goes through, your phone rings or vibrates one time, displays **Redial Successful**, and then connects the call.

You must turn on automatic redial to use the feature. To turn automatic redial on or off:

Find the Feature

- > Settings
- > Initial Setup
- > Auto Redial

When automatic redial is turned off, you can manually activate the feature to redial a phone number. When you hear a busy signal and see **Call Failed**:

Press	To
 or RETRY ()	activate automatic redial

Using Caller ID

Incoming Calls



Calling line identification (caller ID) displays the phone number for incoming calls in your phone's external and internal displays.

The phone displays the caller's name when the name is stored in your phonebook, or **Incoming Call** when caller ID information is not available.

Outgoing Calls



You can show or hide your phone number as an ID for the calls that you make.

Find the Feature

- > Settings
- > In-Call Setup
- > My Caller ID

You can override the default caller ID setting when you make a call. While dialing (with digits visible in the display):

Press	To
> Hide ID/Show ID	hide or show your caller ID for the next call

Canceling an Incoming Call

While the phone is ringing or vibrating:

Press	To
IGNORE ()	cancel the incoming call



Depending on your phone settings and/or service subscription, the call may be forwarded to another number, or the caller may hear a busy signal.



Turning Off a Call Alert

You can turn off your phone's incoming call alert before answering the call.

Press	To
either volume key	turn off the alert

Calling an Emergency Number

Your service provider programs one or more emergency phone numbers, such as 911, that you can call under any circumstances, even when your phone is locked or the SIM card is not inserted.

Note: Emergency numbers vary by country. Your phone's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

Press	To
1 keypad keys	dial the emergency number
2 	call the emergency number

Dialing International Numbers

Press and hold  to insert the local international access code (+) for the country from which you are calling.

Viewing Recent Calls

Your phone keeps lists of the calls you recently received and dialed, even if the calls did not connect. The lists are sorted from newest to oldest entries. The oldest entries are deleted as new ones are added.

Shortcut: Press  to go directly to the dialed calls list from the idle display.

Find the Feature

 > More > Recent Calls

Press	To
1 	scroll to Received Calls or Dialed Calls
2 SELECT ()	select the list
3 	scroll to an entry Note: ✓ means the call connected.
4 	call the entry's number Tip: Press and hold  for 2 seconds to send the number as DTMF tones during a call.
or	
VIEW ()	view entry details
or	
	open the Last Calls Menu to perform other procedures



The **Last Calls Menu** can include the following options:

Option	Description
Store	Create a phonebook entry with the number in the No. field.
Delete	Delete the entry.
Delete All	Delete all entries in the list.
Hide ID/Show ID	Hide or show your caller ID for the next call.
Send Message	Open a new text message with the number in the To field.
Add Digits	Add digits after the number.
Attach Number	Attach a number from the phonebook or recent call lists.
Send Tones	Send the number to the network as DTMF tones. Note: This option appears only during a call.
Talk then Fax	Talk and then send a fax in the same call. See page 76.



Returning an Unanswered Call

Your phone keeps a record of your unanswered calls, and displays:

- the  (missed call) indicator

- **X Missed Calls**, where **X** is the number of missed calls

Press	To
1 VIEW (☐)	see the received calls list
2 	select a call to return
3 	make the call

Using the Notepad

Your phone stores the most recent string of digits entered on the keypad in a temporary memory location called the *notepad*. This can be a phone number that you called, or a number that you entered but did not call. To retrieve the number stored in the notepad:

Find the Feature

 > More > Recent Calls
> Notepad

Press	To
	call the number
or	
	open the Dialing Menu to attach a number or insert a special character
or	
STORE (☐)	create a phonebook entry with the number in the No. field



Attaching a Number

While dialing (with digits visible in the display):

Press	To
 > Attach Number	attach a number from the phonebook or recent call lists

Calling With Speed Dial

Each entry you store in your phonebook is assigned a unique *speed dial* number that identifies the location where the entry is stored in phone memory or on the SIM card. To speed dial a phonebook entry:

	Press	To
1	keypad keys	enter the speed dial number for the entry you want to call
2		submit the number
3		call the entry

Calling With 1-Touch Dial

To call phonebook entries 1 through 9, just press and hold the single-digit speed dial number for 1 second.

Tip: You must specify which phone number list you want to use with this feature: phone memory phonebook, or SIM card phonebook. See page 71.



Using Voicemail



Voicemail messages that you receive are stored on the network. To listen to your messages, you must call your voicemail phone number.

Note: Your service provider may include additional information about using this feature.

Listening to Voicemail Messages

Find the Feature

 > More > Messages
> VoiceMail

The phone calls your voicemail phone number. If no voicemail number is stored, your phone prompts you to store one.

Receiving a Voicemail Message

When you receive a voicemail message, your phone displays the  (voice message waiting) indicator and a **New VoiceMail** notification.

Press	To
CALL 	listen to the message

The phone calls your voicemail phone number. If no voicemail number is stored, your phone prompts you to store one.



Storing Your Voicemail Number

If necessary, use the following procedure to store your voicemail phone number on your phone. Usually, your service provider has already done this for you.

Find the Feature

 > **More** > **Messages**
 > **VoiceMail Setup**

	Press	To
1	keypad keys	enter your voicemail number
2	OK ()	store the number

Using Call Waiting



When you are on a call, an alert tone sounds to indicate that you have received a second call.

	Press	To
1		answer the new call
2	SWITCH ()	switch between calls
	or	
	LINK ()	connect the 2 calls
	or	
	 > End Call On Hold	end the call on hold



You must turn on call waiting to use the feature. To turn call waiting on or off:

Find the Feature

- ☰ > Settings
- > In-Call Setup
- > Call Waiting

Putting a Call On Hold

Press

To

HOLD (⏸) (if available) or put the call on hold
☰ > Hold

Transferring a Call



You can announce that you are transferring an active call to another party, or you can directly transfer the call.

Announce the Call Transfer

Find the Feature

- ☰ > Hold

Press	To
1 keypad keys	dial the number where you are transferring the call
2 	call the number and speak to the person who answers
3 	open the menu
4 	scroll to Transfer



Press	To
5 SELECT (⏏)	select Transfer
6 OK (⏏)	confirm the transfer.

Do Not Announce the Call Transfer

Find the Feature  > Transfer


Press	To
1 keypad keys	dial the number where you are transferring the call
2 	transfer the call



Phone Features

Main Menu

This is the standard main menu layout. **Menu organization and feature names may vary on your phone.** If you do not find a feature in the main menu, select **More** (☰) to see additional menu features. Not all features may be available for all users.



Settings Menu

Personalize

- Main Menu
- Home Keys
- Color Style
- Greeting
- Wallpaper
- Screen Saver
- Quick Dial

Call Forward

- Voice Calls
- Fax Calls
- Data Calls
- Cancel All
- Forward Status

In-Call Setup

- In-Call Timer
- Call Cost Setup
- My Caller ID
- Talk and Fax
- Answer Options
- Call Waiting

Phone Status

- My Tel. Numbers
- Credit Info/Available
- Active Line
- Battery Meter
- Other Information

Security

- Phone Lock
- Lock Application
- Fixed Dial
- Call Barring
- SIM Pin
- New Passwords

Initial Setup

- Time and Date
- 1-Touch Dial
- Auto Redial
- Backlight
- Status Light
- Zoom
- TTY Setup
- Scroll
- Animation
- Language
- Battery Save
- Contrast
- DTMF
- Master Reset
- Master Clear

Java Tools

- Java System
- Network Access
- DNS IP

Network

Car Settings Headset



Shortcuts

Change display zoom:

Press , then
press and hold 

Change ringer alert:

Open flip, press down volume key to decrease volume, then switch to vibrate alert, then silent alert. Press up volume key to reset ring alert and increase volume.

Display my phone number:

Press  

Go to dialed calls list:

Press 

Exit menu system:

Press 

Feature Quick Reference

You can do more with your phone than make and receive phone calls! For example, you can store frequently called numbers in the phonebook for easy dialing, organize your meetings and other events in the datebook, browse the Web, download applications, send messages, and more.

Use this chapter to locate features on your phone that are not described in this guide. For more detailed information, see the *More Here* guide.

Calling Features

Feature	Description
Conference Call	During a call: ☰ > Hold , dial next number, press  , press LINK () 
Call Forwarding	Set up or cancel call forwarding: ☰ > Settings > Call Forward 
Call Barring	Restrict outgoing or incoming calls: ☰ > Settings > Security > Call Barring 
TTY Calls	Set up your phone for use with an optional TTY device: ☰ > Settings > Initial Setup > TTY Setup 



Messages

Feature	Description	
Send Message	Send a text message: ☰ > More > Messages > Create Message	
Insert Pictures & Ring Tones	While composing a message: ☰ > Insert	
Receive Message	Read a new text message or MMS picture message that you have received: Press READ (☐)	
Download Pictures & Ring Tones	Highlight a picture or ring tone in a message, then: ☰ > Store	

Chat

Feature	Description	
Start Chat	Start a new chat session: ☰ > Chat ☰ > New Chat	



Feature	Description
Receive Chat Request	When you receive a chat request: Press ACCEPT (☑) or IGNORE (☒)
End Chat	During a chat session: ☰ > End Chat



Phonebook

Feature	Description
Create Entry	Create a new phonebook entry: ☰ > More > Phonebook ☰ > New > Phone Number or Email Address
Dial Number	Call a number stored in the phonebook: ☰ > More > Phonebook > <i>entry to call</i>
Voice Dial Number	Voice dial a number stored in the phonebook: Press and release the voice key, and say the entry's name (in 2 seconds)
1-Touch Dial	Set 1-touch dial to call entries stored in your phone memory phonebook or the SIM card phonebook: ☰ > Settings > Initial Setup > 1-Touch Dial



Personalizing Features

Feature	Description
Ring Alert	Change the ring alert for an event: ☰ > More > Ring Styles > Style Detail > <i>event name</i>
Ring Volume	Set ringer volume: ☰ > More > Ring Styles > Style Detail > Ring Volume
Keypad Volume	Set keypad keypress volume: ☰ > More > Ring Styles > Style Detail > Key Volume
Menu View	Display the main menu as graphic icons or as a text-based list: ☰ > Settings > Personalize > Main Menu > View
Change Soft Keys & Menu Icons	Change soft key labels and menu feature icons in the idle display: ☰ > Settings > Personalize > Home Keys
Shortcuts	Create a shortcut to a menu item: Highlight the menu item, then press and hold ☰ Select a shortcut: ☰ > Shortcuts > <i>shortcut name</i>



Menu Features

Feature	Description
Language	Set menu language:  > Settings > Initial Setup > Language
Master Reset	Reset all options <i>except</i> unlock code, security code, lifetime timer:  > Settings > Initial Setup > Master Reset
Master Clear	Reset all options <i>except</i> unlock code, security code, lifetime timer, clear all user settings and entries <i>except</i> SIM card information:  > Settings > Initial Setup > Master Clear

Dialing Features

Feature	Description
Fixed Dial	Turn fixed dialing on or off:  > Settings > Security > Fixed Dial Use the fixed dial list:  > More > Services > Fixed Dial
Service Dial	Dial service phone numbers:  > More > Services > Service Dial



Feature	Description
Quick Dial	Dial pre-programmed phone numbers:  > More > Services > Quick Dial
DTMF Tones	Activate DTMF tones:  > Settings > Initial Setup > DTMF Send DTMF tones during a call: Press number keys Send stored numbers as DTMF tones during a call: Highlight a number in the phonebook or recent call lists, then press  > Send Tones



Call Monitoring

Network connection time is the elapsed time from the moment you connect to your service provider's network to the moment you end the call by pressing . This time includes busy signals and ringing.

The amount of network connection time you track on your resettable timer may not equal the amount of time for which you are billed by your service provider. For



billing information, please contact your service provider directly.

Feature	Description	
Call Times	View call timers:  > More > Recent Calls > Call Times	
In-Call Timer	Display time or cost information during a call:  > Settings > In-Call Setup > In-Call Timer	
Call Cost	View call cost trackers:  > More > Recent Calls > Call Cost	

Hands-Free Features

Note: The use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Feature	Description	
Speaker-phone	Activate a connected external speakerphone during a call: Press SPEAKER () (if available) or  > Spkrphone On	
Auto Answer (car kit or headset)	Automatically answer calls when connected to a car kit or headset:  > Settings > Car Settings or Headset > Auto Answer	



Feature	Description	
Auto Hands-Free (car kit)	Automatically route calls to a car kit when connected: ☰ > Settings > Car Settings > Auto Handsfree	
Power-Off Delay (car kit)	Set the phone to stay on for a period of time after the ignition is switched off: ☰ > Settings > Car Settings > Power-Off Delay	
Charger Time (car kit)	Charge the phone for a period of time after the ignition is switched off: ☰ > Settings > Car Settings > Charger Time	

Data and Fax Calls

Feature	Description	
Send Data or Fax	Connect your phone to the device, then place the call through the device application	
Receive Data or Fax	Connect your phone to the device, then answer the call through the device application	
Talk Then Fax	Connect your phone to the device, enter the number, press ☰ > Dialing Menu > Talk Then Fax , then press Ⓜ to make the call	

Network Features

Feature	Description
Network Settings	View network information and adjust network settings:  > Settings > Network



Personal Organizer Features

Feature	Description
Add Datebook Event	Add an event to the datebook:  > More > Datebook > <i>day</i>  > New
View Datebook Event	View or edit event details:  > More > Datebook > <i>day</i> > <i>event name</i>
Event Reminder	View event reminder: VIEW (☐) Dismiss event reminder: EXIT (☐)
Set Alarm	Set the alarm clock (from datebook week view or day view):  > More > Datebook  > Alarm Clock
Turn Off Alarm	Turn off alarm: Press EXIT (☐) or  Set 8-minute delay: Press DELAY (☐)



Feature	Description
Calculator	Calculate numbers: ☰ > Calculator
Currency Converter	Convert currency: ☰ > Calculator ☰ > Exchange Rate Enter exchange rate, press OK (⏏), enter amount, select \$ function

Security

Feature	Description
SIM PIN	Lock or unlock the SIM card: ☰ > Settings > Security > SIM PIN Caution: If you enter an incorrect PIN code 3 times in a row, your SIM card is disabled and your phone displays SIM Blocked .
Lock Application	Lock phone applications: ☰ > Settings > Security > Lock Application



News and Entertainment

Feature	Description
Launch Micro-Browser	Start a micro-browser session:  > Web Access > Browser 
Download Picture or Ring Tone from Web Page	Download a picture, animation, or sound file from a Web page: highlight the file, press SELECT (⏏), press STORE (⏏) 
Web Sessions	Select or create a Web session:  > Web Sessions 
Download Game or Application	Download a Java game or application:  > Web Access > Browser , highlight the application, press SELECT (⏏), press DOWNLOAD (⏏) 
Launch Game or Application	Launch a Java game or application:  > Games & Apps , highlight the application, press SELECT (⏏) 
Picture Viewer	Manage pictures and animations:  > Media Center > Picture Viewer 



Feature	Description
My Tones	Compose your own ring tones, manage ring tones that you have composed or downloaded:  > Media Center > My Tones
Camera	Adjust light level and light frequency settings for the optional Motorola Original™ Digital Camera accessory:  > Picture Msgs > Settings



Specific Absorption Rate Data

The model wireless phone meets the government's requirements for exposure to radio waves.

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government and by Health Canada for Canada. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age or health.

The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC and by Health Canada is 1.6 W/kg.¹ Tests for SAR are conducted using standard operating positions accepted by the FCC and by Industry Canada with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station, the lower the power output.

Before a phone model is available for sale to the public in the U.S. and Canada, it must be tested and certified to the FCC and Industry Canada that it does not exceed the limit established by each government for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) reported to the FCC and available for review by Industry Canada. The highest SAR value for this model phone when tested for use at the ear is 0.82 W/kg, and when worn on the body, as described in this user guide, is 0.62 W/kg. (Body-worn measurements

differ among phone models, depending upon available accessories and regulatory requirements).²

While there may be differences between the SAR levels of various phones and at various positions, they all meet the governmental requirements for safe exposure.

Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications & Internet Association (CTIA) Web site:

<http://phonefacts.net>

or the Canadian Wireless Telecommunications Association (CWTA) Web site:

<http://www.cwta.ca>

1. In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.
2. The SAR information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

**The U.S. Food and Drug
Administration's Center for
Devices and Radiological Health
Consumer Update on Mobile Phones**



FDA has been receiving inquiries about the safety of mobile phones, including cellular phones and PCS phones. The following summarizes what is known—and what remains unknown—about whether these products can pose a hazard to health, and what can be done to minimize any potential risk. This information may be used to respond to questions.

Why the concern?

Mobile phones emit low levels of radio frequency energy (i.e., radio frequency radiation) in the microwave range while being used. They also emit very low levels of radio frequency energy (RF), considered non-significant, when in the stand-by mode. It is well known that high levels of RF can produce biological damage through heating effects (this is how your microwave oven is able to cook food). However, it is not known whether, to what extent, or through what mechanism, lower levels of RF might cause adverse health effects as well. Although some research has been done to address these questions, no clear picture of the biological effects of this type of radiation has emerged to date. Thus, the available science does not allow us to conclude that mobile phones are absolutely safe, or that they are unsafe. However, the available scientific evidence does not demonstrate any adverse health effects associated with the use of mobile phones.

What kinds of phones are in question?

Questions have been raised about hand-held mobile phones, the kind that have a built-in antenna that is positioned close to the user's head during normal telephone conversation. These types of mobile phones are of concern because of the short distance between the phone's antenna—

the primary source of the RF—and the person's head. The exposure to RF from mobile phones in which the antenna is located at greater distances from the user (on the outside of a car, for example) is drastically lower than that from hand-held phones, because a person's RF exposure decreases rapidly with distance from the source. The safety of so-called “cordless phones,” which have a base unit connected to the telephone wiring in a house and which operate at far lower power levels and frequencies, has not been questioned.

How much evidence is there that hand-held mobile phones might be harmful?

Briefly, there is not enough evidence to know for sure, either way; however, research efforts are on-going. The existing scientific evidence is conflicting and many of the studies that have been done to date have suffered from flaws in their research methods. Animal experiments investigating the effects of RF exposures characteristic of mobile phones have yielded conflicting results. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. In one study, mice genetically altered to be predisposed to developing one type of cancer developed more than twice as many such cancers when they were exposed to RF energy compared to controls. There is much uncertainty among scientists about whether results obtained from animal studies apply to the use of mobile phones. First, it is uncertain how to apply the results obtained in rats and mice to humans. Second, many of the studies that showed increased tumor development used animals that had already been treated with cancer-causing chemicals, and other studies exposed the animals to the RF virtually continuously—up to 22 hours per day.

For the past five years in the United States, the mobile phone industry has supported research into the safety of mobile phones. This research has resulted in two findings in particular that merit additional study:

- 1 In a hospital-based, case-control study, researchers looked for an association between mobile phone use and either glioma (a type of brain cancer) or acoustic neuroma (a benign tumor of the nerve

sheath). No statistically significant association was found between mobile phone use and acoustic neuroma. There was also no association between mobile phone use and gliomas when all types of types of gliomas were considered together. It should be noted that the average length of mobile phone exposure in this study was less than three years.

When 20 types of glioma were considered separately, however, an association was found between mobile phone use and one rare type of glioma, neuroepitheliomatous tumors. It is possible with multiple comparisons of the same sample that this association occurred by chance. Moreover, the risk did not increase with how often the mobile phone was used, or the length of the calls. In fact, the risk actually decreased with cumulative hours of mobile phone use. Most cancer causing agents increase risk with increased exposure. An ongoing study of brain cancers by the National Cancer Institute is expected to bear on the accuracy and repeatability of these results.¹

- 2 Researchers conducted a large battery of laboratory tests to assess the effects of exposure to mobile phone RF on genetic material. These included tests for several kinds of abnormalities, including mutations, chromosomal aberrations, DNA strand breaks, and structural changes in the genetic material of blood cells called lymphocytes. None of the tests showed any effect of the RF except for the micronucleus assay, which detects structural effects on the genetic material. The cells in this assay showed changes after exposure to simulated cell phone radiation, but only after 24 hours of exposure. It is possible that exposing the test cells to radiation for this long resulted in heating. Since this assay is known to be sensitive to heating, heat alone could have caused the abnormalities to occur. The data already in the literature on the response of the micronucleus assay to RF are conflicting. Thus, follow-up research is necessary.²

FDA is currently working with government, industry, and academic groups to ensure the proper follow-up to these industry-funded research findings. Collaboration with the Cellular Telecommunications Industry Association (CTIA) in particular is expected to lead to FDA providing research

recommendations and scientific oversight of new CTIA-funded research based on such recommendations.

Two other studies of interest have been reported recently in the literature:

- 1 Two groups of 18 people were exposed to simulated mobile phone signals under laboratory conditions while they performed cognitive function tests. There were no changes in the subjects' ability to recall words, numbers, or pictures, or in their spatial memory, but they were able to make choices more quickly in one visual test when they were exposed to simulated mobile phone signals. This was the only change noted among more than 20 variables compared.³
- 2 In a study of 209 brain tumor cases and 425 matched controls, there was no increased risk of brain tumors associated with mobile phone use. When tumors did exist in certain locations, however, they were more likely to be on the side of the head where the mobile phone was used.

Because this occurred in only a small number of cases, the increased likelihood was too small to be statistically significant.⁴

In summary, we do not have enough information at this point to assure the public that there are, or are not, any low incident health problems associated with use of mobile phones. FDA continues to work with all parties, including other federal agencies and industry, to assure that research is undertaken to provide the necessary answers to the outstanding questions about the safety of mobile phones.

What is known about cases of human cancer that have been reported in users of hand-held mobile phones?

Some people who have used mobile phones have been diagnosed with brain cancer. But it is important to understand that this type of cancer also occurs among people who have not used mobile phones. In fact, brain cancer occurs in the U.S. population at a rate of about 6 new cases per 100,000 people each year. At that rate, assuming 80 million users of

mobile phones (a number increasing at a rate of about 1 million per month), about 4800 cases of brain cancer would be expected each year among those 80 million people, whether or not they used their phones. Thus it is not possible to tell whether any individual's cancer arose because of the phone, or whether it would have happened anyway. A key question is whether the risk of getting a particular form of cancer is greater among people who use mobile phones than among the rest of the population. One way to answer that question is to compare the usage of mobile phones among people with brain cancer with the use of mobile phones among appropriately matched people without brain cancer. This is called a case-control study. The current case-control study of brain cancers by the National Cancer Institute, as well as the follow-up research to be sponsored by industry, will begin to generate this type of information.

What is FDA's role concerning the safety of mobile phones?

Under the law, FDA does not review the safety of radiation-emitting consumer products such as mobile phones before marketing, as it does with new drugs or medical devices. However, the agency has authority to take action if mobile phones are shown to emit radiation at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of mobile phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions at this time, FDA has urged the mobile phone industry to take a number of steps to assure public safety. The agency has recommended that the industry:

- support needed research into possible biological effects of RF of the type emitted by mobile phones
- design mobile phones in a way that minimizes any RF exposure to the user that is not necessary for device function

- cooperate in providing mobile phone users with the best possible information on what is known about possible effects of mobile phone use on human health

At the same time, FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of mobile phone safety to ensure a coordinated effort at the federal level. These agencies are:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Federal Communications Commission
- Occupational Health and Safety Administration
- National Telecommunications and Information Administration

The National Institutes of Health also participates in this group.

In the absence of conclusive information about any possible risk, what can concerned individuals do?

If there is a risk from these products—and at this point we do not know that there is—it is probably very small. But if people are concerned about avoiding even potential risks, there are simple steps they can take to do so. For example, time is a key factor in how much exposure a person receives. Those persons who spend long periods of time on their hand-held mobile phones could consider holding lengthy conversations on conventional phones and reserving the hand-held models for shorter conversations or for situations when other types of phones are not available.

People who must conduct extended conversations in their cars every day could switch to a type of mobile phone that places more distance between their bodies and the source of the RF, since the exposure level drops off dramatically with distance. For example, they could switch to:

- a mobile phone in which the antenna is located outside the vehicle

- a hand-held phone with a built-in antenna connected to a different antenna mounted on the outside of the car or built into a separate package
- a headset with a remote antenna to a mobile phone carried at the waist

Again, the scientific data do not demonstrate that mobile phones are harmful. But if people are concerned about the radio frequency energy from these products, taking the simple precautions outlined above can reduce any possible risk.

Where can I find additional information?

For additional information, see the following Web sites:

Federal Communications Commission (FCC) RF Safety Program (select “Information on Human Exposure to RF Fields from Cellular and PCS Radio Transmitters”):

<http://www.fcc.gov/oet/rfsafety>

World Health Organization (WHO) International Commission on Non-ionizing Radiation Protection (select Qs & As): <http://www.who.int/emf>

www.who.int/emf

United Kingdom, National Radiological Protection Board:

<http://www.nrpb.org.uk>

Cellular Telecommunications Industry Association (CTIA): <http://www.wow-com.com>

www.wow-com.com

U.S. Food and Drug Administration (FDA) Center for Devices and Radiological Health:

<http://www.fda.gov/cdrh/consumer/>

1. Muscat et al. Epidemiological Study of Cellular Telephone Use and Malignant Brain Tumors. In: State of the Science Symposium; 1999 June 20; Long Beach, California.
2. Tice et al. Tests of mobile phone signals for activity in genotoxicity and other laboratory assays. In: Annual Meeting of the Environmental Mutagen Society;

March 29, 1999, Washington, D.C.; and personal communication, unpublished results.

3. Preece, AW, Iwi, G, Davies-Smith, A, Wesnes, K, Butler, S, Lim, E, and Varey, A. Effect of a 915-MHz simulated mobile phone signal on cognitive function in man. *Int. J. Radiat. Biol.*, April 8, 1999.
4. Hardell, L, Nasman, A, Pahlson, A, Hallquist, A and Mild, KH. Use of cellular telephones and the risk for brain tumors: a case-control study. *Int. J. Oncol.*, 15: 113-116, 1999.

Motorola Limited Warranty for the United States and Canada

What Does this Warranty Cover?

Subject to the exclusions contained below, Motorola, Inc. warrants its telephones, pagers, messaging devices, and consumer and professional two-way radios (excluding commercial, government or industrial radios) that operate via Family Radio Service or General Mobile Radio Service, Motorola-branded or certified accessories sold for use with these Products (“Accessories”) and Motorola software contained on CD-ROMs or other tangible media and sold for use with these Products (“Software”) to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. This limited warranty is a consumer's exclusive remedy, and applies as follows to new Motorola Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:

Products and Accessories

Products Covered	Length of Coverage
Products and Accessories as defined above, unless otherwise provided for below.	One (1) year from the date of purchase by the first consumer purchaser of the product unless otherwise provided for below.
Decorative Accessories and Cases. Decorative covers, bezels, PhoneWrap™ covers and cases.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.

Products Covered	Length of Coverage
Monaural Headsets. Ear buds and boom headsets that transmit mono sound through a wired connection.	Limited lifetime warranty for the lifetime of ownership by the first consumer purchaser of the product.
Consumer and Professional Two-Way Radio Accessories.	Ninety (90) days from the date of purchase by the first consumer purchaser of the product.
Products and Accessories that are Repaired or Replaced.	The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer.

Exclusions

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

Use of Non-Motorola Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products Accessories or Software is excluded from coverage.

Software

Products Covered	Length of Coverage
Software. Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk).	Ninety (90) days from the date of purchase.

Exclusions

Software Embodied in Physical Media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

Software NOT Embodied in Physical Media. Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided “as is” and without warranty.

Who is Covered?

This warranty extends only to the first consumer purchaser, and is not transferable.

What Will Motorola Do?

Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty. We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information

USA	Phones 1-800-331-6456 Pagers 1-800-548-9954 Two-Way Radios and Messaging Devices 1-800-353-2729
Canada	All Products 1-800-461-4575
TTY	1-888-390-6456
For Accessories and Software , please call the telephone number designated above for the product with which they are used.	

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

What Other Limitations Are There?

ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF

THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted.

Product Registration

Online Product Registration:

<http://www.motorola.com/warranty>

Product registration is an important step toward enjoying your new Motorola phone. Registering helps us facilitate warranty service, and permits us to contact you should your phone require an update or other service. Registration is for U.S. residents only and is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

RF Energy Interference

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Index

A

- accessories 12, 13, 18, 69
- accessory connector port 1
- active line indicator 24, 25
- alarm clock 77
- alert
 - creating 80
 - defined 49
 - downloading 70, 79
 - setting 72
 - turning off 21, 22, 58
- animation
 - downloading 70, 79
 - inserting in message 70
 - screen saver 52
 - viewing 79
 - wallpaper 51
- answering a call 21, 50
- application, locking and
 - unlocking 78
- automatic redial 56

B

- backlight 54
- barring calls 69
- battery
 - car kit charger time 76
 - charging 16

- extending battery life 16,
41, 52, 54
- installing 14
- level indicator 16, 24, 25
- block cursor 32, 35
- browse text mode 33

C

- calculator 78
- call
 - adding digits after phone
number 60
 - alert, setting 72
 - alert, turning off 21, 22,
58
 - answer options 50
 - answering 21
 - barring 69
 - barring password,
changing 44
 - call waiting 64
 - canceling 57
 - costs 75
 - deleting 59
 - dialed calls list 59
 - dialing 21
 - emergency number 58
 - ending 21

- call (continued)
 - forwarding 69
 - hold 65
 - international access code 58
 - making 21
 - received calls list 59
 - receiving 21
 - recent calls 59
 - speakerphone 75
 - storing 59
 - talk then fax 60
 - timers 75
 - transferring 65
 - unanswered call 60
- Call Failed** message 56
- call waiting 64
- caller ID 56, 60
- calling line identification.
 - See caller ID
- camera
 - attaching 19
 - settings 80
 - taking photos 45
- car kit
 - automatic answer 75
 - automatic hands-free 76
 - charger time 76
 - power-off delay 76
- character chart 36
- chat 70

- clock
 - illustration 23
 - setting 49
- codes
 - changing 43
 - default 20, 43
 - forgetting 44
- color, setting 53
- conference call 69
- contrast, setting 53
- convertible covers 18
- cursor 32, 35
- customizing the menu 72

D

- data call
 - receive 76
 - send 76
- date, setting 49
- datebook 77
 - menu feature icon 27
- deleting a call 59
- diald calls list 59
- dialing
 - fixed numbers 73
 - quick dial numbers 74
 - service numbers 73
- dialing a number 21
- display
 - backlight 54
 - color 53
 - contrast 53

- description 23
- idle display 24
- idle display, defined 23
- language 73
- menu icons, personalizing 72
- zooming in/out 53

DTMF tones

- activating 74
- sending 59, 60, 74

E

- earpiece volume 20
- emergency number 58
- end key 1, 21, 28
- ending a call 21
- Enter Unlock Code** message 43, 44
- event alert 72
- external display 42

F

- fax call 60
 - receive 76
 - send 76
- fixed dial 73
- flashing cursor 32, 35
- flip
 - activating 22
 - external display 42
 - open to answer 50

- replacing flip cover 18
- screen saver 52
- forwarding calls 69
- 4-way navigation key 1, 26, 28

G

- games 79
- GPRS indicator 24

H

- hands-free use
 - automatic answer 75
 - automatic call routing 76
 - charger time 76
 - power-off delay 76
 - speakerphone, activating 75
- headset
 - automatic answer 75
- headset jack 1
- Hide ID** feature 60
- hold a call 65
- home keys, personalizing 72

I

- idle display 23
- idle display, defined 24
- in use indicator 24, 25
- Incoming Call** message 56

incoming call, canceling 57

indicators

active line 24, 25

battery level 16, 24, 25

GPRS 24

in use 24, 25

loud ring style 26, 50

menu 23

message waiting 24, 26

missed call 60

ring style 24, 26

roam 24, 25

signal strength 24

silent alert 26

silent ring style 26, 50

soft ring style 26, 50

text entry mode 24, 25

vibrate and ring style 26,
50

vibrate style 26, 50

voice message waiting
63

international access code
58

iTAP software 36

J

Java applications 79

joystick 1, 26, 28

K

key

end 1, 21, 28

4-way navigation 1, 26,
28

left soft key 1, 24, 28, 72

menu 1, 28, 29

power 1, 20

right soft key 1, 24, 28,
72

send 1, 21, 59

voice 1

volume control 1, 20

keypad

answering calls 50

backlight 54

volume, setting 72

L

language, setting 73

left soft key

functions 1, 24, 28

personalizing 72

lock

application 78

phone 42

SIM card 78

Low Battery message 25

M

- making a call 21
- master clear 73
- master reset 73
- menu
 - entering text 31, 33, 41
 - icons, changing in idle display 72
 - icons, converting to text 72
 - icons, described 27
 - language, setting 73
 - lists 30
 - navigating 26, 28
 - using features 30
 - view, changing 72
- menu indicator 23
- menu key 1, 28, 29
- message
 - chat 70
 - menu feature icon 27
 - picture 45, 70
 - receiving 70
 - text 70
- message waiting indicator 24, 26
- messages menu feature icon 27
- micro-browser
 - browser setup 79
 - Java applications 79

using 79

Web sessions 79

- microphone 1
- missed call indicator 60
- Missed Calls** message 61
- MMS, defined 45
- my telephone number 22, 49, 68
- my tones 80

N

- network settings 77
- notepad 61
- number
 - storing your number 49
 - viewing your number 22, 68
- numeric text mode 33

O

- 1-touch dial
 - setting preference 71
 - using 62
- optional accessory, defined 13
- optional feature, defined 13

P

passwords. *See* codes

phone

- active line indicator 25
- active line, changing 55
- alert, setting 72
- alert, turning off 21, 22, 58
- answer options 50
- clear stored information 73
- codes 43
- date, setting 49
- flip 18, 22
- keypad, answering calls 50
- language, setting 73
- locking 42
- network settings 77
- reset all options 73
- security code 43
- time, setting 49
- turning on/off 20
- unlock code 43
- unlocking 20, 42, 43, 44

phone number

- active line indicator 25
- active line, changing 55
- adding digits after 60
- attaching 2 numbers 60
- attaching two numbers 62

international access code 58

redialing 55

storing in phonebook 71

storing your number 49

viewing your number 22, 68

phonebook

attaching 2 numbers 60

attaching two numbers 62

dialing a number 71

menu feature icon 27

1-touch dial 62

speed dial number 62

storing an entry 71

voice dialing 71

photo 45

picture

downloading 70, 79

inserting in message 70

screen saver 52

viewing 79

wallpaper 51

picture message 45

PIN code

changing 44

entering 78

PIN2 code

changing 44

power key 1, 20

predictive text entry 36

Q

quick dial 74

R

received calls list 59

recent calls 59

recent calls menu feature
icon 27

redial

automatic redial 56

busy number 55

reference guide 12

right soft key

functions 1, 24, 28

personalizing 72

ring alert

setting 72

turning off 21, 22, 58

ring style

personalizing 72

setting 21, 49

ring style indicator 26

ring style indicators 24, 50

ring tone

creating 80

downloading 70, 79

inserting in message 70

ringer volume, setting 20,
72

roam indicator 24, 25

S

screen saver 47, 52

security code

changing 43

default 43

forgetting 44

send key 1, 21, 59

service dial 73

shortcuts 68, 72

Show ID feature 60

signal strength indicator 24

silent alert indicator 26

silent ring alert, setting 49

silent ring style, setting 21

SIM Blocked message 20,
78

SIM card

defined 13

installing 13

locking 78

PIN code entry 20

PIN code, changing 44

PIN2 code, changing 44

precautions 13

SIM Blocked message 20,
78

SIM PIN code

changing 44

entering 78

SIM PIN2 code

changing 44

- soft keys
 - functions 24, 28
 - illustration 1
 - labels 23
 - personalizing 72
- sound
 - downloading 70, 79
 - inserting in message 70
- speakerphone, activating 75
- speed dial
 - using 62
- standby time, increasing 41, 52, 54
- status light 1, 41
- storing a call 59
- symbol chart 40
- symbol text entry 40–41

T

- talk then fax call 60
- tap method text entry 33
- telephone number
 - storing your number 49
 - viewing your number 22, 68
- text
 - block cursor 32, 35
 - browse mode 33
 - character chart 36
 - entering 33
 - entering from keypad 41

- entry mode, changing 33
- flashing cursor 32, 35
- iTAP software predictive text entry 36
- numeric mode 33
- symbol chart 40
- symbol mode 40–41
- tap method 33
- text entry mode indicator 24, 25
- text mode, changing 33
- time, setting 49
- timers 75
- transfer a call 65
- travel charger 16
- TTY device 69

U

- unlock
 - application 78
 - phone 42
- unlock code
 - bypassing 44
 - changing 43
 - default 20, 43
 - entering 20, 42, 43
 - forgetting 44

V

- vibrate alert
 - setting 72
 - turning off 21, 22, 58

- vibrate ring alert, setting 49
- vibrate ring style, setting 21
- voice dial 71
- voice key
 - dialing a number 71
 - illustration 1
- voice message waiting
 - indicator 63
- voicemail 63
- volume
 - earpiece 20
 - keypad 72
 - ringer 20, 72
- volume keys 1, 20

W

- wallpaper 47, 51
- warranty 91
- Web pages 79
- Web sessions 79

Z

- zooming in/out 53



MOTOROLA

Wireless Phone Safety Tips

“Safety is your most important call!”

Your Motorola wireless telephone gives you the powerful ability to communicate by voice—almost anywhere, anytime, wherever wireless phone service is available and safe conditions allow. But an important responsibility accompanies the benefits of wireless phones, one that every user must uphold.

When driving a car, driving is your first responsibility. If you find it necessary to use your wireless phone while behind the wheel of a car, practice good common sense and remember the following tips:

- 1 Get to know your Motorola wireless phone and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.
- 2 When available, use a hands-free device.** If possible, add an additional layer of convenience to your wireless

phone with one of the many Motorola Original™ hands-free accessories available today.



- 3 **Position your wireless phone within easy reach.** Be able to access your wireless phone without removing your eyes from the road. If you receive an incoming call at an inconvenient time, if possible, let your voice mail answer it for you.
- 4 **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- 5 **If you receive an incoming call at an inconvenient time do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility—driving safely.
- 6 **Dial sensibly and assess the traffic; if possible, place calls when you are not moving or before pulling into traffic.** Try to plan calls when your car will be stationary. If you need to make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- 7 **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations which have the potential to divert your attention away from the road.
- 8 **Use your wireless phone to call for help.** Dial 9-1-1 or other local emergency number in the case of fire, traffic accident or medical emergencies.*



- 9 Use your wireless phone to help others in emergencies.** If you see an auto accident, crime in progress or other serious emergency where lives are in danger, call 9-1-1 or other local emergency number, as you would want others to do for you.*

- 10 Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number.*

* Wherever wireless phone service is available.

Check the laws and regulations on the use of wireless telephones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas.



For more information,
please call
1-888-901-SAFE
or visit the
CTIA Web site at
www.wow-com.comTM



motorola.com

8988485L61-0