



TIME

In TIME mode you can set time and calendar information and adjust your watch's display settings.





Time Warp



Hold for 1 second in any other mode to return to TIME.



Switch Time Zones






Chime ON/OFF



Electrolite

CHRO

In CHRONOGRAPH mode you can capture lap, split and run times. Save your times for review in DATA mode.








Start

Mark Lap/Split

Mark Lap/Split


Mark Lap/Split

Stop Run





You will have 7 seconds to read your lap or split time.

6 Reset




ALARM

In ALARM mode you can set 2 alarms within 2 time zones.
Press any button to stop alarm. Alarm will stop after 20 seconds.




DATA

In DATA mode you can review lap, split and run times.
Record your times in CHRONOGRAPH mode.



TIMER

In TIMER mode you can set a repeating timer for your workout.



Start & Stop
Countdown

