


Nokia 3155 User Guide



LEGAL INFORMATION

Copyright ©2005 Nokia. All rights reserved.

Nokia, Nokia Connecting People, Nokia 3155, Pop-Port™, and the Nokia Original Enhancements logos are trademarks or registered trademarks of Nokia Corporation. Other company and product names mentioned herein may be trademarks or trade names of their respective owners.

Copyright ©1999–2005. Tegic Communications, Inc. All rights reserved.



Includes RSA BSAFE cryptographic or security protocol software from RSA Security.



Java
POWERED

Java™ is a trademark of Sun Microsystems, Inc.

The information contained in this user guide was written for the Nokia 3155 products. Nokia operates a policy of ongoing development. Nokia reserves the right to make changes to any of the products described in this document without prior notice.

UNDER NO CIRCUMSTANCES SHALL NOKIA BE RESPONSIBLE FOR ANY LOSS OF DATA OR INCOME OR ANY SPECIAL, INCIDENTAL, AND CONSEQUENTIAL OR INDIRECT DAMAGES HOWSOEVER CAUSED. THE CONTENTS OF THIS DOCUMENT ARE PROVIDED "AS IS." EXCEPT AS REQUIRED BY APPLICABLE LAW, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY AND RELIABILITY OR CONTENTS OF THIS DOCUMENT. NOKIA RESERVES THE RIGHT TO REVISE THIS DOCUMENT OR WITHDRAW IT AT ANYTIME WITHOUT PRIOR NOTICE.

EXPORT CONTROLS This device may contain commodities, technology, or software subject to export laws and regulations from the U.S. and other countries. Diversion contrary to law is prohibited.

Issue 1

Contents

For your safety	vi	Loudspeaker.....	11
About your device	vii	Call options.....	11
Network Services.....	vii	Keypad	12
Shared memory.....	viii	Lock the keypad.....	12
		Unlock the keypad	12
Phone at a glance.....	1	Text entry.....	13
Keys and parts.....	1	Standard mode.....	13
Standby mode.....	2	Text (Abc).....	13
Quick keys.....	2	Numbers (123).....	13
Indicators and icons	2	Punctuation and	
Get the most out of this guide.....	3	special characters.....	13
Phone menus	3	Predictive text mode	13
Scroll method.....	4	Activate or deactivate	14
In-phone help.....	4	Text entry.....	14
Security feature	4	Change case and mode.....	14
Go to functions.....	5	Messages.....	15
Choose Go to functions.....	5	Text messages.....	15
Organise functions.....	5	Compose and send.....	15
Set up your phone.....	6	Read message	17
Antenna.....	6	Reply to message	17
Battery.....	6	Templates	18
Remove the back cover	7	Text message folders.....	18
Remove the battery.....	7	Distribution list.....	19
UIM card slot.....	7	Delete messages.....	19
Replace the battery	7	Change sending options.....	20
Replace the back cover	8	Change message settings	20
Charge the battery.....	8	Picture messages.....	21
Turn your phone on or off.....	9	Receive and save.....	21
Connect the headset	9	Compose and send.....	21
Make a call	9	Multimedia messages.....	22
Keypad.....	9	MMS settings.....	23
Contacts list.....	10	Voice messages.....	27
Last dialled number.....	10	Save voice mailbox number.....	27
Conference calling	10	Call and setup voice mail	27
Answer calls.....	10	Listen to voice messages	27
An incoming call	10	Automate voice mail.....	27
Adjust the earpiece volume	11	Clear voice mail icon.....	29
Answer a call with the		Web messaging.....	29
keypad locked.....	11		

Call register	30	Settings.....	46
View missed calls	30	Profiles	46
View received calls	30	Personalise a profile	46
View dialled numbers.....	31	Set a timed profile	46
View call times	31	Tone settings.....	47
Delete call registers.....	31	Themes	47
Call duration.....	31	Main display settings.....	47
Data and fax call duration	32	Wallpaper	47
Minibrowser duration	32	Screen saver.....	48
Contacts.....	34	Power saver.....	48
Add new contacts	34	Colour schemes.....	48
Save contact name and number .	34	Choose a banner	48
Save contact number only.....	34	Backlight time-out.....	48
Save an entry	34	Mini display settings.....	48
Save numbers and text items	34	Power saver.....	48
Change default number.....	35	Time and date settings.....	48
Caller groups.....	35	Clock.....	48
Set up speed dial	35	Date	48
Voice tags.....	36	Date and time auto-update.....	49
Assign a voice tag to an entry.....	36	Call settings.....	49
Dial a number	36	Anykey answer	49
Voice tags	37	Automatic redial	49
Edit contacts list entries.....	37	Speed dial	49
Delete contacts entries	38	Open fold to answer	50
Access the contacts menu.....	38	Calling card	50
Search for a name.....	38	International prefix.....	51
Configure settings.....	38	Data or fax calls.....	51
Send and receive contacts	39	Call summary.....	51
Send a business card	39	Ringing tone for no caller ID.....	51
Gallery	40	Phone settings	52
Folders.....	40	Phone language	52
Media.....	42	Memory status	52
Media player.....	42	Automatic keyguard	52
Radio.....	42	DTMF tones	52
Turn the radio on and off.....	42	Start-up tone.....	53
Voice recorder.....	43	Help text activation.....	53
Record speech or sound.....	44	Voice commands	53
Options	44	Hands-free operation	53
Media equaliser	44	Enhancement settings.....	54
Activate an equaliser set.....	44	Headset	54
		Hands-free operation	54
		Loopset	55

Charger.....	55	Measure time.....	67
Security settings.....	55	Operation note.....	68
Phone lock.....	55	Options.....	68
Allow numbers.....	56	Extras.....	69
Change lock code.....	56	Games.....	69
Call restrictions.....	57	Collection.....	69
Voice privacy.....	57	Memory.....	69
Application settings.....	58	Mobile web.....	70
Network.....	58	Mobile Internet access.....	70
Roaming options.....	58	Sign on.....	71
Mode.....	58	Navigate the mobile Internet.....	71
Network services.....	59	Phone keys.....	71
Store a feature code.....	59	Receive a call while online.....	71
Call diverting.....	59	Make an emergency call	
Restore factory settings.....	60	while online.....	71
Organiser.....	61	Clear the cache and disconnect..	72
Alarm clock.....	61	PC connectivity.....	73
Set or change alarm setting.....	61	USB data transfer.....	73
Repeat alarm.....	61	Transfer with Windows Explorer.....	73
Set the alarm tone.....	61	Nokia PC Suite.....	74
Snooze time-out.....	61	Enhancements.....	75
Alarm conditions.....	61	Battery information.....	76
Turn an alarm off.....	62	Charging and discharging.....	76
Calendar.....	62	Nokia battery authentication	
Open.....	62	guidelines.....	77
Go to a date.....	62	Care and maintenance.....	79
Note a specific date.....	62	Additional safety information.....	80
View notes (day view).....	62	Operating environment.....	80
Options while viewing		Medical devices.....	80
a list of notes.....	63	Vehicles.....	81
Send a note.....	63	Potentially explosive	
Notes.....	64	environments.....	81
To-do list.....	64	Emergency calls.....	82
Add a to-do note.....	64	Certification information (SAR).....	82
Calculator.....	65	Index.....	84
Currency converter.....	66		
Countdown timer.....	66		
Set the timer.....	66		
Change the time.....	67		
Interrupt the timer.....	67		
Stopwatch.....	67		

For your safety

Read these simple guidelines. Not following them may be dangerous or illegal. Read the complete user guide for further information.



SWITCH ON SAFELY

Do not switch the device on when wireless phone use is prohibited or when it may cause interference or danger.



ROAD SAFETY COMES FIRST

Obey all local laws. Always keep your hands free to operate the vehicle while driving. Your first consideration while driving should be road safety.



INTERFERENCE

Do not switch the device on when wireless phone use is prohibited or when it may cause interference or danger.



SWITCH OFF IN HOSPITALS

Follow any restrictions. Switch the device off near medical equipment.



SWITCH OFF IN AIRCRAFT

Follow any restrictions. Wireless devices can cause interference in aircraft.



SWITCH OFF WHEN REFUELLING

Don't use the device at a refuelling point. Don't use near fuel or chemicals.



SWITCH OFF NEAR BLASTING

Follow any restrictions. Don't use the device where blasting is in progress.



USE SENSIBLY

Use only in the normal position as explained in the product documentation. Don't touch the antenna unnecessarily.



QUALIFIED SERVICE

Only qualified personnel may install or repair this product.



ENHANCEMENTS AND BATTERIES

Use only approved enhancements and batteries. Do not connect incompatible products.



WATER-RESISTANCE

Your phone is not water-resistant. Keep it dry.



BACK-UP COPIES

Remember to make back-up copies or keep a written record of all important information.



CONNECTING TO OTHER DEVICES

When connecting to any other device, read its user guide for detailed safety instructions. Do not connect incompatible products.



EMERGENCY CALLS

Ensure the device is switched on and in service. Press the end key as many times as needed to clear the display and return to the main screen. Enter the emergency number, then press the call key. Give your location. Do not end the call until given permission to do so.

■ About your device

The wireless devices described in this guide are approved for use on the CDMA 800 and 1900 and AMPS networks. Contact your service provider for more information about networks.

When using the features in this device, obey all laws and respect privacy and the legitimate rights of others.



Warning: To use any features in this device, other than the alarm clock, the device must be switched on. Do not switch the device on when wireless phone use may cause interference or danger.

■ Network Services


To use the device you must have service from a wireless service provider or network operator. Many of the features in this device depend on features in the wireless network to function. These network services may not be available on all networks or you may have to make specific arrangements with your service provider before you can utilise them. Your service provider may need to give you additional instructions for their use and explain what charges will apply. Some networks may have limitations that affect how you can use network services. For instance, some networks may not support all language-dependent characters and services.

Your service provider may have requested that certain features be disabled or not activated in your device. If so, they will not appear on your device menu. Contact your service provider for more information.

■ Shared memory

The following device features may share memory: contacts; text messages; photos, images, and tones in gallery; calendar notes; games; and applications. Use of one or more of these features may reduce the memory available for the remaining features sharing memory. If your phone displays a message that the memory is full when you try to use a shared memory feature, delete some of the information or entries stored in the shared memory features before continuing. Some of the features, such as photos, images, and tones in gallery; text messages; and applications may have a certain amount of memory specially allotted to them in addition to the memory shared with other features.

1. Phone at a glance




- Earpiece port (1)
- Display screen (2)
- Left selection key (3)
- Call key (4)
- Keypad (5)
- Four-way scroll and selection key (6)

- Right selection key (7)
- Power key/end key (8)
- Charger port (9)
- Pop-Port™ connector (10)
- Microphone (11)

■ Keys and parts

- Loudspeaker (1)
- Voice key (2)
- Volume key (3)
- Front display (4)
- Headset jack (5)




The voice key functions as follows:

- Press once (Short press)—Answer an incoming call.
- Press and hold (Long press)—Answer or make a voice dialling.

■ Standby mode

Depending on your wireless service provider or network operator and the model number of your phone, some or all of the following selection keys may appear in standby mode.

The standby mode is home base and indicates your phone is in the idle state..



Signal strength (1)—A higher bar indicates a stronger network signal.

Menu (2)—Press the centre selection key to select this option.

Go to (3)—Press the left selection key to select this option.

Names or network operator menu (4)—Press the right selection key to select this option.

Battery level (5)—A higher bar indicates more power in the battery.

■ Quick keys



Note: Depending on your wireless service provider or network operator or network operator and the model number of your phone, some or all of the following Quick keys may appear in standby mode.

In standby mode, the four-way scroll key instantly takes you to frequently accessed menus:

Scroll up key—Go to the contacts list.

Scroll right key—View the calendar.

Scroll down key—Go to the contacts list.

Scroll left key—Quickly create a text message.

Centre selection key—Go to the main menu or a selected submenu.

■ Indicators and icons

Depending on your wireless service provider or network operator and the model number of your phone, some or all of the following indicators and icons may appear in standby mode.

You have new text or picture messages. See "[Text messages](#)," p. 15.

You have new voice messages. See "[Voice messages](#)," p. 27.

Your phone keypad is locked. See "[Keyguard](#)," p. 12.

Your phone is set to the silent profile. See "[Profiles](#)," p. 46.

The alarm clock is set to on. See "[Alarm clock](#)," p. 61.

The countdown timer is running.

The stopwatch timer is running in the background.

Integrated hands-free is active. See "[Loudspeaker](#)," p. 11.

The timed profile is selected. See "[Profiles](#)," p. 46.

  or  An enhancement is connected to the phone. See "Enhancement settings," p. 54.

 Voice privacy encryption is active (or is not active) in the network.

 You are in a digital network. See "Network Services," p. vii.

 You are in an analogue network. See "Network Services," p. vii.

 You are in a 1XRTT network. See "Network Services," p. vii.

 You are roaming outside your home network. See "Roaming options," p. 58.

■ Get the most out of this guide

The following sections illustrate the various components of your phone. Familiarise yourself with these sections to help you understand the instructions that follow.

This guide uses certain terms for the steps you need to perform.

- Press means to press and release a key quickly (short press). For example, press 7 means press the key on the keypad labeled with the number 7 and the letters pqrs.
- Press and hold means to press and hold a key for 2–3 seconds; then release the key (long press).

- Use selection keys to select a menu option. To select an option, press the selection key below the menu item on the phone screen.
- Use scroll keys to move up, down, left, or right in the menus.
- Call and end keys: Press the call key to place a call or to answer an incoming call. Press the end key to end a call or return to the idle state (standby mode).

■ Phone menus

Phone features are grouped according to function and are accessed through the main menus. Each main menu contains submenus and lists from which you can select or view items and personalise your phone features. To access these menus and submenus, use the scroll method or a shortcut.

You can change your menu view from list to grid. Select *Menu > Options > Main menu view > List or Grid*.



Note: Some features may not be available, depending on your network. For more information, contact your wireless service provider or network operator.

Scroll method

You can use the four-way scroll key to scroll up, down, left, and right through the options.



1. In standby mode, select *Menu*, and scroll through the main menus using the scroll key.

As you scroll through the menus, the menu number appears in the upper right corner of the display. Below the battery level indicator is a scroll bar with a tab that moves up or down on the right side of the display screen as you scroll through the menus, providing a visual representation of your current position in the menu structure.

2. When you arrive at a menu, press the centre selection key to select submenus.
 - Select *Back* (the right selection key) to return to the previous menu.
 - Press the end key to return to standby mode from any menu or submenu.

In-phone help

Many features have brief descriptions (help text) you can view on the display. To view these descriptions, you must first activate help text as follows.

In standby mode, select *Menu* > *Settings* > *Phone* > *Help text activation* > *On* or *Off*.

Scroll to a feature and wait about 14 seconds. Scroll down to view all of the description, or select *Back* to exit.

■ Security feature

The security feature protects your device from unauthorised outgoing calls or access to the stored information with the lock and security codes. The lock code and security code are both preset to 12345. By default, the security feature uses the lock code (defaulted to the last four digits of your phone number) instead of the security code to protect your phone.

You need to enter the lock code to access the following *Security* option:

1. In standby mode, select *Menu* > *Settings* > *Security*.
2. Enter the lock code, and select *OK*. See "Security settings," p. 55.

Your device, by default, requires you to enter the lock code to restore factory settings:

1. In standby mode, select *Menu > Settings > Restore factory sett..*
2. Enter the security code, and select *OK*. See "Change lock code," p. 56.



Note: Depending on your wireless service provider or network operator, your device may sometimes ask you for the security code (defaulted to 12345) instead of the lock code.

■ Go to functions

The *Go to* menu enables you to change the function of the left selection key on your phone. With this function, you can quickly access your most frequently used functions from the *Go to* menu in standby mode.

Choose Go to functions

1. In standby mode, select *Go to > Options > Select options.*
2. Scroll up or down to highlight the desired function.
3. Select *Mark* to add a function or *Unmark* to remove a function.
4. Select *Done* when you have added all desired functions.
5. Select *Yes* to save the changes.
6. In standby mode, select *Go to* to display a list of the functions you selected in step 2.


Organise functions

1. In standby mode, select *Go to > Options > Organise.*
2. Scroll up or down to highlight the function you want to rearrange, and select *Move > Move up, Move down, Move to top, or Move to bottom.*
3. Select *Done > Yes* to save the changes.

2. Set up your phone

■ Antenna

Your device has two antennas—the fixed antenna is active unless the extendable antenna is fully extended.



Note: Do not touch the antenna unnecessarily with the device switched on. Contact with the antenna affects call quality and may cause the device to operate at a higher power level than otherwise needed. Not touching the antenna area during a phone call optimises the antenna performance and battery life.



Your device has a fixed and extendable antenna located towards the top of the phone with the fold closed. Hold the phone with the antenna area pointed up and over your shoulder.




■ Battery




Note: Always switch off the power, and disconnect the charger and any other device before removing the cover. Always store and use the device with the cover attached.

Remove the back cover



1. With the back of the phone facing you, push down on the back cover.
2. Slide the back cover toward the bottom of the phone and remove.

Remove the battery




After you have removed the back cover, insert your finger into the finger grip, and lift the battery from its compartment.



Note: Always switch off the device, and disconnect the charger before removing the battery.

UIM card slot



Your phone has a UIM (CDMA SIM) card slot built into the mechanics. However, the UIM is not functional in this phone model. Avoid placing anything into the UIM card slot.


Replace the battery

1. Insert the battery, gold-coloured contact end first, into the battery slot.



2. Push down on the other end of the battery to snap the battery into place.

Replace the back cover




1. Set the back cover on the phone with the cover tabs aligned with the slots in the phone.
2. Slide the back cover toward the top of the phone until the back cover is securely in place.

Charge the battery



Note: Check the model number of any charger before use with this device. This device is intended for use when supplied with power from the AC-3 or AC-4 charger.


1. Plug the charger transformer into a standard AC outlet.
2. Insert the charger output plug into



the round jack at the bottom end of the phone.

After a few seconds, the battery indicator in the display starts to scroll from bottom to top. If the battery is completely discharged, it may take a few minutes before the charging indicator appears on the display or before any calls can be made.

You can also use the CA-44 charger adapter to connect the phone with Nokia chargers having a larger barrel size, including ACP-7, ACP-8, ACP-9, ACP-12, AC-1 (retractable charger), and LCH-12 (mobile charger).



1. Plug the charger transformer into a standard AC outlet.
2. Insert the charger output plug into the CA-44 adapter jack.
3. Insert the CA-44 plug into the jack on the bottom of the phone.



Warning: Use only batteries, chargers, and enhancements approved by Nokia for use with this particular model. The use of any other types may invalidate any approval or warranty, and may be dangerous.

■ Turn your phone on or off

1. To turn your phone on or off, press and hold the end key on the keypad for at least 4 seconds.
2. Enter the lock code, if necessary, and select **OK**. See "Change lock code," p. 56.




Warning: Do not switch the phone on when wireless phone use is prohibited or when it may cause interference or danger.

■ Connect the headset

A compatible headset, such as HS-5, may be purchased with your phone or separately as an enhancement. See "Enhancement settings," p. 54.

1. Plug the headset connector into the Pop-Port connector at the bottom end of your phone.  appears in standby mode.
2. Position the headset on your ear.



With the headset connected, you can make, answer, and end calls as usual.

- Use the keypad to enter numbers.
- Press the call key to place a call. See "Phone at a glance," p. 1.
- Press the end key to end a call.



You can also plug a compatible headset, such as the HS-9 Universal Headset, into the 2.5-mm headset jack on the right side of your phone to allow hands-free operation. See "Enhancement settings," p. 54.

■ Make a call



Note: Before making or receiving a call, fully extend the whip antenna.

Keypad

1. Enter the phone number and press the call key. (To delete a character to the left of the cursor, select **Clear**.)
2. Press the end key to end the call, or select **End call** to cancel the call attempt.

Contacts list

1. In standby mode, scroll down to display your contacts list and highlight your desired entry.
2. Select *Details* to highlight your desired number, and then select *Call*.

Last dialled number

1. In standby mode, press the call key to display the last 30 numbers dialled.
2. Scroll to the number (or name) you want to redial, and press the call key.

Conference calling

Conference calling is a network dependant service that allows you to take part in a conference call with two other participants.



Note: Conference calling is a network dependant service.

1. Make a call to the first participant.
2. With the first participant on the line, select *Options* > *New call*.
3. Enter the phone number of the second participant, or select *Search* to retrieve a number from the contacts list. Select *Call*. The first participant is put on hold.
4. When the second participant picks up, press the call key to connect the calls.

5. To end the conference call, select *Options* > *End all calls*, or press the end key.

Answer calls

An incoming call

1. With the fold open, press the call key, or select *Answer* to answer the call.
2. Press the end key to reject the call. Select *Silence* to mute the ringing tone, then *Dismiss*, or do nothing. The call is eventually diverted to voicemail.

With your phone set to silent in the profiles menu, select *Dismiss* to divert the call to voicemail.

3. With the fold closed, press the volume key to mute the ringing tone.

A short press of the voice key answers an incoming call with the loudspeaker.

By default, your phone answers an incoming call when you open the fold. You can change the setting to not answer the call when the fold opens.

In standby mode, select *Menu* > *Settings* > *Call* > *Answer when fold is opened* > *On* or *Off*.

Adjust the earpiece volume

Whether in or out of a call, you can scroll the volume key located on the left side of your device up or down to adjust the volume of the earpiece. When you adjust the volume, a bar chart indicates the volume level.

Answer a call with the keypad locked

To answer a call with the keypad locked, press the call key with the fold open. To answer a call with the fold closed and the keypad locked, press and hold the voice key to answer with the loudspeaker. During the call, all features function as normal. When you end or reject the call, the keypad automatically relocks. See "Keyguard," p. 12.

When the keypad lock is on, calls still may be possible to the official emergency number programmed into your device. Enter the emergency number, and press the call key.

Loudspeaker



Warning: Do not hold the device near your ear when the loudspeaker is in use, because the volume may be extremely loud.

You can use your phone as a loudspeaker during a call.

- To activate the loudspeaker while in a call with the fold open, select *Loudsp.*
- To activate the loudspeaker when answering a call with the fold closed, press the voice key.
- To deactivate the loudspeaker during a call, with the fold open, select *Normal*.

The loudspeaker is deactivated automatically when a call (or a call attempt) ends or when certain enhancements are connected.

Call options

Many of the options you can use during a call are network services. Check with your wireless service provider or network operator for more information.

1. Select *Options* during a call to display the following options:
 - Loudspeaker* or *Handset*—Activate or deactivate the loudspeaker while in a call.
 - New call*—Initiate a conference call. See "Conference calling," p. 10.

Save—Save a number while in a call to your contacts list. You can also save a number directly from the standby screen.

Add to contact—Add a phone number to an existing contact in your contacts list while in a call. This option is available only when entering numbers during a call.

End all calls—Disconnect from all active calls.

Send DTMF—Enter the numbers, and select **DTMF** to send the numbers as tones.

Contacts—View the contacts menu.

Menu—View the phone menu.

2. Scroll to and select an option to activate the option or enter its submenu.

■ Keyguard

With keyguard, you can lock the keypad to prevent keys from being pressed accidentally. The locked keypad unlocks when you receive a call. After the call, the lock automatically reactivates.

With the keyguard on, calls still may be possible to the official emergency number programmed into your phone. Enter the emergency number, and press the call key.

Lock the keypad

Select **Menu** with the centre selection key; then press * within 2 seconds.

Unlock the keypad

Select **Unlock** with the centre selection key; then press * within 2 seconds.

3. Text entry

You can use two methods for entering text and numbers: standard mode and predictive text mode.

Select *Clear* to backspace the cursor and delete a character. Select and hold *Clear* to backspace continuously and delete characters.

■ Standard mode

Standard mode is the only way to enter text into the contacts list and to rename caller groups.

Text (Abc)

- Press a key once to insert the first letter on the key, twice for the second letter, etc. If you pause briefly, the last letter in the display is accepted and your device awaits the next entry.
- Press 0 to enter a space, thereby accepting a completed word.
- Press 1 to insert a period into your message.
- Press * to display a complete list of special characters.
- Press and hold # to bring up the *Editor settings* (*Number mode*, *Dictionary on* or *Dictionary off*, *Writing language*).

Numbers (123)

To switch to 123 mode from Abc mode, press and hold # at any message entry screen to bring up the *Editor settings* menu list of *Number mode*, *Dictionary on* or *Dictionary off*, and *Writing language*. Select *Number mode*, and the device returns to the message entry screen and switches the Abc icon in the upper left corner of the display to the 123 icon (or back).

Punctuation and special characters

While at any text entry screen, press * to display special characters (press and hold * if predictive text is on). Press * again to cycle through all available characters. Scroll to navigate through the list of special characters. With a character highlighted, select *Use* to insert the character into your message.

■ Predictive text mode

Much faster than the standard mode method, predictive text input enables you to write messages quickly using your keypad and the built-in dictionary. In predictive text mode, your phone predicts the words as you enter them.


Activate or deactivate

- At any text entry screen, select *Options* > *Dictionary on* to activate or *Dictionary off* to deactivate.

Text entry

The following illustration shows your text entry of the word Nokia in predictive text mode. With the English dictionary selected, press each of the following number keys once, and the screen will display Nokia by predicting the appropriate letter to use based on your keypad entry:

Enter:



- Press 0 to enter a space, and begin writing the next word.
- If a displayed word is not correct, press * to see other matches. To return to the previous word in the list of matches, select *Prev*.
- If ? appears after a word, select *Spell* to add the word to the dictionary.
- Press 1 to insert a period into your message.
- Press and hold * to display special characters. Press * again to cycle through all available characters.

Change case and mode

Press # to switch between uppercase, lowercase, and sentence case text. As you press #, the following icons (not the descriptions) appear in the upper left of the display screen.:

Uppercase text: standard mode is on.

Lowercase text: standard mode is on.

Sentence case text: standard mode is on. This option is available only at the beginning of a sentence.




Note: You can press # within 2 seconds to switch between standard mode and predictive text mode.

Uppercase text: predictive text is on.

Lowercase text: predictive text is on.

Sentence case text: predictive text is on. This option is available only at the beginning of a sentence.

4. Messages



You can send and receive messages to compatible phones. You can also send and receive picture, multimedia, and e-mail messages if supported by your service provider. Also, you can make distribution lists that contain phone numbers and names from your contacts list. See "Text entry," p. 13.

When composing text, picture, or multimedia messages, check the number of characters allowed in the top right corner of the message. Using Unicode characters takes up more space. With Unicode characters in your message, the indicator may not show the message length correctly. Before sending the message, the phone tells you if the message exceeds the maximum length allowed for one message.



Important: Exercise caution opening messages. Messages may contain malicious software or otherwise be harmful to your device or PC.



Note: When you send a message, your device may display *Message sent*, indicating your device has sent the message to the message centre number programmed into your device. This is not an indication that the message has been received at the intended destination. For more details about messaging services, check with your service provider.

■ Text messages

Compose and send

1. In standby mode, select *Menu* > *Messages* > *Text messages* > *Create message*.

To go quickly to *Create message*, scroll left in standby mode.

2. Compose and send a message using the keypad.

Depending on the messaging service enabled, some or all of the following options are available while composing your message:

Preview—Preview the message when sending a picture message (only available with a picture inserted).

Sending options—*Mark* or *Unmark* the sending options of a single message as *Urgent*, *Delivery reports*, *Callback no.*, or *Signature* (not available with a picture inserted). See "Change sending options," p. 20.

Clear text—Erase all the text from the message editor.

Insert picture—Insert a picture from a templates folder into your message.

Change picture—Change the picture in a picture message (only available with a picture inserted).

Delete picture—Delete the picture in a picture message (only available with a picture inserted).

Insert contact—Insert a name from your contacts list into your message.

Insert number—Insert a phone number or find a phone number in the contacts list.

Save—Select *Drafts* to save the message in the drafts folder; select *Templates* to save the message as one of your predefined templates in the templates folder.

Exit editor—Exits the message editor.

Use template—Insert a predefined template into your message.

Insert smiley—Insert a smiley into your message.

Insert word or *Edit word*—Enter or edit the text of a new word that might not appear in the predictive text dictionary (only available with predictive text on).

Insert symbol—Insert a special character into your message (only available with predictive text on).

Dictionary on or *Dictionary off*—Turn the predictive text on or off.

Matches—View matches in the dictionary for the word you want to use (only available with predictive text on and when the same set of key strokes can produce multiple words).

3. To send the message, select *Send to* > *Send to number*, *Send to many*, or *Send to distrib. list* (if a distribution list has been created). Enter the recipient's phone number or e-mail address; or select *Search* to retrieve a number or e-mail address from your contacts list, and select *OK*.

Read message

When you receive a message, a notification message and  are displayed.

1. Select *Show* to read the message or *Exit* to dismiss the notification and read the message later from your inbox. See "View saved messages," p. 18.
2. Scroll up or down to view the whole message, if necessary.

Options

When reading a text message, select *Options* to access some or all of the following options:

Delete—Discard the message.

Use detail—Access the following three options:

- *Number*—Uses or saves the number. Select *Options > Add to contact, Send message, or Call*.
- *E-mail address*—Lists the e-mail addresses included in the message (available only if the message contains an e-mail address). Select *Save* to save the email address as a new phone book entry or *Options > Add to contact or Send message*.
- *Web address*—Displays if a URL is included in the message.

Move—Save the message to *Templates, Archive*, or a folder you have created.

Forward—Divert the message to another phone number or e-mail address.

Lock or *Unlock*—Lock or unlock the message.

Save picture—Save the picture to your *Templates* folder for later use. You can enter a title for the picture, and select *OK*.

Rename—Edit the title of the message.

Reply to message

1. In standby mode, select *Menu > Messages > Text messages > Inbox* and your desired message, or when you receive a message, select *Show*.
2. Select *Reply > Empty screen, Original text, Template*, or one of the predefined answers; then compose your reply using the keypad.
3. After creating the reply, select *Send*. The sender's phone number or e-mail is used as the default.

Templates

Templates are short, prewritten messages you can recall and insert into new text messages when you are short on time.

1. In standby mode, select *Menu > Messages > Text messages > Create message > Options > Use template.*
2. Select your desired template.
3. Select *Send to > Send to number, Send to many, or Send to distrib. list* (with a distribution list created).
4. Enter the recipient's phone number select *Search* to retrieve a number or e-mail address from your contacts list; and select *Send.*

A distribution list only contains phone numbers of recipients and is selected from a list of predefined groups you create.

Text message folders

Save messages

You can save drafts of messages or received messages to an existing folder or to a folder that you have created.

1. Open the received message or create a new message, and select *Options.*
2. To save a received message, select *Move > Archive, Templates,* or a folder you have created.

3. To save the draft of a message you have created, select *Save > Drafts* or *Templates.*

View saved messages

1. In standby mode, select *Menu > Messages > Text messages.*
2. Select the folder containing the message you want to view:
 - Inbox*—Automatically stores any incoming messages.
 - Outbox*—Stores messages that have not been sent
 - Sent items*—Stores messages that have been sent.
 - Drafts*—Stores messages created as drafts.
 - Archive*—Stores messages that you choose to archive, including unread ones.
 - Templates*—Stores pictures and prewritten templates. Preloaded templates can be edited and personalised.
 - My folders*—Allows you to organise your messages by creating custom folders and saving some of your messages here. Select *Options > Add folder, Rename folder, or Delete folder* to add a custom folder or rename or delete a folder you have created.

You can only delete folders created in my folders; the inbox, sent items, archive, and templates folders are protected. When deleting a folder, you are also deleting all messages in the folder.

Distribution lists—Stores created distribution lists.

3. When the folder opens, select the message you want to view.

Distribution list

The distribution list enables you to send messages to a group of contacts. In standby mode, select *Menu > Messages > Text messages > Distribution lists*.

To create a distribution list, select *New list* with no list created or *Options > Create new list* to create additional lists. To populate your list, select *Add new* and a contact from your contacts list.

To use, rename, or modify a distribution list, highlight the distribution list; and select *Options > Send message, Rename list, Clear list, or Delete list*.

Delete messages

If your message memory is full and you have more messages waiting at the network, *No space for new text messages* appears in standby mode. You can do the following:

- Read some of the unread messages, and delete them individually.
- Delete messages from some of your folders.

Delete a single message

1. In standby mode, select *Menu > Messages > Text messages*.
2. Select the folder containing the message you want to delete.
3. Highlight the message you want to delete.
4. Select *Options > Delete*.
5. Select *Yes* to delete the message or *No* to exit.

Delete all messages inder

1. In standby mode, select *Menu > Messages > Text messages > Delete messages*.
2. Select the messages you want to delete:
 - All*—Deletes all messages in all of the folders.
 - All read*—Deletes any messages that have been read in all of the folders.

All unread—Deletes any messages that have not been read in all of the folders.

3. Select and *Mark* the folders that have messages you want to delete:

Inbox—Deletes all messages from the inbox folder.

Sent items—Deletes all messages from the Sent items folder.

Outbox—Deletes all messages from the outbox folder.

Drafts—Deletes all messages from the drafts folder.

Archive—Deletes all messages from the archive folder.

User defined folders—Deletes all messages from the user defined folder.

4. Select *Done* > *Yes* to empty the marked folder.

Change sending options

To change sending options for all future text messages, in standby mode, select *Menu* > *Messages* > *Text messages* > *Message settings* > *Sending options* and the setting you want to change:

Priority—Set the priority of the note as *Normal* or *Urgent*.

Delivery reports—Send a note to yourself confirming delivery of the message. Select *On* or *Off*.

Send callback number—Send a callback number to the recipient. Select *Off* or enter your desired phone number to send to the recipient as a callback number, and select *OK*.

Signature—Select *On* to create a signature to send with text messages or *Off* to turn this feature off.

To change sending options for one message, in standby mode, select *Menu* > *Messages* > *Text messages* > *Create message* > *Options* > *Sending options*, and *Mark* or *Unmark* the setting you want to change:

Urgent—Set the priority of the note as urgent.

Delivery reports—Send a note to yourself confirming delivery of the message.

Send callback number—Enter your desired phone number to send to the recipient as a callback number, and select *OK*.

Signature—Create a signature to send with text messages.

Change message settings

In standby mode, select *Menu* > *Messages* > *Text messages* > *Message settings* > *Other settings* and the setting you want to change:

Message font size—Select *Small font* or *Large font*.

Message overwriting—Select *Sent items only*, *Inbox only*, *S. items & Inbox*, or *Off*.



Note: When the message memory is full, your phone cannot send or receive any new messages. To free up the memory, you can select *Message overwriting* to make your phone automatically replace old messages in the inbox and outbox folders when new ones arrive.

Save sent messages—Select *Always save*, *Always prompt*, or *Off*.

Queue msgs. when digital unavailable—Select *On*, *On prompt*, or *Off*. Messages are stored in the outbox until they can be sent with digital service.

■ Picture messages

Your phone comes with five preloaded pictures. If necessary, you can overwrite any of the preloaded pictures. You can send a text message with pictures attached to compatible phones. However, pictures take up more space than text.

To select your desired picture in the templates folder, in standby mode, select *Menu > Messages > Text messages > Templates*.

You cannot send a picture message using e-mail.

Receive and save



Note: Only compatible devices that offer picture message features can receive and display picture messages.

When you have unopened picture messages in your inbox,  appears.

Select *Show* to view the picture message or *Exit* to view the picture message in your inbox later. If you have more than one picture message, scroll to and select the message you want to view. Scroll to view the whole picture if necessary.

To save a received picture in your templates folder, select *Options > Save picture*. Enter a title, and select *OK*. If your templates folder is full of pictures, scroll to and select a picture you want to replace.

Compose and send

When you insert a standard picture into a message, the number of characters you can add changes as shown in the upper right corner of the display screen.

1. In standby mode, select *Menu > Messages > Text messages > Create message*.
2. Write the message, and select *Options > Insert picture*.
3. Scroll to a picture, and select *Use* or *View > Insert*.

To replace with another picture, select *Options > Change picture*,

scroll to another picture, and select *Use* or *View* > *Insert*.

4. Select *Send to* > *Send to number*, *Send to many*, or *Send to distrib. list* if distribution list exists.
5. Enter the phone number of the recipient, or select *Search* to retrieve a number from contacts list.

To view, change, or delete the picture, select *Options* > *Preview*, *Change picture*, or *Delete picture*.

■ Multimedia messages

A multimedia message (MMS) can contain text, sound, a picture, and a video clip. Your device supports multimedia messages up to 300 KB. With the maximum size exceeded, the device may not be able to receive the message. Depending on your network, you may receive a message that includes an Internet address where you can go to view the multimedia message. Pictures are scaled to fit the display area of the device. Your device has a multimedia message viewer for playing messages and a multimedia folder for storing saved messages. When you save the multimedia message, you can use the image as a screen saver or the sound as a ringing tone unless protected by copyright. The appearance of a multimedia message may vary depending on the receiving device.



Important: Exercise caution when opening messages. Messages may contain viruses or otherwise be harmful to your device or PC.

Copyright protections may prevent some images, ringing tones, and other content from being copied, modified, transferred, or diverted. This function is only available if supported by your service provider or network operator. For availability and a subscription to the multimedia messaging service, contact your service provider or network operator.



Note: Only devices that offer compatible multimedia message features can receive and display multimedia messages. Multimedia message objects may contain viruses or otherwise be harmful to your device or PC. Do not open any attachment if unsure of the trustworthiness of the sender.

Multimedia messaging supports the following formats:

- Picture: JPEG, GIF, animated GIF, WBMP, BMP, and PNG
- Sound: SP-MIDI, AAC, AMR audio, QCELP, and monophonic ringing tones
- Video: clips in H.263 format with SubQCIF image size and AMR audio

If a received message contains unsupported elements, these elements

may be replaced with *Object format not supported*.

You can receive MMS notifications at anytime; whether you can retrieve MMS depends, as shown in the following:

- While in a call or an active browsing session, you cannot retrieve multimedia messages.
- While in a standalone application such as a game or calendar instead of a browser or voice call, you can retrieve multimedia messages.

MMS settings

Before you can use the multimedia message feature, you must specify whether you want to receive message at all times or only if you are in your wireless service provider or network operator's home system. This is a network service. Check with your service provider for more information.

The default setting of the multimedia message service is on. The appearance of a multimedia message may vary depending on the receiving device.

Allow or block multimedia reception

You can choose to receive all messages, block all messages, or receive messages only when you are in the wireless service provider or network operator's home network.

In standby mode, select *Menu > Messages > Multimedia messages > Message settings > Allow multimedia reception* and one of the following:

Yes—Allow all incoming messages.

In home network—Allow incoming messages only if you are in the wireless service provider or network operator's home system. This is a network service. Check with your service provider for more information.

No—Block all incoming messages.

Retrieve or reject multimedia messages

This setting is unavailable with multimedia reception blocked.

In standby mode, select *Menu > Messages > Multimedia messages > Message settings > Incoming multimedia messages* and one of the following options:

Retrieve—Automatically retrieve all messages to your inbox.

Retrieve manually—Enable choosing from a notification whether to retrieve a message waiting on the network.

Reject—Reject incoming multimedia messages.

When you receive messages, *Multimedia message received* appears.

Allow or block advertisements

This setting is unavailable with multimedia reception blocked.

In standby mode, select *Menu > Messages > Multimedia messages > Message settings > Allow adverts > Yes* or *No*.

Other MMS settings

Other multimedia settings include saving your messages to *Sent items*.

In standby mode, select *Menu > Messages > Multimedia messages > Message settings* and one of the following:

Save sent messages—Select *Yes* to save sent multimedia messages to the *Sent items* folder or *No* to discard.

Delivery reports—Select *Yes* to be informed if the message was delivered or *No* to not be informed.

Scale image down—Select *Yes* or *No* to define whether to scale image down.

Default slide timing—Set the default time in mm:ss format for each slide in an MMS to remain on the screen.

MMS folders

To use and arrange messages, select *Messages > Multimedia messages* and one of the following:

Inbox—Contains received multimedia messages.

Outbox—Contains multimedia messages which you have sent and are

still waiting to be transmitted, or failed to be sent out.

Sent items—Contains sent multimedia messages.

Saved items—Contains saved multimedia messages that you can send later.

Delete messages—Deletes messages in the *Inbox*, *Outbox*, *Sent items*, or *Saved items* folder.

Write and send multimedia messages

1. In standby mode, select *Menu > Messages > Multimedia messages > Create message*.

2. Enter your message text, and select *Options > Insert > Image, Sound clip, New sound clip, Video clip, Slide, Business card, or Calendar note*. The list of available folders in the *Gallery* is displayed.

Selecting *Business card* displays your contact lists; selecting *Calendar note* shows the calendar.

3. Open the desired folder; scroll to the image, sound clip, or video clip; and select *Options > Insert*.

The indicator in the message header shows the available memory size left for the message.

Copyright protections may prevent some images, ringing tones, and other content from being copied, modified, transferred, or diverted.

4. To add a new page or slide to the message, select *Options > Insert > Slide*. This applies only if there is no video clip in the message
 Each slide can contain text, one image, and one sound clip. If the message contains several slides, to open the desired slide, select *Previous slide, Next slide, or Slide list*.
 You can also add business cards and calendar notes.
 5. To set the time interval between the slides, select *Options > Slide timing*. Enter the time interval in mm:ss format, and select *OK*.
 6. To move the text to the top or bottom of the message, select *Options > Place text first or Place text last* (default).
 7. To insert a name from contacts, select *Options > More options > Insert contact* and the desired name.
 8. To insert a number, select *Options > More options > Insert number*.
 9. Enter the number or search for it in contacts, and select *OK*.
 10. To insert a business card, select *Options > Insert > Business card*.
 11. To insert a calendar note, select *Options > Insert > Calendar note*.
 12. To delete an image, slide, video clip, or sound clip from the message, select *Options > Delete > Image, Sound clip, Video clip, or Slide*.
 13. To add a subject to the message, select *Options > More options > Edit subject*, enter a subject, and select *OK*.
 14. To view the message or slide presentation before sending it, select *Options > Preview*.
 15. To save the message to *Saved items*, select *Options > Save*.
 16. To send the message, select *Send to > Phone number, E-mail address, or Many*.
 17. Enter the recipient's number or e-mail address, or search for it in contacts, and select *OK*. The message is moved to the outbox folder to be sent.
- It takes more time to send a multimedia message than a text message. While sending the multimedia message, your device displays the animated indicator  , and you can use other functions on the device. If there is an interruption while sending the message, the device automatically tries to resend it a few times. If this fails, the message remains in the outbox folder, and you can try to manually resend it later. Check your outbox folder for unsent messages.



Note: When sending messages, your device may display *Multimedia message sent*, indicating that the message has been sent to the message centre number programmed into your device. This is not an indication that the message has been received at the intended destination. For more details about messaging services, check with your network operator.

Sent messages are saved in the sent items folder if you set *Save sent messages* to *Yes*. See "Other MMS settings," p. 24. This is not an indication that the message has been received at the intended destination.

Read multimedia messages

When a multimedia message is being received,  appears animated in the display along with the percentage display indicating the receiving progress. With the message fully downloaded,  appears, and the number of messages received also shows in the display (with the light indicator blinking near the bottom of your antenna).

- To view the message immediately, select *Show*.
- To view a saved message, select *Menu > Messages > Multimedia messages > Saved items*, and scroll to view the message.

While viewing the message, select *Play* to view the entire MMS or *Options* and one of the following:

View text—View only the text included in the message.

Open image, Open sound clip, or Open video clip—View or listen to the corresponding file.

Delete message—Delete the message you are viewing.

Forward to no., Forward to e-mail, or Forward to many—Divert the message to a phone number, to an e-mail address, or to multiple recipients.

Message details—View the sender's name and phone number, the message centre used, reception date and time, and message size and type.

Save image, Save sound clip, or Save video clip—Save the file to the *Gallery*. You must open images, sound clips, and video clips before you can save them.

If  blinks and *Multimedia memory full. view waiting msg.* appears, memory for multimedia messages is full. To view the waiting message, select *Show*. Before you can save the message, delete some of your old messages. See "Delete messages," p. 19.

Reply to multimedia message

Select *Reply* or *Reply to all* to enter a reply and send it to the original sender and any other message recipients.

Voice messages

If you subscribe to voice mail, your wireless service provider or network operator will furnish you with a voice mailbox number. You need to save this number to your device to use voice mail. When you receive a voice message, your device beeps, displays a message, or both. If you receive more than one voice message, your device shows the number of voice messages received.

Save voice mailbox number

Your wireless service provider or network operator may have already saved your voice mailbox number to your device. Select *OK* to leave the number unchanged.

1. In standby mode, select *Menu > Messages > Voice messages > Voice mailbox number*. The voice mailbox number is displayed.
2. If the box is empty, enter the voice mailbox area code and number, and select *OK*.

Call and setup voice mail

1. After you save the voice mailbox number, in standby mode, press and hold 1.
2. When you connect to voice mail and the prerecorded greeting begins, follow the automated instructions to setup voice mail.

Listen to voice messages

After you set up voice mail, in standby mode, press and hold 1; or select *Menu > Messages > Voice messages > Listen to voice messages* to dial the voice mailbox number. When you connect and the prerecorded greeting begins, follow the automated instructions to listen to your voice messages.

Automate voice mail

You can insert special characters called dialling codes into phone numbers such as voice mail, and save the number to a speed dial location. Dialling codes instruct the receiving system to pause, wait, bypass, or accept the numbers that follow them in the dialling string. See "[Phone numbers with dialling codes](#)," p. 28.

Voice mail services vary by wireless service provider or network operator. The following instructions are examples of common operations.

Please check with your wireless service provider or network operator for specific instructions on using your voice mail service.

Write down voice mailbox number and process

1. Write down your voice mailbox number.
2. Call and check your voice mail as you normally would.
3. Write down your interaction with the recorded prompts step-by-step. Keep in mind that each voice mail service may vary. However, it may look similar to the following:

Dial 8585551212, pause 5 seconds, press 1, pause 2 seconds, press 1234, and press #.

Phone numbers with dialling codes

Dialling codes instruct the receiving system to pause, wait, bypass, or accept the numbers that follow them in the dialling string. To set up dialling codes, do the following:

1. In standby mode, select *Menu > Contacts > Speed dials*.
2. Scroll to an (*empty*) Speed dials slot, and select *Assign*.
3. Enter your number, including the area code.

4. Enter any dialling codes as necessary after the entered phone number.

For example, if you pause for 5 seconds after connecting to voice mail, enter p twice (two times 2.5 seconds) after the voice mailbox number: 2145551212pp.

5. Enter any remaining pauses or other information that enables you to listen to your messages, and select *OK*.
6. Enter a name (such as voice mail), and select *OK*.

To dial and listen to your voice mail, press and hold the assigned speed dial key in standby mode.

Insert dialling codes

Press * repeatedly to cycle through dialling codes. When the desired code appears in the display, pause briefly and the code is inserted into the dialling string.

The following dialling codes are available:

*—Bypasses a set of instructions.

p—Pauses for 2.5 seconds before sending any numbers that follow.

+—Replaced by the international access code.

w—Waits for you to press the call key before sending the numbers or codes that follow.

Clear voice mail icon

To clear the voice mail icon from the display, in standby mode, select *Menu*

> *Messages* > *Voice messages* > *Clear voice message icon*.

■ Web messaging

Web messaging is a network service.

See "[Network Services](#)," p. *vii*.

If your wireless service provider or network operator supports this feature, you can use the minibrowser to check for e-mail messages. In standby mode, select *Menu* > *Messages* > *Minibrowser messages* > *Connect*.

See "[Mobile web](#)," p. *70* for more information on using the minibrowser in your device to access web pages.

5. Call register



Call register stores information about your last 30 missed, received, and dialled calls respectively and adds the total duration of all calls. When the number of calls exceeds the maximum, the most recent call replaces the oldest.

Whether viewing missed, received, or dialled calls, select *Options* to access these menu options:

Time of call—Displays the date and time of the call.

Send message—Sends a message to the number.

Use number—Edits the number and associates a name with the number.

Save—Enters a name for the number and saves it to your contacts list.

Add to contact—Adds a number to a contact and saves it to your contacts list (available only with the number not yet stored in your contacts list).

Delete—Clears the number from memory.

Call—Calls the number.

■ View missed calls

The missed calls feature does not function with your device switched off. Missed calls are calls you have never answered. To view missed calls, do the following:

1. In standby mode, select *Menu* > *Call register* > *Missed calls*, or with missed call notification displayed, select *List*.
2. Scroll to a name or number, and select *Options* and an option to view or activate.

■ View received calls

Received calls are calls that have been answered.

1. In standby mode, select *Menu* > *Call register* > *Received calls*.
2. Scroll to a name or number, and select *Options* and an option to view or activate.

■ View dialled numbers

Dialled calls are previous numbers you have dialled from your device:

1. In standby mode, press the call key, or select *Menu > Call register > Dialled numbers*.
2. Scroll to a name or number, and select *Options*.
3. Select an option to view or activate.

View call times

You can make or receive calls to or from the same number and view up to five calls displayed with the time each call occurred. Your device clock must be set for this feature to work accurately.

1. In standby mode, select *Menu > Call register > Missed calls, Received calls, or Dialled numbers*.
2. Highlight your desired name or number, and select *Options > Time of call*.
3. Scroll down to view the call times from this number; select *Back* to return to the options list.

■ Delete call registers

You can delete any missed, dialled, or received calls from your device memory.

1. In standby mode, select *Menu > Call register > Delete recent calls*.
2. Select the call type you want to clear: *All, Missed, Received, or Dialled*.

■ Call duration

Contact your wireless service provider or network operator for the actual calls and services invoice, which may vary depending on network features, rounding off for billing, taxes, and so forth.

You can view the duration of your last call, all your dialled calls, all your received calls, all your calls, and your life timer, as well as clear your timers. Select *Menu > Call register > Call duration > Last call duration, Dialled calls' duration, Received calls' duration, All calls' duration, Life timer, or Clear timers*. After you select *Clear timers*, enter your lock code, and select *OK*. See "Change lock code," p. 56.



Note: All call duration, except the life timer, are reset to zero with *Clear timers* selected.



Note: Some timers, including the life timer, may be reset during service or software upgrades.

To activate the call timer in standby mode while in a call, select

Call Duration > Last Call Duration > Details > Show call time on display > On or Off.

To view the duration of dialled or received calls placed while in the home network or while roaming, select *Details > Home* or *Roaming*.

■ Data and fax call duration

Data and fax calls are a network service. See "Network Services," p. vii. If your wireless service provider or network operator supports this feature, you can view the size or duration of sent or received data and fax calls.



Note: The actual time invoiced for calls and services by your service provider may vary, depending on network features, rounding off for billing, taxes, and so forth.

In standby mode, select *Menu > Call register > Data/fax calls* and one of the following options:

Last sent data/fax—View the size (KB) of the last sent data or fax call.

Last received data/fax—View the size (KB) of the last received data or fax call.

All sent data/fax—View the size (KB) of all sent data and fax calls.

All received data/fax—View the size (KB) of all received data and fax calls.

Duration of last data/fax call—View the duration time of the last data or fax call.

Duration of all data/fax calls—View the duration time of all calls.

Clear all data/fax registers—Select *OK* and then enter Security code when prompted.

■ Minibrowser duration

Minibrowser is a network service. See "Network Services," p. vii. If your wireless service provider or network operator supports this feature, you can view the size or duration of sent or received data from the minibrowser.



Note: The actual time invoiced for calls and services by your service provider may vary, depending on network features, rounding off for billing, taxes, and so forth.

In standby mode, select *Menu > Call register > Minibrowser calls* and one of the following options:

Last sent browser data—View the size (KB) of the last sent browser data.

Last received browser data—View the size (KB) of the last received data.

All sent browser data—View the size (KB) of all sent browser data.

All received browser data—View the size (KB) of all received browser data.

Last browser session—View the duration time of the last browser session.

All browser sessions—View the duration time of all browser sessions.

Clear all browser registers—Select *OK* > *Yes* to clear all browser logs.

6. Contacts



The contacts list can hold up to 500 contacts with multiple numbers and text notes for each contact. The amount of numbers and text entries you can save may vary, depending on the length and total number of entries in the contacts list.

■ Add new contacts

To access the contacts list in standby mode, press the right selection key, or select *Menu* > *Contacts* > *Names* if the right selection key on your device has a network operator menu.

Save contact name and number

1. In standby mode, enter the phone number you want to save.
2. Select *Save*.
3. Enter the name, and select *OK*.

Save contact number only

1. In standby mode, enter the phone number you want to save.
2. Select and hold *Options*.

Save an entry

1. In standby mode, select *Menu* > *Contacts* > *Names* > *Options* > *Add new*.
2. Enter the name, and select *OK*.
3. Enter the phone number, and select *OK* > *Back*.

Save numbers and text items

You can save different types of phone numbers and short text items per name to the contacts list. The first number you save for any entry is automatically set as the default number, which you can always change.

1. In standby mode, scroll down to display your contacts list, and highlight the entry to which you want to add a phone number or text item.
2. Select *Details* > *Options* > *Add detail* > *Number* (*General*, *Mobile*, *Home*, *Office*, or *Fax*), *E-mail address*, *Web address*, *Postal address*, *Note*, *Image*, or *Tone*.
3. Enter the number or text for the type you have selected, and select *OK*.
4. To change a number type (*General*, *Mobile*, *Home*, *Office*, or *Fax*),

highlight the number, and select *Options > Change type*.

Change default number

You can also change which phone number is the default (primary) number for the contact entry.

1. In standby mode, scroll down to select the contact entry you want to change, and select *Details*.
2. Scroll to the number you want to set as default, and select *Options > Set as default*.

Caller groups

You can add contacts list entries to any of five caller groups, and assign a unique ringing tone or graphic to that group. This enables you to identify callers from the group by their unique ringing tone or graphic.

1. To assign an entry in your contacts list to a caller group, scroll to your desired contact entry, and select *Details > Options > Caller groups > Family, VIP, Friends, Business, Other, or No group*.
2. To manage your caller groups, in standby mode, select *Menu > Contacts > Caller groups > Family, VIP, Friends, Business, or Other* to display the following caller group options:

Group name—Rename the group to your preference.

Group ringing tone—Set the ringing tone for the group.

Group logo—Turn the graphic for the caller group *On* or *Off*, or *View* the graphic.

Group members—Add or remove members from the caller group.

Set up speed dial

You can associate any entry in the contacts list with a key from 2–9. To dial those entries, press and hold the assigned key. See "Speed dial," p. 49 to activate or deactivate speed dials.

Assign a key to speed dial

1. In standby mode, select *Menu > Contacts > Speed dials*.
2. Scroll to an (*empty*) speed dial slot, and select *Assign*.
3. Enter the number (including the area code) and a name for the number, and select *OK*; or select *Search* to retrieve a number from the contacts list.
If speed dial is off, the device displays a prompt and asks if you want to turn speed dial on.
4. Select *Yes* to activate speed dial.

Change speed dial numbers

1. In standby mode, select *Menu* > *Contacts* > *Speed dials*.
2. Scroll to the speed dial entry you want to change, and select *Options* > *Change*.
3. Enter the new number and a name for the entry, and select *OK*; or select *Search* to retrieve a number from the contacts list.

Delete speed dial numbers

1. In standby mode, select *Menu* > *Contacts* > *Speed dials*.
2. Scroll to the speed dial entry you want to delete, and select *Options* > *Delete* > *Yes*.

Voice tags

You can dial up to 25 stored numbers using voice dialling.

Before using voice tags, note the following:

- Voice tags are not language-dependent. They depend on the speaker's voice.
- You must say the name exactly as you said it when you recorded it.
- Voice tags are sensitive to background noise. Record voice tags, and use them in a quiet environment.

- Very short names are not accepted. Use long names and avoid similar names for different numbers.



Note: Using voice tags may be difficult in a noisy environment or during an emergency, so you should not rely on voice dialling in all circumstances.

Assign a voice tag to an entry

Before you can use voice dialling, you must first assign a voice tag to the number.

1. In standby mode, scroll to the entry in your contacts list to which you want to assign a voice tag.
2. Select *Details* > *Options* > *Add voice tag* > *Start*.
3. Speak clearly into the microphone. Do not select *Quit* unless you want to cancel the recording. The device automatically stops recording, and saves and replays the voice tag.

 appears next to commands that have voice tags assigned.

Dial a number

1. In standby mode, press and hold the right selection key with the fold open, or press and hold the voice key regardless of the fold being open or closed.

- When you hear several beeps and *Speak now* appears, release the key.
- Pronounce the voice tag clearly into the microphone.

When the device finds the voice tag, *Found:* appears, and the device automatically dials the number. If the device does not locate a number or recognise the voice tag, *No match found* appears.

Voice tags

- After you have associated a voice tag to a contact, select *Menu > Contacts > Voice tags* and your desired voice tag entry.
- Select *Playback, Change, or Delete*.

■ Edit contacts list entries

- In standby mode, scroll to the entry you want to edit in your contacts list.
- Select *Details > Options*.
- Select one of the following options, which may vary depending on whether you are editing a contact listed by phone number or contact name:

View—View the phone number of the contact.

Add detail—Add more details to the contact: *Name* (only available with no name added), *Number* (*General, Mobile, Home, Office, or Fax*), *E-mail address, Web address, Postal address, Note, Image* (only available with no image added), or *Tone*.

Edit number, Add detail, or Change image—Edit an existing contact, phone number, details, or image attached to the contact.

Delete—Delete more details (*Delete number, Delete detail, or Delete image*) or the entire contact entry (*Delete contact*) of the contact.

Send message—Create and send the contact a text message or multimedia message.

Use number—Use or save the number (available when you select a contact listed with a contact name). Select *Options* to use the number.

Set as default—Change the default number of the contact.

Change type—Change the number type to *General, Mobile, Home, Office, or Fax*.

Add voice tag or Voice tag—Add a voice tag to the contact with no voice tag assigned, or select *Playback, Change, or Delete* with a voice tag assigned.

Send bus. card—Send the contact as a business card to another device.

Caller groups—Add the contact to an existing caller group.

Speed dial—Add the contact to your speed dial list.

4. Edit the option to your preference, and select *OK*.

■ Delete contacts entries

To delete all entries in your contacts list, in standby mode, select *Menu > Contacts > Delete all contacts*.

■ Access the contacts menu

1. In standby mode, select *Menu > Contacts* and one of the following options:

Names—View the entries in your contacts list, and select *Details* or *Options > Search, Add new*, or *Delete contact* for your selected entry.

Settings—Change the contacts list view or check the memory status of your device.

Caller groups—View and edit the properties of any of the caller groups, including *Family, VIP, Friends, Business*, or *Other*.

Voice tags—Listen to, modify, or delete a voice tag to a contact in the contacts list.

Speed dials—View or modify the list of speed dial numbers.

Delete all contacts—Delete all entries in your contacts list.

2. Select an option to activate the feature or access its submenu.

Search for a name

1. In standby mode, scroll down to display the contents of your contacts list.
2. Press the key corresponding to the first letter of the name for which you are searching.
3. Scroll to select a contact, and select *Details* to view the details.

Configure settings

You can select how the contacts appear in your contacts list and view the amount of memory used or available in your device.

In standby mode, select *Menu > Contacts > Settings > Scrolling view* to change view of name list or *Memory status* to view the device memory used and remaining.

■ Send and receive contacts

You can send and receive an entry in your contacts list using text messaging, if supported by your wireless service provider or network operator.

Send a business card

You can send a business card as a text message to a compatible phone or other handheld device.

1. Highlight your desired entry from your contacts list, and select *Details > Options > Send bus. card > Via multimedia* or *Via text message*. *Default number* and *All details* options appear only if you have more than one number or detail saved to the contact entry.
2. Enter the number for your recipient, or select *Search* to retrieve a number from your contacts list.
3. Select *OK* and the business card is sent.

7. Gallery



You can save pictures, video clips, recordings, and ringing tones to folders in the *Gallery* and add new folders as well. You can download images and tones using MMS, SMS, mobile Internet sites, or Nokia PC Suite.



Note: Only compatible devices offering compatible multimedia message features can receive and display multimedia messages.

Your device supports a digital rights management system to protect content you have acquired. Content such as a ringing tone, can be protected and associated with certain usage rules, for example, the number of usage times or a certain usage period. Usage rules are defined in the content activation key that can be delivered with the content or delivered separately, depending on your wireless service provider or network operator. You may be able to update the activation key. Always check the delivery terms of any content and activation key before acquiring them, as they may be subject to a fee.

Copyright protection may prevent some images, ringing tones, and other content from being copied, modified, transferred, or diverted.

Your device has about 12 MB of memory for storing files in the *Gallery*. This memory is not shared with other

functions, such as contacts. If the device displays a message that the memory is full, delete some existing files before proceeding.

■ Folders

1. In standby mode, select *Menu* > *Gallery* > *Images*, *Video clips*, *Graphics*, *Tones*, *Recordings*, *Themes*, or a user-created folder.
2. Select *Open* to view a list of the files in the folder or *Options* to access the following:

Delete folder—Delete a folder you have created. You cannot delete a preset folder.

Move—Move the selected folder into another folder. After selecting *Move*, scroll to another folder, and select *Move to*. You cannot move a preset folder.

Rename folder—Rename a folder you have created. You cannot rename a preset folder.

Details—Show the name, size, and date of creation of the selected folder.

Type of view—Select *List with details*, *List*, or *Grid* to determine how to display the folders and files within them.

Sort—Sort the contents of the selected folder by name, date, format, or size.

Add folder—Create a new folder.

Memory status—Check the available memory for the device handset.

Activation key list—View the list of available activation keys. You can delete activation keys if desired.

8. Media



Media player

With the media player you can download, view, and play compatible images, audio and video files, and animated images from a variety of sources.

The media player enables you to play streaming videos and streaming audio from a network server. Streaming functionality is a network service and requires network support. Check the availability of these services, pricing, and tariffs with your network operator or the service provider whose service you want to use. Service providers will also give you instructions on how to use their services.

In standby mode, select *Menu > Media > Media player* and one of the following:

Open Gallery—Open the *Gallery*. From *Gallery*, you can play stored audio and video files. See "*Gallery*," p. 40.

Go to address—Enter the address of a mobile Internet service, and select *OK*.

Radio

Your phone has an FM radio that also functions as an alarm clock radio. To listen to the FM radio on your phone, connect a compatible music stand or stereo headset to the connector on the bottom of the phone. The FM radio uses the wire of the headset as an

antenna. A compatible headset needs to be attached to the device for the FM radio to function properly. The quality of a radio broadcast depends on coverage of the radio station in that particular area.



Warning: Listen to music at a moderate level. Continuous exposure to high volume may damage your hearing. Do not hold the device near your ear when the loudspeaker is in use, because the volume may be extremely loud.

Turn the radio on and off

1. Connect the phone to a compatible headset or music stand.
2. In standby mode, select *Menu > Media > Radio*. The channel location number, the name of the radio channel (if you have saved the channel), and the frequency of the radio channel are displayed.

To use the graphical keys ▲, ▼, ◀, or ▶ on the display, scroll left or right to the desired key, and select it.

- If you have already saved radio channels, select ▲ or ▼ to scroll to the channel you would like to listen to.

To select a radio channel location, briefly press the corresponding number keys.

- To turn off the radio, press and hold the end key, or select *Options* > *Switch off*.

Options

With the radio on, select *Options* and one of the following:

Switch off—Turn off the radio.

Save channel—Save the current station to one of 20 locations (only available with a new station entered).

Channels—Scroll up or down to select a channel from 20 locations. With an existing channel highlighted, select *Options* > *Delete channel* or *Rename* to delete or rename the saved channel.

Mono output or *Stereo output*—Listen to the radio in monaural mode (default) or in stereo. Stereo output is available through a stereo enhancement.

Loudspeaker or *Headset*—Listen to the radio through the speakerphone or through the headset.

Set frequency—Manually enter the frequency of a known radio station.

To set the radio frequency, press * and use the keypad to enter the frequency of a known radio station.

To adjust the radio volume, press the volume up and down keys.

When an application using a browser connection is sending or receiving data, it may interfere with the radio.

When you place or receive a call, the radio automatically mutes. When the call ends, the radio switches back on.

Tune and save a radio channel

You can save a preset station to any one of 20 locations in memory.

- With the radio on, select ◀ or ▶ to change the radio frequency in 0.1 MHz steps, or select and hold ◀◀ or ▶▶ to start the channel search. Searching stops when a channel is found.
- To save the channel, select *Options* > *Save channel*.
- Enter a name for the channel, and select *OK*.

■ Voice recorder

This feature enables you to record pieces of speech or sound with your device and listen to them later. The total available time is 3 minutes with no memos stored. The maximum length of a recording depends on how much memory remains available.

In standby mode, select *Menu > Media > Recorder > Record* to start the recording or *Recordings list* to manage the folder you have defined for recording storage.

Record speech or sound

1. In standby mode, select *Menu > Media > Recorder > Record*.
2. After you hear the recorder start tone, begin recording speech or sound.
3. When you finish recording, select *Stop* and your recording is saved to the *Recordings* folder in the *Gallery*.

Options

After you have saved the recording to the *Recordings* folder, highlight the recording, and select *Open* to listen to the recording using the earpiece; or select *Options* and one of the following.

Delete—Erase the recording.

Rename—Change the name of the recording.

Set as ring tone—Use your recording as a ringtone (a carrier-dependent feature).

Details—Show the name, size, and date of creation of the recording.

Type of view—Select *List with details*, *List*, or *Grid* to determine how to display the recording

Sort—Sort the contents of the recording by name, date, format, or size.

Media equaliser

The equaliser enhances the sound quality when using the music player by amplifying or attenuating frequency bands. You can access five preset equaliser settings (*Normal*, *Pop*, *Rock*, *Jazz*, and *Classical*) and two customisable settings.

Activate an equaliser set

In standby mode, select *Menu > Media > Equaliser*, scroll to the desired setting, and select *Activate*.

Create a custom equaliser set

1. In standby mode, select *Menu > Media > Equaliser*.
2. Scroll to *Set 1* or *Set 2*, and select *Options > Edit*.



The selected set appears in the display with the bar on the far left highlighted. The bars adjust frequencies, from the lowest

(the leftmost bar) to the highest (the rightmost bar). The higher the indicator on a particular bar, the more that frequency is amplified.

3. To adjust the lowest frequency, scroll up and down on the bar.
4. To adjust other frequencies, scroll left or right to the other bars.
5. Repeat steps 3 and 4 to adjust the setting for each frequency; then select *Save*.
6. To rename the setting, select *Options > Rename*, enter a new name, and select *OK*.
7. To activate the setting, select *Activate*.

9. Settings



Use this menu to change profiles, themes, main display settings, mini display settings, tone settings, time and date settings, call settings, phone settings, voice commands, enhancement settings, security settings, application settings, network settings, network services, and restore factory settings.

■ Profiles

Profiles define how your device reacts when you receive a call or message and how your keypad sounds when you press a key. You can leave ringing options, keypad tones, and other settings for each of the available profiles at their default setting, or personalise them to suit your needs.

Profiles are also available for enhancements such as the headset and car kit. See "[Enhancement settings](#)," p. 54.

To activate a profile, in standby mode, select *Menu > Settings > Profiles > General, Silent, Meeting, Outdoor, or Pager > Activate*.

Personalise a profile

You can personalise any of the profiles in various ways.

1. In standby mode, select *Menu > Settings > Profiles*.
2. Select the profile you want to personalise.
3. Select *Personalise* and the option you want to personalise.

Set a timed profile

You can use timed profiles to prevent missed calls. For example, suppose you attend an event requiring your device set to *Silent* before the event starts, but you forget to return it to *General* until long after the event. A timed profile can prevent missed calls by returning your device to the default profile at a time you specify. You can set timed profiles up to 24 hours in advance.

1. In standby mode, select *Menu > Settings > Profiles*.
2. Select the profile you want to activate and *Timed* for timed expiration.
3. Enter the time in hh:mm format for the profile to expire, and select *OK*.

■ Tone settings

You can adjust the ringing volume, keypad tones, and more for the active profile. See "Personalise a profile," p. 46 for more information on profile settings.

Select *Menu* > *Settings* > *Tones* and one of the following:

Incoming call alert—Select how the device notifies you of an incoming call.

Video ringing tone—Select *On* or *Off* to indicate whether to replace the default audio ringing tone with the selected video.

Ringing tone—Select the ringing tone for incoming calls.

Ringing volume—Set the volume of your ringing tone.

Light indicator—Turn the light indicator on or off with *On* or *Off*.

Vibrating alert—Turn the vibrating alert *On* or *Off*.

Message alert tone—Select the tone for received messages.

Keypad tones—Set the volume of your keypad tones (or turn them off).

Warning tones—Turn warning and confirmation tones *On* or *Off*.

Alert for—Define which caller groups the selected profile will accept or decline. See "Caller groups," p. 35.

■ Themes

A theme contains many elements for personalizing your phone, such as wallpaper, screen saver, colour scheme, and a ringing tone.

To choose the theme of your display, in standby mode, select *Menu* > *Settings* > *Themes* > *Select theme* and then select the desired theme.

■ Main display settings

Wallpaper

You can set your device to display a background picture (wallpaper).

1. In standby mode, select *Menu* > *Settings* > *Main display* > *Wallpaper* > *Select wallpaper* > *Images*, *Video clips*, *Graphics*, or a user-created folder > *Open*.
2. Browse your selected folder containing the graphics or image of your desired wallpaper.
3. When you arrive at the image of your choice, select *Options* > *Set as wallpaper*.
4. To activate or deactivate wallpaper, in standby mode, select *Menu* > *Settings* > *Main display* > *Wallpaper* > *On* or *Off*.

Screen saver

In standby mode, select *Menu > Settings > Main display > Screen saver > On, Off, Screen savers (Image, Slide set, or Video clip), or Time-out.*

Power saver

You can turn the power saver on and off. In standby mode, select *Menu > Settings > Main display > Power saver > On or Off.*

Colour schemes

You can change the colour of some display components in your device, such as indicators and signal bars.

In standby mode, select *Menu > Settings > Main display > Colour schemes* and the colour scheme of your choice.

Choose a banner

Banner is a carrier-dependent feature.

If your wireless service provider or network operator supports this feature, you can choose whether the display shows the operator logo when the phone is in the idle state.

In standby mode, select *Menu > Settings > Main display > Banner > Default or Personalise.*

Backlight time-out

You can choose how long to set the backlights on. In standby mode, select *Menu > Settings > Main display > Backlight time-out > 15 seconds or Personalise* (to enter the time-out ranging from 15 seconds to 5 minutes).

■ Mini display settings

Power saver

You can turn the power saver on and off. In standby mode, select *Menu > Settings > Mini display > Power saver > On or Off.*

■ Time and date settings

Clock

In standby mode, select *Menu > Settings > Time and date > Clock > Show clock or Hide clock, Set the time, Time zone or Time format.*

Date

In standby mode, select *Menu > Settings > Time and date > Date > Show date or Hide date, Set the date, Date format, or Date separator.*

Date and time auto-update

Auto-update is a network service. See "Network Services," p. vii. If your wireless service provider or network operator supports this feature, you can allow the digital network to set the clock, which is useful when you are out of your home area, for instance when you have traveled to another network or time zone.

In standby mode, select *Menu > Settings > Time and date > Auto-update of date & time > On, Confirm first, or Off.*

If you use the *Auto-update of date & time* option while outside your digital network, you may be prompted to enter the time manually. Network time will replace the time and date when you reenter your digital network.

If your battery has been removed or has discharged outside the digital network, you may be prompted to enter the time manually (when the battery is replaced or recharged, and you are still outside of the digital network).

Call settings

Anykey answer

Anykey answer enables you to answer an incoming call. Briefly press any key except the right selection key or end key.

In standby mode, select *Menu > Settings > Call > Anykey answer > On or Off.*

Automatic redial

Occasionally, your network may experience heavy traffic, resulting in a fast busy signal when you dial.

With automatic redial activated, your device redials the number (number of times is specified by the network), and notifies you when the network is available.

In standby mode, select *Menu > Settings > Call > Automatic redial > On or Off.*

Speed dial

You can activate or deactivate speed dial. In standby mode, select *Menu > Settings > Call > Speed dialling > On or Off.* See "Set up speed dial," p. 35.

Open fold to answer

By default, your phone answers an incoming call when you open the fold. You can change the default setting to have your phone not answer calls with the fold open.

In standby mode, select *Menu* > *Settings* > *Call* > *Answer when fold is opened* > *On* or *Off*.

Calling card

If you use a calling card for long distance calls, you can save the calling card numbers in your device. Your device can store up to four calling cards. Contact your calling card company for more information.

Save information

1. In standby mode, select *Menu* > *Settings* > *Call* > *Calling card*.
2. Enter your security code, and select *OK*. See "[Change lock code](#)," p. 56.
3. Scroll to one of the four card memory locations, and select *Options* > *Edit* > *Dialling sequence* and one of the following sequence types:
Access no.+ phone no.+ card no.—Dial the access number, the phone number, then the card number (and the PIN, if required).
Access no.+ card no.+ phone no.—Dial the access number, the card number (and the PIN, if required), then the phone number.

Prefix+ phone no.+ card no.—Dial the prefix (numbers that must precede the phone number) and phone number you want to dial, then the card number (and the PIN, if required).

4. Enter the required information (access number or prefix and card number), and select *OK* to confirm your entries.
5. Select *Card name*, enter the card name, and select *OK*.

Make calls

After you have saved your calling card information in your device, you can make a call using your calling card.

1. In standby mode, select *Menu* > *Settings* > *Call* > *Calling card*.
2. Enter your lock code, and select *OK*. See "[Change lock code](#)," p. 56.
3. Select your desired calling card.
4. Press the end key to return to standby mode; then enter the phone number, including any prefix (such as 0 or 1) that your calling card may require when you make a calling card call. See your calling card for instructions
5. Press and hold the call key for a few seconds until *Card call* appears.
6. When you hear the tone or system message, select *OK*.

International prefix

You can store an international dialling prefix into your device. In standby mode, select *Menu > Settings > Call > International prefix*.

In standby mode, when you enter + (press * twice) at the beginning of a phone number, your device automatically inserts the international dialling prefix that you have stored after you press the call key. See "Insert dialling codes," p. 28.

Data or fax calls

Data and fax calling is a network service. See "Network Services," p. vii. If your wireless service provider or network operator supports this feature, you can set up the device to send or receive data and fax calls with a terminal, such as a PDA or PC, connected.

For better performance during data calls, place the device on a stationary surface. Do not move the device by holding it in your hand during a data call.

For more information on connectivity, refer to the PC/PDA Connectivity Guide which can be downloaded from the Nokia website at <http://www.nokia-asia.com>.

1. In standby mode, select *Menu > Settings > Call > Data/fax calls > Incoming data/fax call* and one of the following options:

Normal—The device receives incoming calls as usual.

Data calls only—The device receives only data calls.

Fax calls only—The device receives only fax calls.

2. When finished with receiving the Data or Fax call, the phone will return to *Normal* mode.

Data transfer

You can view the transmission speed when sending or receiving data and fax calls.

In standby mode, select *Menu > Settings > Call > Data/fax calls > Data rate display > Graphic* or *Off*.

Call summary

Your device can display the time spent on a call when you hang up. In standby mode, select *Menu > Settings > Call > Call summary > On* or *Off*.

Ringling tone for no caller ID

You can select a different ringing tone for calls received with no caller ID.

In standby mode, select *Menu > Settings > Call > Ringing tone for no caller ID > On* or *Off*.

■ Phone settings

Phone language

The phone language affects time and date formats of the clock, clock, and calendar.

Memory status

You can view the size of memory available on your device. In standby mode, select *Menu* > *Settings* > *Phone* > *Memory status*.

You can view the size of memory available for application installations. In standby mode, select *Menu* > *Extras* > *Memory*.

Automatic keyguard

You can set the keypad of your device to lock automatically after a preset time delay.

1. In standby mode, select *Menu* > *Settings* > *Phone* > *Automatic keyguard* > *On* or *Off*.
2. If you select *On*, *Set delay:* is displayed.
3. Enter the delay time (in mm:ss format), and select *OK*.

When keyguard is on, it may be possible to dial the emergency number programmed into your device.

DTMF tones

DTMF tones are the tones that sound when you press the keys on your device keypad. You can use DTMF tones for many automated dial-up services such as banking and airlines or for entering your voice mailbox number and password.

DTMF tones are sent during an active call. You can send them manually from your device keypad, or send them automatically by saving them in your device.

Set type

In standby mode, select *Menu* > *Settings* > *Phone* > *DTMF tones* > *Manual DTMF tones* and one of the following options:

Continuous—Used to set the tone sound for as long as you press and hold a key.

Fixed—Used to send tones of the duration you specify in the *DTMF tone length* option.

Off—Used to turn off tones. No tones are sent when you press a key.

Set length

You can specify DTMF tone length for the *Fixed* option. In standby mode, select *Menu* > *Settings* > *Phone* > *DTMF tones* > *DTMF tone length* > *Short* (0.1 seconds) or *Long* (0.5 seconds).

Start-up tone

You can select to have a start-up tone when you first turn on your device. In standby mode, select *Menu > Settings > Phone > Start-up tone > On or Off*.

Help text activation

Your device displays brief descriptions for most menu items. When you arrive at a feature or menu, pause for about 14 seconds and wait for the help text to display. If necessary, use the scroll key to page through the full help text.

The default setting for help text is *On*. However, you can turn help text on or off. In standby mode, select *Menu > Settings > Phone > Help text activation > On or Off*.

Voice commands

Before using voice tags, note the following:

- Voice tags are not language-dependent, but depend on the speaker's voice.
- You must say the name exactly as you said it when you recorded it.
- Voice tags are sensitive to background noise. Record voice tags, and use them in a quiet environment.
- Very short names are not accepted. Use long names, and avoid similar names for different numbers.



Note: Using voice tags may be difficult in a noisy environment or during an emergency, so you should not rely on voice dialling in all circumstances.

Hands-free operation

You can set as many as 16 voice commands to enable hands-free operation of certain features in your device.

Assign a voice tag to a command

Before using voice commands, you must first add a voice tag to the device function.

1. In standby mode, select *Menu > Settings > Voice commands*.
2. Select the device function you want to tag: *Profiles, Voice mailbox, Radio, Voice recorder, or Call register*.
3. If necessary, select an option associated with that function.
4. Select *Start*, and speak the voice tag clearly into the microphone. Do not select *Quit* unless you want to cancel the recording.

The device replays and saves the recorded tag.  appears next to commands with voice tags assigned.

Activate a voice command

After you have associated a voice tag with a function in your device, to issue a command, speak the voice tag.

1. In standby mode, press and hold the right selection key or voice key.
2. With *Speak now* displayed, pronounce the voice tag clearly into the microphone.

With the voice tag found, the device displays *Found*; and plays the recognised voice tag through the earpiece. The function you requested is activated.

Options

After you have associated a voice tag to a command, you can select one of the following options:

Playback—Listen to the voice command tag.

Change—Change the voice command.

Delete—Erase the voice command tag.

■ Enhancement settings

The enhancement settings menu is shown only if the device has been connected to a compatible enhancement. In standby mode, select *Menu > Settings > Enhance-ments > Headset, Handsfree, Loopset, Text phone, Music stand, or Charger.*

Headset



Important: The headset may affect your ability to hear sounds around you. Do not use the headset in situations that may endanger your safety.

Select the option of your choice to enter the submenu and modify its settings.

Default profile—Choose the profile you want automatically activated with a headset connected.

Automatic answer—Answer calls automatically after one ring with a headset connected. Select *On* or *Off*.



Note: Automatic answer will only be active whilst *General* profile is active.

Hands-free operation

Select the option of your choice to enter the submenu and modify its settings.

Default profile—Choose the profile you want automatically activated with your device connected to a car kit.

Automatic answer—Answer calls automatically after one ring with a car kit connected. Select *On* or *Off*.



Note: Automatic answer will only be active whilst *General* profile is active.

Lights—Choose to keep the device lights always on, or to shut off automatically after several seconds. Select *On* or *Automatic*.

Loopset

The LPS-4 loopset is recommended for use with your device. Select the option of your choice to enter the submenu and modify its settings.

Default profile—Choose the profile you want to be automatically activated when your device is connected to a loopset.

Automatic answer—Answer calls automatically after one ring when a loopset is connected. Select *On* or *Off*.



Note: Automatic answer will only be active whilst *General* profile is active.

Charger

Select the option of your choice to enter the submenu and modify its settings.

Default profile—Choose the profile you want automatically activated with your device connected to the charger.

Lights—Choose to keep the device lights always on, or to shut off automatically after several seconds. Select *On* or *Automatic*.

Security settings

When first accessing the security settings, enter the preset lock code. The default setting for lock code is 12345. Depending on your wireless service provider or network operator, the preset lock code can be a four digit number such as 1234 or 0000. If none of these work, contact your wireless service provider or network operator for help.

Phone lock

The phone lock feature protects your device from unauthorised outgoing calls or unauthorised access to information stored in the device. With phone lock activated, *Phone locked* appears each time you turn your device on or off.

With the device locked, calls may still be possible to the official emergency number programmed into your device.

1. In standby mode, select *Menu* > *Settings* > *Security*.
2. Enter the lock code, and select *OK*. See "Change lock code," p. 56.
3. Select *Phone lock* and one of the following options:
 - Off*—Immediately turns off the device lock feature.
 - Lock now*—Immediately turns on the device lock feature.

On power-up—Turns on the device lock feature the next time you turn the device on.

With **Lock now** selected, you must enter your lock code before the device can function normally. With the lock code accepted, your device functions normally.

Call not allowed appears if you attempt to place a call with your device locked. To answer a call with phone lock on, select **Answer**, or press the call key.

Allow numbers

With phone lock on, the only outgoing calls you can make are to the emergency number programmed into your device (for example, 111 or 000 or 911) or the number stored in the **Allowed number when lock active** location:

1. In standby mode, select **Menu > Settings > Security**.
2. Enter the lock code, and select **OK**. See "**Change lock code**," p. 56.
3. Select **Allowed number when lock active**. With an empty folder selected, select **Assign**, and enter the phone number; or select **Assign > Search** to recall the number from your contacts list. Select **OK**.

To call the allowed phone number, in standby mode, scroll down to highlight the number you want to call, or enter it on the keypad, and then press the call key to place the call.

Change lock code

The preset lock code, by default, is the last four digits of your phone number. Depending on your wireless service provider or network operator, the preset lock code can be a four digit number such as 1234 or 0000. If none of these work, contact your wireless service provider or network operator for help.

To ensure the security of your device, you may want to change the preset lock code to your own selected four digit number. Avoid using codes similar to emergency numbers such as 111 or 000 or 911 to prevent accidental dialling of the emergency number.

If you enter an incorrect lock code five times in a row, your device may ask you for the security code. By default, the security code is 12345, a five digit number.



Note: With the wrong lock code entered five times in succession, your phone will not accept your correct lock code for 5 minutes, even if you power off the device between incorrect entries.

1. In standby mode, select **Menu > Settings > Security**.
2. Enter the lock code, and select **OK**.
3. Select **Change lock code**.
4. Enter the new lock code (must be 4 characters in length).

5. Reenter the new lock code for verification, and select *OK*.

When changing your lock code, make sure you store it in a safe place, away from your device. Avoid entering access codes similar to emergency numbers to prevent accidental emergency calls.

Call restrictions

Select call restrictions to block or allow numbers for incoming and outgoing calls. With any numbers entered as allowed numbers, all those entered as blocked numbers are ignored. With a number blocked, the phone blocks any call from it, and send the caller to the voice mail.

1. In standby mode, select *Menu > Settings > Security*.
2. Enter the lock code, and select *OK*. See "[Change lock code](#)," p. 56.
3. Select *Call restrictions*.
4. Select the types of calls you want to restrict:
 - Restrict outgoing calls*—Set restrictions on making calls.
 - Restrict incoming calls*—Set restrictions on receiving calls.

5. Select whether to block or allow numbers:

Blocked numbers—Set the numbers the phone can only block, allowing all the rest.

Allowed numbers—Set the numbers the phone can only call or receive, blocking all the rest.

6. Select one of these options: *Select*, *Add restriction* (unavailable with memory full), *Edit* (unavailable with no number added), or *Delete* (unavailable with no number added).



Note: With restricted calls, you may still call the official emergency number programmed into your device.

Voice privacy

Voice privacy is a network service. See "[Network Services](#)," p. vii. If your wireless service provider or network operator supports this feature, the voice privacy feature protects the privacy of your current phone conversation from other callers placing phone calls on your same network.

1. In standby mode, select *Menu > Settings > Security*.
2. Enter the lock code, and select *OK*. See "[Change lock code](#)," p. 56.
3. Select *Voice privacy > On* or *Off*.

■ Application settings

1. In standby mode, select *Menu* > *Settings* > *Application settings*.
2. Scroll to one of the following submenus to activate options for preset or downloaded games or applications.
 - Application sounds*—Select *On* or *Off*.
 - Application lights*—Select *App. defined* or *Default*.
 - Application vibration*—Select *On* or *Off*.

■ Network

The menu options you see in your device depend on your service provider's network. The network determines which options actually appear in the device menu. Check with your service provider for more information.

The *Network* menu enables you to personalise the way your device chooses a network in which to operate while you are within or outside of your primary or home system. Your device is set to search for the most cost-effective network. If your device cannot find a preferred network, it selects a network automatically based on the option you choose in the *Network* menu.

Roaming options

You can set your device to roam or search for another network when you are not in your home area.

1. In standby mode, select *Menu* > *Settings* > *Network* > *Roaming options* and one of the following options:
 - Home only*—You can make and receive calls in your home area only.
 - Automatic*—The device automatically searches for service in another digital network. With no service found, the device uses analogue service. The roaming rate applies when not in the home service area.
2. Select *OK*, if necessary, to confirm the activation.

Mode

You can choose whether your device uses digital or analogue service.

In standby mode, select *Menu* > *Settings* > *Network* > *Mode* and one of the following service options:

- Digital preferred*—The device works in digital mode but will also work in analogue mode with digital mode unavailable.
- Digital only*—The device only works in digital mode.
- Analogue only*—The device only works in analogue mode.

■ Network services

The following features are network services. See "Network Services," p. vii.

Store a feature code

1. In standby mode, select *Menu > Settings > Network services > Network feature setting*.
2. Enter the feature code from your service provider (for example, *633), and select *OK*.
3. Select the type of service that matches the feature code you entered (for example, *Call divert*).

The activated feature code is now stored in your device, and you are returned to the *Feature code*: field. Continue entering other feature codes (for example, *633), or press the end key to return to standby mode. When you enter a network feature code successfully, the feature becomes visible in the *Network services* menu.

Call diverting

Call diverting tells your network to redirect incoming calls to another number. Call diverting is a network service and may not work the same in all networks, so contact your wireless service provider or network operator for availability.

Activate

The following options may not all appear in the display. They will only appear in the display if the relevant feature code has been entered into the phone.

1. In standby mode, select *Menu > Settings > Network services > Call divert* and one of the following options:
 - Divert all calls*—Divert all calls to the number you specify.
 - Divert if busy*—Divert incoming calls when you are in a call.
 - Divert if not answered*—Divert incoming calls to another number if you are unable to answer. You can set a delay before diverting takes place.
 - Divert if out of reach*—Divert incoming calls when your device is off.
2. Select *Activate*.
3. Enter the number to which your calls, data, or other information will be diverted, and select *OK*.

Cancel

In standby mode, select *Menu > Settings > Network services > Call divert > Cancel all diverts*. *Cancel all diverts* may affect your ability to receive voice mail messages. Contact your wireless service provider or network operator for specific details.

■ Restore factory settings

You can reset some of the menu settings to their original values. Data that you have entered or downloaded is not deleted (for example, entries in your contacts list are not affected).

1. In standby mode, select *Menu* > *Settings* > *Restore factory sett.*
2. Enter the lock code, and select *OK*.
See "Change lock code," p. 56.



Note: Depending on your wireless service provider or network operator, your device may sometimes ask you for the security code (defaulted to 12345) instead of the lock code.

10. Organiser



Your device contains features to help organise your everyday life, including an alarm clock, calendar, notes, todo list, calculator, countdown timer, and stopwatch.

■ Alarm clock

If the alarm time arrives with the device switched off, the device switches itself on and starts sounding the alarm tone. If you select *Stop*, the device asks whether you want to activate the device for calls. Select *No* to switch off the device or *Yes* to make and receive calls. Do not select *Yes* when wireless phone use may cause interference or danger.

Set or change alarm setting

The alarm clock depends on the device clock, which sounds an alert anytime you specify and even works with the device turned off.

1. In standby mode, select *Menu > Organiser > Alarm clock > Alarm time > On*.
2. Enter the time for the alarm in hh:mm format.
3. *Alarm on* appears briefly in the display, and  appears in standby mode.

Repeat alarm

You can set the alarm to repeat. In standby mode, select *Menu > Organiser > Alarm clock > Repeat alarm*.

Set the alarm tone

You can set which tone to play when the alarm sounds. In standby mode, select *Menu > Organiser > Alarm clock > Alarm tone > Standard, Radio, or Open Gallery* to choose the tone you want to use.

If you set your alarm to *Radio*, use an accessory that supports FM stereo.

Snooze time-out

To set the alarm snooze time, select *Menu > Organiser > Alarm clock > Snooze time-out > 5 minutes, 10 minutes, 15 minutes, 30 minutes, 60 minutes, or Other* (to enter up to 60 minutes snooze time).

Alarm conditions

When the alarm sounds, your device beeps, vibrates (if vibrating alert is on for currently active profile), and the display lights up.

With the device on, select *Stop* to shut the alarm off or *Snooze*. With *Snooze* selected, the alarm stops for 10

minutes, and *Snooze on* appears in the display.

If you do not press a key, the alarms stops (snoozes) for 10 minutes, then sounds again. You can also select *Menu > Organiser > Alarm clock > Snooze time-out* to reset the snooze time.

Turn an alarm off

In standby mode, select *Menu > Organiser > Alarm clock > Alarm time > Off*.

Calendar

The calendar keeps track of reminders, calls you need to make, meetings, and birthdays, which can even sound an alarm for any of these events.

Monthly view provides an overview of the selected month and weeks, enabling you to jump to a specific date. Any days or dates that appear in bold font contain calendar notes such as a meeting or reminder.

Open

In standby mode, select *Menu > Organiser > Calendar*, or press the right scroll key. Scroll to move the cursor in some calendar views.

Go to a date

1. In standby mode, select *Menu > Organiser > Calendar > Options > Go to date*.

2. Enter the date (dd/mm/yyyy), and select *OK*.

Note a specific date

You can apply five types of notes to your calendar. Your device asks for further information depending on which note you choose. You also have the option to set an alarm for any note you select.

1. Go to the date for which you want to set a reminder. See "Go to a date," p. 62.
2. From the monthly view (with the go-to date highlighted), select *Options > Make a note* and one of the following note types:
 - Meeting*—Enter a subject, location, and a start and end date and time.
 - Call*—Enter a phone number, a name, and the date and time.
 - Birthday*—Enter the person's name, date and year of birth.
 - Memo*—Enter a subject and a start and end date.

Reminder—Enter the subject and date of your reminder.

You are given the option to set an alarm.

3. Enter your note, and select *Save*.

View notes (day view)

After you have created calendar notes, you can view them.

1. In standby mode, select *Menu > Organiser > Calendar*.
2. Scroll to the date containing the note that appears in bold type, and select *View*.

Options while viewing a list of notes

1. Select *Options* while viewing a day's note to display the following:

The options listed below are available while viewing the header of a note.

Make a note—Create a new note for the selected date.

Delete—Delete the note.

Edit—Edit the note.

Move—Move the note to another date on your calendar.

Repeat—Set the note (except for birthday note) to recur on a regular basis (daily, weekly, biweekly, monthly, and yearly).

Go to date—Jump to another date on your calendar.

Go to today—Jump to the current date on your calendar.

Send note—Send the note to another device as a text message or in calendar-to-calendar format by way of multimedia messages or SMS.

Copy—Copy the note for you to paste to another date.

Settings—Set the date and time, date and time format, the day each week starts and whether you want your notes to autodelete after a specified time.

Go to to-do list—Jump to the to-do list on your calendar.

2. Select an option to activate it or enter its submenu.

Send a note

1. In standby mode, select *Menu > Organiser > Calendar*.
2. Scroll to the date that appears in bold type, containing the note you want to send, and select *View*.
3. Scroll to the note you want to send, and select *Options > Send note > Send as message (Text message or Multimedia msg.)* or *Via calendar*.
4. If you selected *Via calendar*, enter the number for the recipient, or select *Search* to retrieve a number from the contacts list, and select *OK*.
5. If you selected *Send as message (Text message or Multimedia msg.)*,

the note appears as a text message in the display.

- Select *Send to* > *Send to number*, *Send to e-mail*, *Send to many*, or *Send to distrib. list*.
- Enter the number for the recipient, or select *Search* to retrieve a number from the contacts list, and select *Send*.

Receive notes

When you receive a calendar note in calendar-to-calendar format, your device displays *Calendar note received*.

- To view calendar notes, select *Show*, and if necessary, scroll to view the entire message.
- To save calendar notes after viewing, select *Options* > *Save*.
- To discard calendar notes after viewing, select *Exit* or *Options* > *Discard*.

When you receive a calendar note or text message, a message notification appears in standby mode. You can save the note in your calendar and set an alarm for any date and time.

Notes

You can write and save information in *Notes* and send notes using multimedia or text message. In standby mode, select *Menu* > *Organiser* > *Notes*. With no notes created, select *Add note*, create your note, and select *Save* when done. With notes already created, highlight the note you want to use, and select *View* to read or *Options* > *Make a note*, *Delete*, *Edit*, *Send note (Send as message)*, or *Delete all notes*.

To-do list

Use the to-do list feature to keep track of your tasks. You can save a note for a task, select a priority level for the note and mark it as done when you have completed it. You can sort the notes by priority or by date.

Add a to-do note

1. In standby mode, select *Menu* > *Organiser* > *To-do list*.
2. If there are no notes, select *Add note*.
3. Enter the subject of the to-do note, and select *Save*.
4. Select *High*, *Medium*, or *Low* priority.
5. Enter the due date and time to set the alarm.

View a to-do note

- In standby mode, select *Menu > Organiser > To-do list*.
- Highlight a to-do note, and select *Options* and one of the following:
 - Add*—Add another note.
 - Delete*—Delete the note.
 - Mark note as done* or *Mark as not done*—Mark a note or task as completed or not; if completed, no more reminders will follow.
 - Sort by deadline*—Sort the notes according to their deadline.
 - Send*—Send the note to another device, as a text or multimedia message, or as a calendar note to another compatible device.
 - Go to calendar*—Leave the to-do list, and go to the calendar.
 - Save to calendar*—Save the to-do note to a date on your calendar.
 - Delete done notes*—Delete all the completed to-do notes.
 - Delete all notes*—Delete all the to-do notes in the list.
- View* the to-do note, and select *Edit* to edit the note or *Options* to select from the following:
 - Deadline*—Set a deadline for the note, listing any uncompleted notes if existing.

Mark note as done or *Mark as not done*—Mark a note or task as completed or not; if completed, no more reminders will follow.

Delete—Delete the note.

Edit priority—Change the priority to high, medium, or low.

Send—Send the note to another device, as a text or multimedia message, or as a calendar note to another compatible device.

Go to calendar—Leave the to-do list, and go to the calendar.

Save to calendar—Save the to-do note to a date on your calendar.

Calculator

The calculator in your device adds, subtracts, multiplies, divides, calculates the square and the square root, changes the sign of the number entered, and converts currency values.



Note: This calculator, designed for simple calculations, has limited accuracy.

- In standby mode, select *Menu > Organiser > Calculator*.
- Enter the first number in the calculation. Press # for a decimal point if necessary.

To change the sign, select *Options > Change sign*, or scroll up or down.

To perform a square or square root calculation, select *Options* > *Square* or *Square root*.

To cycle through the add (+), subtract (-), multiply (*), and divide (/) characters, press *.

3. Enter the second number in your calculation.
4. Select *Equals* to complete calculation or *Options* if more functions are required.

Currency converter

You can convert foreign currency to domestic, or vice versa, directly in standby mode or from the *Calculator* menu.



Note: When you change base currency, you must enter the new rates because all previously set exchange rates are set to zero.

1. In standby mode, select *Menu* > *Organiser* > *Calculator* > *Options* > *Exchange rate* > *Foreign unit in domestic units* or *Domestic unit in foreign units*.

Foreign unit in domestic units—The number of home units cost to make one unit of foreign currency.

Domestic unit in foreign units—The number of foreign units cost to make one unit of your home currency.

2. Enter the exchange rate (press # to insert a decimal), and select *OK*.
3. In standby mode, enter the currency amount to be converted.
4. Select *Options* > *In domestic* or *In foreign*.
In domestic—converts foreign currency to domestic currency.
In foreign—converts domestic currency to foreign currency.
5. If you do not enter an exchange rate, the device will prompt you to do so. Select *OK*. You can edit the exchange rate at anytime.

Countdown timer

The countdown timer in your device enables you to enter a specific time (up to 99 hours and 59 minutes). When the time runs out, your device sounds an alarm.



Note: The countdown timer only works when the device is on. When you turn off your device, the timer is no longer active.

Set the timer

1. In standby mode, select *Menu* > *Organiser* > *Timer* > *Normal timer*, *Interval timer*, or *Settings*.
Use *Normal timer* to measure the countdown time for tasks that have one period (timer name).

Select *Interval timer* to save sets of countdown times with more than one period.

2. Enter the time (in hh:mm:ss format), and select *OK*.
3. Enter a note for the timer, and select *Start*.

 appears in standby mode with the countdown timer set. When the time runs out, your device sounds an alarm, displays the timer note, vibrates (if set), and flashes its lights.

Press any key during the alarm to stop the alarm. After 30 seconds the timer alert stops automatically.

Change the time

After you have set the timer, you can change the time.

1. With a normal timer set, in standby mode, select *Menu > Organiser > Timer > Change time*.
2. Enter the new time, and select *OK*.
3. Leave the note as it was, or enter a new note, and select *Start*.

Interrupt the timer

After you have set the timer, you can stop the timer. In standby mode, select *Menu > Organiser > Timer > Stop timer*.

Stopwatch

You can use the stopwatch in your device to track time. The stopwatch displays time in hours, minutes, seconds, and fractions of a second in hh:mm:ss.ss format.

Using the stopwatch or allowing it to run in the background when using other features increases the demand on battery power and reduces the battery life.

Measure time

1. In standby mode, select *Menu > Organiser > Stopwatch > Split timing or Lap timing > Start*. The running time is displayed.

Split timing—You can use the split time function for such things as a long distance race when you need to pace yourself. Select *Split* to note the lapsed time. The timer continues to run and the split time appears below the running time. Each time you select *Split*, the new measured time appears at the beginning of the list.

Lap timing—You can use the lap time function when you want to track how long it takes to complete each cycle or lap. Select *Lap* to note the lap time. The clock stops, then starts immediately from zero. The lap time appears below the running time. Each time you select

Lap, the new measured time appears at the beginning of the list.

2. Select *Stop* to end the timing and display the total time or *Stop > Options > Start* or *Reset* to continue or reset timing.

Lap and split times

To save a time while the clock is running, select *Stop > Save*, enter a name for the measurement, and select *OK*. If you do not enter a name, the total time is used as the default title for the lap or split time.

To view a saved time, in standby mode, select *Menu > Organiser > Stopwatch > Show last* or *View times*.

To delete a saved time from *Stopwatch*, select *View times* and the time to delete, and select *Delete > Yes*; or select *Delete times > One by one* or *Delete all*.

Operation note

If you press the end key and return to standby mode, the clock continues to run in the background, and  appears in the upper left corner.

To return to the stopwatch screens, in standby mode, select *Menu > Organiser > Stopwatch > Continue*. To stop the clock, select *Stop*.

Options

You can choose the following options when you use the stopwatch:

Continue—Appears when the stopwatch is working in the background.

Show last—Appears when you have saved a split or lap time and displays the last time saved.

Split timing—Asks if you want to discontinue previous timing.

Lap timing—Asks if you want to discontinue previous timing.

View times—Enables you to browse the saved times.

Delete times—Enables you to delete any saved times. You can delete the saved times one by one or all at once.

11. Extras



Challenge yourself or a friend to one of the fun games in your device. Some menus listed are network services. Contact your wireless service provider or network operator for more information. To download games or applications, select either the *Games* or *Collection* menu.

■ Games

In standby mode, select *Menu > Extras > Games* to display the games on your device: Games are Snake Ex2 and Galaxy Balls.

■ Collection

Collections is a network service. See "[Network Services](#)," p. vii. If your wireless service provider or network operator supports this feature, you will find useful applications preinstalled on your device. Also, you can manage and download new Java applications that may be offered by your wireless service provider or network operator.

An application may require a few seconds to load. When you open an application, wait for the launch screen to disappear. At that point, the application is ready.

In standby mode, select *Menu > Extras > Collection* and an application.



Note: Only install applications from sources that offer adequate protection against harmful software.

■ Memory

You can view the size of memory available for games or application installations. In standby mode, select *Menu > Extras > Memory*.



Note: Only install applications from sources that offer adequate protection against harmful software.

12. Mobile web



Minibrowser is a network service. See "Network Services," p. vii.

Your device has a built-in browser you can use to connect to selected services on the mobile internet. If your wireless service provider or network operator supports this feature, then you can view weather reports, check news or flight times, view financial information, and much more. The web browser on your device can display WAP-based content.

Your device may have some bookmarks loaded for sites not affiliated with Nokia. Nokia does not warrant or endorse these sites. If you choose to access them, you should take the same precautions, for security or content, as you would with any internet site.

The security icon does not indicate that the data transmission between the gateway and the content server (or place where the requested resource is stored) is secure. The service provider secures the data transmission between the gateway and the content server.

■ Mobile Internet access

Because mobile Internet content is designed to be viewed from your device, your wireless service provider or network operator is now your mobile Internet service provider as well.

It is likely that your wireless service provider or network operator has created a home page and set up your browser to go to this page when you log on to the mobile Internet. At your service provider's home page, you may find links to a number of other sites.

It should not be necessary to manually configure the browser on your device. Normally this is done by your wireless service provider or network operator after you subscribe to the feature. Contact your wireless service provider or network operator if you have problems using the browser.

■ Sign on

In standby mode, select *Menu > Mobile web*.

After a brief pause, your device attempts to connect to your wireless service provider or network operator's home page. If you receive an error message, your device may not be set up for browsing. Contact your wireless service provider or network operator to make sure that your device is configured properly.

■ Navigate the mobile Internet

Since your device screen is much smaller than a computer screen, mobile Internet content is displayed differently than you may be accustomed to seeing. This section contains guidelines for using the keys to navigate a WAP site.

Phone keys

- Press the power key to display the minibrowser home screen.
- Scroll up or down to browse the WAP site.
- Select an item.
- To enter letters and numbers, press a key from 0–9.
- To enter special characters, press *.

Receive a call while online

If your data connection is not active, you may still be able to receive a voice call while using the WAP browser.

- To answer the incoming call, press the call key.
- To reject the incoming call, press the end key (a carrier-dependent feature).

While in the voice call, you are not able to load new pages in the browser.



Note: If your data connection is active, the incoming calls are automatically diverted to voice mail, depending on your carrier.

Make an emergency call while online

You can end your data connection and make an emergency call.

1. To close your mobile Internet connection, press the end key.
2. Press the end key as many times as needed to clear the display and ready the device for calls.
3. Enter the emergency number for your present location (for example, 111 or 000 or 911). Emergency numbers vary by location.
4. Press the call key.

Clear the cache and disconnect

A cache is a memory location that is used to store data temporarily. If you have tried to access or have accessed confidential information requiring passwords, empty the cache after each use. The information or services you have accessed are stored in the cache.

To empty the cache while in the browser menu, select **Menu > Advanced > Clear > Cache** from the home page. To clear the cache and power off your device, press and hold the power key.

To close your mobile internet connection while browsing, press the end key.

13. PC connectivity

■ USB data transfer

You can transfer data such as music, photos, and videos from your device to a compatible PC or from a compatible PC to your device using a DKU-2 USB data cable. The cable is connected to your device correctly when the arrowhead points toward the display screen. Disconnect the USB data cable from the device to make a call.

Use the Nokia Audio Manager software to handle your music files, and transfer them from the PC to your device. See "Nokia PC Suite," p. 74.

Transfer with Windows Explorer

After you have installed the Nokia Audio Manager, it is possible to use Windows Explorer to transfer music, photo, and video files to your device and from your device to your PC.

1. Connect your PC and your device with a DKU-2 USB cable. *Data enhancement connected* is displayed on your device.
2. Open Windows Explorer. Your device appears as a local drive (named by Nokia 3155) with a drive letter assigned to it.
3. Click on the folders to display a window that shows the contents of the folder on the device.
4. Open a second instance of Windows Explorer, and display the contents of the folder on your PC where you have MP3 files, photo files, or video files stored.
5. Select the files on your PC that you want to transfer to the device.
6. Drag and drop the files from the second window into the first window, and place them in a folder.
7. The files are transferred to the device and can be played or accessed by the media player.
If you select files that require more memory than the memory capacity of the device, an error note appears. Deselect some of the files until the selected files fit the memory.
8. Disconnect the USB cable by double-clicking the green arrow on the taskbar at the bottom of your PC screen. A pop-up window displays **Unplug** or **Eject Hardware**.
9. Click on USB device in the hardware devices window. A pop-up window displays **Stop a Hardware device**.

10. Highlight **USB device** and click **OK**.

The pop-up window displays **Safe to Remove Hardware**, with **The 'USB Device' device can now be safely removed from the system**. Select **OK**.



Important: To ensure that all memory card operations are completed in a controlled way, do not unplug the connectivity cable until Windows notifies you that it is safe to do so. Uncontrolled completion of the memory card operations may cause the memory card and the information stored on it to become corrupted. A corrupted memory card may have to be formatted before it can be used again. When a memory card is formatted, all information on the card is permanently lost.

■ Nokia PC Suite

Nokia PC Suite software is available for the Nokia 3155. Nokia PC Suite is a collection of powerful tools that you can use to manage your device features and data. Each component is a separate program that includes online help. Nokia PC Suite software, installation instructions, and other documentation, which are provided free of charge and can be downloaded

from the software downloads of the Nokia web site:
<http://www.nokia-asia.com>.

Some of the features in your device require network support. Contact your service provider for availability and configuration instructions.

- Nokia Image Converter makes images usable for multimedia messages or wallpapers and transfers them to your device.
- Nokia Sound Converter edits polyphonic ringing tones to be compatible with your device and transfers them to your device.
- Nokia Content Copier copies information or backs up information from your device to the PC or to another compatible Nokia device.
- Nokia Phone Editor sends text messages and edits the contact directory and message settings of your device.
- Nokia PC Sync synchronises the contacts directory and calendar between your device and a compatible PC.
- Nokia Connection Manager selects the connection type between the PC and the device.
- Nokia Phone Browser copies images and tones from your device to your PC and vice versa.

Copyright protection may prevent some images, ring tones, and other content from being copied, modified, transferred, or diverted.

14. Enhancements



Check the model number of any charger before use with this device. This device is intended for use when supplied with power from AC-3 or AC-4.



Warning: Use only batteries, chargers and enhancements approved by Nokia for use with this particular model. The use of any other types may invalidate any approval or warranty, and may be dangerous. For availability of approved enhancements, please check with your dealer.

Power:

- Standard Li-Ion Battery (BL-6C)
- Standard Travel Charger (AC-3)
- Travel Charger (AC-4)
- Mobile Charger (DC-4)
- Charger Adapter (CA-44)

A few practical rules about accessories and enhancements:

- Keep all accessories and enhancements out of the reach of small children.
- When you disconnect the power cord of any accessory or enhancement, grasp and pull the plug, not the cord.
- Check regularly that enhancements installed in a vehicle are mounted and are operating properly.
- Installation of any complex car enhancements must be made by qualified personnel only.

15. Battery information

■ Charging and discharging

Your device is powered by a rechargeable battery. The full performance of a new battery is achieved only after two or three complete charge and discharge cycles. The battery can be charged and discharged hundreds of times, but it will eventually wear out. When the talk and standby times are noticeably shorter than normal, replace the battery. Use only Nokia approved batteries, and recharge your battery only with Nokia approved chargers designated for this device.

If a replacement battery is being used for the first time or if the battery has not been used for a prolonged period, it may be necessary to connect the charger then disconnect and reconnect it to begin charging the battery.

Unplug the charger from the electrical plug and the device when not in use. Do not leave a fully charged battery connected to a charger, since overcharging may shorten its lifetime. If left unused, a fully charged battery will lose its charge over time.

If the battery is completely discharged, it may take a few minutes before the charging indicator appears on the display or before any calls can be made.

Use the battery only for its intended purpose. Never use any charger or battery that is damaged.

Do not short-circuit the battery. Accidental short-circuiting can occur when a metallic object such as a coin, clip, or pen causes direct connection of the positive (+) and negative (-) terminals of the battery. (These look like metal strips on the battery.) This might happen, for example, when you carry a spare battery in your pocket or purse. Short-circuiting the terminals may damage the battery or the connecting object.

Leaving the battery in hot or cold places, such as in a closed car in summer or winter conditions, will reduce the capacity and lifetime of the battery. Always try to keep the battery between 15°C and 25°C (59°F and 77°F). A device with a hot or cold battery may not work temporarily, even when the battery is fully charged. Battery performance is particularly limited in temperatures well below freezing.

Do not dispose of batteries in a fire as they may explode. Batteries may also explode if damaged. Dispose of batteries according to local regulations. Please recycle when possible. Do not dispose as household waste.

Nokia battery authentication guidelines

Always use original Nokia batteries for your safety. To check that you are getting an original Nokia battery, purchase it from an authorized Nokia dealer, look for the Nokia Original Enhancements logo on the packaging and inspect the hologram label using the following steps:

Successful completion of the four steps is not a total assurance of the authenticity of the battery. If you have any reason to believe that your battery is not an authentic original Nokia battery, you should refrain from using it, and take it to the nearest authorized Nokia service point or dealer for assistance. Your authorized Nokia service point or dealer will inspect the battery for authenticity. If authenticity cannot be verified, return the battery to the place of purchase.

Authenticate hologram


1. When looking at the hologram on the label, you should see the Nokia connecting hands symbol from one angle and the Nokia Original Enhancements logo when looking from another angle.



2. When you angle the hologram left, right, down, and up, you should see 1, 2, 3, and 4 dots on each side respectively.



3. Scratch the side of the label to reveal a 20-digit code, for example, 12345678919876543210. Turn the battery so that the numbers are facing upwards. The 20-digit code reads starting from the number at the top row followed by the bottom row.



4. Confirm that the 20-digit code is valid by following the instructions at www.nokiaoriginals.com/check.



Battery information

To create a text message enter the 20-digit code, for example, 12345678919876543210, and send to +44 7786 200276.

To create a text message,

- For countries in Asia Pacific, excluding India: Enter the 20-digit code, for example, 12345678919876543210, and send to +61 427151515.
- For India only: Enter Battery followed by the 20-digit battery code, for example, Battery 12345678919876543210, and send to 5555.

National and international operator charges will apply.

You should receive a message indicating whether the code can be authenticated.

If you need assistance confirming the battery code, contact your local Nokia Care Centres listed at www.nokia-asia.com/carecentrelocator.

What if your battery is not authentic?

If you cannot confirm that your Nokia battery with the hologram on the label is an authentic Nokia battery, please do not use the battery. Take it to the nearest authorized Nokia service point or dealer for assistance. The use of a battery that is not approved by the manufacturer may be dangerous and

may result in poor performance and damage to your device and its enhancements. It may also invalidate any approval or warranty applying to the device.

To find out more about original Nokia batteries, visit www.nokiaoriginals.com/battery.

Care and maintenance

Your device is a product of superior design and craftsmanship and should be treated with care. The suggestions below will help you protect your warranty coverage.

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will corrode electronic circuits. If your device does get wet, remove the battery, and allow the device to dry completely before replacing it.
- Do not attempt to remove the battery from the device. Nokia recommends that you take the device to the nearest authorised service facility for replacement of the battery.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in hot areas. High temperatures can shorten the life of electronic devices, damage batteries, and warp or melt certain plastics.
- Do not store the device in cold areas. When the device returns to its normal temperature, moisture can form inside the device and damage electronic circuit boards.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Use a soft, clean, dry cloth to clean any lenses, such as camera, proximity sensor, and light sensor lenses.
- Use only the supplied or an approved replacement antenna. Unauthorised antennas, modifications, or attachments could damage the device and may violate regulations governing radio devices.
- Use chargers indoors.
- Always create a backup of data you want to keep, such as contacts and calendar notes, before sending your device to a service facility.

All of the above suggestions apply equally to your device, battery, charger, or any enhancement. If any device is not working properly, take it to the nearest authorised service facility for service.

Additional safety information

Your device and its enhancements may contain small parts. Keep them out of the reach of small children.

■ Operating environment

Remember to follow any special regulations in force in any area and always switch off your device when its use is prohibited or when it may cause interference or danger. Use the device only in its normal operating positions. This device meets RF exposure guidelines when used either in the normal use position against the ear or when positioned at least 2.2 cm (7/8 inches) away from the body. When a carry case, belt clip or holder is used for body-worn operation, it should not contain metal and should position the device the above-stated distance from your body. In order to transmit data files or messages, this device requires a good quality connection to the network. In some cases, messages may be delayed until such a connection is available. Ensure the above separation distance instructions are followed until the transmission is completed.

■ Medical devices

Operation of any radio transmitting equipment, including wireless phones, may interfere with the functionality of inadequately protected medical devices. Consult a physician or the

manufacturer of the medical device to determine if they are adequately shielded from external RF energy or if you have any questions. Switch off your device in health care facilities when any regulations posted in these areas instruct you to do so. Hospitals or health care facilities may be using equipment that could be sensitive to external RF energy.

PACEMAKERS

Pacemaker manufacturers recommend that a minimum separation of 6 inches (15.3 cm) be maintained between a wireless device or phone and a pacemaker to avoid potential interference with the pacemaker. These recommendations are consistent with the independent research by and recommendations of Wireless Technology Research. To minimise the potential for interference, persons with pacemakers should

- Always keep the device more than 6 inches (15.3 cm) from their pacemaker when the device is switched on
- Not carry the device in a breast pocket
- Hold the device to the ear opposite the pacemaker to minimise the potential for interference.

If you have any reason to suspect that interference is taking place, switch off your device immediately.

HEARING AIDS

Some digital wireless devices may interfere with some hearing aids. If interference occurs, consult your service provider.

■ Vehicles

RF signals may affect improperly installed or inadequately shielded electronic systems in motor vehicles such as electronic fuel injection systems, electronic antiskid (antilock) braking systems, electronic speed control systems, air bag systems. For more information, check with the manufacturer or its representative of your vehicle or any equipment that has been added.

Only qualified personnel should service the device, or install the device in a vehicle. Faulty installation or service may be dangerous and may invalidate any warranty that may apply to the device. Check regularly that all wireless device equipment in your vehicle is mounted and operating properly. Do not store or carry flammable liquids, gases, or explosive materials in the same compartment as the device, its parts, or enhancements. For vehicles equipped with an air bag, remember that an air bags inflate with great force. Do not place objects, including installed or portable wireless equipment in the area over the air bag or in the air bag deployment area. If in-vehicle wireless equipment is improperly installed and the air bag inflates, serious injury could result.

FCC regulations prohibit using your wireless device while in the air. The use of wireless telephones in an aircraft may be dangerous to the operation of the aircraft, disrupt the wireless telephone network, and may be illegal.

■ Potentially explosive environments

Switch off your device when in any area with a potentially explosive atmosphere and obey all signs and instructions. Potentially explosive atmospheres include areas where you would normally be advised to turn off your vehicle engine. Sparks in such areas could cause an explosion or fire resulting in bodily injury or even death. Switch off the device at refuelling points such as near gas pumps at service stations. Observe restrictions on the use of radio equipment in fuel depots, storage, and distribution areas, chemical plants or where blasting operations are in progress. Areas with a potentially explosive atmosphere are often but not always clearly marked. They include below deck on boats, chemical transfer or storage facilities, vehicles using liquefied petroleum gas (such as propane or butane), and areas where the air contains chemicals or particles such as grain, dust or metal powders.

Failure to observe these instructions may lead to suspension or denial of telephone services to the offender, legal action, or both.

■ Emergency calls



Important: Wireless phones, including this device, operate using radio signals, wireless networks, landline networks, and user-programmed functions. Because of this, connections in all conditions cannot be guaranteed. You should never rely solely on any wireless device for essential communications like medical emergencies.

To make an emergency call, make sure your device is properly charged before attempting any emergency calls. If your battery becomes empty, you cannot receive or make calls, including emergency calls and must wait a few minutes after the charging begins to place your call.

1. If the device is not on, switch it on. Check for adequate signal strength. Some networks may require that a valid UIM (CDMA SIM) card is properly inserted in the device.
2. Press the end key as many times as needed to clear the display and ready the device for calls.
3. Enter the official emergency number for your present location, and press the call key. Emergency numbers vary by location

If certain features are in use, you may first need to turn those features off before you can make an emergency call. If the device is in an offline or flight mode you must change the

profile to activate the device function before you can make an emergency call. Consult this guide or your service provider. When making an emergency call, give all the necessary information as accurately as possible. Your wireless device may be the only means of communication at the scene of an accident. Do not end the call until given permission to do so.

■ Certification information (SAR)

THIS DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES

Your mobile device is a radio transmitter and receiver. It is designed and manufactured not to exceed the limits for exposure to radio frequency (RF) recommended by international guidelines (ICNIRP). These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The guidelines include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

The exposure standard for mobile devices employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit stated in the international guidelines is 2.0 watts/kilogram (W/kg)*. Tests for

SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR of the device while operating can be well below the maximum value. This is because the device is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a base station, the lower the power output of the device.

The highest SAR value for this device when tested for use at the ear is 0.86 W/kg.

SAR values may vary depending on national reporting and testing requirements and the network band. Use of device accessories and enhancements may result in different SAR values. Additional SAR information may be provided under product information at www.nokia-asia.com.

* The SAR limit for mobile devices used by the public is 2.0 W/kg averaged over 10 grams of body tissue. The guidelines incorporate a substantial margin of safety to give additional protection for the public and to account for any variations in measurements. SAR values may vary depending on

national reporting requirements and the network band. For SAR information in other regions, please look under product information at www.nokia-asia.com.

■ Battery information

This section provides information about battery charging times with the Travel Charger (AC-4) and the Standard Travel Charger (AC-3), talk and standby times. Be aware that the information in this section is subject to change. For more information, contact your service provider.

Charging times

The following charging times are approximate with the BL-6C Li-Ion battery:

Travel Charger (AC-4): Up to 1 hour 45 minutes

Standard Travel Charger (AC-3): Up to 3 hours 30 minutes

Talk and standby times

Operation times are estimates only and depend on signal strength, phone use, network conditions, features used, battery age and condition (including charging habits), temperatures to which the battery is exposed, and other factors.

Talk time: 3 to 4 hours (digital)

Standby time: 6 to 10 days

Index

A

- About your device vii
- Activate 59
- Activate a voice command 54
- Activate an equaliser set 44
- Activate or deactivate 14
- Alarm clock 61
- Alarm conditions 61
- Allow numbers 56
- Allow or block advertisements 24
- Allow or block multimedia reception 23
- An incoming call 10
- Answer a call with the keypad locked 11
- Antenna 6
- Anykey answer 49
- Application setting 58
- Assign a key to speed dial 35
- Assign a voice tag to a command 53
- Assign a voice tag to an entry 36
- Automate voicemail 27
- Automatic redial 49

B

- Back cover
 - removing 7
 - replacing 8
- Backlight timeout 48
- Batteries and chargers 76
- Battery
 - charging 8
 - charging times 83
 - information 76, 83
 - removing 7
 - replacing 7
 - talk and standby times 83
- Battery information 76
- Business cards 39

C

- Calculator 65
- Calendar 62
- Call and setup voice mail 27

- Call duration 31
- Call forwarding 59
- Call register 30
- Call restrictions 67
- Call settings 49
- Call summary 51
- Caller groups 35
- Calling card 50
- Calls
 - answering 10
 - in-call options 11
 - making 9
- Cancel 59
- Care and maintenance 79
- Certification information (SAR) 82
- Change default number 35
- Change message settings 20
- Change sending options 20
- Change speed dial numbers 36
- Change time 67
- Charger
 - connecting 8
 - information 76
 - times 83
- Choose a banner 48
- Choose Go to functions 5
- Clear the cache 72
- Clear voice mail icon 29
- Collections 69
- Colour schemes 48
- Compose and send 21
- Conference calling 10
- Configure settings 38
- Contacts list 10, 34
 - add 34
 - delete 38
 - edit 37
 - send 39
 - view 38
- Countdown timer 66
- Create a custom equaliser set 44
- Currency converter 66

D

- Data or fax calls 51
- Data transfer 51

- Date and time auto-update 49
- Date setting 48
- Delete all messages in a folder 19
- Delete speed dial numbers 36
- Deleting call registers 31
- Dial a number 36
- Dialling codes 28
- Display language 52
- Display settings 47, 48
- Distribution list 19
- DTMF tones 52

E

- Emergency calls 82
 - while using wireless Internet 71
 - with keypad locked 52
- Enhancement settings 54
 - handsfree 54
 - headset 54
 - loopset 55
 - music stand 55
- Enhancements 75
- Extras 69

F

- Factory settings 60
- Feature codes 59
- Folders 40

G

- Gallery 40, 42
- Games 69
- Get the most out of this guide 3
- Go to a date 62
- Go to functions 5

H

- Handsfree 54
- Hands-free operation 53
- Headset 9, 54
- HEARING AIDS 81
- Help text 4, 53

I

- Indicators and icons 2
- International prefix 51
- Interrupt timer 67

K

- Keypad 9
- Keypads 12
 - automatic 52
- Keys and parts 1

L

- Languages 52
- Lap and split times 68
- Last dialled number 10
- Listen to voice messages 27
- Lock code 56
- Loopset 55
- Loudspeaker 11

M

- Make calls 50
- Measure time 67
- Media equaliser 44
- Media player 42
- Medical devices 80
- Memory 52, 69
- Message folders 18
- Messages
 - delete 19
 - minibrowser messages 29
 - text messages 15
 - voice messages 27
- Minibrowser 70
- Minibrowser duration 33
- Minibrowser messages 29
- MMS folders 24
- MMS settings 23
- Mobile web 70
- Mode 58
- Multimedia messages 22
- Music stand 55

N

Network services vii, 59
Nokia battery authentication guidelines 77
Nokia PC Suite 74
Note a specific date 62
Notes 64
Numbers (123) 13

O

Open 62
Open fold to answer 50
Operating environment 80
Operation note 68
Options 43, 44, 54, 68
Options while viewing a list of notes 63
Organise functions 5
Organiser 61, 65
Other MMS settings 24

P

PACEMAKERS 80
PC connectivity 73
Personalise a profile 46
Phone at a glance 1
Phone keys 71
Phone lock 55
 change lock code 56
Phone menus 3
Phone numbers with dialling codes 28
Phone settings 52
Picture messages 21
picture messages 21
Potentially explosive environments 81
Power saver 48
Predictive text 13
Profiles 46

Q

Quick keys 2

R

Radio 42
Read multimedia messages 26
Receive and save 21

Receive notes 64
Record speech or sound 44
Repeat alarm 61
Reply to multimedia message 26
Restore factory settings 60
Retrieve or reject multimedia messages 23
Ringing tone for no caller ID 51
Roaming options 58

S

Safety vi
 important safety information 80
Save an entry 34
Save contact name and number 34
Save contact number only 34
Save information 50
Save messages 18
Save numbers and text items 34
Screen saver 48
Scrolling 4
Search for a name 38
Security feature 4
Security settings 55
Send a business card 39
Send a note 63
Set
 time 48
Set length 52
Set or change alarm setting 61
Set the alarm tone 61
Set the timer 66
Set type 52
Setting up phone 6
Settings 46
Shared memory viii
Snooze time-out 61
Speed dial 49
Speed dials 35
Standard mode 13
Standby mode 2
Start screen 2
Start-up tone 53
Stopwatch 67

T

Talk and standby times 83
Text (Abc) 13

- Text entry 13
 - predictive text 13
 - standard 13
- Text messages 15
- Themes 47
- Time and date settings 48
- Timed profiles 46
- To-do list 64
- To-do note
 - add 64
 - view 65
- Tone settings 47, 58
- Transfer with Windows Explorer 73
- Tune and save a radio channel 43
- Turn an alarm off 62
- turn phone off 9
- Turn phone on 9
- Turn the radio on and off 42

U

- UIM card slot 7
- USB data transfer 73

V

- Vehicles 81
- View
 - call duration 31
 - call times 31
 - data/fax call duration 32
 - dialled numbers 31
 - minibrowser duration 32
 - missed calls 30
 - received calls 30
 - saved messages 18
 - to-do note 65
- View notes (day view) 62
- Voice dialling 36, 53
- Voice messages 27
- Voice privacy 57
- Voice recorder 43
- Voice tags 37
- Voicemail 27
- Volume
 - adjusting 11
 - using the loudspeaker 11

W

- Wallpaper 47
- Wireless Internet 70
 - make an emergency call 71
 - receive a call while online 71
 - sign off 72
 - sign on 71
- Write and send multimedia messages 24
- Write down voice mailbox number and process 28