

ASSEMBLY GUIDE

HORIZON T30 & T40



Parts

- 1 Power Cord
- 1 Safety Key
- 2 Water Bottle Holders
- 1 Hardware Pack (contents listed below)


Tools (included)

- 5mm Allen Wrench/Phillips Screw Driver
- Flat Wrench
- 8mm Allen Wrench
- or
- 6mm Allen Wrench


H A R D W A R E




B) 16mm Washer
Quantity: 2





C) 13mm Nut
Quantity: 2




D) Arc Washer
Quantity: 2




A) 60mm Bolt
Quantity: 2




E) 20mm Bolt
Quantity: 4




= Tighten




1. LIFT CONSOLE MAST INTO UPRIGHT POSITION.



2. SET CONSOLE INTO PLACE.



3. TIGHTEN PRE-INSTALLED BOLTS.



4. SAFETY KEY



U N P A C K I N G

Take caution when handling and transporting this unit. Never open box when it is on its side. Once the banding straps have been removed, do not lift or transport this unit unless it is fully assembled and in the upright folded position, with the lock latch secure. Unpack the unit where it will be used. The enclosed treadmill is equipped with high-pressure shocks and may spring open if mishandled. See owner's guide for reference. **FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY!** Place your treadmill on a level flat surface. It is recommended that you place a protective covering on your floor.

NOTE: It is recommended that you apply grease to the threads of each bolt as you assemble your treadmill, to prevent loosening and noise. Also, during each assembly step, ensure that ALL nuts and bolts are in place and partially threaded in before completely tightening any ONE bolt.