



J100i

Sony Ericsson

This is the Internet version of the user's guide © Print only for private use.

Contents

Getting to know your phone	3
Assembling your phone	7
Navigating the phone menus	10
Calling	14
Phonebook	23
Messaging	25
Sounds & Alerts	31
Alarms	33
Games	34
Settings	35
Locks	38
Extras	41
Troubleshooting	42
Important information	51
Index	66

You can find more support and information at
www.SonyEricsson.com/support.

Sony Ericsson

GSM 900/1800

This user guide is published by Sony Ericsson Mobile Communications AB, without any warranty. Improvements and changes to this user guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by Sony Ericsson Mobile Communications AB at any time and without notice. Such changes will, however, be incorporated into new editions of this user guide.

All rights reserved.

© **Sony Ericsson Mobile Communications AB, 2005**

Publication number: EN/LZT 108 8208 R1A.

Please note:

Some of the services in this user guide are not supported by all networks. *This also applies to the GSM International Emergency Number 112.*

Please contact your network operator or service provider if you are in doubt whether you can use a particular service or not.

Please read the *Guidelines for safe and efficient use* and the *Limited warranty* chapters before you use your mobile phone.

T9™ Text Input is a trademark or a registered trademark of Tegic Communications.

T9™ Text Input is licensed under one or more of the following:
U.S. Pat. Nos. 5,818,437, 5,953,541, 5,187,480, 5,945,928, and 6,011,554;

Canadian Pat. No. 1,331,057;

United Kingdom Pat. No. 2238414B;

Hong Kong Standard Pat. No. HK0940329;

Republic of Singapore Pat. No. 51383;

Euro. Pat. No. 0 842 463 (96927260.8) DE/DK, FI, FR, IT, NL, PT, ES, SE, GB; and additional patents are pending worldwide.


Other product and company names may be the trademarks of their respective owners.

Sony Ericsson advises users to backup their personal data information.

All illustrations are for illustration only and may not accurately depict the actual phone.

Any rights not expressly granted herein are reserved.

Getting to know your phone



- | | |
|-------------------------------|--|
| 1 Strength of GSM network | 6 Stereo headset and battery charger connector |
| 2,8 Function of selection key | 7 Battery status |
| 3,9 Selection keys | 10 Navigation key with shortcuts |
| 4 Call key | 11 End/Clear and Power on/off key |
| 5 Keylock | |

Before you start

Before you can use your phone you need to:

- Insert the SIM card.
- Attach and charge the battery.

User guide symbols

The following instruction symbols appear in this user guide:

- ➡ This arrow points you to a page with more information.
- ▶ Use the navigation key to scroll and select.




Note



This symbol indicates that a service or function is network- or subscription-dependent. Because of this, all menus may not be available in your phone. Please contact your network operator for more information.

Keypad



- Press keypad Centre  to go to the main menu.
- Press Left  Right  Up  Down  to navigate.
- Press  to select the options shown immediately above these keys on the display.

To end a function or go back one level

- Press  to go back one level in the menus.
- Press  to end a function.
- Press  to correct mistakes.

Shortcuts

From standby, you can use the navigation keys to go directly to a function:

- Press  to write a text message.
- Press  to select ring style.
- Press  to set an alarm.
- Press  to go to the phonebook.

SIM card

When you register as a subscriber with a network operator, you get a SIM (Subscriber Identity Module) card. The SIM card keeps track of your phone number, the services included in your subscription, and your phonebook information, among other things.



If you have been using a SIM card in another phone, make sure that your information is saved to the SIM card before you remove it from the other phone.

PIN (Personal Identification Number)

You may need a PIN (Personal Identification Number) from your network operator to activate the services in your phone.

Each PIN digit appears as *, unless it starts with emergency number digits, for example 112. This is so that you can see and call an emergency number without entering a PIN

➡ *16 Emergency calls.* Press  to correct mistakes.





*If you enter the wrong PIN three times in a row, the SIM card is blocked and the message **PIN blocked** appears. To unblock it, you need to enter your PUK (Personal Unblocking Key) ➡ 38 Locks.*

Assembling your phone


Insert the SIM card, attach and charge the battery and turn on your phone.

Insert the SIM card and battery



- 1** Gently pull the cover away from the phone.
- 2** Insert the SIM card. Make sure the SIM card is placed under the silvery holders.
- 3** Place the battery on the back of the phone with the label side up and the connectors facing each other.
- 4** Replace the cover as shown in the picture.

Charge the battery



- 1** Connect the charger to the phone. The red battery charging lamp is on during charging.
- 2** It may take up to 30 minutes before the battery icon appears on the display.
- 3** Wait approximately 2.5 hours or until the battery icon indicates that the battery is fully charged. If you do not see the battery icon after this time, press any key above the number keys to activate the display.
- 4** Remove the charger by pulling it out.



The time and date are reset when you remove the battery.

Turn the phone on or off



- 1 Press and hold  to turn the phone on or off.
- 2 Enter your PIN number, if requested ► **OK**.
- 3 When asked to set the time and date ► **OK**.
- 4 Enter the time and date ► **Save**.
- 5 Press  to exit the setup menu.



If the display turns dark when you enter your PIN number, press the right  key to illuminate the display. Press  to delete entered characters.

Standby mode


After you have turned the phone on and entered your PIN, the name of the network operator will appear on the display. This is called standby mode – you can now make and receive calls.

➡ *36 Networks* for details.

Navigating the phone menus




From standby, press  to go to the main menu.




Messaging is the first menu you will see.
Press up  or down  to scroll through the menus.

To turn the display light on

Press any key above the number keys to turn the display light on.



To lock or unlock the keypad



Lock the keypad to avoid dialling a number by accident:

- To lock the keypad, press  ► **Lock**.
 - To unlock the keypad, press  ► **Unlock**.
- ➡ 38 Locks for more information.

Icons

These icons appear on the display to show status and new events.

Icon	Description
	Shows the strength of the GSM network signal. ➡ <i>36 Networks</i>
	Shows the battery status. ➡ <i>7 Assembling your phone</i>
	You have missed a call. ➡ <i>14 Calling</i>
	You have received a new text or voice* message. ➡ <i>25 New message</i>
	The phone is in silent mode. ➡ <i>31 Sounds & Alerts</i>
	The keypad is locked. ➡ <i>38 Locks</i>
	An alarm is activated. ➡ <i>33 Alarms</i>
	*Line 1 is active. ➡ <i>19 Two voice lines</i>
	*Divert calls is activated. ➡ <i>16 Diverting calls</i>

For more information, see www.SonyEricsson.com/support.

* Some items may be operator-, network- and subscription-dependent.

Menu overview

	Messaging	Write new Inbox Call voicemail Drafts Outbox Templates Area info Settings
	Call list	Missed calls Dialled calls Answered calls
	Sounds & alerts	Ringtone Ring style Ring volume Key sound Message alert Alarm signal
	Alarms	Alarms
	Games	Ball Memory
	Settings	Display Time and date Language Locks Calls Network Master reset
	Extras	Calculator Stopwatch
	Phonebook	

Some additional operator-, network- and subscription-dependent menus may occur.

Calling

Making and receiving calls

Turn on the phone and make sure you are within range of a network to make and receive calls ➡ *9 Turn the phone on or off.*

If your subscription includes the Calling Line Identification service and the caller's number is identified, the number is displayed. If you have saved the number in the phonebook, the name is displayed with an incoming call.

To make a call



- 1 Enter the area code and phone number.
- 2 Press  to call. Press  to end the call.

To answer a call

Press  to answer a call.


Press  to reject a call.

 *You can also press Answer or Reject.*

To turn off the ringtone when receiving a call

Press left  right  up  or down  on the navigation key to turn off the ringtone when receiving a call.

To change the speaker volume during a call



Press to increase the volume and to decrease the volume.

Do not hold the phone to your ear when using high ringtones as this can damage your hearing.

To select more options during a call

► More and select an option.

To make international calls

- 1 Press and hold until a + sign appears on the display.
- 2 Enter the country code, area code (without the leading zero), phone number and press .

To put a call on hold

- Hold during a call to put it on hold.
- Resume to resume the call.

To turn off the microphone during a call

- 1 ► More ► Mute to turn off the microphone during a call.
- 2 ► Unmute to resume.

To check your missed calls

- 1 When Missed calls is displayed, ► View to display the missed calls.
- 2 To call a number, scroll to the number and press .

Call list

Information about the last 10 calls is saved in **Call list**.

To call a number from the call list

- 1 Press  from standby and select one of the call lists.
- 2 Scroll to the name or number and press .

To clear a number from a call list

- 1 ► **Call list** and select a call list.
- 2 Select a number ► **More** ► **Delete** ► **Yes**.

Emergency calls

Your phone supports the international emergency numbers, for example 112 and 911. This means that these numbers can normally be used to make an emergency call in any country, with or without a SIM card inserted, if a GSM network is in range.



In some countries, your network operator may have saved additional local emergency numbers on the SIM card.

To make an emergency call

Dial, for example, 112 and press .

Diverting calls

If you cannot answer incoming calls, you can divert them to another number, for example, your answering service.



*When the **Restrict calls** function is activated, some **Divert calls** options are not available.*

To activate a call divert

- 1 ▶ Settings ▶ Calls ▶ Manage calls ▶ Divert calls ▶ Voice calls.
- 2 Select one of the divert options ▶ **Activate**.
- 3 Enter the phone number you want your calls to be diverted to, or ▶ **Look up** to find the contact.
- 4 ▶ **OK**.

To deactivate a call divert

Scroll to the divert option ▶ **Cancel**.

Call waiting service

When call waiting is activated, you hear a beep if you receive a second call.

To activate or deactivate the call waiting service

- 1 ▶ Settings ▶ Calls ▶ Manage calls ▶ Call waiting.
- 2 Select **On** or **Off**.

Receiving a second call

When call waiting is activated and you receive a second call, you can:

- ▶ **Answer** and put the ongoing call on hold.
- ▶ **Reject** to reject and continue the ongoing call.

Handling two calls

If you have an ongoing call and a call on hold, you can:

- ▶ **Switch** to switch between the two calls.
- ▶ **More** ▶ **Join calls** to join the two calls.
- Press  to end the current call.
- ▶ **More** ▶ **End call on hold** to end the held call.
- ▶ **More** ▶ **Transfer call** to connect the two calls. You are disconnected from both calls.

- Press  twice to end both calls.
- You cannot answer a third call without ending one of the first two calls or joining them into a conference call.

 *Contact your network operator to check if this function is supported.*

To make a second call

- 1 ▶ Hold to put the ongoing call on hold.
- 2 Enter the number you want to call and press .
- 3 Press  to end the second call.
- 4 ▶ Resume to continue the first call.

Conference calls

In a conference call you can talk to more than one person at the same time. A conference call is started by joining an ongoing call and a call on hold. You then put the conference on hold to call and add up to six participants or just to make another call.

To join the two calls into a conference call

- ▶ More ▶ Join calls.

To add a new participant

- 1 ▶ Hold to put the joined call on hold.
- 2 Call the next person.
- 3 ▶ More ▶ Join calls to add a new participant.
- 4 Repeat steps 1-3 to include more participants.

To have a private conversation

- 1 ▶ More ▶ Talk to and select the participant.
- 2 ▶ More ▶ Join calls to resume the conference call.

Two voice lines

Separate business and private calls on two lines with different numbers if your subscription supports alternate line service.



This service is network- and subscription-dependent.

To select a voice line

► Settings ► Calls ► Manage calls ► Switch to line 1 or Switch to line 2.

My number

You can view and edit your own phone number(s).

To check your own phone number

- 1 ► Phonebook and scroll to any entry.
- 2 ► More ► Advanced ► My number. If your number is not saved on your SIM card, you can enter it yourself.

Restricted dialling

Restrict outgoing and incoming calls when at home or abroad. You need a password from your service provider.



If you divert incoming calls, you can not activate some restricted dialling options.

To activate call restriction

- 1 ► Settings ► Calls ► Manage calls ► Restrict calls and select an option.
- 2 Enter your password ► OK.
The following calls can be restricted:
 - **Outgoing intl** – All outgoing international calls.
 - **Outg.int.roam** – All outgoing international calls except to your home country.

- All – All outgoing calls.
- Inc. if roam – All incoming calls when you are abroad (when roaming).
- All calls – All incoming calls.

To cancel all call restrictions

- 1 ▶ Settings ▶ Calls ▶ Manage calls ▶ Restrict calls
▶ Cancel all.
- 2 Enter your password ▶ OK.

Fixed dialling

The fixed dialling function allows calls to be made only to certain numbers saved on the SIM card. The fixed numbers are protected by your PIN2.



This service is network- and subscription-dependent.

Partial numbers can be saved. For example, saving 0123456 allows calls to be made to all numbers starting with 0123456.



When fixed dialling is activated, you cannot view or manage any phone numbers saved on the SIM card.

To activate fixed dialling

- 1 ▶ Settings ▶ Locks ▶ Fixed dialling ▶ Activate.
- 2 Enter your PIN2 ▶ OK.

To save a fixed number

- 1 ▶ Settings ▶ Locks ▶ Fixed dialling ▶ Fixed number.
- 2 Enter the information.
- 3 Enter your PIN2 ▶ OK.



You can still call the international emergency number 112, even when the fixed dialling function is activated.

Call time and cost

During a call, the duration of the call is shown. If you subscribe to cost information, you can check the duration of your last call, outgoing calls and the total time.



If you subscribe to cost information, you must enter your PIN2 to reset the cost counter.

To check the call time

► Settings ► Calls ► Time and cost ► Call timers.

To check the call cost

► Settings ► Calls ► Time and cost ► Call costs.

To reset the call cost meter

- 1 ► Settings ► Calls ► Time and cost ► Call costs ► Reset all.
- 2 Enter your PIN2 ► OK.

Credit limit for calls

Enter a credit limit for making calls. When there are zero units, no more calls can be made.

To check available call credit

► Settings ► Calls ► Time and cost ► Call costs ► Credit.

To set a credit limit

- 1 ► Settings ► Calls ► Time and cost ► Call costs ► Set credit.
- 2 Enter your PIN2 ► OK.
- 3 Select **Change** and enter the units ► OK.

Showing or hiding your phone number

If your subscription supports CLIR (Calling Line Identification Restriction), you can hide your phone number when making a call.

To show or hide your phone number

- 1** ▶ Settings ▶ Calls ▶ Caller ID.
- 2** Select Hide number, Show no. or Netw. default.

Phonebook

You can save names and numbers in the **Phonebook**, which is stored on the SIM card.

To add a contact



- 1 Press  ► **New contact** ► **Select**.
- 2 Enter the name ► **Cont**.
- 3 Enter the number ► **Save**.

To call a contact from the phonebook

- 1 Press .
- 2 Scroll to, or enter the first few letters of the contact you want to call.
- 3 Select the contact and press .

To edit a contact

- 1 ► **Phonebook** and select a contact.
- 2 ► **More** ► **Edit contact**.
- 3 Edit the information ► **Save**.

To delete a contact

- 1 ► **Phonebook** and select a contact or number.
- 2 ► **More** ► **Delete contact** ► **Yes**.



Enter the + sign and country code with all phonebook numbers. They can then be used abroad or at home
➡ 15 To make international calls.

Phonebook memory

The number of entries you can save in your phonebook depends on the capacity of your SIM card.

To check the Phonebook memory status

- 1 ▶ Phonebook and scroll to any entry.
- 2 ▶ More ▶ Advanced ▶ Memory status.

Vicemail

If your subscription includes an answering service, callers can leave a voice message when you cannot answer a call.

To call your voicemail service

From standby, press and hold , if you have saved your voicemail number in the phone. You can get the number from your service provider.

To enter your voicemail number

- 1 ▶ Messaging ▶ Settings ▶ Voicemail no.
- 2 Enter the voicemail number ▶ OK. You can get the number from your service provider.

Messaging

Your phone supports various messaging services. Contact your service provider about the services you can use or for more information, see www.SonyEricsson.com/support.

Before you start



If the number to your service centre is not saved on your SIM card, you must specify the number yourself, otherwise you cannot reply to received messages or send your own. Your service centre number is usually provided with your SIM card. If you do not have your service centre number, please contact your service provider.

To check or add a service centre number

- 1 ▶ **Messaging** ▶ **Settings** ▶ **Text message** ▶ **Serv. centre no**: The number is shown if it is saved on the SIM card.
- 2 If there is no number, enter it, including the international “+” sign and country code ▶ **OK**.

Text messages

Text messages can be sent to a mobile phone number or to a contact in your phonebook.

New message

A message icon  appears on your display when you receive a new text message or voice message ▶ **Read**.

Inbox

New messages are saved in your **Inbox**.

To read new messages

- ▶ **Messaging** ▶ **Inbox**.

Entering letters and characters

When writing messages there are two methods to enter letters and characters:

- Multitap text input
- T9™ Text Input

To change writing method

Before, or while entering letters, press and hold  to switch between Multitap and T9™ text input.

To write and send a text message



- 1 Press  from standby.
- 2 Write your message ► **Cont.**
- 3 Enter the recipient's number, or ► **Contact** to add it from a contact in the phonebook.
- 4 ► **Send** ► **Yes**.

To enter letters using multitap text input

- Press  –  until the desired character appears.
- Press  to add a space.
- Press  for comma, period, question mark, etc.
- Press  to shift between capitals and lower case letters.
- Press  to enter the + sign.

- Press and hold  –  to enter numbers.
- Press  to erase one character at a time.
- Press and hold  to quickly erase characters.
- Press and hold  to change text input method.
- Press and hold  to change language.

T9™ Text Input

The T9™ Text Input method uses a dictionary to recognize words. You press each key only once, even if the letter you want is not the first letter on the key.

To enter letters using T9 Text Input

- 1 ► **Messaging ► Write new.**
- 2 For example, to write the word “Jane”, press , , , .
- 3 If the word shown is the one you want, press  to accept and add a space. To accept a word without adding a space, press . If the word shown is not the one you want, press  or  repeatedly to view alternative words. Accept a word and add a space by pressing .
- 4 Continue writing your message. To enter a full stop or other punctuation marks, press  and then  or  repeatedly. Accept a word and add a space by pressing .
 - Press  to erase one character at a time.
 - Press and hold  to quickly erase characters.
 - Press and hold  to change text input method.
 - Press and hold  to change language.

To view options when entering letters

- **More** to view options when entering letters.
- **Add symbol** – Use , , ,  to move through symbols.
- **National char.** – Turn off language-specific characters to save space. This option appears only for some writing languages.

- **Dictionary (T9)** – Turn T9 text input on or off.
- **Writing lang.** – A list of available languages is shown.

To enter symbols in a text message

- 1 While writing the text message, ► **More** ► **Add symbol**.
- 2 Scroll to a symbol ► **Insert**.

To change writing language

- 1 ► **More** ► **Writing lang.**
- 2 Select a language.

Drafts

Messages that you do not wish to send immediately can be saved in **Drafts**. Messages that fail to be sent are also saved in **Drafts**.

To write a text message and save it as a draft

- 1 Press  from standby.
- 2 Write your message ► **Cont.**
- 3 Enter the recipient's number, or ► **Contact** to add it from a contact in the phonebook.
- 4 ► **Send** ► **No** ► **Save in Drafts**.

Outbox

Sent messages are saved in the outbox. The oldest item will be deleted when the outbox is full.

To save a phone number from a text message

- 1 In the text message ► **More** ► **Save** ► **Phone number**.
- 2 Select the number ► **Save**.
- 3 Enter a name for the contact ► **Cont.** ► **Save**.

To delete a message

- 1 ▶ **Messaging** and select a folder.
- 2 Select the message ▶ **More** ▶ **Delete** ▶ **Yes**.

To delete all messages

- 1 ▶ **Messaging** and select a folder.
- 2 ▶ **More** ▶ **Delete all** ▶ **Yes**.

Long messages

The number of characters allowed in a text message depends on the language you are writing in. Long messages are sent by automatic linking of two or more messages. You are charged for each of the messages linked in a long message. You may not receive all parts of a long message at the same time.



Check with your service provider for the maximum number of messages that can be linked.

Templates

Base your message on the predefined templates. You can also add new templates.

To use a message template

- 1 ▶ **Messaging** ▶ **Templates**.
- 2 Select the template you want to use ▶ **Send**.
- 3 Edit the template, select the recipient then send it by pressing **Yes**.

To create a template

- 1 ▶ **Messaging** ▶ **Templates** ▶ **[New templ]**
- 2 Write the message ▶ **OK**.



To create a template of your own you may need to delete one of the predefined templates in the phone.

To delete a template

- 1 ▶ Messaging ▶ Templates.
- 2 Select the template you want to delete ▶ More ▶ Delete.

Message options

The phone supports different types of messages. Your service provider may convert text message into a format (fax, for example) that suits the equipment that is going to receive the message.

To set a default message type

- ▶ Messaging ▶ Settings ▶ Text message ▶ Reply type: and choose an option.

To check the delivery status of a sent message

- 1 ▶ Messaging ▶ Outbox and select a text message.
- 2 ▶ More ▶ Message status.

Area information

Area information is a type of text message (for example, a local traffic report) that is sent to all subscribers within a certain network area.



Please contact your service provider for more information about area information.

To turn area information on or off

- 1 ▶ Messaging ▶ Settings ▶ Area info ▶ Service:.
- 2 Select On or Off.

Sounds & Alerts

Your phone comes with a number of standard and polyphonic melodies which can be used as ringtones.

To select a ringtone

► Sounds & alerts ► Ringtone.

To set the ringtone volume

1 ► Sounds & alerts ► Ring volume.

2 Press  to increase the volume and  to decrease the volume.

3 ► Save.



Do not hold the phone to your ear when using high ringtones as this can damage your hearing.

To turn the keypress sound on and off

1 ► Sounds & alerts ► Key sound.

2 Select On or Off.

Sounds and alerts options


Under **Sounds & alerts** you can also set these options:

- **Ring style** – set the ring style to silent or vibrate.
- **Message alert** – select message notification signal.
- **Alarm signal** – select alarm signal.

Ring styles

Set the ring style to silent or vibrate. Press  from standby for quick access to this menu.

To set the ringtone to silent



- 1 Press  from standby.
- 2 ► Silent ► Select.

To set the vibrating alert

- 1 Press  from standby.
- 2 ► Vibr. & ring or Vibrate only ► Select.

Alarms

You can add up to three alarms over a 24 hour time period. The alarm rings even if the phone is set to silent or turned off.

To set an alarm



- 1 Press  from standby.
- 2 Scroll to an entry ► **Select**.
- 3 Enter the time ► **OK**.
- 4 Enter an alarm name ► **Save**.

To turn an alarm off

- When it rings ► **Disable**.
- ► **Snooze** to snooze for 9 minutes. Snooze is automatically turned on if you do not press a key.

To enable or disable an alarm

- 1 ► **Alarms** and scroll to an entry.
- 2 ► **Enable** or **Disable**.

To select an alarm signal

- **Sounds & alerts** ► **Alarm signal**.

Games

Your phone comes with several games. Information and games controls are given in help texts for each game.

To start and end a game

- 1** ▶ **Games** and select a game ▶ **Start**.
- 2** Press  to end the game.
- 3** ▶ **Help** to read help texts.

Settings

Screen saver and wallpaper

Your phone comes with a predefined screen saver and wallpapers. The screen saver activates when in idle mode for a few seconds, to save power. You can change the appearance of the display by using wallpapers.

To activate the screen saver

▶ Settings ▶ Display ▶ Screen saver.

To select a wallpaper

▶ Settings ▶ Display ▶ Wallpaper.

To adjust the display contrast

- ▶ Settings ▶ Display ▶ Contrast.
- Press  to increase the contrast and  to decrease the contrast.
- ▶ Save.

Time and date

To set the time

- ▶ Settings ▶ Time and date ▶ Set time.
- Enter the time ▶ Save.

To set the time format

- ▶ Settings ▶ Time and date ▶ Set time.
- ▶ Format and select an option ▶ Save.

To set the date

- ▶ Settings ▶ Time and date ▶ Set date.
- Enter the date ▶ Save.

To set the date format

- 1 ▶ Settings ▶ Time and date ▶ Set date.
- 2 ▶ Format and select an option ▶ Save.

Handsfree

When using a portable handsfree and the handsfree setting is activated, you can choose to answer a call by pressing any key (except the  key), or setting the phone to answer the call automatically.

To select handsfree answering mode

- 1 Settings ▶ Calls ▶ Handsfree.
- 2 Select Normal, Any key or Automatic.

Networks

When you turn on the phone, it automatically selects your home network. If your home network is not within range, you may use another network, provided your network operator allows it. You can select the network you want to use, or you can add a new network to your list of preferred networks.

➡ 42 *Troubleshooting* for more information about networks.

To view available network options

- ▶ Settings ▶ Network.

To start an automatic network search

- 1 ▶ Settings ▶ Network ▶ New search.
- 2 The phone searches for a network according to the list of preferred networks saved on your SIM card.

To select a network

- 1 ▶ Settings ▶ Network ▶ Select network.
- 2 Select a network.

To add a preferred network

- 1 ▶ Settings ▶ Network ▶ Preferred nets ▶ New network ▶ Add.
- 2 Select a network operator from the list and set its priority level ▶ OK. Contact your network operator for details.

Master reset

You can reset all the settings in the phone to the way they were when you bought your phone by performing a master reset. All changes that you have made to settings are deleted.

To reset the phone

- 1 ▶ Settings ▶ Master reset.
- 2 Enter the phone lock code (0000 or a new code).
- 3 ▶ OK.

Languages

Select the language for phone menus or the languages that you may use when writing. Most SIM cards automatically set the language used in the menu to the language of the country where you bought your SIM card. If this is not the case, the predefined language is English.

To change the phone language

▶ Settings ▶ Language and select a language.



You can change the phone language to English by pressing (#) 0000 (#) in standby.

To select writing language

➡ 28 To change writing language.

Locks

Phone lock

The phone lock protects the phone against unauthorized use if it is stolen and the SIM card is exchanged. You can change the phone lock code (which is 0000 by default) to any four-digit personal code.

To unlock the phone

If the phone lock is on, enter your code ► OK.

Automatic phone lock

If the phone lock is set to automatic, you do not need to enter your phone lock code until a different SIM card is inserted in the phone.



It is important that you remember your code. If you should forget it, you have to hand in your phone to your local Sony Ericsson retailer.

To turn the phone lock code on or off

- 1 ► Settings ► Locks ► Phone lock ► Protection and select an alternative.
- 2 Enter the phone lock code ► OK.

To edit your phone lock code

► Settings ► Locks ► Phone lock ► Change code.

Keypad lock

Lock the keypad to avoid dialling a number by accident. You can still answer an incoming call and the keypad locks again after it. ► 11 To lock or unlock the keypad.

Automatic keylock

Automatic keylock in standby means the keypad is locked a short while after you last press a key.

To set the automatic keylock

- 1 ▶ Settings ▶ Locks ▶ Auto keylock.
- 2 Select On or Off.



Calls to the international emergency number 112 can still be made, even when the keypad is locked.

SIM card lock

The SIM card lock protects your subscription, but not your phone itself, from unauthorized use. If you change SIM cards, the phone still works with the new SIM card.

Most SIM cards are locked at the time of purchase. If the SIM card lock is on, you have to enter a PIN (Personal Identity Number) every time you turn on your phone.

If you enter your PIN incorrectly three times in a row, the SIM card is blocked. This is indicated by the message **PIN blocked**. To unblock it, you need to enter your PUK (Personal Unblocking Key). Your PIN and PUK are supplied by your network operator. You can edit your PIN and turn off your SIM card lock at any time.



If the message Passwords do not match appears when you edit your PIN, you entered the PIN or PIN2 incorrectly.

To unblock your SIM card

- 1 When **PIN blocked** is displayed, enter your PUK ▶ OK.
- 2 Enter a new four- to eight-digit PIN ▶ OK.
- 3 Re-enter the new PIN to confirm ▶ OK.

To turn the SIM card lock on or off

- 1 ▶ Settings ▶ Locks ▶ SIM lock ▶ Protection and select On or Off.
- 2 Enter your PIN ▶ OK.

To edit your PIN

- 1 ▶ Settings ▶ Locks ▶ SIM lock ▶ Protection and select On.
- 2 Enter your PIN ▶ OK.
- 3 ▶ Settings ▶ Locks ▶ SIM lock ▶ Change PIN.
- 4 Enter your PIN ▶ OK.
- 5 Enter a new four- to eight-digit PIN ▶ OK.
- 6 Re-enter the new PIN to confirm ▶ OK.

To edit your PIN2

- 1 ▶ Settings ▶ Locks ▶ SIM lock ▶ Change PIN2.
- 2 Enter your PIN2 ▶ OK.
- 3 Enter a new four- to eight-digit PIN ▶ OK.
- 4 Re-enter the new PIN to confirm ▶ OK.

Extras

Calculator

The phone has a built-in calculator, which can add, subtract, divide and multiply.

To use the calculator

1 ▶ Extras ▶ Calculator.

2 Enter digits with the keypad, then press:

-  or  to get \div , \times , $-$, $+$, a *decimal point*, $\%$ or $=$.
-  to enter a decimal point.
-  to delete the figure.
- ▶ More ▶ Save to save to memory.
- ▶ More ▶ + / - to change between positive and negative values.
- ▶ More ▶ Retrieve to retrieve from memory.
- ▶ More ▶ Clear memory to clear the memory.

Stopwatch

Your phone has a stopwatch that can save several laps. The stopwatch is turned off when you answer an incoming call or when you exit the stopwatch menu.

To use the stopwatch

▶ Extras ▶ Stopwatch ▶ Start.


- ▶ Stop to stop.
- ▶ Lap to start a new lap.
- ▶ Reset to reset the stopwatch.

Troubleshooting

Some problems require that you call your service provider, but most of the problems you can easily correct yourself. Remove the SIM card before handing your phone in for repair.

Remove the battery and restart the phone

If you have not restarted the phone for a while, you may experience problems with its memory capacity and speed. Restart the phone to improve its capacity.



- 1 Turn the phone off and remove the battery cover.
- 2 Remove the phone battery and then put it back in place.
- 3 Replace the cover.
- 4 Turn the phone on.

Master reset

If you experience problems with your phone such as display flickering or freezing, navigation problems, etc. you should reset the phone:


- 1** ▶ **Settings** ▶ **Master reset**.
- 2** Enter the phone lock code (which is *0000* by default or the new code if you have changed it) ▶ **OK**.

Common questions

Q: I can not turn the phone on.

A: Charge the phone until it has finished charging.

Make sure that the phone is charged. Attach the charger and charge the phone for 2.5 hours. The battery icon may not appear until the phone has charged for 30 minutes.




A green battery means the phone battery is fully charged. A white battery means the phone battery is empty.

Q: I can not charge the phone.

A: Attach the charger properly.

Look carefully at the picture to see how to attach the charger and charge the phone.



Q: How do I change phone language?

A: Go to Settings ► Language and select a language.

Q: What is my phone lock code?

A: The default phone lock code is 0000.

The phone lock protects the phone against unauthorized use if it is stolen and the SIM card is exchanged. You can change it to any four-digit personal code under ► Settings ► Locks ► Phone lock ► Change code.

Q: How do I turn on and off T9 text input when writing a text message?

A: Press and hold  when entering text.

You will see “T9” at the top of the text message when T9 is activated.


Q: It says No service in the display.

A: Try calling from a different location.

No service means that the phone's radio receiver is not picking up a signal from an operator. This may be a problem with your location. Move to a location where you have received

good network coverage earlier. You will get better network coverage outdoors.

Five blue bars mean full network coverage



Q: It says *Emerg. only* in the display.

A: Try calling from a different location.

When the display shows *Emerg. only*, your phone is OK, but you are having problems accessing your own network. Change location and see if the message disappears. ➡ *36 Networks* for details.

Q: It says Insert SIM card in the display.

A: Remove the SIM card and clean it.

Insert SIM card means that the phone has no contact with the SIM card in the phone.

- Remove the battery and the SIM card, and clean the connectors on the SIM card and the phone with an eraser.
- Check if the card is damaged or worn; if so the SIM card connector may not align with the phone connector.
- Contact your network operator to obtain a new SIM card.

Q: The phone turns itself off.

A: Use the automatic key lock.

If your phone turns itself off when being transported, something in your pocket or bag has probably activated the on/off key.

Turn on the automatic key lock function. ➔ 39 *To set the automatic keylock.*

Q: How do I set up SMS/Text messages?

A: Check the service centre number in the phone.

If the number to your service centre is not saved on your SIM card, you must specify the number yourself, otherwise you cannot reply to received messages or send your own.

Your service centre number is usually provided with your SIM card. If you cannot find your service centre number, please contact your service provider.

- 1 Go to ► **Messaging** ► **Settings** ► **Text message** ► **Serv. centre no.**: The number is shown if it is saved on the SIM card.
- 2 If there is no number, enter it, including the international “+” sign and country code ► **OK**.

Q: I have problems using SMS/Text messages on my phone

A: Enter the correct SMS/Text message settings.

If you have problems sending or receiving text messages on your phone, some of your phone settings are probably incorrect. The settings are different for different operators, contact your network operator for the correct SMS service centre setting.

Error messages

Insert SIM card

There is no SIM card in the phone or you may have inserted it incorrectly. Insert a SIM card ➡ *7 Insert the SIM card and battery.*

Invalid SIM card

This error message is shown in two cases:

- The phone only works with certain SIM cards. Insert the correct SIM card.
- You entered your personal unblocking key code (PUK) incorrectly 10 times in a row. Contact your operator. To unblock ➡ *38 Locks.*

Emerg. only

You are within range of a network, but you are not allowed to use it. Some network operators allow emergency calls to the international emergency number 112 ➡ *16 Emergency calls.*

No service

There is no network within range or the received signal is too weak. You have to move to get a signal that is strong enough.

Passwords do not match

You have entered your PIN or PIN2 incorrectly.
Enter the correct PIN or PIN2 ► **Yes** ➡ *38 Locks*.

PIN blocked **or** PIN2 blocked

You have entered your PIN or PIN2 incorrectly three times in a row. To unblock your codes ➡ *38 Locks*.

Phone locked

The phone is locked. To unlock the phone ➡ *38 Locks*.

Phone lock code

Your phone comes with the phone lock code 0000. You can change it to any four-digit code ➡ *38 Locks*.

Fixed dialling only

Fixed dialling is activated and the number you have dialled is not on your fixed numbers list ➡ *20 Fixed dialling*.

Important information

Sony Ericsson Consumer Web site

On www.SonyEricsson.com/support there is a section where help and tips are only a few clicks away. Here you find the latest software updates and tips on how to use your product more efficiently.

Service and support

From now on you will have access to a portfolio of exclusive service advantages such as:

- Global and local websites providing support.
- A global network of Call Centers.
- An extensive network of Sony Ericsson service partners.
- A warranty period. Learn more about the warranty conditions in this user guide.

On www.SonyEricsson.com, under the support section in the language of your choice, you will find the latest support tools and information, such as software updates, Knowledgebase, Phone setup and additional help when you require it.

For operator-specific services and features, please contact your network operator for more information.

You can also contact our Call Centers. See the phone number for the nearest Call Center in the list below. If your country/region is not represented in the list, please contact your local dealer. (The phone numbers below were correct at the time of going to print. On www.SonyEricsson.com you can always find the latest updates.)

In the unlikely event that your product needs service, please contact the dealer from whom it was purchased or one of our service partners. Save your original proof of purchase, you will need it if you need to claim warranty.

For a call to one of our Call Centers you will be charged according to national rates, including local taxes, unless the phone number is a toll-free number.

Australia	1-300 650 050 questions.AU@support.sonyericsson.com
Argentina	800-333-7427 questions.AR@support.sonyericsson.com
Austria	0810 200245 questions.AT@support.sonyericsson.com
Belgium	02-7451611 questions.BE@support.sonyericsson.com
Brazil	4001-0444 questions.BR@support.sonyericsson.com
Canada	1-866-766-9374 questions.CA@support.sonyericsson.com
Central Africa	+27 112589023 questions.CF@support.sonyericsson.com
Chile	123-0020-0656 questions.CL@support.sonyericsson.com
China	4008100000 questions.CN@support.sonyericsson.com
Colombia	18009122135 questions.CO@support.sonyericsson.com
Croatia	062 000 000 questions.HR@support.sonyericsson.com
Czech Republic	844 550 055 questions.CZ@support.sonyericsson.com
Denmark	33 31 28 28 questions.DK@support.sonyericsson.com
Finland	09-299 2000 questions.FI@support.sonyericsson.com
France	0 825 383 383 questions.FR@support.sonyericsson.com
Germany	0180 534 2020 questions.DE@support.sonyericsson.com

Greece	801-11-810-810 210-89 91 919 (from mobile) questions.GR@support.sonyericsson.com
Hong Kong	8203 8863 questions.HK@support.sonyericsson.com
Hungary	06 1 437 7300 questions.HU@support.sonyericsson.com
India	39011111 (Add STD code from a GSM connection) questions.IN@support.sonyericsson.com
Indonesia	021-2701388 questions.ID@support.sonyericsson.com
Ireland	1850 545 888 questions.IE@support.sonyericsson.com
Italy	06 48895206 questions.IT@support.sonyericsson.com
Malaysia	03-78809800 questions.MY@support.sonyericsson.com
Mexico	01 800 000 4722 questions.MX@support.sonyericsson.com
Netherlands	0900 899 8318 questions.NL@support.sonyericsson.com
New Zealand	0800-100150 questions.NZ@support.sonyericsson.com
Norway	815 00 840 questions.NO@support.sonyericsson.com
Philippines	02-6351860 questions.PH@support.sonyericsson.com
Poland	0 (prefix) 22 6916200 questions.PL@support.sonyericsson.com
Portugal	808 204 466 questions.PT@support.sonyericsson.com

Romania	(+4021) 401 0401 questions.RO@support.sonyericsson.com
Russia	095 7870986 questions.RU@support.sonyericsson.com
Singapore	67440733 questions.SG@support.sonyericsson.com
Slovakia	02-5443 6443 questions.SK@support.sonyericsson.com
South Africa	0861 632222 questions.ZA@support.sonyericsson.com
Spain	902 180 576 questions.ES@support.sonyericsson.com
Sweden	013-24 45 00 questions.SE@support.sonyericsson.com
Switzerland	0848 824 040 questions.CH@support.sonyericsson.com
Taiwan	02-25625511 questions.TW@support.sonyericsson.com
Thailand	02-2483030 questions.TH@support.sonyericsson.com
Turkey	0212 47 37 777 questions.TR@support.sonyericsson.com
United Arab Emirates	43 919880 questions.AE@support.sonyericsson.com
United Kingdom	08705 23 7237 questions.GB@support.sonyericsson.com
United States	1-866-766-9374 questions.US@support.sonyericsson.com
Venezuela	0-800-100-2250 questions.VE@support.sonyericsson.com

Guidelines for Safe and Efficient Use


Please read this information before using your mobile phone.



These instructions are intended for your safety. Please follow these guidelines. If the product has been subject to any of the conditions listed below or you have any doubt of the proper function make sure to have the product checked by certified service partner before charging or using it. Failure to do so might lead to risk for product malfunction or even a potential hazard to your health.

Recommendations for safe use of product (mobile phone, battery, charger and other accessories)

- Always treat your product with care and keep it in a clean and dust-free place.
- **Warning!** May explode if disposed of in fire.
- Do not expose your product to liquid or moisture or humidity.
- Do not expose your product to extreme high or low temperatures. Do not expose the battery to temperatures above +60°C (+140°F).
- Do not expose your product to open flames or lit tobacco products.
- Do not drop, throw or try to bend your product.
- Do not paint your product.
- Do not attempt to disassemble or modify your product. Only Sony Ericsson authorised personnel should perform service.
- Do not use your product near medical equipment without requesting permission.
- Do not use your product when in, or around aircraft, or areas posted "turn off two-way radio".
- Do not use your product in an area where a potentially explosive atmosphere exists.
- Do not place your product or install wireless equipment in the area above your car's air bag.



CHILDREN

KEEP OUT OF CHILDRENS REACH. DO NOT ALLOW CHILDREN TO PLAY WITH YOUR MOBILE PHONE OR ITS ACCESSORIES. THEY COULD HURT THEMSELVES OR OTHERS, OR COULD ACCIDENTALLY DAMAGE THE MOBILE PHONE OR ACCESSORY. YOUR MOBILE PHONE OR ITS ACCESSORY MAY CONTAIN SMALL PARTS THAT COULD BE DETACHED AND CREATE A CHOKING HAZARD.



Power supply (Charger)

Connect the AC power adapter only to designated power sources as marked on the product. Make sure the cord is positioned so that it will not be subjected to damage or stress. To reduce risk of electric shock, unplug the unit from any power source before attempting to clean it. The AC power adapter must not be used outdoors or in damp areas. Never alter the cord or plug. If the plug will not fit into the outlet, have a proper outlet installed by a qualified electrician.

Use only Sony Ericsson branded original chargers intended for use with your mobile phone. Other chargers may not be designed to the same safety and performance standards.

Battery

We recommend that you fully charge the battery before you use your mobile phone for the first time. A new battery or one that has not been used for a long time could have reduced capacity the first few times it is used. The battery should only be charged in temperatures between +5°C (+41°F) and +45°C (+113°F).

Use only Sony Ericsson branded original batteries intended for use with your mobile phone. Using other batteries and chargers could be dangerous.

The talk and standby times depend on several different conditions such as signal strength, operating temperature, application usage patterns, features selected and voice or data transmissions when using the mobile phone.

Turn off your mobile phone before removing the battery. Do not allow the battery to be put into the mouth. Battery electrolytes may be toxic if swallowed. Do not let the metal contacts on the battery touch another metal object. This could short-circuit and damage the battery. Use the battery for the intended purpose only.

Personal medical devices

Mobile phones may affect the operation of cardiac pacemakers and other implanted equipment. Please avoid placing the mobile phone over the pacemaker, e.g. in your breast pocket. When using the mobile phone, place it at the ear opposite the pacemaker. If a minimum distance of 15 cm (6 inches) is kept between the mobile phone and the pacemaker, the risk of interference is limited. If you have any reason to suspect that interference is taking place, immediately turn off your mobile phone. Contact your cardiologist for more information. For other medical devices, please consult your physician and the manufacturer of the device.

Driving

Please check if local laws and regulations restrict the use of mobile phones while driving or require drivers to use handsfree solutions. We recommend that you use only Sony Ericsson handsfree solutions intended for use with your product.

Please note that because of possible interference to electronic equipment, some vehicle manufacturers forbid the use of mobile phones in their vehicles unless a handsfree kit with an external antenna supports the installation.

Always give full attention to driving and pull off the road and park before making or answering a call if driving conditions so require.

Emergency calls

Mobile phones operate using radio signals, which cannot guarantee connection under all conditions. Therefore you should never rely solely upon any mobile phone for essential communications (e.g. medical emergencies).

Emergency calls may not be possible in all areas, on all cellular networks, or when certain network services and/or mobile phone features are in use. Check with your local service provider.

Antenna

This phone contains a built in antenna. Use of antenna devices not marketed by Sony Ericsson specifically for this model could damage your mobile phone, reduce performance, and produce SAR levels above the established limits (see below).

Efficient use

Hold your mobile phone as you would any other phone. Do not cover the top of the phone when in use, as this affects call quality and may cause the phone to operate at a higher power level than needed, thus shortening talk and standby times.

Radio frequency (RF) exposure and SAR

Your mobile phone is a low-power radio transmitter and receiver. When it is turned on, it emits low levels of radio frequency energy (also known as radio waves or radio frequency fields).

Governments around the world have adopted comprehensive international safety guidelines, developed by scientific organizations, e.g. ICNIRP (International Commission on Non-Ionizing Radiation Protection) and IEEE (The Institute of Electrical and Electronics Engineers Inc.), through periodic and thorough evaluation of scientific studies. These guidelines establish permitted levels of radio wave exposure for the general population. The levels include a safety margin designed to assure the safety of all persons, regardless of age and health, and to account for any variations in measurements.

Specific Absorption Rate (SAR) is the unit of measurement for the amount of radio frequency energy absorbed by the body when using a mobile phone. The SAR value is determined at the highest certified power level in laboratory conditions, but the actual SAR level of the mobile phone while operating can be well below this value. This is because the mobile phone is designed to use the minimum power required to reach the network.

Variations in SAR below the radio frequency exposure guidelines do not mean that there are variations in safety. While there may be differences in SAR levels among mobile phones, all Sony Ericsson mobile phone models are designed to meet radio frequency exposure guidelines.

For phones sold in the U.S., before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government-adopted requirement for safe exposure. The tests are performed in positions and locations (that is, at the ear and worn on the body) as required by the FCC for each model. For body worn operation, this phone has been tested and meets FCC RF exposure guidelines when the handset is positioned a minimum of 15 mm from the body without any metal parts in the vicinity of the phone or when used with the original Sony Ericsson body worn accessory intended for this phone. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.

A separate leaflet with SAR information for this mobile phone model is included with the material that comes with this mobile phone. This information can also be found, together with more information on radio frequency exposure and SAR, on: www.SonyEricsson.com.

Accessible Solutions/Special Needs

For phones sold in the U.S., you can use your TTY terminal with your Sony Ericsson mobile phone (with the necessary accessory). For information on Accessible Solutions for individuals with special needs call the Sony Ericsson Special Needs Center at 877 878 1996 (TTY) or 877 207 2056 (voice), or visit the Sony Ericsson Special Needs Center at www.SonyEricsson-snc.com.

Disposal of old electrical & electronic equipment

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment.

By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling



of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Disposing of the battery

Please check local regulations for disposal of batteries or call your local Sony Ericsson Call Center for information.

The battery should never be placed in municipal waste. Use a battery disposal facility if available.



End User Licence Agreement

This wireless device, including without limitation any media delivered with the device, ("Device") contains software owned by Sony Ericsson Mobile Communications AB and its affiliated companies ("Sony Ericsson") and its third party suppliers and licensors ("Software").

As user of this Device, Sony Ericsson grants you a non-exclusive, non-transferable, non-assignable license to use the Software solely in conjunction with the Device on which it is installed and/or delivered with. Nothing herein shall be construed as a sale of the Software to a user of this Device.

You shall not reproduce, modify, distribute, reverse engineer, decompile, otherwise alter or use any other means to discover the source code of the Software or any component of the Software. For avoidance of doubt, you are at all times entitled to transfer all rights and obligations to the Software to a third party, solely together with the Device with which you received the Software, provided always that such third party agrees in writing to be bound by these rules.

You are granted this license for a term of the useful life of this Device. You can terminate this license by transferring all your rights to the Device on which you have received the Software to a third party in writing. If you fail to comply with any of the terms and conditions set out in this license, it will terminate with immediate effect.

Sony Ericsson and its third party suppliers and licensors are the sole and exclusive owner of and retain all rights, title and interest in and to

the Software. Sony Ericsson, and, to the extent that the Software contains material or code of a third party, such third party, shall be entitled third party beneficiaries of these terms.

The validity, construction and performance of this license shall be governed by the laws of Sweden. The foregoing shall apply to the full extent permitted by, when applicable, statutory consumer rights.

Limited Warranty

Sony Ericsson Mobile Communications AB, S-221 88 Lund, Sweden, (Sony Ericsson), provides this Limited Warranty for your mobile phone and original accessory delivered with your mobile phone (hereinafter referred to as "Product").

Should your Product need warranty service, please return it to the dealer from whom it was purchased, or contact your local Sony Ericsson Call Center (national rates may apply) or visit www.SonyEricsson.com to get further information.

Our warranty

Subject to the conditions of this Limited Warranty, Sony Ericsson warrants this Product to be free from defects in design, material and workmanship at the time of its original purchase by a consumer, and for a subsequent period of one (1) year.

What we will do

If, during the warranty period, this Product fails to operate under normal use and service, due to defects in design, materials or workmanship, Sony Ericsson authorised distributors or service partners, in the country/region* where you purchased the Product, will, at their option, either repair or replace the Product in accordance with the terms and conditions stipulated herein.

Sony Ericsson and its service partners reserve the right to charge a handling fee if a returned Product is found not to be under warranty according to the conditions below.

Please note that some of your personal settings, downloads or other information may be lost when your Sony Ericsson Product is repaired or replaced. At present Sony Ericsson may be prevented by applicable

law, other regulation or technical restrictions from making a backup copy of certain downloads. Sony Ericsson does not take any responsibility for any lost information of any kind and will not reimburse you for any such loss. You should always make backup copies of all the information stored on your Sony Ericsson Product such as downloads, calendar and contacts before handing in your Sony Ericsson Product for repair or replacement.

Conditions

- 1** The warranty is valid only if the original proof of purchase issued to the original purchaser by a Sony Ericsson authorised dealer, specifying the date of purchase and serial number**, for this Product, is presented with the Product to be repaired or replaced. Sony Ericsson reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the Product from the dealer.
- 2** If Sony Ericsson repairs or replaces the Product, the repaired or replaced Product shall be warranted for the remaining time of the original warranty period or for ninety (90) days from the date of repair, whichever is longer. Repair or replacement may involve the use of functionally equivalent reconditioned units. Replaced parts or components will become the property of Sony Ericsson.
- 3** This warranty does not cover any failure of the Product due to normal wear and tear, or due to misuse, including but not limited to use in other than the normal and customary manner, in accordance with the Sony Ericsson instructions for use and maintenance of the Product. Nor does this warranty cover any failure of the Product due to accident, software or hardware modification or adjustment, acts of God or damage resulting from liquid. A rechargeable battery can be charged and discharged hundreds of times. However, it will eventually wear out – this is not a defect. When the talk-time or standby time is noticeably shorter, it is time to replace your battery. Sony Ericsson recommends that you use only batteries and chargers approved by Sony Ericsson. Minor variations in display brightness and color may occur between phones. There may be tiny bright or dark dots on the display. These are called defective pixels and occur when individual dots have malfunctioned and can not be adjusted.

Two defective pixels are deemed acceptable. Minor variations in camera image appearance may occur between phones. This is nothing uncommon and is not regarded as a defective camera module.

- 4 Since the cellular system on which the Product is to operate is provided by a carrier independent from Sony Ericsson, Sony Ericsson will not be responsible for the operation, availability, coverage, services or range of that system.
- 5 This warranty does not cover Product failures caused by installations, modifications, or repair or opening of the Product performed by a non-Sony Ericsson authorised person.
- 6 The warranty does not cover Product failures which have been caused by use of accessories or other peripheral devices which are not Sony Ericsson branded original accessories intended for use with the Product.
- 7 Tampering with any of the seals on the Product will void the warranty.
- 8 THERE ARE NO EXPRESS WARRANTIES, WHETHER WRITTEN OR ORAL, OTHER THAN THIS PRINTED LIMITED WARRANTY. ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SONY ERICSSON OR ITS LICENSORS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL LOSS; TO THE FULL EXTENT THOSE DAMAGES CAN BE DISCLAIMED BY LAW.

Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

The warranty provided does not affect the consumer's statutory rights under applicable legislation in force, nor the consumer's rights against the dealer arising from their sales / purchase contract.

***EUROPEAN UNION (EU)**

If you have purchased your Product in an EU country you can have your Product serviced, under the conditions set out above, within the warranty period in any EU country where an identical Product is sold by an authorised Sony Ericsson distributor. To find out if your Product is sold in the EU country you are in, please call the local Sony Ericsson Call Center. Please observe that certain services may not be possible elsewhere than in the country of original purchase, for example due to the fact that your Product may have an interior or exterior which is different from equivalent models sold in other EU countries. It may not be possible to repair SIM-locked Products.

** In some countries/regions additional information is requested. If so, this is clearly shown on the valid proof of purchase.

FCC Statement

This device complies with Part 15 of the FCC rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference,
- and (2) This device must accept any interference received, including interference that may cause undesired operation.



Declaration of Conformity

We, **Sony Ericsson Mobile Communications AB** of
Nya Vattentorget

S-221 88 Lund, Sweden

declare under our sole responsibility that our product

Sony Ericsson type AAA 1002021-BV

and in combination with our accessories, to which this declaration relates is in conformity with the appropriate standards 3GPP TS 51.010-1, EN 301489-7, EN 60950, following the provisions of Radio Equipment and Telecommunication Terminal Equipment directive **99/5/EC** with requirements covering EMC directive **89/336/EEC**, and Low Voltage directive **73/23/EEC**.

CE 0682

Lund, December 2005



Shoji Nemoto, Head of Product Business Unit GSM/UMTS

We fulfil the requirements of the R&TTE Directive (**99/5/EC**).

Index

A

- alarms 33
- answering mode 36
- answering service 24
- area information 30
- assembling, phone 7
- automatic keylock 39

B

- battery 7
 - use and care 56

C

- calculator 41
- call credit limit 21
- call list 16, 24
- call time and cost 21
- call waiting 17
- calling 14
- calls
 - accepting 19
 - emergency 16
 - hold 17
 - restricting 19
- codes
 - PUK 6
- conference calls 18
- contact 23

D

- date format 36
- declaration of conformity 65
- delivery status 30
- display light 11
- diverting calls 16
- drafts 28

E

- emergency calls 16
- end user licence agreement 60
- error messages 49

G

- GSM frequencies 2

H

- handling two calls 17
- handsfree 36
- hiding your phone number 22

I

- icons 12
- important information 51
- inbox 25

K

- keypad 5
- keypad lock 38
- keypress sound 31

L

language

 phone 37

 writing 37

languages 37

locks

 phone lock 50

 SIM card 38

long messages 29

M

master reset 37

menu overview 13

message options 30

message templates 29

message type 30

messaging 25

microphone, off/on 15

missed calls 15

multitap 26

my number 19

N

network search 36

networks 36

new messages 25

O

outbox 28

P

phone lock 38, 50

phonebook 23

PIN 6

PIN code

 changing 40

preferred network 37

PUK 39

R

reject 14

reset 37

restricted dialling 19

ring styles 31

ringtone volume 31

S

safety guidelines 55

screen saver 35

security

 SIM card lock 38

select ringtone 31

settings 35

 time and date 35

shortcuts 5

silent mode 32

SIM 7

- SIM card 6
 - lock 38
 - unlocking 39
- SIM card lock 39
- SOS numbers 16
- speaker volume 15
- standby mode 9
- stopwatch 41
- symbols 28

T

- T9™ Text Input
 - entering letters 27
- text input 27
- text messages 25
- time 35
- time format 35
- troubleshooting 42
- turn the phone on 9
- turning on/off
 - phone lock 38
 - ringtones, melodies 32
 - SIM lock protection 41
- two voice lines 19

V

- vibrating alert 32
- voicemail 24
- volume
 - setting ringtone 31

W

- wallpaper 35
- warranty 64
- writing methods 26