


# MR. COFFEE®



**MODEL TM20**

Instruction Manual

## THE ICED TEA POT™

READ ALL INSTRUCTIONS BEFORE USING THIS APPLIANCE

# IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. **READ ALL INSTRUCTIONS BEFORE USING THE MACHINE.**
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electric shock, do not immerse cord, plugs or machine in water or any other liquid.
4. Close adult supervision is necessary when this appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Return this appliance only to the nearest authorized service center for examination, repair or adjustment.
7. The use of accessory attachments not recommended for MR. COFFEE® products may cause hazards or injuries.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place this appliance on or near a hot gas or electric burner or in a heated oven.
11. To disconnect, remove plug from outlet wall.
12. Do not use appliance for other than intended use.
13. Use on a hard, flat level surface only, to avoid interruption of air flow underneath the appliance.
14. **Pitcher Use and Care**  
Breakage may occur if the following instructions are not followed:
  - a. This pitcher is designed for use with this iced tea maker and therefore must never be used on a rangetop or in any oven, including a microwave.
  - b. Do not use a cracked pitcher.
  - c. Do not clean the pitcher with cleansers, steel wool pads, or other abrasive materials.
  - d. Avoid sharp blows, scratches, or rough handling.
15. **WARNING:** To reduce the risk of fire or electric shock, do not remove any service covers. No user serviceable parts inside. Repair should be done by authorized personnel only.
16. Pitcher is not dishwasher safe.

THIS UNIT IS FOR HOUSEHOLD USE ONLY

## SPECIAL CORD SET INSTRUCTIONS

1. A short power supply cord is provided to reduce the hazards resulting from becoming entangled in or tripping over a longer cord.
2. An extension cord may be purchased and used if care is exercised in its use.
3. If an extension cord is used, the marked electrical rating of the extension cord must be at least 10 amps and 120 volts. The resulting extended cord must be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over accidentally.

**This appliance has a polarized plug (*one blade is wider than the other*). To reduce the risk of electric shock, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not modify the plug in any way.**

### IF SERVICE IS REQUIRED, DO NOT RETURN TO YOUR STORE

FOR SERVICE, CALL 1-800 MR COFFEE (1-800-672-6333)  
9:00 A.M. TO 6:00 P.M., EASTERN STANDARD TIME, MONDAY THROUGH FRIDAY  
9:00 A.M. TO 3:00 P.M., EASTERN STANDARD TIME, SATURDAY

**TO ASSIST US IN SERVING YOU, PLEASE HAVE THE MODEL NUMBER  
(TM20) AND DATE OF PURCHASE AVAILABLE.**

#### **PLEASE DO NOT RETURN THIS APPLIANCE TO YOUR STORE.**

All repairs must be made by SUNBEAM or by an *Authorized* Sunbeam Service Center.  
Please call us for assistance or for the location of the nearest Authorized Sunbeam Service Center.

#### **We welcome your questions, comments or suggestions.**

Please include your complete name, address and telephone number so we can reach you if necessary. Do not send product to the address below.

#### **CONSUMER SERVICE DEPARTMENT**

**SUNBEAM PRODUCTS, INC.**

**P.O. Box 948389**

**Maitland, FL 32794-8389**

or email: [consumeraffairs@consumer.sunbeam.com](mailto:consumeraffairs@consumer.sunbeam.com)

## SAVE THESE INSTRUCTIONS

## INTRODUCTION

**CONGRATULATIONS!** You are the owner of a MR. COFFEE® Iced Tea Maker.

This unique appliance will enable you to prepare 3 quarts of delicious iced tea in your very own home.


Please read all of the instructions in this manual carefully before you begin to use this appliance. Proper care and maintenance will ensure the long life of this appliance and its trouble-free operation. Save these instructions and refer to them often for cleaning and care tips.

## TABLE OF CONTENTS


	<b>PAGE</b>
Important Safeguards . . . . .	2
Cord Set Instructions . . . . .	3
Service . . . . .	3
Introduction . . . . .	4
Diagram of Parts . . . . .	5
Operation and Use . . . . .	6
Precautions . . . . .	7
Brewing . . . . .	8
Measurement Chart . . . . .	9
Helpful Hints . . . . .	10
Cleaning . . . . .	10
Deliming . . . . .	10
Warranty . . . . .	11

# DIAGRAM OF PARTS

(THIS PRODUCT IS NOT DISHWASHER SAFE)



## MODEL TM20



MR. COFFEE®  
REPLACEMENT  
PITCHER (TP14)

# OPERATION AND USE

## BEFORE FIRST USE

Before using your Iced Tea Maker for the first time, follow these easy cleaning instructions.

**WARNING:** To prevent injury from steam, do not plug the unit in until water is in the reservoir, lid is closed and the pitcher is in place.

1. Wash pitcher/lid and brew basket by using a mild, non-abrasive detergent and water. Rinse each thoroughly.
2. Next, fill pitcher with water to the top **water level mark** on the pitcher. Lift the reservoir lid, remove the brew basket. Pour water into the reservoir. Do not overfill. Replace brew basket.
3. Rotate the shower head so that it is over the brew basket. Close lid.
4. Place the pitcher lid onto the pitcher. Open the spout cover. Slide the pitcher against the appliance (*spout-first*) under the appliance.
5. Plug cord into electrical outlet. Push "ON" button. The button will illuminate to let you know the appliance is on.\*
6. When the cycle is complete, your appliance will shut off automatically.\*\*  
The button light will turn off.
7. Slide the pitcher away from the appliance.
8. Discard the water in the pitcher.

---

**\*NOTE:** If light does not turn on, push the "ON" button again firmly and release. The first time the appliance is used, it may not be necessary to depress the "ON" button to turn the appliance on. Plugging the appliance into an outlet may trigger the brewing cycle. If the "ON" button is depressed before the appliance is plugged into an outlet, this would trigger the brewing cycle.


**\*\*NOTE:** If you wish to turn the appliance off during the brew cycle, grasp the molded plug and unplug the power cord.

## PRECAUTIONS WHEN USING THIS MACHINE

- Place the machine well back from the edge of the counter.
- To stop the brewing cycle before completed, grasp the molded plug and unplug from electrical outlet.
- Avoid areas which may become hot or emit steam when the machine is on, particularly the steeping basket and water reservoir. The water reservoir lid must be on while the machine is brewing.
- Unplug the unit when not in use or when wiping the exterior. Wipe with a damp cloth only.
- **To maintain the quality of parts, we recommend hand washing only. These items are not dishwasher safe.**
- DO NOT operate the machine unless the pitcher with the lid on is snug against the machine.
- DO NOT move the machine while in use or afterwards, until it has cooled. Steam may escape from the steeping basket while the unit is cooling.
- DO NOT place a cloth or otherwise restrict airflow beneath the appliance.
- Avoid jerking or straining the power cord when unplugging. Grasp the molded plug to unplug.
- This machine is not designed for commercial use.
- Never reheat a beverage by passing it through the brewing system.
- Do not permit children to use this machine unless under close adult supervision.
- Do not immerse the appliance in water. This may cause permanent damage and void the warranty.


# BREWING

1. Fill the pitcher with tap water to the desired "water" level capacity. Be careful not to overfill.
2. Lift the water reservoir lid, remove the basket. Pour water into the reservoir. (See *Illustration*)
3. This machine includes 2 baskets. The white tea steeping basket is for preparing iced tea. The black coffee brew basket is for preparing iced coffee. Place the appropriate basket into place. (See *Illustration*)



STEP 2


4. Insert an 8-12 cup paper filter into the basket. Add desired amount of tea/coffee. Refer to the Measurement Chart. You may now add sugar, lemon or other flavorings to suit your taste.



STEP 3

5. Rotate the shower head so it is over the basket. Close the water reservoir lid.

6. Adjust the steeping lever. For iced coffee, the steeping lever should be set to the left at the coffee mark. For iced tea, you may adjust the lever. The farther the lever is to the left, the stronger the tea.



STEP 7

7. Fill pitcher with ice cubes to the desired ice level marked on the pitcher. Replace the lid with the lid spout cover in the open position (See *Illustration*)



8. Slide the pitcher with lid in place, spout first and in the open position, under the machine. (See Illustration) Read caution before continuing.

**CAUTION:** Do not operate the machine unless the pitcher and lid are pushed snugly against the machine. Hot water and hot steam could escape and cause injury.

9. Turn machine on by plugging the cord into an electrical outlet. Push the "on" button firmly until a click is heard. The indicator light will come on when the button is released. **NOTE:** If it does not turn on the first time, push the "on" button again firmly and release. The first time the machine is used, it may not be necessary to depress the "on" button to turn the machine on. Plugging the machine into an outlet may trigger the brewing cycle. Also, if the "on" button is depressed before the machine is plugged into an outlet this would trigger the brewing cycle.

**NOTE:** If you wish to turn the machine off during the brew cycle, grasp the molded plug and unplug the power cord.


10. When the brewing cycle is complete, the machine will automatically shut off and indicator light will go out. Allow 30 seconds, then proceed to Step 11

11. Slide the pitcher away from the machine.


**CAUTION:** Some residual steam may escape from the machine. For your safety, slide the pitcher away from the machine before you continue.

12. Open reservoir lid, rotate shower head, discard contents of brew basket and rinse with water.

13. When not in use, the pitcher is designed to be stored sideways next to the machine. (See Illustration)



STEP 8



STEP 13

## BREWING ICED TEA/ICED COFFEE

Use the suggested amount of tea/coffee noted in the chart below.

MEASUREMENT CHART (ICED TEA AND ICED COFFEE)

TO MAKE:	WATER	ICE CUBES	TEA	COFFEE
3 QUARTS	Fill to "WATER" level marked on pitcher	Fill to "ICE" level marked on Pitcher	5-7 bags or 2-3 Tbsp. of loose tea	7-11 level Tbsp. or 4-6 coffee scoops
2 QUARTS	Fill to "WATER" level marked on pitcher	Fill to "ICE" level marked on pitcher (2-3 frays/ice)	3-5 bags or 1-2 Tbsp. of loose tea	4-7 level Tbsp. or 2-4 coffee scoops
1 QUART	Fill to "WATER" level marked on pitcher	Fill to "ICE" level marked on pitcher	1-3 bags or 1/2-1 Tbsp. of loose tea	2-4 level Tbsp. or 1-2 coffee scoops

## HELPFUL HINTS

- Use only fresh, cold tap water in the appliance.
- Use MR. COFFEE® 8-12 cup basket filters for best brewing performance.
- The steeping lever may be moved to the right for stronger tea or the left for weaker tea, to suit your taste. Additional tea bags may be needed when using herbal tea.
- If your ice supply is low, you may substitute cold water. After filling the water reservoir with the proper amount of water, refill the pitcher with cold tap water a second time to the desired 1, 2, 3 Quart Water Level. **NOTE:** Do not fill to the Ice Level as this will cause an overflow.
- Tea may turn cloudy as it chills due to tannic acids found in tea.

## CLEANING

- To maintain the quality of all the parts and minimize tea stains, we recommend washing the pitcher/lid, and brew basket, with warm water and mild detergent after each use.
- Hard water can leave mineral deposits inside the pitcher and brew basket. To remove, fill the brew basket and pitcher with warm, undiluted, white household vinegar. Let soak for 20 minutes. Rinse.
- Do not use harsh, abrasive cleaners. They will cause scratches which can lead to breakage.

## DELIMING

Your appliance must be delimed when you begin to notice an increase in steaming or if the pumping action stops before all the water has been pumped out of the appliance. The frequency of cleaning depends on the hardness of your water. Refer to chart.

### **TO DELIME, FOLLOW THESE EASY INSTRUCTIONS.**

1. Pour 1 quart (32 oz.) of undiluted white household vinegar into the water reservoir.
2. Place the pitcher lid on the pitcher. Slide the pitcher under the appliance.
3. Push the "ON" button to begin brewing cycle. After 1 cup of vinegar has pumped into the pitcher, unplug appliance. Let stand 30 minutes.
4. Re-plug the cord. Your appliance will automatically continue to pump out the remaining vinegar.
5. When your appliance shuts off, unplug the cord, remove the pitcher. Discard the vinegar.
6. Fill the pitcher with clear tap water to the water level marked on the pitcher. Repeat Steps 1-5 without vinegar. Repeat if necessary.

## SUGGESTED CLEANING INTERVAL

<u>TYPE OF WATER</u>	<u>CLEANING FREQUENCY</u>
Soft Water	Every 80 Brew Cycles
Hard Water	Every 40 Brew Cycles

---

## 1-YEAR LIMITED WARRANTY

Sunbeam Products, Inc. ("Sunbeam") warrants that for a period of **ONE** year from the date of purchase, this product will be free from defects in material and workmanship. Sunbeam, at its option, will repair or replace this product or any component of the product found to be defective during this warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. Sunbeam dealers, service centers or retail stores selling Sunbeam products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear of parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than Sunbeam or an Authorized Service Center. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes.

Sunbeam shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province.

### HOW TO OBTAIN WARRANTY SERVICE

Take the product to an Authorized Sunbeam Service Center. You can find the nearest Authorized Sunbeam Service Center by calling **1-800-672-6333**. If a Service Center is not conveniently located, attach a tag to the product that includes your name, address, daytime telephone number and description of the problem. Include a copy of the original sales receipt. Carefully package the product and send either by UPS or Parcel Post with shipping and insurance prepaid to:

**SUNBEAM SERVICE CENTER**  
**c/o Warranty Center**  
**117 Central Industrial Road**  
**Purvis, MS 39475**

**DO NOT RETURN THIS PRODUCT TO THE PLACE OF PURCHASE.**

If you have any questions regarding this warranty please call 1-800-672-6333.

MR. COFFEE®

©2000 Sunbeam Products, Inc. All rights reserved.

MR. COFFEE® is a registered trademark of Sunbeam Products, Inc.

THE ICED TEA POT™ is a trademark of Sunbeam Products, Inc.

Distributed by Sunbeam Products, Inc., Boca Raton, Florida 33431.