

# **BLACK & DECKER®**

**SAVE THIS USE AND CARE BOOK**

**LEASE ESTE INSTRUCTIVO ANTES DE USAR EL PRODUCTO**

**CONSERVER CE GUIDE D'ENTRETIEN ET D'UTILISATION**

## **10-Cup**

**Drip Coffeemakers** (English See Pg. ??)

**Cafetera para 10 tazas** (Consulte lá pagina ??)

**Cafetière de 10 tasses** (Fraçais à la page ??)



(DCM903WH Shown)

**U.S.A. 1-800-231-9786**

QUESTIONS?

**MEXICO 9-1-800-70128**

PREGUNTAS?

**CANADA 1-800-465-6070**

DES QUESTIONS?

**Series DCM300** **Séries**  
**Series DCM900** **Séries**

**IMPORTANT / IMPORTANTE / IMPORTANT**  
**WASH CARAFE BEFORE FIRST USE!**  
**LAVE LA JARRA ANTES DEL PRIMER USO!**  
**LAVER LA CARAFE AVANT LA PREMIERE UTILISATION!**

# IMPORTANT SAFEGUARDS


When using electrical appliances, in order to reduce the risk of fire, electric shock, and/or injury to persons, basic safety precautions should always be followed, including the following:

- Please read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against fire, electric shock and injury to persons, do not immerse cord, plug, or coffeemaker base in water or other liquid.
- To prevent fire or electric shock, do not remove bottom cover from coffeemaker base. There are no user-serviceable part inside. Repair should be done by authorized service personnel only.
- Close supervision is necessary when any appliance is used by or near children.
- Allow to cool before putting on or taking off parts and before cleaning the coffeemaker.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return the appliance to the nearest Black & Decker (U.S.) Inc., Household Appliance Company-Owned or Authorized Service Center for examination, repair, or adjustment.
- The use of an accessory not evaluated for use with this coffeemaker may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Do not place on or near a hot gas or electric burner or in a hot oven.
- Do not use coffeemaker for other than intended use.
- Keep lid on carafe while serving coffee.
- The carafe is designed for use with this coffeemaker. It must never be used on a range top or in a microwave oven.
- Do not set a hot carafe on a wet or cold surface.
- Do not use a cracked carafe or a carafe with a loose or weakened handle.
- Do not clean carafe with cleansers, steel wool pads, or other abrasive material.
- Remember to place carafe on the “Keeps Hot” Plate before brewing and when using the automatic timer on clock models.
- Do not pour liquid other than water or the cleaning solution specified in this manual into the water reservoir.  
(See “Mineral Deposits and Cleaning”)
- Do not move entire unit when carafe contains hot liquid.

- Do not operate in the presence of explosive and/or flammable fumes.
- This appliance is intended FOR HOUSEHOLD USE ONLY and not for commercial or industrial use.

## SAVE THESE INSTRUCTIONS

- 1 Water Reservoir Lid
- 2 Filter Basket
- 3 10-Cup Level Mark on Handle
- 4 Carafe
- 5 "Keeps Hot" Plate (Under Carafe)
- 6 Power "On" Light (Red)
- 7 Brew Later Light (Green)
- 8 Clock/Control Panel
- 9 Carafe Lid
- 10 Drip Stop (Under Basket)
- 11 Water Reservoir



### POLARIZED PLUG


This appliance has a polarized plug—one blade is wider than the other. To reduce the risk of electric shock, this plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse it. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature by modifying the plug in any way.

### TAMPER RESISTANT SCREW

This appliance is equipped with a tamper-resistant screw to prevent removal of the outer cover. To reduce the risk of fire or electric shock, do not attempt to remove the outer cover. There are no consumer serviceable parts inside. Repair should be done only by authorized service personnel.

# How To Use

## SETTING THE CLOCK



**NOTE:** It is not necessary to set the clock before brewing.

1. When you plug in the Coffeemaker. The Clock will flash 12:00 a.m. and continue flashing until either the Up or Down Buttons are pressed (Figure A).
2. Push and hold the Up or Down Button until the current time of day, a.m. or p.m., is reached.
3. To move forward or backward one minute at a time, push and

release the Up or Down Button until the desired time is reached.

## BEFORE BREWING COFFEE

1. Brew 10 cups of water by following the instructions under "Brewing Coffee - With or Without Clocks", but do not add coffee grounds to the paper filter.

---

2. When all the water has brewed into the Carafe, turn the Coffeemaker off, wait 10 minutes, discard the water then repeat steps 1 and 2.

---

3. Wash and dry the Filter Basket, Carafe, and Carafe Lid.

## BREWING COFFEE

1. Fill the Carafe with cold water to the level for the desired number of cups. Open the Water Reservoir Lid and pour the water into the Water Reservoir.

2. Remove the Filter Basket and place a standard cupcake-style paper coffee filter in it.
3. Put coffee grounds in the filter, using 1 level tablespoon of drip grind coffee for each cup (5 oz.) of brewed coffee.

---

**NOTE:** Use more or less grounds per cup to suit your taste. When brewing 2-4 cups, use slightly more grounds per cup (20 tablespoons maximum).

---


4. Shake the Filter Basket to spread the grounds, and place it back in the Coffeemaker. Be sure the Filter Basket is pushed all the way into the unit.
5. Place the Carafe on the "Keeps Hot" Plate, making sure the Carafe Lid is on the Carafe.
6. Press the ON/OFF Button. A red Power "On" Light will glow showing the unit is brewing and the "Keeps Hot" plate will automatically come on. Let all brewed coffee drip from the Filter Basket before removing the Carafe.
7. Always keep the Carafe Lid on the Carafe when pouring. To keep coffee hot, place the Carafe back on the "Keeps Hot" Plate when not serving.
8. The "Keeps Hot" Plate will remain on for two hours then will shut off automatically. If you wish to turn the Coffeemaker off sooner, depress the ON/OFF Button and the red Power "On" Light will turn off.
9. If you'd like to extend the "Keeps Hot" after the auto shut-off, press the ON/OFF Button to turn the "Keeps Hot" Plate on for two more hours.

---

**NOTE:** The amount of coffee in the Carafe may be slightly less than the amount of water placed in the Water Reservoir, since some water is absorbed by the coffee grounds during brewing.

---

## SNEAK-A-CUP™ INTERRUPT FEATURE



The **clock** models have a Sneak-A-Cup™ Interrupt Feature – an automatic drip stop. During the brewing cycle, the Carafe can be removed to pour a cup of coffee from the Carafe. (Figure B)

**IMPORTANT:** *The Carafe must be replaced under the Brew Basket in less than a minute to prevent the Brew Basket from overflowing.*

## BREWING COFFEE - MODELS WITHOUT CLOCKS

1. Fill the Carafe with cold water to the level for the desired number of cups. Open the Water Reservoir Lid, and pour the water from the Carafe into the Water Reservoir.
2. Remove the Filter Basket and place a standard, cupcake-style paper coffee filter in it.
3. Put coffee grounds in the filter, using 1 level tablespoon of drip grind coffee for each cup (5 oz.) of brewed coffee.

---

**NOTE:** Use more or less grounds per cup to suit your taste. When brewing 2-4 cups, use slightly more grounds per cup (20 tablespoons maximum).

---

4. Shake the Filter Basket to spread the grounds, and place it back in the Coffeemaker. Be sure the Filter Basket is pushed all the way into the unit.
5. Place the Carafe on the “Keeps Hot” Plate making sure the Lid is on the Carafe.

## **6. Depending on the model, Flip or Slide**

Flip the OFF/ ON Switch to the right to turn the Coffeemaker on. The “Keeps Hot” plate will automatically come on when the brewing begins. Let all the brewed coffee drip from the Filter Basket before removing the Carafe.

---

**NOTE:** The amount of coffee in the Carafe may be slightly less than the amount of water placed in the Water Reservoir, since some water is absorbed by the coffee grounds during brewing.

---

7. Always keep the Carafe Lid on the Carafe when pouring. To keep coffee hot, place the Carafe back on the “Keeps Hot” Plate when not serving.
8. To turn the Coffeemaker off when the Carafe is empty or you no longer want to keep the coffee hot, flip or slide the Switch to the left, depending on the style of your model. The “Keeps Hot” plate will go off when the unit is turned off.

## PROGRAMMING THE COFFEEMAKER TO BREW LATER MODELS WITH CLOCKS




Figure C

1. Press and release the Brew Later Button under the Program heading on the Coffeemaker. A clock symbol ( ⌚ ) will appear on the display indicating you are in the Brew Later Program mode. (Figure C)

---

**NOTE:** The first time the Program Brew Later Button is pressed after the Coffeemaker has been plugged in, the display will show a colon, 3 broken lines, and the clock symbol ( - : - - ⌚ ). This means the Timer has no Brew Later time programmed. Press the Up or Down Buttons to program a Brew Later time. This will also occur if the Coffeemaker is unplugged or there is a power outage for more than 30 seconds.


---

2. Press and hold either the Up or Down Button until the desired Brew Later start time - a.m. or p.m. - is reached. The clock will return to the current time of day within a few seconds.

---

**NOTE:** If the Clock symbol disappears before pressing the Up or Down Buttons, the display will go back to the current time of day. Press the Brew Later Button again to reactivate the Program mode.

---



## BREWING LATER USING THE AUTOMATIC TIMER

1. Be sure the Coffeemaker is ready to brew coffee. (See "Brewing Coffee - Models with Clock")
2. Press the Brew Later Button next to the ON/OFF Button. The green light above the Button will glow indicating the Coffeemaker will brew when the current time of day is the same time as the Brew Later programmed time. (Figure F)
3. When the current time of day reaches the Brew Later programmed time, the red Power "On" Light will glow and the Coffeemaker will begin brewing.

## CANCELING OR RESETTING BREW LATER

Brew Later can be canceled at any time by pressing the Brew Later Button. This will turn off the green Brew Later Light, but no change will be made to the currently stored Brew Later set time. To change the stored Brew Later time, follow the procedures in "Programming the Coffeemaker to Brew Later."

## AUTOMATIC POWER OUT BACK-UP

Models with clocks are equipped with an automatic 30-second power out back-up function. If you should lose power (or if you unplug the unit to relocate it once it has been programmed), the unit will automatically save the pre-set brew time and the current time of day as long as power is restored within 30 seconds. If power is out longer than 30 seconds, you will have to reset the time of day and re-program your brew-later timer.

---

**NOTE:** To view the currently stored Brew Later time, push the **Program** Brew Later Button and the stored time will display. After a few seconds, the present time of day will be displayed again.

---

## TO REHEAT LEFTOVER COFFEE

1. Pour the coffee into a saucepan and heat on a range top until the coffee is hot but not boiling; boiling will affect the coffee's flavor.
2. **IMPORTANT:** Never pour brewed coffee back into the Water Reservoir. Do not place the Carafe on a cooking surface or in a microwave oven.

# Care Guide

## CLEANING AFTER BREWING COFFEE

---

**NOTE:** Do not place anything other than water or the cleaning solution specified in this book into the Water Reservoir.

---

To clean your Coffeemaker after brewing coffee, be sure the Coffeemaker is turned OFF and is cool. Discard the paper filter, and clean each part as follows:

Filter Basket, Glass Carafe, and Carafe Lid:

Dishwasher - top rack only; or hot, sudsy water.

Coffeemaker: Wipe with soft, damp cloth and dry.

Do not use abrasive soaps or scouring pads.

Parts washed in a dishwasher may appear to fade.

The original color may be restored by polishing with a soft, dry cloth.

## CARING FOR YOUR CARAFE

A damaged Carafe may result in possible burns from hot liquid. To avoid breaking Carafe:

- Do not allow all liquid to evaporate from Carafe while on the "Keeps Hot" Plate or heat Carafe when empty.
  - Discard Carafe if damaged in any manner. A chip or crack could result in breakage.
  - Never use abrasive scouring pads or cleansers as they will scratch and weaken the glass.
  - Do not place Carafe on or near a hot gas or electric burner, in a heated oven, or in a microwave oven.
  - Avoid rough handling and sharp blows.
-

---

## **MINERAL DEPOSITS AND CLEANING**

Mineral deposits left by water can clog your Coffeemaker. Clean your Coffeemaker about every 1 - 3 months to flush out these deposits.

Frequency of cleaning will be affected by water hardness. If you live in a hard water area, you may have to clean the Coffeemaker more frequently.

Excessive steaming or a prolonged brewing cycle are signs that cleaning is needed. During cleaning, more steaming occurs than when brewing coffee.

1. Pour white vinegar into the Carafe up to the "6" cup level mark and add cold water up to the 10-cup level.
  2. Pour this cleaning solution into the Water Reservoir. Place the Carafe on the "Keeps Hot" Plate making sure the Carafe Lid is on the Carafe.
  3. Remove the Filter Basket and place a standard cupcake-style paper coffee filter in it. Put the Filter Basket back in the Coffeemaker.
  4. Turn the Coffeemaker on.
  5. Let 1/2 the cleaning solution brew into the Carafe, then turn the Coffeemaker off.
  6. Let the Coffeemaker cool for 15 minutes to soften the deposits.
  7. Pour the liquid that brewed into the Carafe back into the Water Reservoir.
  8. Turn the Coffeemaker on and let all the cleaning solution brew into the Carafe.
  9. Turn the Coffeemaker off and discard the cleaning solution and soiled paper filter.
  10. Fill the Coffeemaker with fresh water; follow the steps in "Before Brewing Coffee" to flush out the remaining cleaning solution.
  11. Wash the filter Basket, Carafe and Lid as instructed in "Cleaning After Brewing".
-

# Need Help?

## **ELECTRICAL CORD**

---

The cord length of this appliance was selected to reduce safety hazards that may occur with a longer cord. If more cord length is needed, an extension cord may be used. It should be rated not less than 10 amperes, 120 volts, and should have UL, CUL or CSA listing. A properly rated extension cord may be purchased from a Black & Decker (U.S.) Inc., Household Appliance Company-Owned or Authorized Service Center. Handle cord carefully for longer life; avoid jerking or straining it at outlet and appliance connections.

---

## **SERVICE OR REPAIR**

---

Service, if necessary, must be performed by a Black & Decker (U.S.) Inc., Household Appliance Company-Owned or Authorized Service Center. The Service Center nearest you can be found in the yellow pages of your phone book under "Appliances - Small - Repairing" or you may call the appropriate "800" number on the cover of this book.

If mailing or shipping your Coffeemaker, clean, dry, and pack it carefully in its original carton or any sturdy carton with enough packing material to prevent damage. Include a note describing the problem to our Service Center and be sure to give your return address. We also suggest that you insure the package for your protection.

---

# BLACK AND DECKER COMPANY-OWNED SERVICE CENTERS

## ALABAMA

**BIRMINGHAM** — 2412 Green Springs, Hwy., 35209  
205-942-0838  
**MOBILE** — 3831 Airport Blvd., 36608 205-343-6624

## ALASKA

**ANCHORAGE** — 910 West International Airport Rd.,  
99518 907-563-4664

## ARIZONA

**MESA** — 535 South Dobson Rd., Suite 7, 85202  
602-461-1074  
**PHOENIX** — 4501 N. 7th Ave., 85013 602-279-6414  
**TUCSON** — 4845 E. Speedway Blvd., 85712  
602-323-3388

## ARKANSAS

**LITTLE ROCK** — 519 W. Seventh St., 72201 501-372-3040

## CALIFORNIA

**ANAHEIM** — 540 South State College Blvd., 92806  
714-772-4050  
**CHULA VISTA** — 309 Broadway, 91911 619-420-6350  
**CONCORD** — 1500 Monument Blvd., #C2, 94520  
510-682-4880  
**FRESNO** — 5412 North Blackstone Ave., 93710 209-435-0810  
**LONG BEACH** — 2011 South St., 90805 310-422-5825  
**LOS ANGELES** — 4820 South Eastern Ave., Suite "L"  
90040  
213-720-1834  
**RIVERSIDE** — 6215 Magnolia Ave., Suite B, 92506  
714-787-9700  
**SACRAMENTO** — 2033 Fulton Ave., 95825 916-972-9090  
**SAN DIEGO** — 9270 Clairmont Mesa Blvd., 92123  
619-279-2011  
**SAN JOSE** — 1185 South Bascom Ave., 95128 408-293-7350  
**SAN LEANDRO** — 15206 East 14th St., 94578 510-276-1610  
**VAN NUYS** — 14920 Victory Blvd., 91411 818-787-5531

## COLORADO

**DENVER** — 1171 South Federal Blvd., Box 19220, 80219  
303-922-8325

## CONNECTICUT

**HARTFORD** — 662 Silas Deane Hwy., 06109 203-563-5800  
**ORANGE** — 481 Boston Post Rd., 06477 203-795-3583

## DISTRICT OF COLUMBIA

**COLMAR MANOR, MD** — 4153 Bladensburg Rd., 20710  
301-779-3808  
**FALLS CHURCH, VA** — 344 W. Broad St., 22046  
703-533-7313

## FLORIDA

**FT. LAUDERDALE** — 799 East Oakland Pk. Blvd., 33334  
305-566-5102  
**FT. MYERS** — 5224 Bank St., 33907 813-278-1188  
**JACKSONVILLE** — 920 Cassat Ave., 32205 904-781-2253  
**MIAMI** — 13345 North West Seventh Ave., 33168  
305-681-6658  
**MIAMI** — 12233 South Dixie Hwy., 33156 305-232-9497  
**ORLANDO** — 3807 East Colonial Dr., 32803 407-894-7011  
**ST. PETERSBURG** — 5635 49th St. North, 33709  
813-525-0273  
**TAMPA** — 3432 West Kennedy Blvd., 33609 813-872-8317  
**WEST PALM BEACH** — 310 South Military Trail, 33415  
407-689-3247

## GEORGIA

**ATLANTA (South)** — 5330 Old National Hwy., 30349 404-762-8844  
**SMYRNA** — 2550 Cobb Parkway South, 30080 404-956-0869  
**STONE MOUNTAIN** — 5723 Memorial Dr., 30083 404-292-4714

## HAWAII

**HONOLULU** — Unit No. 106, Sand Island Access Rd.,  
96819 808-847-7447

## ILLINOIS

**CHICAGO (Lincolnwood)** — 6710 North Crawford Ave.,  
60646 708-673-0923  
**DES PLAINES** — 1277 South Elmhurst Rd., 60018 708-364-5220  
**LISLE** — 2950 Ogden Ave., Unit H, 60532 708-717-1075  
**MOLINE** — 4433 23rd Ave., 61265 309-762-3000  
**OAK LAWN** — 6343 W. 95th St., 60453 708-423-7212  
**WAUKEGAN** — 39 S. Greenbay Rd., 60085 703-249-4390

## INDIANA

**EVANSVILLE** — 307 First Ave., Crescent Ctr., 47710 812-425-4269  
**HAMMOND** — 7103 Kennedy Ave., 46323 219-845-5100  
**INDIANAPOLIS (Speedway)** — 5999 Crawfordsville Rd.,  
46224 317-243-8308

## IOWA

**DES MOINES** — 3427 Merle Hay Rd., 50310 515-270-1340

## KANSAS

**WICHITA** — 155 South West St., 67213 316-943-1271

## KENTUCKY

**LOUISVILLE** — 5211 Preston Hwy., 40213 502-968-7100

## LOUISIANA

**BATON ROUGE** — 11859 Florida Blvd., 70815 504-272-8111  
**HARVEY** — 2500 Lapalco Blvd., 70058 504-366-8676  
**METAIRIE (New Orleans)** — 3504 North Causeway  
Blvd., 70002 504-837-2550  
**SHREVEPORT** — 7710-7714 Jewella Rd., 71108 318-688-1553

## MARYLAND

**BALTIMORE** — 4712 Erdman Ave., 21205 410-485-5550  
**BALTIMORE** — 29-31 Cranbrook Rd., Cockeysville, 21030  
410-666-5966  
**COLMAR MANOR (Wash. D.C.)** — 4153 Bladensburg  
Rd., 20722 301-779-3808  
**PASADENA** — 8220 Ritchie Hwy., 21122 410-647-8456

## MASSACHUSETTS

**BRIGHTON (Boston)** — 12 Market St., 02135 617-782-6264  
**SEEKONK** — 120 Highland Ave., 02771 508-336-6510

## MICHIGAN

**GRAND RAPIDS** — 3040 28th St., SE, 49512 616-949-8331  
**LANSING** — 3203 W. Saginaw Hwy., 48917 517-323-4181  
**WARREN** — 27035 Van Dyke Blvd., 48093 313-756-6711  
**WESTLAND** — 8067 N. Wayne Rd., 48185 313-427-1520

## MINNESOTA

**BLOOMINGTON** — 9517 Lyndale Ave., South, 55420  
612-884-9191

## MISSOURI

**KANSAS CITY** — 4324 Main St., 64111 **816-531-0629**  
**ST. ANN** — 3637 North Lindbergh Blvd., 63074  
**314-739-4661**  
**ST. LOUIS** — 12852 Manchester Rd., 63131 **314-821-8740**

## NEBRASKA

**OMAHA** — 4225 South 84th St., 68127 **402-592-5666**

## NEVADA

**LAS VEGAS** — 3411 East Charleston Blvd., 89104  
**702-641-6555**

## NEW JERSEY

**CHERRY HILL** — 1444 East Marlton Pike (Rt. 70), 08034  
**609-429-2822**  
**LITTLE FALLS** — 1189 U.S. Hwy. 46, 07424 **201-256-9373**  
**SCOTCH PLAINS** — 2520 Route #22 East, 07076 **908-233-5665**

## NEW MEXICO

**ALBUQUERQUE** — 5617 Menaul Blvd., N.E., 87110  
**505-884-1002**

## NEW YORK

**ALBANY (Latham)** — 836 Troy-Schenectady Rd., 12110  
**518-785-1867**  
**BUFFALO** — 881 West Delavan Ave., 14209 **716-884-6220**  
**CENTEREACH LI.** — 2061-63 Middle Country Rd., 11720  
**516-737-4706**  
**NEW YORK (Elmhurst)** — 77-20 Queens Blvd., 11373  
**718-335-1042**  
**NEW YORK (Manhattan)** — 50 West 23rd St., 10010  
**212-929-6450**  
**NEW YORK (Westbury, LI.)** — 1061 Old Country Rd.,  
11590 **516-997-6140**  
**ROCHESTER** — 2969 W. Henrietta Rd., 14623 **716-424-1310**  
**SYRACUSE** — 3485 Erie Blvd., East, 13214 **315-446-3086**

## NORTH CAROLINA

**CHARLOTTE** — 3007 East Independence Blvd., 28205  
**704-374-1779**  
**GREENSBORO** — 3716 High Point Rd., 27407 **919-852-1300**  
**RALEIGH** — 2930 Capital Blvd., 27604 **919-878-0357**

## OHIO

**CINCINNATI** — 2310 East Sharon Rd., 45241 **513-772-3111**  
**COLUMBUS** — 3975 East Livingston Ave., 43227  
**614-237-0461**  
**DAYTON** — 2898 South Dixie Drive, 45409 **513-298-1951**  
**MAYFIELD HEIGHTS** — 5881 Mayfield Rd., 44124  
**216-449-2770**  
**PARMA HEIGHTS (Cleveland)** — 6483 Pearl Rd., 44130  
**216-842-9100**  
**TOLEDO** — 3231 Dorr St., 43607 **419-531-8921**

## OKLAHOMA

**OKLAHOMA CITY** — 1318 Linwood Blvd., 73106  
**405-232-7515**  
**TULSA** — 3120 S. Sheridan Rd, 74145 **918-622-5666**

## OREGON

**PORTLAND** — 1640 NW Johnson St., 97209  
**503-228-8631**

## PENNSYLVANIA

**ALLENTOWN (Whitehall)** — 2242 MacArthur Rd., 18052  
**215-435-9544**  
**EVANS CITY** — Cranberry Town Center Plaza, 20808 Rt.  
19 N., 16033 **412-779-9600**

**HARRISBURG** — 6080 Allentown Blvd., 17112 **717-545-0651**

**LANCASTER** — 118 Keller Ave., 17601 **717-393-5251**

**PHILADELPHIA** — 9977-81 Bustleton Ave., 19115

**215-464-7771**

**PHILADELPHIA** — 333 North 20th St., 19103 **215-564-5520**

**PITTSBURGH** — 5437 Baum Blvd., 15232 **412-362-2700**

**WILKES-BARRE** — 759 Kidder St., 18702 **717-824-5704**

## PUERTO RICO

**GUAYNABO** — "C" Street # 14, Rexco Industrial Park,  
00922-1924 **809-783-3535**

## RHODE ISLAND

**SEEKONK, MA** — 120 Highland Ave., 02771 **508-336-6510**

## SOUTH CAROLINA

**GREENVILLE** — 1557 Laurens Rd., 29607 **803-232-3038**

## TENNESSEE

**CHATTANOOGA** — Perimeter Place Shopping Ctr., Sp.  
E, 6231 Perimeter Dr., 37421 **615-894-5957**

**KNOXVILLE** — 4118 North Broadway, 37917 **615-688-0921**

**MEMPHIS** — 1085 East Brooks Rd., 38116 **901-332-3444**

**NASHVILLE** — 4811 Nolensville Rd., 37211 **615-833-8277**

## TEXAS

**AMARILLO** — 3008 West 6th Ave., 79106 **806-373-1531**

**AUSTIN** — 6549 Burnet Rd., 78757 **512-459-1133**

**DALLAS** — 2257 Royal Lane, 75229 **214-620-8655**

**EL PASO** — 6822 Gateway East, 79915 **915-778-9769**

**FORT WORTH** — 721 North Beach St., 76111 **817-831-3828**

**GARLAND** — 78 West Centerville Rd., 75043 **214-686-9302**

**HOUSTON** — 536 East Tidwell Rd., 77022 **713-692-7111**

**SAN ANTONIO** — 500 Culebra Ave., 78201 **210-732-1221**

**WEBSTER** — 100 East Nasa Road One, Ste. 75, 77598  
**713-338-4556**

## UTAH

**SALT LAKE CITY** — 1541 S. Third West St., 84115 **801-486-5828**

## VIRGINIA

**FALLS CHURCH** — 344 W. Broad St., 22046 **703-533-7313**

**HAMPTON** — 3416 W. Mercury Blvd., 23666 **804-826-9382**

**NORFOLK** — 7631 Sewells Point Rd., 23513 **804-480-3333**

**RICHMOND** — 1424 Chamberlayne Ave., 23222 **804-649-9245**

## WASHINGTON

**SEATTLE** — 421 S. Michigan, 98108 **206-763-2010**

**SPOKANE** — N. 7011 Division St., 99208 **509-467-8190**

**TACOMA** — 2602 S. 38th St., 98409 **206-473-6040**

## WEST VIRGINIA

**CHARLESTON** — 1638 Sixth Ave., 25312 **304-343-0289**

## WISCONSIN

**MILWAUKEE (Wauwatosa)** — 10424 W. Bluemound Rd.,  
53226 **414-453-4240**

REV: 8/94

# Quick Tips

## QUESTIONS & ANSWERS

### **1. Do I have to set the clock in order to brew coffee?**

No. You don't have to set the clock or the automatic timer to brew coffee. Simply follow the regular brewing instructions and press the "On/Off" Button to begin brewing.

### **2. Do I have to wait until my coffeemaker shuts off automatically to extend the "Keeps Hot" plate for another two hours?**

No. You can extend the "Keeps Hot" plate time for two more hours on the clock models any time during operation by pressing the "On/Off" Button twice — once to turn the unit off and again to turn it back on.

### **3. If there is a power outage, will I lose the brew time I programmed in?**

If the power returns within 30 seconds, the automatic power back-up will save the pre-set brew time and the current time of day on clock models. If the outage lasts longer than 30 seconds, you will have to re-program your clock and timer.

### **4. I have a black model and I noticed a dusty film on the unit. What should I do?**

The black coffeemakers are made of a durable plastic that occasionally develop a thin white film. This is normal. To restore the original black sheen, simply wipe the unit with a soft, dry cloth.

### **5. Will coffee drip from the basket when I remove the carafe during brewing?**

No. The Sneak-A-Cup™ Interrupt Feature on some models has a drip stop that prevents coffee from dripping when the carafe is removed to "sneak-a-cup" during brewing. Be sure to return the carafe to the "Keeps Hot" plate within 60 seconds to avoid overflow from the brew basket.

## ACCESSORIES OR REPLACEMENT PARTS

---

Accessories or parts are available at most Black & Decker Company-Owned Service Centers. However, you may order parts or accessories by phone.

**To place an order by phone, call  
TOLL-FREE: 1-800-258-6003**

Orders may be called in 8:00 a.m. to 4:30 p.m. EST Monday thru Friday. We accept VISA, MasterCard, American Express, or Discover. Offer good only in the United States. Allow 3-4 weeks for delivery.

---

**FULL  
TWO-YEAR  
WARRANTY**

Black & Decker (U.S.) Inc. warrants this product against any defects that are due to faulty material or workmanship for a two-year period after the original date of consumer purchase or receipt as a gift. This warranty does not include damage to the product resulting from accident or misuse. If the product should become defective within the warranty period, we will repair it or elect to replace it free of charge. We will return your product, transportation charges prepaid, provided it is delivered prepaid to any Black & Decker (U.S.) Inc., Household Appliance Company-Owned or Authorized Service Center.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Answers to any questions regarding warranty or service locations may be obtained by calling toll free, 1-800-231-9786, or by writing:

Consumer Assistance and Information  
Black & Decker (U.S.) Inc.  
626 Hanover Pike  
Hampstead, MD 21074-0618



Listed by Underwriters Laboratories Inc.  
Copyright © 1989, 1994 Black and Decker  
Pub. No. 168638-10-RV03  
Printed in U.S.A.

---