



IntelliBoil Jug Kettle



Please read and keep these instructions

Choosing the right temperature for you.

Getting the correct water temperature is essential if you are to enjoy your favourite hot drinks with maximum flavour and taste, e.g. if you're a green tea drinker then water that is brewed too hot will scorch the leaves creating a bitter taste.

The "Quick Reference Guide" table includes some of the most popular drinks, to help you get the most from your IntelliBoil jug kettle.

The IntelliBoil kettle has been pre-programmed with 3 of the most popular temperatures for drinks; 85, 95 and 100 degrees. However if you require a setting which is not pre-programmed, e.g. 45, 50, 60 etc; then you can manually switch off the kettle when the display indicates your required temperature.

By choosing the correct temperature for your drink, not only will you create better tasting drinks, you will also save time and energy too.

Remember : Only boil the correct amount of water you need to help save water and energy.

Quick Reference Guide

Water Temperature	Drinks
85°C	Green, White and Herbal Teas, Powder Based Cold and Flu Remedies, Black Instant Coffee.
95°C	French Press/Cafetiere Coffee Instant Coffee with Milk Hot Toddlies Malted Milk, Hot Chocolate
100°C	Black Teas e.g. Darjeeling, Assam, Ceylon, English Breakfast and Earl Grey, Noodle / Pasta Snacks, Cup of Soup Type Drinks

KT43870 MUK REV1



For replacement parts, help with using your Morphy Richards product, problems and lots more, contact us by phone or through our website.

UK Helpline: 0844 871 0954
Replacement parts: 0844 873 0720
Ireland 1800 409 119

For details of other Morphy Richards products, plus replacement parts and accessories, please see our website:

www.morphyrichards.com

GETTING THE BEST FROM YOUR NEW KETTLE

- **Safety first**
Always pour water slowly and carefully to prevent the splashing of scalding water.
- **Empty the water out of the kettle after first boiling.**
To clean away any deposits that are left in the kettle after the manufacturing process.
- **Descale as appropriate for the hardness of the water in your area.**
It is important to descale as the performance of the kettle for auto switch-off will be impaired.
- **Fast boil kettles perform differently.**
The IntelliBoil Kettle is a fast boil model, it may sound louder during boiling, and switch off suddenly with no after noise - this is normal.

IMPORTANT SAFETY INSTRUCTIONS

The use of any electrical appliance requires the following common sense safety rules.

Primarily there is danger of injury or death and secondly the danger of damage to the appliance. These are indicated in the text by the following two conventions:

WARNING: Danger to the person!

IMPORTANT: Damage to the appliance!

In addition we offer the following safety advice.

Location

- Always locate your appliance away from the edge of the worktop.

- Ensure that the appliance is used on a firm, flat surface.
- Do not use the appliance outdoors or near water.
- **WARNING: Do not place the appliance onto a metal tray or metal surface whilst in use.**

- Extreme caution must be used when moving an appliance containing hot liquid.

- Do not touch hot surfaces, use handles or knobs.
- Always close the lid if applicable and always have the filter in place.

- Avoid contact with emitting steam when the water is boiling or just after it has switched off.

- Take care if opening the lid of the appliance when hot.

- Do not open the lid whilst the water is boiling.

- Do not fill above the MAX mark, otherwise boiling water may be ejected.

- Do not hold the switch in the ON position or tamper with the switch to fix it in the ON position as this may cause damage to the switch-off mechanism.

- Unplug from the outlet before cleaning.

- Allow to cool before putting on or taking off parts and before cleaning.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- Ensure that the kettle is switched off before removing it from its stand.

Children

- Never allow a child to operate this appliance.
- Children are vulnerable in the kitchen particularly when unsupervised and if

appliances are being used or cooking is being carried out.


- Teach children to be aware of dangers in the kitchen, warn them of the dangers of reaching up to areas where they cannot see properly or should not be reaching.
- Children should be supervised to ensure that they do not play with the appliance.

Treating scalds

- Run cold water over the affected area immediately. Do not stop to remove clothing, get medical help quickly.

Other safety considerations

- Do not leave appliance unattended whilst in use.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Contact Morphy Richards for advice.
- The kettle is only to be used with the stand provided.
- The use of attachments or tools not recommended or sold by Morphy Richards, may cause fire, electric shock or injury.
- Do not attempt to connect any other appliance to the base unit or this appliance to another base unit.
- Do not tamper with the connector in any way.
- Do not use the appliance for any use other than to heat water.
- Do not place the appliance on or near a hot gas or electric burner or in a heated oven.
- The appliance must not be on the base unit when being filled with water.



ELECTRICAL REQUIREMENTS

Check that the voltage on the rating plate of your appliance corresponds with your house electricity supply which must be A.C. (Alternating Current).

Should the fuse in the 13 amp plug require changing, a 13 amp BS1362 fuse must be fitted.

If the socket outlets in your home are not suitable for the plug supplied with this appliance, the plug should be removed and the appropriate one fitted.

WARNING: The plug removed from the mains lead if severed, must be destroyed as a plug with bared flexible lead is hazardous.

WARNING: This appliance must be earthed.

FEATURES

- ① Lid with lid release lever
- ② Spout filter
- ③ Base and cable tidy
- ④ 360° connector
- ⑤ Cord storage
- ⑥ Water level indicator with illuminating light
- ⑦ Temperature gauge
- ⑧ + Temperature control button
- ⑨ - Temperature control button
- ⑩ Start/Stop button

- Always ensure that the appliance is filled until the water is visible through the level indicator.
- Boil only as much water as you need as this saves electricity.
- 1 Place the appliance on the base unit, ensuring the appliance locates onto the 360° connector.
- The 360° connector allows the appliance to be located at any position - ideal for left and right handed users and convenient positioning on worktop.
- 2 Plug in and switch on at the wall socket.
- 3 The gauge shows the temperature of the water, if the current water temperature is below 40°C the display will read LO.
- 4 The kettle is automatically set to heat the water to 100°C. To heat the water in the kettle to 85°C or 95°C, use the + and -programming buttons to adjust the selected heating temperature.
- The red dot will highlight the user selected setting and the selected temperature will flash on the digital gauge for 3 seconds.
- After the desired temperature is selected, the display will return to showing the current water temperature.
- 5 Press the start/stop button to begin heating the water. The kettle will beep and show the selected temperature for 3 seconds.
- 6 When the required temperature has been reached, the kettle will beep 3 times and switch off.
- After the kettle has switched off, the display will show the current temperature of the water.
- It is not possible to reheat the water in the kettle until it has dropped below 80°C on the 85°C setting and 90°C on the 95°C. This prevents unnecessary re-heating and energy usage.
- It is not possible to use the kettle to reduce the temperature of previously heated water.
- On the 100°C setting it is possible to re-boil the water as soon as the kettle has switched off.
- When there is no function activated for 15 minutes, the LED display and the internal illumination will switch off. The display will wake up if any button is pressed or if the kettle is lifted up and replaced back on its base.

BEFORE FIRST USE

Before using the appliance for the first time, fill with water, boil and pour away.

Water Temperature

Getting the right water temperature is essential for you to enjoy your favourite hot drinks with maximum flavour and taste. Eg. if you're a green tea drinker, water that is brewed too hot will scorch the leaves and create a bitter taste. If you're a coffee lover, then getting the water temperature is crucial to getting the best flavours from the ground coffee.

See the table on the front of this booklet for a quick reference guide for some of the most popular hot drinks to allow you to get the most from your IntelliBoil Jug Kettle.

OPERATING THE APPLIANCE

The integrated water level indicators allow you to easily see the amount of water in the kettle.

Filter removal

- 1 Open the lid.
- 2 Lift the filter upwards from its location using the tab provided.
- 3 To refit the filter, slot it into the side wall guides and press down firmly. Ensure the filter is correctly located into the central guide.

WARNING: Make sure that the filter is put in correctly otherwise the lid will not close.

Dry Boil

The kettle cuts off and beeps when switched on while empty.

Remove the kettle from its base to stop the beeping and then fill with water for boiling.

Colours

- The kettle features an illuminated water tank which changes colour to reflect the temperature of the water as it is heated. This allows you to easily identify the temperature of the water in the kettle at a glance. When the kettle is switched on the tank is illuminated blue. When the water temperature reaches 76°C, the water is illuminated purple. As the temperature heats to 86°C, the colour changes to orange. When the water temperature reaches 96°C, the water in the kettle is illuminated red. As the water in the kettle cools, the colour of the water reflects the current water temperature.

Temperature	Colour
0°C-75°C	Blue
76°C-85°C	Purple
86°C-95°C	Orange
96°C-100°C	Red

Descaling

IMPORTANT: As this appliance is fitted with a concealed element it must be descaled regularly. The frequency of descaling depends on usage and the hardness of the water in your area.

Excessive scale can cause the appliance to switch off before boiling and may damage the element invalidating the warranty.

It is essential that regular descaling takes place.

Remove hard scale using a proprietary descaling product suitable for stainless steel, glass or plastic.

For plastic kettles please follow the instructions carefully.

Alternatively use citric acid crystals (available from most pharmacies) as follows:

- Fill the appliance 3/4 full, boil, then unplug the appliance (remove the cordless kettle from the base unit) and stand it in an empty sink or bowl.
- Gradually add 50gm of citric acid crystals to the water, then leave the kettle to stand. Do not use a more concentrated solution.
- As soon as the effervescence subsides, empty the appliance and rinse it thoroughly with cold water.
- Wipe the outside of the appliance thoroughly with a damp cloth to remove all traces of acid which may damage the finish.

IMPORTANT: Ensure that the electrical connections are completely dry before using the appliance.

Hints and tips

Cleaning and maintenance

WARNING: Always disconnect the plug from the mains and allow the appliance to cool before cleaning.

Wipe the outside with a damp cloth.

IMPORTANT: Do not use abrasive cleaners on the outside of the appliance which may scratch the surface.

HELPLINE

If you have any difficulty with your appliance, do not hesitate to call us.

We are more likely to be able to help than the store from where you bought it.

Please have the following information ready to enable our staff to deal with your query quickly.

- Name of the product.
- Model number as shown on the underside of the appliance.
- Serial number as shown on underside of the appliance.

UK Helpline 0844 871 0954

Replacement Parts 0844 873 0720

Ireland Helpline 1800 409 119

Website

You may also contact us through our website, or visit the site to browse and purchase appliances, spare parts and accessories from the extensive Morphy Richards range.

www.morphyrichards.com

YOUR TWO YEAR GUARANTEE

It is important to retain the retailers receipt as proof of purchase. Staple your receipt to this back cover for future reference.

Please quote the following information if the product develops a fault. These numbers can be found on the base of the product.

Model no.

Serial no.

All Morphy Richards products are individually tested before leaving the factory. In the unlikely event of any appliance proving to be faulty within 28 days of purchase, it should be returned to the place of purchase for it to be replaced.

If the fault develops after 28 days and within 24 months of original purchase, you should contact the Helpline number quoting Model number and Serial number on the product, or write to Morphy Richards at the address shown.

You may be asked to return a copy of proof of purchase.

Subject to the exclusions set out below (see Exclusions) the faulty appliance will then be repaired or replaced and dispatched usually within 7 working days of receipt.

If for any reason this item is replaced during the 2 year guarantee period, the guarantee on the new item will be calculated from

original purchase date. Therefore it is vital to retain your original till receipt or invoice to indicate the date of initial purchase.

To qualify for the 2 year guarantee, the appliance must have been used according to the instructions supplied. For example crumb trays should have been emptied regularly.

EXCLUSIONS

Morphy Richards shall not be liable to replace or repair the goods under the terms of the guarantee where:

- 1 The fault has been caused or is attributable to accidental use, misuse, negligent use or used contrary to the manufacturers recommendations or where the fault has been caused by power surges or damage caused in transit.
- 2 The appliance has been used on a voltage supply other than that stamped on the products.
- 3 Repairs have been attempted by persons other than our service staff (or authorised dealer).
- 4 The appliance has been used for hire purposes or non domestic use.
- 5 The appliance is second hand.
- 6 Morphy Richards are not liable to carry out any type of servicing work, under the guarantee.

7 Plastic filters for all Morphy Richards kettles and coffee makers are not covered by the guarantee.

8 Batteries and damage from leakage are not covered by the guarantee.

- This guarantee does not confer any rights other than those expressly set out above and does not cover any claims for consequential loss or damage. This guarantee is offered as an additional benefit and does not affect your statutory rights as a consumer.

- This guarantee is valid in the UK and Ireland only.



For electrical products sold within the European Community. At the end of the electrical products useful life it should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice in your country.

morphy richards®

The After Sales Division
Morphy Richards Ltd
Mexborough, South Yorkshire,
England, S64 8AJ

Registration 644702

Helpline (office hours)
UK 0844 871 0954
Republic of Ireland 1800 409 119

Morphy Richards products are intended for household use only.

Morphy Richards has a policy of continuous improvement in product quality and design. The company, therefore reserves the right to change the specification of its models at any time.

For details of other Morphy Richards products, plus replacement parts and accessories, please see our website:

www.morphyrichards.com