



3122 CH

The Original and America's #1 Brand of Slow Cookers

Crock-Pot[®]

Stoneware Slow Cooker



Owner's Guide

READ AND SAVE THESE INSTRUCTIONS

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including the following:

1. Read all instructions before using.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against electrical shock, do not immerse cord, plug, or cooking unit in water or other liquid.
Caution: Never submerge the heating unit in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the manufacturer (see warranty) for examination, repair, or adjustment.
7. The use of accessory attachments not recommended by the manufacturer may cause fire, electric shock or injury.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch heated surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot oil or other hot liquids. Always use hot pads when moving your heated slow cooker.
12. Do not use appliance for other than intended use.
13. Avoid sudden temperature changes, such as adding refrigerated foods into a heated pot.
14. To disconnect, turn CONTROL to OFF, then remove plug from wall outlet.

SAVE THESE INSTRUCTIONS

This appliance is for HOUSEHOLD USE ONLY. No user-serviceable parts inside. Do not attempt to service this product.

A short power-supply cord is provided to reduce the hazards resulting from entanglement or tripping over a longer cord. **AN EXTENSION CORD MAY BE USED WITH CARE; HOWEVER, THE MARKED ELECTRICAL RATING SHOULD BE AT LEAST AS GREAT AS THE ELECTRICAL RATING OF THE SLOW COOKER.** The extension cord should not be allowed to drape over the counter or tabletop where it can be pulled on by children or tripped over.

NOTE: During initial use of this appliance, some slight smoke and/or odor may be detected. This is normal with many heating appliances and will not recur after a few uses.

POLARIZED PLUG



This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way. If the plug fits loosely into the AC outlet or if the AC outlet feels warm do not use that outlet.

HOW TO USE YOUR SLOW COOKER

1. When your slow cooker is switched ON, it will cook on the LOW setting. The LOW setting is recommended for slow "all day" cooking.
2. Frozen foods such as vegetables and shrimp may be used as part of a recipe. However, do not cook frozen meats (such as roasts or chickens) unless you first add at least 1 cup of warm liquid. The liquid will act as a "cushion" to prevent sudden changes in temperature. Cook recipes containing frozen meats an additional 4 to 6 hours on LOW.
3. Always cook with the lid on.
4. Follow recommended cooking times.
5. Do not use slow cooker stoneware for storage of food.
6. Do not reheat foods in your slow cooker.
7. Unplug unit when cooking is done and before cleaning.

HOW TO CLEAN YOUR SLOW COOKER

Unplug unit. CAUTION: Never submerge heating unit in water or other liquid.

1. Fill stoneware with hot or warm soapy water to loosen food remains. Do not use abrasive compounds — a cloth, sponge or rubber spatula will usually remove the residue. If necessary, a plastic cleaning pad may be used. Use a non-abrasive cleaner (such as Bon-Ami® Polishing Cleanser) or vinegar to remove water spots or other stains.
2. The outside case may be cleaned with a soft cloth and warm soapy water. Wipe dry. Do not use abrasive cleaners.
3. The lid may be washed in the top rack of the dishwasher.

CARE OF STONEWARE

As with any fine ceramic, the stoneware bowl will not withstand the shock of sudden temperature changes.

- If the stoneware has been preheated or is hot to the touch, do not put in cold foods. Do not preheat slow cooker before using unless specified in the recipe. The stoneware should be at room temperature before adding hot foods.
- To wash your stoneware right after cooking, use hot water. Do not pour in cold water if the stoneware is hot.

HINTS

- Trim fats and wipe meats well to remove residue. (If meats contain fats, brown in a separate skillet or broiler and drain well before adding to cooker.) Season with salt and pepper. Place meat in cooker on top of vegetables.
- For roasts and stews, pour liquid over meat. Use no more liquid than specified in the recipe. More juices in meats and vegetables are retained in slow cooking than in conventional cooking.
- Most vegetables should be thinly sliced or placed near the sides or bottom of the stoneware. Meats generally cook faster than most vegetables in a slow cooker.
- Use whole leaf herbs and spices for the best and truest flavor for all-day cooking. If ground herbs and spices are used, they should be stirred in during the last hour of cooking.
- Because there is no direct heat at the bottom, always fill the stoneware at least half full to conform to recommended times. Small quantities may be prepared, but cooking time will be affected.
- A specific liquid called for in a recipe may be varied if an equal quantity is substituted. (Such as substituting a 10³/₄ ounce can of soup plus 4 ounces of water for a 14¹/₂ ounce can of tomatoes OR 1/2 cup beef or chicken broth for 1/2 cup of wine, etc.)
- Beans must be softened completely before combining with sugar and/or acid foods (NOTE: Sugar and acid have a hardening effect on beans and will prevent softening). Dried beans, especially red kidney beans, should be boiled before adding to a recipe. Cover the beans with 3 times their volume of unsalted water and bring to a boil. Boil 10 minutes, reduce heat, cover and allow to simmer 1¹/₂ hours or until beans are tender. Soaking in water, if desired, should be completed before boiling. Discard water after soaking or boiling.

QUESTIONS AND ANSWERS

Q “What if the food isn’t done after 8 hours...when the recipe says 8 to 10 hours?”

A This is due to voltage variations which are commonplace everywhere; altitude; or even extreme humidity. The slight fluctuations in power do not have a noticeable effect on most appliances; however, it can slightly alter the cooking times. Allow plenty of time, and remember, it is practically impossible to overcook. You will learn through experience whether to decrease or increase cooking times.

Q “Must the slow cooker be covered? Is it necessary to stir?”

A Cook with the cover on. The slow cooker will not recover heat losses quickly when cooking on **LOW** setting. Significant amounts of heat escape whenever the lid is removed; therefore the cooking time must be extended. Avoid frequent removal of the cover for checking cooking progress or stirring. Never remove cover during the first 2 hours when baking breads or cakes. It is not necessary to stir while cooking on **LOW** heat.

Q “Can I cook a roast without adding water?”

A Yes – if cooked on **LOW**. We recommend a small amount because the gravies are especially tasty. The more fat or “marbling” the meat has, the less liquid you need. The liquid is needed to properly soften and cook vegetables.

GUIDE TO ADAPTING YOUR OWN RECIPES

This guide is designed to help you adapt recipes to the slow cooker — your own favorites and prized recipes collected from friends, food companies, newspapers and magazines. Our aim is to save preparation time with fewer steps and dishes and to keep cooking simple. In most cases, all ingredients can go into your slow cooker in the beginning and can cook all day. Many preparatory steps are unnecessary when using the slow cooker. A few hints:

- Allow sufficient cooking time.
- Cook with cover on.
- Do not add as much water as some recipes indicate.
- Remember — liquids don't "boil away" as in conventional cooking. Usually you'll have more liquid at the end of cooking instead of less.
- It's "one-step" cooking: many steps in recipes may be deleted. Add ingredients to stoneware at one time and cook 8 to 12 hours (add any liquid last).
- Vegetables do not overcook as they do when boiled in your oven or on your range. Therefore, everything can go into the slow cooker at one time. **EXCEPTION:** milk, sour cream or cream should be added during last hour.

GUIDE TO ADAPTING YOUR OWN RECIPES (CONT.)

TIME GUIDE

IF RECIPE FOR OVEN SAYS:	COOK ON LOW IN SLOW COOKER:
15 to 30 minutes	4 to 6 hours
35 to 45 minutes	6 to 10 hours
50 minutes to 3 hours	8 to 18 hours

Most uncooked meat and vegetable combinations will require at least 8 hours on **LOW**.

PASTA AND RICE

If recipe calls for cooking noodles, macaroni, etc., cook on rangetop before adding to slow cooker. Don't overcook — just until slightly tender. If cooked rice is called for, stir in with other ingredients; add $\frac{1}{4}$ cup extra liquid per $\frac{1}{4}$ cup of raw rice. Use long grain converted rice for best results in all-day cooking.

LIQUIDS

Use less in slow cooking — usually about half the recommended amount. One cup of liquid is enough for any recipe unless it contains rice or pasta.

SAUTEING VEGETABLES

Generally not necessary! Stir in chopped or sliced vegetables with other ingredients. **ONLY EXCEPTION:** eggplant should be parboiled or sauteed, due to strong flavor. Since vegetables develop their full flavor potential with slow cooking, expect delicious results even when you reduce quantities. Because vegetables take longer to cook than meat, slice or chop them when possible.

GUIDE TO ADAPTING YOUR OWN RECIPES (CONT.)

HERBS AND SPICES

Leaf or whole herbs and spices are preferred, but their flavor power may increase — use half the recommended amount. If you use ground herbs and spices, add during last hour of cooking.

MILK

Milk, cream and sour cream tend to break down during extended cooking. When possible add during last hour of cooking. Condensed soups may be substituted for milk, etc., and can cook for extended times.

SOUPS

Some soup recipes call for 2 to 3 quarts of water. Add other soup ingredients to slow cooker; then add water only to cover. If thinner soup is desired, add more liquid at serving time. If milk-based recipes have no other liquid for initial cooking, add 1 or 2 cups water. Then during last hour of cooking, stir in milk or cream as called for.

RECIPES

NOTE: The recipes in this manual may be used, as printed, in the 1½, 2, 2½, 3, 3½ Quart Crock-Pot® Slow Cookers.

POT ROAST OF BEEF

2 potatoes, sliced	Salt and pepper to taste
2 carrots, sliced	2 pound beef roast
1 onions, sliced	½ cup beef broth

Put vegetables in bottom of stoneware. Salt and pepper meat to taste, put in pot. Add liquid. Cover; cook on LOW 10 to 12 hours. Remove meat and vegetables with spatula and thicken for gravy if desired (see "HINTS" page 6). Without Vegetables: Season roast with salt and pepper and any other favorite seasonings. Add no liquid. Cook as directed.

HEARTY BEEF STEW

1½ lbs. stew beef, cut in 1-inch cubes	1 can (28-oz.) tomatoes
4 carrots, sliced	2 stalks celery, sliced
1 small onion, diced	2 tbs. quick-cooking tapioca
Salt and pepper to taste	1 whole clove (optional)
	2 bay leaves

Trim all fat from meat. Put all ingredients in stoneware and mix. Cover and cook on LOW 8 to 10 hours.

CHICKEN CACCITORE

1 medium onion, thinly sliced	2 cloves garlic, minced
2-lb. chicken, cut up	2 tsp. oregano leaves
2 cans (6-oz. each) tomato paste	½ tsp. basil leaves
1 can (4-oz.) sliced mushrooms, drained	½ tsp. celery seed
1 tsp. salt	1 bay leaf
½ tsp. pepper	½ cup dry white wine

Place sliced onion in bottom of stoneware. Add chicken pieces. In a bowl, stir together tomato paste, mushrooms, salt, pepper, garlic, herbs and white wine. Pour over chicken. Cover; cook on LOW 8 hours. Serve chicken pieces over spaghetti or vermicelli.

RECIPES

CLASSIC MEAT LOAF

2 lbs. ground chuck
½ cup chopped green pepper
½ cup chopped onion
½ tsp. salt
1 cup cracker crumbs

1 egg
1 packet (½-ounce) brown gravy mix
1 cup milk
4 small potatoes, cubed

Mix all ingredients, except potatoes, in large bowl. Shape into a loaf. Place in stoneware. Place potatoes at the sides of loaf. (If potatoes are peeled, wrap in foil to keep from darkening). Cover and cook on LOW 8 to 10 hours.

ISLANDER PORK

2½ lbs. boneless pork loin-end
or sirloin roast, rolled and tied
5 whole cloves garlic, peeled
½ tsp. nutmeg
¼ tsp. paprika
¼ cup catsup

2 tbs. orange juice
2 tbs. honey
1 tbs. soy sauce
2 tsp. lemon juice
¼ tsp. Kitchen Bouquet® (optional)

Place roast on rack and broil 15 to 30 minutes or until brown. Rub meat with cloves. Place roast in stoneware. Sprinkle with nutmeg and paprika. Stir together catsup, orange juice, honey, soy sauce, lemon juice and Kitchen Bouquet®. Pour over roast. Cover and cook on LOW 8 to 10 hours. Remove meat from stoneware. Juices may be thickened with 1½ tbs. cornstarch and 2 tbs. water.

SWISS STEAK

1½ lbs. round steak, cut ¾-inch thick
2 tbs. flour
1 medium onion, sliced
Salt and pepper to taste

1 carrot, chopped
1 stalk celery, chopped
1 can (15-oz.) tomato sauce

Cut round steak into serving pieces. Season flour with salt and pepper. Dredge meat in seasoned flour. Place onions in bottom of stoneware; add meat. Top with carrots and celery and cover with tomato sauce. Cover and cook on LOW 8 to 10 hours. Creamy Swiss Steak: Place onions and meat in stoneware as directed. Spread one 10-ounce can cream of mushroom soup over meat. Cook as directed.

RECIPES

BARBECUE RIBS

2½ lbs. spareribs
1 bottle (16-oz.) of smoky barbecue sauce
(or 2 cups homemade sauce)

1 onion, sliced
Salt and pepper to taste

Sprinkle ribs with salt and pepper. Place ribs in broiler pan under broiler for 15 minutes to brown and remove excess fat. Put sliced onion in stoneware. Slice ribs into serving pieces and put in slow cooker. Pour in barbecue sauce. Cover and cook on LOW 8 to 10 hours.

Barbecue Meats. Place uncooked, seasoned and cut-up chicken, ham, pork chops, or beef in stoneware. Pour a little barbecue sauce on each piece. Add no water. Cover and cook on LOW 8 to 10 hours.

NOTE: For added flavor, put cooked meat in broiler pan; pour remaining sauce and drippings over top. Place under broiler for 5 to 10 minutes.

SWEET AND SOUR SHRIMP

1 package (6 oz.) frozen
Chinese pea pods, partially thawed
1 can (13 oz.) juice-pack pineapple
chunks or tidbits (drain and reserve juice)
2 tbs. cornstarch
3 tbs. sugar
1 chicken bouillon cube
Fluffy rice

1 cup boiling water
½ cup reserved pineapple juice
2 tsp. soy sauce
½ tsp. ground ginger
2 cans (4½ oz. each) shrimp,
rinsed and drained
2 tbs. cider vinegar

Place pea pods and drained pineapple in stoneware. In a small saucepan, stir together cornstarch and sugar. Dissolve bouillon cube in boiling water and add with juice, soy sauce and ginger to saucepan. Bring to a boil, stirring, and cook sauce for about 1 minute or until thickened and transparent. Gently blend sauce into pea pods and pineapple. Cover and cook on LOW for 5 to 6 hours. Before serving, add shrimp and vinegar, stirring carefully to avoid breaking up shrimp. Serve over hot rice.

RECIPES

ITALIAN TOMATO AND MEAT SAUCE

- | | |
|--------------------------------|-----------------------------|
| 1 ½ lbs. ground chuck, browned | 1 bay leaf |
| 1 cup chopped onion | 2 stalks celery, chopped |
| 2 cloves garlic | 1 tsp. salt |
| 1 can (14½-oz.) tomatoes | 2 tsp. dried oregano leaves |
| 2 cans (6-oz.) tomato paste | ¼ tsp. dried thyme leaves |

Put all ingredients in stoneware. Stir thoroughly. Cover and cook on LOW 8 to 10 hours.

BEEF BOURGIGNON (BEEF STEW WITH WINE)

- | | |
|--|------------------------------------|
| 6 strips bacon, cut in ½-inch pieces | 1 lbs. tomato paste |
| 2 lbs. beef rump or chuck,
cut in 1½-inch cubes | 2 cloves garlic, minced |
| 1 medium carrot, sliced | ¾ tsp. whole thyme |
| 1 small onion, sliced | 1 bay leaf |
| Salt and pepper to taste | ½ lb. tiny white onions |
| 3 tbs. flour | ½ to 1 lb. fresh mushrooms, sliced |
| 1 can (10¾-oz.) condensed beef broth | 2 tbs. butter |
| | ¼ cup red or Burgundy wine |

Cook bacon in large skillet until crisp. Remove and drain. Add beef cubes and brown well. Place browned beef cubes in stoneware. Brown carrot and onion. Season with salt and pepper; stir in flour. Add broth, mix well and add to slow cooker. Add cooked bacon, tomato paste, garlic, thyme, bay leaf and onions. Cover and cook on LOW 8 to 10 hours. Saute mushrooms in butter, and add with wine to stoneware about 1 hour before serving.

SPANISH RICE

- | | |
|------------------------------|---------------------------------|
| 1½ lbs. ground chuck or beef | 1 cup water |
| 1 medium onion, chopped | 2½ tsp. chili powder |
| 1 green pepper, chopped | ½ tsp. salt |
| 1 can (28-oz.) tomatoes | 2 tsp. Worcestershire sauce |
| 1 can (8-oz.) tomato sauce | ¾ cup uncooked rice (converted) |

Brown beef in skillet and drain off fat. Put all ingredients in stoneware. Stir thoroughly. Cover and cook on LOW 7 to 9 hours.

RECIPES

FAVORITE CHILI

- | | |
|---|---|
| ¼ lb. dry pinto or kidney beans
(see page 6) | 1 clove garlic, minced |
| 1 can (14½-oz.) tomatoes | 2 tbs. chili powder |
| 1 lb. coarsely ground chuck,
browned and drained | ½ tsp. ground cumin |
| 1 small onion, chopped | ½ tsp. ground black pepper |
| | ½ green bell pepper, seeded and chopped |
| | Salt to taste |

Completely soften beans as directed on page 6. Put all ingredients in stoneware. Stir to combine. Cover and cook on LOW 8 to 10 hours.

NOTE: One 16-oz. can of red kidney beans, drained, may be substituted for dry beans.

SMOTHERED STEAK

- | | |
|---|---|
| 2 medium onions, sliced | ¼ tsp. paprika |
| 1½ lbs. round steak, ½ to ¾-inch thick,
cut into 5 or 6 pieces | 1 can (4-oz.) sliced mushrooms, drained |
| ¼ cup flour | ½ cup beef broth |
| ½ tsp. salt | 2 tsp. Worcestershire sauce |
| ¼ tsp. pepper | 1 tsp. Kitchen Bouquet® (optional) |

Place layer of onions in bottom of stoneware. Mix flour, salt, pepper and paprika together and dredge steak pieces until lightly coated with flour mixture. Place ½ of meat pieces on onions; add another layer of onions and drained mushrooms. Add remaining meat and onions. Mix beef broth, Worcestershire and Kitchen Bouquet® and pour over entire meat mixture. Cover; cook on LOW 8 to 10 hours.

For gravy: Combine 2 tbs. flour with 3 tbs. water. Stir into drippings and cook until thickened. Pour over steak and serve.

CHICKEN IN A POT

- | | |
|-----------------------------------|--|
| 1 carrot, sliced | 1 tsp. salt |
| 1 onion, sliced | ½ tsp. coarse black pepper |
| 1 celery stalk, sliced | ¾ cup water, chicken broth or white wine |
| 2 lb. whole broiler/fryer chicken | ½ to 1 tsp. basil |

Put vegetables in bottom of stoneware. Add whole chicken. Top with salt, pepper, liquid. Sprinkle basil over top. Cover and cook on LOW 8 to 10 hours. Remove chicken and vegetables with spatula.

RECIPES

NEW ENGLAND STYLE BAKED BEANS

1 lb. dry navy beans
1 lb. smoked ham or ham hocks
or ½-pound cubed salt pork
½ cup chopped onion
1½ cups water

½ cup packed brown sugar
½ cup maple syrup
1 tsp. salt
1 tsp. dry mustard

Completely soften beans as directed on page 6. Drain and put beans in stoneware. Add all remaining ingredients along with the water; mix well. Cover; cook on LOW 10 to 12 hours. Cut ham from bone and return to slow cooker.

CHICKEN IN MUSHROOM GRAVY

2 to 3-lb. chicken, cut up
(or 3 whole chicken breasts, halved)
1 can (10½-oz.) condensed cream
of mushroom soup

½ cup dry white wine or chicken broth
1 can (4-oz.) sliced mushrooms, drained
Salt and pepper

Place chicken pieces in stoneware. Salt and pepper chicken to taste. Mix wine and soup; pour over chicken. Add mushrooms. Cover and cook on LOW 7 to 9 hours. Chicken Parisienne: Prepare recipe as directed above. Remove cooked chicken pieces to warm serving platter. Stir together 1 cup sour cream and ¼ cup flour. Stir sour cream mixture into mushroom gravy. Heat 30 minutes on LOW. Serve sauce over chicken with rice or noodles.

CHICKEN BREASTS À L'ORANGE

3 whole chicken breasts, halved
½ cup flour
1 tsp. salt
1 tsp. nutmeg
½ tsp. cinnamon
Dash ground black pepper
Dash garlic powder
2 to 3 sweet potatoes, peeled and cut into ¼-inch slices

1 can (10½ ounces) condensed cream
of celery or cream of chicken soup
1 can (4 ounces) sliced mushrooms, drained
½ cup orange juice
½ tsp. grated orange rind
2 tsp. brown sugar
3 tbs. flour

Buttered rice. Rinse chicken breasts and pat dry. Combine ½ cup flour with salt, nutmeg, cinnamon, pepper and garlic powder. Thoroughly coat chicken in flour mixture. Place sweet potato slices in bottom of stoneware. Place chicken breasts on top. Combine soup with remaining ingredients except buttered rice; stir well. Pour soup mixture over chicken breasts. Cover and cook on LOW for 8 to 10 hours or until chicken and vegetables are tender. Serve chicken and sauce over hot buttered rice.

RECIPES

STEAK SOUP

2 to 3 cups water
1 can (14½ oz.) tomatoes
1 to 2 onions, chopped
½ tsp. ground black pepper
1 lb. ground beef, coarsely ground
or chuck roast, finely diced and drained
½ cup flour

2 carrots, sliced
1 package (10-oz.) frozen mixed vegetables
2 to 3 stalks celery, chopped
2 to 4 tbs. beef base,
granules or paste
½ cup butter, melted

Put all ingredients except butter and flour in stoneware. Cover and cook on LOW 8 to 12 hours. Make a paste of melted butter and flour. Stir until smooth. Pour into stoneware and stir until blended.

FRENCH ONION SOUP

1 quart beef bouillon or brown stock
3 medium yellow onions, thinly sliced
3 tbs. butter
½ tsp. salt

1 tbs. sugar
2 tbs. flour
½ cup dry vermouth or cognac (optional)
1 cup grated Parmesan cheese

Pour bouillon or stock in stoneware. Cook onions slowly in butter (about 15 minutes) in large covered skillet. Stir occasionally. Uncover and add salt, sugar, flour and vermouth. Stir well. Add to stock in stoneware. Cover and cook on LOW 6 to 8 hours. Before serving, top with grated cheese.

BAKED MACARONI 'N CHEESE

1 package (8-oz.) macaroni,
cooked and drained (6 cups cooked)
2 tbs. oil
1 can (13-oz.) evaporated milk
1½ cups milk

½ tsp. salt
3 cups shredded sharp processed cheese
½ cup melted butter
2 tbs. minced onion

Toss cooked macaroni in 2 tbs. oil. Add all remaining ingredients. Pour into lightly greased stoneware. Stir well. Cover and cook on LOW 3 to 4 hours. Stir occasionally.

NOTES

NOTES

LIMITED ONE-YEAR WARRANTY

Rival® warrants this product to be free from defects in materials or workmanship for one (1) year from date of original purchase. If you have a claim under this warranty please follow these procedures:

- 1) Within the first 45 days from date of original purchase, defective product should be returned to original place of purchase for replacement (with proof-of-purchase).
- 2) Within the first 12 months from date of purchase Rival will repair or replace (at no charge) the defective product if it is delivered freight prepaid during that period to an authorized service station. To obtain warranty service visit:

www.rivalproducts.com

Or, you may write to Rival c/o The Holmes Group, attention: Consumer Returns, 32 B Spur Drive, El Paso, TX 79906. Proof of purchase is required when requesting warranty service - SAVE YOUR SALES RECEIPT. This warranty is extended only to the original purchaser and does not apply to commercial use, unreasonable use, or to damage to the product (not resulting from defect or malfunction) while in the possession of the consumer. **Rival disclaims all responsibility for consequential, incidental, or commercial losses caused by the use of this product.** Some states do not allow this exclusion or limitation of incidental or consequential losses, so the foregoing disclaimer may not apply to you. This warranty gives you specific legal rights, and you may also have other legal rights which vary from state to state.



©2003, Rival

A Division of The Holmes Group