


Auto-Dimming Compass Mirror User Guide

Congratulations! Your new automobile is equipped with an Automatic Dimming Mirror, manufactured by Gentex Corporation. During nighttime driving, this safety feature senses distracting glare from vehicle headlights behind you and automatically dims the mirror to eliminate glare and preserve your vision. The mirror also displays your compass heading.



To Operate the Auto-Dimming Feature

 If the green LED indicator is illuminated, the Auto-Dimming feature is on. 2. If it is not on, push and hold the switch for 3 seconds, or until the green LED is illuminated. Upon release, Auto-Dimming is enabled.

To Operate the Compass Feature

- 1. Push and release the switch in less than 3 seconds to toggle the directional heading display On/Off.
- If the display reads "C", calibrate the compass by driving the vehicle in a complete circle - 360° - at less than five mph.

Cleaning the Mirror

When cleaning the mirror, use a paper towel or similar material dampened with glass cleaner. Do not spray glass cleaner directly on the mirror as that may cause the liquid cleaner to enter the mirror housing and damage the mirror.

Outside Auto-Dimming Mirror With Approach Lighting - If Equipped



CHROME RING

The exterior auto-dimming feature is controlled by the interior auto-dimming mirror and will automatically dim the exterior mirror to eliminate place and preserve your vision when the interior mirror adjusts. The auto-dimming feature of the exterior mirror can be turned on/off by setting the interior mirror's auto-dimming feature to on or off. Refer to "To Operate the Auto-Dimming Feature" section for operation.

The approach lighting feature illuminates the front and rear doors and also shines downward to illuminate the area in front of the doors when the doors are unlocked or opened.

Troubleshooting Guidelines

Mirror, Compass Feature Will Not Function (with ignition "On").

Check to make sure that the ignition battery voltage and ground wires are properly connected.

"C" is Displayed in the Compass Window The compass needs to be calibrated. Drive the vehicle in a circle

The compass needs to be calibrated. Drive the venicle in a circle - 360°- at five mph or less until the display reads a direction. You can also calibrate the compass by driving your vehicle on your everyday routine. The compass will be calibrated once it has tracked one complete circle.

3. Inaccurate Compass Direction

- With the display turned on, push the button for 6 seconds, until the Zone selection comes up (a number will be displayed in the mirror compass window).
- Toggle until correct zone is found and release switch.
 The display will return to the normal compass mode within 10
- The display will return to the normal compass mode within 10 seconds of no switch activity.
 If the vehicle changes zone, repeat steps 1 thru 3. See map.
 If adjusting the zone setting did not correct the compass heading
- error, or if the zone was already properly set for your area, then recalibrate the compass per section 4.
- 4. To Recalibrate the Compass
 - To put the compass in the calibration mode, push and hold the switch for 9 seconds until a "C" appears in the display window.

Calibrate the compass as in number 2 above. Note

- (1) Installing items such as a ski rack, antenna, or even some body repair work can cause changes to the vehicle's magnetic field.

 In these situations, the compass will need to be recalibrated to the
- vehicle's magnetic field.

 (2) The compass may not indicate the correct compass point in tunnels or while driving up or down a steep hill.



