

Novaris

**INSTALLATION and OPERATING
INSTRUCTIONS**

NOVARIS SURGE FILTERS

Three Phase 250A

Handbook No: SFH3-250-xxx-275

Thank you for choosing a Novaris surge filter for your protection requirements. This manual explains the operation and features of your filter as well as installation information. In addition troubleshooting and maintenance guides are provided.

For this filter to function correctly, it must be installed as described. Please instruct your installation personnel to read this manual before proceeding with installation.

WARNING: THIS UNIT IS DESIGNED FOR CONNECTION TO THE AC MAINS. DANGEROUS VOLTAGES EXIST ON COMPONENTS INSIDE THE CASE. THIS PRODUCT MUST BE INSTALLED BY A LICENCED ELECTRICAL CONTRACTOR IN ACCORDANCE WITH AUSTRALIAN STANDARD AS3000 OR THE RELEVANT COUNTRY WIRING RULES.



CONTENTS

1. Operation
2. Specifications
3. Installation
4. Maintenance
5. Warranty



1. Operation

Novaris power line surge filters are designed for the protection of sensitive equipment from the damaging effects of lightning surges, power transients and RF interference.

Novaris hardwire filters comprise MOV surge protection plus LC low pass filters for both single and three phase applications. The prime surge diverting elements are metal oxide varistors of a rating chosen to suit the application. This is primarily based upon current rating of the filter but high surge rating options are available for high exposure sites.

Three stages of protection include metal oxide varistors, inductors and capacitors forming a low pass filter and a final stage of metal oxide varistors.

The first stage of protection consists of the metal oxide varistors. MOVs are connected between each phase and neutral to absorb transverse mode surges usually generated by load switching and other power system disturbances. These MOVs in conjunction with the MOV between neutral and ground absorb common mode surges most often caused by lightning induced disturbances or power system earth faults.

Novaris power filters are designed for general installation at any point in a LV distribution system. When installed near a main switchboard close to the building MEN point the neutral-earth components serve no function but are necessary when the filter is installed at distribution boards some distance from the MEN point to remove possible induced common mode voltages.

The second stage of the filter consists of the inductors and capacitors. The LC section low pass filter elements further attenuate surge voltages already clamped by the MOV stages. In addition the filter stages attenuate noise and power system harmonics. Filter cutoff frequency is around 800Hz. The filter stage is designed to attenuate both transverse and common mode noise.

Metal oxide varistors are voltage dependent electrical resistors with symmetrical V/I characteristics. Their resistance value decreases with increasing voltage, thus "short-circuiting" a further rise in overvoltage. The metal oxide varistors in Novaris Technologies filters are conservatively rated to handle a large number of surge events. However due to the unpredictable nature of transients a varistor may occasionally be overloaded. To sense the integrity of each varistor a fuse is connected in series with each MOV.

Should an overload occur the varistor leakage current will increase causing the fuse to blow.



To sense this condition the terminal voltage of each varistor is monitored. An LED relevant to each MOV is normally ON both at the MOV and on the mimic panel and an alarm condition is signalled to the alarm circuitry.

Each filter capacitor has a series fuse so that capacitor failure will not interrupt supply. Capacitor terminal voltage is also monitored with an LED indicator at the capacitor bank and at the mimic panel and this condition is signalled to the alarm circuitry.

External alarm provision is available via a voltage free changeover contact accessible via terminals on the filter backplane.

Under no fault conditions the mimic panel Filter OK lamp is ON, the Alarm lamp is OFF and the alarm relay is in its energised state.

Please note that the alarm relay contacts are labelled for the non-energised condition.

The alarm circuitry may be tested by holding down the Alarm Test button. The lamps for the Capacitors, MOVs and Filter OK should extinguish regardless of MOV or capacitor condition. The Alarm lamp should light and the relay contacts on the filter backplane should change to the de-energised (Normal) state.

On releasing the test button the lamps and relay will return to their previous state after a short period.

Loss of power to the first or second phase will result in an alarm condition and extinguish all the lamps for the respective phase.

The alarm circuitry is powered from the third phase; loss of power to this phase will result in an alarm condition and extinguish all lamps on the mimic panel.




2. Specifications

Model No:	SFH3-250-xxx-275
No phases:	3
Current Rating:	250A per phase
Rated operating voltage:	240V AC (L-N)
Rated VA:	144KVA
Maximum operating voltage:	275V AC (L-N)
Insertion voltage drop:	<1% per phase at full load
Efficiency:	99%
Protection modes:	Transverse and common mode
Surge withstand:	SFH3-250-50-275 50kA
(8/20µs impulse)	SFH3-250-100-275 100kA
	SFH3-250-150-275 150kA
	SFH3-250-200-275 200kA
	SFH3-250-250-275 250kA
Frequency response:	-3dB point 200Hz
Internal protection:	Each surge diverter individually protected with series fuse and thermal overload indication.
Alarms:	LED display of surge diverter function for the SFH3-250-50-275 versions. Digital display of % active for 100kA-250kA units using MULTIMOV. External alarm via voltage N/O contact. Other options available.
Dimensions enclosure:	710H x 710W x 285D (enclosure) 640H x 658W x 260D (backplane)
Enclosure:	Pressed steel powdercoated.
Environmental rating:	IP55
Location:	Main switchboard or distribution board in all TN and TT distribution systems.



3. Installation

One of the most important factors determining the performance of Novaris filters is the manner in which they are installed.



It is mandatory that Novaris filters be installed by a licensed electrician in accordance with Australian Standard AS3000 or the relevant country wiring rules. To meet AS3000 the filter must be protected by a circuit breaker or fuses of rating equal to the current rating of the filter. 63A filters may be fitted with line fuses. If these are not included the filter must be preceded by external fuses or a circuit breaker.

If some latitude is allowed in the positioning of this filter, choose a location which affords a short direct run to a substantial earthing point, either a station earth bar or switchboard earth bus.

The filter should be installed before any earth leakage protection devices although earth leakage is negligible and once power is applied ELCB operation will not be affected.

The purpose of the filter is to remove surges and other transient overvoltage disturbances which may be caused by induction or direct injection. It is therefore vital to segregate input and output cabling. Do not run these cables in a common duct. Treat the input cabling as "dirty".

The optimum cabling configuration is to run input or line side cabling in the bottom left hand side of the cabinet and output or load cabling out the bottom right hand side.



Correct earthing is essential. Run an earth conductor of size specified in AS3000 or the relevant wiring rules to the nearest earth bar or station earth bus. Avoid sharp bends and keep the earth conductor as short as possible. The best earth connection is made with 25 x 3mm copper strap. Otherwise use at least 16mm² conductor.

Connect the external alarm if necessary. A voltage free N/O contact is provided. Rewiring the alarm connections to the line and load side surge diverters may modify this. Maximum conductor size is 2.5mm². These contact descriptions relate to the power on condition. Under normal operating conditions the relay is energised.

After installation the filter may be tested for continuity and insulation with a hand held multimeter. A megger test will indicate excessive leakage, as it will cause the surge suppression components to operate.



4. Maintenance

Novaris surge filters are virtually maintenance free. Should any abnormality arise the filter will initiate an alarm condition, which will enable the external alarm. Inspection of the internal alarms will reveal the nature of the fault. Note that a power failure will be interpreted as an alarm condition.

The surge diverting components are all enclosed in metal cases and may be replaced individually. These devices are either DIN rail mounted and may be clipped in and out. Alternatively MULTIMOV surge diverters may be panel mounted. These are simply held in place with four screws.

**DANGEROUS VOLTAGES EXIST INSIDE THE CABINET.
THIS WORK SHOULD ONLY BE CARRIED OUT BY QUALIFIED PERSONNEL.**

In all cases of suspected faults contact your distributor or Novaris Pty Ltd for advice.

A filter exhibiting an alarm condition does not necessarily have to be taken out of service. In most cases some form of protection will still be provided.

80kA, 120kA, 160kA and 200kA versions feature redundant line side MULTIMOV surge diverter segments so that a segment failure will not effect filter performance.



5. Warranty

This is limited to 5 years and is given by Novaris Pty Ltd (Novaris) to the original purchaser of products made by Novaris ("the products"). The warranty certificate must be completed by the distributor and the purchaser in order to claim under this warranty.

1. What Novaris will do

If the product fails under normal use and service because of a manufacturing defect in materials or workmanship within 5 years from the date of purchase Novaris will at its option, either repair or replace the product with an equivalent product. The repaired or replacement product will be warranted under the terms of this warranty for the remainder of the warranty period for the product originally supplied.

2. How to obtain warranty service

To obtain warranty service you must return the product to Novaris. The product must be accompanied by the warranty certificate duly completed along with your sales receipt or invoice. Freight and insurance is your responsibility.

3. What is not covered

This warranty does not cover any failure of equipment not supplied by Novaris or any consumables* attached to or forming part of the product nor does it cover any failure of or damage to the product due to:

- (a) it being connected to equipment or accessories not authorised by Novaris.
- (b) improper handling, misuse, neglect, accident, improper installation or non compliance with the directions for use;
- (c) any alteration or modification which in the opinion of Novaris will affect the ability to service the product, or
- (d) repair by anyone other than an authorised Novaris service agent

No guarantee is given concerning the operation of surge or transient protection products since atmospheric lightning discharges are an unpredictable process subject to the laws of nature and independent of human control. The products do not provide total protection. Component parts of some products may be sacrificial when exposed to the effects of lightning and also voltage surges and transients. Novaris does not guarantee repair or replacement services will be available after expiration of the 5 year warranty period.



4.Rights under the Trade Practices Act

It is acknowledged by Novaris that, under applicable State and Commonwealth Law certain conditions may be implied and rights and remedies conferred on the purchaser in relation to the product which cannot be excluded, restricted or modified by agreement (non excludable rights).

Novaris disclaims all express or implied conditions and warranties in relation to the product other than the express terms of this warranty and any excludable rights. Novaris' responsibility to the Purchaser is, where permitted, limited to the undertakings stated in section 1 of this warranty and subject to the above, in no event is Novaris liable (where before or after discharge of the contract for supply of the product or otherwise) for any loss or damage suffered by the Purchaser as the user caused or contributed to by negligence of Novaris, its servants or agents, nor is Novaris liable for special, incidental, indirect or consequential loss or damage suffered by the Purchaser including but not limited to economic loss, loss of profit or revenue or reputation or costs arising from the loss of use of the product.

*consumables include indicator lamps and illumination sources, items made wholly or partly of glass or ceramic material, electrical elements, transformer windings, electric motors, reconditioned parts and batteries.

