

900W DMX Fog Machine

AF-1213

User Manual



WARNING

FOR YOUR OWN SAFETY, PLEASE READ THIS USER MANUAL CAREFULLY
BEFORE YOUR INITIAL START-UP!



CAUTION!

Keep this equipment away from rain,
moisture and liquids.



manual.

Please note that damages caused by user modifications to this equipment are not subject to warranty.

Important

The manufacturer will not accept liability for any resulting damages caused by the non-observance of this manual or any unauthorized modification to the equipment.

Never let the power-cable come into contact with other cables. Handle the power-cable and all mains voltage connections with particular caution!

Never remove warning or informative labels from the equipment.

Do not open the equipment and do not modify the equipment.

Only use the equipment indoors.

Do not expose to flammable sources or gases.

Always disconnect the power from the mains when equipment is not in use or before cleaning! Only handle the power-cable by the plug. Never pull out the plug by pulling the power-cable.

Make sure that the available voltage is 240VAC.

Make sure that the power-cable is never crimped or damaged. Check the equipment and the power-cable periodically.

If the equipment is dropped or damaged, disconnect the mains power supply immediately. Have a qualified engineer inspect the equipment before operating again.

If the equipment has been exposed to drastic temperature fluctuation (e.g. after transportation), do not switch it on immediately. The arising condensation might damage the equipment. Leave the equipment switched off until it has reached room temperature.

Only use fuses of same type and rating.

Repairs, servicing and power connection must only be carried out by a qualified technician. **THIS UNIT CONTAINS NO USER SERVICEABLE PARTS.**

OPERATING DETERMINATIONS

If this equipment is operated in any other way, than those described in this manual, the product may suffer damage and the warranty becomes void. Incorrect operation may lead to danger e.g. short-circuit, burns, electric shocks etc.

Do not endanger your own safety and the safety of others! Incorrect installation or use can cause serious damage to people and property.

Before filling the unit disconnects the mains. Never fill with hot liquids. **Only use high quality, water based smoke fluid recommended by the manufacturer. Other smoke fluids may cause clogging.**

Always make sure there is sufficient smoke fluid in the tank. Operating this smoke machine without smoke fluid will cause damage to the pump as well as overheating of the heater.

Operate the unit only after you have familiarized yourself with its functions, Do not permit operation by persons not qualified for operating the unit and always drain the tank and use the original packaging if the unit is to be transported.

CONTROLLER OVERVIEW:

Timer Remote Operations:

Warm Up Time

This 900W DMX fog machine has a warm up time of approximately 7 minutes. Once the machine has warmed up, please follow the instructions below.

Interval Time Setting

To set the interval times, press the **"MENU"** button to show Interval on the LCD display. Now use the **"UP"** and **"DOWN"** buttons to increase or decrease the interval times between each burst. The interval time can be set from 1-900s.



Duration Time Setting

To set the duration times, press the “**MENU**” button to show Duration on the LCD display. Now use the “**UP**” and “**DOWN**” buttons to increase or decrease the duration between each burst. The duration time can be set from 1-200s.

Output Volume Setting

To set the output volume, press the “**MENU**” button to show Output on the LCD display. Now use the “**UP**” and “**DOWN**” buttons to increase or decrease the smoke output each burst. The output volume can be set from 0-100%.

Manual Fogging

For manual fog output, simply press the “**MANUAL**” button and hold until the desired amount of smoke is emitted.

Constant Burst Operation

To set unit for constant burst, press the “**LOCK**” button. To stop the constant burst simply press the “**LOCK**” button again. During this operation you can change the volume output by pressing the “**UP**” and “**DOWN**” buttons.

Timer Operation

To use the timer operation, press the “**TIMER**” button. The timer will now work with the Interval, Duration and Volume setting that you have previously set. To change any of the

settings for these options please follow the steps on the previous page.

DMX Address Setting

There are two methods to set the units DMX address: one is pressing the “**MENU**” button to show DMX-512 on the LCD display. Now use the “UP” and “DOWN” buttons to set the desired DMX address from 001-512, another is setting DMX Address through DIP Switch as usually. For DMX function, please refer to the DMX chart below:

DMX Chart

Channel	Value	Function
1	0-255	Manual fogging (low - high output)

STARTING OPERATION

The fluid tank of the unit needs to be filled with smoke fluid before switching on. Always disconnect it from the mains supply as fluid could be spilled.

Only use quality smoke fluids recommended by your dealer. We recommend high quality smoke fluids. You must not use substances which are classified as “**DANGEROUS WORKING MATERIALS**” or “**FLAMMABLE FLUIDS**”.

If fluid should get inside the main housing, disconnect the unit from the mains immediately and consult a technician.

OPERATION

Before switching the unit on, please make sure that the LCD timer remote control is connected to the unit properly.

After switching on via the On/Off switch the controllers LCD screen will display “**WARMING UP**”. When the unit has reached the correct temperature, the LCD display will show “**READY TO FOG**” and the unit is now ready for operation.

DMX Control Mode

Operating in a DMX control mode environment gives the user the greatest flexibility when it comes to customizing or creating a show. In this mode you will be able to control each individual trait of the fixture and each fixture independently.

When under DMX mode with DMX cable connected, MANUAL AND WIRELESS IS INVALID; if you need to use MANUAL AND WIRELESS Function, you must unplug the DMX cable.

Setting the DMX address

The DMX mode enables the use of a universal DMX controller. Each fixture requires a “start address” from 1- 511. A fixture requiring one or more channels for control begins to read the data on the channel indicated by the start address.

For example, a fixture that occupies or uses 7 channels of DMX and was addressed to start on DMX channel 100, would read data from channels: 100,101,102,103,104,105 and 106. Choose a start address so that the channels used do not overlap. E.g. the next

unit in the chain starts at 107.

DMX-512:

- DMX (Digital Multiplex) is a universal protocol used as a form of communication between intelligent fixtures and controllers. A DMX controller sends DMX data instructions from the controller to the fixture.

DMX data is sent as serial data that travels from fixture to fixture via the DATA "IN" and DATA "OUT" XLR terminals located on all DMX fixtures (most controllers only have a data "out" terminal).

DMX Linking

- DMX is a language allowing all makes and models of different manufactures to be linked together and operate from a single controller, as long as all fixtures and the controller are DMX compliant.

To ensure proper DMX data transmission, when using several DMX fixtures try to use the shortest cable path possible. The order in which fixtures are connected in a DMX line does not influence the DMX addressing. For example; a fixture assigned to a DMX address of 1 may be placed anywhere in a DMX line, at the beginning, at the end, or anywhere in the middle.

When a fixture is assigned a DMX address of 1, the DMX controller knows to send DATA assigned to address 1 to that unit, no matter where it is located in the DMX chain.

DATA Cable (DMX cable) requirements (for DMX operation):

- The 900W DMX FOG MACHINE can be controlled via DMX-512 protocol. The DMX address is set on the back of the unit. Your unit and your DMX controller require a standard 3-pin XLR connector for data input/output as follows:.



Also remember that DMX cable must be daisy chained and cannot be split.

DIP SWITCH REFERENCE CHART DIP SWITCH POSITION

DMX DIP SWITCH SET 0=OFF 1=ON					#9	0	0	0	0	0	0	0	0	1	1	1	1	1	1	1	1		
					#8	0	0	0	0	1	1	1	1	0	0	0	0	1	1	1	1	1	1
					#7	0	0	1	1	0	0	1	1	0	0	1	1	0	0	1	1	1	1
					#6	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1
#1	#2	#3	#4	#5																			
0	0	0	0	0		32	64	96	128	160	192	224	256	288	320	352	384	416	448	480			
1	0	0	0	0	1	33	65	97	129	161	193	225	257	289	321	353	385	417	449	481			
0	1	0	0	0	2	34	66	98	130	162	194	226	258	290	322	354	386	418	450	482			
1	1	0	0	0	3	35	67	99	131	163	195	227	259	291	323	355	387	419	451	483			
0	0	1	0	0	4	36	68	100	132	164	196	228	260	292	324	356	388	420	452	484			
1	0	1	0	0	5	37	69	101	133	165	197	229	261	293	325	357	389	421	453	485			
0	1	1	0	0	6	38	70	102	134	166	198	230	262	294	326	358	390	422	454	486			
1	1	1	0	0	7	39	71	103	135	167	199	231	263	295	327	359	391	423	455	487			
0	0	0	1	0	8	40	72	104	136	168	200	232	264	296	328	360	392	424	456	488			
1	0	0	1	0	9	41	73	105	137	169	201	233	265	297	329	361	393	425	457	489			
0	1	0	1	0	10	42	74	106	138	170	202	234	266	298	330	362	394	426	458	490			
1	1	0	1	0	11	43	75	107	139	171	203	235	267	299	331	363	395	427	459	491			
0	0	1	1	0	12	44	76	108	140	172	204	236	268	300	332	364	396	428	460	492			
1	0	1	1	0	13	45	77	109	141	173	205	237	269	301	333	365	397	429	461	493			
0	1	1	1	0	14	46	78	110	142	174	206	238	270	302	334	366	398	430	462	494			
1	1	1	1	0	15	47	79	111	143	175	207	239	271	303	335	367	399	431	463	495			
0	0	0	0	1	16	48	80	112	144	176	208	240	272	304	336	368	400	432	464	496			
1	0	0	0	1	17	49	81	113	145	177	209	241	273	305	337	369	401	433	465	497			
0	1	0	0	1	18	50	82	114	146	178	210	242	274	306	338	370	402	434	466	498			
1	1	0	0	1	19	51	83	115	147	179	211	243	275	307	339	371	403	435	467	499			
0	0	1	0	1	20	52	84	116	148	180	212	244	276	308	340	372	404	436	468	500			
1	0	1	0	1	21	53	85	117	149	181	213	245	277	309	341	373	405	437	469	501			
0	1	1	0	1	22	54	86	118	150	182	214	246	278	310	342	374	406	438	470	502			
1	1	1	0	1	23	55	87	119	151	183	215	247	279	311	343	375	407	439	471	503			
0	0	0	1	1	24	56	88	120	152	184	216	248	280	312	344	376	408	440	472	504			
1	0	0	1	1	25	57	89	121	153	185	217	249	281	313	345	377	409	441	473	505			
0	1	0	1	1	26	58	90	122	154	186	218	250	282	314	346	378	410	442	474	506			
1	1	0	1	1	27	59	91	123	155	187	219	251	283	315	347	379	411	443	475	507			
0	0	1	1	1	28	60	92	124	156	188	220	252	284	316	348	380	412	444	476	508			
1	0	1	1	1	29	61	93	125	157	189	221	253	285	317	349	381	413	445	477	509			
0	1	1	1	1	30	62	94	126	158	190	222	254	286	318	350	382	414	446	478	510			
1	1	1	1	1	31	63	95	127	159	191	223	255	287	319	351	383	415	447	479	511			

CLEANING AND MAINTENANCE



Disconnect from the mains before starting maintenance



Smoke fluids we recommend are non-hazardous to the environment and can be disposed of via the sewage system.

There are no user serviceable parts inside this unit except for the fuse. Maintenance and service operations are only to be carried out by authorized dealers.

REPLACING THE FUSE

Only replace the fuse with a fuse of same type and rating.

Before replacing the fuse, disconnect from the mains.

Procedure:

Step 1: Open the fuse holder on the rear panel with a suitable screwdriver.

Step 2: Remove the old fuse from the fuse holder

Step 3: Install the new fuse in the fuse holder

Step 4: Replace the fuse holder in the housing.

Should you need any spare parts, only use genuine parts. If defective, please dispose of the unusable unit in accordance with the current legal regulations. Should you have any further questions, please contact your dealer.

Technical Specifications

Smoke output	10,000 cubic ft per minute
Warm up time	Up to 7 minutes
Tank capacity	1.2L
Power consumption	900W
Power supply	240V
Dimensions	35.5 X 16.5 X 23CM
Weight	3Kgs

LCD-Controller

Cable length	2.5M
Connector	5-pin XLR
Function	Interval, Duration, Output and DMX
Dimensions	15 x 7.5x 3CM
Weight:	0.46Kgs



CAUTION! TAKE CARE USING THIS EQUIPMENT!



HIGH VOLTAGE-RISK OF ELECTRIC SHOCK!!

