

ARF35

User Guide



PRESENTATION	3
PRODUCT POWER SUPPLY	4
SERIAL LINK WIRING	5
<i>MODEM / DTE RS232</i>	<i>5</i>
<i>DCE RS232</i>	<i>5</i>
<i>RS485 wiring</i>	<i>5</i>
<i>RS485 interface activation</i>	<i>6</i>
RADIO COMMUNICATION	7
<i>Communication channels</i>	<i>7</i>
<i>RSSI reading</i>	<i>7</i>
WORKING MODE	8
<i>Addressed mode</i>	<i>8</i>
<i>Serial commands</i>	<i>8</i>
<i>Set of commands</i>	<i>9</i>
<i>Description of the registers</i>	<i>9</i>
<i>Configuration of the serial interface</i>	<i>12</i>
<i>MODBUS compatibility</i>	<i>13</i>
<i>Sending a serial command using HYPERTERMINAL</i>	<i>13</i>
SPECIFICATIONS	14
ANNEX 1 - Firmware updates	15

DECLARATION OF CONFORMITY

according to ISO/IEC Guide 22 and EN45014



Manufacturer's name: **ADEUNIS R.F.**

Manufacturer's address Parc technologique PRE ROUX IV
283 rue Paul Louis NEEL
38920 CROLLES - FRANCE

declares that the product

Product Name: ARF35
Product Number(s): ARF7120C / ARF7120D / ARF7120E / ARF7120F
Product options:

conforms to the RTTE Directive 99/5/EC:

EMC: conformity is proven by compliance to the standard EN 301489 according to the requirements of EMC Directive 89/336/EEC.

Safety: conformity to the standard EN 60950 according to the requirements of Low Voltage Directive 73/23/EEC.

Radio: conformity is proven by compliance to harmonised standard EN 300220 covering essential radio requirements of the RTTE directive.

Notes: - Conformity has been evaluated according to the procedure described in Annex III of the

RTTE directive.

- The use of the spectrum is harmonised by the fact that the product never falls in one of the restrictions listed in appendix 3 (Annex 1, band E) of the CEPT recommendation 70-03.

- Receiver class (if applicable): 2.

Crolles, December 3rd, 2004

VINCENT Hervé / Quality manager

PRESENTATION

The modem converts data from a serial link into a radio frame to be sent to a similar piece of equipment.




The operating parameters of these modems (serial link, radio management....) can be modified through commands on the serial link.


The products are available either in card version to be integrated in an assembly or as an IP65 chip with integrated or external antenna (RG58C cable + TNC connector).

PRODUCT POWER SUPPLY

To perform wiring of these products, the bottom part of the housing (part with stuffing box) has to be opened by unscrewing the two stainless steel screws on each side.



The ARF35 range products are supplied from a **DC voltage** source. This voltage source must be 8V minimum and must not exceed 30 V_{DC}.



The INHIB input MUST be connected to +V for turning ON the modem


➔ The INHIB input must be used to turn ON or OFF the modem according to the following table

IN HI B	Modem power supply
GN D	OFF
unc onn ecte d	OFF
+ V (8- 32v)	ON

SERIAL LINK WIRING


- **MODEM / DTE RS232**

This is for example the case of a modem connected to a PC




- **DCE RS232**

This is for example the case of a modem connected to a measuring device.



- **RS485 wiring**



The RS485 link needs to be adapted (each side). The modem includes a 100Ω termination resistor:

- Jumper mounted, the resistor is connected between A and B (respectively RX+ and RX-)
- No jumper, the resistor is not connected between A and B

If the modem is ending the RS485 bus, the jumper must be mounted.

The RS485 bus wiring needs only two wires for the PCB revision B (ARF7120/B) or greater. For the PCB revision A (ARF7120/A), the TX+ (respectively TX-) and RX+ (respectively RX-) MUST be connected together by the USER.




Figure 1: RS485 wiring, PCB marked ARF7120/B or greater





Figure 2: RS485 wiring, PCB marked ARF7120/A

The wiring could be checked by sending the SLI command using a terminal (see serial command). If the link is properly configured, the modem register values are sent back by the modem to the terminal (if not try to reverse the RS485 bus polarity → reverse RX+/TX+ with RX-/TX- connection).

- **RS485 interface activation**

When delivered the product is configured in RS232 → for **ACTIVATING** the RS485 interface, please refer to chapt. **Configuration of the serial interface**

WARNING: when using the RS485 interface, the minimum time for switching from RS485 transmission to RS485 reception is 4 ms, 20 ms for baudrate 600 and 1200bps.



RADIO COMMUNICATION


- Communication channels

This modem has 2 or 5 channels that could be selected through commands

C h a n n e l S 2 0 0	2-channel version Frequency (Radio data rate 34800 kbit/s)	5-channel version Frequency (Radio data rate 9600 kbit/s)
0	869.4625 MHz	869.425 MHz
1	869.5875 MHz	869.475 MHz
2		869.525 MHz
3		869.575 MHz
4		869.625 MHz

- RSSI reading

The RSSI (Received Strength Signal Indicator) gives an indication for the received power level.



Notes:

- The RSSI level is only an indicator. Use this level with care due to the dispersion between components.
- The schema above could be modified from one to another product. The Operating temperature could also have an impact on these dispersions.
- The RSSI level could also indicate the potential presence of jammer in the used channel.
- **The RSSI is a necessary but not sufficient condition to obtain a correct reception.**

WORKING MODE

Half duplex transmission

This modem has 2 working modes:

- Transparent mode, without flow control. When transmitting, data received from the serial link are transmitted on the radio link. When data are received on the radio link, these data are sent on the serial link.
- Addressed mode, with flow control (see register S216)

In these modes, the frame transmission always start on the following conditions:

- Detection of a silence on the serial link, greater than S217, after the reception of the latest character.
- Or when the number of received characters from the serial link is greater or equal to the maximum radio frame size (S218).

- **Addressed mode**

In transmission mode, data received on the serial link are sent on the radio link with the following format:

- Frame format: <preamble><synchro><Address> DATA <postamble>. Preamble, synchronisation and postamble are used for the radio reception.
- The Address field is set up with S256 (destination address) value (LSB first).

In reception mode: The <Address> field of the radio frame is checked with the local address (S252)

- If the addresses match, DATA (and only DATA) are transmitted on the serial link, otherwise received data are silently discarded.

- **Serial commands**

- They are used to configure the modem parameters or read the modem set-up.
- They are sent during the modem mode. They aren't sent on the radio link.
- A SLSTRING is interpreted as a command only if a silence is present before (see <silenced>) the SLSTRING and after (see <silencef>) the SLSTRING. Otherwise the string is not interpreted as a command, and therefore it is sent on the radio link.

Serial Command format: <silenced>SLSTRING<silencef> with

- <silenced>: silence before the command, more than 3 characters (see S214).
- SLSTRING, serial command, always starting with the characters SL. (Example SLI for displaying modem registers)
- <silencef> : end silence, more than 3 characters (see S214)

The answer to a SL command could be:

- the string OK → command executed successfully
- The string ERROR (syntax error, unknown command...)
- a specific string according to the requested information

Sending a serial command using a terminal: see chapt. *Sending a serial command using HYPERTERMINAL*

- Set of commands

Commands	Description	Note
SL#=xxxx	Program all the addresses (TX/ RX) with value xxxx = hexadecimal address (0000... FFFF)	
SL@R?	Display the reception level of the latest received message. Response: -xxx dBm with xxx decimal value The RSSI values are between -115 and -60 dBm.	
SL**>	Save the current configuration in EEPROM. Each time you switch on the modem, the EEPROM configuration will be loaded in the modem registers.	
SL%V?	Display the software version (response Vn.nn)	
SLSn?	Reading the value of register n	
SLSn=m	Initialise the register n with the value m (m=0000...FFFF)	
SLR	All the registers are initialised with their default value	
SLTn	auto-test mode (n = test number) SLT1 = carrier emission, TX data = 0 SLT2 = carrier emission, TX data = 1 SLT3 = 19200 kHz modulation (38400 bauds) SLT4 = 1 kHz modulation (2000 bauds) Test mode exit : by updating the working mode (SLS220=x)	1
SLI	Display all the registers values	

Note 1: During SLTn command transmission, the new working mode (S220 register) is stored in E2PROM → The modem will run again in auto-test mode at each power up. To leave the auto-test mode, you have to modify the S220 register and save the parameters.

- Description of the registers

The parameters of the modems could be updated through the SLS commands and save in EEPROM.

When upgrading a register value, the value is updated in RAM. You must use the SL**> command to save the parameters in EEPROM. In case of parameters lost, the default values are restored.

Access	Register	Function	Description	Note
R/W	S200	Channel number	Radio control Communication channel. Value between '0' and '4'. Default value: '0' 2-channel version 0 → 869.4625 MHz, 1 → 869.5875 MHz 5-channel version 0 → 869.425 MHz, 1 → 869.475 MHz, 2 → 869.525 MHz, 3 → 869.575 MHz, 4 → 869.625 MHz	
R/W	S218	Radio frame size	Maximum size of the radio frame data. When this size is reached, the CTS signal is activated. From 50 up to 240. Default value: 128	
R	S230	RSSI value	Read of the RSSI signal value (read on the ADC converter, hexadecimal value)	
			Serial link control	

R/W	S210	Baud rate	Serial data rate '0' : 600 bits/s '1' : 1 200 bits/s '2' : 2 400 bits/s '3' : 4 800 bits/s '4' : 9 600 bits/s (Default value) '5' : 19 200 bits/s '6' : 38 400 bits/s	1, 4
R/W	S211	Number of bits	'7' : 7 bits '8' : 8 bits (Default value)	
R/W	S212	Parity	'1' : none (Default value) '2' : even '3' : odd	
R/W	S213	Number of stop bits	'1' : 1 stop bit (Default value) '2' : 2 stop bits '3' : 3 stop bits	2
R/W	S214	Time out	Serial link Time out to detect a command (units 1 ms). Value from 3 up to 240. Default value: '3' (3 ms = 3 characters at 9600 bauds)	1
R/W	S215	Interface type	'0' : RS232 (Default value) '1' : RS485 half duplex	3
R/W	S216	Flow Control	'0' : hardware (RTS/CTS) '2' : none, default value	
R/W	S217	Start transmission Time out	Serial link Time out to start the radio transmission (units 1 ms). Value from 3 up to 240. Only one value: '3' (3 ms = 3 characters at 9600 bauds)	1
			Working type	
R/W	S220	Working mode	'1' = transparent mode '6' = addressed (default value) from '11' up to '14' → auto-test	
			Network control (addressed mode only)	
R/W	S252	Local Address	2 bytes value, from 0 to FFFF In addressed mode, allow filtering the incoming radio frame (all frame with an <address> field different from this local address are silently discarded)	
R/W	S256	Destination Address	2 bytes value, from 0 to FFFF In addressed mode, the <address> field of a radio frame is filled with this destination address)	

Note 1: when a serial speed change is requested, the S214 and S217 register values are automatically set to a value greater or equal to the duration of three characters in the requested speed (13 ms for 2400 bauds, 7 ms for 4800, 3 ms otherwise).

Note 2: 3 stop bits are only usable with 8 bits of data. With 7 bits of data and 3 stop bits, the serial format used is 7 bits of data and 1 stop bit.

Note 3: When changing the interface type (example: RS232 to RS485), the response is sent before the interface updates (in our example on the RS232 link); the following serial communications must be done on the new interface (in our example, on the RS485 link).

As a reminder: the parameters are saved with the SL**> command.

Note 4: If the flow control is not used, the serial data rate must be coherent with the radio rate. For example, with the 5-channel version the radio rate is 10 kbit/s: a serial rate of 9600 must be used without flow control, while using a serial rate of 19200 will produce data overrun (radio reception buffer)

Configuration of the serial interface

The choice between the RS232 or 485/422 interface depends of the S215 register value. There is two ways for activating the RS485 mode:

- Software mode (updating the S215 value using a command)
- Hardware mode (forcing default parameters)

Serial interface switching, software mode

For switching from RS232 to RS485 interface:

- Step 1. Connect both RS232 and RS485 interface to your modem
- Step 2. Using the RS232 serial link, send the serial command SLS215=1
- Step 3. Now the RS485 interface is activated; (Using the RS485 link send the SLI command for checking the RS485 activation)
- Step 4. Using the RS485 interface send the SL**> command for saving the S215 register value. Now at next start-up, the product will work with the RS485 interface

For switching from RS485 to RS232 interface:

- Step 1. Connect both RS232 and RS485 interface to your modem
- Step 2. Using the RS485 serial link, send the serial command SLS215=0
- Step 3. Now the RS232 interface is activated; (Using the RS232 link send the SLI command for checking the RS232 activation)
- Step 4. Using the RS232 interface Send the SL**> for saving the S215 register value. Now at next start-up, the product will work with the RS232 interface

Serial interface switching, Hardware mode

The kind of interface can be updated when the modem is powered up: the configuration switches (#2 and 4) allow choosing a requested configuration.

- **WARNING: when using these switches the new configuration is saved in EEPROM**

Hardware switch to RS232 interface:

1. Switch off the module
2. Put the switch 2 in position ON
3. Switch on the modem → the green led is ON
4. Put the switch 2 in position OFF
5. The modem is ready to work with the RS232 interface (the serial parameters used in RS485 mode are preserved).

Hardware switch to RS485 interface:

1. Switch off the module
2. Put the switch 4 in position ON
3. Switch on the modem → the green led is ON
4. Put the switch 4 in position OFF
5. The modem is ready to work with the RS485 interface (the serial parameters used in RS232 mode are preserved).

Hardware switch to restore factory settings for interface:

1. Switch off the module
2. Put the switch 2 and 4 in position ON
3. Switch on the modem → the green led is ON
4. Put the switch 2 in position OFF
5. The modem is ready to work with the RS232 interface with the following serial settings:
9600 bauds, 8 bits, 1 stop and no parity.

- MODBUS compatibility

The ARF35 is MODBUS RTU and ASCII compatible, if the following recommendation is fulfilled: the radio rate and the serial rate must be equivalent (this for avoiding a MODBUS packet splitting).

- With the 10 kbit version (radio rate) the serial speed must be 9 600 baud
- With the 40 kbit version (radio rate) the serial speed must be 38 400 baud

- Sending a serial command using HYPERTERMINAL


The serial command can be sent using a standard terminal. Hereafter an illustration is done with *HyperTerminal* and the *SLI* command.

Step 1. First you must edit a text file and type the command you want to send (without any additional character): *SLI*.

Step 2. When saved, check the length of the text file in its properties → the size MUST be 3 for the *SLI* command

Step 3. Open *HyperTerminal*, configure the serial parameter to 9600, 8 bits, 1 stop, no parity

Step 4. Send the text file created in step 1



Step 5. The terminal must display all registers values.

WARNING: When using a terminal in WINDOWS environment, the delay between characters is not guaranteed. Even if you are sending the command using a text file (as describe above) you can have some delay between the characters → if so, the modem is not able to successfully retrieve the requested command. Try to use another terminal or another PC.

SPECIFICATIONS

General technical characteristics

- Operating temperature: -20 to +70 °C
- Power supply: 8 to 30 Volts (integrated regulator)
- Size: 145x100x40 mm + 85 mm antenna
- Number of channels: 2 or 5
- Modulation: FSK
- Packaging: IP65 box with integrated or external antenna

Transmission

- Programmable frequencies: 869,4625 and 869,5875 MHz (2-channel version)
869,425 / 869,475 / 869,525 / 869,575 / 869,625 MHz (5-channel version)
- Radiated RF power: 500 mW (+ 27 dBm)
- Tx / Rx Consumption: 400 mA / 40 mA (under 8 Volts)

Reception

- Sensitivity: -100 dBm (2-channel version)
-105 dBm (high sensitivity 5-channel version)
- Radio data rate: 40 kbits/s (2-channel version)
10 kbits/s (high sensitivity 5-channel version)
- RSSI: Available through serial commands

Protocol

- Serial data rate: from 2400 to 38400 bauds (programmable through serial commands)
- Serial ports: TxD, RxD, RTS. Standard configuration: RS232. The RS485 configuration is performed through serial commands.
- Handshake: none or RTS/CTS
- Configuration: through serial commands
- Modes: transparent or addressed, full custom firmware on request
- Standard compliance: EN 300-220 and EN 301-489 (full certified modem)
- Range: 6 km in free field

Alternative versions

ARF 7120C: 2-channel RS232/RS485 modem IP 65 box with integrated antenna

ARF 7120D: 5-channel RS232/RS485 modem IP 65 box with integrated antenna

ARF 7120E: 2-channel RS232/RS485 modem IP 65 box with external antenna (RG58C cable +

TNC connector)

ARF 7120F: 5-channel RS232/RS485 modem IP 65 box with external antenna (RG58C cable + TNC connector)

Version		Radio data rate	Receiver sensitivity	Range(in free field)
ARF 7120C	2 channels	40 kbits/s	-100 dBm	4 km
ARF 7120D	5 channels	10 kbits/s	-105 dBm	6 km
ARF 7120E	2 channels	40 kbits/s	-100 dBm	4 km
ARF 7120F	5 channels	10 kbits/s	-105 dBm	6 km

ANNEX 1 : Firmware updates

Firmware	Updates
V1.06 /V10.06	<p data-bbox="352 304 762 338">Add Baudrate 600 and 1200bps</p> <p data-bbox="352 371 1444 517">Increase RS485 buffer deactivation time (when the modem ends data transmission to equipment) for baudrate 2400 and 4800bps. Add the delay for 600 and 1200bps baudrates. Increase RS485 buffer deactivation time for command mode to be able to work properly to every baudrate.</p> <p data-bbox="352 551 1436 663">Change SW1 and SW2 management: When SW1 or SW2 is set, serial parameters are not changed. When SW1 and SW2 are set, serial parameters are backed to 9600, n,8,1 and the RS232 interface is activated.</p> <p data-bbox="352 696 1038 730">Correct the bug of invalid switch sampling at startup.</p>