

WIP-1000 User Manual

V1.1

2011/02/11

VOISMART

CONTENTS


For your safety

Read the complete user guide carefully. Not following them may be dangerous or illegal.

- **SWITCH ON SAFELY** Do not switch the phone on when wireless phone use is prohibited or when it may cause interference or danger.
- **ROAD SAFETY COMES FIRST** Obey all local laws. Always keep your hands free to operate the vehicle while driving.
- **INTERFERENCE** All wireless phone may be susceptible to interference, which could affect performance.
- **SWITCH OFF IN HOSPITALS** Follow any restrictions. Switch the phone off near medical equipments.
- **SWITCH OFF IN AIRCRAFT** Follow any restrictions, Wireless phone can cause interference in aircraft.
- **SWITCH OFF WHEN REFUELING** Do not use the device at a refueling point. Do not use near fuel or chemicals.
- **SWITCH OFF NEAR BLASTING** Follow any restrictions. Do not use the phone where blasting is in progress.
- **USE SENSIBLY** Use only in the normal position as explained in the product documentation. Do not touch the antenna unnecessary.
- **QUALIFIED SERVICE** Only qualified personnel may install or repair the product.
- **ENHANCEMENT AND BATTERIES** Use only approved enhancements and batteries. Do not connect incompatible product.
- **Not WATER-RESISTANCE** Your device is not water-resistant. Keep it dry.
- **BACK-UP COPIES** Remember to make back-up copies or keep a written record of all important information stored in your phone.
- **CONNECTING TO OTHER DEVICES** When connecting to any other device, read its user guide for detailed safety instructions. Do not connect incompatible products.

Getting Started

Phone Overview



1	Call Key
2	Earphone speaker
3	Screen

4	C Key
5	Navigation Key
6	End Key and Power Key
7	Keypad
8	Microphone
9	Loudspeaker
10	Battery Cover

To insert the battery

Before starting to use your phone, you need to insert the battery.

1. Remove the battery cover.
2. Insert the battery with the label facing up.
3. Close the battery cover into place.

Charging the battery

The phone battery is partly charged when you buy it. You can use the phone while it is charging.

1. Connect the charger to the phone. It takes about 4 hours to fully charge the battery. It will take longer if you use the phone while charging.
2. Remove the charger by pulling the plug backwards.

When the phone is turned on, you can check the charging status in standby.

• • • • •

Otherwise, you can press any key to view the screen which will indicate the charging status as well.



Turn on and turn off the phone

To turn on and turn off the phone

1. Press and hold down  (power key) to turn the phone on.
2. Press and hold down  (power key) to turn the phone off.

VoIP settings

Your phone normally has a default VoIP settings based on your service provider's information. You may have the settings from your service provider already installed in your phone or you may receive the settings from the service provider as a special text message. You also can add more VoIP settings manually. [See "VoIP settings"](#) .

WiFi network settings

Your phone normally has a default WiFi network settings based on your service provider information. You may have the settings from your service provider already installed in your phone or you may receive the settings from the service provider as a special text message. You also can add more WiFi network settings manually. [See "WiFi settings"](#) .

Standby

After you have turned your phone on and the number or service provider of the phone appears, the view is called standby.

Flight Mode

If you turn on your phone and Flight mode is activated, you will be given the option of using your phone either in Normal Mode with full functionality, or Flight Mode with limited functionality. WiFi network will be disconnected to prevent from disturbing sensitive equipments.

Please follow on board regulations and flight crew’s instructions for use of electronic devices.

To view flight mode

- 1. From standby select Menu > Setting > WiFi settings > Flight Mode
- 2. Press the navigation key (left) or (right) to turn on or turn off Flight Mode.
- 3. Press (OK) to save this mode.

Navigation

The main menus are shown as icons and submenus are shown as a list.

To navigate the phone menus

- 1. From Standby select Menu.
- 2. Use navigation key to move through the main menus and submenus.

Shortcuts

You can use keypad shortcuts to go directly to a menu or functions.

From Standby, pressing the key below will guide you

	Press Key	Go To
	(left)	Main Menu
	(right)	Phonebook
	*	AP Search
	#	SMS
	1	Alarm
	2	Dialed Calls
	3	Clear/Back
	4	Speaker
	5	

	🔊	Sound
	☰	My Menu

Essential indicators

Some illustrations will show on the screen in standby.

[illegible]

Group 2	
	The phone is unsuccessfully registering to your service provider's SIP server.
	The phone is successfully registering to your service provider's SIP server.

Group 3	
	The phone does vibrate for an incoming call.
	The phone does ring and vibrate for an incoming call.
	The phone does ring for an incoming call.
	The phone does not ring for an incoming call.

Group 4	
	Alarm clock is on.

Group 5	
	You have missed calls.

Group 6	
	Call divert is on.

Group 7	
	The battery capacity.
	The battery capacity.
	The battery capacity.
	The battery capacity.
	The battery capacity.
	The battery capacity.

Entering text

You can use multitap text input to enter text.

- When you enter text, press **↵** to shift among uppercase letters (AB), lowercase letters (ab)
- When you enter text, press **123** and then press **1** to **9** to enter numbers.
- When you enter text, press **☰**, and select symbols from the table.
- When you enter text, press **↵** to **↵** repeatedly until the desired letter appears. When a word is written, press and hold **↵** to add a space.

Auto keypad lock

Use the auto keypad lock to prevent accidental key presses.

1. From standby select Menu > Settings > Personalize > Auto key lock.
2. Use navigation key to select the settings you prefer to and save.
3. The keypad lock will be on automatically when the phone is idle to the time you have

set.

4. When the lock is on, "Unlock" will be shown on the screen.
5. To unlock, press , and then press .

Calling

You need to turn on your phone and be within connecting to WiFi network and registering to SIP server successfully.

To make a call

1. From standby enter a phone number (with international country code and area code if applicable).
2. Press  to make this call.
3. Press  to end this call.

To make an international call

1. From standby press  till "+" sign appears.
2. Enter the country code, area code (without the first zero), and phone number.
3. Press  to make this call. It will show  icon on the screen.
4. Press  to end this call. It will show  icon on the screen.

To answer a call

1. When a call is coming, it will show  icon on the screen.
2. Press  to answer this call.

To reject a call

1. When a call is coming, it will show  icon on the screen.
2. Press  to reject this call.

To change the ear speaker volume during a call

Press the navigation key  or  to change the ear speaker volume when you are on the phone.

To mute the microphone during a call

When you are on the phone,

1. Press  to mute the microphone.
2. Press  again to resume.

To turn the handsfree on during a call

When you are on the phone,

1. Press  to turn on the handsfree.
2. Press  again to turn off the handsfree.

Do not hold your phone near your ear when the handsfree is in use because the volume may be extremely loud.

Phonebook



You can save names, numbers, and personal information in Phonebook which are saved in the phone memory.

To view your contact list

1. From standby select Menu > Phonebook > Phonebook.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to view your contact list.
3. You can enter the name you have saved in the phonebook in the top column, and then the name you are looking for will be highlighted.
 - Press $\cdot$ and select "Open" for details.
 - Press $\cdot$ and select "Call" to make a call.
 - Press $\cdot$ and select "Edit" to edit details.
 - Press $\cdot$ and select "New" to add a new contact.
 - Press $\cdot$ and select "Delete" to delete a contact.
 - Press $\cdot$ and select "Delete all" to delete all contacts.

To add a new contact

1. From standby, select Menu > Phonebook > New Contact.
2. Enter the name, numbers, and personal information. See "Entering text" P. 11 for details.
 - Press $\cdot$ and select "Input" to shift the input method.
 - Press $\cdot$ and select "Set as default" to set the number as default number for the new contact.
 - Press $\cdot$ and select "Save" for the new contact.
 - Press $\cdot$ and select "Cancel" to cancel the new contact.

Speed Dial

Speed dialing lets you select nine contacts that you can dial quickly. The contact you can save in positions from 1 to 9.

To set one speed dial

1. From standby select Menu > Phonebook > Speed dial.
2. Select one number and Press $\cdot$, press the number directly or press $\cdot$ again to assign a contact from your phonebook.

To delete one speed dial

1. From standby, select Menu > Phonebook > Speed dial.
2. Press $\cdot$ and select "Clear" to clear the speed dialing assignment.

To make a speed dial call

1. From standby pressing and holding one number 1 to 9 will make a speed dial call.
2. Press $\cdot$ to end this call.

Contact group

You can organize your contacts. One default group is given as "Blacklist". Once you have assigned your contacts to this "Blacklist" group, it will help you to screen the numbers you do not want to answer.

To create a group

1. From standby select Menu > Phonebook > Groups.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to view your group list.
3. Press $\cdot$ and select "New group" to create a group.
4. Enter the name you want to give to the group.
5. Press $\cdot$ and select "Save" to save the group.
6. Select the group and press $\cdot$ and
 - Select "Open" to view the contacts of the group.
 - Select "Edit" to edit the contact of the group.
 - Select "Ringtone" to assign the ringtone of the group.
 - Select "Icon" to assign to icon of the group.
 - Select "Rename" to rename the group.
 - Select "Delete" to delete the group from your group lists.

Phonebook Capacity

You can view your phonebook memory. 200 contacts can be saved in your phonebook.

To view your phonebook capacity

1. From standby select Menu > Phonebook > Capacity.
2. It will show the quantity of your contacts that you have used.

Call History



You can view information about recent calls.

To view your call history


1. From standby, select Menu > Call history.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) and
 - Select "All calls" to view your recently all calls history, including missed calls, dialed calls and received calls.
 - Select "Missed calls" to view your recently missed calls.
 - Select "Dialed calls" to view your recently dialed calls.
 - Select "Received calls" to view your recently received calls.
3. While you are viewing your call history, press $\cdot$ and

- Select "Open details" for details.
- Select "Call" to make a call.
- Select "Save number" to a new contact or a existing contact.
- Select "Delete" to delete a call history.
- Select "Delete all calls" to delete all call history.

Call duration

You can check the duration of your last call, incoming calls, outgoing calls, and the total time of your calls.

To check the call time



1. From standby select Menu > Call history > Call duration.
 - · Shows your last call duration.
 - · Shows your incoming call duration.
 - · Shows your outgoing call duration.
 - · Shows the total time of your calls.
2. Select one call duration and press · and
 - Press · to select "Yes" if you want to reset the timer.
 - Press · to select "No" if you do not want to reset the timer.

Organizer



Organizer helps you to organize your life well. It provides the functions of "Alarm Clock", "Calendar", "World Clock", and "Calculator".

Alarm clock



You can set five alarms and give each alarm different configurations.

To set one new alarm clock

1. From standby select Menu > Organizer > Alarm clock.
2. Press · and select "Edit" to edit the configurations of the alarm and the icon

- · Shows the time at present.
- · Shows the time of a day that alarm has to be activated.
- · Shows the day of a week that alarm has to be activated.
- · Shows the sound of this alarm signal.
- · Shows the times of this alarm signal which has to be activated.
- · Shows the interval of this alarm signal which has to be activated.
- · Shows the note you can make for this alarm.

3. Press · to save this alarm setting.

To close, clear, or edit one alarm clock

You can clear the alarm clock you have set.

1. From standby select Menu > Organizer > Alarm clock.
2. Press the navigation key · (·) or · (·) and select one alarm.
3. Press · and
 - Select "Close" to close the alarm clock.
 - Select "Clear" to clear the alarm clock setting.
 - Select "Edit" to edit the alarm clock setting.

Calendar



You can use calendar to remind you of meetings, dates, travels, vacations, anniversaries and so on. It will help you track of your tasks and other notes.

To create a new event

4. From standby select Menu > Organizer > Calendar.
5. Press the navigation key · (·) or · (·) and select one date.
6. Press · and select "New event"
7. Set the selected event type, new subject, location, date, time, duration, and reminder.
8. Press · to save this event.

Calendar view

You can view the calendar in different ways.

1. From standby select Menu > Organizer > Calendar.
 - Press · 2 to shift monthly view.
 - Press · 5 to shift weekly view.
 - Press · 8 to shift day view.
 - Press · 1 to go to last week.
 - Press · 4 to go to last month.

- Press $\cdot$ 7 to go to last year.
- Press $\cdot$ 3 to go to next week.
- Press $\cdot$ 6 to go to next month.
- Press $\cdot$ 9 to go to next year.
- Press $\cdot$ and select "Go to date", then enter the date, and press $\cdot$ to go to a certain date.

Manage your calendar events

You can delete past events in your calendar to save space of your phone memory.

To delete more than one event at a time, go to monthly view, and

1. Press $\cdot$ and select "Delete events".
 - Select "Before date" and enter the date that the events you want to delete before it.
 - Select "All events" and press $\cdot$ to delete all events.

Calendar settings

You can modify your default calendar settings.

1. From standby select Menu > Organizer > Calendar.
2. Press $\cdot$ and select "Settings". You can modify the default settings of duration, alarm tone, calendar view.


World clock



World clock shows current local time in cities in all time zones.

1. From standby select Menu > Organizer > World clock.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to view current local time in cities.

Calculator



The calculator in your phone provides you basic arithmetic functions, addition, subtraction, multiplication, and division are included.

1. From standby select Menu > Organizer > Calculator.
2. When 0 is displayed on the screen,
 - Enter the first number in the calculation.

PRELIMINARY

- Press the navigation key $\cdot$ ($\cdot$), $\cdot$ ($\cdot$), $\cdot$ ($\cdot$), $\cdot$ ($\cdot$) to perform the calculation.
- Enter the second number in the calculation.
- Repeat the sequence as many times as it is necessary.
- Press the navigation key $\cdot$ to get the calculated result.
- Press $\cdot$ for decimal point.
- Press $\cdot$ for negative or positive.

Advanced calculation

To perform advanced calculation, press $\cdot$ and

- Select "Clear all" to clear the number and 0 is displayed on the screen.
- Select "M+" to save the number on the screen as positive in the memory.
- Select "M-" to save the number on the screen as negative in the memory.
- Select "MR" to recall the number amount saved in the memory.
- Select "MC" to clear the number saved in the memory.

Profiles



Your phone has various setting groups called profiles for which you can customize the phone tones for different events and environments.

1. From standby select Menu > Profile.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) and select the desired profile.
3. Press $\cdot$ and select "Activate" to activate the selected profile.
4. Press $\cdot$ and select "Settings" to personalize the selected profile.
 - Ring tone
 - Ring volume
 - Vibration setting
 - Dialing tones
 - Keypad tones
 - Keypad volume
 - New message tone
 - On/Off Sound
 - Profile name
5. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to change the setting above.
6. Press $\cdot$ to save the profile.

Settings



Personalize

Personalize contains many elements for personalizing your phone, such as wallpapers, skins, lighting, time, language, and auto key lock.

Wallpapers

You can change the background image to the display in the standby mode.

1. From standby select Menu > Settings > Personalize > Wallpapers.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) and press $\cdot$ to view the selected wallpaper.
3. Press $\cdot$ to save selected wallpaper and your standby illustration will be changed.

Skins

You can change the color for the button bar of the screen.

1. From standby select Menu > Settings > Personalize > Skins.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to view the selected skin.
3. Press $\cdot$ to save selected skin and your color for the button bar of the screen will be changed.

Lighting

You can change the lighting of the screen, including brightness, backlight, and contrast.

1. From standby select Menu > Settings > Personalize > Lighting.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to the desired setting.
 - Press $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to adjust the brightness of the screen.
 - Press $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to select the time of the backlight to be turned off.
 - Press $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to adjust the contrast of the screen.
3. Press $\cdot$ to save the lighting settings.

Time

You can correct your time and date of your phone while you are traveling to another country where has time difference.

Time and date

1. From standby select Menu > Settings > Personalize > Time > Time and Date.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to the desired setting.
 - Press $\cdot$ to $\cdot$ to input the current time.
 - Press $\cdot$ to $\cdot$ to input the current date.
 - Press $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to select one time format.
 - Press $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to select one date format.
3. Press $\cdot$ to save the time and date settings.

Time server and Time zone

When time server is started, you can correct your time and date according to where the

place you are by changing the time zone. Therefore, it is necessary to setup time server before you can correct your time and date by changing the time zone.

1. From standby select Menu > Settings > Personalize > Time > Time server.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to the desired setting.
 - Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to change the state.
 - Input the NTP Server 1, which is usually set by your service provider already.
 - Input the NTP Server 2, which is usually set by your service provider already.
3. Press $\cdot$ to save the time server settings.

When time server is setup, you can correct your time and date easily by changing the time zone only.

4. From standby select Menu > Settings > Personalize > Time > Time zone.
5. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to change the city.
6. Press $\cdot$ to save the time zone settings and the time and date of your phone will be corrected.

Language

You can change the language of your phone to display.

1. From standby select Menu > Settings > Personalize > Language.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to the language setting.
3. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to change the language.
4. Press $\cdot$ to save the language settings.

Typing letter timeout

You can adjust the reaction time of your keypad when you enter text.

1. From standby select Menu > Settings > Personalize > Typing letter timeout.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) and select the desired setting.
 - Expert means that the reaction time of your keypad is short.
 - Normal means that the reaction time of your keypad is normal.
 - Novice means that the reaction time of your keypad is long.
3. Press $\cdot$ to save the typing letter timeout settings.

WiFi settings

You can view your WiFi network setting or add a new WiFi network setting.

Before setting by yourself, you need to get the setting information from the WiFi network administrator if it is not open.

To view your WiFi network

1. From standby select Menu > Settings > WiFi settings > Network Configs.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to the desired WiFi network.
3. Press $\cdot$ and
 - Select "Details" for SSID, security, and IP/ DNS Mode information.


- Select "New" to add a new WiFi network.
- Select "Edit" to edit the WiFi network.
- Select "Delete" to delete the WiFi network.

To add a new Wifi network

1. From standby select Menu > Settings > WiFi settings > Network search.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to the desired Network.
3. Press $\cdot$ and
 - Select "ReScan" for research WiFi Network again.
 - Select "Connect" or "Disconnect" to connect or disconnect your phone to the selected WiFi Network.
 - Select "Details" for SSID, security, and IP/ DNS Mode information.
 - Select "New" to add a new WiFi AP setting.
 - Select "Edit" to edit the selected WiFi AP setting.
4. For details, please follow the instructions to setup the WiFi network before you can connect to this WiFi network.

Step 1: Search for available WiFi networks.

- From standby press the navigation key $\cdot$ ($\cdot$) and the screen will show "AP Searching" message.



- All available networks will be listed.






Step 2: Select one WiFi network from the list and make necessary setup if the selected WiFi network is not in your network configs. list.

- Select one WiFi network which is in your network configs. list already and press $\cdot$ and select "connect" to connect your phone to the selected WiFi network.




- Select one WiFi network which is not in your network configs. list and press  and select “connect” to connect your phone to the selected WiFi network. Since it is not in your network configs. list, you are required to fill in the necessary information based on its security type and IP type.

□ Security Type Settings

Security Type	Further Setting	Further Setting Info.
	X	X
	Index	Please input Index No and Password
	Index	Please input Index No and Password
	Key	Please input Password
	Key	Please input Password

□ IP Type Settings

IP Type	Further Setting	Further Setting Info.
 DHCP	X	X
 STATIC IP	IP	Please input IP address
	Gateway	Please input Gateway address
	Mask	Please input Mask address

Call settings

You can set the answer mode in the call settings.

1. From standby select Menu > Settings > Call settings.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) and select "answer mode".
3. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) to the desired setting.
 - Select "send key" means that you have to press $\cdot$ to answer incoming calls.
 - Select "any key" means that you can press any key to answer incoming calls.
4. Press $\cdot$ to save the call settings.

Call divert

Call divert allows you to divert your incoming calls to another phone number. For details, please contact your service provider.

1. From standby select Menu > Settings > Call divert.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) and select one option
 - Divert all calls please select "Unconditional"
 - Divert calls when your call is busy please select "Busy."
 - Divert call when your call is no reply please select "No reply."
3. Set the divert option yes (activate) or no (cancel) to turn on or turn off the divert function.

Above divert options can be activated at the same time.

Security

When phone lock is activated, the code is required when the phone is switched on.

Avoid using access code similar to the emergency number to prevent accidental dialing of the emergency number.

If you forget the codes, contact your service provide.

To activate phone lock

1. From standby select Menu > Settings > Security > Phonelock.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) and select "Activate".
3. Press $\cdot$ and one box will appear to ask you to enter one password.
4. Press $\cdot$ to activate it.

To change phone lock code

The code can be used to lock the phone in order to avoid unauthorized usage. The factory setting for the code is 1234. To avoid unauthorized usage, please change the lock code when you get the phone. Keep the new code secret and in a safe place separating from your phone.

1. From standby select Menu > Settings > Security > change phone code.
 - Enter your current phone code.
 - Enter your new phone code.
 - Enter your new phone code again as verification.

Factory reset

You can reset your phone to the factory settings, including profiles, personalization, WiFi settings, passwords, and so on.

1. From standby select Menu > Settings > Factory reset.
2. Enter the password which is given from your service provider.
3. When the password is confirmed, the settings will be back to factory settings.

My phone info.

You can view your phone information.

1. From standby select Menu > Settings > My phone info.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) and
 - Select "Phone info." will show the phone number, firmware version, and Mac address.
 - Select "WLAN info." will show the WLAN your phone is connecting to.
 - Select "Network info." will show the network setting your phone is connecting to.

Admin Menu

Admin Men provides ping test, VoIP setting and coder settings.

Ping Test

Ping Test can help you identify if the connection of your phone and WiFi network goes well.

1. From standby select Menu > Settings > Admin Menu > Ping Test.
2. Press the navigation key $\cdot$ ($\cdot$) or $\cdot$ ($\cdot$) and select "Gateway" or "DNS Server".
3. Your phone will send messages to the Gateway or DNS Server where your phone is connecting to.
4. Press $\cdot$ to stop sending messages to the Gateway or DNS Server and get the sending result showing on the screen.

It means the channel between your phone and the Gateway or DNS Server is good if your phone gets all replies.

You can also check the connecting of your phone with another WiFi network by manual input.

- 1. From standby select Menu > Settings > Admin Menu > Ping Test.
- 2. Press the navigation key (·) or (·) and select "Manual Input".
- 3. Input IP address or website address.
- 4. Press (·) to start to connect test.
- 5. Press (·) again to stop sending messages to IP address or website address and get the sending result showing on the screen.


It means the channel between your phone and another WiFi network is good if your phone gets all replies.

VoIP Setting

Voip Setting is usually setup by your service provider already. Before setting by yourself, you need to get the setting information from your service provider.

Setup a new VoIP Profile

- 1. From standby select Menu > Settings > Admin Menu > VoIP Setting.
- 2. Press the navigation key (·) or (·) and select profile. Input the following information.
 - Display Name: The name to display on your phone in mode.
 - User Name: Should be provided by your service
 - Auth. Password: Should be provided by your service
 - Domain: Should be provided by your service provider. It fill in the right setting or the VoIP Phone cannot be correctly. The format of Domain is IP address sometimes. The compositions of IP address are four separated by one dot "."
 - 1st Proxy: Should be provided by your service provider. to fill in the right setting or the VoIP Phone cannot be correctly. The format of Proxy is IP address following sometimes. One colon ":" has to be added before Port default port no is 5060 if you do not enter it.
 - 2nd Proxy: Should be provided by your service provider necessary.
 - 1st Registrar: Should be provided by your service is must to fill in the right setting or the VoIP Phone activated correctly. The format of Registrar is IP address



one
standby
provider.
provider.
is must to activated
integers
It is must activated Port no no. The
if
provider. It cannot be following

PRELIMINARY

Port no sometimes. One colon ":" has to be added before Port no. The default port no is 5060 if you do not enter it.

- 2nd Registrar: Should be provided by your service necessary.
- OutBond Proxy: Should be provided by your service necessary.
- SIP Type: Should be provided by your service provider if necessary.
- User Agent: Should be provided by your service provider if necessary.
- Proxy String: Should be provided by your service necessary.
- VoIP Name: The name of the settings.

3. Press **•** to save the settings.

- ✧ When setting Proxy, Registrar, OutBond Proxy, User Proxy String, you can press **•** and select "Same as for quickly setup if the value is same.

- ✧ See "Entering text" P. 11 for details.

Activate your VoIP Profile

If you have more than one VoIP profile, you can activate different VoIP profile.

1. From standby select Menu > Settings > Admin Menu > VoIP Setting.
2. Press the navigation key **•** (**•**) or **•** (**•**) and select one profile.
3. Press **•** and select "Activate" to activate the selected profile.

Codec

Your phone supports three audio compression codec standards, including G.711 μ -Law, G.711 A-Law, and G.729. It allows you to activate them at the same time. Be sure to activate one of them at least.

To activate codec

1. From standby select Menu > Settings > Admin Menu > Codec.
2. Press the navigation key **•** (**•**) or **•** (**•**) select one codec standard.
3. Press **•** to enable the selected codec.


To change the priority of the codec

You can change the priority of the codec.

1. From standby select Menu > Settings > Admin Menu > Codec.
2. Press the navigation key **•** (**•**) or **•** (**•**) and select one codec standard.
3. Press **•** and select up or down to change the priority.

Roaming

Your phone supports roaming when more than 1 WiFi network is available if they are in your WiFi (AP) config. list. When you activate roaming, it will allow your phone to shift



between or among WiFi networks according to the signal strength.

To activate roaming

1. From standby select Menu > Settings > Admin Menu > Roaming.
2. Press the navigation key  () or  () to turn on or turn off Roaming Mode.
3. Press  to save this mode.