Operating Instructions

Digital Video Recorder Models: DPR-2016/500D





Safety instructions

EMC class

- This video recorder (DVR) is a class A device in accordance with EN 55022.
- This device may cause interference to other equipment in domestic use. In such cases the persons operating the DVR are required to provide appropriate countermeasures, for which they themselves bear the cost.

Importance of these Operating Instructions

- Please read the safety instructions and the other information contained in the Operating Instructions before connecting up and operating the DVR.
- The Operating Instructions should be kept in a safe place for later reference.

Ambient conditions for the DVR

- The DVR should be protected against excessive heat, dust, damp and vibration.
- The DVR may only be operated at temperatures between +5°C and +40°C, and up to a maximum air humidity of 90%.
- The DVR may only be operated indoors, and must be protected against incursion of water and damp.

Care of the DVR

- Never switch on the DVR when damp has penetrated it. In such cases, have the DVR checked by a qualified service engineer.
- Do not place any heavy objects on the DVR.
- Never cover over the DVR's vents.
- Never insert metal objects or any other items into the vents. This may permanently damage the DVR.
- The housing may only be opened by authorised persons. Repairs may only be carried out by qualified service personnel.
- The DVR must be disconnected from the power supply before its housing is opened.

Getting started with the DVR

When laying the connecting cables, make sure no weight is placed on them, that they are not kinked or damaged, and that no damp can penetrate them.

Cleaning the DVR

- The housing of the DVR may only be cleaned with a damp (not wet) cloth,
- Use only a mild detergent. Do not use solvent-containing detergents or petrol. This could permanently damage the surface finish.

Spare parts

Use only original spare parts from Videor Technical GmbH.

Table of contents

Overview	7
Package contents	7
Basic functions	7
Features	7
Requirements for operation	7
Control options	7
Connections on the rear	8
Front panel controls	10
Key to controls	12
Function buttons	12
PTZ camera functions	12
Playback functions	12
Remote control functions	13
Playback functions	13
Menu overview	14
Accessing the menus	16
Accessing the Display menu	16
Accessing the PTZ menu	16
Accessing the Setup menu	17
Accessing the Search menu	17
Getting started	18
Checklist for DVR operation	18
Connecting the remote control and DVR	18
Switching on the DVR	19
Switching off the DVR	19
Administration	20
Saving your system setup	20
Loading your system setup	20
Deleting recordings	20
Downloading software updates	21
Hiding from specific users	21
Restoring factory defaults	21
Changing hard disk	22
Fitting hard disk into an empty drive rack	23
Mirroring of hard disks	24
Determining the memory requirement of a recording	25
Searching for recordings	26
Using Bookmark search	28
Using calendar search	29
Using event log search	30
Using text-in search	31
Using motion search	32
Copying recordings	33

Table of contents

Menu descriptions – Setup menu	34
System – Information	35
System – Date/Time	36
System – Storage	37
System – User	39
System – Shutdown	40
System – Log out USER	40
Network – Network	40
Network – Notification	43
Devices – Camera	44
Devices – Alarm-Out	45
Devices – Display	46
Devices – Remote Control	47
Record – Record	48
Record – Schedule	49
Record – Pre-Event	50
Record – Archive	51
Event – Alarm-In	52
Event – Motion Detection	54
Event – Object Detection	56
Event – Video Loss	58
Event – Video Blind	60
Event – Text-In	62
Event – System Event	64
Event – Event Status	66
WebGuard – WebWatch controls	67
WebGuard – WebSearch controls	68
Using WebGuard	69
Specifications DPR-2016	70
Accessories	72
Supported PTZ cameras	73
Index	75
Notes on disposal	78

Overview

Package contents

- Digital video recorder (DVR)
- · Mains power cord
- · Operating instructions
- RAS (Remote Administration System) software on CD
- · Operating instructions for RAS software on paper and CD
- Mounting kit for cabinet installation
- Screws for attaching SCSI Connector
- · Mounting screws for installation of hard disk drives
- Infrared remote control
- Key for hard disk drive rack

Basic functions

- · Record video images using multiple cameras
- Event-based recording start
- Video playback
- · Search for specific video sequences

Features

- MPEG-4 compression / pentaplex mode
- 16 loop-through inputs / VGA, S-VHS/FBAS outputs
- · Audio and alarm inputs / outputs
- Max. recording speed: 400 field images per sec (PAL)2
- Memory capacity 500 GB
- 4 hard disks max., CD/DVD-RW writer included
- Standard hard disk mirroring
- Maximum video resolution 720 x 576 pixels
- SCSI port for archiving / memory expansion
- · Integral motion detector/object tracking
- ATM/POS text display / 2x to 4x digital zoom
- RS-232 / RS-485 ports
- Network port (Ethernet) / IR remote control

Requirements for operation

- Digital video recorder DTR connected
- At least 1 camera connected
- At least 1 monitor connected
- Mouse connected, if DVR is to be controlled by mouse

Control options

- Front panel
- Remote control
- Mouse
- WebGuard
- RAS program

Connections on the rear





Connections on the rear (continued)

1VIDEO IN 1-16Max. 16 video channelsCameras2LOOP 1-16Max. 16 loop-through video channelsCameras3AUDIO IN 1-16Max. 16 Audio inputsMicrophone4AUDIO OUTAudio outputAmplifier, spect5SPOT1 - SPOT4Max. 4 video outputsSpot monitors6SVHS OUTS-VHS outputMonitors7VIDEO OUTVideo outputMonitors8NC1 - NC4, C1 - C4, NO1 - NO4Relay alarm output for external deviceSiren, flashing9VGAPC monitorPC monitor10SCSIExternal storage mediaHard disk11AO1 - AO12Alarm outputs for external devicesSiren, flashing12NETWORKNetworkNetwork cable13USBExternal interfaceDrive, mouse14ARI/GNDReset alarm with external signalSwitch15RS-232C2 external interfacesModem	
3AUDIO IN 1-16Max. 16 Audio inputsMicrophone4AUDIO OUTAudio outputAmplifier, spe5SPOT1 - SPOT4Max. 4 video outputsSpot monitors6SVHS OUTS-VHS outputMonitors7VIDEO OUTVideo outputMonitors8NC1 - NC4, C1 - C4, NO1 - NO4Relay alarm output for external deviceSiren, flashing9VGAPC monitorPC monitor10SCSIExternal storage mediaHard disk11AO1 - AO12Alarm outputs for external devicesSiren, flashing12NETWORKNetworkNetwork cable13USBExternal interfaceDrive, mouse14ARI/GNDReset alarm with external signalSwitch	
4AUDIO OUTAudio outputAmplifier, spectrum5SPOT1 - SPOT4Max. 4 video outputsSpot monitors6SVHS OUTS-VHS outputMonitors7VIDEO OUTVideo outputMonitors8NC1 - NC4, C1 - C4, NO1 - NO4Relay alarm output for external deviceSiren, flashing9VGAPC monitorPC monitor10SCSIExternal storage mediaHard disk11AO1 - AO12Alarm outputs for external devicesSiren, flashing12NETWORKNetworkNetwork cable13USBExternal interfaceDrive, mouse14ARI/GNDReset alarm with external signalSwitch	
5SPOT 1 - SPOT 4Max. 4 video outputsSpot monitors6SVHS OUTS-VHS outputMonitors7VIDEO OUTVideo outputMonitors8NC1 - NC4, C1 - C4, NO1 - NO4Relay alarm output for external deviceSiren, flashing9VGAPC monitorPC monitor10SCSIExternal storage mediaHard disk11AO1 - AO12Alarm outputs for external devicesSiren, flashing12NETWORKNetworkNetwork cable13USBExternal interfaceDrive, mouse14ARI/GNDReset alarm with external signalSwitch	
6SVHS OUTS-VHS outputMonitors7VIDEO OUTVideo outputMonitors8NC1 - NC4, C1 - C4, NO1 - NO4Relay alarm output for external deviceSiren, flashing9VGAPC monitorPC monitor10SCSIExternal storage mediaHard disk11AO1 - AO12Alarm outputs for external devicesSiren, flashing12NETWORKNetworkNetwork cable13USBExternal interfaceDrive, mouse14ARI/GNDReset alarm with external signalSwitch	akers
7 VIDEO OUT Video output Monitors 8 NC1 - NC4, C1 - C4, NO1 - NO4 Relay alarm output for external device Siren, flashing 9 VGA PC monitor PC monitor 10 SCSI External storage media Hard disk 11 AO1 - AO12 Alarm outputs for external devices Siren, flashing 12 NETWORK Network Network cable 13 USB External interface Drive, mouse 14 ARI/GND Reset alarm with external signal Switch	
8 NC1 - NC4, C1 - C4, NO1 - NO4 Relay alarm output for external device Siren, flashing 9 VGA PC monitor PC monitor 10 SCSI External storage media Hard disk 11 AO1 - AO12 Alarm outputs for external devices Siren, flashing 12 NETWORK Network Network cable 13 USB External interface Drive, mouse 14 ARI/GND Reset alarm with external signal Switch	
8 NO1 - NO4 Relay alarm output for external device Siren, flashing 9 VGA PC monitor PC monitor 10 SCSI External storage media Hard disk 11 AO1 - AO12 Alarm outputs for external devices Siren, flashing 12 NETWORK Network Network cable 13 USB External interface Drive, mouse 14 ARI/GND Reset alarm with external signal Switch	
10SCSIExternal storage mediaHard disk11AO1 - AO12Alarm outputs for external devicesSiren, flashing12NETWORKNetworkNetwork cable13USBExternal interfaceDrive, mouse14ARI/GNDReset alarm with external signalSwitch	ı light
11 AO1 - AO12 Alarm outputs for external devices Siren, flashing 12 NETWORK Network Network cable 13 USB External interface Drive, mouse 14 ARI/GND Reset alarm with external signal Switch	
12NETWORKNetworkNetwork cable13USBExternal interfaceDrive, mouse14ARI/GNDReset alarm with external signalSwitch	
13 USB External interface Drive, mouse 14 ARI/GND Reset alarm with external signal Switch	ı light
14 ARI/GND Reset alarm with external signal Switch)
15 RS-232C 2 external interfaces Modem	
16 RS-485 2 external interfaces Keyboard, PT	Z camera
17 Reset switch Reset to factory defaults -	
18 Al1 - Al16 Alarm inputs for external devices Sensors	
19 Power switch On/Off switch -	
20 Power supply Mains power connection -	

Front panel controls

The following diagram and table set out the controls on the front panel of the DVR:



Front panel controls (continued)

No.	Designation	Function		
1	Ċ	Power-on indicator when DVR is in operation		
2	盎	Indicates Ethernet connection		
3	Ð	Display when mirroring hard disks		
4	$\Theta_1 \Theta_2 \Theta_3 \Theta_4$	Display when using hard disks		
5	▲	Open built-in CD/DVD-RW writer		
6	Display window	Status display		
7	■ <)) (1) 11 \$# 11 57 ⊕ € 1 2 3 4	Function buttons		
8	1 to 16	Select camerasEnter passwords		
9	Menu navigation	Navigation and selection within the menu		
10		Open/quit menu structure		
11	Shuttle ring	Infinitely adjust playback speed		
12	● 	USB ports for mouse and external storage media		
13	Jog dial	 Change size of frame in picture-in-picture mode Change numerical values in Setup menu Frame-by-frame playback in Play mode 		
14	¢	Reset alarmView event list		
15	Ĭ	Start/end panic recording		
16	▶∕॥ ♀∕∎ ◀ ▶ ◀I I►	Playback functions (primary assignment)		
10	▲ ☆ ≻ □ ᠿ	PTZ camera functions (secondary assignment)		
17	Hard disks	max. 4 hard disks in the exchange frame		

Key to controls

Function buttons

Element	Function
	On/Off Triplex
⊴≫	On/Off Audio
C.	Defining bookmarks in Search menu by pressing and holding button
۹.	Copying recordings in Search menu by pressing and holding down button
璨	Freeze On/Off
\blacksquare	Change display mode
r C	Sequence On/Off
\oplus	PTZ camera functions On/Off
⊕ 、	Zoom On/Off
1 2 3 4	Spot monitor assignments

\oplus PTZ camera functions

Element	Function
Å	Zoom in
*	Zoom in
\rightarrow	Close-up
)	Wide-angle
	Save preset
\$ \$	Load preset

Q Playback functions

Element	Function
►⁄II	Start/pause playback
٩/٣	Select Search/Play functionStop playback
	Fast rewind
••	Fast forward
▲	Frame-by-frame rewind
►	Frame-by-frame forward

Remote control functions

The following diagram and table set out the functions on the remote control:

ſ			No.	Designation	Function
	Select System D D	$\left \begin{array}{c} 1 \\ \end{array} \right $	1	SPOT 1 - 4	Spot monitor assignments
(12)		2	2	Ϋ́	Reset alarmView event list
(11)_	5 6 7 8 9 10 11 1z 13 14 15 16	3	3	1 to 16	Select camerasEnter passwords
			4	≛★►⊑ᠿ 🍲	PTZ camera functions
(10)		(4)	5	PTZ	PTZ camera functions On/Off
			6	ZOOM	Zoom On/Off
		(5)	7		Playback functions
(9)			8	PANIC	Start/end panic recording
(8)		(6)	9	Menu navigation	Navigation and selection within the menu
\bigcirc	Remote Controller	(7)	10	MENU	Open/quit menu structure
			11	록ѱ₫	Function buttons
			12	田山寺	Function buttons

Playback functions

Element	Function
	Select Search/Play functionStop playback
\square	Pause playback
\triangleright	Start playback
$\langle I \rangle$	Fast rewind
\Box	Fast forward
53	Frame-by-frame rewind
[2]	Frame-by-frame forward

Menu overview

The following illustration shows the structure of the complete menu tree that is accessible using the mouse control:



Menu overview (continued)

The following illustration shows the structure of the complete menu tree that is accessible using the mouse control:

Setup menu	System	Information
		Date/Time
1		- Storage
		— User
		- Shutdown
		Log out user1
1		
	Network	Network
		Notification
	— Devices	Camera
		— Alarm-Out
		— Display
		Remote Control
	Record	Record
		Schedule
		Pre-Event
		Archive
	-	
	Event	Alarm-In
		Motion Detection
		Object Detection
		- Video Loss
		Video Blind Text-In
		System Event
		Event Status
- Triplex		Event Status
Search	Go to the First	
oouron	Go to the Last	
	Go to the Date/Time	
	Bookmarks	
	Calendar Search	
	Event Log Search	
	Text-In Search	
	Motion Search	
	Clip-Copy	
	Print	
	Zoom	
	Audio	
	Use De-Interlace	
	Slow Play	▶ <u> </u> x1
		- x1/2
	Data Source	► Record
		Archive
	Exit Search	

Accessing the menus

Accessing the Display menu

Requirement:

• The current camera image is shown in full image or quad image.

Step	Action	Access using	Key sequence/menu path
1		Device	\blacksquare
	Open Display menu	Remote control	
		Mouse	Display

Access to submenu via Device/Remote Control

Submenu	Camera image	Key sequence
Change Display modes (PIP, 2x2, 3x3, 4x4)	Without frame	$\boxplus\boxplus\boxplus\boxplus\boxplus\ldots$
Previous/Next Group	Without frame	∢ ►
Edit Group	With frames	◀ > 📑
Change position of image-in-image	Without frame	▲ ▼
Change size of image-in-image	Without frame	Jog dial

Accessing the PTZ menu

Requirement:

- A PTZ camera is connected and configured.
- Current camera image is shown as a full image.

Step	Action	Access using	Key se	que	nce/me	nu p	ath
	Open PTZ menu	Device	\oplus	>	◄	>	
1	Result: Menu of the configured PTZ camera is shown.	Remote control	PTZ	>	- ↓	>	MENU
		Mouse	PTZ				

Accessing the menus, continued

Accessing the Setup menu

Requirement:

• The current camera image is shown in full image or quad image.

Step	Action	Access using	Key sequence/menu path
	Open Setup menu Result: Prompt for user name and password.	Device	
1		Remote control	MENU
		Mouse	Setup menu
	Log in as user.		
	User name: admin		
2	Password: (blank)		
	Note: Use default access data only for first-time access.		

Accessing the Search menu

Requirement:

• The current camera image is shown in full image or quad image.

Step	Action	Access using	Key sequence/menu path
	Open Search menu Result: Search for recorded images is activated.	Device	⁰∕∎ > ≣∎
1		Remote control	> MENU
		Mouse	Search

Getting started

Checklist for DVR operation

Step	Action	Menu path
1	Connect peripheral devices as per planned setup.	
2	Specify menu language.	Setup menu > System > Information
3	Adjust date and time.	Setup menu > System > Date/Time
4	Set up user.	Setup menu > System > User
5	Set up network and desired notification channels (optional).	Setup menu > Network >
6	Register peripherals with DVR.	Setup menu > Devices >
7	Set up event types and associated responses.	Setup menu > Event >
8	Set up recording parameters and schedule.	Setup menu > Record >

Connecting the remote control and DVR

The remote control and DVR can be assigned an ID, because the ID of each DVR in the network must be unique. The DVR will then only respond to the remote control with the matching ID.

- If the system ID in the DVR is 0, it will respond to the remote control regardless of the remote's ID.
- If the system ID in the DVR is not 0, you must set the ID of the remote control identically.

Step	Action	Menu path
1	Set DVR system ID.	Setup menu > System > Information
2	Match remote control to system ID by pressing ID button on remote control.	
3	Select relevant number on remote control.	

Getting started (continued)

Switching on the DVR

Requirement:

- The start-up preparations are complete.
- DVR mains plug is connected.

Step	Action
1	Switch on power switch.
2	Switch on monitor.
Z	Result: System starts up automatically and is ready to use.

Switching off the DVR

Requirement:

• You have accessed the Setup menu.

Step	Action	Menu path
1	Shut down the system. Result: System shuts down automatically.	Setup menu > System > Shutdown
2	After shutdown, switch off power switch.	

Administration

Saving your system setup

You can save your DVR's setup data, including its network configuration.

Requirement:

• USB memory stick

Step	Action	Menu path
1	Insert a USB memory stick into one of the USB ports.	
2	Export your setup.	Setup menu > System > Information > Setup Export
3	Specify a file name.	
4	Export your setup.	Export

Loading your system setup

You can load your stored DVR system setup with or without its network configuration.

Requirement:

• USB memory stick with stored setup

Step	Action	Menu path
1	Insert a USB memory stick into one of the USB ports.	
2	Import your setup.	Setup menu > System > Information > Setup Import
3	Select the file name and, where appropriate, the network configuration.	
4	Import your setup.	Import

Deleting recordings

You can only delete all your recordings together. It is not possible to delete recordings from a specific time period.

Step	Action	Menu path
		Setup menu > System > Information > Clear All Data
1	Delete all recordings.	or Setup menu > System > Storage > Information tab > Using > Clear

Downloading software updates

You can download software updates for your DVR from a USB memory stick.

Requirement:

· USB memory stick with latest software release

Step	Action	Menu path
1	Insert a USB memory stick into one of the USB ports.	
2	Start update.	Setup menu > System > Information > Upgrade
3	Install new release.	

Hiding from specific users

You can hide video images and camera data according to the preset user rights.

Step	Action	Menu path
1	Set camera Covert mode.	Setup menu > Devices > Camera > Settings
2	Cancel 'Covert Camera View' access for specific users (groups).	Setup menu > System > User

Restoring factory defaults

Before restoring the factory defaults, you should export your current system settings in case you need to reimport them later. (see Saving your system setup and Loading your system setup)

Step	Action
1	Shut down the system.
2	Switching off the DVR
3	Push a paper clip into the Reset button (on the rear of the DVR) and hold it there.
4	Switching on the DVR
5	Wait for all the LEDs to flash 5 times (about 30 seconds).
6	Withdraw the paper clip.

Changing hard disk

Requirements:

- At least one hard disk is installed in hard disk drive rack.
- · No hard disk operation
- Key for hard disk drive rack



3	Unlock the hard disk using the key.	
4	Open the drive rack frame and pull the hard disk out on its frame.	
5	Open the drive rack frame for the new hard disk and slide the hard disk into the drive rack slot of the video recorder.	
6	Swing down the frame. Result: The hard disk is now connected to the video recorder.	
7	Lock the drive rack using the key.	
8	Swing the hard disk cover back into position.	
9	Select the new hard disk.	Setup menu > System > Storage > Information > HDD Insert

Fitting hard disk into an empty drive rack

Requirements:

- · Mounting screws for installation of hard disk drives
- Suitable screwdriver
- Key for hard disk drive rack

Step	Action
1	Swing out the hard disk cover on the front of the device.
2	Release the empty drive using the key.
3	Open the drive rack frame and pull out the drive rack frame.
4	Insert the hard disk to be connected into the empty drive rack and secure it with the fastening screws.
5	Open the drive rack frame for the new hard disk and slide the hard disk into the drive rack slot of the video recorder.
6	Swing down the frame. Result: The hard disk is now connected to the video recorder.
7	Lock the drive rack using the key.
8	Swing the hard disk cover back into position.

Mirroring of hard disks

Mirroring of hard disks prevents the loss of records in the event of a hard disk defect.

Requirements:

- The Digital Video Recorder has 2 or 4 hard disks installed
- The destination hard disk is identical to the source hard disk in type and memory capacity
- The source hard disk and the destination hard disk are used for records only

Step	Action	Menu path
1	Format the source and destination hard disks for records.	Setup menu > System > Storage > Information > Format > Record
2	Select the source and destination hard disks as Mirror 1 and Mirror 2. Note: Only the hard disk pairings internal1 to internal2, and internal3 to internal4 can be used for mirroring.	Setup menu > System > Storage > Information > Mirroring Setup > InternalX -> InternalX
	Start Mirroring. Results:	Start
3	 The source hard disk and destination hard disk are synchronised (approx. 40 minutes for 10 GB). 	
	• All data on the destination hard disk are deleted.	
	All records are written to both hard disks.	
	Interrupting Mirroring. Results:	Setup menu > System > Storage > Information > Mirroring Setup > No Mirror 1/2
4	• The status of the destination hard is set to:	Not used
4	• The hard disk can now only be used for searching for records.	
	• If the hard disk is to be used for records or archiving, it must be formatted.	Setup-menu > System > Storage > Information > Format > Format
5	Continuing Mirroring - see step.2	Setup menu > System > Storage > Information > Mirroring Setup > InternalX -> InternalX

Determining the memory requirement of a recording

The amount of memory recorded video sequences will take up depends on the following factors:

- · Picture quality
- number of images per second
- duration

The memory requirement is calculated by this formula:

Memory requirement = picture size x duration of recording x images per second

Calculation example: CIF resolution (PAL):

Picture	Picture Duration of		Approx. memory space		
quality	size	recording	5 images/s	10 images/s	25 images/s
Basic	2.4 kB	24 hours	1.04 GB	2.07 GB	5.18 GB
Standard	4.8 kB	24 hours	2.07 GB	4.15 GB	10.37 GB
High	9.6 kB	24 hours	4.15 GB	8.29 GB	20.74 GB
Very high	14.4 kB	24 hours	6.22 GB	12.44 GB	31.10 GB

Calculation example: 2CIF / Half D1 resolution (PAL):

Picture	Picture Duration of		Approx. memory space		
quality	size	recording	5 images/s	10 images/s	25 images/s
Basic	4.8 kB	24 hours	2.07 GB	4.15 GB	10.37 GB
Standard	9.6 kB	24 hours	4.15 GB	8.29 GB	20.74 GB
High	19.2 kB	24 hours	8.29 GB	16.59 GB	41.47 GB
Very high	28.8 kB	24 hours	12.44 GB	24.88 GB	62.20 GB

Calculation example: 4CIF / Half D1 resolution (PAL):

Picture	Picture Duration of	Duration of	Approx. memory space		
quality	size	recording	5 images/s	10 images/s	25 images/s
Basic	8 kB	24 hours	3.46 GB	6.9 GB	17.28 GB
Standard	18 kB	24 hours	7.78 GB	15.55 GB	38.88 GB
High	36 kB	24 hours	15.55 GB	31.1 GB	77.76 GB
Very high	80 kB	24 hours	34.56 GB	69.12 GB	172.8 GB

Searching for recordings

Find first stored recording

Search

Ľ

Find last stored recording

Go to the Last...

Find recording by date and time

Search

Go to the Date/Time...

Bookmark Search

Using Bookmark Search you can search for records based on previously defined bookmarks:

Search

Calendar search

For each camera the calendar search indicates:

- the days from which there are recordings
- the time ranges of recordings on those days



Event log search

The event log search enables you to search for events based on specific criteria, such as:

- movements recorded by a specific camera
- alarm from a specific alarm input
- System events

Search

Event Log Search...

Text-in search

The text-in search enables you to search for recordings based on specific text inputs.

Search

Text-In Search...

Searching for recordings (continued)

Motion search

The motion search function can detect movements in recordings within defined zones for one camera. 2 types of motion search are possible:

- Motion search: Search for movement in a defined zone.
- Museum search: Search for movement of a defined object.



Copying recordings

Recordings can be written to a CD or copied to a USB memory stick.



Using Bookmark search

Defining bookmarks

Step	Action	Menu path	
1	Find desired recordings.	Search	
	Open bookmark search.		
2	Result: A list of all bookmarks so far defined will be displayed.	Search > Bookmarks	
3	Add bookmark.		
	Result: The new bookmark with date and time will be added to the list.	Add Current Position	

Perform bookmark search

Step	Action	Menu path
	Open bookmark search.	
1	Result: A list of all bookmarks so far defined will be displayed.	Search > Bookmarks
2	Select the desired bookmark from the list.	Bookmark

Search

Term	Symbol	Meaning
No.		Number of the bookmark
Title		Name of the bookmark
Bookmark		Activates the search for the defined bookmark
Channels		Display the channels
Add Current Position		Adds a new bookmark.

Using calendar search

Performing a calendar search

Step	Action	Menu path
1	Open calendar search. Result: Calendar and time line are displayed.	Search > Calendar Search
2	Select day and time	
3	Confirm input.	Go

Search Calendar Search...

Term	Symbol	Meaning
		Date display • Grey: No recording available • White: Recording available
		Hours displayWhite: Recording available
Select a Segment	_	If the date and time on the DVR have been changed (such as when switching to Summer time) there may be multiple recordings for one time from the same camera. They are stored in separate segments.

Using event log search

Performing an event log search

Step	Action	Menu path
1	Open event log search. Result: The result of the last search is displayed.	Search > Event Log Search
2	Define criteria.	Option
3	Confirm input. Result: List of search results is displayed.	Search
4	Select desired entry from list.	

Search C Event Lo	og Search ⊏	> Option
Term	Symbol	Meaning
From First	V	Start date
To Last	····	End date
Check Time Overlap	\checkmark	Activates a system prompt if there are multiple recordings for the same time range
Alarm-In		Alarm inputs in response to which a search for events is to start
Motion		Cameras on which to search for motion detection
Objekt Detection		Cameras on which to search for object detection
Video Loss		Cameras on which to search for video loss
Video Blind		Cameras on which to search for video blind
Text-In		Text input devices on which to search for events
Record Channels		Cameras on which to search for events
	$\bigtriangledown \oslash \bigtriangledown$	Search for system events: Setup menu > Event > System Event > Actions

Using text-in search

Performing a text-in search

Step	Action	Menu path
1	Open text-in search. Result: The result of the last search is displayed.	Search > Text-In Search
2	Define text inputs.	Option
3	Confirm input. Result: List of search results is displayed.	Search
4	Select desired entry from list.	

Search	Text-In Search	> Option
Term	Symbol	Meaning
From First		Start date
To Last		End date
Channels		Text input devices on which to search for events
		Type of text input:
		Any Text-In Product
		Generic Text
		Epson
No.	\checkmark	Numbers of text elements to search for
Keyword		Text element
Case Sensitive	\checkmark	Makes search case-sensitive

Using motion search

Performing a motion search

Step	Action	Menu path
1	Display desired camera in single frame.	Display > Camera >
	Open motion search.	Search > Motion Search
	Enter settings for motion search.	Option
	Confirm input. Result: List of search results is generated.	Search
	Select desired entry from list.	

Search	Motion Search.	Cption
Term	Symbol	Meaning
From First		Start date
To Last	V	End date
		Type of search:
Туре		Motion search Search for movement in a defined zone
		Museum Search Search for movement of a defined object.
Zone		Definition of motion-sensitive zones for motion search or museum search: See "Zone" on page 46.
		Sensitivity of motion detection of:
		1 (Dull)
Constituite		2
Sensitivity		3
		4
		5 (Sensitive)
Min. Blocks	_ 	Motion search only (not museum search): Specify in how many motion-sensitive blocks motion must be detected as a minimum to trigger an alarm

Copying recordings

Search

 \triangleleft

Copying recordings to CD or USB memory stick

Clip-Copy...

Step	Action	Menu path
1	Find desired recordings. Note: Make a note of the data of the recordings you want to copy.	Search >
2	Define settings.	Search > Clip-Copy
3	Start copying. Result: The recordings are copied.	Start

T	0	Handar
Term	Symbol	Meaning
Data Source		Record
From First	✓	Start date
To Last	····	End date
Channels		Assignment of cameras from which recordings are to be copied
Password		Use password, if desired
		Destination medium:
		Internal CD-RW
Dest.		USB-CD-RW
Dest.		1. USB Storage
		2. USB Storage
		3. USB Storage
File name		Name of file on destination medium
Status		Copy status

Menu descriptions – Setup menu

The Setup menu has the following sub-menus:

System menu

					ы
5-e=	-	-	-	0	
				£.	
			- 52	۶.	

On the "System" menu

- · the basic settings are made
- · users are administered
- the system is shut down.

Network menu

On the "Network" menu the network settings are made. Network access provides access to all the functions of the DVR via

- WebGuard, same access using Internet Explorer
- RAS (Remote Administration System), independent of Internet Explorer

The DVR can be configured so that alarms trigger a notification by e-mail or notify an RAS.

Devices menu



On the "Devices" menu the connected peripheral devices are configured. Possible peripherals are:

- Cameras
- · Microphones and speakers (through amplifier)
- Sirens and signal lamps
- Monitors
- Remote control for PTZ

Record menu



- On the "Record" menu the following settings are made:
- Recording quality
- Timer control
- Duration of pre-event recording
- · Schedule and method of archiving

Event menu

On the "Event" menu the following settings are made:



- · Assignment of alarm inputs to alarms
- · Configuration of motion-sensitive zones individually for each camera
- Definition of text input device and assignment to alarms
- Response to undesirable events

The event status is additionally displayed.

Setup menu

System – Information

On the "Information" menu

- basic information is entered and displayed
- · software updates are installed
- recorded data are deleted as required

Setup menu	System	Information
Term	Symbol	Meaning
Site		Location of DVR
System ID		 Identifier for remote control The remote control and DVR must be set to the same ID. If the system ID in the DVR is 0, it will respond to the remote control regardless of the remote's ID.
Language	_	Menu language
Version		Version of DVR software
Upgrade		Starts installing latest version of software via USB port
Import		Import setup
Export		Export setup
Show System Log		Show log of all actions and events
Recorded data		
From		Date of oldest recording
То		Date of newest recording
Clear All Data		Deletes all stored data

Setup menu (continued)

System – Date/Time

On the "Date/Time" menu

- time and date settings are made
- dates of public holidays are entered
- time synchronisation is configured.

Setup menu	System	Date/Time
Term	Symbol	Meaning
Date		Date
Format	_	Date display format
Time		Time
Format		Time display format
Time Zone		Local time zone
Use Daylight Saving Time	• 🗸	Activates use of summertime Daylight Saving Time
Setup menu	System ⊏	Date/Time
Term	Symbol	Meaning
No.		Number of entered public holiday
Date		Date of each desired public holiday
Setup menu	System	Date/Time
Term	Symbol	Meaning
Term Automatic Sync.	Symbol	Meaning Activates synchronisation with time server
	Symbol	•
Automatic Sync.		Activates synchronisation with time server
Automatic Sync. Time Server		Activates synchronisation with time server IP address of time server
System – Storage

On the "Storage" menu the status and usage of the available storage media is displayed.

Setup menu	System	Storage
Term	Symbol	Meaning
Туре		Type of storage medium
Capacity		Size of storage medium
Format		Storage medium usage >>
Information		Time range of recorded data >>
Mirroring Setup		
		Mirroring hard disks 1 and 2
No Mirror 1		No Mirror 1
		Internal 1 -> Internal 2
		Internal 2 -> Internal 1
		Mirroring hard disks 3 and 4
No. Misson O		No Mirror 2
No Mirror 2		Internal 3 -> Internal 4
	-	Internal 4 -> Internal 3
HDD Remove/Insert		Deactivates/activates the use of the respective hard disk

└── Format

Term	Symbol	Meaning	
		Use of storage medium:	
	-	Record	
Use as		Archive	
		Not using	
		Activating permits:	
Partition		CD/DVD burn Reserves a data buffer as a separate partition. This is essential for burning CDs, and must be activated for a storage medium with "Record" usage.	
Format		Formatting deletes the recordings from the hard disk	
L Information	Symbol	Meaning	
Recorded data	Symbol	meannig	
From		Start date of recorded data	
То		End date of recorded data	
Clear		Delete all recordings	
Setup menu C	∕stem ⊂≻	Storage	
Term	Symbol	Meaning	
Туре		Memory type	
Disk Bad		Data carrier status	
Temperature		Temperature status	
S.M.A.R.T.		Result of S.M.A.R.T. check	

System – User

On the "User" menu the user groups and individual users are set up.

Setup menu	System 🖒	User
Term	Symbol	Meaning
Group & User, Group field		Assignment of group access privileges Table of possible group access privileges >>
Group & User, User field		Set password
+ Group		Add a new group
+ User		Add a new user Set password
Auto Login	_	User to be logged in automatically
Auto Logout	_	Time after which logged-in user is automatically logged out

Table of possible group access privileges

Group access privilege	Meaning
Shutdown	May shut down the DVR
Upgrade	May install a new firmware version
System Time Change	May change the time setting
Data Clear	May delete recording data
Setup	May make changes anywhere on the Setup menu
Colour Control	May change the picture settings
PTZ Control	May control PTZ cameras
Alarm-Out Control	May reset alarms
Covert Camera View	May view video images from covert cameras
System Check	May interrogate system status
Record Setup	May make changes to the Record menu
Search	May use Search mode
Clip-Copy	May copy video images

System – Shutdown									
Setup menu									
System – Log out USER									
Setup menu		0		Log out USER					

Network – Network

On the "Network" menu all settings required to ensure network access are made.

Setup menu	Network	Network	Network
Term	Symbol	Meaning	
		Transmission	bandwidth:
Transfer Speed		(bps)	bits per second
		(ips)	images per second
		Quality of pic	ture transmission via network (PAL):
		Very high	14.4 kB/picture
Quality		High	9.6 kB/picture
		Standard	4.8 kB/picture
		Basic	2.4 kB/picture
		Quality of rec	corded images
Resolution		Standard (CII	F) CIF
		High (Half D1	I) 2CIF
		Selecting Auc	dio Channel
Remote Audio Channel	_	Select From I	RAS
		1 - 16	

Setup menu (cor	ntinued)	
Setup menu	twork □	> Networ	k 🖒 🗀 LAN
Term	Symbol	Meaning	
		Type of con	nection to DVR:
		Manual	Manual connection required input of: • IP Address • Gateway • Subnet mask
Туре		DHCP	Automatic assignment of IP address of DNS server
		ADSL (with PPPoE)	Requires following input as specified by provider:IDPassword
		Note: Use of	of modem must not be activated.
DNS Server		Address of	DNS server
Port Number Setup		Definition of the port numbers that are required for access to the Digital Video Recorder using the RAS plus software or using WebGuard	

Setup menu	ork 🖒	Network
Term	Symbol	Meaning
Use DVR Name Service	\checkmark	Enables the DVR name service
DVRNS Server	•••	IP address or domain name of DVRNS server DVRNS = Digital Video Recorder Name Service
Port	•••	Port for DVRNS
Use NAT	\checkmark	Enables NAT (Network Address Translation) use
DVR Name		Name by which the DVR is to be registered with the DVRNS server
Check		Check DVR name for usability after entering
Help Desk		Information from help desk if DVRNS setting correct
Setup menu	ork 🖒	Network
Term	Symbol	Meaning
Use WebGuard Service	\checkmark	WebGuard Service activated
Port		Port for the WebGuard Service

Network – Notification

On the "Notify" menu the method of notification is defined.

Setup menu	work	Notification
Term	Symbol	Meaning
Enable	\checkmark	Enables notification by e-mail
SMTP Server		IP address of SMTP server
Port		Port for SMTP server Default is port 25.
Use SSL/TLS	\checkmark	Activates the Encryption
Authentication		Login to SMTP server
Sender		E-mail address of sender
Recipient		E-mail address of recipient
Attached Image Quality	_	Resolution of attached picture
Setup menu	work	Notification
Term	Symbol	Meaning
LAN	\checkmark	Enables notification of an RAS via LAN
No.		Number of IP address
IP Address		IP addresses of RAS PCs
Retry	_	Number of notification attempts by the DVR in the event of an error

Devices – Camera

On the "Camera" menu the cameras are configured.

Setup menu	Device	s Camera Settings		
Term	Symbol	Meaning		
No.	\checkmark	Activates the cameras		
Title		Name of camera		
		Visibility of recordings and camera data depending on user access privileges:		
		Normal All users see all camera data and all recordings		
Use	_	Covert1 Users without relevant access see camera title, status symbol, but no recordings		
		Covert2 Users without relevant access see only camera title, but no recordings		
Setup menu	Device	s 🖒 Camera 🖒 🗋 PTZ		
Term	Symbol	Meaning		
No.		Number of camera		
Product	_	PTZ camera type as per specified list		
ID		Unique ID of PTZ camera		
Port		Interface type of PTZ cameras		
		Settings as specified by PTZ camera manufacturer:		
	-	Baud rate		
		Dauu Tale		
Setup		Data		
Setup				

Devices – Alarm-Out

On the "Alarm-Out" menu the alarm outputs are configured.

- "Settings" tab: The alarm outputs are configured.
- "Schedule" tab: Time slots are defined in which the alarm outputs respond in specific ways.

Setup menu		5 ⊂>	Alarm-Out
Term	Symbol	Meaning	
No.		Number o	of alarm output
Title		Name of a	alarm output
		Contact m	nethod of alarm output:
Туре		NO	Normally Open
		NC	Normally Closed
Dwell time	_	Duration of	of alarm signal
Setup menu		s⊂>	Alarm-Out
Term	Symbol	Meaning	
Term No.	Symbol	•	of schedule entry
	Symbol	•	•
No.		Number o Day of the	•
No. Day		Number o Day of the Time rang	e week
No. Day Range	· · · · · · · · · · · · · · · · · · · ·	Number o Day of the Time rang	e week ge at 15-minute intervals
No. Day		Number of Day of the Time rang Response	e week ge at 15-minute intervals e in defined period:
No. Day Range	· · · · · · · · · · · · · · · · · · · ·	Number o Day of the Time rang Response Event	e week ge at 15-minute intervals e in defined period: Alarm in response to event

Devices – Display

On the "Display" menu the mode of on-screen display is configured.

- "OSD" tab: Specify what additional information is displayed on-screen.
- "Main Monitor" tab: Specify how the camera images are displayed on the main monitor.
- "Spot Monitor" tab: Specify which cameras are displayed on the spot monitors.

Setup menu	> Devices	☐ ☐> Display	
Term	Symbol	Displayed symbol	Meaning
Status			Activates display of:
Remote control	\checkmark	<u> </u>	Remote control
Zoom	\checkmark	€	Visible when Zoom mode enabled
Network	\checkmark	嵒	Visible when DVR operating in a network
Freeze & Sequence	\checkmark	පප	FreezeVisible when Sequence mode enabled
Screen Group	\checkmark	1/4	Displays number of groups, and their ID numbers
Free Space		è	 Visible when Recycle mode enabled Remaining hard disk capacity, if Recycle mode not selected
Archive	\checkmark	≙	Visible when archiving in progress
Mirror	\checkmark	Ø	Mirroring
Date	\checkmark	-	Date
Time	\checkmark	-	Time
User name	\checkmark	-	Display of user name
Camera			Activates display of:
No.	\checkmark	-	Display of camera number
Title	\checkmark	-	Display of camera title
Record	\checkmark	≇⊡⊙	Display of Record symbols
PTZ	\checkmark	PIZ	Visible when PTZ camera is displayed
Text-In	\checkmark		Display of character string
Audio	\checkmark	<)))	Audio
Transparency		-	Transparency of menu screens
OSD Margin		-	Distance of displayed symbols from screen margin

Setup menu (continued)				
Setup menu	Devices	Display C Main Monitor		
Term	Symbol	Meaning		
		Modes of sequences in multiple playback:		
Mode		Full All cameras are switched through sequentially.		
		Cameo Sequence Only the image at the bottom right is switched through; cameras in "Covert" mode are not displayed to users without "Covert" access.		
Interval	_	Time interval between picture refresh		
Event Monitoring On	\checkmark	Displays image of relevant camera in full-screen mode when an event occurs		
Setup menu	Devices	Display C In Spot monitor		
Term	Symbol	Meaning		
No.		Number of spot monitor output		
Channels		Camera Selecting a camera		
Unanneis		Dwell time Duration of display of the camera image		

Devices – Remote Control

On the "Remote Control" menu the remote control function is configured.

Setup menu	evices	> Remote Control
Term	Symbol	Meaning
Port	_	Interface type of remote control
		Setup as specified by manufacturer:
		Baud rate
Setup		Data
		Stop Bit
		Parity
Remote Control Product	_	Remote control type as per specified list

Record – Record

On the "Record" menu the basic settings for recordings and their quality are made.

Setup menu Record Record				
Term	Symbol	Meaning		
Recycle	\checkmark	Enables automation hard disk is full	c overwriting of the oldest recordings when the	
	_	Note: If not enable	ed, recording ends when the hard disk is full.	
Event Record Dwell	_	Duration of record	ing when an event occurs	
Auto Deletion		Specify time after	which automatically deleted	
Use Real Time High Resolu- tion Record	\checkmark	Activates high reso	olution recording	
Audio Record		Selection of the au	udio channels	
Use Panic Recording	\checkmark	Enables the panic	recording function	
		Duration of panic r	recording	
Panic Recording Duration		No Limit	End panic recording by pressing PANIC button	
		xx min.	Panic recording ends after preset time or by pressing PANIC button	
ips	—	Number of recorde	ed images per second in panic recording	
Quality	_	Picture quality of t	he recorded images in panic recording	
Resolution	_	Quality of recorded	d images	

Record – Schedule

On the "Schedule" menu the schedule for recording is defined.

Setup menu	Record	Schedu	le
Term	Symbol	Meaning	
Schedule On	\checkmark	Note: A reco	edule entries ording is made only if schedule entries are enabled. nly panic recording is possible.
No.		Number of s	chedule entry
Day	_	Day of the w	veek
Range		Time range a	at 15-minute intervals
		Response:	
		No Record	-
		Time	Always record in the defined time slot in the quality set for "Time" mode
Mode		Event	Record only in case of event in the defined time slot in the quality set for "Event" mode
		Time & Event	Always record in the defined time slot in the quality set for "Time" mode, also in case of event in the defined time slot in the quality set for "Event" mode
Channels		Assignment	of cameras to schedule
		Picture data	settings in Time and Event modes:
Settings	_	ips N	Number of recorded images per second
		Quality F	Picture quality of recorded images
		Picture data	defaults in Time and Event modes:
Default.	_	ips N	Number of recorded images per second
		Quality F	Picture quality of recorded images

Record – Pre-Event

On the "Pre-Event" menu the settings for recording prior to the event are made.

Setup menu	Record	Pre-Event
Term	Symbol	Meaning
No.	\checkmark	Activates the cameras
ips	_	Number of recorded images per second prior to the event
Quality		Picture quality of the recorded images prior to the event
Resolution	_	Quality of recorded images
Dwell Time		Recording time prior to the event Note: The pre-event recording memory capacity is limited. Consequently, the maximum recording time prior to the event, the number of recorded images and picture quality are inter- dependent.

Record – Archive

On the "Archive" menu the schedules and settings for archiving are entered.

Setup menu	Record	> Archive
Term	Symbol	Meaning
Archiving on	\checkmark	Enables the archiving settings
Schedule		
Day	\checkmark	Day of week from which to archive recordings
Range		Time range
Archiving - data range		
		Start of archiving, from:
From		Last Archived Time of last archiving
		xx/yy/200x Defined date and time
		End of archiving, up to:
То		Continue No end
		xx/yy/200x Defined date and time
Popula		Enables automatic overwriting of the oldest recordings when the archive medium is full.
Recycle		Note: If not enabled, archiving ends when the archive medium is full.

Event – Alarm-In

On the "Alarm-In" menu the alarm inputs and responses to events are configured.

Setup menu	Event	L→ Alarm-In L→ C→ Settings	
Term	Symbol	Meaning	
No.	\checkmark	Enables the alarm inputs	
Title		Name of alarm input	
		Contact method of alarm input:	
Туре	•	NO Normally Open	
		NC Normally Closed	
Setup menu	Event	Alarm-In C→ Actions 1	
Term	Symbol	Meaning	
No.		Number of alarm input	
Record		Assignment of cameras to record in event of alarm These cameras must be in "Event" or "Time and Event" mode within the time slot: Setup menu > Record > Schedule	
Alarm-Out		Assign and enable • alarm outputs • internal beep by DVR These alarm outputs and the internal beep must be enabled within the time slot: Setup menu > Devices > Alarm-Out > Schedule	
		Assign and enable notifications:	
Notify		Mail Option "Image Attachment" for Camera 1-16	
		LAN 1 to LAN 5	
1		Alert Window	
		The selected function must be enabled: Setup menu > Network > Notification	

Setup menu	Event	Alarm-In ☐ Actions 2
Term	Symbol	Meaning
No.		Number of alarm input
PTZ		Select PTZ cameras to record in event of alarm and select the desired settings
Spot monitor		Select spot monitor on which camera image is displayed in event of alarm

Event – Motion Detection

On the "Motion Detection" menu the motion-sensitive zones are defined and responses to events configured.

Setup menu	Event	Image: Constraint of the section Image: Constraintof the section	
Term	Symbol	Meaning	
No.	\checkmark	Enables motion detection for the camera	
		Sensitivity of motion detection:	
Sensitivity		Daytime	
		Nighttime	
		Select the motion-sensitive blocks within the time slot Left mouse button functions: • Click to select/deselect • Click - hold down - drag to define a zone for selection/deletion/back	
		Right mouse button functions or menu in time slot to select blocks:	
Zone		Select Select complete row of blocks	
Zone		Clear Clear selection of a row	
		Reverse Reverse selection of a row	
		Select all Select all blocks	
		Clear all Clear selection of all blocks	
		Reverse all Reverse selection of all blocks	
		Specify in how many motion-sensitive blocks motion must be detected as a minimum to trigger an alarm:	
Min. Blocks		Daytime	
		Nighttime	
Zone View	\checkmark	Mark the motion-sensitive zones (red in event of motion)	
Motion Ignoring		Time interval between 2 events logged as separate events:	
Interval		Never Each motion detection is logged as a separate event.	
Daytime Setup		Definition of "Daytime" time range	

Setup menu (continued) Motion Detection \leq Actions 1 Setup menu... Event Term Symbol Meaning No. Number of alarm input Assignment of cameras to record in event of alarm These cameras must be in "Event" or "Time and Event" mode within Record |the time slot: Setup menu > Record > Schedule Assign and enable · alarm outputs internal beep by DVR Alarm-Out \bigvee These alarm outputs and the internal beep must be enabled within the time slot: Setup menu > Devices > Alarm-Out > Schedule Assign and enable notifications: Mail Option "Image Attachment" for Camera 1-16 LAN 1 to LAN 5 $\overline{\mathbf{V}}$ Notify Alert Window The selected function must be enabled: Setup menu > Network > Notification Setup menu... Event Motion Detection Actions 2 Term Symbol Meaning Number of alarm input No. Select PTZ cameras to record in event of alarm and select the PTZ desired settings -Select spot monitor on which camera image is displayed in event

of alarm

•

Spot monitor

Event – Object Detection

On the "Object Detection" menu the motion-sensitive zones are defined and responses to events configured.

Setup menu	-> Event	C Cbject Detectio	n	
Term	Symbol	Meaning		
No.	\checkmark	Enables object detection for	the camera	
		Sensitivity of object detection	1:	
Sensitivity		1 (Dull)		
		5 (Sensitive)		
		Select the motion-sensitive blocks within the time slot Left mouse button functions: • Click to select/deselect • Click - hold down - drag to define a zone for selection/deletion/back		
			s or menu in time slot to select blocks:	
		Select	Select complete row of blocks	
Zone		Clear	Clear selection of a row Reverse selection of a row	
	(_)	Reverse		
		Select all	Select all blocks	
			Clear selection of all blocks	
		Reverse all	Reverse selection of all blocks	
		View Ref. Image	Displays the reference image	
		Set Ref. Image	Uses the current image as the reference image	
	_	v	nent-sensitive blocks in which movement /hat period of time, for the alarm to be	
Settings		Min. Blocks		
	-	Max. Blocks		
	Activation Time			
Zone View	\checkmark	Mark the motion-sensitive zo	nes (red in event of motion)	
Use Ignoring Time		Time Setup Definition of t reaction to the occurrence of	the period of time during which there is no an event	

Setup menu (continued) **Object Detection** \leq Actions 1 Setup menu... Event Term Symbol Meaning No. Number of alarm input Assignment of cameras to record in event of alarm These cameras must be in "Event" or "Time and Event" mode within Record |the time slot: Setup menu > Record > Schedule Assign and enable · alarm outputs internal beep by DVR Alarm-Out $\left| \checkmark \right|$ These alarm outputs and the internal beep must be enabled within the time slot: Setup menu > Devices > Alarm-Out > Schedule Assign and enable notifications: Mail Option "Image Attachment" for Camera 1-16 LAN 1 to LAN 5 Notify Alert Window The selected function must be enabled: Setup menu > Network > Notification Setup menu... Event **Object Detection** Actions 2 Г Term Symbol Meaning Number of alarm input No. Select PTZ cameras to record in event of alarm and select the PTZ desired settings -Select spot monitor on which camera image is displayed in event Spot monitor of alarm •

Event – Video Loss

The "Video Loss" menu allows configuration of checking for loss of signal and the responses to events.

Setup menu	Event	└ Video Loss └ C Settings	
Term	Symbol	Symbol Meaning	
No.		Number of camera	
Status View	\checkmark	Activates the status display	
Setup menu	Event	Video Loss	
Term	Symbol	Meaning	
No.		Number of camera	
Record		Assignment of cameras to record in event of alarm These cameras must be in "Event" or "Time and Event" mode within the time slot: Setup menu > Record > Schedule	
Alarm-Out		Assign and enable alarm outputs internal beep by DVR These alarm outputs and the internal beep must be enabled within	
		the time slot: Setup menu > Devices > Alarm-Out > Schedule	
		Assign and enable notifications:	
		Mail Option "Image Attachment" for Camera 1-16	
Notify		LAN 1 to LAN 5	
		Alert Window	
		The selected function must be enabled: Setup menu > Network > Notification	

Setup menu	Event	└〉 Video Loss └〉 └ Actions 2
Term	Symbol	Meaning
No.		Number of camera
PTZ		Select PTZ cameras to record in event of alarm and select the desired settings
Spot monitor		Select spot monitor on which camera image is displayed in event of alarm

Event – Video Blind

The "Video Blind" menu allows configuration of checking for covert cameras and the responses to events.

Setup menu	Event	└〉 Video Blind └〉 └ Settings	
Term	Symbol	Meaning	
No.		Number of covert camera	
		Sensitivity of check as to whether camera is covert	
Sensitivity		1 Not very sensitive	
		100 very sensitive	
		Activation Time of check as to whether camera is covert	
Activation Time	_	Don't Use	
		xx min.	
Status View	\checkmark	Activates the status display	
Use Ignoring Time		Time Setup Definition of the period of time during which there is no reaction to the occurrence of an event	

Setup menu	Event	└〉 Video Blind └〉 □ Actions 1
Term	Symbol	Meaning
No.		Number of covert camera
Record		Assignment of cameras to record in event of alarm These cameras must be in "Event" or "Time and Event" mode within the time slot: Setup menu > Record > Schedule
Alarm-Out		Assign and enable • alarm outputs • internal beep by DVR These alarm outputs and the internal beep must be enabled within the time slot: Setup menu > Devices > Alarm-Out > Schedule
		Assign and enable notifications:
		Mail Option "Image Attachment" for Camera 1-16
Notify		LAN 1 to LAN 5
litetity		Alert Window
		The selected function must be enabled: Setup menu > Network > Notification
Setup menu	Event	L Video Blind L L L Actions 2 L
Term	Symbol	Meaning
No.		Number of covert camera
PTZ		Select PTZ cameras to record in event of alarm and select the desired settings
Spot monitor		Select spot monitor on which camera image is displayed in event of alarm

Event – Text-In

On the "Text-In" menu the text input device is defined and the responses to text input are configured.

Setup menu	Event	└〉 Text-In └〉 □ Settings		
Term	Symbol	Meaning		
No.		Number of text input device		
Setup		Configuration of text input >>		
Title		Name of text input		
Setup				
Term	Symbol	Meaning		
Port	_	Interface		
		Setting as specified by manufacturer of text input device (ATM, cash-till etc.):		
Colum		Baud rate		
Setup		Data		
		Stop Bit		
		Parity		
		Type of text input:		
Text-In Product		Generic Text		
		Epson		
Transaction Start		Character string with which text input must start for the DVR to respond		
Any Character	\checkmark	DVR responds to any character		
Transaction End		Character string with which text input must end for the DVR to respond		
0 more line(s)	_	Enables recording of n more lines		
Line Delimiter		Line delimiter as specified by the text input device manufacturer: ^J for LF or ^M for CR		
Ignore String		Character string in the text input which the DVR is to ignore All transmittable character strings are specified by the text input device manufacturer.		
Case Sensitive	\checkmark	Case sensitivity according to text input device manufacturer's specification		

Setup menu (continued) Text-In Setup menu... Event Term Symbol Meaning No. Number of alarm input Assignment of cameras to record in event of alarm These cameras must be in "Event" or "Time and Event" mode within Record |the time slot: Setup menu > Record > Schedule Assign and enable · alarm outputs internal beep by DVR Alarm-Out $\left| \right\rangle$ These alarm outputs and the internal beep must be enabled within the time slot: Setup menu > Devices > Alarm-Out > Schedule Assign and enable notifications: Mail Option "Image Attachment" for Camera 1-16 LAN 1 to LAN 5 $\langle \checkmark \rangle$ Notify Alert Window The selected function must be enabled: Setup menu > Network > Notification Setup menu... Event Text-In Ц Actions 2 Г Term Symbol Meaning Number of alarm input No. Select PTZ cameras to record in event of alarm and select the PTZ desired settings -Select spot monitor on which camera image is displayed in event Spot monitor of alarm •

Event – System Event

On the "System Event" menu the self-diagnostics and corresponding messages are configured..

Setup menu	Event	System Event
Term	Symbol M	Meaning
System	• 5	System self-diagnostics interval
Check Recording		Setup Configuration of schedule >>
Check Alarm-In		nterval for checking Alarm Inputs
Setup		
Term	Symbol M	Meaning
Schedule On	E E	Enables schedule entries
No.	N	Number of schedule entry
Day		Day of the week
Range	 1	Fime range at 15-minute intervals
Interval		Checking interval
Setup menu	Event 🗅	System Event
Term	Symbol	Meaning
Disk Bad Notify	•	Percentage of bad sectors on hard disk as from which an alarm is triggered
Disk Almost Full Notify	•	Percentage hard disk space available as from which "Disk Almost Full" alarm is triggered
Setup		Configuration of data media S.M.A.R.T. check Opens a window in which the frequency rate and time and a temperature limit (in Celsius or Fahrenheit) for the S.M.A.R.T. check can be specified. If the temperature limit is exceeded an alarm is triggered. For details of your hard disk's temperature limit refer to the manufacturer's manual.

Setup menu (continued)			
Setup menu	∟⇒ Event	⊑⇒ System Ev	vent 🖒 🗋 Actions
Term	Symbol	Meaning	
		Events (based on chec	ks):
		System	System check failed
		Panic Record	Panic recording in progress
		Check Recording	Recording check failed
		Check Alarm-In	Check of alarm inputs failed
Event		Disk Almost Full	Preset limit value for hard disk capacity reached
		Disk Full	Hard disk full
		Disk Bad	Preset limit value for number of bad sectors reached
		Disk Temperature	Preset temperature limit reached
		Disk S.M.A.R.T.	S.M.A.R.T. check failed
Alarm-Out		Assign and enable alarm outputs internal beep by DVI Note: Not possible for a	R system event and panic recording
		Assign and enable noti	fications:
Notify		Mail	Option "Image Attachment" for Camera 1-16
		LAN 1 to LAN 5	(not in case of system event)
· •·· J		Alert Window	(not in case of system event)
		The selected function n Setup menu > Network	

Event – Event Status

The "Event Status" menu indicates the status of all possible events:

- Grey text: Event detection not enabled
- White text: Event detection enabled
- Flashing border: Message acute event for 5 sec
- Yellow field: Pending event

Setup menu	Event Constant Event Status
Term	Event
Alarm-In	At alarm input 1 to 16
Check Alarm-In	Error detected at one of alarm inputs 1 to 16
Motion	Motion detected on camera 1 to 16
Object Detection	Object detected on camera 1 to 16
Video Loss	Loss of signal on camera 1 to 16
Video Blind	Covert camera on camera 1 to 16
Text-In	Text input on text input device 1 to 16
Panic Record	Panic recording
Check Recording	On checking the recording
Disk Almost Full	On checking the data medium (only if DVR is not operating in Overwrite mode)
Disk Full	On checking the data medium (only if DVR is not operating in Overwrite mode)

Setup menu	Event Constant Event Status
Term	Meaning
Туре	Memory type
Disk Bad	Data carrier status
Temperature	Data carrier status
S.M.A.R.T.	Result of S.M.A.R.T. check
Internal 1 to 4	Name of hard disk drives

WebGuard – WebWatch controls

The following diagram and table set out the functions on the Web Watch:



No.	Designation	Function
1		WebGuard Logging out
2	3	Open Search (WebSearch)
3	DVR	Date/TimeIP AddressUser name
4	2	Send Audio data
4		Receive Audio data
5		Image display modes
6	10 to 16	Select cameras
7	Display	Monitoring image
	22	Image optimisation
8		PTZ camera functions
	0	Activate Alarm Outputs
9	Display	Event log

WebGuard – WebSearch controls

The following diagram and table set out the functions on the Web Search:



No.	Designation	Function
1		WebGuard Logging out
2		Open Display (WebWatch)
3	DVR	Date/TimeIP AddressUser name
4	••	Zoom On/OffImage optimisation
5		Playback functions
6		Image display modes
7	Display	Monitoring image
	•	Search for date/time
8	1	Calendar search
	×	Event Search
9	E	Save records
9	4	Print
10	Display	Time bar calendar searchEvent log

Using WebGuard

WebGuard permits the following, using an Internet connection

- View current video images
- · Search and view recorded records

Requirements:

- The Internet connection is set up and the WebGuard service is activated.
- A PC with Internet access to the DVR must be available.
- Internet Explorer must be installed on the PC.

Using WebGuard

Step	Action
1	Ask your System Administrator about the current access data.
2	Start Internet Explorer. Enter the access data in the address line, e.g.: 192.168.1.129:12088
3	Enter your User Name (admin), Password (blank) and if necessary the port addresses.
4	Select Login. Result: WebGuard window is opened.

Specifications DPR-2016

Model	DPR-2016/500D
EDP No.	71955
Video standard	PAL/NTSC (auto detection)
Remark	-
Event logs	Unlimited number of entries for alarm/event/text messages, loss of signal
Security against unauthorised use	Key locking, 64 user groups with programmable access (up to 256 users)
Transmission rate	100 field images per sec (CIF), 50 field images per sec (2CIF), PAL
Alarm triggering	E-Mail, Remote SW (RAS plus)
Alarm activation	Automatic multi-screen display of alarm images programmable
Remote control	Wireless IR remote control (included)
Text display interface	ATM/POS, 10 channels max.
Monitor display	Real-time playback: 25 field images per sec (PAL), 30 field images per sec (NTSC) per camera
Covert camera mode	Programmable
Time synchronisation	Network time log, network time server
System change log	Up to 5000 entries for login/logout, configuration changes, remote access, change of signal connection, disk read/write errors
Zoom function	2x~4x
Playback	Full image, 4-, 3+4-, 9-, 2+8-, 1+12-, 16-channel split, PIP
Post-alarm recording	Up to 15 minutes
VGA	-
Control interface	RS-485 port for PTZ control (verified logs: eneo-Fastrax, Pelco P/D) or keyboard connection for remote control
Activity detection	Programmable 24 x 30 (720) grid, 5 sensitivity settings
Simplex/Duplex/Triplex/Pen- taplex mode	Pentaplex (Live/Recording/Playback/Network/Backup without loss of performance)
Video inputs	16x 1 Vp-p, (F)BAS, 75 Ohm, BNC, loop-through
Monitor outputs	4x Spot-Outputs 1Vss, (F)BAS, 75 Ohm, BNC, 1x VGA
Video output	1x 1 Vp-p, (F)BAS, 75 Ohm, BNC; 1x S-VHS, S= 1 Vp-p, C= 0.3 Vp-p, 75 Ohm
Audio input	16x amplifier input, cinch
Audio output	1x amplifier output, cinch
Resolution	FBAS/PAL: 720 x 576 Pixels VGA: 720 x 576, 800 x 600 Pixels (Display)
Compression method	MPEG-4, higher compression rates with same picture quality enable maxi- mum recording times

Specifications DPR-2016 (continued)

Madal	
Model	DPR-2016/500D
Recording speed	400 field image per sec at CIF/2CIF resolution (352 x 288 / 704 x 288 pixels/PAL), 200 field image per sec at 4CIF resolution (704 x 576 pixels/PAL)
Picture size	Basic: 6.7/8 kB; Standard: 15/18 kB; High: 30/36 kB; Very high: 66.7/80 kB (NTSC/PAL). Modus: "High Resolution/4CIF"
Hard disk capacity	500 GB ATA hard disk, expandable to as many as 4 internal hard disks
Playback speed	100 field image per sec at CIF/2CIF resolution (352 x 288 / 704 x 288 pixels/PAL), 50 field image per sec at 4CIF resolution (704 x 576 pixels/PAL)
Export of picture data	via USB 2.0, SCSI port, CD/DVD writer. Network data export: Clip Player, AVI, JPG, BMP
Alarm inputs	16x TTL, programmable as NC/NO (terminal strip)
Alarm outputs	12x TTL, open collector, 4x relay contacts (125 VAC / 0,6 A, 110 VDC / 0,6 A, 30 VDC / 2 A)
Alarm reset	1 TTL (terminal strip)
Alarm messages	System error, hard disk error
Pre-alarm recording	Up to 30 minutes
Recording medium	SATA hard disks, built-in CD/DVD-RW writer
Archiving	With EIDE, SCSI and USB hard disks. Real-time mirroring
Menu languages	German, English, Italian, French, Spanish
Ethernet port	10Base-T, 100Base-TX, RJ-45
Remote software	For remote administration and image search function (RAS plus included)
Ports	3x USB, 2x RS-485, 2x RS-232 (ATM/POS, telemetry, configuration or modem), 1x SCSI for extending the memory
Power Supply	100 VAC~230 VAC, 50/60 Hz
Power consumption	approx. 240 W
Temperature range	5°C to 40°C
Housing	Metal with plastic front panel
Colour	Pantone 877C
Dimensions (H x W x D)	177 x 430 x 504 mm (4HE 19" rack)
Weight	approx. 16 kg

Accessories

EDP No.	Short description	
71950	Hard disk 250GB for DPR-2016	
71956	Hard disk 500GB for DPR-2016	
71975	CD/DVD Writer DVD+/-RW 48x/18x, CD/DVD	
74088	System keyboard with 3-axis joystick	
74092	System keyboard with joystick, 5" monitor	
71902	USB mouse for DVR series DLR3 and DTR	

Supported PTZ cameras

Manufacturer	Designation
Costar	CDC 2500
Dyna Color	CDC2400
Chilsung	CRD-J6416
Fine	CRR-1660s
Pelco	D-log
Dennard	Dennard2060
Tokina	DMP-1223
Dongyang Unitech	DRX-500
Dongyang	DY-255RXC
Sensormatic	Delta Dome II/Ultra IV
Eneo	Fastrax
Philips	G3 Basic AutoDome
LG Honeywell)	GRU604A
JVC	TK-S576
Sensormatic	Ultra VI
Canon	VC-C4
Canon	VC-C50i
Inter-M	VRX-2201
Vicon	Vicon
Hitron	22x AF Zoom
360Vision	VisionDome
Panasonic	WJ-SX550A
Panasonic	WV-CS850/854
CBC	ZC-SD622J
Samsung	Zoom Camera
Honeywell	HDC-655
LG Honeywell	HSD-25X
Honeywell	HSDN-251
Idis	IRX-100
Ultrak	KD6
Ultrak	KD6 Z-series
Kalatel	KTD-312
LG	LPT-A100L
	Novus-C
Samsung	MRX-1000

Manufacturer	Designation
Ademco Video	Orbiter Microsphere
SysMania	ORX_1000
Linlin	PIH-717
ELMO	PTC-200C/CVAS
ELMO	PTC-250C
Pacom	Pacom 2036
Dongyang	Power Controller
Sungjin	Receiver/MPU
Costar	SIC722V
Samsung Techwin	SPD 1600
Samsung	Samsung Dome
Pelco	Spectra Dome
Samsung Techwin	SRX-100B
Hitron	Speed Dome

DPR-2016/500D

Index

A

Accessories 72 Alarm Configuring inputs 52 Configuring outputs 45 Connecting inputs 8 Connecting outputs 8 Motion Detection 55 Object Detection 57 Resetting 10 Setting schedule for outputs 45 Setting signal duration 45 Video Blind 61 Video Loss 58 Ambient conditions 3.71 Archiving Configuring 51 Memory requirement 25, 51 Setting schedule 51 Assigning cameras Alarm-In 52 Motion Detection 54, 55 Object Detection 56, 57 Text-In 63 Video Blind 60 Video Loss 58 Assigning PTZ cameras Alarm-In 53 Motion Detection 54, 55 Object Detection 57 Text-In 63 Video Blind 61 Video Loss 59, 61

В

Basic functions 7

С

Calendar search 29 Cameo 47 Cleaning 3 Clip-Copy 33 Configuring a pre-event 50 Configuring event responses 52 Configuring Motion Detection 54 Configuring panic recording 48 Configuring PTZ cameras 44 Configuring remote control 47 Configuring text input as event 62

DPR-2016/500D

Configuring the cameras 44 Configuring Video Blind as an event 60 Configuring video loss as event 58 Connecting cameras 8 Control options 7 Control protocols 73 Controls Front panel 10 Remote control 13 WebSearch 68 WebWatch 67 Copying recordings 33 Covert mode 21, 44

D

Date setting 36 Defining bookmarks 28 Defining group access rights 39 Defining motion-sensitive zones 54 Display Configuring 46 Hiding 21, 44 Displaying event status 66 Display menu Access 16 Disposal 78 DVRNS Network configuration 42 Dwell time 45

Ε

F-mail Notification 43 EMC class 3 Enabling notification Alarm-In 52 Motion Detection 55 Object Detection 57 System Event 65 Text-In 63 Video Blind 61 Video Loss 58 Event Configuring a pre-event 50 Configuring Object Detection 56 Configuring responses 52 Defining motion-sensitive zones 54 Displaving status 66 Setting recording time 48

Index (continued)

System events 64 Text input 62 Video Blind 60 Video Loss 58 Event log 30

F

Front panel 10 Controls 10, 12

G

Getting started Video recorder 3, 18

Η

Hard disks changing 22 installing 23 Mirroring 24, 37 Health Check 64

I

IP Address 41, 42

L

LAN Network configuration 41

Μ

Memory requirement Archiving 25, 51 Recording 25 Memory type 37 Menu descriptions Search menu 26 Setup menu 34 Menu structure 14 Mirroring of hard disks 24, 37 Monitor Configuring display 46 Configuring display sequence 47 Connecting 8 Motion search 32

Ν

Network configuration 40 Network settings DVRNS 42 LAN 41

Ρ

Package contents 7 PANIC 10, 48 PTZ-menu Access 16 PTZ cameras Connecting 8 Supported cameras 73

R

Recording Copying 33 delete 20 Memory requirement 25 Search 26 Setting schedule 49 Recreate factory settings 21 Recycling the device 78 Remote control Controls 13 Setting system ID 18, 35 Reset 8, 21

S

Safety instructions 3 Schedule Setting for alarm 45 Setting for archiving 51 Setting for recording 49 Search Bookmark Search 28 Calendar search 29 Event log 30 Motion search 32 Text-In 31 Search-menu Access 17 Setting a password 39 Setting automatic overwrite 48 Setting bookmarks 28 Setting menu language 35 Setting recording guality 48

Index (continued)

Setting system ID for remote control 35 Setting the duration of records in an event occurrence 48 Setting up a concealed camera 21, 44 Setting up Notification 43 Setting up user groups 39 Setting up users 39 Setup menu Access 17 Menu descriptions 34 Shutdown 19 Software updates 21 Software version 35 Specifications 70 Specifying public holidays 36 Spot monitor Assigning a camera 47 Connecting 8 Storage media Displaying status 37 Displaying usage 37 Setting automatic overwrite 48 Switching off 19 Switching on 19 System Export setup 35 Import setup 35 Logging out as USER 40 Shutdown 40 System events Configuring 64 Health Check 64

Т

Text-in search 31 Time Setting 36 Synchronising 36

W

WebGuard Controls 67, 68 Use 69 WebSearch Controls 68 Use 69 WebWatch Controls 67 Use 69

Notes on disposal

Correct disposal of this DVR



WEEE (Waste Electrical & Electronic Equipment)

Applicable in the member states of the European Union and other European countries with a separate collection system

The marking on the DVR and on the documentation stipulates that it must not be thrown away in normal domestic waste at the end of its useful life.

General rules

- Avoid uncontrolled waste disposal: Please dispose of this DVR separately from other waste, so as to avoid posing a hazard to the environment and to human health.
- Recycle the DVR in order to aid the sustainable reuse of material resources.

Private users

Contact the retailer from whom you purchased the DVR or your competent local authority to find out how you can recycle the DVR in an environmentally friendly way.

Commercial users

This DVR must not be thrown away with trade waste. To clarify the conditions of disposal, check your purchase contract or contact your supplier.



eneo® is a registered trademark of Videor Technical E. Hartig GmbH

Exclusive distribution through specialised trade channels only.

VIDEOR TECHNICAL E. Hartig GmbH Carl-Zeiss-Str. 8 · 63322 Rödermark, Germany Tel. +49 (0) 6074 / 888-0 · Fax +49 (0) 6074 / 888-100 www.videortechnical.com

Operating Instructions version 06/2007 (V1.0) Subject to technical change without notice. © Copyright by VIDEOR TECHNICAL 2007