

**SNV022EC.X**  
Combiner Box Card

# User and Installation Manual

---

**SNV Engineering LTD**  
24BPapadiamantopoulouStreet • 1<sup>st</sup> floor  
Ilissia • Athens • Greece • 11528  
Phone +30 2107779260 • Fax +30 2107703223  
Site: [www.snveng.gr](http://www.snveng.gr)

---

## Document Follow-up

Action	Name	Function	Date	Signature
Written by:	TzanetatosDionysis	Engineer	08/10/2012	
Verified by:	Vaidakis Michael	General Director	08/10/2012	
Verified by:				

## Versions

Indices	Date	Modification
V0.1	08/10/2012	Initial Draft Version.
V1.0	15/05/2013	Initial release version.

This document and the information it contains are the sole property of SNV. They shall not be disclosed nor reproduced without the prior written approval of SNV as originator.

# Table of Contents


Document Follow-up.....	ii
Versions.....	ii
Table of Contents .....	i
Description .....	1
Overview .....	1
Features.....	2
Specifications.....	3
Electrical Characteristics .....	3
Physical & Environmental Characteristics.....	3
Measurement Specifications .....	4
Communications and bus Specifications.....	4
Layout.....	5
Ordering Information .....	8
Safety instructions.....	9
Safety Symbols .....	10
Installation.....	11
Overview .....	11
Communication bus and power supply provision.....	12
Inspection and handling .....	12
Preparation.....	12
Card mounting and support.....	12
Housing preparation .....	13
Cables and fuses.....	14
Connectors plug preparation .....	15
Card Installation .....	15
Card replacement.....	18
Dimensions.....	19
Operation .....	20
Fuse replacement.....	20
Communication and Monitoring .....	20
Modbus Memory Map.....	21
MODBUS Functions .....	27
Technical Assistance.....	29
Annex A – Drawings .....	30

Annex B – Recommended board integration..... 36  
Single line diagram .....36  
3D views .....37  
Photos.....38

## Description

### Overview

SNV022EC.A is a “combiner box” card with dc current, voltage measurement and with one digital input. It is designed to be used in photovoltaic parks with central inverters in order to connect in parallel strings and monitor string currents and voltage.




It has on board fuse holder clips for each string for both positive and negative side, avoiding extra cabling and material costs. Current collector bars are premounted and designed to be directly connected to the disconnecter switch for a more clear installation and cost efficient.

Current measurement is performed on the positive side. Low thermal drift, high quality shunt resistors are used. Voltage on them is amplified through precision amplifiers and then sampled and processed by a 32bit CORTEX-M3 microcontroller at 96MHz.

The microcontroller can deliver measurements through an isolated serial RS485 bus transceiver using Modbus protocol. It can also hold values, in order to perform simultaneous measurements through all the cards in a bus and then retrieve all the measurements. The microcontroller is also calculating the average of voltage, currents and current square values, with 667Hz sampling for each channel. The averaging period is indicated-marked by a master controller

broadcast command. Averaged values of different cards are synchronized and then collected. Bandwidth consumption on the bus is limited, giving the ability for a prompt response of the rest requests.

A contact input is also implemented in order to monitor other component like the condition of an SPD. Board temperature is also measured and provided.



## Features

The SNV022EC.A offers the following (see also specification tables):

- 24 channels
- on board fuse holder clips for positive and negative side
- on board current collector bars ready to connect to disconnection switch
- 24 independent dc current measurement at positive side
- 0 - 13.5A current measurement range (other ranges are available on demand)
- 0 – 1000V voltage measurement
- Very Low Sensing resistance on measurement channels: 10mΩ
- system voltage up to 1000Vdc
- 667Hz sampling per channel
- 1 contact input
- Board temperature measurement
- On board long time averaging and integrations
- Communication using MODBUS over RS485
- Board power consumption < 1.5W
- Operating temperatures : -20°C to +60°C
- 32bit ARM CORTEX-M3 microcontroller @ 96MHz
- CE: EMC: EN61326-1 and Safety: EN61010-1

## Specifications

### Electrical Characteristics

	note	min	nom	max	Unit
Power supply	Absolute	18	24	30	V dc
Consumption:					
24V DC – 0A all 24 channels			21	30	mA
24V DC – 13.5A all 24 channels	Note 1, 2		45	54	
18V DC – 0A all 24 channels			29	39	
18V DC – 13.5A all 24 channels			68	79	
18V DC – 16A all 24 channels	Abs. Max			86	
Measurement channel resistance	each			12	mOhm
Channel maximum current		-16		16	A
Channel max working voltage	Note 3			1000	V dc
Current measurement range	Note 4	0.035	-	13.5	A
Voltage measurement range	Note 5	1	-	1000	V

Note 1: The value is for each installed board

Note 2: The maximum number of cards to be installed in series is 127.

Note 3: Equipment pollution degree 2.

Note 4: Current values lower than 35mA are pulled down to zero

Note 5: Voltage values lower than 1V are pulled down to zero

### Physical & Environmental Characteristics

	Details
Operating Temperature	-20 °C to +60 °C
Storage Temperature	-40 °C to +100 °C
Board Dimensions LxWxH	500x230x40 mm See "User and Installation manual" Annex A for detailed drawings
EMC – Emissions	Meets: EN 61326-1, EN 61000-6-3, EN 50081-1, EN 55011(Class A ITE)
EMC – Immunity	Meets: EN 61326-1, EN 50082-1, EN61000-4-3 (Radiated EM fields immunity) EN61000-4-4 (Fast transient burst (EFT)) EN61000-4-5 (Surges) EN61000-4-6 (Conducted EM fields immunity) Also successfully tested (Criterion A) at Conducted immunity at 10Vrms, and Radiated immunity at 10V/m (instead of 3Vrms and 3V/m required from the above standards) see accuracy report for immunity levels.
Safety	Meets EN 61010-1
Measurement Category	RATED CLASS I and RATED TRANSIENT OVERVOLTAGES 1,5KV
Usage	Indoor or outdoor use installed in a metallic and/or plastic box

### Measurement Specifications

	Details
Maximum averaging time	15 days at 667Hz sampling
Current measurement accuracy	0.4% reading + 0.2% range(13.5A)
ADC resolution (12bit)	3.3mA
Thermal Drift on board compensated(Note 6)	0.04‰ / °C
Calibration current	at 5.5 A
Voltage measurement accuracy	1%
Calibration voltage	700 V


Note 6: Compensation, even for averaged values, is performed before value transmission, using actual board temperature, measured by the on board temperature sensor. Long time averaging with large temperature variations could produce thermal drifts on the transmitted values respectively.

### Communications and bus Specifications

Hardware layer	RS485
Communication Protocol	Modbus RTU
Default baud rate	9600 bps
Max number of nodes	128
Max suggested cable length	1200 m
Protected from Overvoltage Line Faults up to	±60V
Clamp diodes (A and B to GND)	±30V
Bus Short-Circuit Protection	Yes

## Layout

The card is separated in two main areas (see figure 3).



The one (bottom side) is dedicated to the measurement of the current passing through the card and the positive and negative collector bars and to accommodation of the fuses for each string. This area is a high voltage area, where voltage is up to 1000Vdc exist.

---

### CAUTION



**To the card will be connected high voltage signals (up to 1000Vdc)**

**The operation and installation of the card is considered to be done from qualified personnel**

---

The high voltage area is marked on PCB with a dash line. All area inside dash line is in high voltage (up to 1000V dc).

The other area (upper right) is the low voltage area. The Modbus interface and card power supply are connected to this area. The low voltage area is protected through a F1, 1A fuse (P/N: SF-1206F100-2)

The low voltage and high voltage areas are separated by an isolation area.




Figure 1: CMC SNV022EC.A Topology Diagram.

The SNV022EC.A uses the connectors CON1/CON2, CON3/CON4 and CON5/CON6 to connect to the bus and power supply (see table 1).

These connectors are equivalent (terminals are common) and can be used as bus/power supply input or output to the next card in the chain or install terminal/bias resistors.

Connector CON7 has two pins to connect a dry contact (switch). The connector CON7 is used to monitor a switch or a sensor acting as a switch (ex. surge protection, door opening, disconnecter trip etc.).



**CAUTION**

**At the connectors CON1/CON2, CON3/CON4, CON5/CON6 and CON7 should be connected only to safety extra low voltage systems.**

The connections for the connectors CON1/CON2, CON3/CON4, CON5/CON6 and CON7 are listed in the table 1.

Connector	Pin Number	Description	Comments
CON7	Pin 1	Pin1	Dry contact input
	Pin 2	Pin2	
CON5/CON6	Pin 4	BUS A	TxD+/RxD+
	Pin 3	BUS B	TxD-/RxD-
	Pin 2	VCC	24Vdc
	Pin 1	GND	Ground
CON3/CON4	Pin 4	BUS A	TxD+/RxD+
	Pin 3	BUS B	TxD-/RxD-
	Pin 2	VCC	24Vdc
	Pin 1	GND	Ground
CON1/CON2	Pin 4	BUS A	TxD+/RxD+
	Pin 3	BUS B	TxD-/RxD-
	Pin 2	VCC	24Vdc
	Pin 1	GND	Ground

Table 1: CMC Connectors Description

The connector plugs used are equivalent to the ones listed in the following table:

Connector Ref	Manufacturer	Manufacturer P/N
For CON1/CON2	FCI	20020006-H041B01LF
For CON3/CON4	FCI	20020006-H041B01LF
For CON5/CON6	FCI	20020006-H041B01LF
For CON7	FCI	20020006-H021B01LF

Table 2: Connectors Description

## Ordering Information

Listed below are part numbers for the Current Measurement Card and available accessories.

Cards are provided with collector bars mounted and mounting bars as a whole. Separate part numbers for collector bars and mounting bars are provided only for replacements.

Item	Part Number
<b>24 channels card</b>	SNV022EC.A
Collector AL bar	SNV022M.005
Collector AL bar, larger terminal opening	SNV022M.013
Mounting bar, terminals side	SNV022M.002
Mounting bar, collector bar side	SNV022M.004
<b>16 channels card</b>	SNV022EC.B
Collector AL bar	SNV022M.017
Mounting bar, terminals side	SNV022M.020
Mounting bar, collector bar side	SNV022M.022
<i>(according to drawings, see ANNEX A)</i>	

Table 3: CMC ordering information

## Safety instructions

The Combiner Box Card, SNV022EC.A is designed and manufactured to be functionally safe for persons who operate or service it. Potential hazards are addressed by a combination of careful system design and appropriate warning labels.

However, during its operation, high voltages apply on the card. As a consequence, the card is capable of causing serious personnel injury and damage to equipment, if installed, operated, or serviced improperly.

---

### CAUTION



**To the card will be connected high voltage signals (up to 1000Vdc)**

**The installation is considered to be done from qualified personnel**

**The card should be installed in such a way that there is no access to it by hand neither from the cables part nor from any other place**

---

### CAUTION



**The card must be installed following the below restrictions:**

**>= 8mm gap from grounded plates**

**>= 15mm gap from non-grounded plates**

**Note: The gap is defined as the distance between relevant plate, or other element and the card routes, or components' pins, or the highest component mounted on the card, including any other conducting element, like bolts, nuts, bar, cables and cable terminals fixed on the card**

---

SNV does not assume liability for the customer's failure to comply with established procedures. Read this chapter before you perform any operations or installation of the card.

If the equipment used in a manner not specified by the instructions of user manual, the protection provided by the card may be impaired.

SNV's equipment is designed to, and reviewed, against to CE Safety and EMC standards. These standards incorporate applicable electrical codes and safety regulations.

This manual contains information and warnings which users must follow for safe operation and to keep the apparatus in safe condition.

Even when the apparatus is not connected to its power supply, terminals can be electrically live, and the opening of covers or removal of parts is likely to expose live parts.

The card must be disconnected from all voltage sources before it is disassembled for any adjustment, replacement, maintenance, or repair.

The following symbols appear in various places on the card to call your attention to hazards or to indicate that you should consult the manuals for further information.

## Safety Symbols



Double insulation or reinforced insulation.



CAUTION RISK OF ELECTRIC SHOCK



CAUTION RISK OF DANGER

**Note** When an equipment is marked with this symbol the documentation must always be consulted, in order to find out the nature of the potential HAZARD and any actions which have to be taken

# Installation

## Overview

The below installation procedure is proposed by SNV Engineering in order to ensure the good and safe operation of the card.

In case that the described procedure is not followed, SNV Engineering is not responsible from any caused damages or injury.

Card has DC current measurement channels with current output terminal common.




---

### CAUTION

**To the card will be connected to high voltage signals (up to 1000Vdc)**

**The installation is considered to be done from qualified personnel**

**The card should be installed in such a way that there is no access to it by hand neither from the cables part nor from any other place**

---




---

### CAUTION

**The card must be installed following the below restrictions:**

**>= 10mm gap from grounded plates**

**>= 20mm gap from non-grounded plates**

**Note: The gap is defined as the distance between relevant plate, or other element and the card routes, or components' pins, or the highest component mounted on the card, including any other conducting element, like bolts, nuts, bar, cables and cable terminals fixed on the card**

---

Connector CON7 is a dry contact input, having two states depending the contact of the connector's two pins or not.




---

### CAUTION

**No voltage should be applied to any of the two pins of CON7**

---

## Communication bus and power supply provision

Card uses RS485 bus for data communication. Cards are connected to the bus in series using twisted pair cable. There are three equivalent connectors (CON1/CON2, CON3/CON4 and CON5/CON6) to facilitate connection of multiple cards in series.

It is suggested to connect all cards in series in a “line”, preferable with the master controller in the middle. If not convenient a star topology, with the master controller in the center, may work depending of the cable length, the number of the lines, and their relative lengths. In any case all the terminal nodes must be terminated with the appropriate resistor. Bias resistors also must be installed.

RS485 transceiver used supports up to 128 nodes; hence up to 127 boards can be connected to the same bus. The total length of the cable used for the boards interconnection is suggested not to exceed 1200m, when bus repeaters are not used.

The same cable can be used for the power supply of the cards, using an extra pair. The power supply source should be 24Vdc and the current capacity should not exceed 5A. The card has power supply inverse polarity protection.

## Inspection and handling

Visually inspect the Card before installing it, for any defect or damage.

Immediately notify the carrier if any damage is apparent.



---

### CAUTION

**Proper ESD handling procedures must always be used when packing, unpacking or installing the card. Failure to do so may cause damage to the unit.**

---

## Preparation

### Card mounting and support


Current measurement channel and common terminals are connected with M5 bolts through  $\varnothing 5.5$  holes on the card. There are also two additional holes at the plug connector side only for mounting.

The card is mounted on “mounting bars” (see ordering information and drawings in ANNEX A).

If other material is applied, than those supplied by SNV, the following specifications should at least comply:

- ensure following gap, defined as the distance between relevant plate, or other element and the card routes, or components' pins, or the highest component mounted on the card, including any other conducting element, like bolts, nuts, bar, cables and cable terminals fixed on the card.
  - >= 10mm gap from grounded plates
  - >= 20mm gap from non-grounded plates
- ensure dielectric strength >3.5kV
- ensure flammability rating better than 94V1.
- ensure operating temperature range and aging strength depending application specifications.

All M5 bolts must be tight with torque 3-4 Nm, to ensure the conductivity. Use plain washer (DIN125) and above lock washer (DIN127) between ring terminal or common bar and bolt head. Do not apply lock washer directly on the card.



### Housing preparation

The box where the card is installed is considered to be a metallic and/or plastic box.

In case of not using self-tapping screws, the plate of the box is suggested to have a drilling pattern like the one shown in figure 4, for the mounting of the card.




Figure 2: Drilling pattern

### Cables and fuses

The cables should be properly selected and sized according to the application specifications. Voltage must not exceed 1000VDC. A **fuse 10x38 gPV type** must be installed on the card fuse clips, with rated current up to 16A, appropriate voltage rating.



### CAUTION

**Voltage must not exceed 1000VDC. A fuse must be installed for each current measurement channel separately, with rated current up to 16A.**

For the preparation of the cables connected to the current channels the IPC-620 have to be followed by the installer.

The cables should be connected to the current channels using ring terminals and lock washers above the ring terminal.

### **Connectors plug preparation**

The connector plugs to be used are those listed in table 2 or equivalent.

For the preparation of the cables connected to the plugs the IPC-620 have to be followed by the installer.

Plugs should be connected with cables while unplugged.

## **Card Installation**

During the installation of the card any power source is prohibited.

The proposed installation steps for the SNV022EC.A are the following and illustrated in the figures 5 to 8:

1. Mount the assembled card to the back plate using four screws (self-taped or normal) in the appropriate position depending to main switch. (figure 5)
2. Connect collector bars to main switch using the appropriate bolts.
3. Fixing the cable terminal rings with bolts M5 on mounting bar with torque of 3-4 Nm (figure 6).
4. Install fuses 10x38 gPV type up to 16A using the appropriate tool. Ensure that the main switch is off. (figure 7).
5. Plug connectors CON1/CON2, CON3/CON4, CON5/CON6 and CON7 on the card as required. (figure 8).




Figure 3: Mount the card




Figure 4: Install cables




Figure 5: Install the fuses




Figure 6: Place the connectors for bus and indicator





Figure 7: Mounting the common current cable on the CMC SNV022EC.A



All screws must have lock washer and simple washer as illustrated in the above picture.

## Card replacement

During the replacement of the card any power source is prohibited.

## Dimensions

The Combiner Box Card SNV022EC.A dimensions are:

LxWxH in mm → 500x230x40 (without collector and mounting bars)  
→ 520x230x40 (with collector and mounting bars)

The Combiner Box Card SNV022EC.B dimensions are:

LxWxH in mm → 348x230x40 (without collector and mounting bars)  
→ 368x250x40 (with collector and mounting bars)


See drawing for more details.

## Operation

### Fuse replacement

The suggesting steps to replace fuse are:

1. See the safety instructions for high voltage areas. Ensure that you have/wear all the appropriate equipment.
2. Switch off the main switch.
3. Use the appropriate tool to remove the fuses. Careful not to connect the conductors that are near.
4. Use the appropriate tool to install the new fuse. Careful not to connect the conductors that are near.
5. Switch on the main switch.



### Communication and Monitoring

For communication, MODBUS protocol over an RS485 serial line is implemented (RTU mode @9600bps). See further “MODBUS Application Protocol Specification v1.1b” and “MODBUS over Serial Line Specification and Implementation Guide v1.02”.

Data can be read through “16bit input registers”. Commands are sending by writing “Holding registers”. Three commands are implemented: “hold”, “mark” and “change address”. Hold command transfer “instant current” values to “current holded values”. Command can be send with a broadcast write, acquiring a snapshot of all the currents from all the cards in the bus.

Mark command initiates averaging and at the same time terminates previous averaging and transfers the result to the relevant registers. It is suggested to broadcast periodically the “mark” command, with the desired period (as for example 10 mins), and during each period read and store the averaged data.

### Modbus Memory Map

The memory map of the card is describing in the following table:

16bit input registers (use Modbus function 4)					
Address		Type	Units	Description	Channel
dec	hex				
0	0x 000	float	Amperes	instant current	1
1	0x 001				
2	0x 002	float	Amperes		2
3	0x 003				
4	0x 004	float	Amperes		3
5	0x 005				
6	0x 006	float	Amperes		4
7	0x 007				
8	0x 008	float	Amperes		5
9	0x 009				
10	0x 00A	float	Amperes		6
11	0x 00B				
12	0x 00C	float	Amperes		7
13	0x 00D				
14	0x 00E	float	Amperes		8
15	0x 00F				
16	0x 010	float	Amperes		9
17	0x 011				
18	0x 012	float	Amperes		10
19	0x 013				
20	0x 014	float	Amperes	11	
21	0x 015				
22	0x 016	float	Amperes	12	
23	0x 017				
24	0x 018	float	Amperes	13	
25	0x 019				
26	0x 01A	float	Amperes	14	
27	0x 01B				
28	0x 01C	float	Amperes	15	
29	0x 01D				
30	0x 01E	float	Amperes	16	
31	0x 01F				
32	0x 020	float	Amperes	17	
33	0x 021				
34	0x 022	float	Amperes	18	
35	0x 023				
36	0x 024	float	Amperes	19	
37	0x 025				
38	0x 026	float	Amperes	20	

16bit input registers (use Modbus function 4)						
Address		Type	Units	Description	Channel	
dec	hex					
39	0x 027					
40	0x 028	float	Amperes	not used – returns zero	21	
41	0x 029					
42	0x 02A					
43	0x 02B	float	Amperes		22	
44	0x 02C	float	Amperes		23	
45	0x 02D					
46	0x 02E	float	Amperes			24
47	0x 02F					
48	0x 030	float				
49	0x 031					
50	0x 032	float				
51	0x 033					
52	0x 034	float				
53	0x 035					
54	0x 036	float				
55	0x 037					
56	0x 038	float				
57	0x 039					
58	0x 03A	float				
59	0x 03B					
60	0x 03C	float				
61	0x 03D					
62	0x 03E	float				
63	0x 03F					
64	0x 040	float	Amperes	current averaged	1	
65	0x 041				2	
66	0x 042	float	Amperes		3	
67	0x 043				4	
68	0x 044	float	Amperes		5	
69	0x 045				6	
70	0x 046	float	Amperes		7	
71	0x 047				8	
72	0x 048	float	Amperes		9	
73	0x 049				10	
74	0x 04A	float	Amperes			
75	0x 04B					
76	0x 04C	float	Amperes			
77	0x 04D					
78	0x 04E	float	Amperes			
79	0x 04F					
80	0x 050	float	Amperes			
81	0x 051					
82	0x 052	float	Amperes			

16bit input registers (use Modbus function 4)					
Address		Type	Units	Description	Channel
dec	hex				
83	0x 053				
84	0x 054	float	Amperes		11
85	0x 055				
86	0x 056	float	Amperes		12
87	0x 057				
88	0x 058	float	Amperes		13
89	0x 059				
90	0x 05A	float	Amperes		14
91	0x 05B				
92	0x 05C	float	Amperes		15
93	0x 05D				
94	0x 05E	float	Amperes		16
95	0x 05F				
96	0x 060	float	Amperes		17
97	0x 061				
98	0x 062	float	Amperes		18
99	0x 063				
100	0x 064	float	Amperes		19
101	0x 065				
102	0x 066	float	Amperes		20
103	0x 067				
104	0x 068	float	Amperes		21
105	0x 069				
106	0x 06A	float	Amperes		22
107	0x 06B				
108	0x 06C	float	Amperes		23
109	0x 06D				
110	0x 06E	float	Amperes		24
111	0x 06F				
112	0x 070	float		not used – returns zero	
113	0x 071				
114	0x 072	float			
115	0x 073				
116	0x 074	float			
117	0x 075				
118	0x 076	float			
119	0x 077				
120	0x 078	float			
121	0x 079				
122	0x 07A	float			
123	0x 07B				
124	0x 07C	float			
125	0x 07D				
126	0x 07E	float			

16bit input registers (use Modbus function 4)					
Address		Type	Units	Description	Channel
dec	hex				
127	0x 07F				
128	0x 080	float	Amperes	current squared averaged	1
129	0x 081				
130	0x 082	float	Amperes		2
131	0x 083				
132	0x 084	float	Amperes		3
133	0x 085				
134	0x 086	float	Amperes		4
135	0x 087				
136	0x 088	float	Amperes		5
137	0x 089				
138	0x 08A	float	Amperes		6
139	0x 08B				
140	0x 08C	float	Amperes		7
141	0x 08D				
142	0x 08E	float	Amperes		8
143	0x 08F				
144	0x 090	float	Amperes		9
145	0x 091				
146	0x 092	float	Amperes		10
147	0x 093				
148	0x 094	float	Amperes		11
149	0x 095				
150	0x 096	float	Amperes	12	
151	0x 097				
152	0x 098	float	Amperes	13	
153	0x 099				
154	0x 09A	float	Amperes	14	
155	0x 09B				
156	0x 09C	float	Amperes	15	
157	0x 09D				
158	0x 09E	float	Amperes	16	
159	0x 09F				
160	0x 0A0	float	Amperes	17	
161	0x 0A1				
162	0x 0A2	float	Amperes	18	
163	0x 0A3				
164	0x 0A4	float	Amperes	19	
165	0x 0A5				
166	0x 0A6	float	Amperes	20	
167	0x 0A7				
168	0x 0A8	float	Amperes	21	
169	0x 0A9				
170	0x 0AA	float	Amperes		22

16bit input registers (use Modbus function 4)					
Address		Type	Units	Description	Channel
dec	hex				
171	0x 0AB				
172	0x 0AC	float	Amperes		23
173	0x 0AD				
174	0x 0AE				
175	0x 0AF	float	Amperes		24
176	0x 0B0	float		not used – returns zero	
177	0x 0B1				
178	0x 0B2	float			
179	0x 0B3				
180	0x 0B4	float			
181	0x 0B5				
182	0x 0B6	float			
183	0x 0B7				
184	0x 0B8	float			
185	0x 0B9				
186	0x 0BA	float			
187	0x 0BB				
188	0x 0BC	float			
189	0x 0BD				
190	0x 0BE	float			
191	0x 0BF				
192	0x 0C0	float	Amperes	current holded values	1
193	0x 0C1				
194	0x 0C2	float	Amperes		
195	0x 0C3				
196	0x 0C4	float	Amperes		
197	0x 0C5				
198	0x 0C6	float	Amperes		
199	0x 0C7				
200	0x 0C8	float	Amperes		
201	0x 0C9				
202	0x 0CA	float	Amperes		
203	0x 0CB				
204	0x 0CC	float	Amperes		
205	0x 0CD				
206	0x 0CE	float	Amperes		
207	0x 0CF				
208	0x 0D0	float	Amperes		
209	0x 0D1				
210	0x 0D2	float	Amperes		
211	0x 0D3				
212	0x 0D4	float	Amperes		
213	0x 0D5				
214	0x 0D6	float	Amperes		

16bit input registers (use Modbus function 4)					
Address		Type	Units	Description	Channel
dec	hex				
215	0x 0D7				
216	0x 0D8	float	Amperes	not used – returns zero	13
217	0x 0D9				
218	0x 0DA	float	Amperes		
219	0x 0DB				
220	0x 0DC	float	Amperes		
221	0x 0DD				
222	0x 0DE	float	Amperes		
223	0x 0DF				
224	0x 0E0	float	Amperes		
225	0x 0E1				
226	0x 0E2	float	Amperes		
227	0x 0E3				
228	0x 0E4	float	Amperes		
229	0x 0E5				
230	0x 0E6	float	Amperes		
231	0x 0E7				
232	0x 0E8	float	Amperes		
233	0x 0E9				
234	0x 0EA	float	Amperes		
235	0x 0EB				
236	0x 0EC	float	Amperes		
237	0x 0ED				
238	0x 0EE	float	Amperes		
239	0x 0EF				
240	0x 0F0	float			
241	0x 0F1				
242	0x 0F2	float			
243	0x 0F3				
244	0x 0F4	float			
245	0x 0F5				
246	0x 0F6	float			
247	0x 0F7				
248	0x 0F8	float			
249	0x 0F9				
250	0x 0FA	float			
251	0x 0FB				
252	0x 0FC	float			
253	0x 0FD				
254	0x 0FE	float			
255	0x 0FF				
256	0x 100	float	Celsius	temperature	
257	0x 101				
258	0x 102	float	Volt	system voltage	


16bit input registers (use Modbus function 4)					
Address		Type	Units	Description	Channel
dec	hex				
259	0x 103				
260	0x 104	float	Volt	system voltage averaged value	
261	0x 105				
262	0x 106	float	Volt	system voltage holded value	
263	0x 107				

coils (use MODBUS function 1)				
Address		Type	Units	Description
dec	hex			
0	0x 00	bit	-	Dry contact input (1-contact / 0-no contact)

holding registers (MODBUS function 16)				
Address		Type	Description	
dec	hex			
0	0x 00	Hi byte	Commands: "hold"(0x01) or "mark"(0x02) or "change address"(0x0A) if command is "change address", then set new target address	
		Lo byte		
1	0x 01	Hi byte	if command is "change address", then set new target address if command is "change address", then set new target address	
		Lo byte		

## MODBUS Functions

Modbus package structure:



For protocol description see “MODBUS APPLICATION PROTOCOL SPECIFICATION v1.1b”. Implemented Modbus functions are as in the following table.

MODBUS FUNCTION	DESCRIPTION
1 (0x01)	Read Coils
4 (0x04)	Read Input Registers
8 (0x08)	Diagnostics
16 (0x10)	Write Multiple Registers
17 (0x11)	Report Slave ID (Serial Line only)
20 (0x14)	Read File Record
21 (0x15)	Write File Record
43 (0x2B) (0x0E)	Read Device Identification



**CAUTION**

**Do not use functions 20 and 21, can cause damage to card.**

Functions 20 and 21 are used for device calibration.

## Technical Assistance



If you need technical assistance or should it be necessary to return your product for repair or calibration use the contact details below:



SNV Engineering Ltd  
Papdiamantopoulou 24B  
11528 Athens, Greece  
web site: [www.snveng.gr](http://www.snveng.gr)  
email: [snv@snveng.gr](mailto:snv@snveng.gr)  
tel: +30 210 7779260  
fax: +30 210 7703223



## Annex A – Drawings



List of drawings:


No	Reference No	Description
1	SNV022M.002	SNV022EC.A Holder Bar 1 Assembly
2	SNV022M.004	SNV022EC.A Holder Bar 2 Assembly
3	SNV022M.005	SNV022EC.A Collector Bar 1
4	SNV022M.006	SNV022EC.A Back Plate holes guide
5	SNV022M.020	SNV022EC.B Holder Bar 1 Assembly
6	SNV022M.022	SNV022EC.B Holder Bar 2 Assembly
7	SNV022M.017	SNV022EC.B Collector Bar 1
8	SNV022M.025	SNV022EC.B Back Plate holes guide
9	SNV022M.026	SNV022EC.B Assembly layout
10		
11		
12		
13		
14		














## Annex B – Recommended board integration

### Single line diagram



### 3D views



**Photos**

