■ Specification

D 540TVL				
1/3"SONY Color CCD 520TVL				
1/3"SONY Color CCD 520TVL				
1/3" SHARP Color CCD 420TVL				
1/4"SHARP Color CCD 420TVL				
PAL:795×596	NTS	C:811×508		
PAL:752×582	NTS	C:768×494		
PAL:500×582	NTS	C:510×492		
PAL:19.3125 / NISC:19.0699				
2:1Deinterlacing				
0.1LUX(Infrared light to open)				
Synchronization				
48 dB				
PAL:1/50-1/100,000sec;NTSC:1/60-1/100,000				
0.45				
1 Vpp,75 Ohms				
Auto				
3.6mm				
23EA				
20 meters				
DC12V , Adapter DC12V 1A				
DC12V 300mA				
53*41*50cm				
94*94*69mm				
	D 520TVL CD 420TVL PAL:795x596 PAL:795x596 PAL:752x582 PAL:500x582 PAL:19.3125 / NI 2:1Deinterlacing 0.1LUX(Infrared I Synchronization 48 dB PAL:1/50-1/100,0 0.45 1 Vpp,75 Ohms Auto 3.6mm 23EA 20 meters DC12V , Adapter DC12V 300mA 53*41*50cm	D 520TVL D 520TVL CD 420TVL CD 420TVL PAL:795x596 NTS PAL:752x582 NTS PAL:19.3125 / NISC:19.0699 2:1Deinterlacing 0.1LUX(Infrared light to open) Synchronization 48 dB PAL:1/50-1/100,000sec;NTSC 0.45 1 Vpp,75 Ohms Auto 3.6mm 23EA 20 meters DC12V , Adapter DC12V 1A DC12V 300mA 53*41*50cm	D 520TVL D 520TVL D 520TVL CD 420TVL CD 420TVL PAL:795x596 NTSC:811x508 PAL:752x582 NTSC:768x494 PAL:500x582 NTSC:510x492 PAL:19.3125 / NISC:19.0699 2:1Deinterlacing 0.1LUX(Infrared light to open) Synchronization 48 dB PAL:1/50-1/100,000sec;NTSC:1/60-1/100 0.45 1 Vpp,75 Ohms Auto 3.6mm 23EA 20 meters DC12V , Adapter DC12V 1A DC12V 300mA 53*41*50cm	

■ Content

Operating Tperature

No	Name	QTY.
1.	Vandalproof IR Dome Camera	1
2.	UserGuide	1

User Manual

Vandalproof IR Dome Camera



Notes: Before providing power for the camera, please read this User Guide in detail!

Do not attempt to disassemble the camera. If the camera can not work, please contact local franchiser or our company.

■ CONNECTING

Monitor Video 12V DC

Link

Video

wire

■ PRODUCT IMAGE



■ TROUBLE AND SOLUTION

1. No Picture after providing power

- May be the power supply voltage abnormity, please check the power supply voltage and pole whether exactitude.
- . Please check all the connecting cable and monitors whether be connected correctly or not.

2. The picture level direction have flowing interference ripples

- . May be caused by the power supply AC ripples, it need filter the wave of the power supply.
- . Check the monitor and peripheral equipments used.

3. The picture background color changes continuously

- . The fluorescent lamp's electromagnetic field cause color roll. This is proper phenomenon of the cameras.
- . Reduce the fluorescent lamp numbers or increase the distance between the camera and the fluorescent lamps can improve it.
- . Use power supply external sync. camera can solve it.

4. The picture smear too mass

- . The power supply's voltage unstable.
- . Connecting cables not connect correctly or have high impedance.

■ INTRODUCTION

Congratulations on your purchase of this product. We adopt the latest SONY technical of sensor and driver. The most attractive characteristics are water-resistant, and widely applicable to day & night, indoor & outdoor. In addition, it owns the characters of high definition and stability, strong anti-jamming, rich and real color. Fixing and using this model are convenient too. It is very good for you to apply to yours CCTV system.

Please read this instruction manual carefully to ensure proper use of the product.



To prevent fire or shock hazarded. Do not expose the unit into water too long time directly.



The symbol is intended to alert the user to the presence of important operating and maintenance (servicing)
Instructions in the literature accompanying the appliance.



The symbol is intended to alert the user to the presence of uninsulated 'dangerous voltage' within the product's enclosure that may be of sufficient Magnitude to constitute a risk of electric shock to persons.



CAUTION: RISK OF ELECTRIC. DO NOT OPEN



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER OR BANCK NO USER

SERVICEABLE PARTS INSIDE. REFER SERVICING
TO OUALIFIED SERVICE PERSONNEL.

CAUTION:

To prevent electric shocks and risk of fire hazards, do NOT use other than specified power source.



Note:

- Please note the camera's operating temperature and its using environment requirement. Avoid using the camera at too high or too low temperatures. The operating temperature is -10℃-50℃. (Recommendatory operating temperature is -5℃--40℃.)
- Never make the camera face the sun or bright object. Otherwise, it will damage the CCD.
- Do not mount the camera near by the radiator or heater.



Notes:

- The power supply must through safe attestation. Its output voltage current, voltage polarity and operating temperature must match the camera's requirement.
- When using the camera in the thunderbolt condition, please note to mount Anti-thunder device or put off the power supply plug and cable.
- In order to capture high quality pictures, the power supply's cable and video output cable should not be too long.