
IP PBX

PX0050

User Manual

Revision History

Revision	Release Date	Summary
1.0	2005/12/15	First Release
1.1	2006/02/22	First Revision
1.2	2006/03/10	<ol style="list-style-type: none"> 1. Modify Virtual Server Section 2. Modify Call Route Section 3. Add Appendix V
1.3	2006/05/02	<ol style="list-style-type: none"> 1. Modify 1.2 Key Features 2. Modify 1.3 Hardware Specification 3. 2. User Management: Reg → Call Status 4. 4.1.1 Remote Codec → Remote/PBX Codec 5. 4.1.2 Add Goto Voicemail after Ringing 6. Modify 4.2 Proxy Server 7. Modify 4.3 Call Route 8. Add 4.4 Call Status 9. Modify Appendix III Graphics 10. Modify Appendix V Graphics
1.4	2006/06/22	<ol style="list-style-type: none"> 1. This revision is based on firmware version v1.00.08 2. Support Music On Hold and Music On Transfer 3. 4.1.1 General : Add RTP Port Range 4. 4.1.5 Call Park: The default value of Call Park has changed from #9 to 9. 5. Add Appendix VI to describe the Call Park procedures
1.5	2006/08/28	<ol style="list-style-type: none"> 1. This revision is based on firmware version v1.01.00 2. 1.2 Key Features : Modify Contents 3. 2.1 Network Setup : Modify the Contents and Graphics 4. 2.2 User Management : Modify the Contents and Graphics 5. 2.2.4 Two Level Management : Add this new section 6. 4.1.4 Call Forward : Modify Contents and add call forward on no answer enable/disable options 7. 4.1.5 Call Park : Remove Transfer Digit Timeout Contents 8. 4.3 Call Route : Modify Contents and the Graphics 9. 4.5 Block List : Modify the Graphics 10. 4.7 Service Time and Service Digit List : Modify Contents and the Graphics 11. 4.8 Upload Voice File : Add this new page 12. Appendix VII Upload Voice File Procedures : Add this new appendix

1.6	2006/11/07	<ol style="list-style-type: none">1. This revision is based on firmware version v1.01.052. 1.2 Key Features : Modify Contents3. 2.2 User Management : Modify the Contents and Graphics4. 4 IP-PBX : Modify the Contents and Graphics 45. Change Appendix V Content from Master Proxy Server to Make a Call via HTTP CGI6. Add Appendix VIII How to Setup a FXO Gateway
-----	------------	--

Table of Contents

1. OVERVIEW	6
1.1 INTRODUCTION	6
1.2 KEY FEATURES	7
1.3 HARDWARE SPECIFICATION	10
2. BASIC INSTALLATION	11
2.1 NETWORK SETUP	13
2.2 USER MANAGEMENT	15
2.2.1 <i>Install IP-Phone Automatically</i>	18
2.2.2 <i>Install IP-Phone Manually</i>	20
2.2.3 <i>IP Phone Registration and Call Status</i>	21
2.2.4 <i>Two-Level Management</i>	22
3. DHCP SERVER CONFIGURATION	23
4. IP-PBX SETTINGS	24
4.1 SYSTEM	24
4.1.1 <i>General</i>	25
4.1.2 <i>Voice Mail</i>	26
4.1.3 <i>Call Forward</i>	27
4.1.4 <i>Call Park</i>	29
4.2 PROXY SERVER	30
4.2.1 <i>IP-PBX behind NAT</i>	31
4.2.2 <i>Register Expire</i>	31
4.2.3 <i>Proxy Server</i>	32
4.3 GATEWAY.....	33
4.4 CALL ROUTE.....	35
4.5 BLOCK LIST	37
4.6 CALL STATUS	38
4.7 HUNT GROUP.....	39
4.8 CDR	41
4.9 AUTO ATTENDANT	42
4.9.1 <i>Auto Attendant Recording</i>	43
4.9.2 <i>Auto Attendant Message List</i>	44
4.9.3 <i>Auto Attendant Service Time List</i>	45
4.10 UPLOAD VOICE FILE	47
5. NAT ADVANCED CONFIGURATION	48
5.1 ACCESS CONTROL LIST.....	49
5.2 VIRTUAL SERVER	50
5.3 URL FILTER.....	51
5.4 STATIC ROUTE.....	52
5.5 SPECIAL APPLICATION.....	53
5.6 DMZ HOST	54
5.7 DOS	55
5.8 DYNAMIC DNS	56
5.9 PASSTHROUGH	57

5.10 UPnP.....	58
5.11 PING TOOLKIT.....	59
6. LOG	60
7. MANAGEMENT	61
7.1 REMOTE MANAGEMENT	61
7.2 PASSWORD	62
7.3 UPGRADE.....	63
APPENDIX I - DHCP SERVER FUNCTION NOTICE	65
APPENDIX II – USB DISK USAGE NOTICE	66
APPENDIX III – HOW TO MAKE OFF-NET CALLS (PSTN CALLS).....	67
APPENDIX IV –AUTO ATTENDANT ANNOUNCEMENT	70
APPENDIX V – MAKE A CALL VIA HTTP CGI.....	71
APPENDIX VI – CALL PARK PROCEDURES.....	72
APPENDIX VII – UPLOAD VOICE FILE PROCEDURES.....	77
APPENDIX VIII – HOW TO SETUP A FXO GATEWAY.....	84

1. Overview

1.1 Introduction

We believe that the next generation networks based on VoIP technologies will change the way people communicate with each other and people will benefit a lot from the technologies. The usage of the technologies should be simple to most users; the users should only find the benefits without facing the technology barriers. So, our mission is to make the usage of VoIP technologies just as simple as the usage of normal telephone set. "Simple is the best" is our goal in developing the VoIP products.

The Future IP PBX system PX0050 is a next generation IP PBX that provides a cost-saving solution for small business/enterprise users on their telecommunication/data needs. The PX0050 is an embedded system with built-in SIP proxy server and NAT functions that makes it perfect for enterprise usage. The enterprise can combine both data and PBX and VoIP functions together with this single box to treat it as a Communication Center.

The PX0050 provides not only basic call functions on traditional PBX system but also many advanced functions including voice mail to email, web management, roaming etc that's not possible on traditional PBX.

With PX0050, company with branch offices in different countries can be easily combined together to work like a virtual single office through internet. PX0050 can also register to an ITSP vendor to let all offices share the benefits of the services from ITSP.

The two most important considerations of designing PX0050 are easy installation and system stability. The easy installation is provided through some auto-provisioning procedures and is detailed in section 2. The system stability is established by a very stable embedded system platform and the USB disk storage. Since all the system configurations (including voice mail) are stored in the USB storage, if in any chance that the system damaged, you could restore the whole system by just putting the USB disk to a new PX0050, no re-configuration is needed. In this way, the maintenance effort is minimized.

1.2 Key Features

- **Built-in SIP Proxy Server**
 - RFC3261 Session Initialization Protocol
 - DTMF Relay: Inband/Info/RFC-2833
 - Proxy Routed Mode and Direct Mode
 - 200 User Registrations
 - 60 Concurrent Calls (up to 30 Concurrent Remote Calls)
- **Built-in NAT(Router) and Firewall Functions**
 - DHCP Server for LAN Users
 - Access Control / URL Filter
 - Virtual Server / DMZ / Special Application
 - Static Route
 - Passthrough
 - UPnP
 - DoS
- **Management**
 - 2 Level Management – Administrator / Registered User
 - HTTP Web Browser Management
 - Remote HTTP Management
 - Password Authentication using MD5 digest
 - Software Upgrade via the Web Browser (HTTP-POST)
 - Configuration Backup/Restore via Web Browser or USB Disk
- **PBX Features**
 - Automated Attendant (AA)
 - Interactive Voice Response (IVR)
 - ✓ Record IVR via Phone
 - ✓ Upload IVR via Web Browser
 - Voicemail (VM)
 - ✓ Embedded SMTP Server that Can Send VM notification or VM Attachment via Email
 - ✓ Visual Indicator for Message Waiting (VMWT)
 - ✓ VM Notification via SUBSCRIBE/NOTIFY
 - ✓ Personal VM Greeting
 - FXO Gateway (16)
 - Register to Different ITSP SIP Account (16)
 - ✓ DID to User
 - ✓ DID to Hunting Group – Round Robin, Parallel, Random

-
-
- Least Cost Call Routing (20)
 - Call Detailed Record (CDR)
 - User Management via Web Browser
 - Call/Pickup Group
 - Codec: G.723.1(6.3k/5.3k)*, G.729A/B, G.711(A-law/U-law)
 - Display 200 Registered User's Status: Unregistered / Registered / On-Call
 - Outgoing Call Block List (10)
 - Register to Other PX0050
 - Remote Office Support
 - Interoperable with Other SIP Devices

Call Features

- Call Forward Immediate
- Call Forward on Busy
- Call Forward on No Answer
- Do Not Disturb (Forward to VM)
- Direct Inward Dialing (DID)
- Call Pickup
- Call Park
- Call Retrieval
- Caller ID
- Roaming Extensions
- Music on Hold / Music on Transfer
- Call Queuing
- Call Recording*
- SMS Messaging*

Additional Features when used with VanAccess IP-Phones

- Call Transfer (Attended and Blind)
- Call Hold
- Call Waiting
- Dial By Name
- Three-way Calling
- Intercom*
- Paging*
- Distinctive Ring*
- IP-Phone Downloading the Configuration Automatically (TFTP)
- IP-Phone Downloading the Company Phone Book Automatically

(Notice: the items with '*' is available for future release)

1.3 Hardware Specification

WAN Port	1xRJ45 10/100 Base-T Ethernet, line auto-sensing/switching.
LAN Port	4xRJ45 10/100 Base-T Ethernet, line auto-sensing/switching.
USB Port	USB host interface compliant with OHCI 1.1
Reset Button	1 reset button to restart the system
LED Light	1 LED for power status 5 LEDs for the indication of LAN/WAN link status 1 LED for USB
Universal Switching Power Adaptor	Input: 100-240V AC Output: +12V DC, 1 A
Dimension	15cm(W)x12cm(D)x3cm(H)
Weight	500 g
Operating Temperature	32 - 104 °F (0 – 40 °C)
Humidity	10%-95% (non-condensing)
EMI Compliance	CE / FCC

Table 1. Hardware Specification of PX0050

2. Basic Installation

PX0050 is designed to be installed easily. Before installation, connecting a computer or a Notebook PC to the LAN port of PX0050, setting the network environment of the computer to be static IP with IP address 192.168.1.xxx (could be for example 192.168.1.100). Then log into PX0050 with the web browser on the connected Notebook/PC. The default value of the LAN IP of PX0050 is 192.168.1.1.

There are only three things that must be followed to let the PX0050 work:

1. Configure the LAN IP of PX0050 – if there is already another DHCP server (another NAT/Router device) existed in the LAN network, you must make sure that they are not using the same sub networks; otherwise you need to change the LAN IP of PX0050 to a different sub network.
2. Configure the WAN IP of PX0050 – depends on the internet connection of the office, you can configure the WAN IP as PPPoE, DHCP or static IP.
3. Configure the users of the PX0050 – the user management page of the configuration will allow you to determine the number/password and other things that you needed to let the IP Phone register to this PX0050. For more detailed configurations, please go to section 2.2.

After the three basic configurations, you can install the IP Phone on the LAN network, the IP Phone will automatically find this PX0050 and get its user configuration and function immediately. Of course, there are something needed to be noticed to let this auto-installation work correctly, please go to section 2.2 for detailed description.




Figure 1 The installation environment of PX0050 (PX0050 used as a IP PBX only)


As shown in Figure 1, it's very possible that the office already has a NAT/Router for internet connection, so we had better to have another internet connection for PX0050. In this way, the data traffics from PC are handled by the NAT/Router and voice packet traffics from IP Phones are handled by PX0050, and these two kinds of packets will not interfere with each other, the voice quality will be guaranteed.

(Please notice that the PX0050 not only has the IP PBX and SIP Proxy server functions, it also has the NAT/Router function inside. You can let PX0050 to work as a NAT/Router for the computers on your office, or you can just let PX0050 work as a pure IP PBX and let other NAT/Router device to do the NAT function for the computers on the office. Our recommendation is to just let PX0050 work as a pure IP PBX to guarantee the voice quality.)

The basic installation steps could be more detailed in the following two sections 2.1 and 2.2:

2.1 Network Setup

Once your PC has configured a static IP address 192.168.1.xxx (for example 192.168.1.7), you can log into the PX0050 (default IP address 192.168.1.1) web server with the username **root** and password **1234**. (Please **notice** that the default mode of PX0050 can only provide DHCP service to IP Phones, not to Notebook/PC. Notebook/PC can not get IP address from PX0050 by DHCP). The **Status** page will be displayed.



System	
Product Model	IP-PBX
Firmware Version	v1.01.00
Firmware Date	2006/08/11 15:01:30
NAT	Enable
USB	Mounted (Total:973 MB, Used:291 MB, Available:682 MB)
Time	Fri Aug 11 15:25:49 2006 (GMT +08:00)

LAN	
IP Address	192.168.1.1
Subnet Mask	255.255.255.0
MAC Address	00:13:48:6D:F6:0C
DHCP Server	Enable
Received	0 packets, 0 bytes
Transmitted	0 packets, 0 bytes
Dropped	83 packets

WAN	
Connection Type	Static
IP Address	192.168.0.157
Subnet Mask	255.255.255.0
Default Gateway	192.168.0.254
DNS 1 IP Address	168.95.1.1
DNS 2 IP Address	168.95.192.1
MAC Address	00:13:48:6D:F6:0B
Received	691 packets, 71701 bytes
Transmitted	302 packets, 56614 bytes
Dropped	83 packets

Click the **Network Setup** item on the main menu; you will see the following web page.

1. **LAN:** You can change the LAN IP Address and Subnet Mask of the PX0050 here. If there is already another DHCP server or another NAT/Router device existed in the LAN network, you must make sure that they are not using the same sub network.
2. **WAN:** You can configure the WAN IP as PPPoE, DHCP or static IP depending on the internet connection method provided for the PX0050 in the office.
3. **NTP:** To get the real time from internet, you need to choose the correct Time Zone of your area. If the default NTP servers cannot work in your area, you have to find the workable NTP servers and set the values in these fields. (In almost all cases, just use the default NTP server and everything should be fine).

The image shows a router configuration interface with a sidebar on the left and a main configuration area on the right. The sidebar contains a navigation menu with the following items: Status, Network Setup, DHCP Server, IP PBX (highlighted in red), NAT Advanced, Log, and Management. The main configuration area is divided into three sections: LAN, WAN, and NTP, each with a red header bar. The LAN section includes fields for Domain, IP Address (192.168.1.1), and Subnet Mask (255.255.255.0). The WAN section includes fields for WAN Connection Type (Static IP), IP Address (192.168.0.157), Subnet Mask (255.255.255.0), Default Gateway (192.168.0.1), DNS 1 (168.95.1.1), and DNS 2 (168.95.192.1). The NTP section includes fields for Time Zone (Asia/Taipei), NTP Server 1 (time.windows.com), and NTP Server 2 (time-b.nist.gov). At the bottom of the configuration area are buttons for Apply and Cancel.

LAN

Domain:

IP Address: 192 . 168 . 1 . 1

Subnet Mask: 255 . 255 . 255 . 0

WAN

WAN Connection Type: Static IP

IP Address: 192 . 168 . 0 . 157

Subnet Mask: 255 . 255 . 255 . 0

Default Gateway: 192 . 168 . 0 . 1

DNS 1: 168 . 95 . 1 . 1

DNS 2: 168 . 95 . 192 . 1

NTP

Time Zone: Asia/Taipei

NTP Server 1: time.windows.com

NTP Server 2: time-b.nist.gov

2.2 User Management

To let the IP-Phone register to PX0050, you need to set the user accounts of all the IP Phones to be installed in the **User Mgmt.** page.

By clicking the **IP PBX** link, the submenu will expand. Then click **User Mgmt.**, you can see four default users shown in the web page.



The screenshot displays the 'User Management' web interface. On the left is a navigation menu with categories like 'Status', 'Network Setup', 'DHCP Server', 'IP PBX', 'NAT Advanced', 'Log', and 'Management'. The 'IP PBX' section is expanded, showing options like 'System', 'Proxy Server', 'Gateway', 'Call Route', 'Block List', 'Users Mgmt.', 'Call Status', ' Hunt Group', 'CDR', 'Auto Attendant', and 'Upload Voice File'. The main content area has a red header 'User Management' and a checkbox 'DHCP Only for IP Phones: Total: 4 Users, Registered: 1 Users.' which is checked. Below this is a table with columns: Index, Call Status, Disp. Name, Number, Passwd, Call Group, Pickup Group, Hunt Group, Call Type, IP:Port, A P S, VMWI (new/old), and Action. The table contains four rows of user data. Below the table are buttons for 'Delete', 'Apply', 'Add User', and 'Batch Add'. A red number '1' is positioned below the 'Add User' button.

Index	Call Status	Disp. Name	Number	Passwd	Call Group	Pickup Group	Hunt Group	Call Type	IP:Port	A P S	VMWI (new/old)	Action
001	<input type="checkbox"/>	100	100	100	1	1	-	-	-	N	0/0	Edit
002	<input type="checkbox"/>	101	101	101	1	1	-	-	-	N	0/0	Edit
003	<input type="checkbox"/>	102	102	102	1	1	-	Remote	192.168.0.110:5060	N	5/0	Edit
004	<input type="checkbox"/>	103	103	103	1	1	-	-	-	N	3/0	Edit

Some items/checks must be explained below:

1. DHCP Only for IP Phones

If this check box is checked, the DHCP server in this PX0050 will only provide IP address to IP Phones in this user management page, the PC in the same network will not be able to get any IP address from PX0050. In this way, as depicted in **Figure 1**, the voice packets from IP Phones will go through PX0050 and data packets from Notebook/PC will go through other NAT/Router. The default value for this field is **checked**.

If you want to use the PX0050 as both IP PBX and NAT/Router for the office, you need to uncheck **DHCP Only for IP Phones** checkbox. The PX0050 will assign IP address to IP Phones and Notebook/PC in the office network. Fig 2 depicts this usage. But this kind of usage is not recommended.




Figure 2 PX0050 used as both IP PBX and NAT/Router

2. **Index:** the sequence number in this list of the users (IP Phones) accounts.
3. : check this box for the items that wanted to be deleted together.
4. **Call Status:** this field displays the call status of the IP Phone, red light means unregistered, green light means registered successfully, and yellow light means registered and on-call.
5. **Disp. Name:** the display name of the IP Phone account. Max allowed length is 32.
6. **Number:** the user number of the IP Phone account. Max allowed length is 64.
7. **Password:** the password of the IP Phone account. The allowed characters for the password are all digits. Max allowed length is 64. This is also the password for accessing the voicemail records for this account.
8. **Call Group:** the call groups this IP Phone belongs to. An IP Phone can belong to multiple call groups. The purpose of assigning IP Phones to some call groups is for the pickup usage as explained in the next item below.
9. **Pickup Group:** an IP Phone can have multiple pickup groups. Any extension IP Phone can only pickup the call of another ringing extension when the ringing extension is in one of the pickup groups of this IP Phone.
10. **Hunt Group:** an IP Phone can belong to a maximum of 5 hunt groups. This feature allows multiple users to be contacted by dialing into one configured hunt group number.



Figure 3 the relationship of call group and pickup group

As shown in Figure3, IP Phone #103 belongs to call group #1 and #2, suppose that its pickup group is #1, and then it can only pickup the calls of #101, #102 and #104. And suppose that IP Phone #101 has pickup groups #1 and #2, and then it can pickup calls of every IP Phones in this figure.

11. **Call Type:** PX0050 will automatically detect whether the IP Phone is registered from this office (displayed “local”) or from another office (displayed “remote”).
12. **IP Port:** this field will show the IP address and port number of the registered IP Phone.
13. **APS:** the field when set to “YES” will enable the auto-provisioning (auto-installation) of this specific IP Phone, the PX0050 will give the user accounts to the specific IP Phone (identified by the MAC address), and thus the IP Phones could be installed without any configuration.
14. **VMWI (new/old):** the number of new and old voice mails of this extension IP Phone.

The following sections will detail the possible installation methods (manually or automatically) of PX0050 and IP Phones step by step:

2.2.1 Install IP-Phone Automatically

If you purchased a batch of IP-Phones with the PX0050 at the same time, you can install all these IP Phones automatically without doing any configuration on each IP Phone, you just need to do some configurations on PX0050 only.

The following steps will lead you to do this automatic installation step by step:

1. Click on **Batch Add** button, and the following page will appear.

User Attributes	Values
First Number	104
Number of Users	6 users
Password	104 <input type="checkbox"/> Auto-increase
Call Group	<input checked="" type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/> 5 <input type="checkbox"/> 6 <input type="checkbox"/> 7 <input type="checkbox"/> 8 <input type="checkbox"/> 9 <input type="checkbox"/> 10 <input type="checkbox"/> 11 <input type="checkbox"/> 12 <input type="checkbox"/> 13 <input type="checkbox"/> 14 <input type="checkbox"/> 15 <input type="checkbox"/> 16 <input type="checkbox"/> 17 <input type="checkbox"/> 18 <input type="checkbox"/> 19 <input type="checkbox"/> 20
Pickup Group	<input checked="" type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/> 5 <input type="checkbox"/> 6 <input type="checkbox"/> 7 <input type="checkbox"/> 8 <input type="checkbox"/> 9 <input type="checkbox"/> 10 <input type="checkbox"/> 11 <input type="checkbox"/> 12 <input type="checkbox"/> 13 <input type="checkbox"/> 14 <input type="checkbox"/> 15 <input type="checkbox"/> 16 <input type="checkbox"/> 17 <input type="checkbox"/> 18 <input type="checkbox"/> 19 <input type="checkbox"/> 20
Do Not Disturb	<input checked="" type="checkbox"/> Forward to Voicemail
Call Forward Immediate	Disable
Call Forward on Busy	Disable
Call Forward on No Answer	Disable
MAC Address	00 : 13 : 4b : 01 : 01 : 04
APS	YES
e-mail	pbx.com.tw

2. Fill in the **First Number**, **Number of Users** and **Password** fields. The system will automatically generate some user accounts with alphabetically increased user name and same password. If you want all the IP-Phones to have different password, just check the **Auto-increase** check box.
3. The **Call Group** and **Pickup Group** check boxes could be multiply selected. You can set the IP Phones to belong to some **Call Groups**, and let the IP Phones to pick up the call of some **Pickup Groups**. These two settings are independent. Please refer to Figure3 for more detailed illustration.
4. **Do Not Disturb**: When the PX0050 receives SIP response 486 from the IP Phone, it can forward the call to the voicemail or will reply the 486 to the user that will cause the IP-Phone busy.
5. Enable/Disable the **Call Forward Immediate/Call Forward on Busy/Call Forward on No Answer** settings.
6. Fill in the start MAC address of all the IP Phones in the **MAC Address** field. This field will only be used when the **DHCP Only for IP Phones** is enabled or **APS** field is enabled.

When **DHCP Only for IP Phones** is enabled, the DHCP service of PX0050 will only give DHCP address to the device with this MAC address.

When **APS** field is enabled, PX0050 will generate the auto configuration file to the IP Phone with this MAC address.

7. Choose the **APS to Yes**; the IP-Phone will then be able to get the individual configuration from the PX0050 and work automatically. If the user is the local user, it will get the TFTP server IP address and auto configuration file via DHCP header. If the user is the remote user, you have to enter the WAN IP address of PX0050 to the IP phone web page manually.
8. Fill in the e-mail server of the office; this is for voice mail to email service usage.
9. Click **Apply** to generate all the user accounts of all the IP Phones back to the main menu.
10. Make sure that **DHCP Only for IP Phones** is checked. This will ensure the PX0050 only offer the IP address to the following users. This is the recommended setting when there is another DHCP server existed in the same network.
11. Click **Apply** to save the settings.
12. You can now install all the IP Phones in the network of the office, and the IP Phones will automatically find out the PX0050 and be ready for call.

The screenshot shows a web interface for 'User Management' with a sidebar on the left containing navigation options like 'Status', 'Network Setup', 'DHCP Server', 'IP PBX', 'System', 'Proxy Server', 'Gateway', 'Call Route', 'Block List', 'Users Mgmt', 'Call Status', ' Hunt Group', 'CDR', 'Auto Attendant', 'Upload Voice File', 'NAT Advanced', 'Log', and 'Management'. The main content area has a red header 'User Management' and a status bar indicating 'DHCP Only for IP Phones: Total: 10 Users, Registered: 1 Users.' Below this is a table with columns: Index, Call Status, Disp. Name, Number, Passwd, Call Group, Pickup Group, Hunt Group, Call Type, IP:Port, APS (new/old), VMWI (new/old), and Action. The table lists 10 users (Index 001-010) with various settings. At the bottom of the table area are buttons for 'Delete', 'Apply', 'Add User', and 'Batch Add'. A small red '1' is visible below the table.

Index	Call Status	Disp. Name	Number	Passwd	Call Group	Pickup Group	Hunt Group	Call Type	IP:Port	APS (new/old)	VMWI (new/old)	Action
001	<input type="checkbox"/>	100	100	100	1	1	-	-	-	N	0/0	Edit
002	<input type="checkbox"/>	101	101	101	1	1	-	-	-	N	0/0	Edit
003	<input type="checkbox"/>	102	102	102	1	1	-	Remote	192.168.0.110:5060	N	5/0	Edit
004	<input type="checkbox"/>	103	103	103	1	1	-	-	-	N	3/0	Edit
005	<input type="checkbox"/>	104	104	104	1	1	-	-	-	Y	0/0	Edit
006	<input type="checkbox"/>	105	105	105	1	1	-	-	-	Y	0/0	Edit
007	<input type="checkbox"/>	106	106	106	1	1	-	-	-	Y	0/0	Edit
008	<input type="checkbox"/>	107	107	107	1	1	-	-	-	Y	0/0	Edit
009	<input type="checkbox"/>	108	108	108	1	1	-	-	-	Y	0/0	Edit
010	<input type="checkbox"/>	109	109	109	1	1	-	-	-	Y	0/0	Edit

2.2.2 Install IP-Phone Manually

Other than the automatic installation of IP Phones, you could also install IP Phone manually. The manual installation steps for IP Phone and PX0050 are detailed in the followings:

IP-Phone settings:

On the IP Phone, you need to at least set the user account and proxy server address to let the IP Phone register to the PX0050 manually. Suppose that your IP-Phone is with number/password as 101/101, and then just fill in this account into the IP Phone. The default IP address of PX0050 is 192.168.1.1, so, just key in this IP address as the proxy server address field in the IP Phone. The IP-Phone network type is better set to be DHCP type.

PX0050 settings:

On the PX0050, you need to add this user account to allow the IP Phone to register into it. By clicking the **Edit** button on the 001 row, the following page will pop-up. The MAC address field is needed if the IP Phone wants to get IP address from PX0050 by DHCP.

2.2.3 IP Phone Registration and Call Status


After some IP Phones installed, whether automatically or manually, the registration status of all the IP Phones are displayed in the **User Mgmt.** page as shown in the figure below. If the IP Phone is registered to the PX0050 successfully, the **Call Status** field of that IP Phone will be green light. Red light means unregistered and yellow light means registered on on-call.

The screenshot shows the 'User Management' page in a web interface. On the left is a navigation menu with categories like Status, Network Setup, DHCP Server, IP PBX, NAT Advanced, Log, and Management. The main content area has a red header 'User Management' and a sub-header 'DHCP Only for IP Phones: Total: 10 Users, Registered: 1 Users.' Below this is a table with columns: Index, Call Status, Disp. Name, Number, Passwd, Call Group, Pickup Group, Hunt Group, Call Type, IP:Port, A P S, VMWI (new/old), and Action. The table lists 10 users (Index 001-010). User 003 is the only one with a green call status icon and a populated IP:Port field (192.168.0.110:5060). All other users have red call status icons. Below the table are buttons for 'Delete', 'Apply', 'Add User', and 'Batch Add'. A small red '1' is positioned below the table.


Index	Call Status	Disp. Name	Number	Passwd	Call Group	Pickup Group	Hunt Group	Call Type	IP:Port	A P S	VMWI (new/old)	Action
001	Red	100	100	100	1	1	-	-	-	N	0/0	Edit
002	Red	101	101	101	1	1	-	-	-	N	0/0	Edit
003	Green	102	102	102	1	1	-	Remote	192.168.0.110:5060	N	5/0	Edit
004	Red	103	103	103	1	1	-	-	-	N	3/0	Edit
005	Red	104	104	104	1	1	-	-	-	Y	0/0	Edit
006	Red	105	105	105	1	1	-	-	-	Y	0/0	Edit
007	Red	106	106	106	1	1	-	-	-	Y	0/0	Edit
008	Red	107	107	107	1	1	-	-	-	Y	0/0	Edit
009	Red	108	108	108	1	1	-	-	-	Y	0/0	Edit
010	Red	109	109	109	1	1	-	-	-	Y	0/0	Edit

2.2.4 Two-Level Management

PX0050 supports two levels management – administrator and user. The administrator can configure everything in the IP-PBX, while the user can only configure his setting or view his status. For each legal user, he can login the PX0050 with the registered number and password. The following page shows the menu structure when user 101 has login into the PX0050 successfully.



The screenshot displays the 'User Management' interface of an IP PBX system. On the left, there is a sidebar with a red gradient background containing a small image of a white IP PBX device and a menu with the following items: 'IP PBX', 'Users Mgmt.', 'Call Status', and 'CDR'. The main content area features a red header bar with the text 'User Management'. Below the header is a table with the following columns: 'Call Status', 'Disp. Name', 'Number', 'Passwd', 'Call Group', 'Pickup Group', 'Hunt Group', 'Call Type', 'IP:Port', 'A P S', 'VMWI (new/old)', and 'Action'. A single row of data is visible, representing user 102. Below the table, there is an 'Apply' button.

Call Status	Disp. Name	Number	Passwd	Call Group	Pickup Group	Hunt Group	Call Type	IP:Port	A P S	VMWI (new/old)	Action
	102	102	102	1	1	-	Remote	192.168.0.110:5060	N	5/0	Edit

3. DHCP Server Configuration

By clicking the **DHCP Server** page, you can configure the DHCP server of the PX0050. You can specify the **DHCP Server IP Pool Start IP** and **DHCP Server IP Pool End IP**. Also you can specify the **WINS Server (for Windows)**.

PX0050 could possibly get the DNS server from ISP (using PPPoE or DHCP), if you want this DNS server information passed to DHCP client, you can check on **Provide Real DNS Server** option.

Notice: this DHCP server configuration will work for both Notebook/PC and IP Phones if the “DHCP only for IP Phones” box in User Management is disabled. If the “DHCP only for IP Phones” box in User Management is enabled, this DHCP server will work only for IP Phones.

In the **Dynamic DHCP Client List**, you can see the active DHCP client lists.

The screenshot shows a web-based configuration interface for a DHCP server. On the left is a navigation menu with items: Status, Network Setup, DHCP Server (highlighted), IP PBX, NAT Advanced, Log, and Management. The main content area is divided into two sections:

- DHCP Configuration:** This section has a red header. It contains the following settings:
 - DHCP Server Status: Enable Disable
 - DHCP Server IP Pool Start IP: 192 . 168 . 1 . 2
 - DHCP Server IP Pool End IP: 192 . 168 . 1 . 20
 - WINS Server: 0 . 0 . 0 . 0
 - Provide Real DNS Server:At the bottom of this section are **Apply** and **Cancel** buttons.
- Dynamic DHCP Client List:** This section also has a red header and contains a table with the following data:

Hardware Address	Assigned IP	Hostname
00:13:48:01:01:01	192.168.1.2	

4. IP-PBX Settings

In the following sections, all the IP PBX related functions will be introduced.

4.1 System

The **System** settings are for the IP PBX related basic parameters, including the following parts.

General

Voice Mail

Call Forward

Call Park

General	
WAN IP	192.168.0.157
LAN IP	192.168.1.1
Port	5060 (1~65535)
RTP Port Range	10000 ~ 10200
Remote/PBX Codec	G.729
DTMF	RPC2833
Authentication	YES
Concurrent Calls per User	2 (1~3)
Maximum System Concurrent Calls	60 (1~60)
Inter-PBX Call In Prefix	91

Voice Mail	
Send Voicemail to E-mail	YES
Go to Voicemail after Ringing	15 seconds (10~255)
Maximum Time of a Voicemail	30 seconds (10~254)
Maximum Time of Voicemail per User	120 seconds (10~254)
Maximum Time of Voicemail for System	1200 seconds
Maximum Time of Voicemail for USB	12000 seconds
Local Voice Mail Access Number	9999
Global Voice Mail Access Number	9998

Call Forward	
Call Forward Immediate Enable	*1
Call Forward Immediate Disable	*2
Call Forward on Busy Enable	*3
Call Forward on Busy Disable	*4
Call Forward on No Answer Enable	*5
Call Forward on No Answer Disable	*6
Call Pickup Number	*7

Call Park	
Call Park Number	9
Call Retrieve Number	9900 ~ 9910
Parking Time	30 seconds

Apply

4.1.1 General

WAN IP: displayed current WAN IP address of PX0050.

LAN IP: displayed current LAN IP address of PX0050.

Port: The PX0050 works as a SIP proxy server for the other SIP devices, any SIP devices can register to PX0050 to the WAN IP or LAN IP addresses, you can change the port of this proxy server by modifying the **Port** field in the IP PBX Configuration page. The default value is 5060. The allowed value for this field is between 1 and 65535.

RTP Port Range: This is the range of ports used by the PX0050 for RTP transmission and reception. All the calls routed through PX0050, including call to auto-attendant, will have the RTP port in this range.

Remote/PBX Codec: PX0050 will determine the remote call codec by this selection. Also the IP Phone will use this codec to access the voicemail and IVR.

DTMF: This is the DTMF relay detection method used by PX0050 when a call is connected between registered devices. PX0050 cannot support **Inband** DTMF when the **Remote/PBX Codec** is G.723 or G.729.

Authentication: This field can determine if the other SIP devices needed to be authenticated if they try to register to PX0050. If this field is enabled, only those devices with the correct accounts listed in the User Management page are allowed to register into PX0050

Concurrent Calls per User: This is the max allowed calls for a single IP Phone in the same time. If want the call waiting function to work, set this field to a value bigger than two.

Maximum System Parallel Call: This is the max allowed calls for the whole PX0050 system in the same time, that includes inter-extension calls and incoming and outgoing calls. The allowed value for this field is between 1 and 60.

Inter-PBX Call In Prefix: This is the prefix number for incoming call from other PX0050, with this prefix, the calls between PX0050 could be like an inter-extension calls. The way it works like this - the dialed number outside of the other PX0050 will be prefixed with this prefix number, and before incoming into this PX0050, this prefix number will be removed, and call into the specific extension number.

4.1.2 Voice Mail

Send Voicemail to E-mail: You can send the voicemail to your e-mail account by enabling this option.

Go to Voicemail after Ringing: You can set the ringing time before go to the voicemail.

Maximum Time of a Voicemail: You can set the maximum recording time length of a specific voicemail. The allowed value for this field is between 10 and 254 seconds.

Maximum Time of Voicemail per User: You can set the total time length of all the voicemails for a single user. The allowed value for this field is between 10 and 254 seconds.

Maximum Time of Voicemail for System: PX0050 can store up to 1200 seconds of total voicemails in the system DRAM.

Maximum Time of Voicemail for USB: If the external 512 MB USB disk is plugged into the system, PX0050 can store up to 12000 seconds of total voicemails in this USB disk.

Local Voice Mail Access Number: By dialing 9999 from your IP Phone, you can access this IP Phone's voicemail records. The IVR system will ask for a password, just press the password of the SIP account to access your voicemail records. This local access number could be changed.

Global Voice Mail Access Number: By dialing 9998 from any other IP Phone, you can still access your own voicemail records. The IVR system will first ask for your mailbox number, just press the extension number of your IP Phone. The IVR system will then ask for a password, just press the password of the SIP account to access your voicemail records. This global access number could be changed.

4.1.3 Call Forward

PX0050 can enable/disable some call forwarding functions for the extension IP Phones by dialing some digits on the extension IP Phone. First off-hook the IP Phone, after hearing the dial tone, presses the specific digits, and then presses a '#' digit. Notice that the IP Phone could also have some call forwarding settings on its own menu configurations, both of IP Phone's and PX0050's call forwarding could work independently.

Call Forward Immediate Enable:

Enable the call forward immediate function of each IP Phone by pressing the specific digits on the IP Phone followed by the extension number to be forwarded, and then press a '#' digit. (This procedure must be done when the IP Phone is off-hooked and heard the dial tone). You can also enable this function through the menu configuration of the IP Phone device. The default value for this function is *1.

Call Forward Immediate Disable:

Disable the call forward immediate function of each IP Phone by pressing these specific digits on the IP Phone, and then press a '#' digit. (This procedure must be done when the IP Phone is off-hooked and heard the dial tone). You can also disable this function through the menu configuration of the IP Phone device. The default value for this function is *2.

Call Forward on Busy Enable:

Enable the call forwarding on busy function of each IP Phone by pressing the specific digits on the IP Phone followed by the extension number to be forwarded, and then press a '#' digit. (This procedure must be done when the IP Phone is off-hooked and heard the dial tone). You can also enable this function through the menu configuration of the IP Phone device. The default value for this function is *3.

Call Forward on Busy Disable:

Disable the call forward on busy function of each IP Phone by pressing these specific digits on the IP Phone, then press a '#' digit. (This procedure must be done when the IP Phone is off-hooked and heard the dial tone). You can also disable this function through the menu configuration of the IP Phone device. The default value for this function is *4.

Call Forward on No Answer Enable:

Enable the call forward on no answer function of each IP Phone by pressing the specific digits on the IP Phone followed by the extension number to be forwarded, and then press a '#' digit. (This procedure must be done when the IP Phone is off-hooked and heard the dial tone). You can also enable this function through the menu configuration of the IP Phone device. The default value for this function is *5.

Call Forward on No Answer Disable:

Disable the call forward on no answer function of each IP Phone by pressing these specific digits on the IP Phone, then press a '#' digit. (This procedure must be done when the IP Phone is off-hooked and heard the dial tone). You can also disable this function through the menu configuration of the IP Phone device. The default value for this function is *6.

Call Pickup Number:

This is the digits for any IP Phone to press (after off-hooked) to pickup a call of the other ringing extension on the same pickup group. Remember to press a '#' digit after the specific digits. The default value for this function is *7.

4.1.4 Call Park

Call Park Number:

This is the digit(s) for any extension IP Phone to press during a call conversation to park this call, a following '#' digit must be pressed, then, a retrieve number (9900~9910) will be heard on the phone, . After you walk to another IP Phone, you can dial the retrieve number you just heard in the parked IP Phone to retrieve back the previous call conversation. The default value for this Call Park Number is **9**.

Call Retrieve Number:

This is the retrieve number range the user will heard from the phone when parking a call.

Parking Time:

This is the maximum allowed parking time for the parked call. The default value for this function is 30 seconds.

4.2 Proxy Server

The **Proxy Server** page includes the following parts:

IP-PBX Behind NAT

Register Expire

Proxy Server

If PX0050 has the **private WAN IP address** (behind the NAT), you may need to set **IP-PBX behind NAT** to **Yes**, and enable the **SIP Keep Alive** settings. If you ITSP cannot support the private IP address registration, you need to enable the **Stun Server** Settings. You should turn on **Stun Server** or **Outbound Proxy Settings** according to the ITSP instructions. The settings in **IP-PBX behind NAT** and **Register Expire** are effective for all the items in the Proxy server settings.

If the WAN IP address of the PX0050 is a public IP address, just set **IP-PBX behind NAT** to **No**.



IP-PBX behind NAT

IP-PBX behind NAT: YES

SIP Keep Alive Enable:

SIP Keep Alive Period: 20 seconds (20~65535)

Stun Enable:

Stun Server: stun.voip.eutelia.it

Stun Port: 3478 (1~65535)

Stun Status: 

Register Expire

Register Expire Period: 3600 seconds (60~65535)

Proxy Server

Reg	Name	Number	Password	Auth. ID	Proxy IP	Proxy Port	Outbound Proxy	DID	Action
<input type="checkbox"/>		eutelia	0245071688	485mP1Xp	voip.eutelia.it	5060	-	IVR	Edit

Delete Add Apply

4.2.1 IP-PBX behind NAT

IP-PBX behind NAT: If your IP-PBX is behind NAT, please select this value to **Yes**.

Stun Enable: You can enable or disable these Stun settings by clicking on the checkbox.

Stun Server: You can fill in the stun server FQDN or IP address in this field.

Stun Port: You can fill in the stun server port in this field. The default value is 3478.

Stun Status: If PX0050 can connect to the stun server, this will show the green light. **SIP Keep Alive Enable:** You can enable or disable this option by clicking on the checkbox. You will need to enable this only when the PX0050 is put behind another NAT device.

SIP Keep Alive Period: If you enable the keep alive, you can fill in the period in this field. The PX0050 will periodically send out a small SIP message to keep the signal path between PX0050 and the Proxy Server to prevent another NAT device from disconnecting this path.

When you complete the configurations, you can press **Apply** to save all the settings. The system will restart to take the new settings effect.

4.2.2 Register Expire

Register Expire Period: You can fill in the register expire period in this field. The PX0050 will periodically re-register to the Proxy Server.

4.2.3 Proxy Server

The PX0050 works as a SIP proxy server for the other SIP devices, any SIP devices can register to PX0050 to the WAN IP or LAN IP addresses. The PX0050 can also register to other PX0050 or other SIP Proxy server on this setting. The system can allow up to 8 registrations to other proxies.

The fields of each registration item are explained below:

Reg: this field displays the registration status of the Proxy Server, green light means registered successfully.

Name: this is the name of this registration. And this name will be used in the **Call Route** settings.

User Name: the user name of this registration item.

Password: the password of this registration item.

Auth. ID: the authentication ID of this registration item.

Proxy IP: the IP address of the registered SIP proxy server.

Proxy Port: the port number of the registered SIP proxy server.

Outbound Proxy: if ComCenter is behind the NAT, you should enable this option. This will show the IP address and port of the registered SIP outbound proxy.

DID (Direct Inward Dialing): Any calls originating from the registered ITSP to PX0050 will go into the auto-attendant or direct to the selected user or hunting group.

Action: You can modify the existing entry by clicking **Edit** button.

After **Delete/Add/Edit** of any items, you need to press the **Apply** button to save the configurations to the system. And all the settings will work immediately after pressing the **Apply** button. Do not need to restart the system to let this settings work.

For some ITSP, you cannot send the **User Number** to make the off net call. You can see the **Caller ID Delivery** when you **Add/Edit** proxy server entry. In this case, you need to select **Anonymous** as the **Caller ID Delivery**.


If you delete the **Proxy Server** item, the **Call Route** items associating with the **Proxy Server** will be deleted at the same time. PX0050 will prompt a message box to allow you to confirm the deleting.

4.3 Gateway

PX0050 can make the off-net call either via the ITSP Proxy or the FXO gateway. Before you can make the successful call, you have to add the **Gateway** entry or the **Proxy Server** entry and set the proper **Call Route**. In this section, we'll describe how to add a FXO gateway entry.

By clicking **Add** button, you'll see the Add Gateway page. Fill in the **Name**, **Gateway IP**, **Gateway Port**, **Number of Analog Ports** (Physical FXO Ports) and press **Apply**. This **Name** will be used in the **Call Route**, and it must be a unique for each Gateway.

If the PX0050 is behind NAT, we recommend you to connect the FXO gateway to the WAN side of the IP-PBX. If the PX0050 has the public IP address, we recommend you to connect the FXO gateway to the LAN side of the IP-PBX.




Add Gateway

Entry Attributes	Values
Name	FXO-1
Gateway IP	140.112.45.23
Gateway Port	5060 (1~65535)
Number of Analog Ports	4

Status
Network Setup
DHCP Server
IP PBX
System
Proxy Server
Gateway
Call Route
Block List
Users Mgmt.
Call Status
Hunt Group
CDR
Auto Attendant
Upload Voice File
NAT Advanced
Log
Management

Back to the **Gateway** page, you can see the new entry, and press **Apply** to save the settings to the flash. If you delete the **Gateway** item, the **Call Route** items associating with the **Gateway** will be deleted at the same time. PX0050 will prompt a message box to allow you to confirm the deleting.



Gateway

<input type="checkbox"/>	Name	IP:Port	Number of Analog Ports	Action
<input type="checkbox"/>	FXO-1	140.112.45.23:5060	4	<input type="button" value="Edit"/>


1. IP-PBX behind NAT: Connect the FXO gateway to the IP-PBX's WAN side.
2. IP-PBX has the public IP address: Connect the FXO gateway to IP-PBX's LAN side.

4.4 Call Route

The extension of a PX0050 can call out to other extensions of other PX0050 or to other SIP proxy server or to other gateway device by setting the call route rules in this configuration page. For a called number, when the first few digits match the pattern of a call route, this call will be routed to a destination in this call route rule.

The **Call Route** settings make many PX0050 to be able to group together to become a much larger system and make PX0050 to bundle to other SIP service system and to call to PSTN through the gateway devices.

The **default route** entry always exists in the PX0050 and the user cannot delete it. If the outgoing call cannot match any other call routes, it will match the **default route**.



Name	Pattern	Destination	Drop Digits	Prefix	Action
default route	.		0		Edit

Buttons: Delete, Add, Apply

The fields of all items are explained below:

Name: this is the name of this route entry.

Pattern: this is the number that when the first few digits a call number matched will be routed specifically. For the call pattern, the 'x' is used to represent the wildcard for one digit, and '.' is used to represent the unlimited length of wildcards.

Destination: the destination of this call route item, this could be the **Proxy Server** or **Gateway** name.

Drop Digits: the first few digits of the dialed number will be removed after going out of the PX0050 when the dialed number matches this pattern. This field is the length of the removed first few digits.

Prefix: this prefix number will be added to the dialed number after going out of the PX0050 when the dialed number matches this pattern.

You can press **Add** button to add the new **Call Route** entry. By pressing **Add**, you can see the following page. The following steps will guide you how to setup a **Call Route** entry.

1. Fill the **9**. in the **Pattern** field, any call begin with digit 9 will route to this entry.
2. Then choose the existing **Proxy Server Name** from the dropdown combo box, or select the existing **FXO Gateway** from the combo box.
3. Fill in 1 in **Drop Digits** field.
4. We don't want to add any prefix to the outgoing number, so leave **Prefix** field empty.
5. Press **Apply** to go back the main page.

After **Delete/Add/Edit** of any items, you need to press the **Apply** button to save the configurations to the system. And all the settings will work immediately after pressing the **Apply** button.

Route Attributes	Values
Name	FXO-Route
Pattern	9.
Route via	<input type="radio"/> Proxy Server gossiptel <input checked="" type="radio"/> Gateway FXO-1
Drop Digits	1
Prefix	

4.5 Block List

By dialing 9991, you can record your customized **Block List** announcement. You can change this number by typing the new number and press **Apply**.

If you want to block some certain outgoing calls, you can add the block number here. For example, if you want to block any number that starts with 0204, you can add the block pattern **0204.**. This setting will block the number 0204x/0204xx/0204xxx etc, but it cannot block 0204. The **Name** must be unique for each **Block List** entry.

Call Out Block List

Block List Recording Number:

<input type="checkbox"/>	Name	Block Pattern	Action
<input type="checkbox"/>	sex	0204.	<input type="button" value="Edit"/>

4.7 Hunt Group

This feature allows multiple users to be ringed by dialing into one configured hunt group number. Any call to the hunt group number will be forwarded to all the users configured in that number based on the mode of the hunt group. Hunt Group can have three modes, **Round Robin**, **Parallel** and **Random**. All hunt group members will be ringed one by one in **Round Robin** mode. For example, if Sale's Group contains members 101, 102 and 103, the first incoming call will ring 101, then 102, then 103. The second call will ring 102, then 103, then 101. All the users will be ringed in the same time in **Parallel** mode. PX0050 will ring the members randomly in **Random** mode.

By pressing **Add** button, you can see the **Add Hunt Group** page.

Group Attributes	Values
Name	FXO-1
Number	2000
Hunt Mode	Round Robin
Hunting Time	30 seconds (30~120)
Members	102 100 103 101
Goto VM after Hunting Time	100


Apply **Cancel**

1. In the Round Robin/Random mode, the system will ring each user 7 seconds and break 2 seconds. Number of Ringing Users = Hunting Time/9.

2. In the Parallel mode, the system will ring the group 10 seconds and break 5 seconds. Number of Ringing Loops = Hunting Time/15.

1. Fill the hunt group name in the **Name** field. The name should be unique for each hunting group.
2. Give a hunt group number that is not used by any other users, and fill this number in **Number** field.
3. Select the **Hunt Mode** from the combo box.
4. Fill in the **Hunting Time**. For the **Round Robin** mode, the system will ring each member for 7 seconds and pause for 2 seconds. The minimal hunting time cannot be less than #members*9 seconds. In the **Random** mode, it's similar with the Round Robin mode. If you set the hunting time to 30 seconds, it will ring 30/ (7+2) members in each incoming call. In the **Parallel** mode, the system will ring the group members 10 seconds and pause for 5 seconds periodically. i.e. If you set the hunting time to 30 seconds, it will ring the hunting group 30/ (10+5) times.
5. Select the group members from the left box to the right box.
6. If no one will answer the call after the hunting time, the system will go to one of the member's voicemail. You need to choose one member from **Go to VM after Hunting Time** combo box.

7. Press **Apply** to go back the main page.



Hunt Group

<input type="checkbox"/>	Group Name	Number	Hunt Mode	#Members	Action
<input type="checkbox"/>	FXO-1	2000	Round Robin	100,101	<input type="button" value="Edit"/>

1. Each hunt group can have a maximum of 20 users.
2. A user can belong to a maximum of 5 hunt groups.

4.8 CDR

The CDR (Call Detailed Record) of PX0050 can save & display some information of all the calls, successful or failed etc.

The fields of each CDR items are explained below:

Caller: this is the calling party number.

Callee: this is the called party number.

Start Time: the time when the caller starts the call.


Answer Time: the time when the callee answered the call, if the call is not answered, this field will be empty.

End Time: the time when any party hangs up the call.

Total Duration: the total duration of the call from Start time to end time.

Bill: the total duration of the call from Answer time to end time

Call Action: shows the result of the call - answered or busy.



CDR - Call Detailed Record							
Caller	Callee	Start Time	Answer Time	End Time	Total Duration (secs)	Bill (secs)	Call Action
101	103	2006-04-21 18:24:54	2006-04-21 18:24:54	2006-04-21 18:25:04	10	10	ANSWERED
102	IVR_record_main	2006-04-21 18:24:44	2006-04-21 18:24:44	2006-04-21 18:24:52	8	8	ANSWERED
101	102	2006-04-21 18:24:32	2006-04-21 18:24:34	2006-04-21 18:24:40	8	6	ANSWERED

1

4.9 Auto Attendant

PX0050 provides the flexible Auto Attendant architectures. The system will play the different message according to the **Service Time** configurations. If someone dials into PX0050 in the business hours, it will play the welcome message that will say that please press 0 for native language or press 9 for the operator. If the call is coming during the off-duty period, it will play the off-duty message that will say that it's the after business hour and please dial the extension number directly. The digit 0 or 9 is called **Service Digit**, the user can record the customized message that prompt the different digit ranging from 0~9 for different services.

This page is divided into three parts. The first part provides two numbers for auto attendant and auto attendant recording.

The second part is the **Auto Attendant Message List** that allows the user to record 4 customized messages. The system provides default English and Chinese welcome and off-duty messages. User can upload their own messages to replace the default messages.

The third part is the **Auto Attendant Service Time List**. User can add the service time range, and select the associating message. System allows the user to add 6 service time entries.

Auto Attendant Recording

Auto Attendant Number: 9997
Auto Attendant Recording Number: 9990

Auto Attendant Message List

Message	Service Digit	Action
Welcome Message	0, 9	Edit
Off-Duty Message	0	Edit
Custom-1 Message	0	Edit
Custom-2 Message	0	Edit
Custom-3 Message	0	Edit
Custom-4 Message	0	Edit

Auto Attendant Service Time List

Times	Weekdays	Date	Message	Action
-------	----------	------	---------	--------

Delete Add Apply

4.9.1 Auto Attendant Recording

Auto Attendant Number:

By dialing 9997 from any extension IP Phone, you can listen to your customized auto attendant announcement. This number 9997 could be changed.

Auto Attendant Recording Number:

By dialing 9990 from any extension IP Phone, user can record the customized auto attendant announcement. The IVR system will direct you to record every sentences needed for the auto-attendant announcements, that include welcome message, off-duty message in both English and native languages. This number 9990 could be changed.

4.9.2 Auto Attendant Message List

PX0050 provides 6 messages that can be played at different service times. There are two default messages called Welcome and Off-Duty messages and 4 Custom messages. By clicking the **Edit** button in the **Welcome Message**, the following page will be shown. Before you can use the upload function, you must make sure the USB is mounted. The maximum size of the voice file size is 200 Kbytes. The 200 Kbytes will allow you to upload 204.8 seconds G.729 voice file and 172 seconds GSM file.

The screenshot shows the 'Auto Attendant Message' configuration page. The left sidebar contains a navigation menu with categories: Status, Network Setup, DHCP Server, IP PBX (including System, Proxy Server, Gateway, Call Route, Block List, Users Mgmt., Call Status, Hunt Group, CDR, Auto Attendant, Upload Voice File), NAT Advanced, Log, and Management (Remote Mgmt., Password, Upgrade). The main content area is titled 'Auto Attendant Message' and shows 'Welcome Message' configuration. It features a table for message types and a table for service digits and extensions.

Message Type	G.711 (.gsm)	G.729 (.g729)
English Welcome Message	<input type="text"/> <input type="button" value="浏览..."/> <input type="button" value="Upload"/>	<input type="text"/> <input type="button" value="浏览..."/> <input type="button" value="Upload"/>
Native Welcome Message	<input type="text"/> <input type="button" value="浏览..."/> <input type="button" value="Upload"/>	<input type="text"/> <input type="button" value="浏览..."/> <input type="button" value="Upload"/>

<input type="checkbox"/>	Service Digit	Extension	Action
<input type="checkbox"/>	0	Native Language Service	
<input type="checkbox"/>	9	100	<input type="button" value="Edit"/>

Buttons:

For each message, the system has reserved service digit 0 for the native language service and the user can add 5 digits for different services. For Welcome message, it always plays at the working hour. The system has reserved digit 9 for operator service and the default operator's extension is 100. You can upload the customized English and Native Welcome message by browsing the .gsm or .g729 file in the local storage and upload to the system. Once you have done all the changes, press **Apply** button to take effect.

4.9.3 Auto Attendant Service Time List

You can set six Service Time List entries. By clicking **Add** button, you can see the following page. The following settings show the working hour is from 9:00~18:30 Monday to Friday. Any call coming in this period will play the **Welcome Message**. Press **Apply** to back to the previous screen and press **Apply** again.

45

Attributes	Values
Date	
Weekdays	MON To FRI
Times	09:00 To 18:30
Message Type	Welcome Message

Apply Cancel

Auto Attendant Number: 9997
Auto Attendant Recording Number: 9990

Message	Service Digit	Action
Welcome Message	0, 9	Edit
Off-Duty Message	0	Edit
Custom-1 Message	0	Edit
Custom-2 Message	0	Edit
Custom-3 Message	0	Edit
Custom-4 Message	0	Edit

	Times	Weekdays	Date	Message	Action
<input type="checkbox"/>	09:00-18:30	MON-FRI	-	Welcome Message	Edit

Delete Add Up Down
Apply

For example, your company will be closed during Dec 25 ~ Dec 31 every year and you want to play the **Custom-1** message. After you have added this entry and press **Apply** button, you can see the following page.

Auto Attendant Recording

Auto Attendant Number: 9997
 Auto Attendant Recording Number: 9990

Auto Attendant Message List

Message	Service Digit	Action
Welcome Message	0, 9	<input type="button" value="Edit"/>
Off-Duty Message	0	<input type="button" value="Edit"/>
Custom-1 Message	0	<input type="button" value="Edit"/>
Custom-2 Message	0	<input type="button" value="Edit"/>
Custom-3 Message	0	<input type="button" value="Edit"/>
Custom-4 Message	0	<input type="button" value="Edit"/>

Auto Attendant Service Time List

<input type="checkbox"/>	Times	Weekdays	Date	Message	Action
<input type="checkbox"/>	09:00-18:30	MON-FRI	-	Welcome Message	<input type="button" value="Edit"/>
<input type="checkbox"/>	-	-	Dec/25-Dec/31	Custom-1 Message	<input type="button" value="Edit"/>

Unfortunately you can never the **Custom-1** message during Dec 25 ~ Dec 31. The system will always match the first entry of the service time and play the **Welcome Message**, since the first entry has the highest priority when matching the rule. So you have to select the second entry and press **Up** button to move this entry to the first priority.

Auto Attendant Service Time List

<input type="checkbox"/>	Times	Weekdays	Date	Message	Action
<input type="checkbox"/>	09:00-18:30	MON-FRI	-	Welcome Message	<input type="button" value="Edit"/>
<input checked="" type="checkbox"/>	-	-	Dec/25-Dec/31	Custom-1 Message	<input type="button" value="Edit"/>

Then you can see the following page. Press **Apply** to save the settings to the flash.

Auto Attendant Service Time List

<input type="checkbox"/>	Times	Weekdays	Date	Message	Action
<input checked="" type="checkbox"/>	-	-	Dec/25-Dec/31	Custom-1 Message	<input type="button" value="Edit"/>
<input type="checkbox"/>	09:00-18:30	MON-FRI	-	Welcome Message	<input type="button" value="Edit"/>

4.10 Upload Voice File

You can upload **English/Native Invalid Message**, **English /Native Block List Message**, **Call Queuing Message**, and **Music on Hold File** via this page. Before you can use the upload function, you must make sure the USB is mounted. The maximum size of the voice file size is 200 Kbytes. The 200 Kbytes will allow you to upload 204.8 seconds G.729 voice file and 172 seconds GSM file.

Message Type	G.711 (.gsm)	G.729 (.g729)
English Invalid Message	<input type="text"/> 浏览... Upload	<input type="text"/> 浏览... Upload
Native Invalid Message	<input type="text"/> 浏览... Upload	<input type="text"/> 浏览... Upload
English Block List Message	<input type="text"/> 浏览... Upload	<input type="text"/> 浏览... Upload
Native Block List Message	<input type="text"/> 浏览... Upload	<input type="text"/> 浏览... Upload
Call Queuing Message	<input type="text"/> 浏览... Upload	<input type="text"/> 浏览... Upload
Music On Hold File	<input type="text"/> 浏览... Upload	<input type="text"/> 浏览... Upload

1. You can do the upload voice file function only when the USB disk is mounted.
2. The maximum size of the upload voice file size is 200 kbytes.

If the PX0050 **Remote/PBX Codec** is G.711ulaw or G.711alaw, you have to upload the gsm file to the system. If the codec is G.729, you have to upload the file with .g729 format. We'll show the details in Appendix VII.

5. NAT Advanced Configuration

PX0050 has the built-in Hardware NAT functions, so most of the NAT functions are accelerated by the hardware. PX0050 provides the following NAT functions.

- Access Control List
- Virtual Server
- URL Filter
- Static Route
- Special Application
- DMZ Host
- DoS
- Dynamic DNS
- Passthrough
- UPnP
- Ping Toolkit

Notice 1 : Section 5.1 to 5.11 are all related to NAT advanced functions of PX0050, these functions will work when PX0050 is not only working as an IP PBX, but also working as a NAT/Router for the office. But we recommend just use PX0050 as a pure IP PBX to guarantee the voice quality. So, if you just use PX0050 as a pure IP PBX, then don't need to do any configurations for section 5.1 to 5.11.

Notice 2: When PX0050 is used as a pure IP PBX, the WAN port IP address also needed to be configured so that the PX0050 can be accessed by remote users or register to another proxy server.

5.1 Access Control List

With **Access Control List**, you can **forbid/block** a certain Notebook/PC from accessing certain internet service. There are 8 different access control lists for user's configuration. If you want to generate the ACL log, you have to check the **Generate ACL Log** box on.

The following setting give the example of blocking a certain Notebook/PC with IP address 192.168.1.250 from doing the FTP access (port 21) to the internet.

Priority	IP	Type	Port	Enable
1	192 . 168 . 1 . 250	TCP	21	<input checked="" type="checkbox"/>
2	192 . 168 . 1 . 0	TCP	0	<input type="checkbox"/>
3	192 . 168 . 1 . 0	TCP	0	<input type="checkbox"/>
4	192 . 168 . 1 . 0	TCP	0	<input type="checkbox"/>
5	192 . 168 . 1 . 0	TCP	0	<input type="checkbox"/>
6	192 . 168 . 1 . 0	TCP	0	<input type="checkbox"/>
7	192 . 168 . 1 . 0	TCP	0	<input type="checkbox"/>
8	192 . 168 . 1 . 0	TCP	0	<input type="checkbox"/>

5.2 Virtual Server


Virtual Server can be used to set up public server services on your network. When users from the Internet make certain service requests on your network, the PX0050 can forward those requests to computers that really have the service. For example, if you set the port number 80 (HTTP) to be forwarded to IP Address 192.168.1.2, then all HTTP requests from internet will be forwarded to 192.168.1.2.

You may use this function to establish a Web server or FTP server service through PX0050. Be sure that you enter a valid IP Address. (You may need to establish a static IP address with your ISP in order to properly run an Internet server). The packets will simply be forwarded through the PX0050.

Enter the range of port numbers and the protocol type (UDP or TCP) that will be used by the server service. Then enter the IP Address and port range of the real local server that will handle the service requests.

There are eight virtual server entries for user configuration.

Click the **Apply** button to save the settings.




WAN Port Range	Server IP Address	Server Port Range	Protocol	Enable
20 ~ 21	192 .168 .1 .0	20 ~ 21	TCP	<input checked="" type="checkbox"/>
0 ~ 0	192 .168 .1 .0	0 ~ 0	TCP	<input type="checkbox"/>
0 ~ 0	192 .168 .1 .0	0 ~ 0	TCP	<input type="checkbox"/>
0 ~ 0	192 .168 .1 .0	0 ~ 0	TCP	<input type="checkbox"/>
0 ~ 0	192 .168 .1 .0	0 ~ 0	TCP	<input type="checkbox"/>
0 ~ 0	192 .168 .1 .0	0 ~ 0	TCP	<input type="checkbox"/>
0 ~ 0	192 .168 .1 .0	0 ~ 0	TCP	<input type="checkbox"/>
0 ~ 0	192 .168 .1 .0	0 ~ 0	TCP	<input type="checkbox"/>

Apply Cancel

- Virtual servers using single port number is accelerated by hardware at wirespeed.

5.3 URL Filter

You can deny some Notebook/PC from accessing to some websites by listing them in this “URL Filter” list. For example, if you want to deny all the Notebook/PC with IP addresses from 192.168.1.2 to 192.168.1.254 to access the www.playboy.com website, you can do the following settings.



URL String Pattern to be Blocked	Source IP Range	Enable
http://www.playboy.com	192.168.1.2-192.168.1.254	<input checked="" type="checkbox"/>
	0.0.0.0-0.0.0.0	<input type="checkbox"/>
	0.0.0.0-0.0.0.0	<input type="checkbox"/>
	0.0.0.0-0.0.0.0	<input type="checkbox"/>
	0.0.0.0-0.0.0.0	<input type="checkbox"/>
	0.0.0.0-0.0.0.0	<input type="checkbox"/>
	0.0.0.0-0.0.0.0	<input type="checkbox"/>

- Any web access traffic (ie. destined to any TCP port) is inspected by hardware at wirespeed.

5.4 Static Route

You will need to configure “Static Route” function if there are multiple routers installed on your network.

The “Static Route” function let the PX0050 be able to direct some packets to go to correct interface (LAN or WAN) when the packets were with destination IP address listed in the “Static Route” list.

For example, if you have the following network hierarchy, you can configure the following settings in the routing table.



Static Route

Route	Route Mask	Next Hop IP	Interface
192.168.2.0	255.255.255.0	192.168.1.100	LAN
192.168.3.0	255.255.255.0	192.168.0.100	WAN
0.0.0.0	255.255.255.255	0.0.0.0	-----
0.0.0.0	255.255.255.255	0.0.0.0	-----
0.0.0.0	255.255.255.255	0.0.0.0	-----

Apply Cancel

- Given "Next Hop IP" must be in the same subnet as specified "Interface" to be accepted.

5.5 Special Application

PX0050 has a natural firewall that rejects any *unsolicited* data from traveling into a computer on the LAN network. Basically, if you didn't ask for the data, it isn't going to pass through the firewall. A **Special Application** is one that breaks this rule. For some applications, you can configure the PX0050 to allow them to pass inside PX0050 to a specific Notebook/PC by setting this "Special Application" list, or a certain special application to pass through PX0050, first, a trigger packet that has a destination port falling in the range between **Trigger Start Port** and **Trigger End Port** must be sent from a Notebook/PC in the LAN side out to the WAN side. Second, the packets of the special application from the internet must have the destination port falling in the **Incoming Port Range**. These packets then will be forwarded to the Notebook/PC that has sent the trigger packet.

Name	Incoming Type	Incoming Port Range	Trigger Type	Trigger Start Port	Trigger End Port	Enable
Quick Time 4	UDP	6970-6999	TCP	554	554	<input checked="" type="checkbox"/>
MSN Gaming Zor	TCP	28800-29000	TCP	6667	6667	<input checked="" type="checkbox"/>
ICQ	TCP	20000-20019,20020-20039	TCP	4000	4000	<input checked="" type="checkbox"/>
	TCP		TCP	0	0	<input type="checkbox"/>
	TCP		TCP	0	0	<input type="checkbox"/>
	TCP		TCP	0	0	<input type="checkbox"/>
	TCP		TCP	0	0	<input type="checkbox"/>
	TCP		TCP	0	0	<input type="checkbox"/>

Apply Cancel

5.6 DMZ Host


The **DMZ Host** setting can allow one local user to be exposed to the Internet with no firewall protection. When a local user wishes to use some special-purpose service, such as an Internet game or Video-conferencing, set the dedicated DMZ Port and click the **Apply** button.



5.7 DoS


DoS (Denial_of_Service) Protection

When you enable this function, it will block most of the Internet attacks. This option is enabled as default value.



5.8 Dynamic DNS

PX0050 supports dynamic DNS service. If the WAN IP address of PX0050 is dynamic and public (PPPoE), you can use this service to let other Internet host to access PX0050 by its dynamic domain name.




The screenshot shows a web-based configuration interface for a device. On the left is a vertical navigation menu with the following items: Status, Network Setup, DHCP Server, IP PBX, NAT Advanced, Access Control List, Virtual Server, URL Filter, Static Route, Special Application, DMZ Host, DoS, Dynamic DNS (highlighted in red), Passthrough, UPnP, Ping Toolkit, Log, and Management. The main content area is titled "Dynamic DNS" in a red header. It contains the following fields and controls:

- Service Type: A dropdown menu with "http://www.dhs.org" selected.
- Username: A text input field containing "mydns".
- Password: A text input field containing six dots.
- Host Name: A text input field containing "mydns".
- Buttons: "Apply" and "Cancel" buttons.

5.9 Passthrough

PX0050 provides the following pass through functions; you can let some specific types of packets to pass through PX0050 without any modification of the packets. The types of packets that could be enabled to pass through are PPPoE, IPv6, IPX, NETBIOS and IP multicast. You can choose to enable some of these types to pass through by checking the Pass through page.




5.10 UPnP

Universal Plug and Play (UPnP) is designed to support zero-configuration, "invisible" networking, and automatic discovery for some devices installed inside the LAN network of PX0050. The specific devices must have some UPnP application running to let this function work. Window XP can support UPnP function. MSN version above 6.0 can use UPnP to learn the NAT router's WAN IP and thus traverse the NAT seamlessly. To enable the UPnP function, just check on the box and press **Apply** to take effect.



5.11 Ping Toolkit

You can use the **Ping Toolkit** to allow PX0050 to ping another device in the LAN network or in the Internet to check if the network link between PX0050 and the specific device are connected. The results of the pinging will be displayed in this page. The following web page shows the example of pinging “www.google.com”.



The screenshot displays the 'Ping Toolkit' interface. On the left is a navigation menu with categories: Status, Network Setup (containing DHCP Server, IP PBX, NAT Advanced, Access Control List, Virtual Server, URL Filter, Static Route, Special Application, DMZ Host, DoS, Dynamic DNS, Passthrough, UPnP, and Ping Toolkit), Log, and Management. The main content area has a red header 'Ping Toolkit' and a search bar with 'www.google.com' and a 'Ping' button. Below the search bar, the results of the ping are shown:

```
IP Address / Host Name : www.google.com Ping
PING www.l.google.com
(66.102.7.104): 56 data
bytes
64 bytes from
66.102.7.104:
icmp_seq=0 ttl=241
time=180.0 ms
64 bytes from
66.102.7.104:
icmp_seq=1 ttl=241
time=180.0 ms
64 bytes from
66.102.7.104:
icmp_seq=2 ttl=241
time=180.0 ms
64 bytes from
66.102.7.104:
icmp_seq=3 ttl=241
time=180.0 ms

Response :


--- www.l.google.com
ping statistics ---
4 packets transmitted, 4
packets received, 0%
packet loss
round-trip min/avg/max
= 180.0/180.0/180.0 ms
```

6. Log

In this setting, you can decide which kind of events to be logged and to view these individually logged events.

There are five kinds of events that could be logged; they are system, ACL (section 5.1), URL filter (section 5.3), New NATP (newly opened port mapping) and PBX logs.

For example, if you want to log the system events, you need to check on this **System Log** check box and pressing **Apply** button. Latter on, you could then press the **View System Log** to see the logged events.



7. Management

7.1 Remote Management

Remote Management Port:

PX0050 allows you to do the remote management via the web browser. You can change the remote management port by modifying this field. The default port number is 8080. If you want to disable remote management through web, you need to enter 0 in this field.

Ping from WAN Side:

This feature is designed to prevent attacks through the Internet. When it is disabled, the PX0050 will drop ICMP packets from the WAN side. The hacker cannot find the PX0050 by pinging the WAN IP address. The default value of this field is enabled.



7.2 Password

This setting allows you to change the web login password of the administrator account.

If you want to change the password, just click on **Password** page and type the new password. Press the **Apply** button when you have done the input.



The screenshot shows a web interface for configuring the administrator password. On the left is a navigation menu with a red background and white text, listing various system settings: Status, Network Setup, DHCP Server, IP PBX, NAT Advanced, Log, Management, Remote Mgmt., Password (highlighted with a red box), and Upgrade. Above the menu is a small image of a white network device. The main content area has a red header bar with the text "Administrator Password" in white. Below the header, there are two text input fields: "New Password" and "Confirm Password". An "Apply" button is positioned below the "Confirm Password" field. The interface is presented in a browser window with standard scrollbars.

7.3 Upgrade

By clicking on the **Upgrade** page, you can do the following functions.

Firmware Upgrade:

The firmware of PX0050 could be upgraded if you have a newer firmware on your Notebook/PC. Just press the **Browse** button on this page, a small window will pop up that allows you to select the new firmware file in your PC. After the firmware file is selected, press the **Upgrade** button to do the firmware upgrade. A progress bar will pop up to display the upgrading status. The upgrade progress will take about 4~5 minutes. Please don't reboot the device during upgrade.

Backup Configuration:

By pressing **Backup** button, you can save PX0050's current configuration settings into a file in your PC. The saved filename is "config.dat".

Restore Configuration:

The configuration of PX0050 could be restored from the backup configuration file you stored previously with the file name of "config.dat". You can press the **Browse** button to select the backup configuration file name. Then, by pressing **Restore** button, the configuration will be restored to PX0050. If the external USB disk is inserted and works with PX0050, the new settings will be restored to the flash and external USB disk at the same time.

Factory Default:

Press the **Factory Default** will restore the flash & external USB settings to the factory default values.

System Restart:

Press the **System Restart** will reboot the system.

Appendix I - DHCP Server Function Notice

There are two web pages related to the DHCP Server options. One is **DHCP Server Status** in the **DHCP Server** page (see section 4.0) and the other is the **DHCP Only for IP Phones** in the **User Management** page (see section 2.2).

This appendix will illustrate the different combinations and results.

DHCP Server Status: Enabled / DHCP Only for IP Phones : Checked

- The DHCP server in this PX0050 will only provide IP address to IP Phones with MAC addresses listed in the user management page, the Notebook/PC in the same network will not be able to get any IP address from PX0050. In this way, as depicted in **Figure 1**, the voice packets from IP Phones will go through PX0050 and data packets from Notebook/PC will go through NAT/Router. This is the default setting.
- Under this situation, if the APS selection is checked, the IP Phone will also get the auto-configuration information (file name) from DHCP packets, and the IP Phone could be installed automatically.

DHCP Server Status: Disabled

- The DHCP Server will not offer IP addresses to any devices that were connected to the LAN network of the PX0050.
-

DHCP Server Status: Enabled / DHCP Only for IP Phones: Unchecked

- The DHCP Server will offer IP addresses to any devices that were connected to the LAN network of the PX0050. The devices could be IP Phones and/or Notebook/PC.

Appendix II – USB Disk Usage Notice

We recommend you to plug the 512 Mbytes external USB Disk to PX0050. There are two very important benefits of using the USB disk:

1. The storage size of voicemail and CDR records is 10 times larger.
2. When under some terrible situation that the PX0050 damaged, you can get a new PX0050 in a fastest speed and insert the old USB disk into it, the whole configurations of the old PX0050 will be back, no need to worry about any re-configuration and storage lost.

This appendix will describe the USB Disk behavior in more details.

Fresh USB Disk

- When you plug a fresh USB Disk into PX0050, PX0050 will backup all current configurations to the USB Disk in the booting time.

Load Setting Sequence

- During system boot up, if the USB Disk is inserted and is not fresh, the system will load the settings from the USB Disk; these settings will then be saved into system flash memory after boot up. If there is no valid configuration in the USB Disk or the USB Disk is not plugged into the system, the system will load the configurations from the system flash memory instead.

Configuration Synchronization

- During the web page configuration, when the **Apply** button in each page is pressed, the new settings will be saved into the system flash memory and USB Disk simultaneously.

Factory Default

- When the **Factory Default** button in the management/upgrade page is pressed, the configurations in system flash memory and USB Disk will be cleared to factory default values.

Don't try to unplug the USB Disk at runtime

- PX0050 does not support hot plug-and-unplug, so make sure that the USB Disk is plugged into the system before power on. Don't unplug the USB Disk during system runtime.

Persistent Storage

- The CDR records and Voicemail when stored into the USB Disk, the storage could be permanent.
- The CDR records and Voicemail when stored into the USB Disk, the storage size could be much larger.

LED

- When the system boots up and mount the USB Disk successfully, the USB LED will be on. Since the system doesn't support hot plug-unplug, the LED won't be turned off.

Appendix III – How to make off-Net Calls (PSTN calls)

There are two ways to make the off-net calls (call to PSTN numbers). One is via other proxy server and the other is via the local FXO gateway.

For method one, the PX0050 needs to register to a sip proxy server provided by a service provider, this could be configured in the **Proxy Server** page (see section 4.2). The following web page is an example of setting PX0050 to register to a proxy server “sip.gossiptel.com”, and this service is named “gossiptel”.


The screenshot shows the configuration page for a PBX system. On the left is a navigation menu with items like Status, Network Setup, DHCP Server, IP PBX, System, Proxy Server, Call Route, Call Status, Users Mgmt, Block List, CDR, Service Digit List, NAT Advanced, Log, and Management. The main content area has several sections:

- Stun Server:** Includes checkboxes for Enable (checked), Stun Server (stun.fwdnet.net), Stun Port (3478), and Connection Status (green icon).
- Signaling Keep Alive:** Includes checkboxes for SIP Keep Alive Enable (checked) and SIP Keep Alive Period (20).
- Register Expire:** Register Expire Period is set to 3500 seconds (50~65535).
- Proxy Server:** A table with columns: Reg, Name, User Name, Password, Auth. ID, Proxy IP, Proxy Port, *Outbound Proxy Enable, *Outbound Proxy ID, *Outbound Proxy Port, DID, and Action. One entry is shown for 'gossiptel' with Proxy IP 'sip.gossiptel.com' and Proxy Port '5060'. Below the table are 'Delete', 'Add', and 'Apply' buttons.

A note at the bottom states: "*: If the PBX's WAN has the private IP address, you need to config these fields."

Since a PX0050 could register to up to eight different proxy servers, so, there must be a way to direct a call to go to the correct proxy server you desired to use. This is done through the **Call Route** settings (see section 4.3). For example, as depicted in the following web page of a call route setting, if you want to make the off-net call via “gossiptel” proxy server, you have to dial 9 followed by the PSTN phone number. The PX0050 will direct this call to the “gossiptel” proxy server and drop digit 9 before sending the telephone number to the proxy server. The “gossiptel” proxy server will then call to the correct PSTN phone number.

In the reverse direction, if any user of the public proxy server dials into PX0050 by calling the PX0050’s registered number, this call will enter into the **Auto Attendant** announcement of PX0050 or the selected user.




The image shows a web-based configuration interface for an IP PBX system. On the left is a vertical navigation menu with the following items: Status, Network Setup, DHCP Server, IP PBX (selected), System, Proxy Server, Call Route (highlighted in red), Call Status, Users Mgmt., Block List, CDR, Service Digit List, NAT Advanced, Log, and Management (with sub-items: Remote Mgmt., Password, Upgrade). The main content area is titled "Call Route (Dial Plan)" and features a table with the following data:

	Pattern	Destination	Drop Digits	Prefix	Action
	default route		0		Edit
<input type="checkbox"/>	9.	gossiptel	1		Edit

Below the table are three buttons: [Delete](#), [Add](#), and [Apply](#).

The second method is to put a FXO gateway in the LAN network and there could be two methods for configuring PX0050 to do the PSTN call:

- a. Configure the FXO gateway to register to PX0050. If the FXO gateway registered to PX0050 with the registered number as 0, then, any extension IP Phone can dial 0# to first connect to the gateway, and then dial the desired PSTN number. This is a two-stage dialing.
- b. If you want to configure a one-stage dialing, a call route with destination IP address pointed to the FXO gateway must be added in the **“Call Route”** list. The following figure shows the sample configuration. In this way, the FXO gateway does not need to register to PX0050.



Appendix IV –Auto Attendant Announcement

PX0050 provides the **Auto Attendant** function. When a registered IP Phone calls the **Auto Attendant Number** (9997) or other user dials into the number that is registered to other proxy server, the **Auto Attendant** announcement will be heard.

There are six default auto attendant messages as following:

1. Welcome message: Welcome to VanAccess Technology, please dial the extension number or press 9 for operator, for native language service please press 0.
2. Busy message: Sorry, the extension number cannot be recognized, please check again or wait for operator.
3. Off-duty message: We are sorry we cannot take your call now, please dial the extension number, or press 0 for native language service.
4. Chinese welcome message.
5. Chinese invalid message.
6. Chinese after business hour message.

If you want to record your customized auto attendant messages, you can press **9990** to record your messages.

Appendix V – Make a Call via HTTP CGI

PX0050 allows the user to make a call via the HTTP CGI. You can type in the following cgi string in the web browser.

<http://ipaddress/goform/call.asp?from=<exten>&to=<callerid>&timeout=<seconds>>

<http://ipaddress/goform/hangup.asp?from=<exten>>

For example, you want to make a call from extension 102 to 5781019. You can type the following cgi string. The system will ring the 102 firstly. After the extension 102 has pickup the call, the system will ring 5781019. If the callee has not pickup the call in 30 seconds, the system will terminate the call.

<http://192.168.1.1/goform/call.asp?from=102&to=5781019&timeout=30>

To hang up the call, you have to type the following cgi string.

<http://192.168.1.1/goform/hangup.asp?from=102>

Appendix VI – Call Park Procedures

We'll demonstrate how to do the Call Park with SJ Phone in this appendix. SJ Phone is the soft phone developed by SJ Labs. You can find the document from <http://www.sjlabs.com/sjp.html>. Of course you can use other soft phones to do the call park function without any problem.

Before you go into the following steps, we assume that you have installed the SJ phone and registered to the PX0050 successfully. SJ Phone only supports G.711 codec, so you have to set the PX0050 **Remote/PBX Codec** to G.711-uLaw or G.711-aLaw. For this demonstration, we'll set the SJ-Phone and PX0050 codec to G.711-uLaw.

Suppose we have the following architecture as Figure 4. The user 101 call 103, 103 park the call and 102 retrieve the call. We would show how 103 park the call in the following steps.





Figure 4 the architecture for demonstrating Call Park procedures

Step1: 103 have received the incoming call from user 101, Press **Accept** button to accept the call.



Step2: After you have accepted the incoming call, you will see the following display.



Step3: Press **Hold** button to hold the call.



Step4: Type 9 and press the **Dial** button to park the call.



Step5: Now you can see 2 phone calls shown on the screen and heard a number between 9900~9910 to retrieve the call. In this case, the retrieve number is 9900.



Step6: Now you have two calls, move the mouse to select the On-Hold 101 call.



Step7: Press the **Transfer** button and click the **9**. Now the call has been parked successfully.




Step8: You can now walk to IP Phone 102, pick up the handset and dial 9900# to retrieve the call.


Appendix VII – Upload Voice File Procedures

PX0050 allows the user to upload customized IVR or Music on Hold files via web page. If the **Remote/PBX Codec** is G.711, you can upload the .gsm file to replace the default IVR. If the **Remote/PBX Codec** is G.729, you can upload .g729 file. The upload files will be placed at the USB disk, and the file size cannot exceed 200 Kbytes.


Many shareware or software can record the voice in .gsm format. We'll use WavePad to demonstrate the recording procedures. You can find the information of WavePad in <http://www.nch.com.au/wavepad/masters.html>.

The following steps demonstrate how to record a file using the WavePad and how to use the VanAccess G.729 encoder utility to convert the uncompress wave file to .g729 file.

Step1: Press the  button




Step2: Press **OK** button




Step3: Start to record the IVR till you press  button to stop recording.




Step4: Move the mouse to the upper-right corner of the window, and close the recording window.




Step5: Click on  to play the voice.




Step6: Move the mouse to File and select **Save File As...** menu to save the voice.



Step7: Type in the filename, select the extension to .GSM, and press **Save** button to save the file.




Step8: Type in the filename, select the extension to .Wave, and press **Save** button to save the file.



Step9: Choose the 8 kHz, 16 bits, Mono, 15 kb/second, PCM, and press **OK** button to save the file. This will be the uncompressed wave file format.



Step10: Then you can use G.729 encoder to convert the uncompress wave file to .g729 file.



```
命令提示字元
C:\temp>encoder ivr.wav ivr.g729

-----
*****   Wave to G.729   *****
-----   Version 1.0   -----

450 frames processed
Input wave file: ivr.wav, size: 72000
Output 729 file: ivr.g729, size: 4500

C:\temp>_
```


Appendix VIII – How to Setup a FXO Gateway

You can connect the FXO gateway to the LAN or WAN side of PX0050. We recommend you to connect to the PX0050 LAN side. There are many brands of FXO gateways that can connect to the PX0050. We don't want to demonstrate how to configure all the gateways to work with PX0050. We just use Occtel Gateway as an example to show the configurations. If you have problem in configuring your FXO gateway, please ask the customer service of your Gateway vendors.

The FXO physical ports don't need to register to PX0050 as the users. You just need to follow the following three steps.

1. [PX0050] Add the one FXO gateway entry in **4.3**
2. [FXO] Set the **Hot Line No.** of each port to 9997 that is the auto attendant number of PX0050.

Line	Enable	Type	Hot Line	Hot Line No.	Warm Line (Hot Line Delay) [0 - 60 s]	Dial-Out Prefix	FXO Line Default Dial-Out	Fax / Modern
1	<input checked="" type="checkbox"/>	FXO	<input checked="" type="checkbox"/>	9997	0			T.38 Fax
2	<input checked="" type="checkbox"/>	FXO	<input checked="" type="checkbox"/>	9997	0			T.38 Fax
3	<input checked="" type="checkbox"/>	FXO	<input checked="" type="checkbox"/>	9997	0			T.38 Fax
4	<input checked="" type="checkbox"/>	FXO	<input checked="" type="checkbox"/>	9997	0			T.38 Fax

Trunk Hunting Order	First Idle		
Enable FXO / Trunk Extension Number	<input checked="" type="checkbox"/>	Pick up Line by Dialing Extension Number	<input checked="" type="checkbox"/>
Wait for Caller ID before FXO / Trunk pick up	<input checked="" type="checkbox"/>		
Transit In Busy Tone Limit [0 - 60 s]	3		
Ring (Early Media) Time Limit [10 - 600 s]	90		
Enable End of Digit Tone	<input type="checkbox"/>		
VoIP Call Out Notification	<input type="checkbox"/>		
Enable Built-in Call Hold Music	<input checked="" type="checkbox"/>		
Force Calling Thru PSTN Code			
Trunk Early Media Option	One Way Voice		

3. [FXO] Check on the checkbox of **Enable SIP Proxy 1**. Fill in the LAN IP of PX0050 to **Proxy Server IP/Domain** and fill in the server port of PX0050 to **Proxy Server Port**

<input checked="" type="checkbox"/> Enable Support of SIP Proxy Server / Soft Switch			
<input checked="" type="checkbox"/> Enable SIP Proxy 1			
Proxy Server IP / Domain	<input type="text" value="192.168.8.254"/>	Proxy Server Port [1 - 65535]	<input type="text" value="5060"/>
Proxy Server Realm	<input type="text"/>	TTL (Registration interval) [10 - 7200 s]	<input type="text" value="600"/>
SIP Domain	<input type="text"/>	Use Domain to Register	<input type="checkbox"/>
<input type="checkbox"/> Enable SIP Proxy 2			
Proxy Server IP / Domain	<input type="text"/>	Proxy Server Port [1 - 65535]	<input type="text" value="5060"/>
Proxy Server Realm	<input type="text"/>	TTL (Registration interval) [10 - 7200 s]	<input type="text" value="600"/>
SIP Domain	<input type="text"/>	Use Domain to Register	<input type="checkbox"/>
VoIP failure announcement	<input type="checkbox"/>		
Bind Proxy Interval for NAT [0 - 180 s]	<input type="text" value="0"/>		
Initial Unregister	<input type="checkbox"/>		