

Part No. 300867-G
November 2000

4401 Great America Parkway
Santa Clara, CA 95054

Setting Up the BayStack Instant Internet 400 Unit

NORTEL
NETWORKS™

Copyright © 2000 Nortel Networks

All rights reserved. November 2000.

The information in this document is subject to change without notice. The statements, configurations, technical data, and recommendations in this document are believed to be accurate and reliable, but are presented without express or implied warranty. Users must take full responsibility for their applications of any products specified in this document. The information in this document is proprietary to Nortel Networks NA Inc.

Trademarks

NORTEL NETWORKS is a trademark of Nortel Networks.

BayStack, Instant Internet, and the Nortel Networks logo are trademarks of Nortel Networks.

All other trademarks and registered trademarks are the property of their respective owners.

Statement of conditions

In the interest of improving internal design, operational function, and/or reliability, Nortel Networks NA Inc. reserves the right to make changes to the products described in this document without notice.

Nortel Networks NA Inc. does not assume any liability that may occur due to the use or application of the product(s) or circuit layout(s) described herein.

USA requirements only

Federal Communications Commission (FCC) Compliance Notice: Radio Frequency Notice

Note: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy. If it is not installed and used in accordance with the instruction manual, it may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case users will be required to take whatever measures may be necessary to correct the interference at their own expense.

European requirements only

EN 55 022 statement

This is to certify that the Nortel Networks BayStack Instant Internet 400 is shielded against the generation of radio interference in accordance with the application of Council Directive 89/336/EEC, Article 4a. Conformity is declared by the application of EN 55 022 Class A (CISPR 22).

Warning: This is a Class A product. In a domestic environment, this product may cause radio interference, in which case, the user may be required to take appropriate measures.

Achtung: Dieses ist ein Gerät der Funkstörgrenzwertklasse A. In Wohnbereichen können bei Betrieb dieses Gerätes Rundfunkstörungen auftreten, in welchen Fällen der Benutzer für entsprechende Gegenmaßnahmen verantwortlich ist.

Attention: Ceci est un produit de Classe A. Dans un environnement domestique, ce produit risque de créer des interférences radioélectriques, il appartiendra alors à l'utilisateur de prendre les mesures spécifiques appropriées.

EC Declaration of conformity

This product conforms to the provisions of the R&TTE Directive 1999/5/EC.

Japan/Nippon requirements only

Voluntary Control Council for Interference (VCCI) Statement

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラス A 情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

Taiwan requirements

Bureau of Standards, Metrology and Inspection (BSMI) Statement

警告使用者:

這是甲類的資訊產品，在居住的環境中使用時，可能會造成射頻干擾，在這種情況下，使用者會被要求採取某些適當的對策。

Canada requirements only

Canadian Department of Communications Radio Interference Regulations

This digital apparatus (BayStack Instant Internet 400) does not exceed the Class A limits for radio-noise emissions from digital apparatus as set out in the Radio Interference Regulations of the Canadian Department of Communications.

Règlement sur le brouillage radioélectrique du ministère des Communications

Cet appareil numérique (BayStack Instant Internet 400) respecte les limites de bruits radioélectriques visant les appareils numériques de classe A prescrites dans le Règlement sur le brouillage radioélectrique du ministère des Communications du Canada.

Canada CS-03 rules and regulations

Notice: The Industry Canada label identifies certified equipment. This certification means that the equipment meets telecommunications network protective, operational and safety requirements as prescribed in the appropriate Terminal Equipment Technical Requirements document(s). The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent the degradation of service in some situations.

Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

Notice: For equipment using loopstart lines, please note that the Ringer Equivalence Number (REN) assigned to each terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5. The REN is located on the "FCC Rules Part 68" label located on the bracket of the module or on the back of the unit.

Canada CS-03 -- Règles et règlements

Avis: L'étiquette d'Industrie Canada identifie le matériel homologué. Cette étiquette certifie que le matériel est conforme aux normes de protection, d'exploitation et de sécurité des réseaux de télécommunications, comme le prescrivent les documents concernant les exigences techniques relatives au matériel terminal. Le Ministère n'assure toutefois pas que le matériel fonctionnera à la satisfaction de l'utilisateur.

Avant d'installer ce matériel, l'utilisateur doit s'assurer qu'il est permis de le raccorder aux installations de l'entreprise locale de télécommunication. Le matériel doit également être installé en suivant une méthode acceptée de raccordement. L'abonné ne doit pas oublier qu'il est possible que la conformité aux conditions énoncées ci-dessus n'empêche pas la dégradation du service dans certaines situations.

Les réparations de matériel homologué doivent être coordonnées par un représentant désigné par le fournisseur. L'entreprise de télécommunications peut demander à l'utilisateur de débrancher un appareil à la suite de réparations ou de modifications effectuées par l'utilisateur ou à cause de mauvais fonctionnement.

Pour sa propre protection, l'utilisateur doit s'assurer que tous les fils de mise à la terre de la source d'énergie électrique, des lignes téléphoniques et des canalisations d'eau métalliques, s'il y en a, sont raccordés ensemble. Cette précaution est particulièrement importante dans les régions rurales.

Avertissement: L'utilisateur ne doit pas tenter de faire ces raccordements lui-même; il doit avoir recours à un service d'inspection des installations électriques, ou à un électricien, selon le cas.

Avis: Veuillez prendre note que pour tout appareillage supportant des lignes de type "loopstart," l'indice d'équivalence de la sonnerie (IES) assigné à chaque dispositif terminal indique le nombre maximal de terminaux qui peuvent être raccordés à une interface. La terminaison d'une interface téléphonique peut consister en une combinaison de quelques dispositifs, à la seule condition que la somme d'indices d'équivalence de la sonnerie de tous les dispositifs n'excède pas 5. Le REN figure sur l'étiquette "FCC Rules Part 68" située sur le support du module ou à l'arrière de l'unité.

Nortel Networks NA Inc. software license agreement

NOTICE: Please carefully read this license agreement before copying or using the accompanying software or installing the hardware unit with pre-enabled software (each of which is referred to as "Software" in this Agreement). BY COPYING OR USING THE SOFTWARE, YOU ACCEPT ALL OF THE TERMS AND CONDITIONS OF THIS LICENSE AGREEMENT. THE TERMS EXPRESSED IN THIS AGREEMENT ARE THE ONLY TERMS UNDER WHICH NORTEL NETWORKS WILL PERMIT YOU TO USE THE SOFTWARE. If you do not accept these terms and conditions, return the product, unused and in the original shipping container, within 30 days of purchase to obtain a credit for the full purchase price.

1. License grant. Nortel Networks NA Inc. ("Nortel Networks") grants the end user of the Software ("Licensee") a personal, nonexclusive, nontransferable license: a) to use the Software either on a single computer or, if applicable, on a

single authorized device identified by host ID, for which it was originally acquired; b) to copy the Software solely for backup purposes in support of authorized use of the Software; and c) to use and copy the associated user manual solely in support of authorized use of the Software by Licensee. This license applies to the Software only and does not extend to Nortel Networks Agent software or other Nortel Networks software products. Nortel Networks Agent software or other Nortel Networks software products are licensed for use under the terms of the applicable Nortel Networks NA Inc. Software License Agreement that accompanies such software and upon payment by the end user of the applicable license fees for such software.

2. Restrictions on use; reservation of rights. The Software and user manuals are protected under copyright laws. Nortel Networks and/or its licensors retain all title and ownership in both the Software and user manuals, including any revisions made by Nortel Networks or its licensors. The copyright notice must be reproduced and included with any copy of any portion of the Software or user manuals. Licensee may not modify, translate, decompile, disassemble, use for any competitive analysis, reverse engineer, distribute, or create derivative works from the Software or user manuals or any copy, in whole or in part. Except as expressly provided in this Agreement, Licensee may not copy or transfer the Software or user manuals, in whole or in part. The Software and user manuals embody Nortel Networks' and its licensors' confidential and proprietary intellectual property. Licensee shall not sublicense, assign, or otherwise disclose to any third party the Software, or any information about the operation, design, performance, or implementation of the Software and user manuals that is confidential to Nortel Networks and its licensors; however, Licensee may grant permission to its consultants, subcontractors, and agents to use the Software at Licensee's facility, provided they have agreed to use the Software only in accordance with the terms of this license.

3. Limited warranty. Nortel Networks warrants each item of Software, as delivered by Nortel Networks and properly installed and operated on Nortel Networks hardware or other equipment it is originally licensed for, to function substantially as described in its accompanying user manual during its warranty period, which begins on the date Software is first shipped to Licensee. If any item of Software fails to so function during its warranty period, as the sole remedy Nortel Networks will at its discretion provide a suitable fix, patch, or workaround for the problem that may be included in a future Software release. Nortel Networks further warrants to Licensee that the media on which the Software is provided will be free from defects in materials and workmanship under normal use for a period of 90 days from the date Software is first shipped to Licensee. Nortel Networks will replace defective media at no charge if it is returned to Nortel Networks during the warranty period along with proof of the date of shipment. This warranty does not apply if the media has been damaged as a result of accident, misuse, or abuse. The Licensee assumes all responsibility for selection of the Software to achieve Licensee's intended results and for the installation, use, and results obtained from the Software. Nortel Networks does not warrant a) that the functions contained in the software will meet the Licensee's requirements, b) that the Software will operate in the hardware or software combinations that the Licensee may select, c) that the operation of the Software will be uninterrupted or error free, or d) that all defects in the operation of the Software will be corrected. Nortel Networks is not obligated to remedy any Software defect that cannot be reproduced with the latest Software release. These warranties do not apply to the Software if it has been (i) altered, except by Nortel Networks or in accordance with its instructions; (ii) used in conjunction with another vendor's product, resulting in the defect; or (iii) damaged by improper environment, abuse, misuse, accident, or negligence. THE FOREGOING WARRANTIES AND LIMITATIONS ARE EXCLUSIVE REMEDIES AND ARE IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Licensee is responsible for the security of its own data and information and for maintaining adequate procedures apart from the Software to reconstruct lost or altered files, data, or programs.

4. Limitation of liability. IN NO EVENT WILL NORTEL NETWORKS OR ITS LICENSORS BE LIABLE FOR ANY COST OF SUBSTITUTE PROCUREMENT; SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES; OR ANY DAMAGES RESULTING FROM INACCURATE OR LOST DATA OR LOSS OF USE OR PROFITS ARISING OUT OF OR IN CONNECTION WITH THE PERFORMANCE OF THE SOFTWARE, EVEN IF NORTEL NETWORKS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN NO EVENT SHALL THE LIABILITY OF NORTEL NETWORKS RELATING TO THE SOFTWARE OR THIS AGREEMENT EXCEED THE PRICE PAID TO NORTEL NETWORKS FOR THE SOFTWARE LICENSE.

5. Government licensees. This provision applies to all Software and documentation acquired directly or indirectly by or on behalf of the United States Government. The Software and documentation are commercial products, licensed on the

open market at market prices, and were developed entirely at private expense and without the use of any U.S. Government funds. The license to the U.S. Government is granted only with restricted rights, and use, duplication, or disclosure by the U.S. Government is subject to the restrictions set forth in subparagraph (c)(1) of the Commercial Computer Software—Restricted Rights clause of FAR 52.227-19 and the limitations set out in this license for civilian agencies, and subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause of DFARS 252.227-7013, for agencies of the Department of Defense or their successors, whichever is applicable.

6. Use of Software in the European Community. This provision applies to all Software acquired for use within the European Community. If Licensee uses the Software within a country in the European Community, the Software Directive enacted by the Council of European Communities Directive dated 14 May, 1991, will apply to the examination of the Software to facilitate interoperability. Licensee agrees to notify Nortel Networks of any such intended examination of the Software and may procure support and assistance from Nortel Networks.

7. Term and termination. This license is effective until terminated; however, all of the restrictions with respect to Nortel Networks' copyright in the Software and user manuals will cease being effective at the date of expiration of the Nortel Networks copyright; those restrictions relating to use and disclosure of Nortel Networks' confidential information shall continue in effect. Licensee may terminate this license at any time. The license will automatically terminate if Licensee fails to comply with any of the terms and conditions of the license. Upon termination for any reason, Licensee will immediately destroy or return to Nortel Networks the Software, user manuals, and all copies. Nortel Networks is not liable to Licensee for damages in any form solely by reason of the termination of this license.

8. Export and re-export. Licensee agrees not to export, directly or indirectly, the Software or related technical data or information without first obtaining any required export licenses or other governmental approvals. Without limiting the foregoing, Licensee, on behalf of itself and its subsidiaries and affiliates, agrees that it will not, without first obtaining all export licenses and approvals required by the U.S. Government: (i) export, re-export, transfer, or divert any such Software or technical data, or any direct product thereof, to any country to which such exports or re-exports are restricted or embargoed under United States export control laws and regulations, or to any national or resident of such restricted or embargoed countries; or (ii) provide the Software or related technical data or information to any military end user or for any military end use, including the design, development, or production of any chemical, nuclear, or biological weapons.

9. General. If any provision of this Agreement is held to be invalid or unenforceable by a court of competent jurisdiction, the remainder of the provisions of this Agreement shall remain in full force and effect. This Agreement will be governed by the laws of the state of California.

Should you have any questions concerning this Agreement, contact Nortel Networks, 4401 Great America Parkway, P.O. Box 58185, Santa Clara, California 95054-8185.

LICENSEE ACKNOWLEDGES THAT LICENSEE HAS READ THIS AGREEMENT, UNDERSTANDS IT, AND AGREES TO BE BOUND BY ITS TERMS AND CONDITIONS. LICENSEE FURTHER AGREES THAT THIS AGREEMENT IS THE ENTIRE AND EXCLUSIVE AGREEMENT BETWEEN NORTEL NETWORKS AND LICENSEE, WHICH SUPERSEDES ALL PRIOR ORAL AND WRITTEN AGREEMENTS AND COMMUNICATIONS BETWEEN THE PARTIES PERTAINING TO THE SUBJECT MATTER OF THIS AGREEMENT. NO DIFFERENT OR ADDITIONAL TERMS WILL BE ENFORCEABLE AGAINST NORTEL NETWORKS UNLESS NORTEL NETWORKS GIVES ITS EXPRESS WRITTEN CONSENT, INCLUDING AN EXPRESS WAIVER OF THE TERMS OF THIS AGREEMENT.

Modular components used in this assembly

This product contains a base unit and possibly one or more of the following Communication and Network Connection Options Devices. Please refer to your specific product for a description of what option cards (if any) are included. Compliance Statements for all the following devices are on file and available on request.

FCC Part 68 compliance statement

This equipment complies with Part 68 of FCC Rules. All direct connections to telephone network lines must be made using standard plugs and jacks compliant with FCC Part 68. Please note the following:

1. You are required to request service from the telephone company before you connect the unit to a network. When you request service, you must provide the telephone company with the following data:

When you request T1 Service, you must provide the telephone company with:

- The Facility Interface Code

Provide the telephone company with all the codes below:

- 04DU9-BN (1.544 MB, D4 framing format)
- 04DU9-DN (1.544 MB, D4 framing format with B8ZS coding)
- 04DU9-1KN (1.544 MB, ESF framing format)
- 04DU9-ISN (1.544 MB, ESF framing format with B8ZS coding)

The telephone company will select the code it has available.

- The Service Order Code(s) (SOC): 6.0F
- The required Universal Service Order Code (USOC) jack: RJ48C

When you request 56K/64K Service, you must provide the telephone company with:

- The Facility Interface Code: 04DU5-56/64
- The Service Order Code(s) (SOC): 6.0F

When you request 56K/64K Service, you must provide the telephone company with:

- The Facility Interface Code: 04DU5-56/64
- The Service Order Code(s) (SOC): 6.0F
- The required Universal Service Order Code (USOC) jack: RJ48S

When you request V.34 Service, you must provide the telephone company with:

- The required Universal Service Order Code (USOC) jack: RJ11C
- The make, model number, Ringer Equivalence Number (REN), and FCC Registration number of the unit

The REN helps you determine the number of devices you can connect to your telephone line and still have all of those devices ring when your number is called. In most, but not all, areas, the sum of the RENs of all devices should not exceed 5.0. To be certain of the number of devices you can connect to your line, you should call your local telephone company to determine the maximum REN for your calling area.

When you request ISDN "U" Interface Service, you must provide the telephone company with:

- The Facility Interface Code: 02IS5
- The Service Order Code(s) (SOC): 6.0F
- The required Universal Service Order Code (USOC) jack: RJ49C

When you request ISDN "S/T" Interface Service, you must provide the telephone company with:

- The Service Order Code(s) (SOC): 6.0N
- The make, model number, and FCC Registration number of the NT1

Note the following:

- The ISDN S/T cannot be directly connected to the network.
- The V.35 cannot be connected to the PSTN.
- The X.21 cannot be connected to the PSTN.

2. Your telephone company may make changes to its facilities, equipment, operation, or procedures that could affect the proper functioning of your equipment. The telephone company will notify you in advance of such changes to give you an opportunity to maintain uninterrupted telephone service.
3. If the unit causes harm to the telephone network, the telephone company may temporarily discontinue your service. If possible, they will notify you in advance, but, if advance notice is not practical, you will be notified as soon as possible and will be informed of your right to file a complaint with the FCC.
4. You are required to notify the telephone company when you disconnect the unit from the network.

UL listing/C-UL listing

This information technology equipment is UL-Listed and C-UL-Listed for the uses described in this and accompanying documents.

Connecting an Instant Internet unit to the network

Important safety information

To avoid contact with electrical current:

- Never install electrical wiring during an electrical storm
- Never install telephone jacks in wet locations unless that jack is specifically designed for wet locations
- Use caution when installing or modifying telephone lines
- Use a screwdriver and other tools with insulated handles
- You and those around you should wear safety glasses or goggles
- Do not place telephone wiring or connections in any conduit, outlet or junction box containing electrical wiring

Warning: Do not work on your telephone wiring if you wear a pacemaker. Telephone lines carry electrical current.

Installation of inside wire may bring you close to electrical wire, conduit, terminals and other electrical facilities. Extreme caution must be used to avoid electrical shock from such facilities. You must avoid contact with all such facilities.

- Telephone wiring must be at least 6 feet from bare power wiring or lightning rods and associated wires, and at least 6 inches from other wire (antenna wires, doorbell wires, wires from transformers to neon signs), steam or hot water pipes, and heating ducts.
- Before working with existing inside wiring, check all electrical outlets for a square telephone dial light transformer and unplug it from the electrical outlet. Failure to unplug all telephone transformers can cause electrical shock.
- Do not place a jack where it would allow a person to use the telephone while in a bathtub, shower, swimming pool, or similar hazardous location.
- Protectors and grounding wire placed by the service provider must not be connected to, removed, or modified by the customer.

Specific information related to different types of communication connections

Connecting an Instant Internet unit containing an analog modem

It is not necessary to notify the telephone company before installing the modem. However, the telephone company may request the telephone number(s) to which the unit is connected and the related FCC information including the FCC Part 68 registration number and the ringler equivalence number.

Be sure that the telephone line you are connecting the modem to is a standard analog line and not a digital (PBX), party, or coin telephone line. If the modem is malfunctioning, it may affect the telephone lines. In this case, disconnect the modem until the source of the difficulty is traced.

Connecting an Instant Internet unit containing an ISDN modem with NT


When connecting this version of the product to the network, avoid contact with the Telecommunications lead wire. Telephone wiring can carry dangerous voltage from electrical faults or lightning.

The product is equipped with a standard 8-pin RJ-49C jack for connection to the ISDN network.

If you need to add wiring to your facility, refer to the National ISDN Users Forum document NIUF 433-94 ISDN Wiring and Powering Guidelines (Residence and Small Business).

Connecting an Instant Internet unit containing an ISDN modem without NT1

This version of the product is equipped with two standard 8-pin RJ-45 jacks for connection to the NT1 (the BRI line can be attached to either jack, and the unused jack can be used to connect a second ISDN device).



9611EA

At the product interface point, the interface cable must be wired “straight-through” (pin 1 at one end connected to pin 1 at the other end, pin 2 to pin 2, etc.), and must have at least the middle 4 pins (pins 2, 3, 4, and 5) connected. The cables included in your package are wired in this fashion.

Your NT1 must be properly connected to your ISDN service; check with your service provider.

If you need to add wiring to your facility, refer to the National ISDN Users Forum document NIUF 433-94 ISDN Wiring and Powering Guidelines (Residence and Small Business).

Avis: L'étiquette d'Industri Canada identifie le matériel homologué. Cette étiquette certifie que le matériel est conforme à certaines normes de protection, d'exploitation et de sécurité des réseaux de télécommunications. Toutefois, le Ministère n'assure pas que le matériel fonctionnera à la satisfaction de l'utilisateur.

Avant d'installer ce matériel, l'utilisateur doit assurer qu'il soit permis de le raccorder aux installations de l'entreprise locale de télécommunications. Le matériel doit également être installé en suivant une méthode de raccordement acceptée. Dans certains cas, les fils intérieurs de l'entreprise utilisés pour un service individuel à ligne unique peuvent être prolongés au moyen d'un dispositif de raccordement homologué (cordon rallonge téléphonique interne). L'abonné ne doit pas oublier qu'il est possible que la conformité aux conditions énoncées ci-dessus n'empêchent pas la dégradation du service dans certaines situations. Actuellement, les entreprises de télécommunication ne permettent pas que l'on raccorde leur matériel à des jacks d'abonné, sauf dans les cas précis prévus par les tarifs particuliers de ces entreprises.

Les réparations de matériel homologué doivent être effectuées par un centre d'entretien canadien autorisé désigné par le fournisseur. La compagnie de télécommunications peut demander à l'utilisateur de débrancher un appareil à la suite de réparations ou de modifications effectuées par l'utilisateur, ou à cause de mauvais fonctionnement.

Pour sa propre protection, l'utilisateur doit assurer que tous les fils de mise à la terre de la source d'énergie électrique, des lignes téléphoniques et des canalisations d'eau métalliques, s'il y en a, sont raccordés ensemble. Cette précaution est particulièrement importante dans les régions rurales.

Avertissement: L'utilisateur ne doit pas tenter de faire ces raccordements lui-même; il doit avoir recours aux services d'un électricien.

L'indice de charge (IC) assigné à chaque dispositif terminal indiqué, pour éviter toute surcharge, le pourcentage de la charge totale qui peut être raccordée à un circuit téléphonique bouclé utilisé par ce dispositif. La terminaison du circuit bouclé peut être constituée de n'importe quelle combinaison de dispositifs, pourvu que la somme des indices de charge de l'ensemble des dispositifs ne dépasse pas 100.

L'indice de charge se trouve sur le modem.

Contents

Preface	17
Before you begin	17
Acronyms	18
Related publications	19
How to get help	20
Chapter 1	
Introduction	21
Instant Internet package	21
Available options	22
Requirements and compatibility	23
Chapter 2	
Installation preparation	25
Preparing for Internet access	25
Making decisions	26
Selecting an Internet service provider	26
Installation checklist	27
Installation worksheet	29
Chapter 3	
Instant Internet 400 hardware installation	31
Getting to know your Instant Internet 400 unit	31
Instant Internet quick installation	35
Mounting your Instant Internet unit in a rack	37

Chapter 4	
DIP switch settings	41
DIP switches	41
Switch settings for normal operation	42
Switch settings for token ring speed	42
Single token ring switch settings	42
Dual token ring switch settings	43
Switch settings for special configurations	44
Resetting your Instant Internet unit	46
Chapter 5	
LEDs: support and diagnostic functions	47
Interpreting LEDs	47
LEDs at power-up sequence	47
Recognizing single token ring speed	48
Recognizing dual token ring speed	48
LEDs during operation	49
Appendix A	
Technical specifications	51
Physical specifications	51
Environmental specifications	51
Appendix B	
Adapter cable pinout diagrams	53
Adapter cable part numbers	53
V.35 adapter cable	54
X.21 (DCE) adapter cable	55
Index	57

Figures

Figure 1	Front panel of the Instant Internet 400 unit	31
Figure 2	Rear panel of the Instant Internet 400 unit	32
Figure 3	Removing screws from cover of Instant Internet 400 unit	38
Figure 4	Attaching mounting brackets to the Instant Internet 400 unit	38
Figure 5	Attaching the Instant Internet 400 unit to the front of the rack	39
Figure 6	DIP switches on the rear panel of the unit	41
Figure 7	V.35 adapter cable pinout diagram	54
Figure 8	X.21 (DCE) adapter cable diagram.	55

Tables

Table 1	Installation checklist	27
Table 2	LAN interfaces	33
Table 3	Communication interfaces	34
Table 4	Switch settings for normal operation	42
Table 5	Single token ring: 16 Mb/s	42
Table 6	Single token ring: 4 Mb/s	42
Table 7	Dual token ring: 16 Mb/s Tok1 / 16 Mb/s Tok2	43
Table 8	Dual token ring: 16 Mb/s Tok1 / 4 Mb/s Tok2	43
Table 9	Dual token ring: 4 Mb/s Tok1 / 16 Mb/s Tok2	43
Table 10	Dual token ring: 4 Mb/s Tok1 / 4 Mb/s Tok2	43
Table 11	Switch settings for resetting the password	44
Table 12	Switch settings for resetting the password and user-defined configurations	44
Table 13	Switch settings to disable switch settings for resetting the password and user-defined configurations	45
Table 14	Switch settings for restoring factory default conditions	45
Table 15	Single token ring speed (first 30 seconds)	48
Table 16	Dual token ring (Tok1) speed (first 30 seconds)	48
Table 17	Dual token ring (Tok2) speed (first 30 seconds)	48
Table 18	LED status and appearance during operation	49

Preface

This guide describes the BayStack™ Instant Internet 400 unit. This guide also describes what you do to install the Instant Internet™ hardware and to access the Internet.

Before you begin

Before using this guide, you need to do two things. First, write down the model number and serial number of your Instant Internet unit. You will need this information if you call Nortel Networks Technical Support. Model and serial numbers are located on the rear panel of your Instant Internet unit.

Model #: _____

Example: CQ1001078

Serial #: _____

Example: I0200004F

Second, you must complete the steps outlined in [Chapter 2, “Installation preparation,” on page 25](#). The steps include:

- 1 Preparing for Internet access
- 2 Selecting an Internet service provider
- 3 Selecting the type of connection to use

Acronyms

The following acronyms are used in this guide:

AC	alternating current
AUI	attachment unit interface
CHAP	Challenge Handshake Authentication Protocol
CSU	channel service unit
dBA	decibels audible
DIP	Dual Inline Pins
DSL	digital subscriber lines
DSU	digital (or data) service unit
IP	Internet Protocol
ISDN	Integrated Services Digital Network
ISP	Internet service provider
Kb/s	kilobits per second
LAN	local area network
LED	light-emitting diode
Mb/s	megabits per second
MP	Multilink Protocol
NAT	Network Address Translation
NT1	Network termination type 1
PAP	Password Authentication Protocol
POP	point of presence
PPP	Point-to-Point Protocol
PPPoE	Point-to-Point Protocol over Ethernet
PVC	permanent virtual circuit
ROM	read-only memory
WAN	wide area network

Related publications

For more information about using Instant Internet, refer to the following publications:

- *Important Notice for the BayStack Instant Internet Version 7.11*
(Part number 307603-E)

Provides instructions for viewing documentation and installing the Instant Internet software and third-party applications (Adobe Acrobat Reader, Netscape Communicator, and AniTa Terminal Emulator).
- *Installing the BayStack Instant Internet Management Software Version 7.11*
(Part number 209226-B)

Provides instructions for installing the Instant Internet software.
- *Using the BayStack Instant Internet Management Software Version 7.11*
(Part number 300868-G)

Provides an introduction to Instant Internet, instructions for administering the product, and procedures for using Instant Internet features.
- *Reference for the BayStack Instant Internet Remote Access Commands Version 7.11* (Part number 302005-F)

Provides instructions and commands for remotely accessing Instant Internet.
- *BayStack Instant Internet Software and Documentation Version 7.11 CD*
(Part number 206664-D)

Provides manuals for using and installing the Instant Internet software and third-party applications. The CD contains the following documents:
 - *Installing the BayStack Instant Internet Management Software Version 7.11*
 - *Setting Up the BayStack Instant Internet 100 Unit*
 - *Setting Up the BayStack Instant Internet 100-S Unit*
 - *Setting Up the BayStack Instant Internet 400 Unit*
 - *Setting Up the BayStack Instant Internet 400-S Unit*
 - *Using the BayStack Instant Internet Management Software Version 7.11*
 - *Reference for the BayStack Instant Internet Remote Access Commands Version 7.11*

You can print selected technical manuals and release notes free, directly from the Internet. Go to the www25.nortelnetworks.com/library/tpubs/ URL. Find the product for which you need documentation. Then locate the specific category and model or version for your hardware or software product. Use Adobe Acrobat Reader to open the manuals and release notes, search for the sections you need, and print them on most standard printers. Go to Adobe Systems at the www.adobe.com URL to download a free copy of the Adobe Acrobat Reader.

You can purchase selected documentation sets, CDs, and technical publications through the Internet at the www1.fatbrain.com/documentation/nortel/ URL.

How to get help

If you purchased a service contract for your Nortel Networks product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

If you purchased a Nortel Networks service program, contact one of the following Nortel Networks Technical Solutions Centers:

Technical Solutions Center	Telephone
EMEA	(33) (4) 92-966-968
North America	(800) 2LANWAN or (800) 252-6926
Asia Pacific	(61) (2) 9927-8800
China	(800) 810-5000

An Express Routing Code (ERC) is available for many Nortel Networks products and services. When you use an ERC, your call is routed to a technical support person who specializes in supporting that product or service. To locate an ERC for your product or service, go to the www12.nortelnetworks.com/ URL and click ERC at the bottom of the page.

Chapter 1

Introduction

This chapter introduces your Instant Internet 400 unit and describes package contents, available options for your Instant Internet unit, and any requirements and compatibility issues.

Instant Internet package

The Instant Internet package contains:

- Instant Internet 400 unit
- Depending on the type of connection you ordered, your Instant Internet package contains one or more of the following connector cables:
 - RJ-11 cable (phone cord) for a dial-up connection
 - ISDN cable for an ISDN connection
 - RJ-45 cable for a 10BASE-T or 100BASE-T Ethernet connection
 - RJ-48 cable for a T1 or DDS connection



Note: If you ordered your Instant Internet unit for use on a token ring network or with a V.35 or X.21 modem, you must provide the connection cable. For pinout diagrams for V.35 and X.21 adapter cables, refer to [Appendix B, “Adapter cable pinout diagrams,” on page 53.](#)

- *Important Notice for the BayStack Instant Internet Version 7.11*
(Part number 307603-E)
- *Installing the BayStack Instant Internet Management Software Version 7.11*
(Part number 209226-B)

- *BayStack Instant Internet Software and Documentation Version 7.11 CD* (Part number 206664-D)

For contents, see [“Related publications” on page 19](#).

Available options

The Instant Internet 400 is shipped with several options. The standard unit includes a full-duplex/half-duplex autonegotiating 10/100 megabits per second (Mb/s) Ethernet connection. Token ring units for LANs or routers are also available.

You can order your Instant Internet unit configured with one of the following:

- One or two internal V.90 analog modems
- Internal ISDN 128K card (with or without NT1)
- Internal DDS connection
- Internal T1 connection
- V.35, X.21 support of external synchronous devices (CSUs/DSUs)
- One or two token ring connections
- Second or third Ethernet connections (for an external router, cable modem, xDSL modem, and others)



Note: If your unit does not have an internal analog modem or ISDN card, disregard all references to dial-up account and dial-up configuration throughout this manual.

Requirements and compatibility

Instant Internet supports the following Internet connection types:

- Dial-up PPP connection up to V.90
- ISDN connection using synchronous PPP and optional Multilink Protocol (MP) at up to 128 kilobits per second (Kb/s)
- Synchronous leased-line connection at speeds up to 2 Mb/s (T1, DDS, V.35, or X.21) using PPP or frame relay (using RFC 1490)
- PPPoE connection using an external Ethernet device to connect to an access concentrator.



Note: The speed of dial-up connections can vary internationally. Consult your local distributor for specifications.

Chapter 2

Installation preparation

This chapter describes the steps you should follow in preparing for Internet access, explains some decisions you need to make before you install your Instant Internet 400 unit, and provides an installation checklist and worksheet.

Preparing for Internet access

To prepare for access to the Internet:

- 1 Obtain installation and service from your local telephone company.
- 2 Obtain an Internet connection from an Internet service provider (ISP).
- 3 Obtain a cable to connect the Instant Internet unit to your local area network (LAN).
- 4 Obtain the power cord from the Instant Internet packaging.



Note: Do not apply power to the Instant Internet unit until you have completed the installation steps from [page 35](#).

Refer to “[Instant Internet quick installation](#)” on [page 35](#) for more information.

Making decisions

Before you can access the Internet with your Instant Internet unit, you must make the following decisions:

- Who will be your Internet service provider (ISP)?
- What type of connection will you use—dial-up connection (analog or ISDN), leased-line connection (T1, DDS, V.35, or X.21) built in to Instant Internet, cable modem, xDSL modem, PPPoE, or an external router?

Selecting an Internet service provider

There are thousands of Internet service providers (ISPs) from which to choose. Nortel Networks maintains an updated list of the major, national ISPs and as many local ISPs as possible. You can choose an ISP from this list, or you can locate a different one. Either way, try to choose an ISP that has a local access number so that you do not have to pay long distance charges. You can look in the yellow page directory for local or regional ISPs, or you can call a national ISP and ask if it offers local dial-up access in your area.



Note: Only a dial-up connection (analog or ISDN) requires this type of service from an ISP. If you are using a cable modem, xDSL modem, or external Ethernet device, you do not have to obtain dial-up service.

If your ISP is not on the selection list you see during Instant Internet installation, select the ! `Default` provider from the list. If you cannot connect to the Internet with the ! `Default` provider selected, do *one* of the following:

- Call Nortel Networks Technical Solutions Center at 800-2LANWAN, Express Routing Code 169#, 24 hours a day, 7 days a week, 365 days a year (see [page 20](#)).
- Send an e-mail message to support@nortelnetworks.com.

Be sure to have your provider's name, location, and contact person's phone number so that Nortel Networks can create a dial-up script specific to your ISP's access requirements and add your ISP to the list.

Installation checklist

Use the checklist in [Table 1](#) to ensure a smooth installation. As you check off each item, record the information in the “[Installation worksheet](#)” on [page 29](#).

Table 1 Installation checklist

✓	Item	Description
	Type of Account	<p>Instant Internet can provide access to your entire network through a single Internet Protocol (IP) address for unlimited access to the Internet:</p> <ul style="list-style-type: none"> • If you want to use public IP addresses, request a network account. • If you want to use Network Address Translation (NAT) or you are using the Instant Internet unit as an IPX-to-IP gateway, request a single-user account. <p>Your ISP will provide you with a user name, password, primary access phone number, optional alternate access phone number, and name server IP address. Record this information on page 29.</p>
	Dial-up Protocols	<p>If you are using a dial-up connection in North America, ensure that your ISP supplies true IP service using PPP protocols for analog and ISDN connections. ISDN requires the synchronous PPP protocol with authentication via Password Authentication Protocol (PAP) or Challenge Handshake Authentication Protocol (CHAP).</p> <p>For a 128K connection, Multilink PPP must be supported. Some ISPs use their own proprietary protocols or, for ISDN, V.120 rate adaption. Instant Internet does not support these proprietary protocols.</p>
	ISDN Service	<p>When you obtain ISDN service, your telephone company may assign one or two Service Profile Identifier (SPID) numbers to your line. Record the SPID number(s) on page 29.</p>
	Leased-Line Connection	<p>Leased-line (T1, DDS, V.35, or X.21) connections require synchronous PPP or frame relay. The Instant Internet 400 unit supports 1 PVC for frame relay.</p>
	T1 Connection	<p>If you are using a T1 connection, ask your T1 service provider for the framing format, line encoding, data type, line build-out, rate multiplier, and line speed. Record this information on page 29.</p>

Table 1 Installation checklist (continued)

✓	Item	Description
	Connect-Time Charges	Some ISPs and local telephone companies charge a flat fee for unlimited connect time, and some charge fees according to the actual amount of time your Instant Internet unit is dialed in and connected. Be sure that you understand your ISP's and local telephone company's policies.
	PPPoE	If you are connecting using PPPoE, you must obtain a User Name and Password from your ISP. Record this information on page 29 .
	Installation Information	<p>If you choose an ISP from the Nortel Networks list, you need to give only the ISP's telephone number and your user name and password for access.</p> <p>If you are using an analog or ISDN connection, you can choose ! Default as your provider and then enter your name servers.</p> <p>If your ISP is not on the Nortel Networks list, call the Nortel Networks Technical Solutions Center at 800-2LANWAN, Express Routing Code 169#, and provide some additional information so that Nortel Networks can create a dial-up script specific to your ISP's access requirements.</p>
	Application Information	<p>Your ISP usually offers some additional services, which you might consider:</p> <ul style="list-style-type: none"> • Access to a NEWS server • Access to a POP mail server (and an SMTP relay) • Individual POP mail user accounts for each user <p>NOTE: Be aware that a single-user account from an ISP generally comes with only one POP e-mail account. You can arrange for additional e-mail accounts with your ISP.</p>

After completing this checklist, you are ready to begin installing the Instant Internet hardware.

Installation worksheet

ISP User Name: _____

This is the user name you enter to log on to your ISP account.

ISP Password: _____

This is the password you enter to log on to your ISP account.

ISP Connection Phone Number: _____

This number is the primary phone number you dial to access your ISP account.

ISP Connection Alternate Phone Number: _____

This number is an alternate or backup phone number you dial to access your ISP account if the primary phone number is not working. This phone number is optional. Not every ISP supplies an alternate phone number.

ISP Name Server: _____

ISP Name Server (optional): _____

The name server (or domain name server or DNS) is the numeric IP address of your ISP's name server(s). It follows the format nnn.nnn.nnn.nnn where n is a number between 0 and 255.

T1 Connection Information

Framing Format (ESF or D4): _____

Line Encoding (B8ZS or AMI): _____

Data Type (Normal or Inverted): _____

Line Build-Out (in dB): _____

Rate Multiplier (64K or 56K): _____

Line Speed (in Kb/s): _____

This information is available from your T1 service provider. If you are not using a T1 connection, you do not need to provide this information.

Telephone Company Information

ISDN SPID Number: _____

ISDN SPID Number: _____

SPID (Service Profile Identifier) numbers are provided by your telephone company when you install an ISDN line. Usually, two SPID numbers are provided, but sometimes one and sometimes even none is provided. Only those using an ISDN connection, need to provide this information.

Chapter 3

Instant Internet 400 hardware installation

This chapter helps you get to know your Instant Internet unit and provides instructions for connecting your unit to your LAN or WAN according to the type of connection you are using and for mounting the unit in a rack.


Before you install the Instant Internet hardware, make sure that you are familiar with the physical and environmental specifications of the Instant Internet 400 unit. For more information, refer to [Appendix A, “Technical specifications,” on page 51](#).

Getting to know your Instant Internet 400 unit

The front panel of your Instant Internet 400 unit has nine lights, or LEDs, that signal information about your unit. The Power LED is always lit when your unit is turned on. The other eight LEDs as well as the Power LED indicate various active or error conditions.

[Figure 1](#) illustrates the front panel of the unit.

Figure 1 Front panel of the Instant Internet 400 unit




For a description of the LEDs, refer to [Chapter 5, “LEDs: support and diagnostic functions,” on page 47](#).

Switches and connectors are located on the rear panel of your unit as follows:

- At the top are four slots (A through D).
- At the bottom are the network cable connection, two LEDs, the attachment unit interface (AUI) connection, the configuration switches, the power plug connection, and the on/off switch.

Figure 2 illustrates the rear panel of the unit.

Figure 2 Rear panel of the Instant Internet 400 unit



Warning: The Instant Internet unit contains a lithium battery. There is a danger of explosion if the battery is replaced incorrectly. The battery should be replaced only by factory authorized personnel.

Interface cards

Depending on the configuration of your unit, you may have multiple interface cards in slots A through D.



Note: The interface card(s) in your Instant Internet unit may not look exactly like those depicted in the illustrations.

Table 2 shows the LAN interfaces available for your Instant Internet 400 unit.

Table 2 LAN interfaces




Interface name	Interface card	Type
Eth1		Ethernet connection on the back of the unit.
Eth2 Eth3		Ethernet interface card with a BNC connector and an RJ-45 connector. Note: On some Ethernet interface cards the BNC connector can be absent. Note: If you have a triple Ethernet unit, the Ethernet card in slot D is <i>Eth2</i> and the Ethernet card in slot C is <i>Eth3</i> .
Tok1 Tok2		Token ring interface card with a 9-pin connector and an RJ-45 connector. Note: If you have a dual token ring unit, the token ring card in slot D is <i>Tok1</i> and the token ring card in slot C is <i>Tok2</i> .

Table 3 shows the communication interface cards available for your Instant Internet 400 unit.

Table 3 Communication interfaces







Interface name	Interface card	Type
ISDN	<p style="text-align: center;">RJ-45 ISDN</p>  <p style="text-align: right;">9287EB</p>	ISDN interface card (United States) with one RJ-45 connector (does not support NT1).
ISDN	<p style="text-align: center;">RJ-45 RJ-45 ISDN ISDN</p>  <p style="text-align: right;">9288EB</p>	ISDN interface card (international) with two RJ-45 connectors (supports NT1).
Dialup (Analog)	<p style="text-align: center;">RJ-11 RJ-11 Telco Phone</p>  <p style="text-align: right;">9289EB</p> <p>Note: Depending on the type of analog modem card you have, the placement of the jacks may be reversed. Be sure to read the labels of the jacks before you plug in any cables.</p>	<p>Analog modem interface card with one RJ-11 connector for the phone (outgoing to modem) and one RJ-11 connector for the Telco (incoming from wall jack).</p> <p>Note: If you have a dual analog unit, the first modem is located in slot A and the second modem is in slot B.</p>
Serial-1 (port 0) Serial-2 (port 1)	<p style="text-align: center;">26-pin 26-pin X.21 Port 0 X.21 Port 1</p>  <p style="text-align: right;">9290EB</p>	X.21 interface card (leased-line) with one 26-pin connector for X.21 port 0 and one 26-pin connector for X.21 port 1.

Table 3 Communication interfaces (continued)

Interface name	Interface card	Type
Serial-1 (port 0) Serial-2 (port 1)	 <p style="text-align: center;">26-pin V.35 Port 0 26-pin V.35 Port 1</p> <p style="text-align: right;">9291EB</p>	V.35 interface card (leased-line) with one 26-pin connector for V.35 port 0 and one 26-pin connector for V.35 port 1.
Serial (port 0) T1	 <p style="text-align: center;">26-pin V.35 Port 0 LEDs RJ-48 T1</p> <p style="text-align: right;">9292EB</p>	T1 interface card (leased-line) with one 26-pin connector for V.35 port 0 and one RJ-48 connector for T1.
Serial (port 0) DDS	 <p style="text-align: center;">26-pin V.35 Port 0 LEDs RJ-48 56K</p> <p style="text-align: right;">9293EB</p>	DDS interface card (leased-line) with one 26-pin connector for V.35 port 0 and one RJ-48 connector for 56K.

Instant Internet quick installation

These steps will guide you through the general process of installing your Instant Internet hardware.

Be sure to choose a location near your router and LAN or WAN hubs and close to an electrical outlet.



Note: Before you begin installation, be sure that the switch settings are set to normal operation. For information about configuring switch settings, refer to [“Switch settings for normal operation” on page 42.](#)

The communications connection is necessary to provide the link between your Instant Internet unit and your Internet service provider (ISP). To ensure a proper communications connection, make sure that you have ordered the appropriate following services:

- Installation from your telephone service company (Telco)
- Service from your Telco
- Internet access service from your ISP

Be sure to review the information in [“Installation checklist” on page 27](#).

If you experience problems during installation, unplug all connections, except the LAN connection, and then restart the Instant Internet unit.



Note: *Do not* apply power to the Instant Internet unit until you have completed the installation steps.

You can mount your Instant Internet unit in an equipment rack or place it on a flat surface. If you choose not to mount the Instant Internet unit in a rack, be sure to install the unit’s rubber feet. If the feet are not installed, stick the adhesive side of the feet on the spaces provided on the bottom of the unit. You need to use either the mounting brackets or the feet.

To install your Instant Internet hardware:

1 Do one of the following:

- If you want to mount your Instant Internet unit in a rack, you must do so before you connect it to your LAN. Follow the procedure [“Mounting your Instant Internet unit in a rack” on page 37](#) and then return to this procedure and continue with step 2.
- If you do not want to mount your Instant Internet unit in a rack, place the unit on any appropriately level surface that can safely support the weight of the unit and attached cables. Make sure that there is adequate space around the unit for ventilation and access to cable connectors. Allow at least 2 inches (5.1cm) on each side for proper ventilation and 5 inches (12.7cm) at the back for power cord clearance and ventilation. Continue with step 2.

- 2 Attach one end of the communications cable (modem, ISDN, T1, DDS, Ethernet, token ring) to the appropriate connector on the Instant Internet unit.
- 3 Attach the other end of the communications cable to the appropriate source (phone jack, ISDN jack, T1 jack, DDS jack, cable modem, or external router).
- 4 Attach the Instant Internet unit to a hub on your LAN using an Ethernet cable (attach to Eth1) or a token ring cable (attach to Tok1).



Note: A token ring cable is *not* included with your Instant Internet package.

- 5 Plug the power cord into the rear panel of the Instant Internet unit.
- 6 Plug the power cord into an AC wall outlet.
- 7 Turn on the Instant Internet unit.

When you turn on your Instant Internet 400 unit, the LEDs on the front panel illuminate. LED #2 glows amber when the unit is ready for setup. For information about setting up your unit, see *Installing the BayStack Instant Internet Management Software Version 7.11*


Mounting your Instant Internet unit in a rack

To install your Instant Internet in an equipment rack, you will need a Phillips screwdriver (not included) and the brackets, screws, and washers provided in the rack mounting kit.

To mount your Instant Internet 400 in a rack:


- 1 Remove the three screws from the cover on each side of your Instant Internet unit as shown in [Figure 3](#).

Figure 3 Removing screws from cover of Instant Internet 400 unit




- 2 Attach the front mounting brackets to your unit using the screws provided (Figure 4).

Figure 4 Attaching mounting brackets to the Instant Internet 400 unit



- 3 Position your unit in the rack horizontally.
Your unit should be facing out from the rack.
- 4 Align the holes in the mounting bracket with the holes in the rack.
- 5 Attach your unit to the front of the rack using the mounting screws and washers provided (Figure 5).

Figure 5 Attaching the Instant Internet 400 unit to the front of the rack



10046FA

Chapter 4


DIP switch settings

This chapter describes the Dual Inline Pins (DIP) switch settings for your Instant Internet 400 unit, including those for normal operation, for setting the token ring speed, and for resetting your unit's password and configuration settings.

DIP switches

DIP switches enable you to configure your Instant Internet unit for a particular type of operation. There are eight DIP switches on the rear panel of your unit (Figure 6). The switches are labeled left to right from 1 to 8.

Figure 6 DIP switches on the rear panel of the unit



9870EA

The switches have two possible positions: on and off. For the Instant Internet 400 unit, the on position is up and the off position is down. Use a small instrument with a fine point, such as a pen nib or small screwdriver, to move the switches to the proper position. Labels on the unit indicate whether a switch is on or off, and the specific switch pattern indicates a specific configuration item.

Switch settings for normal operation

Leave all switches *off* for normal operation, as shown in [Table 4](#).

Table 4 Switch settings for normal operation

	1	2	3	4	5	6	7	8
ON								
OFF	•	•	•	•	•	•	•	•

Switch settings for token ring speed

If you need to set token ring speed to match the speed of your network, see the information in the following tables for examples of single and dual token ring switch settings.

Single token ring switch settings

[Table 5](#) and [Table 6](#) show the switch settings for the token ring speed for a single token ring unit.

Table 5 Single token ring: 16 Mb/s

	1	2	3	4	5	6	7	8
ON		•		NA	NA	NA	NA	NA
OFF	•		•	NA	NA	NA	NA	NA

Table 6 Single token ring: 4 Mb/s

	1	2	3	4	5	6	7	8
ON		•	•	NA	NA	NA	NA	NA
OFF	•			NA	NA	NA	NA	NA

Dual token ring switch settings

If you have a dual token ring unit and need to set the token ring speed, see one of the following tables:

- [Table 7 \(Dual token ring: 16 Mb/s Tok1 / 16 Mb/s Tok2\)](#)
- [Table 8 \(Dual token ring: 16 Mb/s Tok1 / 4 Mb/s Tok2\)](#)
- [Table 9 \(Dual token ring: 4 Mb/s Tok1 / 16 Mb/s Tok2\)](#)
- [Table 10 \(Dual token ring: 4 Mb/s Tok1 / 4 Mb/s Tok2\)](#)

Table 7 Dual token ring: 16 Mb/s Tok1 / 16 Mb/s Tok2

	1	2	3	4	5	6	7	8
ON		•			NA	NA	NA	NA
OFF	•		•	•	NA	NA	NA	NA

Table 8 Dual token ring: 16 Mb/s Tok1 / 4 Mb/s Tok2

	1	2	3	4	5	6	7	8
ON		•		•	NA	NA	NA	NA
OFF	•		•		NA	NA	NA	NA

Table 9 Dual token ring: 4 Mb/s Tok1 / 16 Mb/s Tok2

	1	2	3	4	5	6	7	8
ON		•	•		NA	NA	NA	NA
OFF	•			•	NA	NA	NA	NA

Table 10 Dual token ring: 4 Mb/s Tok1 / 4 Mb/s Tok2

	1	2	3	4	5	6	7	8
ON		•	•	•	NA	NA	NA	NA
OFF	•				NA	NA	NA	NA

Switch settings for special configurations

During the power-up sequence, your Instant Internet 400 unit checks the settings of the switches. You can use the switches on your unit to:

- Reset the password (Table 11), which is useful if you forget the password.
- Reset the password and other user-defined system configuration (Table 12).
- Disable the switch settings for resetting the password and user-defined configurations (Table 13).
- Restore the original default factory settings (Table 14).

Table 11 shows the switch settings for resetting your unit's password.

Table 11 Switch settings for resetting the password

	1	2	3	4	5	6	7	8
ON	•	•	•		•		•	
OFF				•		•		•

Table 12 shows the switch settings for resetting your unit's password as well as some user-defined configurations.

Table 12 Switch settings for resetting the password and user-defined configurations

	1	2	3	4	5	6	7	8
ON	•	•	•		•	•		
OFF				•			•	•



Caution: If you use these switch settings to restore your unit, the following user-defined settings are removed or reset: password, hosts, port mappings, and unit configuration.

[Table 13](#) shows the switch settings to disable the switch settings for resetting the password and user-defined configurations.

Table 13 Switch settings to disable switch settings for resetting the password and user-defined configurations

	1	2	3	4	5	6	7	8
ON	•	•		•	•	•	•	
OFF			•					•

[Table 14](#) shows the switch settings for restoring your unit to factory default conditions.

Table 14 Switch settings for restoring factory default conditions

	1	2	3	4	5	6	7	8
ON	•	•	•		•	•	•	
OFF				•				•



Caution: If you use these switch settings to restore your unit to factory default conditions, the following user-defined settings are removed or reset: password, hosts, port mappings, unit configuration, access restrictions, unit registration, and encryption authorization.

If you purchased and installed the *3DES Encryption Module* (part number CQ1010005), you need to reinstall it.

If you used the switch settings in [Table 13](#) to disable the reset password and configuration switch settings, these settings are re-enabled.

Resetting your Instant Internet unit

Before you reset your Instant Internet unit, be sure to back up the configuration. If you back up the configuration, you can easily restore it. For details, refer to *Using the BayStack Instant Internet Management Software Version 7.11*.

To reset your Instant Internet unit:

- 1 Turn off your unit.
- 2 Record the current switch settings of your Instant Internet unit.
- 3 Set the switches to the configuration you want.

Refer to “[Switch settings for special configurations](#)” on page 44.

- 4 Turn on your unit.

The LEDs on the front of your unit flash and then glow steadily amber, including the Power LED, when they completely match the sequence for the selected switch settings.



Note: If you used the switch settings in [Table 13](#) to disable the reset password and configuration switch settings, the Power LED glows amber and LEDs 1–8 flash red in the sequence of the selected switch settings.

- 5 Turn off your unit.
- 6 Reset the switches using the information recorded in step 2.
Refer to [Table 4](#) through [Table 10](#) beginning on [page 42](#).
- 7 Turn on your unit.

Chapter 5

LEDs: support and diagnostic functions

This chapter describes how the LEDs work on your Instant Internet 400 unit and how you can use them to interpret activity on your unit.

Interpreting LEDs

On the front panel of the Instant Internet unit, the nine LEDs indicate failures, configuration information, and operational status. When the unit is turned on, it displays any failures as red lights.

LEDs at power-up sequence

If any failure is found during the power-up sequence, the Power LED glows amber, and one or more of LEDs 1 through 8 glow red. This failure indicates a hardware problem. Call the Nortel Networks Technical Solutions Center ([page 20](#)) for assistance.



Caution: During normal operation, the Power LED glows green, except when updating the internal flash ROM. While updating the flash memory, the Power LED glows amber. This amber LED indicates that it is not safe to turn off the unit without potentially damaging the contents of flash memory.

Recognizing single token ring speed

For a single token ring unit, LED 4 shows the ring speed for 30 seconds after the unit is turned on. [Table 15](#) shows the single token ring speed for LED 4. For more information about token ring units, refer to [“Getting to know your Instant Internet 400 unit” on page 31](#).

Table 15 Single token ring speed (first 30 seconds)

LED #	Color	Appearance	Meaning
4	Green	Solid	4 Mb/s (token ring speed)
4	Amber	Solid	16 Mb/s (token ring speed)

Recognizing dual token ring speed

For a dual token ring unit, LED 4 shows the ring speed of the Tok1 token ring, and LED 5 shows the ring speed of the Tok2 token ring, each for 30 seconds after the unit is turned on. For more information about dual token ring units, refer to [“Getting to know your Instant Internet 400 unit” on page 31](#).

[Table 16](#) shows the dual token ring speed for LED 4, and [Table 17](#) shows the dual token ring speed for LED 5.

Table 16 Dual token ring (Tok1) speed (first 30 seconds)

LED #	Color	Appearance	Meaning
4	Green	Solid	4 Mb/s (Tok1 ring speed)
4	Amber	Solid	16 Mb/s (Tok1 ring speed)

Table 17 Dual token ring (Tok2) speed (first 30 seconds)

LED #	Color	Appearance	Meaning
5	Green	Solid	4 Mb/s (Tok2 ring speed)
5	Amber	Solid	16 Mb/s (Tok2 ring speed)

LEDs during operation

After the power-up sequence is complete, the LEDs indicate status and activity during operation as shown in [Table 18](#).

Table 18 LED status and appearance during operation

LED #	Color	Appearance	Meaning
Power	Green	Solid	Unit has electrical power and is turned on.
Power	Green and Amber	Solid Green and Flashing Amber	Unit is updating flash ROM. DO NOT TURN OFF until light returns to green.
1	Green	Blinking	Unit is operating normally.
2	Green	Solid	Unit is ready to service clients.
2	Green and Amber	Solid Green and Flashing Amber	Unit is communicating with clients.
2	Amber	Solid	Unit is ready to run setup but cannot service clients (normally occurs before unit has been configured).
3-8	Green	Solid	Indicated interface (see Note below) is online.
3-8	Green	Flashing	Indicated interface (see Note below) is dialing or attempting connection.
3-8	Green and Amber	Solid Green and Flashing Amber	Traffic is on the indicated interface.
3-8	Red	Solid	Indicated interface (see Note below) has failed.



Note: The “indicated interface” is the interface associated with the LED’s number. This information is available in the main dialog box of the iiSetup program. For more information, refer to *Using the BayStack Instant Internet Management Software Version 7.11*.

Appendix A

Technical specifications

This appendix describes the physical and environmental specifications for your Instant Internet 400 unit.

Physical specifications

The Instant Internet 400 unit is 17 inches wide by 15.25 inches deep and 3.875 inches high (19-inch rack-mountable, 2-rack units).

Environmental specifications

The operating and nonoperating environment for the Instant Internet 400 unit is as follows:

- Operating Temperature: 10° to 40° C maximum
- Nonoperating Temperature: -44° to 66° C maximum
- Operating Humidity
 - 20% minimum to 80% maximum
 - Relative Humidity: noncondensing
- Nonoperating Humidity
 - 10% minimum to 95% maximum
 - Relative Humidity: noncondensing
- Operating Altitude: 8,000 feet (2,438 meters) maximum
- Nonoperating Altitude: 30,000 feet (9,144 meters) maximum
- Acoustic Noise: 55dBA at 1 meter

Appendix B

Adapter cable pinout diagrams

This appendix describes the pinout settings for the V.35 and X.21 adapter cables.

Adapter cable part numbers


If you ordered your Instant Internet 400 unit for use with a V.35 modem or X.21 modem, you must provide the connection cable. You can have a cable made according to the pinout diagrams in this appendix or you can order a cable from Nortel Networks using the following part numbers:

- V.35 Adapter Cable—Part Number CQ2118001
- X.21 Adapter Cable—Part Number CQ2118004

V.35 adapter cable

Figure 7 shows the pinout settings for a V.35 modem adapter cable (part number CQ2118001)


Figure 7 V.35 adapter cable pinout diagram



X.21 (DCE) adapter cable

Figure 8 shows the pinout settings for an X.21 modem adapter cable (part number CQ2118004).

Figure 8 X.21 (DCE) adapter cable diagram.



9109EB

Index

Symbols

! Default provider 26

Numbers

100BASE-T Ethernet connection 21

10BASE-T Ethernet connection 21

26-pin connector 34, 35

3DES Encryption Module 45

56K x2/V.90 analog modem 22

9-pin connector 33

A

acoustic noise 51

acronyms 18

altitude

 nonoperating 51

 operating 51

analog modem card 34

B

BNC connector 33

C

cable

 dial-up connection 21

 Ethernet connection 21

 ISDN connection 21

 pinout diagrams 53

 RJ-11 connection 21

 RJ-45 connector 21

 RJ-48 connector 21

 V.35 adapter 54

 X.21 (DCE) adapter 55

cable modem 22

CHAP 27

connection

 DDS 22, 27

 dial-up 23

 leased-line 23

 PPPoE 28

 T1 22, 27

 V.35 27

 X.21 27

CSU 22

customer support 20

D

DDS card 35

DDS connection

 Leased-line type 27

 speed 23

DDS Connection, cables 21

dial-up connection, V.90 23

dimensions 51

DIP switch

 off position 41

 on position 41

 setting 41

 using 41

DSL modem 22

DSU 22

dual Ethernet card 22

dual token ring unit
 LEDs 48
 switch settings 43

E

environment
 nonoperating 51
 operating 51

Eth1 33

Eth2 33

Ethernet
 100BASE-T 21
 10BASE-T 21

Ethernet card 33

Ethernet connection
 Eth1 33
 Eth2 33

Ethernet connection, cable 21

external router 22

F

factory default conditions, resetting 45

frame relay 23, 27

H

humidity
 nonoperating 51
 operating 51

I

installation
 checklist 27
 worksheet 29

interface
 LED 49

interface, AUI 32

Internet service provider
 ! Default provider 26
 access phone number 27
 additional services 28
 name server 27
 password 27
 selecting 26
 user name 27

Internet Service Provider Hotline
 Nortel Networks Technical Solutions Center 26

ISDN card
 configuration option 22
 interfaces 34
 NT1 22

ISDN connection
 cable 21
 Multilink Protocol 23
 provider options 28
 service connection 27
 SPID number 27
 synchronous PPP 23

L

leased-line
 DDS card 35
 T1 card 35
 V.35 card 35
 X.21 card 34

leased-line connection
 DDS 23
 frame relay 27
 requirements 27
 T1 23
 V.35 23
 X.21 23

LED
 interface 49

LEDs
 activity 49
 after power-up sequence 49
 dual token ring unit 48
 interpreting 47

- normal operation 47
- power-up sequence 47
- red 47
- single token ring unit 48
- status 49

M

- modem
 - analog 22
 - cable 22
 - DSL 22
- Multilink Protocol (MP) 23

N

- NT1 34

P

- package contents 21
- PAP 27
- passwords, resetting 44
- phone cord 21
- physical specifications 51
- Power LED 47
- PPP 23, 27
- PPPoE 23, 28
- product support 20
- protocol
 - analog 27
 - dial-up 27
 - ISDN 27
 - PPP 27
 - PPPoE 28
 - proprietary 27
- publications
 - hard copy 20
 - related 19

R

- rack mounting 37
- ring speed
 - setting 42
 - Tok1 43, 48
 - Tok2 43, 48
- RJ-11 connector 34
- RJ-45 connector 33, 34
- RJ-48 connector 35
- router, external 22

S

- single token ring unit
 - LEDs 48
 - switch settings 42
- size 51
- SPID number 27
- support, Nortel Networks 20
- switch settings
 - disabling 45
 - dual token ring unit 43
 - normal operation 42
 - resetting the password 44
 - resetting to factory default conditions 45
 - resetting user-defined configurations 44
 - single token ring unit 42
 - special configurations 44
 - token ring speed 42
- synchronous PPP 27

T

- T1 card 35
- T1 connection
 - cable 21
 - data type 27
 - framing format 27
 - leased-line connection speed 23
 - line build-out 27
 - line encoding 27

- line speed 27
- rate multiplier 27
- setting up 27
- technical publications 20
- technical support 20
- Telco 36
- temperature
 - nonoperating 51
 - operating 51
- token ring 48
 - connection 22
 - LEDs 48
 - switch setting 42
 - Tok1
 - card 33
 - ring speed 48
 - Tok2
 - card 33
- token ring card 33
- token ring speed
 - 16 Mb/s 42, 43
 - 4 Mb/s 42, 43
 - Tok1 43
 - Tok2 43

U

- unit
 - mounting in a rack 37
 - resetting 46
- user-defined configurations, resetting 44

V

- V.35
 - card 35
 - connection 23, 27
 - port 0 35
 - port 1 35
- V.35 adapter cable 54
- V.90 23

X

- X.21
 - card 34
 - connection 23, 27
 - port 0 34
 - port 1 34
- X.21 (DCE) adapter cable 55