




ML507 QuickStart

May 2008




 **XILINX®**

Overview

- Setup
- Boot with ACE-loader ACE File
- Observe LCD and Terminal messages
- Load new Configuration
- Re-load ACE-loader

ML507 BSB Hardware

- The ML507 PPC440 design hardware includes:
 - PPC440MC DDR2 Interface
 - External Memory Controller (EMC)
 - ZBT SRAM
 - BRAM
 - Networking
 - UART
 - Interrupt Controller
 - System ACE CF Interface
 - GPIO (IIC, LEDs and LCD)
 - PLB Arbiter



 XILINX®

Additional Setup Details

- Refer to ml505_overview_setup document for details on:
 - Software Requirements
 - ML507 Board Setup
 - Equipment and Cables
 - Software
 - Network
 - Terminal Programs
 - This presentation requires the 9600-8-N-1 Baud terminal setup



Hardware Setup

- Connect the Xilinx Parallel Cable IV (PC4) to the ML507 board
- Connect the RS232 null modem cable to the ML507 board



Hardware Setup

- The ML507 uses a DVI video interface
- Connect a DVI monitor
or
- Use a DVI/VGA adapter to connect a VGA monitor
 - <http://www.belkin.com>




Hardware Setup

- USB Keyboard
 - www.dell.com



Factory CompactFlash

- The CompactFlash shipped with the ML507 board has the following ace files preloaded:





A screenshot of a Windows Command Prompt window titled "Command Prompt". The window shows the file structure of a CompactFlash card mounted at drive G. The directory tree is as follows:

- G:\ML507\cfg0
 bootload_video.ace
- G:\ML507\cfg1
 slideshow.ace
- G:\ML507\cfg2
 lwipdemo.ace
- G:\ML507\cfg3
 simon.ace
- G:\ML507\cfg4
 xrom.ace
- G:\ML507\cfg5
 usb_hpi_test.ace
- G:\ML507\cfg6
 my_ace.ace
- G:\ML507\cfg7
 piezo.ace


Verify Factory Default Settings

- Set the Ethernet PHY jumpers, J22, J23 to positions 1-2 (1)
- Insert the Factory CompactFlash into the ML507 board (2)
- Set the Front DIP switches (SW3) to 00010101 (1 = ON) (3)
- Set the Rear DIP switches (SW6) to 11001010 (4)
- Power-up the ML507 board




Bootload

- The bootload_video.ace loads:




Bootload

- The terminal window also reflects the bootload application
- Use the left/center/right buttons to choose an application or type a number in the terminal window
- After each demo, push the SysACE reset to return to bootloader




Slideshow

- Type 1, to launch the slideshow application in Configuration 1
- The slideshow loads the presentation into memory then presents it



Slideshow

- The slideshow app will present a series of slides on the Monitor:



Next Generation of Flexibility: Virtex-5 FXT PowerPC440 Block


- PowerPC 440 Processor Core
 - Industry Standard Processor
- Crossbar Switch
 - Efficiently move data
- Enhanced APU
 - Custom hardware acceleration

More than just a better

Platform Design Tools Deliver Greater Design Productivity

Third Party EDA Software

DSP



Virtex-5 FPGAs Provide the Right Mix of Memories


- Distributed LUT RAM
 - Fast, localized memories
 - Built-in shift register
 - Great for small FIFOs
- 550 MHz block RAM / FIFO
 - Bigger on-chip memories
 - Built-in FIFO and ECC logic
 - Great for mid-sized FIFOs/buffers
- External memory interfacing
 - Fast connection to popular standards
 - Memory controller cores
 - Ideal for large memory requirements



XILINX

Web Server

- Type 2, to launch the web server application in Configuration 2
 - **Note:** You may need to turn off your browser's proxy and specify a direct connection to the Internet in your browser options



The screenshot shows a terminal window titled "Tera Term - COM1 VT". The window displays the following text output from a lwIP-based web server:
Board IP: 192.168.1.10
Netmask : 255.255.255.0
Gateway : 192.168.1.1

----lwIP test WebServer ----
Open up your favorite browser and type:
<http://192.168.1.10>


----lwIP echo server ----
You can connect to the echo server @ port 7

----lwIP TFTP Server ----
Upload or download files from the Memory File System to your localhost
e.g.: upload from WinXP host to the board:
tftp -i 192.168.1.10 PUT source [destination]

XLlTemac detect_phys: PHY detected.
auto-negotiated link speed: 1000
Memory File System initialized

Running the LWIP Demo

- Open a web browser to address 192.168.1.10




Running the LWIP Demo

- Click the Toggle LEDs button; view change on ML507

The screenshot shows a Microsoft Internet Explorer window titled "Xilinx WebServer Demo - Microsoft Internet Explorer". The address bar contains "http://192.168.1.10/". The main content area displays the Xilinx logo and the title "Xilinx Web Server Demo". Below the title, a text block reads: "Hello! This is a demonstration of a simple embedded webserver created using lwIP. Using the lwIP networking stack, a webserver can be easily embedded into your software application. A webserver provides an easy method to control or monitor the embedded platform via an Internet browser." A "Documentation" section links to details on lwIP. A "Controlling the Embedded System" section describes how the system can be controlled from a browser, mentioning the "LED's on the board" which can be switched on or off by clicking the "Toggle LEDs" button. The status message "LEDs are now ON." is displayed in green, indicating the current state. The "Toggle LEDs" button is shown below the message.


Simon

- Type 3, to launch the Simon application in Configuration 3




Board Diagnostics

- Type 4, to launch the XROM application in Configuration 4





Board Diagnostics

- XROM includes a series of board test routines



USB Keyboard

- Type 5, to launch the USB Keyboard application in Configuration 5
- Type **ML507** and view results:




Note: Attach keyboard after demo loads

 XILINX®

© 2008 Xilinx, Inc. All Rights Reserved


My ACE

- Type 6, to launch the My ACE application in Configuration 6



Ringtone

- Type 7, to launch the Ringtone application in Configuration 7
- Press any key then press 1-7 to play a simple melody



Documentation

- Virtex-5
 - Silicon Devices
http://www.xilinx.com/products/silicon_solutions
 - Virtex-5 Multi-Platform FPGA
http://www.xilinx.com/products/silicon_solutions/fpgas/virtex/virtex5
 - Virtex-5 Family Overview: LX, LXT, SXT, and FXT Platforms
http://www.xilinx.com/support/documentation/data_sheets/ds100.pdf
 - Virtex-5 FPGA DC and Switching Characteristics Data Sheet
http://www.xilinx.com/support/documentation/data_sheets/ds202.pdf

Documentation

- Virtex-5
 - Virtex-5 FPGA User Guide
http://www.xilinx.com/support/documentation/user_guides/ug190.pdf
 - Virtex-5 FPGA Configuration User Guide
http://www.xilinx.com/support/documentation/user_guides/ug191.pdf
 - Virtex-5 System Monitor User Guide
http://www.xilinx.com/support/documentation/user_guides/ug192.pdf
 - Virtex-5 Packaging and Pinout Specification
http://www.xilinx.com/support/documentation/user_guides/ug195.pdf

Documentation

- Virtex-5 RocketIO
 - RocketIO GTP Transceivers
http://www.xilinx.com/products/silicon_solutions/fpgas/virtex/virtex5/capabilities/RocketIO_GTP.htm
 - RocketIO GTX Transceivers
http://www.xilinx.com/products/silicon_solutions/fpgas/virtex/virtex5/capabilities/RocketIO_GTX.htm
 - RocketIO GTP Transceiver User Guide – UG196
http://www.xilinx.com/support/documentation/user_guides/ug196.pdf
 - RocketIO GTX Transceiver User Guide – UG198
http://www.xilinx.com/support/documentation/user_guides/ug198.pdf

Documentation

- Design Resources
 - ISE Development Tools and IP
<http://www.xilinx.com/ise>
 - Integrated Software Environment (ISE) Foundation Resources
http://www.xilinx.com/ise/logic_design_prod/foundation.htm
 - ISE Manuals
http://www.xilinx.com/support/software_manuals.htm
 - ISE Development System Reference Guide
<http://toolbox.xilinx.com/docsan/xilinx10/books/docs/dev/dev.pdf>
 - ISE Development System Libraries Guide
http://toolbox.xilinx.com/docsan/xilinx10/books/docs/virtex5_hdl/virtex5_hdl.pdf

Documentation

- Additional Design Resources
 - Customer Support
<http://www.xilinx.com/support>
 - Xilinx Design Services:
<http://www.xilinx.com/xds>
 - Titanium Dedicated Engineering:
<http://www.xilinx.com/titanium>
 - Education Services:
<http://www.xilinx.com/education>
 - Xilinx On Board (Board and kit locator):
<http://www.xilinx.com/xob>

Documentation

- Platform Studio
 - Embedded Development Kit (EDK) Resources
<http://www.xilinx.com/edk>
 - Embedded System Tools Reference Manual
http://www.xilinx.com/support/documentation/sw_manuals/edk10_est_rm.pdf
 - EDK Concepts, Tools, and Techniques
http://www.xilinx.com/ise/embedded/edk92i_docs/edk_ctt.pdf

Documentation

- MicroBlaze
 - MicroBlaze Processor
<http://www.xilinx.com/microblaze>
 - MicroBlaze Processor Reference Guide – UG081
[http://www.xilinx.com/support/documentation/sw_manuals\(mb_ref_guide.pdf](http://www.xilinx.com/support/documentation/sw_manuals(mb_ref_guide.pdf)

Documentation

- Memory Solutions
 - Demos on Demand – Memory Interface Solutions with Xilinx FPGAs
http://www.demosondemand.com/clients/xilinx/001/page_new2/index.asp#35
 - Xilinx Memory Corner
http://www.xilinx.com/products/design_resources/mem_corner
 - Additional Memory Resources
<http://www.xilinx.com/support/software/memory/protected/index.htm>
 - Xilinx Memory Interface Generator (MIG) 2.1 User Guide
<http://www.xilinx.com/support/software/memory/protected/ug086.pdf>
 - Memory Interfaces Made Easy with Xilinx FPGAs and the Memory Interface Generator
http://www.xilinx.com/support/documentation/white_papers/wp260.pdf

Documentation

- Ethernet
 - Virtex-5 Embedded Tri-Mode Ethernet MAC Wrapper Data Sheet
http://www.xilinx.com/support/documentation/ip_documentation/v5_emac_ds550.pdf
 - Virtex-5 Embedded Tri-Mode Ethernet MAC Wrapper Getting Started Guide
http://www.xilinx.com/support/documentation/ip_documentation/v5_emac_gsg340.pdf
 - Virtex-5 Tri-Mode Ethernet Media Access Controller User Guide
http://www.xilinx.com/support/documentation/user_guides/ug194.pdf
 - LightWeight IP (lwIP) Application Examples – XAPP1026
http://www.xilinx.com/support/documentation/application_notes/xapp1026.pdf

Documentation

- ML505/506/507
 - ML505 Overview
<http://www.xilinx.com/ml505>
 - ML506 Overview
<http://www.xilinx.com/ml506>
 - ML507 Overview
<http://www.xilinx.com/ml507>
 - ML505/506/507 Evaluation Platform User Guide – UG347
http://www.xilinx.com/support/documentation/boards_and_kits/ug347.pdf
 - ML505/506/507 Getting Started Tutorial – UG348
http://www.xilinx.com/support/documentation/boards_and_kits/ug348.pdf
 - ML505/506/507 Reference Design User Guide – UG349
http://www.xilinx.com/support/documentation/boards_and_kits/ug349.pdf

Documentation

- ML505/506/507
 - ML505/506/507 Schematics
http://www.xilinx.com/support/documentation/boards_and_kits/ml50x_schematics.pdf
 - ML505/506/507 Bill of Material
http://www.xilinx.com/support/documentation/boards_and_kits/ml505_501_bom.xls