



Nios Development Board Stratix II Edition

Reference Manual



101 Innovation Drive
San Jose, CA 95134
www.altera.com

Development Board Version	6XX-40019R
Document Version	1.3
Document Date	May 2007

Copyright © 2007 Altera Corporation. All rights reserved. Altera, The Programmable Solutions Company, the stylized Altera logo, specific device designations, and all other words and logos that are identified as trademarks and/or service marks are, unless noted otherwise, the trademarks and service marks of Altera Corporation in the U.S. and other countries. All other product or service names are the property of their respective holders. Altera products are protected under numerous U.S. and foreign patents and pending applications, maskwork rights, and copyrights. Altera warrants performance of its semiconductor products to current specifications in accordance with Altera's standard warranty, but reserves the right to make changes to any products and services at any time without notice. Altera assumes no responsibility or liability arising out of the application or use of any information, product, or service described herein except as expressly agreed to in writing by Altera Corporation. Altera customers are advised to obtain the latest version of device specifications before relying on any published information and before placing orders for products or services.

Part Number MNL-01001-1.3



I.S. EN ISO 9001



About this Manual	v
How to Contact Altera	v
Typographic Conventions	vi
Chapter 1. Overview	
Features Overview	1-1
General Description	1-1
Factory-Programmed Reference Design	1-2
Chapter 2. Board Components	
Component List	2-1
Stratix II EP2S60 Device (U60)	2-3
Push-Button Switches (SW0 - SW3)	2-4
Individual LEDs (D0 - D7)	2-5
Seven-Segment LEDs (U8 & U9)	2-5
SSRAM Chip (U74)	2-6
DDR SDRAM Chip (U63)	2-9
Flash Memory (U5)	2-11
Ethernet MAC/PHY (U4) & RJ45 Connector (RJ1)	2-13
Serial Connector (J19)	2-15
Expansion Prototype Connectors (PROTO1 & PROTO2)	2-16
CompactFlash Connector (CON3)	2-23
PMC Connector (JH1 & JH2)	2-26
Mictor Connector (J25)	2-29
Test Points (TP1 - TP8)	2-31
EPCS64 Serial Configuration Device (U69)	2-32
Configuration Controller Device (U3)	2-33
Configuration-Status LEDs	2-33
Configuration & Reset Buttons	2-34
SW8 - CPU Reset	2-34
SW9 - Factory Config	2-35
SW10 - Reset, Config	2-35
Reset Distribution	2-36
Starting Configuration	2-36
Factory & User Configurations	2-36
Configuration Process	2-37
Flash Memory Partitions	2-38
User Application Space	2-38
User Configuration	2-39
Factory Configuration	2-39
Persistent Data	2-39

JTAG Connectors (J24 & J5)	2-39
JTAG Connector to FPGA (J24)	2-39
JTAG Connector to EPM7256AE Device (J5)	2-41
Clock Circuitry	2-41
Power-Supply Circuitry	2-44
Appendix A. Restoring the Factory Configuration	
Introduction	A-1
Reprogramming the Flash Memory	A-1
Reprogramming the EPM7256AE Configuration Controller Device	A-1
Appendix B. Connecting to the Board via Ethernet	
Introduction	B-1
Connecting the Ethernet Cable	B-1
Connecting the LCD Screen	B-2
Obtaining an IP Address	B-2
LAN Connection	B-3
DHCP	B-3
Static IP Address	B-3
Point-to-Point Connections	B-4
Browsing to Your Board	B-5



About this Manual

This manual provides details about the Nios[®] development board, Stratix[™] II Edition.

The table shows this document's revision history.

Date & Version	Description
May 2007, 1.3	<ul style="list-style-type: none">• Corrected Figure 2-21.• Revised "How to Contact Altera".• Updated headers and footers.
October 2006, 1.2	<ul style="list-style-type: none">• Corrected pin assignments for proto2_io1, proto2_io29, proto2_io30 in Table 2-12.• Changed Reference Designator for FPGA from U62 to U60.
October 2006, 1.1	<ul style="list-style-type: none">• Corrected statement: LEDs D0 - D7 turn on when driven to 0 (not 1).
June 2006, 1.0	First publication.

How to Contact Altera

For the most up-to-date information about Altera products, refer to the following table.

Contact (1)	Contact Method	Address
Technical support	Website	www.altera.com/support
Technical training	Website	www.altera.com/training
	Email	custrain@altera.com
Product literature	Website	www.altera.com/literature
Altera literature services	Email	literature@altera.com
Non-technical support (General) (Software Licensing)	Email	nacomp@altera.com
	Email	authorization@altera.com

Note to table:

(1) You can also contact your local Altera sales office or sales representative.

Typographic Conventions

This document uses the typographic conventions shown below.

Visual Cue	Meaning
Bold Type with Initial Capital Letters	Command names, dialog box titles, checkbox options, and dialog box options are shown in bold, initial capital letters. Example: Save As dialog box.
bold type	External timing parameters, directory names, project names, disk drive names, filenames, filename extensions, and software utility names are shown in bold type. Examples: f_{MAX} , lqdesigns directory, d: drive, chiptrip.gdf file.
<i>Italic Type with Initial Capital Letters</i>	Document titles are shown in italic type with initial capital letters. Example: <i>AN 75: High-Speed Board Design</i> .
<i>Italic type</i>	Internal timing parameters and variables are shown in italic type. Examples: <i>t_{PIA}</i> , <i>n + 1</i> . Variable names are enclosed in angle brackets (< >) and shown in italic type. Example: <file name>, <project name>.pdf file.
Initial Capital Letters	Keyboard keys and menu names are shown with initial capital letters. Examples: Delete key, the Options menu.
“Subheading Title”	References to sections within a document and titles of on-line help topics are shown in quotation marks. Example: “Typographic Conventions.”
Courier type	Signal and port names are shown in lowercase Courier type. Examples: data1, tdi, input. Active-low signals are denoted by suffix n, e.g., resetn. Anything that must be typed exactly as it appears is shown in Courier type. For example: c:\qdesigns\tutorial\chiptrip.gdf. Also, sections of an actual file, such as a Report File, references to parts of files (e.g., the AHDL keyword SUBDESIGN), as well as logic function names (e.g., TRI) are shown in Courier.
1., 2., 3., and a., b., c., etc.	Numbered steps are used in a list of items when the sequence of the items is important, such as the steps listed in a procedure.
	Bullets are used in a list of items when the sequence of the items is not important.
	The checkmark indicates a procedure that consists of one step only.
	The hand points to information that requires special attention.
	The caution indicates required information that needs special consideration and understanding and should be read prior to starting or continuing with the procedure or process.
	The warning indicates information that should be read prior to starting or continuing the procedure or processes
	The angled arrow indicates you should press the Enter key.
	The feet direct you to more information on a particular topic.

Features Overview

The Nios Development Board, Stratix II Edition, provides a hardware platform for developing embedded systems based on Altera® Stratix II devices. The Nios Development Board, Stratix II Edition provides the following features:

- A Stratix II FPGA with more than 13,500 adaptive logic modules (ALM) and 1.3 million bits of on-chip memory
- 16 MBytes of flash memory
- 2 MBytes of synchronous SRAM
- 32 MBytes of double data rate (DDR) SDRAM
- On-board logic for configuring the FPGA from flash memory
- On-board Ethernet MAC/PHY device and RJ45 connector
- Two 5V-tolerant expansion/prototype headers each with access to 41 FPGA user I/O pins
- CompactFlash connector for Type I CompactFlash cards
- 32-bit PMC Connector capable of 33 MHz and 66 MHz operation
- Mictor connector for hardware and software debug
- RS-232 DB9 serial port
- Four push-button switches connected to FPGA user I/O pins
- Eight LEDs connected to FPGA user I/O pins
- Dual 7-segment LED display
- JTAG connectors to Altera devices via Altera download cables
- 50 MHz oscillator and zero-skew clock distribution circuitry
- Power-on reset circuitry

General Description

The Nios development board comes pre-programmed with a Nios II processor reference design. Hardware designers can use the reference design as an example of how to build systems using the Nios II processor and to gain familiarity with the features included. Software designers can use the pre-programmed Nios II processor design on the board to begin prototyping software immediately.


This document describes the hardware features of the Nios development board, including detailed pin-out information, to enable designers to create custom FPGA designs that interface with all components on the board. A complete set of schematics, a physical layout database, and GERBER files for the development board are installed with the Nios II development tools in the *<Nios II EDS install path>/documents* directory.



See the *Nios II Development Kit, Getting Started User Guide* for instructions on setting up the Nios development board and installing Nios II development tools.

Figure 1–1 shows a block diagram of the Nios development board.

Figure 1–1. Nios Development Board, Stratix II Edition Block Diagram



Factory-Programmed Reference Design

When power is applied to the board, on-board logic configures the FPGA using hardware configuration data stored in flash memory. After successful configuration, the Nios II processor design in the FPGA wakes up and begins executing boot code from flash memory.

The board is factory-programmed with a default reference design. This reference design is a web server that delivers web pages via the Ethernet port. For further information on the default reference design, refer to *Appendix B: Connecting to the Board via Ethernet*.

In the course of development, you might overwrite or erase the flash memory space containing the default reference design. Altera provides the flash image for the default reference design so you can return the board to its default state. Refer to *Appendix A: Restoring the Factory Configuration* for more information.

Component List This section introduces all the important components on the Nios development board. See [Figure 2-1](#) and [Table 2-1](#) for component locations and brief descriptions of all board features.

Figure 2-1. Nios Development Board




Table 2-1. Nios Development Board, Stratix II Edition Components & Interfaces		
Board Designation	Name	Description
U60	Stratix II FPGA	EP2S60F672C3N device.
User Interface		
SW0 – SW3	Push-button switches	Four momentary contact switches for user input to the FPGA.
D0 – D7	Individual LEDs	Eight individual LEDs driven by the FPGA.
U8, U9	Seven-segment LEDs	Two seven-segment LEDs that display numeric output from the FPGA.

Table 2–1. Nios Development Board, Stratix II Edition Components & Interfaces (Continued)

Board Designation	Name	Description
Memory		
U74	SSRAM memory	2 MBytes of synchronous SRAM.
U5, LED7	Flash memory	16 MBytes of nonvolatile memory for use by both the FPGA and the configuration controller. LED7 lights whenever the flash chip-enable is asserted.
U63	DDR SDRAM memory	32 MBytes of DDR SDRAM.
Connections & Interfaces		
U4, RJ1	Ethernet MAC/PHY	10/100 Ethernet MAC/PHY chip connected to an RJ-45 Ethernet connector.
J19	Serial connector	RS-232 serial connector with 5V-tolerant buffers. Supports all RS-232 signals.
PROTO1 (J11, J12, J13)	Expansion prototype connector	Expansion headers connecting to 41 I/O pins on the FPGA. Supplies 3.3 V and 5.0 V for use by a daughter card.
PROTO2 (J15, J16, J17)	Expansion prototype connector	Expansion headers connecting to 41 I/O pins on the FPGA. Supplies 3.3 V and 5.0 V for use by a daughter card.
CON3	CompactFlash connector	CompactFlash connector for memory expansion.
JH1, JH2	PMC connector	Expansion connector for a PCI mezzanine card.
J25	Mictor connector	Mictor connector providing access to 27 I/O pins on the FPGA. Allows debugging Nios II systems using a First Silicon Solutions (FS2) debug probe.
TP1 – TP8	Test Points	Test points providing access to eight FPGA I/O pins.
J24	JTAG connector	JTAG connection to the FPGA allowing hardware configuration using the Quartus® II software and software debug using the Nios II IDE.
J5	JTAG connector	JTAG connection to the MAX® configuration controller.
J27	EPCS configuration header	Connects to the EPCS serial configuration device for in-system programming.
Configuration & Reset		
U3	MAX Configuration controller	Altera MAX EPM7256AE device used to configure the FPGA from flash memory.
U69	Serial configuration device	Altera EPCS64 low-cost serial configuration device to configure the FPGA.
SW8	CPU Reset button	Push-button switch to reboot the Nios II processor configured in the FPGA.

Table 2–1. Nios Development Board, Stratix II Edition Components & Interfaces (Continued)

Board Designation	Name	Description
SW9	Factory Config button	Push-button switch to reconfigure the FPGA with the factory-programmed reference design.
SW10	Reset, Config	Push-button switch to reset the board.
LED0 – LED3, LED6	Configuration status LEDs	LEDs that display the current configuration status of the FPGA.
Clock Circuitry		
Y2	Oscillator	50 MHz clock signal driven to FPGA.
J4	External clock input	Connector to FPGA clock pin.
Power Supply		
J26	DC power jack	16 V DC unregulated power source.
D34	Bridge rectifier	Power rectifier allows for center-negative or center-positive power supplies.
J28, J29, J30, J33 (and more)	Optional Power Supply	External power supply can be connected for high-current applications.

The sections that follow describe each component in detail.

Stratix II EP2S60 Device (U60)

U60 is a Stratix II FPGA in a 672-pin FineLine BGA® package. The part number is EP2S60F672C3N. [Table 2–2](#) lists the device features.

Table 2–2. Stratix II EP2S60 Device Features

LEs	60,440
M4K Memory Blocks	255
Total RAM Bits	2,544,192
Embedded 18x18 Multiplier Blocks	144
Enhanced PLLs	4
Fast PLLs	8
User I/O Pins	718

The development board provides two separate methods for configuring the FPGA:

1. Using the Quartus® II software running on a host computer, a designer configures the device directly via an Altera download cable connected to the FPGA JTAG header (J24).
2. When power is applied to the board, a configuration controller device (U3) attempts to configure the FPGA with hardware configuration data stored in flash memory. For more information on the configuration controller, refer to “[Configuration Controller Device \(U3\)](#)” on page 2–33.




For Stratix II-related documentation including pin out data for the EP2S60 device, see the Altera Stratix II literature page at www.altera.com/literature/lit-stx2.jsp.

Push-Button Switches (SW0 - SW3)

SW0 – SW3 are momentary-contact push-button switches to provide stimulus to designs in the FPGA. Refer to [Figure 2–2](#). Each switch is connected to an FPGA general-purpose I/O pin with a pull-up resistor as shown in [Table 2–3](#). Each I/O pin perceives a logic 0 when its corresponding switch is pressed.

Figure 2–2. Push-Button Switches (SW0 – SW3)



Button	FPGA Pin	Board Net Name
SW0	P4	user_pb0
SW1	P5	user_pb1
SW2	N6	user_pb2
SW3	N7	user_pb3

Individual LEDs (D0 - D7)

This Nios II development board provides eight individual LEDs connected to the FPGA. Refer to “[Push-Button Switches \(SW0 - SW3\)](#)” on [page 2-4](#). D0 - D7 are connected to general purpose I/O pins on the FPGA as shown in [Table 2-4](#). When a pin drives logic 0, the corresponding LED turns on.

Table 2-4. LED Pin Table

LED	FPGA Pin	Board Net Name
D0	W15	pld_led0
D1	V14	pld_led1
D2	AD17	pld_led2
D3	AA17	pld_led3
D4	V16	pld_led4
D5	AB17	pld_led5
D6	AD18	pld_led6
D7	V17	pld_led7

Seven-Segment LEDs (U8 & U9)

U8 and U9 connect to the FPGA, and each segment is individually controlled by a general-purpose I/O pin. Refer to [Figure 2-3](#). When a pin drives logic 0, the corresponding U8 and U9 LED turns on. See [Table 2-5](#) for pin-out details.

Figure 2-3. Dual Seven-Segment Display




Table 2-5. Dual Seven-Segment Display

FPGA Pin	U8 & U9 Pin	Pin Function	Board Net Name
U8			
L8	10	a	hex_0A
L9	9	b	hex_0B
M7	8	c	hex_0C
M8	5	d	hex_0D
M5	4	e	hex_0E
M6	2	f	hex_0F
N4	3	g	hex_0G
N5	7	dp	hex_0DP
U9			
K8	10	a	hex_1A
K9	9	b	hex_1B
L4	8	c	hex_1C
L5	5	d	hex_1D
M3	4	e	hex_1E
M4	2	f	hex_1F
L6	3	g	hex_1G
L7	7	dp	hex_1DP

SSRAM Chip (U74)

U74 is a 32-bit, 2 MByte Cypress SSRAM chip. The part number is CY7C1380C-167AC or CY7C1380D-167AXC. The chip is rated for synchronous accesses up to 167 MHz. U74 connects to the FPGA so it can be used by a Nios II embedded processor as general-purpose memory. The factory-programmed Nios II reference design identifies the SSRAM devices in its address space as a contiguous 2 MByte, 32-bit word, zero-wait-state main memory.

Table 2–6 shows all connections between the FPGA and the SSRAM chip.

Table 2–6. SSRAM Pin Table			
FPGA Pin	U74 Pin	Pin Function	Board Net Name
G16	37	A0	ssram_a0
G17	36	A1	ssram_a1
E26	35	A2	ssram_a2
E25	34	A3	ssram_a3
E24	33	A4	ssram_a4
E23	32	A5	ssram_a5
F26	38	NC/A19	ssram_a6
F25	39	NC/A20	ssram_a7
C17	42	A6	ssram_a8
C18	43	A7	ssram_a9
C19	44	A8	ssram_a10
C20	45	A9	ssram_a11
G26	46	A10	ssram_a12
G25	47	A11	ssram_a13
G24	48	A12	ssram_a14
G23	49	A13	ssram_a15
G21	50	A14	ssram_a16
G20	81	A15	ssram_a17
H26	82	A16	ssram_a18
H25	99	A17	ssram_a19
H24	100	A18	ssram_a20
B16	85	ADSC_N	ssram_adsc_n
H23	93	BE_n0	ssram_be_n0
J23	94	BE_n1	ssram_be_n1
K24	95	BE_n2	ssram_be_n2
F16	96	BE_n3	ssram_be_n3
C16	98	CE1_n	ssram_ce1_n
A17	52	D0	ssram_d0
A18	53	D1	ssram_d1
A19	56	D2	ssram_d2
A20	57	D3	ssram_d3
B17	58	D4	ssram_d4

Table 2–6. SSRAM Pin Table (Continued)

FPGA Pin	U74 Pin	Pin Function	Board Net Name
B18	59	D5	ssram_d5
B19	62	D6	ssram_d6
B20	63	D7	ssram_d7
B24	68	D8	ssram_d8
C22	69	D9	ssram_d9
B22	72	D10	ssram_d10
C21	73	D11	ssram_d11
E18	74	D12	ssram_d12
D18	75	D13	ssram_d13
E17	78	D14	ssram_d14
D17	79	D15	ssram_d15
F23	18	D24	ssram_d16
F22	19	D25	ssram_d17
F21	22	D26	ssram_d18
B23	23	D27	ssram_d19
D25	24	D28	ssram_d20
F24	25	D29	ssram_d21
H21	28	D30	ssram_d22
F19	29	D31	ssram_d23
B21	2	D16	ssram_d24
A21	3	D17	ssram_d25
A22	6	D18	ssram_d26
A24	7	D19	ssram_d27
C26	8	D20	ssram_d28
C25	9	D21	ssram_d29
J22	12	D22	ssram_d30
J21	13	D23	ssram_d31
J26	86	OE_n	ssram_oe_n
F17	87	WE_n	ssram_we_n
J25	84	ADSP_n	ssram_adsp_n
J24	83	ADV_n	ssram_adv_n
L25	97	CE2	ssram_ce2
L24	92	CE3_n	ssram_ce3_n

Table 2–6. SSRAM Pin Table (Continued)

FPGA Pin	U74 Pin	Pin Function	Board Net Name
G18	88	GW_n	ssram_gw_n
A12	89	CLK	sram_clk

The following pins on U74 have fixed connections, which restricts the usable modes of operation:

- MODE is pulled low to enable Linear Burst
- ZZ is pulled low to leave the chip enabled
- GLOBALW_n is pulled high to disable the global write. This is the default behavior for GLOBALW_n that can be changed.
- CE2 and CE3_n are wired high and low respectively to be enabled and to make CE1_n the master chip enable. This is the default behavior for GLOBALW_n that can be changed.



See www.cypress.com for detailed information about the SSRAM chip.

DDR SDRAM Chip (U63)

U63 is a Micron DDR SDRAM chip. The part number is MT46V16M16P-6T. The DDR SDRAM pins are connected to the FPGA as shown in [Table 2–7](#). Altera provides a DDR SDRAM controller that allows a Nios II processor to access the DDR SDRAM device as a large, linearly-addressable memory.

Table 2–7. DDR SDRAM Pin Table

FPGA Pin	U63 Pin	Board Net Name
DD9	2	sdrām_dq0
D8	4	sdrām_dq1
C8	5	sdrām_dq2
A9	7	sdrām_dq3
B11	8	sdrām_dq4
C11	10	sdrām_dq5
A10	11	sdrām_dq6
D10	13	sdrām_dq7
A5	54	sdrām_dq8
B5	56	sdrām_dq9
D6	57	sdrām_dq10
A6	59	sdrām_dq11
A8	60	sdrām_dq12

Table 2–7. DDR SDRAM Pin Table (Continued)

FPGA Pin	U63 Pin	Board Net Name
A7	62	sdram_dq13
C7	63	sdram_dq14
D7	65	sdram_dq15
C9	16	sdram_dqs0
C6	51	sdram_dqs1
C10	20	sdram_dm0
B7	47	sdram_dm1
B10	29	sdram_a0
B9	30	sdram_a1
B8	31	sdram_a2
B6	32	sdram_a3
C5	35	sdram_a4
E11	36	sdram_a5
E10	37	sdram_a6
E9	38	sdram_a7
E8	39	sdram_a8
E7	40	sdram_a9
F11	28	sdram_a10
F10	41	sdram_a11
F8	42	sdram_a12
F10	26	sdram_ba0
G11	27	sdram_ba1
B3	22	sdram_cas_n
F13	44	sdram_cke
E12	24	sdram_cs_n
A3	23	sdram_ras_n
B4	21	sdram_we_n
C4	46	sdram_clk_n
C3	45	sdram_clk_p



See www.micron.com for detailed information.

Flash Memory (U5)

U5 is an 8-bit, 16 MByte AMD flash memory device connected to the FPGA. The part number is S29GL128M10TFIR1. Refer to [Table 2–8](#) for connections between the FPGA and the flash memory chip. U5 can be used for two purposes:

1. A Nios II embedded processor implemented on the FPGA can use the flash memory as general-purpose memory and non-volatile storage.
2. The flash memory can hold FPGA configuration data that is used by the configuration controller to load the FPGA at power-up. Refer to [“Configuration Controller Device \(U3\)”](#) on page 2–33 for related information.

A Nios II processor design in the FPGA can identify the 16 MByte flash memory in its address space, and can program new data (either new FPGA configuration data, Nios II software, or both) into flash memory. The Nios II development software includes subroutines for writing and erasing flash memory.



The flash memory device shares address and data connections with the Ethernet MAC/PHY device.

Table 2–8. Flash Memory Pin Table

FPGA Pin	U5 Pin	Board Net Name
V25	51	fe_a0
U26	31	fe_a1
U25	26	fe_a2
T25	25	fe_a3
T24	24	fe_a4
V20	23	fe_a5
V19	22	fe_a6
U20	21	fe_a7
U19	20	fe_a8
T22	10	fe_a9
T21	9	fe_a10
T20	8	fe_a11
T19	7	fe_a12
U22	6	fe_a13
U21	5	fe_a14
V22	4	fe_a15

Table 2–8. Flash Memory Pin Table (Continued)

FPGA Pin	U5 Pin	Board Net Name
V21	3	fe_a16
W22	54	fe_a17
W21	19	fe_a18
V24	18	fe_a19
V23	11	fe_a20
U24	12	fe_a21
U23	15	fe_a22
R24	2	fe_a23
D15	35	fe_d0
G15	37	fe_d1
E19	39	fe_d2
D20	41	fe_d3
G19	44	fe_d4
D19	46	fe_d5
E20	48	fe_d6
F20	50	fe_d7
H19	32	flash_cs_n
H20	34	flash_oe_n
V26	13	flash_rw_n
H22	16	flash_wp_n
K18	53	flash_byte_n (1)
W25	17	flash_ry_by_n

Note to Table 2–8:
(1) BYTE_n on U5 is pulled low to keep the flash memory in byte mode which restricts the usable modes of operation.

The on-board configuration controller makes assumptions about what resides where in flash memory. For details refer to “SW10–Reset, Config” on page 2–35.




See www.amd.com for detailed information about the flash memory device.

Ethernet MAC/PHY (U4) & RJ45 Connector (RJ1)

The LAN91C111 chip (U4) is a 10/100 Ethernet media access control and physical interface (MAC/PHY) chip. The control pins of U4 are connected to the FPGA so that Nios II systems can access Ethernet networks via the RJ-45 connector (RJ1) as shown in [Figure 2-4](#). The Nios II development tools include hardware and software components that allow Nios II processor systems to communicate with the LAN91C111 Ethernet device.

Figure 2-4. Ethernet RJ-45 Connector



Refer to [Table 2-9](#) for connections between the FPGA and the MAC/PHY device.



The Ethernet MAC/PHY device shares both address and data connections with the flash memory.

Table 2-9. Ethernet MAC/PHY Pin Table

FPGA Pin	U4 Pin	Pin Function	Board Net Name (1)
AB25	41	Address Enable	enet_aen
W20	43	Synchronous Ready	enet_srdy_n
W19	40	VL Bus Access	enet_vlbus_n
Y21	45	Local Device	enet_ldev_n
Y20	38	IO Char Ready	enet_iochrdy
AA22	37	Address Strobe	enet_ads_n
AA21	42	Local Bus Clock	enet_lclk
W26	46	Ready/Return	enet_rdyrtn_n
AA26	35	Bus Cycle	enet_cycle_n
AA25	36	Write/Read	enet_w_r_n
W24	34	Bus Chip Select	enet_datacs_n
W23	29	Interrupt	enet_intr0

Table 2–9. Ethernet MAC/PHY Pin Table (Continued)

FPGA Pin	U4 Pin	Pin Function	Board Net Name (1)
Y24	94	Byte Enable 0	enet_be_n0
Y23	95	Byte Enable 1	enet_be_n1
AA24	96	Byte Enable 2	enet_be_n2
AA23	97	Byte Enable 3	enet_be_n3
Y26	31	Read	enet_ior_n
Y25	32	Write	enet_iow_n
U26	78	Address Line	fe_a1
U25	79	Address Line	fe_a2
T25	80	Address Line	fe_a3
T24	81	Address Line	fe_a4
V20	82	Address Line	fe_a5
V19	83	Address Line	fe_a6
U20	84	Address Line	fe_a7
U19	85	Address Line	fe_a8
T22	86	Address Line	fe_a9
T21	87	Address Line	fe_a10
T20	88	Address Line	fe_a11
T19	89	Address Line	fe_a12
U22	90	Address Line	fe_a13
U21	91	Address Line	fe_a14
V22	92	Address Line	fe_a15
D15	107	Data Line	fe_d0
G15	106	Data Line	fe_d1
E19	105	Data Line	fe_d2
D20	104	Data Line	fe_d3
G19	102	Data Line	fe_d4
D19	101	Data Line	fe_d5
E20	100	Data Line	fe_d6
F20	99	Data Line	fe_d7
M20	76	Data Line	fe_d8
M19	75	Data Line	fe_d9
N20	74	Data Line	fe_d10
N19	73	Data Line	fe_d11
N22	71	Data Line	fe_d12

Table 2–9. Ethernet MAC/PHY Pin Table (Continued)

FPGA Pin	U4 Pin	Pin Function	Board Net Name (1)
N21	70	Data Line	fe_d13
M22	69	Data Line	fe_d14
M21	68	Data Line	fe_d15
M24	66	Data Line	fe_d16
M23	65	Data Line	fe_d17
L19	64	Data Line	fe_d18
L18	63	Data Line	fe_d19
L21	61	Data Line	fe_d20
L20	60	Data Line	fe_d21
L23	59	Data Line	fe_d22
L22	58	Data Line	fe_d23
K20	56	Data Line	fe_d24
K19	55	Data Line	fe_d25
K22	54	Data Line	fe_d26
K21	53	Data Line	fe_d27
J20	51	Data Line	fe_d28
J19	50	Data Line	fe_d29
J22	49	Data Line	fe_d30
J21	48	Data Line	fe_d31

Note to Table 2–9:

(1) Nets fe_a0 and fe_a16 to fe_a23 do not connect to U4.



See www.smc.com for detailed information about the LAN91C111 device.

Serial Connector (J19)

J19 is a standard DB-9 serial connector. It is typically used for communication between the FPGA and a host computer via an RS-232 serial cable. Level-shifting buffer (U52) is used between J19 and the FPGA because the FPGA device cannot interface to RS-232 voltage levels directly.

J19 is able to transmit all RS-232 signals. Alternately, the FPGA design can use only the signals it needs, such as J19's RXD and TXD pins. LEDs are connected to the RXD and TXD signals and visually indicate when data is being transmitted or received. Figure 6 and Table 2-10 show the pin connections between the serial connectors and the FPGA.

Figure 2-5. Serial Connector J19




Table 2-10. Serial Connector Pin Table

FPGA Pin	J19 Pin	Board Net Name
AD26	3	serial_rxd
AB23	2	serial_txd
AC25	4	serial_dtr
AC24	1	serial_dcd
AB24	6	serial_dsr
K23	9	serial_ri
AB26	8	serial_cts
AD25	7	serial_rts

Expansion Prototype Connectors (PROTO1 & PROTO2)

PROTO1 and PROTO2 are standard-footprint, mechanically-stable connectors that can be used (for example) as an interface to a special-function daughter card. Headers J11, J12, and J13 collectively form PROTO1, and J15, J16 and J17 collectively form PROTO2.

The expansion prototype connector interface includes:

- 41 I/O pins for prototyping. All 41 I/O pins connect to user I/O pins on the FPGA. Each signal passes through analog switches to protect the FPGA from 5.0 V logic levels. These analog switches are permanently enabled. The output logic-level on the expansion prototype connector pins is 3.3 V.
 - PROTO1 switches: U19, U20, U21, U22 and U25
 - PROTO2 switches: U27, U28, U29, U30 and U31
- A buffered, zero-skew copy of the on-board oscillator output from U2.
- A buffered, zero-skew copy of the FPGA phase-locked loop (PLL) output.
- A power-on reset signal that is asserted low.
- Five regulated 3.3 V power-supply pins (2 A total max load for both PROTO1 & PROTO2).
- One regulated 5.0 V power-supply pin (1 A total max load for both PROTO1 & PROTO2).
- Numerous ground connections.

The PROTO1 expansion prototype connector shares FPGA I/O pins with the CompactFlash connector (CON3). Designs can use either the PROTO1 connector or the CompactFlash connector.

 Do not connect cards to PROTO1 and CON3 at the same time. Damage to one or both cards might result.



See the Altera web site for a list of available expansion daughter cards that can be used with the Nios development board at www.altera.com/devkits.

Table 2–11, Figure 2–6 and Figure 2–7 show connections from the PROTO1 expansion headers to the FPGA.

Figure 2–6. PROTO1 Expansion Prototype Connector - J11, J12 & J13




Figure 2–7. PROTO1 Pin Information – J11, J12, & J13

J11		
proto1_RESET_n	1	○
proto1_io0	3	○
proto1_io2	5	○
proto1_io4	7	○
proto1_io6	9	○
proto1_io8	11	○
proto1_io10	13	○
proto1_io12	15	○
proto1_io14	17	○
GND	19	●
proto1_io16	21	○
proto1_io17	23	○
proto1_io18	25	○
proto1_io19	27	○
proto1_io21	29	○
proto1_io22	31	○
proto1_io24	33	○
proto1_io25	35	○
proto1_io27	37	○
proto1_io28	39	○
GND	2	○
proto1_io1	4	○
proto1_io3	6	○
proto1_io5	8	○
proto1_io7	10	○
proto1_io9	12	○
proto1_io11	14	○
proto1_io13	16	○
proto1_io15	18	○
NC	20	○
GND	22	○
GND	24	○
GND	26	○
proto1_io20	28	○
GND	30	○
proto1_io23	32	○
NC	34	○
proto1_io26	36	○
proto1_cardsel_n	38	○
GND	40	○

J12		
GND	1	●
proto1_io40	3	○
proto1_io30	5	○
proto1_io32	7	○
proto1_io34	9	○
proto1_io36	11	○
proto1_io38	13	○
VCC5	2	○
proto1_io29	4	○
proto1_io31	6	○
proto1_io33	8	○
proto1_io35	10	○
proto1_io37	12	○
proto1_io39	14	○

J13		
(1) Vunreg	1	●
NC	3	○
VCC3_3	5	●
VCC3_3	7	●
proto1_osc	9	○
proto1_pllclk	11	○
proto1_clkout	13	○
VCC3_3	15	●
VCC3_3	17	●
VCC3_3	19	●
GND	2	○
GND	4	○
GND	6	○
GND	8	○
GND	10	○
GND	12	○
GND	14	○
GND	16	○
GND	18	○
GND	20	○

Notes to Figure 2–7:

- (1) Unregulated voltage from DC power supply.
- (2) Clk from board oscillator.
- (3) Clk from FPGA.
- (4) Clk output from PROTO1 card to FPGA.

Table 2–11. PROTO1 Pin Table

FPGA Pin	PROTO1 Pin	Connector	Board Net Name
J11			
U3 pin 56	1	J11	proto1_RESET_n
C1	3	J11	proto1_io0
C2	4	J11	proto1_io1
D2	5	J11	proto1_io2
D3	6	J11	proto1_io3
E1	7	J11	proto1_io4
E2	8	J11	proto1_io5
E3	9	J11	proto1_io6
E4	10	J11	proto1_io7
F1	11	J11	proto1_io8
F2	12	J11	proto1_io9
F3	13	J11	proto1_io10
F4	14	J11	proto1_io11
G3	15	J11	proto1_io12
G4	16	J11	proto1_io13
H3	17	J11	proto1_io14
H4	18	J11	proto1_io15
J3	21	J11	proto1_io16
J4	23	J11	proto1_io17
G1	25	J11	proto1_io18
G2	27	J11	proto1_io19
H1	28	J11	proto1_io20
H2	29	J11	proto1_io21
K3	31	J11	proto1_io22
K4	32	J11	proto1_io23
J1	33	J11	proto1_io24
J2	35	J11	proto1_io25
K1	36	J11	proto1_io26
KK2	37	J11	proto1_io27
J8	38	J11	proto1_cardsel_n
L2	39	J11	proto1_io28

Table 2–11. PROTO1 Pin Table (Continued)

FPGA Pin	PROTO1 Pin	Connector	Board Net Name
J12			
J7	3	J12	proto1_io40
L3	4	J12	proto1_io29
M1	5	J12	proto1_io30
M2	6	J12	proto1_io31
G6	7	J12	proto1_io32
G7	8	J12	proto1_io33
H5	9	J12	proto1_io34
H6	10	J12	proto1_io35
J5	11	J12	proto1_io36
J6	12	J12	proto1_io37
H7	13	J12	proto1_io38
H8	14	J12	proto1_io39
J13			
U2 pin 19	9	J13	proto1_osc
K6	11	J13	proto1_pllclk
R26	13	J13	proto1_clkout

Table 2–12, Figure 2–8 and Figure 2–9 show connections from the PROTO2 expansion headers to the FPGA. Unless otherwise noted, the labels indicate FPGA pin numbers


Figure 2–8. PROTO2 Expansion Prototype Connector - J15, J16 & J17

Figure 2–9. PROTO2 Pin Information – J15, J16 & J17

J15		J16		J17	
1	GND	1	proto2_RESET_n	1	(1) Vunreg
2	VCC5	2	GND	2	GND
3	proto2_io29	3	proto2_io1	3	NC
4	proto2_io31	4	proto2_io3	4	GND
5	proto2_io33	5	proto2_io5	5	VCC3_3
6	proto2_io35	6	proto2_io7	6	VCC3_3
7	proto2_io37	7	proto2_io9	7	proto2_osc
8	proto2_io39	8	proto2_io11	8	proto2_pllclk
9		9	proto2_io13	9	proto2_clkout
10		10	proto2_io15	10	GND
11		11	proto2_io17	11	GND
12		12	proto2_io19	12	VCC3_3
13		13	proto2_io21	13	VCC3_3
		14	proto2_io23	14	GND
		15	proto2_io25	15	GND
		16	proto2_io27	16	GND
		17	proto2_io29	17	GND
		18	proto2_io31	18	VCC3_3
		19	proto2_io33	19	VCC3_3
		20	proto2_io35	20	GND
		21	proto2_io37		
		22	proto2_io39		
		23	GND		
		24	GND		
		25	GND		
		26	GND		
		27	GND		
		28	proto2_io20		
		29	GND		
		30	GND		
		31	proto2_io23		
		32	proto2_io25		
		33	NC		
		34	proto2_io26		
		35	proto2_io28		
		36	proto2_io30		
		37	proto2_io32		
		38	proto2_io34		
		39	proto2_io36		
		40	proto2_io38		

Notes to Figure 2–9:

- (1) Unregulated voltage from DC power supply.
- (2) Clk from board oscillator.
- (3) Clk from FPGA.
- (4) Clk output from PROTO2 card to FPGA.

Table 2–12. PROTO2 Pin Table

FPGA Pin	PROTO2 Pin	Connector	Board Net Name
J16			
U3 pin 57	1	J16	proto2_RESET_n
T2	3	J16	proto2_io0
T3	4	J16	proto2_io1
U1	5	J16	proto2_io2
U2	6	J16	proto2_io3
V1	7	J16	proto2_io4
V2	8	J16	proto2_io5
W1	9	J16	proto2_io6
W2	10	J16	proto2_io7
Y1	11	J16	proto2_io8
Y2	12	J16	proto2_io9
AA1	13	J16	proto2_io10
AA2	14	J16	proto2_io11
AB1	15	J16	proto2_io12
AB2	16	J16	proto2_io13
W3	17	J16	proto2_io14
W4	18	J16	proto2_io15
Y3	21	J16	proto2_io16
Y4	23	J16	proto2_io17
AA3	25	J16	proto2_io18
AA4	27	J16	proto2_io19
AB3	28	J16	proto2_io20
AB4	29	J16	proto2_io21
AC2	31	J16	proto2_io22
AC3	32	J16	proto2_io23
AD1	33	J16	proto2_io24
AD2	35	J16	proto2_io25
Y7	36	J16	proto2_io26
W9	37	J16	proto2_io27
Y10	38	J16	proto2_cardsel_n
W10	39	J16	proto2_io28


Table 2–12. PROTO2 Pin Table (Continued)

FPGA Pin	PROTO2 Pin	Connector	Board Net Name
J15			
AE3	3	J15	proto2_io40
Y9	4	J15	proto2_io29
AD7	5	J15	proto2_io30
W11	6	J15	proto2_io31
V12	7	J15	proto2_io32
AD8	8	J15	proto2_io33
Y11	9	J15	proto2_io34
W12	10	J15	proto2_io35
Y12	11	J15	proto2_io36
AD11	12	J15	proto2_io37
AE11	13	J15	proto2_io38
AB8	14	J15	proto2_io39
J17			
U2 pin 18	9	J17	proto2_osc
K7	11	J17	proto2_pllclk
P2	13	J17	proto2_clkout

CompactFlash Connector (CON3)

The CompactFlash connector header (CON3) enables hardware designs to access a CompactFlash card. Refer to [Figure 2–10](#). The following two access modes are supported:

- ATA (hot swappable mode)
- IDE (IDE hard disk mode)

Figure 2–10. CompactFlash Connector

Most pins of CON3 connect to I/O pins on the FPGA. The following pins have special connections:

- Pin 13 and 38 of CON3 (VCC) are driven by a power MOSFET that is controlled by an FPGA I/O pin. These connections allow the FPGA to control power to the CompactFlash card for the IDE connection mode.
- Pin 26 of CON3 (-CD1) is pulled up to 5 V through a 10 k Ω resistor. This signal is used to detect the presence of a CompactFlash card; when the card is not present, the signal is pulled high through the pull-up resistor.
- Pin 41 of CON3 (RESET) is pulled up to 5.0 V through a 10 k Ω resistor, and is controlled by the EPM7256AE configuration controller. The FPGA can cause the configuration controller to assert RESET, but the FPGA does not drive this signal directly.

The CompactFlash connector shares several FPGA I/O pins with expansion prototype connector PROTO1. Refer to “[Expansion Prototype Connectors \(PROTO1 & PROTO2\)](#)” on page 2–16 for details on PROTO1.



Do not connect cards to PROTO1 and CON3 at the same time. Damage to one or both cards might result.

Table 2–13 lists connections between CON3 and the FPGA.

FPGA Pin	CON3 Pin	Pin Function	Board Net Name (1)
C1	6	D7	proto1_io0
C2	47	D8	proto1_io1

Table 2–13. CompactFlash Pin Table (Continued)

FPGA Pin	CON3 Pin	Pin Function	Board Net Name (1)
D2	5	D6	proto1_io2
D3	48	D9	proto1_io3
E1	4	D5	proto1_io4
E2	49	D10	proto1_io5
E3	3	D4	proto1_io6
E4	27	D11	proto1_io7
F1	2	D3	proto1_io8
F2	28	D12	proto1_io9
F3	23	D2	proto1_io10
F4	29	D13	proto1_io11
G3	22	D1	proto1_io12
G4	30	D14	proto1_io13
H3	21	D0	proto1_io14
H4	31	D15	proto1_io15
J4	35	IOWR_n	proto1_io17
G1	34	IORD_n	proto1_io18
G2	42	IORDY_n	proto1_io19
K3	37	INTRQ	proto1_io22
K4	24	IOCS16_n	proto1_io23
J1	19	A1	proto1_io24
J2	20	A0	proto1_io25
K1	18	A2	proto1_io26
KK2	7	CS0_n	proto1_io27
L2	45	DASP	proto1_io28
L3	8	A10	proto1_io29
M1	46	PDIAG	proto1_io30
M2	10	A9	proto1_io31
G6	11	A8	proto1_io32
G7	12	A7	proto1_io33
H5	14	A6	proto1_io34
H6	15	A5	proto1_io35
J5	16	A4	proto1_io36
J6	17	A3	proto1_io37
H7	36	WE_n	proto1_io38

Table 2–13. CompactFlash Pin Table (Continued)

FPGA Pin	CON3 Pin	Pin Function	Board Net Name (1)
H8	43	INPACK_n	proto1_io39
J7	44	REG_n	proto1_io40
AE7	32	CS1_n	cf_cs_n
AE8	9	ATA_SEL_n	cf_atasel_n
AB12	5	Power supply enable	cf_power (2)
AB11	26	CD1_n	cf_present_n
57 (U3)	41	RESET#	proto1_RESET_n (3)

Notes to Table 2–13:

(1) Nets proto_io16, proto_io20, and proto_io21 do not connect to CON3.

(2) The FPGA I/O pin controls a power MOSFET that supplies 5.0 V V_{CC} to this net.

(3) proto1_RESET_n is driven by the EPM7256AE configuration controller device (U3).




For more information on the CompactFlash connector (CON3), see www.compactflash.org and www.molex.com.

PMC Connector (JH1 & JH2)

The PCI mezzanine card (PMC) connector, formed by JH1 and JH2, allows Nios II systems in the FPGA to interface to daughter cards using the standard 32-bit PMC form factor. Refer to [Figure 2–11](#). The PMC connector is capable of running at 33MHz or 66 MHz, and is configured as the PMC host.

w Before connecting a daughter card to the PMC connector, the FPGA must first be configured with a design that includes a PMC interface. Damage to either the FPGA or daughter card can result if the FPGA is not configured correctly.

The factory-programmed Nios II reference design does not include a PMC interface.

Figure 2–11. PMC Connector

The PMC connector supplies +3.3 V, +5.0 V and ± 12 . V, as required by the PCI specification. However, DC power regulators for these supplies cannot provide enough power to fully satisfy the PCI power specification. The current that the board can supply through JH1 and JH2 is dependent on the design configured in the FPGA. As a general guideline, if the PMC card power requirements exceed the specifications shown in [Table 2–14](#), you must connect an external power source.

Table 2–14. PMC Card Power Specifications

DC Supply	Maximum Power	Apply External Power Source
+3.3V	9.5 Watts	J29
+5V	15 Watts	J28
+12V	45 Watts	J31
-12V	1.2 Watts	TP13

- w When connecting an external power supply, the fuse for the corresponding voltage should be removed from the development board to prevent the two power supplies from interfering with each other. Refer to [“Power-Supply Circuitry”](#) on [page 2–44](#) for more information.

Table 2–15 lists the connections between the PMC connector and the FPGA.

FPGA Pin	JH1 & JH2 Pin	Connector	Board Net Name
AF22	61	JH1	pmc_ad0
AE22	60	JH1	pmc_ad1
AD22	59	JH1	pmc_ad2
AF21	58	JH1	pmc_ad3
AD21	55	JH1	pmc_ad4
AF20	54	JH1	pmc_ad5
AD20	53	JH1	pmc_ad6
AF19	51	JH2	pmc_ad7
AE19	49	JH2	pmc_ad8
AD19	49	JH1	pmc_ad9
AF18	48	JH2	pmc_ad10
AC18	48	JH1	pmc_ad11
Y18	47	JH1	pmc_ad12
AF17	46	JH2	pmc_ad13
AC17	45	JH2	pmc_ad14
Y17	46	JH1	pmc_ad15
AE16	31	JH2	pmc_ad16
AD16	32	JH1	pmc_ad17
AB16	29	JH2	pmc_ad18
AA16	29	JH1	pmc_ad19
Y16	28	JH2	pmc_ad20
AF10	28	JH1	pmc_ad21
AD10	27	JH1	pmc_ad22
AF9	26	JH2	pmc_ad23
AC9	23	JH2	pmc_ad24
AC8	23	JH1	pmc_ad25
AF7	22	JH2	pmc_ad26
AE6	22	JH1	pmc_ad27
AF5	21	JH1	pmc_ad28
AE5	20	JH2	pmc_ad29
AE4	19	JH2	pmc_ad30
AD4	20	JH1	pmc_ad31

Table 2–15. PMC Connector Pin Table (Continued)

FPGA Pin	JH1 & JH2 Pin	Connector	Board Net Name
AC6	52	JH1	pmc_be_n0
AF6	43	JH2	pmc_be_n1
AA10	32	JH2	pmc_be_n2
AC7	26	JH1	pmc_be_n3
AF8	43	JH1	pmc_par
AE14	13	JH1	pmc_clk
AA11	39	JH2	pmc_perr_n
AC10	42	JH2	pmc_serr_n
AA12	37	JH1	pmc_devsel_n
AD9	38	JH2	pmc_stop_n
AC14	36	JH1	pmc_irdy_n
AB9	4	JH1	pmc_inta_n
AB7	5	JH1	pmc_intb_n
V10	6	JH1	pmc_intc_n
AA8	9	JH1	pmc_intd_n
AD14	13	JH2	pmc_reset_n
AE9	33	JH1	pmc_frame_n
AF15	35	JH2	pmc_trdy_n
AB10	25	JH2	pmc_idsel
AD6	16	JH1	pmc_gnt_n
AD5	17	JH1	pmc_req_n
AD3	40	JH1	pmc_lock_n
AF3	47	JH2	pmc_m66en
AE23	64	JH1	pmc_req64_n

Mictor Connector (J25)

The Mictor connector (J25) can be used to transmit up to 27 high-speed I/O signals with very low noise via a shielded Mictor cable. J25 can be used as a debug port for the Nios II processor or as a general-purpose I/O connector to the FPGA. Twenty-five of the Mictor connector signals are used as data, and two signals are used as clock input and clock output.


Most pins on J25 connect to I/O pins on the FPGA (U60). For systems that do not use the Mictor connector for debugging the Nios II processor, any on-chip signals can be routed to I/O pins and probed at J25. External scopes and logic analyzers can connect to J25 and analyze a large number of signals simultaneously.



For details on Nios II debugging products that use the Mictor connector, see www.altera.com.

Figure 2–12 shows an example of an in-target system analyzer ISA-Nios/T by First Silicon Solutions (FS2) Inc. connected to the Mictor connector. For details, see www.fs2.com.

Figure 2–12. An ISA-Nios/T Connecting to the Mictor Connector (J25)



Five of the signals connect to both the JTAG pins on the FPGA (U60), and the FPGA's JTAG connector (J24). The JTAG signals have special usage requirements. J25 and J24 cannot be used at the same time.

Figure 2–13 below shows connections from the Mictor connector to the FPGA.

Figure 2–13. Mictor Connector Signaling




Table 2–16 shows the pin out information for J25.

<i>Table 2–16. Mictor Connector Pin Table</i>		
FPGA Pin	J25 Pin	Board Net Name
AD15	5	mictor_clk
T4	38	mictor0
T5	36	mictor1
U3	34	mictor2
U4	32	mictor3
T8	30	mictor4
T9	28	mictor5
V3	26	mictor6
V4	24	mictor7
U5	22	mictor8
U6	20	mictor9
T6	18	mictor10
T7	16	mictor11
U7	10	mictor12
U8	8	mictor13
V5	37	mictor14
V6	35	mictor15
V7	33	mictor16
V8	31	mictor17
WW5	29	mictor18
W6	27	mictor19
W	25	mictor20
W8	23	mictor21
AA5	13	mictor22
AA6	9	mictor23
Y6	7	mictor24
R1	6	mictor_trclk

Test Points (TP1 – TP8)

TP1 – TP8 are test points connected to I/O pins on the FPGA. FPGA designs can route signals to these I/O pins to be probed. TP1 –TP8 also connect to the configuration controller (U3).

Table 2–17 lists the connections between the FPGA, U3, and the test points.

Test Point	FPGA Pin	CPLD Pin	Board Net Name
TP1	V18	75	pld_user0
TP2	AC19	76	pld_user1
TP3	W16	77	pld_user2
TP4	W17	78	pld_user3
TP5	AE17	79	pld_user4
TP6	AE18	80	pld_user5
TP7	AE20	81	pld_user6
TP8	AE21	83	pld_user7

EPCS64 Serial Configuration Device (U69)

U69 is a serial configuration device connected to the FPGA. Serial configuration devices are flash memory devices with a serial interface which can store configuration data, and load the data into the FPGA upon power up or reconfiguration. U69 can store FPGA configuration data, or Nios II program data, or both.

Table 2–18 lists the connections between U69 and the FPGA.

FPGA Pin	U69 Pin	Board Net Name
C24	16	pld_dclk
E16	8	fe_d0
E14	7	pld_cs_n
G14	15	pld_asdo

The SOPC Builder EPCS Serial Flash Controller component enables Nios II processor systems to access the EPCS device. Nios II processor systems can read program code or data from the device, and can write new data into the EPCS device.

U69 is blank by default. The Quartus II software can program FPGA configuration data (a .**pcf** file) into U69 through an Altera download cable connected to J27. Alternately, software running on a Nios II processor design can write configuration data to U69.

 The orientation of J27 is the reverse of J24.



See the *Serial Configuration Devices* chapter in Altera's *Configuration Device Handbook* for more information about the EPCS64 device. See the *EPCS Device Controller Core with Avalon Interface* chapter in the *Quartus II Handbook, Volume 5: Altera Embedded Peripherals* for information about the EPCS serial flash controller component in SOPC Builder.

Configuration Controller Device (U3)

The configuration controller (U3) is an Altera MAX7000 EPM7256AE device. It comes preprogrammed with logic for managing board reset conditions and configuring the FPGA from data stored in flash memory and the EPCS64 serial configuration device (U69).

FPGA configuration data files are generated by the Quartus II software. The Nios II integrated development environment (IDE) can write new configuration data to the board's flash memory.



For complete details on the configuration controller connections, see the board schematic. For detailed information about the Altera EPM7256AE device, see the MAX 7000 family literature at www.altera.com/literature/lit-m7k.html. For details on programming configuration data to flash memory, see the *Nios II Flash Programmer User Guide*, or refer to the Nios II IDE help system.

Configuration-Status LEDs

The configuration controller is connected to four status LEDs that show the configuration status of the board at a glance as shown in [Figure 2-14](#). The LEDs indicate which configuration, if any, was loaded into the FPGA at power-on as shown in [Table 2-19](#).

Figure 2-14. LED1 – LED 4




Table 2–19. Configuration Status LED Indicators

LED	Led Name	Color	Description
LED3	Loading	Green	This LED blinks while the configuration controller is actively transferring data from flash memory into the FPGA.
LED4	Error	Red	If this LED is on, then configuration was not transferred from flash memory into the FPGA. This can happen if, for example, the flash memory does not contain either a valid user or factory configuration.
LED1	User	Green	This LED turns on when the user configuration is being transferred from flash memory and stays illuminated when the user configuration data is successfully loaded into the FPGA. If the FPGA was successfully configured by the EPCS64, LED1 will blink slowly.
LED2	Factory	Amber	This LED turns on when the factory configuration is being transferred from flash memory and stays illuminated if the factory configuration was successfully loaded into the FPGA.
LED6	LED6	Red	This LED is an indicator of the CONFIG_DONE_signal from the FPGA. This LED illuminates when FPGA configuration completes successfully and CONFIG_DONE goes high.
LED7	LED7	Red	This LED is an indicator of the flash_CE_n line. It illuminates when the flash is being accessed and the CE_n line is being asserted.


Configuration & Reset Buttons

The Nios development board uses dedicated switches SW8, SW9 and SW10 for the following fixed functions:

SW8 – CPU Reset


When SW8 is pressed, a logic 0 is driven onto the FPGA I/O pin C5 (DEV_CLRn). The result of pressing SW8 depends on how the FPGA is configured. Refer to [Figure 2–15](#).

The factory-programmed Nios II reference design treats SW8 as a CPU-reset button. The Nios II reference design resets and starts executing code from its reset address when SW8 is pressed.

Figure 2-15. CPU Reset Button


SW9 – Factory Config

Pressing Factory Config (SW9) commands the configuration controller to reconfigure the FPGA with the factory configuration. Refer to [Figure 2-16](#).

Figure 2-16. Factory Config Button

SW10 – Reset, Config

Reset, Config (SW10) is the power-on reset button. Refer to [Figure 2-17](#). When SW10 is pressed, a logic 0 is driven to the power on reset controller (U18). Refer to [“Power-Supply Circuitry” on page 2-44](#) for more details. Whenever SW10 is pressed, the configuration controller attempts to reconfigure the FPGA.

Figure 2–17. Reset, Config Button

Reset Distribution

The EPM7256AE device takes a power-on reset pulse from the Linear Technologies 1326 power-sense/reset-generator chip (U18) and distributes it (through internal logic) to other reset pins on the board, that include the following:

- LAN91C111 (Ethernet MAC/PHY) reset
- Flash memory reset
- CompactFlash reset
- Reset signals delivered to the expansion prototype connectors (PROTO1 & PROTO2)

Starting Configuration

The following four methods start a configuration sequence:

1. Board power-on
2. Pressing the Reset, Config button (SW10).
3. Asserting (driving 0 volts on) the `p1d_reconfigreq_n` input pin of the EPM7256AE device (U3 pin 94) from the FPGA (U60 pin H16).
4. Pressing the Factory Config button (SW9).

Factory & User Configurations

The configuration controller can manage two separate FPGA configurations stored in flash memory U5. These two configurations are referred to as the factory configuration and the user configuration. A

Nios II reference design is factory-programmed into the factory configuration region of the flash memory. In addition, the FPGA can be configured by the EPCS64 serial configuration device.

Configuration Process

At power-up or reset, the configuration controller attempts to configure the FPGA with data from one of three sources, in the following order:

1. The EPCS64 serial configuration device
2. The user configuration from flash memory
3. The factory configuration from flash memory

First, the configuration controller puts the FPGA in active serial (AS) configuration mode. The FPGA then attempts to read configuration data from the EPCS64. If the FPGA finishes configuration successfully, the configuration controller stops. If there is a valid configuration image stored in the EPCS64, then the FPGA will only boot from the EPCS64 or from the factory image of flash memory when the SW9 switch is depressed. The user segment of EPCS64 will be ignored.

If configuration from the EPCS64 does not succeed, the configuration controller puts the FPGA into passive serial (PS) mode and attempts to load the user configuration from CFI flash memory (U5). If this also fails (because the user configuration is either invalid or not present), the configuration controller attempts to load the factory configuration from flash memory.

When SW9 (Factory Config) is pressed, the configuration controller ignores the user configuration and EPCS64, and configures the FPGA with the factory configuration. SW9 provides an escape from a situation in which a valid-but-nonfunctional design is present in user flash memory or the EPCS64.



If the FPGA is configured in passive serial mode (such as when it is configured from the CFI flash), the EPCS64 device is not available to the FPGA after configuration.

Flash Memory Partitions

The configuration controller expects user and factory configuration data to be stored at fixed locations (offsets) in flash memory. In addition, the factory-programmed reference design expects Nios II software and data to exist at certain locations in flash memory. [Table 2–20](#) shows the expected flash memory partitioning.

Offset	Usage	Factory-Programmed Content
0x00000000 - 0x000FFFFF	User Application Space (8 MB)	Web Server Software
0x00100000 - 0x001FFFFF		Web Pages
0x00200000 - 0x007FFFFF		
0x00800000 - 0x00BFFFFF	User Configuration (4 MB)	
0x00C00000 - 0x00FEFFFF	Factory Configuration (4032 KB)	Nios II Processor Reference Design
0x00FF0000 - 0x00FFFFFF	Persistent Data (64 KB)	Network Settings for Web Server



This partitioning scheme is merely a convention used by the configuration controller and the factory-programmed reference design. Custom FPGA designs can use the flash memory space in any way necessary.



Altera recommends that you not overwrite the factory-programmed flash memory contents. Without a valid factory configuration, the configuration controller may not be able to successfully configure the FPGA. If you alter the factory configuration, you can restore the board to its factory-programmed state. Refer to *Appendix B: Restoring the Factory Configuration*.

User Application Space

The lower 8 MB of flash memory is the user application space. This is free space for user designs to store code and data for Nios II programs. The Nios II IDE allows you to compile Nios II programs and program them into the user application space.

User Configuration

The user configuration partition is 4 MB, starting at offset 0x00800000. This section contains the FPGA configuration data for the user configuration. Nios II development tools include documentation on how to create your own user configuration image and program it into flash memory.

Factory Configuration

The factory configuration partition is 4032 KB, starting at offset 0x00C00000. This section contains the FPGA configuration data for the factory configuration. The Nios II processor system in the factory configuration is designed to start executing code from offset 0x00000000 in the flash memory. The Nios II development tools include the source files for the factory programmed hardware and software reference designs.

Persistent Data



The persistent data partition is 64 KB, starting at offset 0x00FF0000. This partition is for maintaining nonvolatile settings and data, such as the MAC address and IP address for the factory-programmed web server reference design. Persistent data is technically no different than other application data, but it is often convenient to think of certain data as independent from the user hardware or software.

JTAG Connectors (J24 & J5)

The Nios development board has two 10-pin JTAG headers (J24 and J5) compatible with Altera download cables, such as the USB-Blaster™. On the Nios development board, each JTAG header connects to one Altera device and forms a single-device JTAG chain. J24 connects to the FPGA (U60), and J5 connects to the EPM7256AE device (U3).

JTAG Connector to FPGA (J24)

J24 connects to the JTAG pins (TCK, TDI, TDO, TMS, TRST) of the FPGA (U60) as shown in [Figure 2–18](#). Altera Quartus II software can directly configure the FPGA with a new hardware image via an Altera download cable as shown in [Figure 2–19](#). In addition, the Nios II IDE can access the Nios II processor JTAG debug module via a download cable connected to the J24 JTAG connector.

Figure 2–18. JTAG Connector (J24) to Stratix II Device**Figure 2–19. USB Blaster Connected to J24 JTAG Connector**

The FPGA's JTAG pins can also be accessed via the Mictor connector (J25). The pins of J24 are connected directly to pins on J25, and care must be taken so that signal contention does not occur between the two connectors.

JTAG Connector to EPM7256AE Device (J5)

J5 connects to the JTAG pins (TCK, TDI, TDO, TMS, TRST) of the EPM7256AE device (U3). Altera Quartus II software can perform in-system programming (ISP) to reprogram the EPM7256AE device (U3) with a new hardware image via an Altera download cable as shown in [Figure 2–20](#).


 The orientation of J5 is rotated 180 degrees compared to J24.

Most users never need to reprogram the configuration controller design in the EPM7256AE device. Reprogramming the configuration controller can result in an inoperable development board.



To restore the board to its factory-programmed condition, see *Appendix B: Restoring the Factory Configuration*.


Figure 2–20. JTAG Connector (J5) to MAX Device



Clock Circuitry

The Nios development board includes a 50 MHz free-running oscillator (Y2) and a zero-skew, point-to-point clock distribution network that drives the FPGA (U60), the EPM7256AE configuration controller device (U3), and pins on the PROTO1 & PROTO2 connectors. The zero-skew buffer (U2) drives the clock distribution network using the free-running 50 MHz clock. Refer to [Figure 2–21](#).

Figure 2–21. Clock Circuitry

**Note to Figure 2–21:**

- (1) To use an external clock signal, remove the crystal oscillator from its socket. Make sure to note the correct orientation of the oscillator before removing it.

The FPGA receives clock input from buffer U2, and from the PROTO1 and PROTO2 connectors, as shown in [Table 2–21](#).

Table 2–21. FPGA Clock Input Pin Table

FPGA Pin	FPGA Pin Name	PLL	Signal Source	Board Net Name
R1	CLK8p	PLL3, PLL4	J25 pin 6	mictor_TRCLK
R26	CLK2p	PLL1, PLL2	J13 pin 13	proto1_CLKOUT
P2	CLK10p	PLL3, PLL4	J17 pin 13	proto2_CLKOUT
B13	CLK12p	PLL5	U2 pin 2	osc_CLK0
P25	CLK0p	PLL1, PLL2	U2 pin 3	osc_CLK1
AC13	CLK7p	PLL6	U2 pin 4	osc_CLK2
R3	CLK9p	PLL3, PLL4	U2 pin 6	osc_CLK3

The FPGA can synthesize new clock signals internally using on-chip PLLs, and drive the clocks to various components on the board, as shown in [Table 2–22](#).

Table 2–22. FPGA Clock Output Pin Table

FPGA Pin	FPGA Pin Name	PLL	Signal Destination	Board Net Name
C3	IO	N/A	U63 pin 45	sdram_CLK_p
C4	IO	N/A	U63 pin 46	sdram_CLK_n
A12	PLL5_OUT0p	PLL5 (1)	U74 pin 89	sram_CLK
AE14	IO	N/A	JH1 pin 13	pmc_CLK
K6	IO	N/A	J13 pin 11	proto1_PLLCLK
K7	IO	N/A	J17 pin 11	proto2_PLLCLK
AD15	PLL12_OUT0p	PLL12 (1)	J25 pin 5	mictor_CLK

Note to Table 2–22:
 (1) PLLS pins are only dedicated when using the Enhanced PLL. If you use the Fast PLL, the PLL inputs and outputs can be routed to any user pin on the device. For more information on using PLLs in the Stratix II refer to the data sheet.

The 50 MHz oscillator (Y2) is socketed and can be changed or removed by the user. To drive the clock circuitry using the external clock connector (J4), remove Y2.



The factory-programmed configuration controller and Altera-provided reference designs work only with the 50 MHz clock.

Power-Supply Circuitry

The Nios development board runs on a 16.0 V, unregulated, input power supply connected to J26. On-board circuitry generates ± 12.0 V, +5.0 V, +3.3 V, +2.5 V, and +1.2 V regulated power levels. For applications requiring high current, separate voltage levels can be supplied from a workbench power supply.

- The input power-supply on J26 can be either center-negative or center-positive. A bridge rectifier (D34) presents the appropriate polarity to the voltage regulators.
- The 5.0 V supply is presented on pin 2 of J12 and J15 for use by any device plugged into the PROTO1 & PROTO2 expansion connectors.
- The 3.3 V supply is used as the power source for all FPGA I/O pins. The 3.3 V supply is also available for PROTO1 & PROTO2 daughter cards.
- The 2.5 V supply is used only as the power supply for the DDR SDRAM chip and is not available on any connector or header.
- The 1.2 V supply is used only as the power supply for the Stratix II device core (VCCINT) and it is not available on any connector or header.
- The ± 12.0 V supply is provided for the PMC connectors JH1 and JH2. Refer to “[PMC Connector \(JH1 & JH2\)](#)” on page 2–26 for more details. When workbench power supplies are connected to the board, a corresponding fuse must be removed to decouple the on-board voltage regulator. Each on-board regulator drives power through a 7 A fuse. Refer to [Table 2–23](#).

[Table 2–23](#) lists the details of what voltage levels can be supplied to what points on the board.

Voltage	Pad	Fuse	Note
1.2V	J30	F3	Core power for FPGA.
1.2V	TP12	F7	FPGA PLL power supply.
1.25V	TP10	F5	DDR SDRAM I/O V_{TT} .
1.25V	TP9	F4	DDR SDRAM I/O V_{REF} .
2.5V	TP11	F6	DDR SDRAM VDD power supply. FPGA V_{CCIO} for pins that interface to DDR SDRAM.
3.3V	J29	F2	3.3 V power for multiple components on the board.
5V	J28	F1	5.0 V power for multiple components on the board.
+12V	J31	F8	Power for the PMC connectors.
-12V	TP13	F9	Power for the PMC connectors.

Introduction

To restore the factory configuration, you must reprogram the flash memory on the board, and you must reprogram the EPM7256AE configuration controller device.

Nios II Embedded Design Suite provides the files required for this operation in the directory `<Nios II EDS install path>/examples/factory_recovery`.

Reprogramming the Flash Memory

To reprogram the flash memory on the development board, perform the following steps:

1. Open a Nios II command shell.

On a Windows PC, click **Windows Start**, point to **Programs, Altera, Nios II EDS <installed version>**, and then click **Nios II Command Shell**.

2. From the **examples** directory, change to the **factory_recovery** directory for your development kit.

```
cd factory_recovery/niosII_stratixII_2s60_rohs
```

3. Run the flash-restoration script:

```
./restore_my_flash
```

4. Follow the script's instructions.

Reprogramming the EPM7256AE Configuration Controller Device

If the configuration controller design was modified, you must also reprogram the EMP7256AE device (U3). To reprogram the EMP7256AE configuration controller, perform the following steps:

1. Move the programming cable from J24 to J5, labeled "For U3."



The orientation of J5 is opposite that of J24. When properly connected to J5, the programming cable lies naturally over the clock oscillator and the dual seven-segment display.


-
2. Launch the Quartus II software, and click **Programmer** on the Tools menu.
 3. Click **Add File** and select the following programming file:
*<Nios II EDS install path>/examples/
factory_recovery/niosII_stratixII_2s60_rohs/config_controller.pof.*
 4. In the **Programmer**, turn on the **Program/Configure** checkbox, and click **Start** to reprogram the EPM7256AE device.
 5. Press the **Factory Config** button to perform a power on reset and reconfigure the FPGA from flash memory. You should see the Factory LED turned on and activity on LEDs D0 through D7.

Your board is now reconfigured to the default factory condition.

Introduction

The Nios development board is factory-programmed with a reference design that implements a web server, among other functions as shown in [Figure B-1](#). This chapter describes how to connect a host computer to the board's Ethernet port, assign an IP address to the board, and browse to the web server from the host computer.

Figure B-1. Web Server Reference Design




Connecting the Ethernet Cable

The Nios II development kit includes an Ethernet (RJ45) cable and a male/female RJ45 crossover adapter. Before you connect these components, you must decide how you want to use the network features of your board. Select one of the two following connection methods:

1. *LAN Connection* — To use your Nios development board on a LAN (for example, connecting to an Ethernet hub) do the following:
 - a. Connect one end of the RJ45 cable to the Ethernet connector on the development board (RJ1).
 - b. Connect the other end to your LAN connection (hub, router, wall plug, etc.).

-
2. *Point-to-Point Connection* — To use your Nios development board connected directly to a host computer point-to-point (not on a LAN), do the following:
 - a. Connect one end of your RJ45 cable to the female socket in the crossover adapter and insert the male end of the crossover adapter into RJ1 on the Nios development board as shown in [Figure B-2](#).

Figure B-2. Point-to-Point Connection



- b. Connect the other end of the RJ45 connector directly to the network (Ethernet) port on your host computer.

Connecting the LCD Screen

The Nios II development kit includes a two-line x 16-character LCD text screen. The web-server software displays useful status and progress messages on this display. If you wish to use the network features of the board, connect the LCD screen to expansion prototype connector J12. Refer to the *Nios II Development Kit, Getting Started User Guide* for details.

Obtaining an IP Address

In order to function on a network (either LAN or point-to-point), your board must have an IP address. This section describes the methods to assign an IP address to your board.

LAN Connection

If you have connected your board to a LAN, the board will either obtain a dynamic IP address using DHCP, or a static IP address stored in flash memory. If you do not know whether or not your LAN supports DHCP, it is easiest to try DHCP first.

DHCP

Upon reset, the web server attempts to acquire an IP address via the DHCP protocol. The board continues to attempt DHCP self-configuration for two minutes. You can determine if DHCP has succeeded, or if it is still in progress, by reading status messages on the LCD screen. If your LAN does not support DHCP then DHCP configuration ultimately fails, and the web server defaults to a static IP address.

If DHCP succeeds, the board displays a success message and the IP address on the LCD screen. The web server is now ready to display web pages. See [“Browsing to Your Board” on page B-5](#) to continue.

Static IP Address

If the DHCP process fails, the board uses a static IP address stored in flash memory. You need to obtain a safe IP address in your LAN's subnet from your system administrator. Once you know a safe IP address, you can assign it to your board using the steps below.

These steps send IP configuration data to the board via an Altera JTAG download cable, such as the USB-Blaster cable.

1. Install the Nios II development tools, connect the JTAG download cable, and apply power to the board, as described in the *Nios II Development Kit, Getting Started User Guide*.
2. Open a Nios II command shell. On Windows PCs, On a Windows PC, click **Windows Start**, point to **Programs, Altera, Nios II EDS <installed version>**, and then click **Nios II Command Shell**. A shell window appears with a command prompt.
3. Press the SW9 button labeled Factory Config on the board.
4. At the Nios II command shell command prompt, type:

```
nios2-terminal<Enter>
```

This command opens a terminal connection via the JTAG download cable to a monitor program running on the board. The monitor program displays status messages and text instructions that tell you how to set the IP address for your board.

-
5. Press the ! key to abort the DHCP process and display a prompt. If you don't abort the DHCP process, it will fail after two minutes, and eventually a prompt will appear.



The monitor's prompt is the + character. You can enter `h<Enter>` at the prompt for a complete list of supported commands.

6. At the prompt, type `xip:<safe IP address><Enter>`

The `xip` command saves the IP address in flash memory. In general, you only need to assign an IP address to your board once. However, you can change it at any time by issuing another `xip` command. You can also use the commands `xsubnet` and `xgateway` to assign subnet and gateway addresses, but setting these addresses is not usually necessary.

7. Type `xdhcp:off<Enter>` to disable the board from attempting to obtain the IP address using DHCP in the future. (You can re-enable DHCP later, using the `xdhcp:on` command.)
8. Type CTRL+C to terminate the JTAG terminal session and disconnect from the monitor program, then close the Nios II command shell.
9. Press the SW8 button labeled *CPU Reset* to reboot the Nios II processor and start the web server using the new IP address. The LCD screen displays the static IP address assigned to the board, along with other status messages.

The web server is now ready to display pages using the IP address you assigned. See [“Browsing to Your Board” on page B-5](#) to continue.

Point-to-Point Connections

All boards are factory programmed with a default IP address of 10.0.0.51 stored in flash memory. The 10.0.0.x subnet is conventionally reserved for development, test, and prototyping. If DHCP fails or is aborted, the board uses this static IP address. The LCD screen displays status messages to indicate when the web server starts running using the default IP address.

Your host computer and the development board are the only two devices connected to this simple point-to-point network. For most host operating systems, it is necessary to assign your host computer an IP address on the same subnet as the board. For example, the address 10.0.0.1 will work fine. Any address in the 10.0.0.x subnet will work, and there is no possibility of conflicting with another device on the network. After

modifying the host computer's IP address, your computer is ready to connect to the web server. Refer to [“Browsing to Your Board” on page B-5](#) to continue.

If you don't have the ability to change the IP address of your host computer, you can change the IP address of the board to match the subnet of the host computer. For example, if your computer's IP address is 1.2.3.4, then you can assign the address 1.2.3.5 to your board. To change the board IP address, follow the steps in [“Static IP Address ” on page B-3](#).

Every time you reset the board, the web server will attempt to obtain an IP address via DHCP, which takes two minutes to time out. You can abort the DHCP process, or disable DHCP entirely by using the steps in [“Static IP Address ” on page B-3](#).

Browsing to Your Board

Once your board has a valid IP address (obtained from either DHCP self-configuration or from flash memory), you can access the board via a web browser (e.g., Microsoft Internet Explorer). To browse to this site, open a web browser and type the IP address of the board (four numbers separated by decimal-points) as a URL directly into the browser's **Address** input field. You can determine your board's IP address by reading the messages displayed on the LCD screen.

