

# PURE

**Jongo**

S3

**Quick start guide**



## **Jongo safety instructions**

1. Read these instructions – All the safety and operating instructions should be read before this product is operated.
2. Keep these instructions – The safety and operating instructions should be retained for future reference.
3. Heed all warnings – All warnings on the appliance and in the operating instructions should be adhered to.
4. Follow all instructions – All operating and use instructions should be followed.
5. Clean only with dry cloth.
6. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
7. Only use attachments/accessories specified by the manufacturer.
8. Unplug the apparatus during lightning storms or when unused for long periods of time.
9. Refer all servicing to qualified personnel. Servicing is required when the apparatus has been damaged in any way, does not operate normally, or has been dropped.
10. To reduce the risk of electric shock, do not remove plastic cover or screws as there are no user-serviceable parts inside. Refer servicing to qualified personnel.
11. Avoid liquids getting into Jongo. Should not be immersed in water, or used where this may happen, such as a bathroom.
12. The equipment's ventilation should not be impeded by covering the ventilation openings with items such as newspaper, table-cloths, curtains etc.
13. WARNING Please refer to the information on the bottom exterior of the enclosure for electrical and safety information before installing or operating the apparatus.
14. WARNING To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture. The apparatus shall not be exposed to dripping or splashing and that objects filled with liquids, such as vases, shall not be placed on apparatus.
15. CAUTION: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
16. WARNING: The direct plug-in adapter is used as disconnect device, the disconnect device shall remain readily operable.
17. This equipment is a Class II or double insulated electrical appliance. It has been designed in such a way that it does not require a safety connection to electrical earth.

## **ChargePAK F1 safety instructions**


1. Read the instructions for ChargePAK use in this document.
2. Only use your ChargePAK with original Pure products.
3. Ensure that Jongo is disconnected from the power supply before removing or replacing ChargePAK.
4. Store ChargePAK in a cool, dry place at normal room temperature. Remove from devices that will be stored unused for extended periods.
5. Do not puncture, modify, drop, throw, or cause other unnecessary shocks to your ChargePAK. May present a risk of fire, explosion, or chemical burn if mistreated.
6. Do not dispose of ChargePAK in a fire or incinerator, or leave in hot places such as a motor car under direct sunlight. Do not store near oven, stove, or other heat source.
7. Do not connect ChargePAK directly to an electrical source, such as a building outlet or automobile power-point. Do not place into a microwave oven, or any other high-pressure container.
8. Do not immerse ChargePAK in water or otherwise expose it to liquids.
9. Do not short circuit ChargePAK.
10. Do not use or charge a ChargePAK that appears to be leaking, discoloured, rusty, deformed; emitting an odour; or is otherwise abnormal.
11. Do not touch a leaking ChargePAK directly; wear protective material to remove and dispose of it properly immediately.
12. Do not store where children may have access.
13. Dispose of ChargePAK as per normal rechargeable batteries according to the local laws and regulations of your region. Some batteries may be recycled, and may be accepted for disposal at your local recycling centre.

# Jongo

S3


Thank you for choosing Jongo S3. This quick start guide will get you up and running in no time. If you need more help setting up your Jongo, you can access our online help in the Pure Connect app or watch our Jongo setup video at:

**[www.pure.com/jongo-setup-video](http://www.pure.com/jongo-setup-video)**




# Connecting Jongo to Wi-Fi

## 1 Power up Jongo



Plug Jongo in and switch it on .

**Note:** Make sure that the supplied Bluetooth adapter is inserted into the USB connector on the back of Jongo before going to the next step (see below for more information).



## 2 Download the Pure Connect app

Search for the Pure Connect app on the Apple App Store or Google Play from your phone or tablet.




If you already have the Pure Connect app, check on the Apple App Store or Google Play to see that you have the latest version and then skip to the next page.

### **Don't have an Android or iOS device?**

To find out how to play music to your Jongo from another device, e.g. a Blackberry, Windows Phone or PC, visit our support site at:


**[support.pure.com/au](https://support.pure.com/au)**

### 3 Open the Pure Connect app and sign in



To make the most of your Jongo you really need to create a free Pure Connect account. You can create a Pure Connect account using your Facebook account or your e-mail address\*.

### 4 Connect Jongo to your Wi-Fi




The first time you sign in to the app, you will see an option to connect Jongo to your Wi-Fi. Simply tap **Set up a Jongo** and follow the prompts on screen to connect Jongo to your Wi-Fi.

\*If you are using the iOS Pure Connect app, you will need to visit [connect.pure.com](http://connect.pure.com) to create an account using your e-mail address.

# Adding another Jongo to your Wi-Fi



If you have already connected a Jongo to your Wi-Fi, follow the steps below to add another Jongo to your Wi-Fi.

- A. Open the Pure Connect app and sign in.
- B. Open the **Settings** menu.
- C. Tap **Set up a Jongo** and follow the prompts on screen.



# Playing music from the Pure Connect app




You can use the Pure Connect app to play music using Wi-Fi and manage various settings, including the volume, stereo pairing and software updates.


- A. Open the Pure Connect app.
- B. Tap  in the player bar to view a list of available speakers.
- C. Switch on  the speakers that you want to stream to.
- D. Select the music that you want to play.



# Playing music from other apps

If your speakers are connected to Wi-Fi, you can use Bluetooth Caskeid to stream content from other music services, such as Spotify and Pandora, to all of your speakers.

- A. Open the Pure Connect app.
- B. Tap  in the player bar to view a list of available speakers on your network.
- C. Tap  next to the speaker that you want to stream to.
- D. Switch **Bluetooth Caskeid** on  and return to the previous screen.
- E. Repeat steps B to D for each speaker that you want to play music on.
- F. Enable the Bluetooth option on your mobile device and search for Bluetooth devices.
- G. Pair to one of your speakers. If your device requires a key, enter '0000'.
- H. Open the music streaming service that you want to listen to and play a track.




## Don't have an Android or iOS device?

To find out how to play music to your Jongo from another device, e.g. a Blackberry, Windows Phone or PC, visit our support site at:

**[support.pure.com/au](http://support.pure.com/au)**


# Changing audio profiles

You can use the audio profile setting to get the best sound from your Jongo in every environment. You can change the audio profile by pressing the **Audio** button on the rear of your speaker.




## **Mono 360°**

Select this profile to activate all five speakers in Jongo. This option is ideal if placing Jongo in the middle of a room or table.




## **Outdoor boost**

Select this profile to boost all five speakers in Jongo for outdoor use.



## **Stereo 360°**

Select this profile to enable the four speakers to play Stereo Left and Right audio – and enable the subwoofer. This option is ideal for creating a big stereo sound.



## **Stereo forward facing**

Select this profile to enable stereo on the front two speakers and enable the subwoofer. This option is ideal if placing Jongo on a bookshelf or in a corner.

# Troubleshooting

## Why does the power light on my Jongo change colour?

The power light on the front of Jongo is used to tell you about Jongo's status. The list below explains some of the common colours that you may see when setting up and using your Jongo.

**Green (steady):** Jongo is ready to play your music or is already playing a track.

**Green (pulsing):** Jongo is in Wi-Fi setup mode (you'll see this when powering up your Jongo for the first time) or Jongo is busy. The power light will turn steady green when Jongo is ready to play your music.

**Amber (steady):** Jongo is in sleep mode. Jongo will automatically wake up and play your music when you try to stream a track from your smartphone or tablet.

**Red (flashing):** Jongo cannot connect to your Wi-Fi. Check that you are within range of your Wi-Fi network and that you have entered the correct password (matching any upper and lower case letters) and run Jongo Setup again. To get more help with setting up your Wi-Fi, visit our support site at [support.pure.com/au](http://support.pure.com/au).

## Why did Jongo Setup not work?



If there was a problem during Jongo Setup, the Pure Connect app will display an error message to help you troubleshoot the problem.

### No Wi-Fi detected

This message will appear if your mobile device is not connected to a Wi-Fi network. Check the Wi-Fi settings on your mobile device to see if you are connected to a Wi-Fi network and then tap **Try again**.

### Setup failed

This message will appear if there was a problem during Jongo setup. One common reason for this message to be displayed is an incorrect Wi-Fi password. Tap **Try again** to try setting up your Jongo again.






### Need more help?

If you need more help setting up your Jongo, you can visit our support site at:

**[support.pure.com/au](https://support.pure.com/au)**

# Technical specifications

<b>Speakers</b>	4 x Mylar ¾" high frequency drivers, 1 x Neodymium motor upward firing 3.5" mid/bass driver
<b>Audio output</b>	4 x 2.5W + 10W RMS
<b>Input connectors</b>	9V DC power adaptor socket (110-230V supplied), ChargePAK connector, 3.5mm line-in for auxiliary devices. USB for product updates, Bluetooth (dongle supplied) and Ethernet connectivity (optional adapter available)
<b>Controls</b>	Power, Vol+, Vol-, Mute, Audio profile, Wi-Fi setup, Reset
<b>Display</b>	1" LCD display
<b>Network</b>	Wi-Fi: 802.11b and 802.11g supported with WEP and WPA/WPA2 Ethernet (requires optional adapter): 10/100 Mbps Bluetooth: A2DP supported via supplied USB dongle
<b>Codec support</b>	Includes WMA (Standard V9), AAC, MP3, MP2
<b>Mains power supply</b>	Adapter: Input 100-240V AC, 50/60Hz, 0.5A; Output 9V DC, 1500mA Main unit: 9V DC, 1500mA
<b>Battery</b>	ChargePAK F1 (supplied)
<b>Dimensions</b>	131 mm wide x 139 mm deep x 135 mm high
<b>Weight</b>	1.25 kg with ChargePAK, 1.0 kg without ChargePAK
<b>Approvals</b>	   CE marked. Hereby, Pure, declares that this Band II LPD device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The Declaration of Conformity may be consulted at: <a href="http://www.pure.com/R&amp;TTE-DoC">http://www.pure.com/R&amp;TTE-DoC</a> Australian C-Tick N1600 and Electrical Safety

## Warranty information

Imagination Technologies Limited warrants to the end user that this product will be free from defects in materials and workmanship in the course of normal use for a period of three years from the date of purchase. This guarantee covers breakdowns due to manufacturing or design faults; it does not apply in cases such as accidental damage, however caused, wear and tear, negligence, adjustment, modification or repair not authorised by us. Should you have a problem with your unit please contact your supplier or contact Pure Support at <http://support.pure.com/au>.

## Disclaimer

Imagination Technologies Limited makes no representation or warranties with respect to the content of this document and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Further, Imagination Technologies Limited reserves the right to revise this publication and to make changes in it from time to time without obligation of Imagination Technologies Limited to notify any person or organization of such revisions or changes.

## Trademarks

Jongo, Pure, the Pure logo, Imagination Technologies, and the Imagination Technologies logo are trademarks or registered trademarks of Imagination Technologies Limited.

Caskeid is a superior synchronization technology, providing clear multi-speaker wireless audio.

Caskeid and the Caskeid logo are trademarks or registered trademarks of Imagination Technologies.

## Copyright

Copyright © 2014 Imagination Technologies Limited. All rights reserved. No part of this publication may be copied or distributed, transmitted, transcribed, stored in a retrieval system, or translated into any human or computer language, in any form or by any means, electronic, mechanical, magnetic, manual or otherwise, or disclosed to third parties without the express written permission of Imagination Technologies Limited. Version 1 September 2014.

## Disposal of Waste Electrical & Electronic Equipment



This symbol on the product or on its packaging indicates that this product should not be treated as household waste. Instead it should be handed over to a suitable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local council office, your household waste disposal service or the shop where you purchased the product.

# Pure Warranty Statement for Australia

This statement replaces any reference to warranty which may be contained elsewhere within this manual.

## What do you need to do now?

- Keep your proof of purchase as evidence of your purchase date. This proof of purchase would need to be presented if warranty service was ever required.
- Register your purchase on-line at <http://www.pure.com/au/product-registration/> for free technical support.

If you have any questions about your warranty you can call us toll free 1800 988 268.

## What's covered by this warranty?

- Pure agrees to refund, repair or replace, at your election, without charge to you, any part found to be defective during the warranty period.
- If equipment has been used according to its accompanying instruction manual and is used in a domestic situation, a three year warranty period applies.

## How do you make your claim?

Call 1800 988 268 for instructions on how to return your Pure product for warranty service or go to <http://support.pure.com/au/> and complete the contact us form.

## What's NOT covered by this warranty?

Under this express warranty Pure will not be liable for loss or damage of any kind whatsoever, whether direct, indirect, incidental, consequential or otherwise.

- Replacement of parts due to normal wear and tear.
- Products with serial number defacement, modification or removal.
- Water damage or corrosion caused by dampness.
- Any damage or deterioration due to shipment.
- Any product which has been subjected to misuse, abuse or accident.

**Australian consumers** — The benefits to the consumer given by this express warranty are in addition to other rights and remedies of the consumer under a law in relation to the goods or services to which this warranty relates. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Pure is distributed and supported in Australia by PIONEER ELECTRONICS AUSTRALIA PTY LTD, 5 ARCO LANE, HEATHERTON, VICTORIA, 3202.

# PURE

[www.pure.com](http://www.pure.com)  
[connect.pure.com](http://connect.pure.com)  
[www.facebook.com/pure](http://www.facebook.com/pure)

## **Pure**

Imagination Technologies Limited  
Home Park Estate  
Kings Langley  
Herts, WD4 8LZ  
United Kingdom  
[www.pure.com](http://www.pure.com)  
<http://support.pure.com>

## **Pure Australasia Pty Ltd**

PO Box 5049  
Wonga Park  
Victoria 3115  
Australia  
[sales.au@pure.com](mailto:sales.au@pure.com)  
<http://support.pure.com/au>