

WAGAN Corp. Limited Warranty Registration Form

All WAGAN Corporation products are warranted to the original purchaser of this product.
Warranty Duration: This product is warranted to the original purchaser for a period of one (1)Year from the original purchase date, to be free of defects in material and workmanship. WAGAN Corporation disclaims any liability for consequential damages. In no event will WAGAN Corporation be responsible for any amount of damages beyond the amount paid for the product at retail. In the even of a defective item, please ship the item, prepaid, with a complete explanation of the problem, your name, address and daytime phone number. WAGAN Corporation will, at its option, replaces or repair the defective part. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty is effective only if the product is purchased and operated in the USA and does not extend to any units which have been used in violation of written instructions furnished.
Warranty Disclaimers: This warranty is in-lieu of all warranties expressed or implied and no representative or person is authorized to assume any other liability in connection with the sale of our products. There shall be no claims for defects or failure of performance or product failure under any theory of tort, contract or commercial law including, but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract.
Warranty Performance: During the above one (1)Year warranty period, a product with a defect will be replaced with a comparable model when the product is returned to WAGAN Corporation with an original store receipt. The replacement product will be in warranty for the balance of the one (1)Year warranty period.

- Please activate my limited warranty for WAGAN Corp. Mini Stepper
- Enclosed copy of original sales receipt.

Name			
Mail Address			
City			
State, Zip Code			
Item Purchased	Mini Stepper		
Stores Name			
Date of Purchase			
Signature		Date	

All WAGAN Corporation Products must be registered within (30) days of purchased to activate this warranty. Mail the complete registration form, along with a copy of the original receipt to:

Attn: Customer Service
 WAGAN Corporation
 3589Yale Way
 Fremont, CA 94538

© 2005 WAGAN Corp.



Item no. 2273



User's Manual

Mini Stepper by Wagan Tech


USER'S MANUAL — Please read before using this equipment.

Dear valued customer,

Thank you for purchasing Wagan Tech Mini Stepper fitness equipment. We know you will be very happy with our products. Please read before use. This user manual will help you in learning the method of operation and maintenance. Please follow the recommendations in this manual. If you have any questions with regard to assembly or operation, please contact us at 1-800-231-5806 ext. 101 or by email at customerservice@wagan.com

If the specifications, diagrams, and functions have changed, we will not be able to give notice separately.

Note: while using this equipment, please adhere strictly to the instructions of this manual. We will not be held responsible for any harm or damage caused by actions which breach the rules in this manual.



ASSEMBLING

*Please refer to the diagram on previous page.

1. Take out the power cable from the LED meter (5).
2. Wire the power cable inside the stand tube (3).
3. Connect the stand tube (3) to the main frame (2) with bolts.
4. Wire the power cable inside the connecting tube (4).
5. Connect the connecting tube (4) to the stand tube (3) with bolts.
6. Put the LED meter (5) on the top of the connecting tube (4) and connect it to the power cable.
7. Connect the two handle bars (6) to the connecting tube (4) with bolts.

TENSION ADJUSTMENT

1. Locate the screwdriver with the triangular cap called the tension key (see figure 1)




Figure 1

2. Locate the threaded hole on the opposite side on the stepper (see figure 2)




Figure 2

3. Screw in the tension key slowly into the threaded hole
4. One side of the stepper will be automatically lifted up as the tension key gets screwed in deeper into the tube. It might get harder to screw in once it gets deeper (see figure 3)




Figure 3

Hint: Please, lift up one of the stepper pedals manually and continue to screw in the tension key

5. Once the tension key has been properly adjusted, please try the stepper by stepping on both sides
6. If it is properly done, one step will be up and the other will be down as you do the step exercise and vice versa

7. Adjust tension according to your comfortable step exercise.
 - a. If the tension key is all the way in, it is the highest tension for step exercise
 - b. If the tension key is loosed all the way out, it will loose the tension for step exercise

MAINTENANCE

1. Inspect the Mini Stepper at regular intervals to find if there are joints loose and parts damaged/worn.
2. Put lubricating oil or grease on hydraulic and any revolving parts at 3 months' intervals.
3. Store the Mini Stepper in cool and dry environment.
4. Don't clean the surface of the Mini Stepper with an organic solvent (i.e. gasoline, benzene, etc.) or the surface will be damaged.
5. Inspect the unit properly before exercise. Make sure that there are no troubles such as; loose joints, loose hydraulic, wobbling pedals.
6. Use lubricating grease on the hydraulic, to minimize noise or unsmooth revolutions.
7. This product was designed for individuals weighing up to 225 lbs only.

USING THE MINI STEPPER

We would like to recommend that you utilize your Mini Stepper for half an hour every day. We believe you will feel the marvelous effects of cardio-training about one month later. This Mini Stepper is excellent for use in office. Exercising during a break from work is extremely beneficial. Rather than feeling fatigue and exhausted, you will be refreshed and energized!

1. Persons with hypertension, obesity, and heart disease should not do strenuous exercise with the Mini Stepper.
2. Doing exercise when exhausted is not recommended.
3. We suggest you should keep your food structure reasonable: enough protein, vitamin, mineral clement and proper sugar.
4. Do some warm up exercise before training to avoid possible injury; for example: stretching arms, legs and back.
5. Please note the coordination of arms and legs. Try adding hand weights for a better workout.
6. Paces should be mild and gentle; sudden actions are not recommended, so as to avoid possible injury to your body.

TIME READ-OUT SPECIFICATIONS

TIME-----00:00-59:59 Min
REPS/MIN-----0-9999 Reps/Min
COUNT-----0-9999 Times
CALORIES-----0-9999 Cal

METER FUNCTION

MODE: 1. This key allows you to select and lock on to a particular function you want.
2. Hold the key for 3 – 4 second to have all function values reset. (total reset)

RESET: The unit will be reset by pressing the key.

OPERATION PROCEDURES

AUTO ON/OFF:

1. The system turns on when any key is pressed or when it senses an input from the speed sensor.
2. The monitor will be automatically shut off if there is no signal in 4 or 5 minutes.

FUNCTION:

TIME:

1. Press the MODE key until the pointer advance to TIME.
2. When the speed sensor receives any signal input, it starts to count up.
3. It accumulates workout time when starting exercise.

REPS/MIN:

Displays current estimate repetitions per minutes during workout.

COUNT:

Displays accumulated workout steps since starting exercise

CALORIES:

1. Press the MODE key until the pointer changes to CAL.
2. When the speed sensor receives any signal input, it starts to count up.
3. It accumulates calories consumed when starting exercise.

SCAN:

Automatic display of the following functions in the order shown:

TIME --> CALORIES --> SPEED (REPS/MIN)

BATTERY

1. Please replace the battery if improper display appears.
2. The monitor operates on one AAA battery.