

Level 3 Service Manual

Draft 1.1

MOTOROLATM

DIGITAL WIRELESS TELEPHONE



Model A920/ A925

UMTS 2100MHz / PCS 1900MHz / DCS 1800MHz / GSM 800MHz

Distribution Policy and Copyright

Copyright

© 2003 by Motorola. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language in any form by any means without the written permission of Motorola.

Software License

The Agreement sets forth the license terms and conditions for using the enclosed Software. You may use this Software on a single computer, and you may transfer it to another computer as long as it is used on only one computer at a time. You may copy the Software for backup purposes only. You may not rent, sell, lease, sublicense, time-share or lend the Software to a third party or otherwise transfer this License without written consent of Motorola. You shall not decompile, disassemble, reverse-engineer or modify the Software. This License is effective until terminated. You may terminate it at any time by destroying the Software together with all copies. The License also terminates if you fail to comply with the terms and conditions of this Agreement. United States copyright laws as well as international treaty provisions protect this Software and accompanying documentation. Any use of the Software in violation of these laws constitutes termination of the License.

Limited Liability

The Software and accompanying documentation is provided "AS IS" without warranty of any kind. Motorola specifically disclaims all other warranties, expressed or implied, including but not limited to implied warranties of merchantability and fitness for a particular purpose. With respect to the use of this product, in no event shall Motorola be liable for any loss of profit or any other commercial damage, including but not limited to special, incidental, consequential or other damages.

Table of Contents

| | |
|--|------------|
| 3G Flash Procedures | 1-1 |
| Introduction | 1-1 |
| Hardware Requirements | 1-1 |
| Power Solution | 1-1 |
| Interface Solution | 1-1 |
| PST Software | 1-2 |
| Flash Software Access | 1-2 |
| Phone Flashing | 1-2 |
| Power Solutions | 1-2 |
| Hardware Connection Solution | 1-2 |
| <i>Figure 1. PST Hardware Configuration</i> | 1-3 |
| PST Flash Procedure | 1-4 |
| A920/A925 Special Procedures | 1-5 |
| Flash Procedure Summary | 1-5 |
| Handset Test Commands | 2-1 |
| Introduction | 2-1 |
| Application Installation* | 2-1 |
| <i>Figure 1. Launcher Menu.....</i> | 2-1 |
| <i>Figure 2. Install Window</i> | 2-1 |
| <i>Figure 3. Test Command Icon</i> | 2-1 |
| Handset Test Command Mode Entry | 2-2 |
| <i>Figure 4. Password Prompt</i> | 2-2 |
| <i>Figure 5. Sub Applications</i> | 2-2 |
| <i>Figure 6. Main Entry Screen</i> | 2-2 |
| <i>Figure 6. Input Format</i> | 2-2 |
| Entry Method | 2-3 |
| Opcode entry | 2-3 |
| <i>Figure 7. Fields entered Separately</i> | 2-3 |
| Entering Data | 2-3 |
| <i>Figure 8. Fields Entered with Delimiter</i> | 2-3 |
| <i>Figure 9. Keyboard Entry</i> | 2-3 |
| <i>Figure 10. Stylus Entry</i> | 2-4 |
| <i>Figure 11. Invalid Entry</i> | 2-4 |
| Result Screen | 2-4 |
| <i>Figure 12. Results Screen</i> | 2-4 |
| <i>Table 1. Handset Test Command Summary</i> | 2-5 |
| <i>Table 2. Standard Response Codes</i> | 2-6 |
| <i>Table 3. Field and Parameter descriptions</i> | 2-7 |
| <i>Table 3. Field and Parameter descriptions - continued</i> | 2-8 |
| <i>Table 3. Field and Parameter descriptions - continued</i> | 2-9 |

| | |
|--|------------|
| <i>Table 3. Field and Parameter descriptions - continued</i> | 2-10 |
| <i>Table 3. Field and Parameter descriptions - continued</i> | 2-11 |
| Manual Test Procedures | 3-1 |
| Introduction | 3-1 |
| Call-Processing Tests | 3-1 |
| Non-Signalling Test Measurements | 3-1 |
| GSM/DCS/PCS Call Processing | 3-2 |
| Hardware Requirements | 3-2 |
| Software Requirements (PCS only) | 3-2 |
| Call Origination (GSM and DCS only) | 3-3 |
| <i>Figure 10. GSM Signalling Setup</i> | 3-3 |
| <i>Figure 11. GSM Connection Control</i> | 3-3 |
| <i>Figure 12. GSM Call Connected</i> | 3-3 |
| <i>Figure 13. A920 Manual Test Hardware Configuration</i> | 3-4 |
| Call Origination (PCS Only) | 3-5 |
| <i>Figure 14. RadioComm COM Port</i> | 3-5 |
| <i>Figure 15. Radio Comm Screen</i> | 3-5 |
| Call Test Parameters (GSM/DCS/PCS) | 3-6 |
| <i>Table 4. GSM Call Parameters</i> | 3-6 |
| <i>Table 5. DCS Call Parameters</i> | 3-6 |
| <i>Table 6. PCS Call Parameters</i> | 3-6 |
| <i>Figure 16. Burst Output Shape</i> | 3-6 |
| <i>Table 7. GSM/DCS/PCS Handover</i> | 3-6 |
| WCDMA Call Processing | 3-7 |
| Hardware Requirements | 3-7 |
| Software Requirements | 3-7 |
| Call Origination (WCDMA) | 3-7 |
| <i>Figure 17. WCDMA Signalling Setup</i> | 3-7 |
| <i>Figure 18. Channel Uplink(UE Signal)</i> | 3-7 |
| <i>Figure 19. TPC Pattern Type(UE Signal)</i> | 3-8 |
| <i>Figure 20. WCDMA Call Connected</i> | 3-8 |
| WCDMA Call Test Parameters | 3-8 |
| <i>Table 5. WCDMA Call Parameters</i> | 3-8 |
| <i>Figure 21. WCDMA Modulation</i> | 3-8 |
| <i>Figure 22. ACLR Screen</i> | 3-8 |
| Non-Signalling Test Procedures (GSM/DCS/PCS) | 3-9 |
| Hardware Requirements | 3-9 |
| Software Requirements | 3-9 |
| Verify TX Power Output (GSM/DCS/PCS) | 3-9 |
| <i>Table 8. TX Power Limits</i> | 3-9 |
| GSM RSSI | 3-10 |
| Non-signalling Test Procedures (WCDMA) | 3-11 |
| Hardware Requirements | 3-11 |
| Software Requirements | 3-11 |
| Verify TX Power Output (WCDMA) | 3-11 |
| <i>Table 9. WCDMA TX Power Output</i> | 3-11 |
| Audio/Vibrator Test Procedures | 3-12 |
| Vibrator Test | 3-12 |
| Handset Mic/Speaker test | 3-13 |

| | |
|--|------------|
| Mono Headset Mic/Speaker test | 3-13 |
| Stereo Headset Mic/Speaker test | 3-14 |
| Melody Speaker test | 3-14 |
| Software Version Check | 3-15 |
| Display Test Procedures | 3-15 |
| Display Backlight Test | 3-15 |
| Display Color Test | 3-16 |
| <i>Figure 23. Eight Color Box Pattern</i> | 3-16 |
| Display Linearity Test | 3-16 |
| <i>Figure 24. Grey Scale Block</i> | 3-16 |
| Display Flicker Test | 3-17 |
| <i>Figure 25. Zebra Pattern</i> | 3-17 |
| Display Pixel Defect (Bright) | 3-17 |
| Display Pixel Defect (Dark) | 3-17 |
| LEDS and Keypad Backlight | 3-18 |
| Status LEDs | 3-18 |
| Keypad Backlight | 3-18 |
| Bluetooth Tests (V500/V600 only) | 3-19 |
| Unmodulated CW TX test | 3-19 |
| Camera Testing | 3-20 |
| Hardware Requirements | 3-20 |
| Camera Test Configuration | 3-20 |
| <i>Figure 9. Camera Test Configuration</i> | 3-21 |
| Image Capture | 3-22 |
| Macbeth Color Chart | 3-23 |
| Focus Chart | 3-23 |
| Grey Scale Chart (Shading Test) | 3-23 |
| Service Diagrams | 4-1 |
| Introduction | 4-1 |
| Test Point Measurements | 4-1 |
| Antenna Circuit | 4-2 |
| GSM Receiver Front End | 4-4 |
| Magic LV (Receiver Back End) | 4-6 |
| Magic LV (Control) | 4-8 |
| Magic LV (Synthesizer/Transmitter) | 4-10 |
| GSM TX VCO | 4-12 |
| GSM Transmitter | 4-14 |
| WCDMA RX Front End | 4-16 |
| WCDMA Receiver (MAX2309) | 4-18 |
| Harmony Lite (Receive Section) | 4-20 |
| Harmony Lite (Control Section) | 4-22 |
| Harmony Lite (Synthesizer Section) | 4-24 |
| Harmony Lite (Transmitter Section) | 4-26 |
| WCDMA VCO | 4-28 |
| WCDMA TX Modulator | 4-30 |
| WCDMA Transmitter | 4-32 |

| | |
|------------------------------------|------------|
| PCAP Charger | 4-34 |
| PCAP Regulators | 4-36 |
| Receive Audio | 4-38 |
| Transmit Audio | 4-40 |
| PCAP | 4-42 |
| POG | 4-44 |
| POG Interfaces | 4-46 |
| POG Memory | 4-48 |
| Bluetooth | 4-50 |
| GPS RF Circuit | 4-52 |
| GPS Baseband Circuit | 4-54 |
| Video Circuit | 4-56 |
| Helen | 4-58 |
| Helen Interfaces | 4-60 |
| Helen Flash Memory | 4-62 |
| Helen SDRAM | 4-64 |
| SIM Connector | 4-66 |
| Battery Connector (J5400) | 4-68 |
| Camera Connector (J7600) | 4-70 |
| MMC Connector (J3900) | 4-72 |
| Keyboard Connector (JPCH) | 4-74 |
| Display Connector (J5200) | 4-76 |
| CE Bus Connector (J5000) | 4-78 |
| Signal Flow Diagram (Side 1) | 4-80 |
| Signal Flow Diagram (Side 2) | 4-81 |
| RF Block Diagram | 4-82 |
| Baseband Block Diagram | 4-83 |
| Parts List | 5-1 |
| Introduction | 5-1 |
| Electrical Parts List | 5-2 |

3G Flash Procedures

Introduction

This document is intended to describe the flashing (software updates) and procedures for 3G terminals. The 3G terminal described in this document will be limited to the A920/A925.

Software updates need to be handled in a controlled manner. Carrier software approvals need to be considered before initializing a flashing procedure. Consult a Motorola representative to ensure that the correct software is programmed.

Software updates allows the service organization to resolve field software issues that customers may be experiencing. Some issues may pertain to specific conditions, therefore, not all units will contain identical software versions.

Hardware Requirements

The following hardware will be required to properly flash the phone.

Power Solution

1. Fully Charged battery (SNN5638A)
2. Full-rate Charger (PSM5049A)

Interface Solution

1. USB PST Tool Kit (S8951)
USB Cable (SKN6311A)
Security Key
Adapter kit
Power supply (SPN4059A)

PST Software

The Product Support Tool (PST) is used to allow functions such as flashing, flexing, memory transfers, and datalogging. Please contact your local Motorola service representative to obtain user documentation for the PST.

Insure that the Motorola service representative also provides installation documentation, security key requirements, and other related information.

Flash Software Access

Flash software can be accessed by Motorola personnel only. Contact your local Motorola service representative to obtain updated software releases.

In some cases the software may be distributed in ZIP format. The user will need to extract the original (.SHX) file from the ZIP file before it can be used with the PST. WINZIP is the application that can be used to extract the original flash file. For more information on WINZIP, visit,

<http://www.winzip.com>

Phone Flashing

Before beginning any flashing procedure, always insure that all hardware connections are secured. Refer to figure 1 for flash connection guides. Any intermittent hardware connections may cause the procedure to fail and result in a nonfunctional (Bricked) 3G terminal.

The A920/A925 contains a set of Flash EPROMs for the Adjunct Processor and a separate set of Flash EPROMs for the Baseband Processor. Due to this design, the A920/A925 will require separate Flash files for each processor if a “Combo” file is not provided.

A “Combo” file contains the following files,

Adjunct Processor Flash
Baseband Processor Flash
Customer image flex

Power Solutions

There are two types of power solutions to perform a flashing procedure.

1. Fully Charged Battery Solution
2. Full-Rate Charger Solution (recommended)

If the user decides on using the battery solution, he/she must verify that the battery is fully charged. Failing to verify the capacity of the battery may result in battery depletion prior to completing the flash process. This action may cause unrecoverable failures to the 3G terminal.

Hardware Connection Solution

A920 flash procedures require a USB hardware configuration. Refer to Figure 1 for details.

Figure 1. PST Hardware Configuration



Flash Procedures


PST Flash Procedure

Use the listed procedure to complete the flash procedure for a 3G terminal. The baseband processor needs to be flashed first. Once the baseband processor flash is successful, follow up with flashing the adjunct processor.

1. Download the desired flash software into the computer.
2. Launch the PST application by choosing Start/ Programs/Motorola PST/Flash & Test Commands.
3. Attach battery and connect hardware as illustrated in figure 1.
4. Press the Power key and insure that the phone is completely powered on.
5. In the PST application, click on the Browse button and select the desired flash software



6. Select the device that will be flashed.



7. The 3G terminal will be placed in Adjunct flash mode, select the device again to enable the Flash button.



8. Click on the Flash button to begin flashing. DO NOT interrupt any hardware connections during the flash process. Connection interruptions may cause the flashing process to fail and render the 3G terminal non-operational.
9. When flashing is complete, a message will pop up stating, "Flash another phone?". Select "No" and waiting for 30 seconds before continuing.
10. Power up the 3G terminal to insure that the flash procedure was successful.
11. On the first power up, the user will be prompted to select a language and calibrate the touch screen.

A920/A925 Special Procedures

There are some variables that need to be considered when updating software for a A920/A925. Improper update procedures may cause the 3G terminal to fail. Always read the release notes for software releases prior to updating the software on a A920/A925.

The user needs to insure that the adjunct and baseband flash files are part of the same build. Also, the user needs to be aware of any step-up procedures. This may require the user to flash an updated bootloader. Step-up procedures can be found in the software release notes.

In order to successfully flash a A920, the following sequence is recommended.

1. Backup user data
2. Flash/upgrade the software
3. Perform a “Master Clear”
4. Restore user data

Flash Procedure Summary

The following is a summary of the procedures for flashing a A920.

1. Launch PST.
2. Connect USB hardware. Insure 3G terminal remains off.
3. Power up 3G terminal.
4. Use the Browse button to open the “Combo” flash file.
5. Select the device for flashing.
6. Select the device again to enable Flash.
7. Click Flash.
8. Click Yes to all the prompts if the user is certain that software being flashed is correct.
9. When flashing is completed, click “No” when prompted, “Flash another phone?.”
10. Power cycle phone. Verify functionality.

Flash Procedures

Handset Test Commands

Introduction

The Handset Test Command mode of the phone is provided primarily for service personnel without access to equipment capable of exercising Test Commands over a computer connection. This mode collects input from the user and packages it in the format required by the Test Command component within the phone.

Application Installation*

The user needs to install the Handset Test Command application before it can be accessed. Obtain the file, “testcmdui.sis”, file from your local Motorola service representative. Use the following procedure to properly install the handset test command application.

1. Copy the testcmdui file into a memory card (SD or MMC) and insure that the card is inserted in the phone.
2. From the App Launcher screen, select *Install* from the Launcher drop down list


Figure 1. Launcher Menu



*Test application can only be loaded if application loading is not secured.

3. The user will be prompt with a list of software installation files.
4. Highlight *Test Command* and select *Install*

Figure 2. Install Window



5. When installation is complete, the Test Command icon will be displayed in the App Launcher screen.


Figure 3. Test Command Icon




Command entry**Handset Test Command Mode Entry**

Follow these procedures to launch the handset test command application.


1. Under the App Launcher screen select the Handset test command icon.
2. The user will then be prompted to input a password

Figure 4. Password Prompt


3. The password is 0HTCMD#
Note: Password is case sensitive
4. Once the application is launched, the user is presented with a list of sub applications

Figure 5. Sub Applications

5. Choose Handset Test Commands to enter the Test command Opcode screen

Figure 6. Main Entry Screen

6. Before entering any commands, the user will should select the data input format under the *Edit* menu

Figure 6. Input Format

7. The user can select Hexadecimal or decimal.
8. Under the Edit menu, the user can also clear a field or all fields
9. The *Back* key will return the user to the App Launcher screen

Entry Method

Once the test command mode is entered, two prompts are used to collect command request information from the user. The opcode entry prompt (Figure 5) allows the entry of either an entire command as described in this section, or entry of a partial command. If a partial command is entered, the user will be prompted to enter the remaining required information via an appropriate number of field entry prompts (Figure 7). Selecting Test with no data entered in the opcode or field entry screen will cause a parse error (unless the field is optional).


The comma is used to delimit fields on the opcode entry prompt and is not allowed on the field entry prompt. On the opcode entry prompt, it is not legal to have a comma immediately follow another comma.

Opcode entry

The opcode entry prompt allows the user to enter the opcode for the test command, or the opcode plus additional parameters delimited by the “,” character.

The user may select *Test* after entering the opcode. If the opcode requires further parameters, the list of Fields shall be shown starting with 1. After all the fields are entered the user shall select *Test*. The results are then shown on the screen.


Figure 7. Fields entered Separately



The *Back* selection will clear the command contents and return the user to the opcode prompt.

If the user chooses to enter the entire command with the necessary parameters in the Opcode prompt, “,” delimiters will be used.

Figure 8. Fields Entered with Delimiter



Entering Data

When the User wants to enter the Fields, they shall click the Keyboard Icon at the bottom of the screen to input the values.


Figure 9. Keyboard Entry



Command Results

They can also use the Stylus, depending on the settings selected by the user in the control panel.

Figure 10. Stylus Entry




If command processing takes more than 2 seconds a message will display, "Running Test..."

Result Screen

The display of the output shall always be in Hexadecimal Format.

Figure 12. Results Screen




The user shall enter values in Hex or Decimal. The following values shall be allowed for each entry method:

- Hex: A to F and 0 to 9. (not case sensitive)
- Decimal: 0 to 9

When the user presses, "Test", the values shall be checked whether they match the values that are allowed. If not, they shall get an Error Message as follows:

Figure 11. Invalid Entry



Pressing the "Back" Key shall always take the user back to the Main Entry Screen as shown in Figure 6

After the user presses, "Continue", they shall be taken back to the field where the incorrect entry method was found.

Table 1. Handset Test Command Summary

| Opcode Hexadecimal | Opcode Decimal | Opcode Mnemonic | Key Entry Format | Op Code Description |
|--------------------|----------------|-----------------|---|--|
| 0 | 0 | AUD_TN_LST | 0 * <Action> * <Tone Identifier>OK | Generate/disable predefined tone |
| 3 | 3 | AUD_CTRL | 3 * <Device/Process> * <Action>OK | Control various audio functions; enable/disable vibrator |
| 4 | 4 | AUD_LPB | 4 * <Loopback Type> * <Action>OK | Enable audio loopback |
| 5 | 5 | AUD_LVL | 5 * <Get/Set> * <Volume>OK | Set audio level |
| 6 | 6 | AUD_PATH | 6 * <Input Path> * <Output Path> * <RX Mute> * <TX Mute>OK | Change audio path |
| 7 | 7 | CARRIER | 7 * <Option> * <Action> OK | Enable GSM TX carrier |
| 0A | 10 | CP_MODE | 10 * <Set/Get> * <Sub-mode> OK | Set Call Processing Mode |
| 12 | 18 | INVM | 18 * <level> OK | Master clear or reset |
| 14 | 20 | LOAD_SYN | 20 * <Channel> * 0 OK | Set GSM channel |
| 22 | 34 | RESTART | 34 * OK | Generate a software restart |
| 2D | 45 | SET_RF_PWR | 45 * <Power level> OK | Set GSM Power level |
| 36 | 54 | SUSPEND | 54 OK | Terminate normal mode and enter test mode |
| 37 | 55 | TST_DISP | 55 * <Parameter> * <Parameter Data> OK | Display predefined patterns |
| 39 | 57 | VERSION | 57 * <version Type>OK | Retrieve SW version information |
| 3E | 62 | LEDS | 62 * <LED> * <Action> * <Data> OK | Control status LEDs |
| C0B | 3083 | WLOAD_SYN | 3083 * <RX_FREQ_ID> * <TX_FREQ_ID>OK | Set WCDMA channels |
| C0E | 3086 | W_CARRIER | 3086 * <Channel ID> * <Action> * <Tx Pwr> * <Max Pwr> * <Min Pwr> * <Data Pattern> * <Channelization> * <Scrambling> * <DPCCH Spread Factor> * <DPDCH Spread Factor> * <Channelization Code> * <Scrambling Code> OK | Enable WCDMA TX carrier |

Table 2. Standard Response Codes

| Opcode (Hexadecimal) | Opcode (Decimal) | Response Field Definition |
|---------------------------------|-----------------------------|--|
| 0000b (0x00) | 0 | parse error (no data follows): invalid data length for command |
| 0001b (0x01) | 1 | parse error (no data follows): inadequate security level for command/parameter |
| 0010b (0x02) | 2 | parser error (no data follows): command/parameter not supported for current protocol (CDMA, GSM, TDMA) |
| 0011b (0x03) | 3 | parse error (no data follows): command/parameter not supported for current mode (normal, test mode, handset test mode) |
| 0100b (0x04) | 4 | parse error (no data follows): unsupported/invalid opcode |
| 0101b (0x05) | 5 | parse error (no data follows): unsupported/invalid parameter for opcode |
| 0110b (0x06) | 6 | command response: generic success (no data follows) |
| 0111b (0x07) | 7 | command response: generic failure (no data follows) |
| 1000b (0x08) | 8 | command response: data follows |
| 1001b (0x09) | 9 | unsolicited/multiple response: data follows (sequence tag is 0) |
| 1010b (0x0A) | 10 | error: couldn't allocate memory |
| 1011b (0x0B) | 11 | error: internal task error |
| 1100b (0x0C) | 12 | error: Test Command task timed out waiting for response from another SW component |
| 1101b (0x0D) | 13 | CDMA: parse error (no data follows): command/parameter not supported for current sub-mode TDMA: command not supported in current Call Stack Test Mode |
| 1110b (0x0E) | 14 | error: length specified in command header greater than length received by transport layer |
| 1111b (0x0F) | 15 | error: irrecoverable error; phone state has been lost. Phone is being powered down |

Table 3. Field and Parameter descriptions

| Opcode (Decimal) | Opcode Mnemonic | Field | Description |
|---------------------|--------------------|---------|---|
| 0 | AUD_TN_LST | Field 1 | 0 = stop a tone 1 = start a tone |
| | | Field 2 | 55 through 64 = DTMF tones, refer to table xx for more tones |
| 3 | AUD_CTRL | Field 1 | 0 = Vibrator 2 = Echo canceling 3 = Noise suppressor |
| | | Field 2 | 0 = Disable 1 = Enable |
| 4 | AUD_LPB | Field 1 | 0 = PCAP loopback 6 = CODEC loopback 7 = VOCODER (speech) loopback |
| | | Field 2 | 0 = Disable Audio loopback 1 = Enable Audio loopback |
| | | Field 3 | This field is valid only for VOCODER loopback 0 = AMR 4.75 1 = AMR 5.15 2 = AMR 5.90 3 = AMR 6.70 4 = AMR 7.40 5 = AMR 7.95 6 = AMR 10.20 7 = AMR 12.20 8 = Full Rate 16 = Enhanced Full Rate 32 = Half Rate |
| 5 | AUD_LVL | Field 1 | 0 = Set the volume specified |
| | | Field 2 | 0 = lowest, 7 = loudest |

Table 3. Field and Parameter descriptions - continued

| Opcode (Decimal) | Opcode Mnemonic | Field | Description |
|---------------------|--------------------|---------|---|
| 6 | AUD_PATH | Field 1 | 0 = As is. 1 = Mute input path 2 = Internal (handset) mic 3 = Ext audio input (CE Bus) 4 = Boom (headset) mic 5 = Ext digital audio (USB) 7 = Bluetooth time slot 1 audio input 8 = Bluetooth time slot 2 audio input 9 = Bluetooth time slot 3 audio input |
| | | Field 2 | 0 = As is 1 = Mute output path 2 = Internal (handset) Speaker 3 = Alert 4 = Ext audio output (CE Bus) 5 = Speakerphone 6 = Boom (headset) speaker |
| 7 | CARRIER | Field 1 | 0 = All zeroes 1 = All ones 2 = pseudo random sequence w/midamble 0 3 = pseudo random sequence w/midamble 1 4 = pseudo random sequence w/midamble 2 5 = pseudo random sequence w/midamble 3 6 = pseudo random sequence w/midamble 4 7 = pseudo random sequence w/midamble 5 8 = pseudo random sequence w/midamble 6 9 = pseudo random sequence w/midamble 7 10 = RACH BURST 12 = pseudo random sequence w/midamble 0 two time slot 13 = pseudo random sequence w/midamble 0 three time slot |
| | | Field 2 | 0 = disable 1 = enable |

Table 3. Field and Parameter descriptions - continued

| Opcode (Decimal) | Opcode Mnemonic | Field | Description |
|---------------------|--------------------|-------------------|--|
| 10 | CP_MODE | Field 1 | 0=set submode 1=get submode |
| | | Field 2 | 5 = GSM 1900 6 = GSM dual band GSM900/GSM1800 8 = WCDMA Region 1 10 = Automatic - Dual mode: WCDMA region 1 and GSM dual band GSM900/GSM1800.a |
| 18 | INVM | Field 1 | 0 = Master Reset 1 = Master Clear |
| 20 | LOAD_SYN | Field 1 | Channel number in decimal. Valid channel numbers are: • 1-124 (PGSM 900 MHz) • 0, 975-1023 (EGSM 900 MHz) • 512-885 (DCS 1800 MHz) • 512-810 (PCS 1900 MHz) |
| | | Field 2 | Reserved for future use and TDMA; set to 0. |
| 34 | RESTART | Field 1 | As is |
| 45 | SET_RF_PWR | Field 1 | PA power level (0-19) |
| 54 | SUSPEND | Field 1 | As is |
| 55 | TST_DISP | Field 1 | 2 = Display Predefined Pattern 9 = Turn On/Off the Front Light |
| | | Field 2 (Data) | Data for 2, 000 = All pixels off (all black) 001 = All pixels on (all white) 005 = Grey scale block: 16 level, Black to white 006 = Horizontal Zebra Line 014 = Eight Color Box Pattern Data for 9, 000 = Front Light Off 001 = Front Light On, Full Intensity |

Table 3. Field and Parameter descriptions - continued

| Opcode (Decimal) | Opcode Mnemonic | Field | Description |
|---------------------|--------------------|---------|--|
| 57 | VERSION | Field 1 | 016000 = DSP Version 017000 = User (login) pf process that created this file 017001 = Build time (universal) in ISO-8601 format 017002 = Clearcase view tag name 017003 = Product base label from Clearcase config spec 017004 = Product ID 017005 = Version Number 017006 = Build commentary 018000 = Flash Booter version number (P2K Booter Only) |
| 62 | LEDS | Field 1 | 0 = Keypad Backlight LED 3 = Red LED 4 = Green LED |
| | | Field 2 | 3 = Set duty cycle (Red/Green LEDS Only) |
| | | Field 3 | Duty Cycle setup, 000 = Off 012 = ON |
| 3083 | WLOAD_SYN | Field 1 | UARFCN for Receive Frequency ID. Valid values are between 0 and 16383. If TX_FREQ_ID is set to 0xFFFF, then RX_FREQ_ID must take values between 190*5 and 16383. Note: If a valid TX_FREQ_ID will be entered, RX_FREQ_ID must be set to FFFF. |
| | | Field 2 | UARFCN for Transmit Frequency ID. Valid values are between 0 and 16383. If it is set to 0xFFFF the TEST_TASK will derive the TX_FREQ_ID from the RX_FREQ_ID. Note: If a valid RX_FREQ_ID is entered, TX_FREQ_ID must be set to FFFF. |

Table 3. Field and Parameter descriptions - continued

| Opcode (Decimal) | Opcode Mnemonic | Field | Description |
|---------------------|--------------------|----------|--|
| 3086 | W_CARRIER | Field 1 | Channel identifier (0-16383). |
| | | Field 2 | 0 = Enable carrier. 1 = Disable carrier. |
| | | Field 3 | Initial transmit power (dBm). -128 dBm to 127 dBm |
| | | Field 4 | Maximum transmit power (dBm). -128 dBm to 127 dBm |
| | | Field 5 | Minimum transmit power (dBm). -128 dBm to 127 dBm |
| | | Field 6 | 0 = All 0s. 1 = All 1s. 2 = PN9. 3 = PN15. |
| | | Field 7 | 0 = Disable spreading. 1 = Enable spreading. |
| | | Field 8 | 0 = Disable scrambling. 1 = Enable long scrambling. 2 = Enable short scrambling. |
| | | Field 9 | 0 = SF256, slot format 0. 1 = SF256, slot format 1. ... 5 = SF256, slot format 5. |
| | | Field 10 | 0 = SF256, slot format 0. 1 = SF128, slot format 1. ... 6 = SF4, slot format 6. |
| | | Field 11 | Channelization Code Number. |
| | | Field 12 | Scrambling Code Number. |

Manual Test Procedures

Introduction

The phone allows keypad and computer controlled testing of various digital test parameters.

This chapter includes the keypad/computer functions and recommended equipment setup to use when testing a phone manually.

Call-Processing Tests

Most communications analyzers can simulate a cell site in order to perform automatic call-processing tests. Automatic call processing tests can be performed while the phone is in standby mode.

Refer to the communications analyzer's manual for details about performing call-processing tests. The following call-processing test sequence is recommended:

1. GSM Mobile Originated Call
2. WCDMA Mobile Originated Call
3. GSM handover
4. DCS handover
5. PCS handover

Non-Signalling Test Measurements

In an event that the phone exhibits RF failures that prevent call processing, the service technician may need to perform some non-signalling tests. These tests will provide information regarding which stage of the phone is failing prior to opening the phone for troubleshooting. The following tests will be described in this chapter.

- GSM/DCS/PCS TX Power Output
- GSM RSSI
- WCDMA TX Power Output

The digital phasing parameters are stored in a EPROM on the Transceiver Board. Each transceiver is shipped from the factory with these parameters already calibrated. However, if a board is repaired, these parameters should be measured and, if necessary, adjusted with the GP-Gate System. Checking and adjusting calibration parameters is also useful as a troubleshooting/diagnostic tool to isolate defective assemblies.

GSM/DCS/PCS Call Processing

GSM/DCS/PCS Call Processing

In order to successfully complete a GSM call processing procedure, a test USIM card needs to be available. Test USIM cards have default call parameters that allow users to perform call processing tests through GSM base station simulators. This allows service technicians to perform simulations without accessing the customer's cellular account.

Hardware Requirements

There are various hardware configurations to perform manual call processing procedures. Below, is a list of the various options. All options require the battery to be attached. A GP-gate system can also be used for manual testing. Refer to the GP-gate user's manual for details.

Power Options

- Fully Charged Battery (SNN5639B¹ or equivalent)
- Full-Rate Power Supply (PSM5049A¹)
- Battery Eliminator (5-00-3F-10000²) with 2-Wire Adapter (2-00-68-10000²)
Note: Requires a single output power supply

Control Interface Options (PCS Only)

- USB Cable (SKN6311A¹)
- Serial Cable (SKN6315A¹) with CE converter (SYN0279B¹)

Note: If handset test commands are being used, a control interface is not needed.

¹Contact your local Motorola dealer for ordering

²Contact AMS Software and Elektronik GmbH for ordering

RF Interface (Everything listed is required)

- SMA/N-type Adapter (0-00-00-40042²)
- SMA Cable 0.5m (0-00-00-40047²)
- Repair Fixture (5-00-4T-10000²)
- USIM (0-00-00-40810²)

Software Requirements (PCS only)

If PCS call processing procedures are necessary, the user will need to send a test command to the phone prior to beginning the test. The command can be initiated through handset test commands or computer test commands. Software requirements for each method is listed below.

Handset Test Command

- No software needed


Computer Test Command

- Radio Comm (latest release)


Call Origination (GSM and DCS only)

Use the following procedures for call processing. The screen shots are from a Rohde and Schwarz CMU 200. The procedures can be adopted to any other test box that will be used to perform call processing.

1. Install the test USIM in phone.
2. Connect hardware as illustrated in figure 13.
3. Setup up the test box for GSM or DCS Signalling

Figure 10. GSM Signalling Setup

4. Set Broadcast Channel (BCH) to 120 (GSM) or 700 (DCS)
5. Set Broadcast channel level to -85dBm
6. Set Traffic Channel (TCH) to 38 (GSM) or 512 (DCS)
7. Set Traffic channel level to -85dBm

Figure 11. GSM Connection Control

8. Wait until the phone indicates a receive signal
9. Dial a number from the phone and press the send button.

10. The phone is now connected.



Figure 12. GSM Call Connected

Figure 13. A920 Manual Test Hardware Configuration



Call Origination (PCS Only)

Before beginning, one of the following test command procedures needs to be completed.


Handset Test Command

- Power up phone
 - Enter the following key sequence
 - Menu 0 H T C M D *
- 
- Enter the following test commands in the Opcode screen
 - 54 ok SUSPEND
 - 10*0*5 CPLOAD, GSM 1900
 - Power cycle phone

RadioComm Test Command

- Connect as illustrated in figure 13
- Power up phone
- Start RadioComm application
- Correctly select Settings option for USB or serial

Figure 14. RadioComm COM Port



- Click on AT+/mode, suspend, CP_Mode 1900, respectfully

Figure 15. Radio Comm Screen



- Power cycle phone

Repeat steps 1 through 10 in the ,“Call Origination (GSM and DCS only),” section with the following modifications,

- Set PCS Signalling
- BCH = 661
- TCH = 512

Once PCS call processing is complete, return the phone to its original state by performing the following procedure,

Handset Test Command

- 54 ok SUSPEND
- 10*0*10 CPLOAD, Dual mode
- Power cycle phone

Computer Test Command (Radio Comm)

- Click on AT+/mode, Suspend, CP_Mode 900/ 1800, respectfully
- Power cycle phone

GSM/DCS/PCS Call Processing

Call Test Parameters (GSM/DCS/PCS)

While the phone under test is in an active call, the parameters for each band should be verified as described.

Table 4. GSM Call Parameters

| Parameter | Low Limit | High Limit | Unit |
|--------------------------------------|-----------|------------|---------|
| Burst Avg Power Out ¹ | 31 | 33 | dBm |
| Burst Output Shape | 1 | 1 | P/F |
| Time Advance Error | -1 | 1 | bit/sym |
| RMS Phase Error | 0 | 5 | deg |
| Peak Phase Error | -20 | 20 | deg |
| Frequency Error | -90 | 90 | Hz |
| RX Level Error@-105 dBm ² | 1 | 9 | |
| RX Quality @-105 dBm ² | 0 | 4 | |
| BER @-105, 10k bits ³ | 0 | 2 | % |

¹Power Level = 5

²Set BS TCH level to -105 dBm

³Set BER TCH level to -105 dBm with 10k bits or 128 Frames

Table 5. DCS Call Parameters

| Parameter | Low Limit | High Limit | Unit |
|--------------------------------------|-----------|------------|---------|
| Burst Avg Power Out ¹ | 28 | 32 | dBm |
| Burst Output Shape | 1 | 1 | P/F |
| Time Advance Error | -1 | 1 | bit/sym |
| RMS Phase Error | 0 | 5 | deg |
| Peak Phase Error | -20 | 20 | deg |
| Frequency Error | -180 | 180 | Hz |
| RX Level Error@-103 dBm ² | 3 | 11 | |
| RX Quality @-103 dBm ² | 0 | 4 | |
| BER @-103, 10k bits ³ | 0 | 2 | % |

¹Power Level = 0

²Set BS TCH level to -103 dBm

³Set BER TCH level to -103 dBm with 10k bits or 128 Frames

Table 6. PCS Call Parameters

| Parameter | Low Limit | High Limit | Unit |
|--------------------------------------|-----------|------------|---------|
| Burst Avg Power Out ¹ | 28 | 32 | dBm |
| Burst Output Shape | 1 | 1 | P/F |
| Time Advance Error | -1 | 1 | bit/sym |
| RMS Phase Error | 0 | 5 | deg |
| Peak Phase Error | -20 | 20 | deg |
| Frequency Error | -190 | 190 | Hz |
| RX Level Error@-104 dBm ² | 2 | 10 | |
| RX Quality @-104 dBm ² | 0 | 4 | |
| BER @-104, 10k bits ³ | 0 | 2 | % |

¹Power Level = 0


²Set BS TCH level to -104 dBm

³Set BER TCH level to -104 dBm with 10k bits or 128 Frames

Burst Output Shape should fall within the standard limits of the Power Ramp.

BER measurements is only required if RX Quality reads a value of 4 or greater.

Figure 16. Burst Output Shape



It is recommended that handover procedures be performed as shown in the following table.

Table 7. GSM/DCS/PCS Handover

| Band | From | | To | |
|------|-----------------|---------------|-----------------|---------------|
| | Traffic Channel | Power Control | Traffic Channel | Power Control |
| GSM | 975 | 5 | 124 | 19 |
| DCS | 512 | 0 | 885 | 15 |
| PCS | 512 | 0 | 810 | 15 |

WCDMA Call Processing

In order to successfully complete a GSM call processing procedure, a test USIM card needs to be available. Test USIM cards have default call parameters that allow users to perform call processing tests through GSM base station simulators. This allows service technicians perform simulations without accessing the customer's cellular account.

Hardware Requirements

Refer to , "Hardware requirements," under, "GSM/DCS/PCS Call Processing." Also Refer to Figure 13.

Software Requirements

None.

Call Origination (WCDMA)


Use the following procedures for call processing. The screen shots are from a Rohde and Schwarz CMU 200 with WCDMA signalling options installed. The procedures can be adopted to any other test box that will be used to perform call processing.

1. Install the test USIM in phone.
2. Connect hardware as illustrated in figure 4.

Note: Control interface doesn't need to be connected at this time.


3. Setup up the test box for WCDMA FDD Signalling

Figure 17. WCDMA Signalling Setup




4. Set UE Signal, RF Channel Uplink to 9750

Figure 18. Channel Uplink(UE Signal)




WCDMA Call Processing

5. Set TPC Pattern Type to All 1

Figure 19. TPC Pattern Type(UE Signal)

6. Wait until the phone indicates a signal
 9. Dial a number from the phone and press the send button.
 10. The phone is now connected.

Figure 20. WCDMA Call Connected

WCDMA Call Test Parameters

While the phone under test is in an active call, the parameters for each band should be verified as described.



Table 5. WCDMA Call Parameters

| Parameter | Low Limit | High Limit | Unit |
|-----------------------------------|-----------|------------|------|
| Avg. RMS Power Out ¹ | 20.5 | 21.5 | dBm |
| Avg. Frequency Error ² | -195 | 195 | Hz |
| Avg. RMS EVM ² | 0 | 13.5 | % |
| Avg. RMS ACLR - 2 ³ | -100 | -43 | dB |
| Avg. RMS ACLR - 1 ³ | -100 | -33 | dB |
| Avg. RMS ACLR + 1 ³ | -100 | -33 | dB |
| Avg. RMS ACLR + 2 ³ | -100 | -43 | dB |

¹Refer to Figure 10

²Refer to Figure 11

³Refer to Figure 12

Figure 21. WCDMA Modulation**Figure 22. ACLR Screen**

Non-Signalling Test Procedures (GSM/DCS/PCS)

To perform non-signalling test procedures, the user is required to be familiarized with sending test commands to the phone under test. The test commands can be sent using the Handset test command interface or through a computer. Please refer to section, "Handset Test commands," for details on how to send test commands through phone keypad entry.

In order to successfully send test commands to the phone under test, the phone needs to be in suspend mode. Follow the listed procedure to place the phone in suspend mode.


Handset Test Commands

54 ok Suspend

Radio Comm Test Commands

Click AT+MODE then SUSPEND (Serial Only)

Click PST Initialize and click SUSPEND when initialization is complete (USB Only)



Hardware Requirements

Refer to page 3-2 for a list of Hardware. Refer to Figure 13 for a configuration illustration.

Software Requirements

Handset Test Command

- No software needed

Computer Test Command

- Radio Comm (latest release)

Verify TX Power Output (GSM/DCS/PCS)

Verify the TX Power output by initiating the commands in this section. Verify that the results fall within the following limits.

Table 8. TX Power Limits

| Parameter | Low Limit | High Limit | Unit |
|------------------|-----------|------------|------|
| GSM TX Power Out | 31 | 33 | dBm |
| DCS TX Power Out | 28 | 29.5 | dBm |
| PCS TX Power Out | 28 | 29.5 | dBm |

Handset Test Commands

| | |
|----------------------|-----------------------|
| 54 | Suspend |
| 10*0*10 ¹ | WCDMA/GSM/DCS mode |
| 20*38*0 ² | Set Channel 38 |
| 45*5 ³ | Set GSM Power Level 5 |
| 7*6*1 | Enable Carrier |


¹10*0*5 for PCS mode

²20*700*0 for DCS Channel 700; 20*661*0 for PCS Channel 661

³45*0 for DCS/PCS Power level 0

Non-Signalling Test Procedures (GSM/DCS/PCS)Radio Comm Test Commands

Click on 900/1800 (GSM/DCS) or 1900 (PCS)




Enter 38 (GSM), 700 (DCS), or 661 (PCS) and then click Set



Enter 5 (GSM) or 0 (DCS/PCS) and then click Set



Select 06 and then click ON

GSM RSSI

Verify GSM RSSI by initiating the commands in this section. Verify that the RSSI results are equal to the Broadcast Channel (BCH) level. The user will need to set the RF generator with the following parameters.

Broadcast Channel (BCH): 20
Broadcast Channel (BCH) Level: -105 dBm

Handset Test Commands

No supported test commands

Radio Comm Test Commands


Click on 900/1800 (GSM/DCS) or 1900 (PCS)



Enter Channel 20
Click INIT



Click Execute
Verify return data is approximately -105 dBm



Non-signalling Test Procedures (WCDMA)**Non-signalling Test Procedures (WCDMA)**

To perform non-signalling test procedures, the user is required to be familiarized with sending test commands to the phone under test. The test commands can be sent using the Handset test command interface or through a computer. Please refer to section, "Handset Test commands," for details on how to send test commands through phone keypad entry. Also, refer to, "Computer Test Commands," for details on how to send test commands through the computer.

In order to successfully send test commands to the phone under test, the phone needs to be in suspend mode. Follow the listed procedure to place the phone in suspend mode.


Handset Test Commands

54 ok Suspend

Radio Comm Test Commands

Click AT+MODE then SUSPEND
(Serial Only)

Click PST Initialize and click SUSPEND when initialization is complete
(USB Only)

**Hardware Requirements**

Refer to page 2 for a list of Hardware. Refer to Figure 4 for a configuration illustration.

Software Requirements**Handset Test Command**

- No software needed

Computer Test Command

- Radio Comm (latest release)

Verify TX Power Output (WCDMA)

Verify the TX Power output by initiating the commands in this section. Verify that the results fall within the following limits.

Table 9. WCDMA TX Power Output

| Parameter | Low Limit | High Limit | Unit |
|-----------------|-----------|------------|------|
| WCDMA Power Out | 20.5 | 21.5 | dBm |

Handset Test Commands

| | | |
|----------|-----------|----------------------|
| 54 | | Suspend |
| 3086 | | W_CARRIER |
| Field 1 | 9750 | Set Channel |
| Field 2 | 0 | Enable Carrier |
| Field 3 | 023 | Max Power Out |
| Field 4 | 027 | Max TX Power |
| Field 5 | 206 | Min TX power |
| Field 6 | 002 | PN9 Data pattern |
| Field 7 | 1 | Enable spreading |
| Field 8 | 01 | Long scrambling |
| Field 9 | 000 | SF256, Slot format 0 |
| Field 10 | 000 | SF256, Slot format 0 |
| Field 11 | 000 | Channelization Code |
| Field 12 | 000000000 | Scrambling Code |

Note: Enter 1 in field 2 to disable carrier


Audio/Vibrator Test Procedures**Radio Comm Test Commands**

Click on WCDMA



For W_CARRIER assign these actions to each field

| | |
|---------------------|-----------------|
| Freq ID (Dec) | 9750 |
| Action | Enable |
| Channelization | Enable |
| Data Pattern | PN 9 |
| Scrambling | Long |
| DPCCH | SF256, SF0 |
| DPDCH | SF256, SF0 |
| Channelization Code | 00 |
| Transmit Power | 15 ¹ |
| Max Power | 15 ¹ |
| Min Power | 80 ² |
| Scram Code | 00 |

¹0x0015 -> 21 dec -> +21dBm²0x0080 -> 128 dec -> (128-256 = -128 dBm)**Audio/Vibrator Test Procedures**

This section describes how to use test commands to verify audio and vibrate functions.


In order to successfully send test commands to the phone under test, the phone needs to be in suspend mode. Follow the listed procedure to place the phone in suspend mode.

Handset Test Commands

54 ok Suspend

Radio Comm Test Commands

Click AT+MODE then SUSPEND
(Serial Only)



Click PST Initialize and click SUSPEND when initialization is complete
(USB Only)

Vibrator Test**Handset Test Commands**

| | |
|-------|------------------|
| 3*0*1 | Enable Vibrator |
| 3*0*0 | Disable Vibrator |

Radio Comm Test Commands

Enable or Disable Vibrator

**Verification**

Verify vibration function when enabled.

Handset Mic/Speaker testHandset Test Commands


- 6*2*2 Enable internal mic and handset speaker
 4*7*1*16 Enable VOCODER loopback at Enhanced Full Rate

Radio Comm Test Commands

Enable internal mic and headset speaker



Enable Vocoder loopback at Enhanced Full Rate

Verification

Speak into the handset mic and listen for undistorted speech in the handset speaker.

Mono Headset Mic/Speaker testHandset Test Commands


- 6*4*6 Enable headset mic and headset speaker
 4*7*1*16 Enable VOCODER loopback at Enhanced Full Rate

RadioComm Test Commands

Enable headset mic and headset speaker



Enable Vocoder loopback at Enhanced Full Rate

Verification

Speak into the headset mic and listen for undistorted speech in the headset speaker.

Software Version Check**Stereo Headset Mic/Speaker test**Handset Test Commands


- 6*4*8 Enable headset mic and headset speaker
4*7*1*16 Enable VOCODER loopback at Enhanced Full Rate

RadioComm Test Commands

Enable headset mic and headset speaker



Enable Vocoder loopback at Enhanced Full Rate

**Melody Speaker test**Handset Test Commands

- 0*1*245 Play BACH_INVENTION_1
0*0*245 Stop BACH_INVENTION_1

NOTE: DO NOT issue a Suspend command (54 ok) for this test.

RadioComm Test Commands

Currently not supported

Verification

Listen for undistorted audio.

Verification

Speak into the headset mic and listen for undistorted speech in the headset speaker.

Software Version Check

Use the following procedures to retrieve software information. Software information can also be retrieved from the phone's customer User Interface. Refer to the phone's user manual for details.


In order to successfully send test commands to the phone under test, the phone doesn't need to be in suspend mode. Follow the listed procedure to configure the phone to accept test commands

Handset Test Commands

None

Radio Comm Test Commands

Click AT+MODE (Serial Only)
Click PST Initialize (USB Only)



Test Commands


57*017003 Read Software Version
57*017001 Read Build Date

RadioComm Test Commands

Select Product Base Label and click "Get" to retrieve software version



Select Build Time and click "Get" to retrieve Build Date



Display Test Procedures

This section will describe the proper test procedures to determine the functionality of the color display. Any tests that involve displaying a predefined pattern can be returned to the Opcode screen by pressing the right softkey of the phone.


In order to successfully send test commands to the phone under test, the phone needs to be in suspend mode. Follow the listed procedure to place the phone in suspend mode.

Handset Test Commands

54 ok Suspend

Radio Comm Test Commands

Click AT+MODE then SUSPEND (Serial Only)
Click PST Initialize and click SUSPEND when initialization is complete (USB Only)



Display Backlight Test

Handset Test Commands

55*9*000 Backlight Off
55*9*001 Backlight On, full intensity

RadioComm Test Commands

Click "FL Off" to disable backlight
Click "FL On-Full" to enable backlight



Verification

Verify that the backlights respond for each issued command.

Display Test Procedures**Display Color Test**Handset Test Commands


55*2*014 Eight Color Box Pattern

RadioComm Test Commands

Select Eight Color Box and click "Set"

Verification

Verify that the color pattern on the phone's display matches the color box in figure 23. Also verify edges (uniform/smooth).

Figure 23. Eight Color Box Pattern**Display Linearity Test**Handset Test Commands

55*2*005 Grey Scale Block

RadioComm Test Commands

Select Grey Scale and click "Set"

Verification

Verify that the Grey scale block on the phone's display matches the Grey scale block in figure 14. This test can also be used to confirm that the color intensity is linear.

Figure 24. Grey Scale Block

Display Flicker TestHandset Test Command


55*2*006 Horizontal Zebra Line

RadioComm Test Commands

Select Horizontal Zebra and click "Set"

Verification

Verify that no noticeable flicker exists.

Figure 25. Zebra Pattern**Display Pixel Defect (Bright)**Handset Test Commands

55*2*001 All pixels on (all white)

RadioComm Test Commands

Select All Pixels Off and click "Set"

Verification

Verify that no greater than two pixels are off.

Display Pixel Defect (Dark)Handset Test Commands

55*2*000 All pixels off (all black)

RadioComm Test Commands

Select All Pixels On and click "Set"

Verification

Verify that no greater than two pixels are on.

LEDS and Keypad Backlight

Use the following procedures to verify status LED and keypad backlight.

In order to successfully send test commands to the phone under test, the phone doesn't need to be in suspend mode. Follow the listed procedure to configure the phone to accept test commands.


Handset Test Commands

None

Radio Comm Test Commands

Click AT+MODE then SUSPEND
(Serial Only)

Click PST Initialize and click SUSPEND when initialization is complete
(USB Only)



Keypad Backlight

Handset Test Commands

62*0*1¹ Enable Keypad Backlight

62*0*0¹ Disable Keypad Backlight

¹Leave field 3 blank and press OK

RadioComm Test Commands



Select Keypad to enable. Deselect Keypad to disable.

Verification

Verify that all keypad backlight LEDs activate.

Status LEDs

Handset Test Commands

62*3*3*012¹ Enable Red LED

62*4*3*012¹ Enable Green LED

¹000 to disable

RadioComm Test Commands

Select Red LED or Green LED to enable. Deselect Red LED or Green LED to disable.



Verification

Verify that the Red and Green status LEDs activate.

Bluetooth Tests (V500/V600 only)

Use the following procedures to verify functionality of the Bluetooth device integrated in the phone.


In order to successfully send test commands to the phone under test, the phone doesn't need to be in suspend mode. Follow the listed procedure to configure the phone to accept test commands.

Handset Test Commands

None

Radio Comm Test Commands

Click AT+MODE then SUSPEND (Serial Only)



Click PST Initialize and click SUSPEND when initialization is complete (USB Only)


Unmodulated CW TX test

Handset Test Commands


Not Supported

RadioComm Test Commands

Under Bluetooth, select parameter 84 and click execute, then select 81 and click execute.



Under Bluetooth, select parameter 01 and enter 2DFC0129 in the "TO Radio" field. Click Execute.



NOTE: The Bluetooth TX signal will activate momentarily once the HCI command is issued. You must have the RF probe positioned for measurement once you click execute.

Verification

Verify that a 2441MHz signal is present. If the phone is closed, use a RF probe to sniff the strongest signal around the "7" key of the keypad. If the phone is open (shields off), verify that -2dBm to +4dBm is read from R320. An high impedance RF probe is required to read this range. Use of lower quality RF probes will result in signal level differences.

Camera Testing

This document is intended to describe the procedures that will determine whether the camera function of a Motorola terminal is under normal operating conditions.

In order to successfully send test commands to the phone under test, the phone doesn't need to be in suspend mode. Follow the listed procedure to configure the phone to accept test commands.


Handset Test Commands

Not supported

Radio Comm Test Commands

Click AT+MODE then SUSPEND
(Serial Only)

Click USB Initialize and click SUSPEND when initialization is complete
(USB Only)



Hardware Requirements

The following hardware will be required to properly test the camera function of the phone.

1. Desktop Charger (SPN5032A or equivalent)
2. USB or RS232 control interface (refer to figure 4)
3. Fast Rate Charger (SPN5078A or equivalent)
4. Hardcopy of Macbeth Color Chart
5. Hardcopy of Focus Chart
6. Hardcopy of Grey Chart

Camera Test Configuration

Use any color printer to print a hardcopy of the Macbeth color chart. The Focus chart and Grey chart can be printed using any B/W printer.

For best results follow this recommended setup,

1. Attach chart to a flat vertical surface (wall)
2. Attach the phone to the desktop charger
3. Attach the control interface to desktop charger
4. If necessary, attach power supply to control interface.
5. Turn on phone.
6. Select Camera option in phone
7. Position Desktop charger so that the camera test chart completely fills the viewfinder.

Assign a permanent space in the test lab for these test procedures. Always use the same lighting conditions. Also, it's recommended that a "golden picture" is saved and used for comparison.

There is a variety of ways the camera test charts can be attached to a vertical flat surface. They can be taped, tacked, attached to flip charts, etc. Use your best judgement.

The desktop charger is being used as a fixture to position the phone for test, therefore, it's recommended that the desktop charger is attached to a countertop to prevent any movement.


Figure 9. Camera Test Configuration

Image Capture


The listed steps should be followed to capture three images (1) the Macbeth color chart, (2) the focus chart, and (3) the grey scale chart. The user will be required to print all images found in Appendix A.

Handset Test Commands

Not supported

Radio Comm Test Commands

Under “Common Features” select Camera



Once the picture is captured, it'll be displayed on the screen. Click “Save To File”




Click “Take Picture”



Macbeth Color Chart

1. From the computer, open the captured color chart image.
2. Compare, the color blocks of the printed Macbeth color chart to the captured image.




Follow the listed verifications to determine the quality of the image.

1. Minimal noise level for Blue, Green and Red on blocks 19 through 24.
2. Uniformity for grey scale blocks 19 through 24.
3. Good white balance on blocks 19 through 24.
4. Good color reproduction on blocks 13 through 18.

Focus Chart

1. From the computer, open the captured focus chart image.



Verify the focus quality at the center, top-left corner, bottom-left corner, top-right corner, and bottom-right corner.

Grey Scale Chart (Shading Test)

1. From the computer, open the captured grey scale chart image.



Verify that there is minimal shading deviations on all four corners when compared to the center of the image.

Service Diagrams

Introduction

The service diagrams were carefully prepared to allow a Motorola certified technician to easily troubleshoot cellular phone failures. Our professional staff provided directional labels, color coded traces, measurement values and other guidelines to help a technician troubleshoot a cellular phone with speed and accuracy.

We worked hard in trying to provide the best service diagrams, therefore, to avoid cluttered diagrams, we may exclude some components from the service diagrams. Our professional staff carefully selected to excluded components that are unlikely to fail.

Because of the sensitivity of RF, measured readings will be greatly affected if they're taken in certain locations. To get the most accurate readings, take measurements nearest to the labeled measurement on the service diagram.


Test Point Measurements

The measurements labeled on the service diagrams are approximate values and may vary slightly. These measurements are dependent on the accuracy of the test equipment.

It is strongly recommended that the test equipment calibration schedule be followed as stated by the manufacturer. RF probes should be calibrated for each frequency in which tests are going to be performed.

The types of probes used will also affect measurement values. Test probes and cables should be tested for RF losses and loose connections.

4-2 A920: Antenna Circuit



Description

All cellular receive bands are fed into either the internal antenna or external antenna. M001 is a mechanical switch which has the internal antenna path connected when a no insertion condition exists. The RF path will switch to external antenna upon insertion of a male SMA connector to M001. The internal antenna path is fed to the FEM(Front End Module) through antenna matching components. The FEM provides band selection and filtering between the EGSM, DCS, PCS and WCDMA receive and transmit bands to a single antenna port. GSM band selection is done by control lines N_BAND_1 and N_BAND_0_G. Mode selection is done by control lines HL_TX_EN, RX_EN_LIFE, N_GSM_EXC_EN, and GSM_EXC_EN. The diplexing arrangement permits reception of WCDMA signals in any FEM switch position. This allows the phone, while in a GSM call in any band, to detect signals from a WCDMA base station. The decision may then be made to hand over to the WCDMA system. Similarly, EGSM base station signals can be detected while the phone is in a WCDMA call to permit a handover decision from WCDMA to EGSM (This is not possible for base station signals in the DCS and PCS bands.).


Signals received at the antenna between 2110 - 2170MHz will see the RF switch as an open circuit at any position. Consequently WCDMA Rx signals will go through FL2 to the WCDMA receiver. FL2 should have a maximum insertion loss of ~0.5dB. Outside of the WCDMA Rx band, FL2 behaves as an open circuit, preventing out-of-band signals from reaching the WCDMA receiver.

GSM, DCS, and PCS receive signals from the antenna port through the FEM should have a maximum insertion loss of -4.4dB. The FEM EGSM transmit path should have a maximum insertion loss of -2.5dB. The FEM DCS transmit path should have a maximum insertion loss of -3.1dB. The FEM PCS transmit path should have a maximum insertion loss of -3.7dB.


Q902 is a dual FET package that's being used to multiplex function of the N_BAND_0 control signal coming from the Magic LV. With the use of Q902, N_GSM_EXC_EN will follow N_BAND_0. GSM_EXC_EN will be the inverted level of N_BAND_0. Q906 is another dual FET package that's used to prevent simultaneous GSM and WCDMA transmission conditions. During WCDMA transmission conditions, HL_TX_EN will be in a high state. This will open both FETs in Q906, thus, disabling any signal functions from control lines NB_EXC_EN and N_BAND_0. Q901 is used to invert the control signal coming from Q906.

A920: Antenna Circuit

Motorola Confidential Proprietary



A920: GSM RX Front End



Motorola Confidential Proprietary

Description

The EGSM, PCS and DCS signals must first pass through baluns before reaching the LIFE IC. Since the LIFE expects differential inputs, the baluns will provide this. Baluns provide the change from an unbalanced to a balanced line condition. By directly connecting to lines together, a possibility might arise where one line might ground a signal and impair the operation of a circuit. This situation is solved through the use of an un-balanced to balanced transformer, a balun. Expected nominal losses is ~.5 - 1.0dBm.

The first IC in the EGSM, DCS, and PCS RX line up is U625 (LIFE), which is an LNA, VCO, and down converter mixer. The RX frequency is mixed down to a Very Low Intermediate Frequency (VLIF) of ~ 100KHz. This design is utilized to improve LO leakage causing RF self-mixing, DC offsets, and noise performance. The LIFE IC operates from the MAGIC_LV (tracking regulator), MAGIC_RF_V2_475, and MAGIC_SF (isolated supply for the VCO).



LIFE is comprised of four low noise amplifiers (three of which are used) with two quadrature mixer paths for use in receive GSM 900 (925- 960MHz), DCS (1805- 1880MHz), and PCS (1930-1990MHz) frequency bands, all SPI programmable. The RX_VCO signal is fed back to the MAGIC_LV prescaler input. Although the frequency will be dependent of the channel selected, the amplitude signal is ~30dBm.

LIFE contains three fully contained VCOs which operate at ~4GHz. These VCOs are internally divided to provide precise quadrature down conversion for the three frequency bands. The input signal RX_VTUNE from the RX backend processor (MAGIC_LV) selects the VCO frequency to operate at. The tune range is .5 - 4.5V. The VCO frequencies for the three technologies are: DCS 3610 - 35759MHz, EGSM 3700 - 3838MHz, and PCS 3859 - 3980MHz.


The AGC is provided by a common amplifier section, which is shared by all four LNAs. The AGC amplifier gain control is controlled by the voltage on the AGC pin, utilizing the internal 6-bit D/A to set the AGC via the SPI lines (SPIDATA, SPI_CLK, and SPI_CE). LIFE has an internal RF detector at the input of the AGC amplifier. The detected DC output level will be compared against a reference, which corresponds to the maximum safe input level to the mixer. This reference is SPI selectable so that the threshold can be set to 0dB, 3dB, 6dB, or 9dB below the level, which results in the mixer malfunction. If the detected level is above the reference then AGC_FLAG will go high. The MAGIC_LV will receive this signal as an interrupt and will reprogram the AGC until the level drops below the safe mixer input level as signified by AGC_FLAG returning low.

The output signals I / IX and Q / QX are @ ~100KHz IF value for the Very Low IF. The input pin, RX_EN_LIFE controls the on / off state of the receiver and the PLL circuits. For input amplitude at the antenna of -50 to -40dBm the expected nominal output should be an AC rms peak-to-peak voltage of ~4.5 - 14mV.

A920: GSM Receiver Front End



4-6 A920: GSM RX Back End (Magic LV)



Description

The MAGIC_LV (U500) handles the backend processing for the EGSM, DCS and PCS (VLIF: RX_I, RX_I_X, RX_Q, and RX_Q_X) signal lines from LIFE. Simply, the MAGIC_LV performs an analog to digital conversion of I/Q and sends it to the data to the board processor (POG) via the SSI (serial synchronous interface). The MAGIC_LV also has a programmable and phase-able digital IF to improve image rejection.



In MAGICLV, each channel is comprised of a Post Mixer Amplifier (PMA), an integrated passive two pole filter, a gain stage (AMP1) followed by an active programmable 2 pole anti-aliasing filter (mainly required to meet the blocking specs). This is followed by a lowpass sigma-delta ADC with a programmable oversampling clock OVSLCK (derived from the reference oscillator) equal to 13MHz for 200kHz channel spacing (13bits).

Digital detector circuits are placed on each channel at the output of the sigma delta converters. The outputs of these detectors are compared against a level defined by DET_LVL. If either of the detected levels exceeds the programmed threshold then the pin DET_FLAG is set high. This indicates that the signal level is excessively high for the sigma delta modulator. DET_FLAG is read by the processor, which will respond by re-programming one of the AGC settings to a lower gain until DET_FLAG returns low.


The outputs of the sigma-delta modulators are digitally processed through a noise cancellation circuit, comb and decimation filters. A second programmable digital LO based on a look up ROM generates digital quadrature oscillators with programmable gain/phase correction (called balanced complex multiplier) to digitally downconvert the I/Q signals to baseband (digital zero IF) through four quadrature mixers that provide image rejection of adjacent/alternate channels. Gain/ Phase correction at a single baseband frequency is performed on the Digital Quadrature Oscillator to compensate the analog gain/phase mismatch of the quadrature I and Q paths. After baseband downconversion and image reduction, the quadrature I and Q signals are further processed by digital filters that perform channel selectivity and out of band noise rejection.

A serial bus consisting of SDFS and SDRX will transmit the RXI and RXQ data in 2's complement format. BDR and BFSR are outputs from MAGIC LV. BFSR is a framing signal which marks the beginning of an I,Q transfer. BDR is the serial data. The clock used for the serial transfer is BCLKR. When NB_RX_ACQ goes high MAGIC LV will activate the SSI interface in the digital receiver section. The data transmission over the serial bus will begin at the next normal occurrence of valid I and Q data, as defined internally to the digital receiver.

A920: Magic LV (Receiver Back End)



4-8 A920: MAGIC LV Control Functions



Description

Motorola Confidential Proprietary

The MAGIC LV contains 4 tracking regulators and one superfilter, which will generate the supplies for most of the IC as well as the front end and the main VCO. The tracking regulators derive their internal power from the REG_REF pins. The reference voltages are filtered and buffered for use on the IC. The buffered voltages should track the references within $\pm 1.5\%$. A raw supply voltage is provided to the tracking regulators which is higher than REG_REF as specified below for each regulator. A superfilter is needed for the external VCO power supply. This superfilter, cascaded with an external regulator and any filtering in front of the IC, will need to provide 80dB of rejection to a 0.1V step occurring at a 217Hz rate with a risetime of 20us on the raw supply (battery) and a duty cycle of 0.125. The superfilter will use an internal pass transistor that is capable of driving a 30 mA load with a voltage drop of less than 0.4V relative to SF_SPLY from the SF_OUT pin. An external 1uf cap is required on SF_OUT. As the superfilter will track SF_SPLY it will need to sense the power on reset and turn off even though its supply may remain active. All supplies within the IC must be within 5% of their final values after 5msec from the start of POR_LB. The power on reset circuit contained within the crystal reference oscillator is used to aid this functionality.


The MAGIC_LV has two sets of SPI interfaces; one set is for handling the control interface for the LIFE IC (AUXSPI lines) and ones for interfacing with POG (SPI lines). AUX_SPI_DX is the serial data input line. AUX_SPI_CLK is the clock input line, where data shifting occurs at the rising edge of this signal. LIFE_CE is the clock enable line, active high, for the LIFE IC.

MAGIC_LV will integrate a system of D/As and control logic to generate the power amplifier control ramps. In addition, MAGIC_LV will integrate the op-amps and comparators which receive the detected output of the power amplifier and create the necessary control voltage to drive the power amplifier control port based on the control ramps. When TX_KEYM goes high, the ramp controller receives a positive input. This will cause the AOC_DRIVE pin to linearly rise which in turn will cause the PA output power to rise. The rising PA output power will cause DET_AOC to begin to rise until the DC level on DET_AOC exceeds the DC level on DET_REF by the intentional offset of the RF detector versus its reference. At this point the "Active Detect" comparator will go low and break the input voltage to the integrator with the ramp controller. This will cause the PA power to stop rising and hold the present power level as determined by the 8 bit offset value fed to the ramp controller. The PA control loop is now at a minimal power needed to keep the control system in a closed loop for a controlled ramp up of the power.

The MAGIC uses two SPI driven GPO lines which are used to control the operating bands of the GSM RF circuits. They are N_BAND_0 and N_BAND_1.

When the MAGIC LV is set to battery save mode it will shutdown the receiver analog sections (via RX_EN_LIFE), the AOC, the main synthesizer and the superfilter.

A920: Magic LV (Control)




4-10 A920: MAGIC LV (Synthesizers/Transmitter)

Description


The MAGIC_LV receives SSI Tx data at DMCS (digital input to start Tx modulation), TXCLK (clock for serial transfer) and SDTX (serial Tx data) from POG. The present serial data bit and the three previous data bits are used to set up one of 16 possible waveforms based on the sum of Gaussian pulses stored in a look up ROM. The resulting signal will then be clocked out at a 16x over-sampling rate. This data pattern input to three-accumulalator fractional N synthesizer with a 24-bit resolution. The VCO control lines must have compliance over an output voltage range of 0.3VDC to Vcc-0.3V. The charge pumps will have their own supply pin. The voltage on this pin is expected to be 2.775V typically to obtain sufficient compliance. This will drive external loop filters, which will in turn drive external VCOs. A dual port modulation mode is obtained with a 9 bit D/A which follows the modulation look up table output waveform is output on the GPO3 pin. This signal is then coupled into the loop filter to add in the higher frequency components of the modulation which may have been attenuated in the main PLL path. This will allow the use of a lower bandwidth main PLL to improve the spectral purity of the transmit signal. For EGSM the synthesizer output is 880 - 915MHz, DCS is 1710 - 1785MHz with GMSK modulation and is directly amplified to the transmitter output.

The prescaler for the main LO is able to accept input frequencies as high as 2.0GHz. The level of this signal shall be between -20dbm and -10dbm. There are two prescaler inputs to this point each has a 100W resistor in series between the pin and the actual prescaler input.


The reference oscillator is a free running 26MHz crystal. AFC is provided through the SPI bus as a programming offset to the fractional N division system. Since the 26MHz crystal is not locked to the AFC, a second fractional divider system is necessary to derive an accurate 200KHz system reference. This reference is then multiplied in a PLL to 13MHz for use as an accurate clock to the logic sections of the transceiver.



A920: Magic LV (Synthesizer/Transmitter)





4-12 A920: GSM TX VCO



Description


The VCO frequencies are 897 - 1880MHz, handling the three technology bands. The technology bands are controlled by MAGIC_LV via the data lines: N_BAND_0 and N_BAND_1. CP_TX and GPO3 provides a dual port modulation mode for the TXVCO. N_BAND_0 and N_BAND_1 will select which VCO band will be activated. GSM_EXC_EN and N_GSM_EXC_EN will enable the buffer stage of U570. TX_EN is activated prior to enabling the buffer and PA. TX_VCO_PRSC is fed back to the MAGICLV for proper PLL operation. The output frequency for GSM is TX_VCO_LB and PCS / DCS is TX_VCO_HB. The charge pump output (CPTX) from MAGIC_LV is the input (VT) for the VCO.

A920: GSM TX VCO



| Legend |
|--------------------------|
| Sig Gen: -20dBm TX: → |

4-14 A920: GSM PA





Description

U800 is a tri-band PA module that operates in EGSM, DCS and PCS bands. The nominal expected maximum gain is ~30dB. .


The AOC_DRIVE input from MAGIC_LV controls the PA output. The voltage applied at the pin is proportionally related to the output power of the PA, as the voltage increases the gain or power level increases. N_BAND_0 is used to select the operating band. LV_EXC_EN will enable PA operation.

The power detector receives the amplified GSM signal at #1 (EGSM_IN), PCS and DCS at pin #12 (DCS_PCS_IN) from the U800. U810 is a dual combination directional coupler and temperature compensated power detector output. The power detector couples the Tx power input and feeds back an output DET_AOC to MAGIC_LV. A comparator within the MAGIC_LV will sample DET_AOC and based on the power amplifier ramps will provide any necessary control voltage adjustments to AOC_DRIVE. The DET_REF is a reference voltage to MAGIC_LV. Expected nominal loss is <. 3dB.

A920: GSM TX



4-16 A920: WCDMA RX Downconverter (MAX2388)



Description

The first IC in the WCDMA Rx line up is U310 (MAX2388), which is an LNA and down converter mixer combination. The RX frequency will be mixed down to an IF frequency of 190MHz. The MAX2388 also has a shutdown mode to power down the IC, via MAX2388_SHDN*, during the front-end receiver's idling period to conserve battery life. U310 operates from the PCAP supply voltage RC_VCCA (derived from VRF_RX_2_775V). The nominal gain expect is ~15dB.

U310 operates in high gain mode selectable from RX_RF_ATTEN by the HARMONY_LITE . The nominal gain expected while in this mode is 15dB. During high input signal levels the LNA will be off.



The receive mixer is a wideband, single-balanced design. The input RF_LO (pin #5) receives the VCO frequency (2330 - 2360MHz) through FL310 from U140 (VCO). The RF input (LNA_IN, pin #10) receives the RX frequency (2110 - 2170MHz) from FL002.

The MIX_IN (pin #3) input is connected to LNAOUT (pin #1) through FL300. The function of FL300 is to provide image rejection and out-of-band interferers filtering. The frequency conversion process performed by the mixer / oscillator combination sometimes will allow a frequency other than desired frequency to be fed into the IF and subsequently amplified.


The IF mixer output (190MHz) appears on the differential IFPOS (pin #8) and IFNEG (pin #7). These open-collector outputs require an external inductor (L320 & L321) to VCC for DC biasing.

The 190MHz IF frequency passes through FL320. The IF SAW filter has a nominal center frequency of 190MHz and a bandwidth of 3.84MHz. Between the input match (C323, C324 & L322), output match (L327, L328, C328, C329, & C325) and the filter (FL320)- the expected nominal losses is ~10dB.

A920: WCDMA RX Front End



4-18 A920: WCDMA RX Demodulator (MAX2309)



Description



The MAX2309 is an IF quadrature demodulator with the signal paths consisting of a variable-gain amplifier (VGA) and an I/Q demodulator. The IF LO synthesizer's reference and RF dividers are fully programmable through the 3-wire serial bus (ASPI_CLK, aSPI_DATA, MAX2309_CS). The 190MHz IF is demodulated to BaseBand differential in phase (I+ / I-) and quadrature (Q+ / Q-) signals to be passed through to the receiver's backend IC, HARMONY LITE. The IC operates from a pair of supply voltages RX_VCCD & RX_VCCA derived from VRF_RX_2_775V.

The MAX2309 VCO output frequency is controlled by an internal phase lock loop (PLL) synthesizer. The external loop filter consists of the components connected to pins #1 and #2 (& pin #26). The VCO output frequency (Tank+ / Tank-) at pins #1 and pin #2 are divided down internally, to a desired comparison frequency. The reference signal at pin #7 (REF_15.36MHz) is also divided down to the same comparison frequency. The two divided signals are compared with a three state digital phase detector. The internal phase detector drives the charge pump as well as the lock-detect logic. The charge pump output at pin #26(CP_OUT) is processed by the external loop filter and drives the tunable resonant network, altering the VCO frequency (380MHz) and closing the loop.



The AGC ensures that the I/Q inputs to HARMONY LITE are at constant signal level. The IF_AGC line is controlled by HARMONY_LITE with a DC control range of 1.2V to 2.1V.

The MAX2309 has a shutdown mode to power down the IC, via MAX2309_SHDN*, during the front-end receiver's idling period to conserve battery life. RX_STBY* is used to shut down VGA and demodulator while maintaining the VCO, PLL, and serial interface active.

A920: WCDMA RX MAX2309




A920: Harmony Lite (RX Section)




| Legend | |
|----------|--------|
| Sig Gen: | -20dBm |
| TX: | → |
| VCO: | → |


A920: Harmony Lite (RX Section)



Motorola Confidential Proprietary



4-22 A920: Harmony Lite (Control Section)



Description



There are several functions that the sequence manager is controlling.

1. Sequence manager outputs to external devices
2. On/Off control of clocks, battery save signals etc...
3. Clock frequency selection for correction paths
4. DCOC register selection coarse, medium and fine modes


The HARMONY LITE has two sets of SPI interfaces; one set is for handling the control interface for the transceiver (AUXSPI lines) and ones for interfacing with POG (SPI lines). Further, all SPI interface is generated from POG and written to HARMONY_LITE or parsed through to the MAXIM (U200 & U310) parts.

Layer one timing signals control the functionality of the RF section of the transceiver relative to the air interface. There are three signals defined on each transmit and receive section of the transceiver. TX_PRE_KEY and RX_ON are asserted before the need to receive or transmit in order to launch the necessary sequence of events to warm up the required functional blocks. TX_RAMP and RX_AQUIRE are asserted when actual transmission and reception are to begin. RX_SLOT and TX_SLOT are used during continuous transmission and reception to trigger events that must be aligned with slot boundaries. It's important to reiterate, the TX_RAMP directly corresponds to the PA turning on and RX_AQUIRE corresponds to data being sent to the WCSP.

A920: Harmony Lite (Control Section)



4-24 A920: Harmony Lite (Synthesizer Section)





Description

The clock source for the Harmony Lite (HLite) is a 15.36Mhz oscillator (TCXO). Y130 is used to generated the 15.36MHz clock source. AFC for Y130 is controlled by the Harmony Lite sequence manager via the AFCDAC line. The 15.36MHz clock source is enabled by an internal SPI bit and external control signal coming from 15.36M_CLK_EN*). The 15.36MHz clock source provides clocks to all A/Ds, DACs, external references and internal digital circuits of the Harmony Lite. In addition, clock references are generated for the POG, RX and TX RF circuits.


The WCDMA VCO(U140) has a frequency range of 2.3G thru 2.36GHz, supplying both the receiver and transmitter with an LO. The control range is controlled by HARMONY_LITE with a control range between 0.5 - 2.5V, with an output power @ ~-3 - 3dBm. The WCDMA VCO output frequency is controlled by an internal phase lock loop (PLL) synthesizer. The phase locked loops use a fractional loop divider to permit fast lock times and low phase noise on their output signals. The VCO output frequency is fed into a prescalar and devived down into a desired comparison frequency. The 15.36MHz reference frequency is also divided down into a comparison frequency. The two divided frequencies are then compared with a phase detector. The phase detector will then drive the charge pump. The charge pump output is processed by the external loop filter and drives the tunable resonant network, altering the VCO frequency and closing the loop.

The superfilter block is used to provide a filtered supply voltage to the WCDMA VCO.

A920: Harmony Lite (Synthesizer Section)



4-26 A920: Harmony Lite (TX Section)





Description

The BBIF(BBIF_TX) is the transmit data path for transferring digitally sampled I / Q data from the POG. The demultiplexing unit performs the I/Q deinterleaving function to supply separate I and Q channel data into the transmit FIR filters. The FIR filter design is used to meet 3GPP spec requirements of simultaneous transmission of a pilot channel and of multiple data channels each requiring a different spreading code and each requiring separate power control. The PN sequence generator provides I/Q interleaved 8-bit PN data into the demultiplexing section. The DC correction(DCOC) block is able to correct for DC offsets due to the D/A's, anti-aliasing filters, and transmit FIR filters in a feedback control loop. A mixed mode control loop located at the output of the transmit FIR filter is employed to correct DC offsets and I/Q gain imbalances, i.e. DCOC and I/Q Phase and Gain equalizer. The outputs of the I/Q gain equalization unit is fed into 10-bit I and Q DAC's. The programmable gain anti-aliasing filters, or TX smoothing filters, accepts differential I/Q signals of DC to 1.92MHz frequency components from the D/A Converters to attenuate the unwanted clock signals of 15.36MHz and to smooth the signals for the TX modulator(MAX2363). The output of the TX smoothing filters are then fed into a multiplexed 6-bit A/D with sample/hold scheme. This gives the information of the amplitude and the DC common mode voltage from the I / Q Tx filter outputs by a single Analog-to-Digital Converter (ADC) as the part of digital correction loop.



The differential TX I and TX Q signal are finally fed into the TX modulator(MAX2363).

A920: Harmony Lite (Transmitter Section)




| Legend | |
|----------|--------|
| Sig Gen: | -20dBm |
| TX: | → |
| VCO: | → |

A920: WCDMA VCO



| Legend |
|-----------------|
| Sig Gen: -20dBm |
| VCO: |

4-28 A920: TX Modulator (MAX2363)



Motorola Confidential Proprietary

Description

The in phase (I) and quadrature phase (Q) inputs are received at pins #23 (Q+), #24(Q-), #25(I+), & #26(I-) of U200. The expected DC bias levels are 1.30V - 1.40V with a minimum 300mVpp signal upon the DC level.

The MAX2363 receives the differential I/Q BaseBand input and converts it up to the IF frequency of 380MHz through a quadrature modulator and IF variable gain amplifier (VGA). The IFINH+ (pin #10) and IFINH- (pin #11) input are connected through off-chip FL201 from IFOUT+ (pin #17) and IFOUT- (pin #16), respectively. The function of FL201 is to provide image rejection and out-of-band interferers filtering. The frequency conversion process performed by the mixer / oscillator combination sometimes will allow a frequency other than desired frequency to be fed into the IF and subsequently amplified. The SAW filter (FL201) has a nominal center frequency of 380MHz and an insertion loss of ~ 3.5dB with a total bandwidth of 5MHz.



The IF and RF VGA (VGC1) are common and allow for varying the IF / RF output level . HARMONY_LITE controls the VGC signal with a range of ~1.3 - 2.6V and provides gain a control range of ~75dB.

The MAX2363 VCO output frequency is controlled by an internal phase lock loop (PLL) synthesizer. The external loop filter consists of the components connected to pins #33 and #32 (& pin #38). The VCO output frequency (TankH+ / TankH-) at pin #33and pin #32 are divided down internally, to a desired comparison frequency. The reference signal at pin #36 (REF_FREQ) is also divided down to the same comparison frequency. The two divided signals are then compared with a three state digital phase detector. The internal phase detector drives the charge pump as well as the lock-detect logic(2361_LOCK). The charge pump output (IFCP, pin # 38) is processed by the external loop filter and drives the tunable resonant network, altering the VCO frequency (760MHz) and closing the loop.


The differential IF output at pins #17 & #16 (IFOUTH+ / IFOUTH-) support high IF operation of frequency of 380MHz. The signal is routed to an off-chip IF SAW filter (FL201) and up-mixed to RF through an image reject mixer and RF VGA. The signal is further amplified with an on-chip PA driver. The RF signal is then routed to an interstage RF SAW filter (FL150).

The IF synthesizer (760 MHz VCO) and local oscillator (RF_LO) buffer are both programmable through the 3-wire bus. The sequence manager from HARMONY_LITE programs standby mode(TX_STBY*) and shutdown mode(2361_SHDN). This IC operates from a pair of supply voltages VCC_DIG (isolated supply for IF_CP and 760 VCO) & VCC_ANA derived from VRF_TX_2_775V.

A920: WCDMA TX Modulator



4-30 A920: WCDMA PA



Description



The U410 provides necessary attenuation of the TX carrier before reaching the PA so that it doesn't exceed the maximum allowable input of 1dBm of the PA and to control the overall power output of the transceiver. U410 has a 16-18 dB of attenuation depending on the control voltage VGC2 applied at HYBOUT1 and HYBOUT2, which is controlled by Harmony Lite.

U420 is a three-stage power amplifier handling the band of WCDMA Tx frequencies between 1920 - 1980MHz. The nominal expected maximum gain is ~30dB. HARMONY_LITE controls the RF biasing of the amplifier at pins #4 (PA_BIAS1) and #5 (PA_BIAS2) with a control range of 0 - 2.5v. HARMONY_LITE also controls pin #12 (VLD) for PA load switching. Although not implemented, the theory of PA load switching in WCDMA is vitally important to conserve battery life and to avoid unnecessary radio interference with base stations. When VLD is at a low state (0v), the transmitter is in high power mode, consuming higher current but with overall better PA performance. When VLD is at a high state, the transmitter is in low power mode, consuming less current with overall poor PA performance. In theory, as the Tx power level increases or decreases beyond a certain power threshold, VLD is enabled or disabled. As Tx power decreases (as requested from a base station) down to ~14.5dBm, VLD will switch high. If Tx power is requested to increase beyond ~19dBm, VLD is switched low.

The power detector receives the amplified WCDMA RF signal at **RF_IN** (pin #6) from the PA. U450 is a combination directional coupler and temperature compensated power detector with a differential output. The power detector couples the TX power input and feedbacks an output **RF_DETECT** to HARMONY LITE. The **TEMP_COMP** also obtains the coupled power but removes the RF signal content, leaving a DC level. The DC level is feedback to HARMONY LITE. Expected nominal loss is < 3dB.

The isolator (FL460) provides isolation between Front-End Module (FEM) and transmitter path. Nominal insertion loss is ~ 0. 55dB.


A920: WCDMA Transmitter



Legend

| | |
|----------|--------|
| Sig Gen: | -20dBm |
| TX: | → |

4-32 A920: Charger



Description

The majority of the charging circuit is integrated in PCAP. This includes a digital to analog converter, analog to digital converter, battery feedback switch, thermistor switch/pullup, and current control sense. External FETs (Q3966 and Q3954) are provided to enable/disable EXT_B+ and BATTERY supply paths to radio circuitry (B+). An external sense resistor (R3961) and a charging FET (Q3960) are provided to control charging current between EXT_B+ and BATTERY.

Due to pin count constraints on the CE bus, the Charger Identification input signal and Battery Feedback output signal share the same accessory connector pin. Software will first detect the Charger ID Voltage (AD6) before enabling the Battery Feedback Voltage via the Battery Feedback Switch in PCAP. The Battery Feedback switch must not be enabled at any time for an accessory that is not a valid Fast Charger.


Battery Feedback Voltage provides a reference voltage to the external power supply during charging. The battery feedback switch is needed to remove the battery feedback voltage from the feedback loop of the AC/DC Adapter or VPA when charging is complete or after a fault has occurred. This switch will be enabled before the charger DAC is programmed when charging is to begin. Battery feedback will turn on before the charger is enabled. The charger will be turned off before battery feedback is disabled.

A thermistor in the battery package is used to determine cell temperature of the battery pack before charging begins. The battery EPROM (BATT_IO) will contain limit parameters that determine the minimum and maximum temperatures at which charging can occur.

PCAP has an integrated over-voltage detection circuit that provides protection against damage caused by external charger voltages exceeding 7.0Vdc. If an over-voltage condition occurs, the EXT_B+ FET (Q3963) will be disabled. This will prevent high voltage (>7Vdc) from being applied to radio circuitry (B+).

Mid-rate charging is supported if a valid mid-rate charger and valid battery are detected. A mid-rate charger will source up to 400mA of current to the radio circuitry and charging circuitry during idle mode. The mid-rate charger will supply 5.9Vdc (up to 400mA) to the phone, regardless of the BATT_FDBK voltage. If the phone is in transmit mode, mid-rate current will be supplied to the battery and radio circuitry via the charging path only (EXT_B+ FET (Q3966) will be disabled via the MIDRATE_1 line). Dead battery TX operation or 'No Battery' operation is not supported with a mid-rate charger.

4-34 A920: Voltage Regulators




Description

Voltage regulation is provided by the PCAP IC (U3000). Multiple regulators are used to provide better isolation between sensitive load circuitry and noisy circuitry. The regulators and their load circuitry are described below:

- VBOOST_LX(VBOOST_5_5V) - VUSB abd V10 input voltage regulator
- VBUCK_LX(VBUCK_2_25V) - V1, V3, V4, V7, and V8 input voltage regulator
- LX2(VBUCK2_1_6V) - Helen core
- V_VIB - Vibrator
- Vsim2(VSIMC) - SIM card interface
- Vaux1(VRF_TX_2_775V) - RF TX circuits
- Vaux2(VRF_RX_2_775V) - RF RX circuits
- Vaux3(VMMC_2_8V) - SD/MMC interface
- Vaux4(VAUX4_3V) - Image processor, USB xcvs (Application processor and Bluetooth USB)
- VUSB - PCAP USB xcvr
- V1(VMEM_1_875V) - Application Processor Flash I/O, Application Procesor DRAM I/O, Baseband Processor Flash Core
- V2(VA_2_775V) - Audio
- V3(VLVIO_1_95V) - Magic LV I/O, WCSP
- V4(VRF_REF_1_875V) - RF reference
- V5(VGPS_RF_2_775V) - GPS RF
- V6(VHVIO_2_775V) - HV I/O, Display(20), Imager(12), GPS Baseband(8), GPS Flash, Application Processor SDRAM core(200)
- V7(VRF_DIG_1_875V) - RF digital
- V8(VBLUETH_1_875V) - Bluetooth
- V9(VRF_REF_2_475V) - RF Reference
- V10(VRF_HV_5V) - RF HV

A920: RX Audio



Description

Receive audio data is transferred from the POG to the PCAP through the ASAP interface for mono audio and the VSAP interface for stereo audio data. The data is then converted into an analog form through a 16-bit Stereo DAC or 13-bit phone DAC. The output of PCAP's internal DAC drives the internal PGA. The output of the PGA can be routed to one of the four supported outputs via the internal multiplexer. All outputs use the same D/A converter so only one output can be active at one time. The user can adjust the gain of the audio outputs with the volume control buttons.

The Handset Speaker is driven by PCAP's internal SPKR differential amplifier. Following the speaker path from the PCAP pins SPKR- and SPKR+, they are routed through R4004 and R4005 respectively, and then connected to the transducer. Off the SPKR- path, SPKR_IN is routed through C4002 for the inverting input of the speaker amp A1. SPKR_OUT1 from PCAP is routed through C4000 and C4002 to SPKR- which is the DAC output of the CODEC. SPKR_IN and SPKR_OUT1 will output their respective bias voltages on these pins during standby times. This is to maintain the voltage across an external coupling capacitor to avoid audio "pops" when the amplifier is enabled.



The headset uses a standard 2.5mm stereo phone jack. The phone will detect the presence of a stereo headset using HS_SPKR_L of the headset jack, which is pulled high by R4395 and connected to the ST_COMP of PCAP (this is an interrupt of PCAP which gets sent to MCU over the SPI bus). This pin will be pulled to a logic low whenever the stereo headset plug is inserted into the jack. The headset may contain a momentary switch, which is normally closed and is in series with the microphone cartridge. When the momentary switch is pressed, the bias current being supplied to the microphone will be interrupted. The phone will detect this action and make an appropriate response to this action, which could be to answer a call, end a call, or dial the last number from scratchpad.


The Headset Speaker is driven by PCAP's internal Left and Right amplifier. Following the speaker path from the PCAP pins ARIGHT_Out and ALeft_Out, they are routed through C4356, R4352 and C4306, R4302 respectively, and then connected to the headset jack. Off the ARIGHT_Out path, AR_IN is tapped off through C4354 for the inverting input of the audio amp ARIGHT. Off the ALeft_Out path, AL_IN is tapped off through C4304 for the inverting input of the audio amp ALEFT.

The External Speaker is connected to pin 15 of J5000 (AUDIO_OUT), the accessory connector for the mobile phone. The audio path is routed through R4400 and C4400 and connected to EXTOOUT of PCAP. The DC level of this Audio_Out signal is also used to externally command the phone to toggle its ON/OFF state. The Audio_Out signal connects to PCAP's ON2 pin via R5053 to provide this capability. When a DC level of <0.4V is applied by an accessory for a minimum of 700 milliseconds on the Audio_Out line, the phone will toggle its ON/ OFF state.

The Loadspeaker is driven by PCAP's ALRT amplifier (A2). The alert path from the PCAP pins ALRT- and ALRT+ are routed directly to the alert transducer. Off the ALRT- path, ALRT_IN is routed through R4201 for the inverting input of the alert amp A2. SPKROUT2 from PCAP is routed through C4200 and R4200 to ALRT- which is the DAC output of the CODEC.

A920: RX Audio





Description



The Internal Microphone is a single ended part. Following the Internal microphone path, the microphone is biased by R4103 to provide a **MIC_BIAS** of 2.0V from pin **MIC_BIAS1** of PCAP. C4198 is connected to **MIC_BIAS1** and **MB_CAP1** pin on PCAP to bypass the gain from the VAG to **MIC_BIAS1** which keeps the noise balanced. From there, the signal is routed through C4100 to **AUX_OUT** pin on PCAP, bypassing the input to the **A5** amplifier.

The headset microphone path (**HS_MIC**) is biased through R4396 and R4392, which is connected to pin **MIC_BIAS2** on PCAP and bypassed with C4199 connected to pin **MB_CAP2**. From here the signal is routed through C4395 and R4388 to **MIC_IN-** pin on PCAP, which is the input to the **A3** Amplifier. The Microphone path is tapped off after R4388 before the **MIC_IN-** input to R4389 connected to the **MIC_OUT** pin on PCAP, which is the output of the **A3** Amplifier. The **HS_MAKE_DET** line monitors the presence of a headset by detecting the voltage at **A1_INT** of PCAP, which passes through R4398. A switching mechanism integrated in the headset jack will open or close the **HS_MAKE_DET** path to ground, depending on whether the headset is attached or not.

The External Microphone input (**AUDIO_IN**) is connected to the accessory connector for the mobile phone. The path is routed through L4400, C4401 and R4401 to the **EXT_MIC** pin on PCAP. This signal feeds directly to the input multiplexer without an intervening gain stage. In addition to audio signals, **AUDIO_IN** supports detection of accessory devices. The accessory attached to the CE bus shall have an output impedance that will load **LOGIC_SENSE** to a predetermined level. The **POG** will read the input level of **LOGIC_SENSE** and configure the audio accordingly.


The proper Microphone path is selected by the **AUD MUX** controller and path gain is programmable at the **PGA**. The **A/D converter** will convert incoming analog signals into 13-bit, 2's compliment, linear PCM words. The digital audio signals are then transferred to the **POG** DSP through a four wire serial interface (**ASAP**).

A920: Transmit Audio



| Legend | |
|----------|--------|
| Sig Gen: | -20dBm |
| TX: | → |

4 A920: PCAP




Description

The Platform Control Audio Power IC (PCAP), U3000, is a mixed signal IC that contains the following features:

- Audio input/output amplification and filtering
- Audio path selection
- Voltage regulation
- Battery charging control
- Real time clock
- Ringer/vibrator control
- RS-232/USB drivers
- Back-light control
- Status LED control
- Multiplexed DAC inputs for temperature and voltage monitoring
- Dual SPI control interface to allow access from two independent baseband processors
- Stereo DAC
- Overvoltage protection
- Touch Screen

The PCAP IC is controlled and configured by the Baseband Processor IC through a four-wire SPI interface. The Baseband Processor has read/write access to the PCAP IC. Audio data is transmitted/received via the Baseband Processor through a four-wire SSI interface.

4-42 A920: POG





Description

The POG(baseband processor) integrates a 32-bit RISC Communications Engine (MCU), a 32-bit DSP Core and an Interprocessor Communications Module (IPCM) along with associated peripherals and co-processors. The following provides a brief description of the cores and associated peripherals being used in this design.

- MCU – Micro Controller
- DSP for GSM Signal processing
- EIM(external interface module) interfaces to FLASH and DRAM
- USB/Serial Communications
- GPIO - For A/Ds
- IPCM which provides a multichannel DMA between the Mcore, DSP and peripherals.
- WCSP Interface
- GQSPI - PCAP Interface
- EBIF(External Bus Interface) DMA – WCDMA Data Transportation
- MQSPI1(Qued Serial Peripheral Interface) – WCDMA Control Signals
- EL1T1(Enhance Layer Timer) – WCDMA Event timer
- CKIH - WCDMA 15.36MHz clock
- GPS Interface
- USIM interface
- ASAP interface for PCAP and Bluetooth audio interface
- Serial BBIF(Baseband Interface) – GSM Data Transportation
- MQSPI2(Qued Serial Peripheral Interface) – GSM Control Signals
- EL1T2(Enhance Layer Timer) – GSM Event timer
- CKIH - GSM 13MHz clock


In addition to POG's internal memory system, the architecture provides 128Mbits (16M byte) of external flash memory via two Intel Danali 64M bit parts. The memory bus is 23 address bits and 32 data bits. The flash memory runs at 42-45MHz.

A920: POG




A920: POG

Motorola Confidential Proprietary




A920: POG Memory



4-6 A920: Bluetooth IC

Motorola Confidential Proprietary



Description

The BCM2033 has an integrated radio transceiver that has been optimized for use in 2.4 GHz Bluetooth wireless systems. It has been designed to provide low-power, low-cost, robust communications for applications operating in the globally available 2.4 GHz unlicensed ISM band. It is fully compliant with the Bluetooth RF Specification v1.1 and meets or exceeds the requirements to provide the highest communication link quality of service.

The receiver has a high degree of linearity, an extended dynamic range, and high order on-chip channel filtering to ensure reliable operation in the noisy 2.4 GHz ISM band. The BCM2033 also features a fully integrated transmitter. Baseband data is GFSK modulated and upconverted to the 2.4 GHz ISM band via an internal mixer. The output Power Amplifier (PA) provides a nominal power output of 0 dBm and has a power control to provide 24 dB of gain control in 8 dB step sizes. Local Oscillator (LO) generation provides fast frequency hopping (1600 hops/second) across the 79 maximum available channels.



The uPU runs software from the Link Control (LC) layer, up to the Host Controller Interface (HCI). The microprocessor is an enhanced performance 8051 micro-controller.

The BBC manages the buffering, segmentation, and routing of data for all connections. It also buffers data that passes through it, handles data flow control, schedules SCO/ACL TX/RX transactions, monitors Bluetooth slot usage, optimally segments and packages data into baseband packets, manages connection status indicators, and composes and decodes HCI packets.

The Peripheral Transport Unit (PTU) handles the Device Interface. The PTU supports three types of devices: USB, UART, and PCM.

The PMU provides power management features that can be invoked by either software through power management registers, or “packet handling” in the baseband core.


A920: Bluetooth



Motorola Confidential Proprietary

| Legend | |
|-----------|--------|
| Sig Gen: | -20dBm |
| TX: | → |
| RX: | ← |
| Ref Freq: | ↔ |

4-48 A920: GPS



Description

The 1575.42 MHz satellite signal can be received through the GPS antenna PIFA_Planar Inverted F Antenna) or external GPS antenna. GPS signal received through the PIFA will pass through FL6055 and LNA U6051. The signal is then passed to the LNA input of U6050 through FL6050.



The input signal at the LNA of U6050 is a Direct Sequence Spread Spectrum (DSSS) signal at 1575.42MHz with a 1.023 Mbps Bi-Phase Shift Keying (BPSK) modulated spreading code. The DSSS signal is then injected into an image reject mixer. The Mixer and on-chip 1565.97 MHz VCO will produce an IF center frequency of 9.45MHz. An IF filter is required between the Mixer and AGC Amplifier to provide an anti-aliasing function before A/D conversion. The IF filter block also contains an I-Q phase shift combiner. This circuit properly phase shifts and sums the I and Q outputs from the image reject mixer to a single channel. The AGC amplifier provides the additional gain needed to optimally load the signal range of the 2-bit A/D Converter. The 2-bit A/D converter will then provide signal and magnitude output bits to the Interface Block. The outputs of the Interface Block provide clocks and the 2-bit sample data to the CGSP2e/LP(U6000). These signals use single-ended PECL(Positive Emitter-Coupled Logic) signaling to simplify the complexity of this interface. The interface block inputs are the single-wire AGC interface, (AGCDAT) and the Power Control pin (PWRCTL).

The GPS DSP within U6000 correlates the incoming MAG and SIGN data. Wide parallel search architecture enables simultaneous search of 1,920 time/frequency bins which enables a powerful combination of very fast reacquisition along with the capability to find and track very weak signals. The UART residing in U6000 is used to interface data information between the GSP2e/LP(U6000) and POG. An integrated GPIO unit provides support for a variety of peripherals.

RTC is an ultra-low power implementation of a high precision 32-kHz driven clock derived from the PCAP. It is separately powered by the VDDRTC to allow maximum battery life by maintaining time for the next power on. REF_FREQ is used as an external clock source for U6000.


GPS_WAKEUP* is an active low signal from POG to wake up SiRFLoc client from the deep sleep mode. GPS_RESET* is an active low hard reset signal for the SiRF BB IC and Flash. GPS_BOOT_SEL is used by POG to set boot configuration upon reset. GPS_TIME_SYNC is an active high signal to provide time stamping of the precise time aiding that is sent over from POG over the UART.

A920: GPS RF Circuit




| Legend | |
|----------|--------|
| Sig Gen: | -20dBm |
| RX: | → |
| Ref Clk: | ↔ |

A920: GPS Baseband Circuit



4-50 A920: Camera



Description

The Conexant imager allows 15 fps(frames per second) image readouts at VGA resolution. The Conexant imager will output raw Bayer RGB 8-bit/pixel data to the Conexant backend processor (U7600).

The Conexant backend processor will receive the Bayer RGB data from the imager and process the image data into 8-bit YUV uncompressed or compressed data that is send through the VODATA bus to the Helen application processor. U7600 can process the YUV data in VGA(640x480), QVGA(320x240), CIF(352x288), and QCIF(176x144) output resolutions. Control functions for U7600 are done through a 2-wire serial interface(SSCLK and SSDA).


The QCIF qualifier logic devices(U7602 and U7603) are used for viewfinder and video capture functions. VSYNC and HSYNC signals provide vertical and horizontal synchronization of the image signals. VSYNC indicates a start and end of a valid video frame while HSYNC indicated the start and end of a valid video line.

VODATA sends 8-bit processed image data in YUV 4:2:2 format to the Helen processor. VODATA3 is shared by the camera and IrDA devices. Due to the hardware restrictions, Camera and IrDA wouldn't work simultaneously. For this reason, IRDA_SHUTDOWN is used to enable VODATA3 during camera operation.


CAM_ROT_DETECT is used to indicate the rotated position of the imager. A magnet integrated in the Conexant imager will activate the Hall effect switch and cause a state change for CAM_ROT_DETECT. The Helen will respond with a horizontal inversion of the image.

The image that Helen receives goes through a DSP pre-processing stage where the YUV 4:2:2 is converted to YUV 4:2:0. To display the image on the unit's display, the YUV 4:2:0 signal passes through a DSP post-processing stage and converts it to RGB. The RGB signal is then passed through a video buffer and to the display. For still image storage cases, the YUV 4:2:0 image passes through JPEG encoding and then transferred to a user selectable storage device(Flash, SD, MMC). For video cases, the YUV 4:2:0 image is passed through MPEG4 or H.263 encoding. The video is then transferred to a user selectable storage device or sent as real time data transmission.

A920: Video Circuit



4-52 A920: Helen



Description


The Helen(adjunct processor) is a dual core processor architecture which incorporates a high-performane TI925T MPU core and a TI TMS320C55x DSP core. The following provides a brief description of the cores and associated peripherals being used in this design.

- Flash I/F, SDRAM I/F - Interfaces to FLASH and SDRAM
- Keypad Interface
- LCD I/F - Display Interface
- UART3 - IrDA interface
- MMC interface
- GPIO - For A/Ds
- Secondary SPI - PCAP interface
- Bluetooth Interface
- Camera IF - Backend Pixel Processor interface


- I2C - Inter-Integrated Circuit Master and Slave interface
- IPCL - Inter-Processor Communications Link for Helen to POG interface
- ULPD - Ultralow-Power Device
- 1 wire Communication for Battery EPROM
- USB(client) - Helen USB is used as a client, signals are routed through PCAP's USB transceiver
- UART1 - RS232 interface to CE bus
- McBSP1 - Multichannel Buffered Serial Port (VSAP) for the PCAP stereo audio interface
- McBSP2 - Multichannel Buffered Serial Port (ASAP) for the PCAP and Bluetooth audio interface

A920: Helen



Motorola Confidential Proprietary





A920: Helen



A920: Helen Flash Memory



A920: Helen SDRAM



Parts List

Introduction

Motorola maintains a parts office staffed to process parts orders, identify part numbers, and otherwise assist in the maintenance and repair of Motorola Cellular products.

Orders for all parts listed in this document should be directed to the following Motorola International Logistics Department:

To order parts please use the following link:

https://wissc.motorola.com/wissc_root/main/BrowserOK.html
(Password is Required)

For information on ordering parts please contact EMEA at +49 461 803 1638.

When ordering replacement parts or equipment information, the complete identification number should be included. This applies to all components, kits, and chassis.

If the component part number is not known, the order should include the number of the chassis or kit of which it is a part, and sufficient description of the desired component to identify it.

Electrical Parts List

Electrical Parts List

The following table lists the electrical parts list for the A920/A925 UMTS/GSM handset.

Table 10. Electrical Parts List

| Reference Number | Part Number | Description |
|------------------|-------------|-------------|
| A1 | 3987724N02 | CONTACT |
| A6050DNP | 3988220M01 | CONTACT |
| C001 | 2113743N03 | CAP, 1pF |
| C002 | 0662057C01 | RES, 0 |
| C003 | 2113743N36 | CAP, 27pF |
| C004 | 2113743N36 | CAP, 27pF |
| C005 | 2113743N42 | CAP, 47pF |
| C006 | 2113743N50 | CAP, 100pF |
| C007 | 2113743N50 | CAP, 100pF |
| C008 | 2113743N50 | CAP, 100pF |
| C010 | 2113743N36 | CAP, 27pF |
| C011 | 2113743N03 | CAP, 1pF |
| C030 | 2113743N16 | CAP, 3.9pF |
| C101 | 2113928P04 | CAP, 1.0uF |
| C102 | 2113928P04 | CAP, 1.0uF |
| C103 | 2113928P04 | CAP, 1.0uF |
| C104 | 2113947C01 | CAP, 1000pF |
| C106 | 2113928N01 | CAP, 0.1uF |
| C107 | 2113947H01 | CAP, 0.1uF |
| C112 | 2113928P04 | CAP, 1.0uF |
| C113 | 2113928P04 | CAP, 1.0uF |
| C114 | 2113928P04 | CAP, 1.0uF |
| C115 | 2113743L17 | CAP, 1000pF |
| C116 | 2113928N01 | CAP, 0.1uF |
| C117 | 2113743M24 | CAP, 0.1uF |
| C118 | 2113928C04 | CAP, 4.7uF |
| C119 | 2113743M24 | CAP, 0.1uF |
| C120 | 2113928N01 | CAP, 0.1uF |
| C121 | 2113928N01 | CAP, 0.1uF |
| C122 | 2113743M24 | CAP, 0.1uF |
| C123 | 2113743M24 | CAP, 0.1uF |
| C130 | 2113928N01 | CAP, 0.1uF |
| C131 | 2113743L41 | CAP, .01uF |
| C132 | 2113743L41 | CAP, .01uF |
| C133 | 2113743L41 | CAP, .01uF |
| C134 | 2113743L41 | CAP, .01uF |
| C140 | 2113743E07 | CAP, .022uF |
| C141 | 2113743L25 | CAP, 2200pF |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|-------------|
| C142 | 2113743N46 | CAP, 68pF |
| C145 | 2113743N01 | CAP, 0.5pF |
| C146 | 2113928C04 | CAP, 4.7uF |
| C148 | 2113743N22 | CAP, 6.8pF |
| C150 | 2113743N28 | CAP, 12pF |
| C151 | 2113743N28 | CAP, 12pF |
| C156 | 2113743N16 | CAP, 3.9pF |
| C157 | 2113743N16 | CAP, 3.9pF |
| C200 | 2113743N38 | CAP, 33pF |
| C201 | 2113743N50 | CAP, 100pF |
| C205 | 2113743L17 | CAP, 1000pF |
| C202DNP | 2113743N03 | CAP, 1pF |
| C203DNP | 2113743N50 | CAP, 100pF |
| C215 | 2113743E07 | CAP, .022uF |
| C216 | 2113741F37 | CAP, 3300pF |
| C221 | 2113743N30 | CAP, 15pF |
| C222 | 2113743N30 | CAP, 15pF |
| C223 | 2104801Z08 | CAP, 1.2pF |
| C241 | 2113743L17 | CAP, 1000pF |
| C242 | 2113743L17 | CAP, 1000pF |
| C243 | 2113743L17 | CAP, 1000pF |
| C244 | 2113743L05 | CAP, 330pF |
| C245 | 2113743L05 | CAP, 330pF |
| C250DNP | 2113947B01 | CAP, 10pF |
| C252DNP | 2113947B01 | CAP, 10pF |
| C260 | 2113743N28 | CAP, 12pF |
| C261 | 2113743N16 | CAP, 3.9pF |
| C270 | 2113743N50 | CAP, 100pF |
| C280 | 2113743N50 | CAP, 100pF |
| C282 | 2113743N09 | CAP, 2pF |
| C290 | 2113743L17 | CAP, 1000pF |
| C291 | 2113947C01 | CAP, 1000pF |
| C292 | 2113743L17 | CAP, 1000pF |
| C293 | 2113743L17 | CAP, 1000pF |
| C294 | 2113743L17 | CAP, 1000pF |
| C295 | 2113743L17 | CAP, 1000pF |
| C296 | 2113743L17 | CAP, 1000pF |
| C297 | 2113743L41 | CAP, .01uF |
| C298 | 2113743N50 | CAP, 100pF |
| C299 | 2113743L41 | CAP, .01uF |
| C302 | 2113743N02 | CAP, 0.75pF |
| C303 | 2113743N26 | CAP, 10pF |
| C304 | 2113743N01 | CAP, 0.5pF |
| C305 | 2113743N50 | CAP, 100pF |

Electrical Parts List

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|--------------|
| C307 | 2113743N50 | CAP, 100pF |
| C310 | 2113743N26 | CAP, 10pF |
| C313 | 2409154M60 | IDCTR, 5.6nH |
| C314 | 2113743Q07 | CAP, 1.5pF |
| C315 | 2113743L41 | CAP, .01uF |
| C316 | 2113743N26 | CAP, 10pF |
| C317 | 2113743L41 | CAP, .01uF |
| C319 | 2113743L41 | CAP, .01uF |
| C321 | 2113743L41 | CAP, .01uF |
| C323 | 2113743N34 | CAP, 22pF |
| C324 | 2113743N34 | CAP, 22pF |
| C325 | 2113743L17 | CAP, 1000pF |
| C326 | 2113743L17 | CAP, 1000pF |
| C327 | 2113743N23 | CAP, 7.5pF |
| C330 | 2113743L29 | CAP, 3300pF |
| C331 | 2113743E07 | CAP, .022uF |
| C332 | 2113743N28 | CAP, 12pF |
| C333 | 2113743N28 | CAP, 12pF |
| C334 | 2113743N18 | CAP, 4.7pF |
| C335 | 2113743N16 | CAP, 3.9pF |
| C338 | 2113743N28 | CAP, 12pF |
| C340 | 2113947C01 | CAP, 1000pF |
| C342 | 2113743N50 | CAP, 100pF |
| C344 | 2113743L05 | CAP, 330pF |
| C348 | 2113743L41 | CAP, .01uF |
| C349 | 2113743L41 | CAP, .01uF |
| C360 | 2113743L41 | CAP, .01uF |
| C361 | 2113743L41 | CAP, .01uF |
| C410 | 2113743L01 | CAP, 220pF |
| C413 | 2113743N38 | CAP, 33pF |
| C414 | 2113743N38 | CAP, 33pF |
| C420 | 2113743N30 | CAP, 15pF |
| C421 | 2113743L41 | CAP, .01uF |
| C422 | 2113928C04 | CAP, 4.7uF |
| C425 | 2113743N28 | CAP, 12pF |
| C444 | 2113743L41 | CAP, .01uF |
| C445 | 2113743N50 | CAP, 100pF |
| C448 | 2113743N26 | CAP, 10pF |
| C449 | 2113743L41 | CAP, .01uF |
| C451 | 2113743N28 | CAP, 12pF |
| C452 | 2113947B05 | CAP, 33pF |
| C453 | 2113743L17 | CAP, 1000pF |
| C460 | 2113743N26 | CAP, 10pF |
| C502 | 2113743L37 | CAP, 6800pF |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|-------------|
| C503 | 2113740F59 | CAP, 220pF |
| C504 | 2113743L13 | CAP, 680pF |
| C505 | 2113741F45 | CAP, 6800pF |
| C506 | 2113743L41 | CAP, .01uF |
| C507 | 2113743N50 | CAP, 100pF |
| C509 | 2113743N50 | CAP, 100pF |
| C510 | 2113743M24 | CAP, 0.1uF |
| C511 | 2113928C03 | CAP, 1.0uF |
| C514 | 2113743L41 | CAP, .01uF |
| C516 | 2113928C03 | CAP, 1.0uF |
| C517 | 2113743L17 | CAP, 1000pF |
| C520 | 2113928C04 | CAP, 4.7uF |
| C521 | 2113928C04 | CAP, 4.7uF |
| C522 | 2113928C04 | CAP, 4.7uF |
| C523 | 2113928C04 | CAP, 4.7uF |
| C524 | 2113743N34 | CAP, 22pF |
| C525 | 2113743N28 | CAP, 12pF |
| C526 | 2113743N32 | CAP, 18pF |
| C527 | 2113743N32 | CAP, 18pF |
| C528 | 2113743N38 | CAP, 33pF |
| C535 | 2113928N01 | CAP, 0.1uF |
| C536 | 2113743L41 | CAP, .01uF |
| C537 | 2113928C04 | CAP, 4.7uF |
| C538 | 2113928A01 | CAP, 1.0uF |
| C539 | 2113743L41 | CAP, .01uF |
| C540 | 2113947E01 | CAP, .01uF |
| C542 | 2113947E01 | CAP, .01uF |
| C543 | 2113928P04 | CAP, 1.0uF |
| C544 | 2113928P04 | CAP, 1.0uF |
| C545 | 2113928P04 | CAP, 1.0uF |
| C546 | 2113947E01 | CAP, .01uF |
| C554 | 2113743L01 | CAP, 220pF |
| C555 | 2113743L01 | CAP, 220pF |
| C556 | 2113743L05 | CAP, 330pF |
| C560 | 2113743M24 | CAP, 0.1uF |
| C576 | 2113743L05 | CAP, 330pF |
| C600 | 2113743N34 | CAP, 22pF |
| C602 | 2113928A01 | CAP, 1.0uF |
| C603 | 2113743N12 | CAP, 2.7pF |
| C604 | 2113743L05 | CAP, 330pF |
| C605 | 2113743L05 | CAP, 330pF |
| C606 | 2113743N54 | CAP, 150pF |
| C607 | 2113743L05 | CAP, 330pF |
| C608 | 2113743L05 | CAP, 330pF |

Electrical Parts List

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|-------------|
| C609 | 2113743N54 | CAP, 150pF |
| C610 | 2113743N36 | CAP, 27pF |
| C631 | 2113928A01 | CAP, 1.0uF |
| C632 | 2113743L41 | CAP, .01uF |
| C650 | 2113743N38 | CAP, 33pF |
| C651 | 2113743N38 | CAP, 33pF |
| C660 | 2113743N28 | CAP, 12pF |
| C661 | 2113743N28 | CAP, 12pF |
| C670 | 2113743N28 | CAP, 12pF |
| C671 | 2113743N28 | CAP, 12pF |
| C700 | 2113928N01 | CAP, 0.1uF |
| C701 | 2113743L03 | CAP, 270pF |
| C702 | 2113743L17 | CAP, 1000pF |
| C703 | 0888600M19 | CAP, 3300pF |
| C704 | 2113743N12 | CAP, 2.7pF |
| C705 | 2113743N28 | CAP, 12pF |
| C708 | 2113743N20 | CAP, 5.6pF |
| C710 | 2113743N28 | CAP, 12pF |
| C711 | 2113743N50 | CAP, 100pF |
| C712 | 2113743N28 | CAP, 12pF |
| C800 | 2113928C04 | CAP, 4.7uF |
| C801 | 2113743E20 | CAP, 0.1uF |
| C802 | 2113743E20 | CAP, 0.1uF |
| C803 | 2113743N26 | CAP, 10pF |
| C804 | 2113743E20 | CAP, 0.1uF |
| C805 | 2113928N01 | CAP, 0.1uF |
| C806 | 2113743E20 | CAP, 0.1uF |
| C808 | 2113743L01 | CAP, 220pF |
| C810 | 2113743N38 | CAP, 33pF |
| C812 | 2113743P01 | CAP, 180pF |
| C830 | 0662057M01 | RES, 0 |
| C832 | 2113743N28 | CAP, 12pF |
| C902 | 2113743N36 | CAP, 27pF |
| C903 | 2113743N28 | CAP, 12pF |
| C908 | 2113743N38 | CAP, 33pF |
| C909 | 2113743N38 | CAP, 33pF |
| C910 | 2113743L41 | CAP, .01uF |
| C1000 | 2113743M24 | CAP, 0.1uF |
| C1001 | 2113743M24 | CAP, 0.1uF |
| C1002 | 2113743M24 | CAP, 0.1uF |
| C1003 | 2113743M24 | CAP, 0.1uF |
| C1004 | 2113743M24 | CAP, 0.1uF |
| C1005 | 2113743M24 | CAP, 0.1uF |
| C1006 | 2113743M24 | CAP, 0.1uF |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|-------------|
| C1007 | 2113743M24 | CAP, 0.1uF |
| C1008 | 2113743M24 | CAP, 0.1uF |
| C1009 | 2113743M24 | CAP, 0.1uF |
| C1010 | 2113743M24 | CAP, 0.1uF |
| C1011 | 2113743M24 | CAP, 0.1uF |
| C1012 | 2113743M24 | CAP, 0.1uF |
| C1013 | 2113743M24 | CAP, 0.1uF |
| C1014 | 2113743M24 | CAP, 0.1uF |
| C1015 | 2113743M24 | CAP, 0.1uF |
| C1016 | 2113743M24 | CAP, 0.1uF |
| C1017 | 2113743M24 | CAP, 0.1uF |
| C1018 | 2113743M24 | CAP, 0.1uF |
| C1019 | 2113743M24 | CAP, 0.1uF |
| C1020 | 2113743M24 | CAP, 0.1uF |
| C1021 | 2113743M24 | CAP, 0.1uF |
| C1022 | 2113743M24 | CAP, 0.1uF |
| C1026 | 2113743M24 | CAP, 0.1uF |
| C1027 | 2113743M24 | CAP, 0.1uF |
| C1028 | 2113743M24 | CAP, 0.1uF |
| C1029 | 2113743M24 | CAP, 0.1uF |
| C1030 | 2113743M24 | CAP, 0.1uF |
| C1031 | 2113743M24 | CAP, 0.1uF |
| C1032 | 2113743M24 | CAP, 0.1uF |
| C1033 | 2113743M24 | CAP, 0.1uF |
| C1034 | 2113743M24 | CAP, 0.1uF |
| C1110 | 2113743M24 | CAP, 0.1uF |
| C1112 | 2113743M24 | CAP, 0.1uF |
| C1113 | 2113743L41 | CAP, .01uF |
| C1114 | 2113743M24 | CAP, 0.1uF |
| C1115 | 2113743M24 | CAP, 0.1uF |
| C1140 | 2113743M24 | CAP, 0.1uF |
| C1150 | 2113743M24 | CAP, 0.1uF |
| C1300 | 2113743M24 | CAP, 0.1uF |
| C1301 | 2113743M24 | CAP, 0.1uF |
| C1302 | 2113743M24 | CAP, 0.1uF |
| C1303 | 2113743M24 | CAP, 0.1uF |
| C1304 | 2113743M24 | CAP, 0.1uF |
| C1305 | 2113743M24 | CAP, 0.1uF |
| C1306 | 2113743M24 | CAP, 0.1uF |
| C1307 | 2113743M24 | CAP, 0.1uF |
| C1308 | 2113743M24 | CAP, 0.1uF |
| C1309 | 2113743M24 | CAP, 0.1uF |
| C1400 | 2113743M24 | CAP, 0.1uF |
| C1401 | 2113743M24 | CAP, 0.1uF |

Electrical Parts List

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|-------------|
| C1402 | 2113743M24 | CAP, 0.1uF |
| C1403 | 2113743M24 | CAP, 0.1uF |
| C2001 | 2113743N30 | CAP, 15pF |
| C2002 | 2113743N30 | CAP, 15pF |
| C2003 | 2113928N01 | CAP, 0.1uF |
| C2004 | 2113928N01 | CAP, 0.1uF |
| C2005 | 2113928N01 | CAP, 0.1uF |
| C2006 | 2113928N01 | CAP, 0.1uF |
| C2008 | 2113928N01 | CAP, 0.1uF |
| C2009 | 2113928N01 | CAP, 0.1uF |
| C2010 | 2113928N01 | CAP, 0.1uF |
| C2011 | 2113928N01 | CAP, 0.1uF |
| C2012 | 2113928N01 | CAP, 0.1uF |
| C2013 | 2113928N01 | CAP, 0.1uF |
| C2014 | 2113928N01 | CAP, 0.1uF |
| C2015 | 2113928N01 | CAP, 0.1uF |
| C2016 | 2113928N01 | CAP, 0.1uF |
| C2017 | 2113928N01 | CAP, 0.1uF |
| C2018 | 2113928N01 | CAP, 0.1uF |
| C2019 | 2113928N01 | CAP, 0.1uF |
| C2020 | 2113743M24 | CAP, 0.1uF |
| C2021 | 2113928N01 | CAP, 0.1uF |
| C2022 | 2113928N01 | CAP, 0.1uF |
| C2023 | 2113743N34 | CAP, 22pF |
| C2024 | 2113743N34 | CAP, 22pF |
| C2025 | 2113928N01 | CAP, 0.1uF |
| C2026 | 2113743M24 | CAP, 0.1uF |
| C2027 | 2113928C12 | CAP, 10uF |
| C2028 | 2113928N01 | CAP, 0.1uF |
| C2030 | 2113928N01 | CAP, 0.1uF |
| C2032 | 2113928N01 | CAP, 0.1uF |
| C2033 | 2113928N01 | CAP, 0.1uF |
| C2034 | 2113928N01 | CAP, 0.1uF |
| C2035 | 2113928N01 | CAP, 0.1uF |
| C2070 | 2113743N38 | CAP, 33pF |
| C2090 | 2113928N01 | CAP, 0.1uF |
| C2094 | 2113928N01 | CAP, 0.1uF |
| C2097 | 2113928N01 | CAP, 0.1uF |
| C2098 | 2113928N01 | CAP, 0.1uF |
| C2099 | 2113928C12 | CAP, 10uF |
| C2302 | 2113928N01 | CAP, 0.1uF |
| C2303 | 2113928N01 | CAP, 0.1uF |
| C2306 | 2113928N01 | CAP, 0.1uF |
| C2350 | 2113928N01 | CAP, 0.1uF |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|-------------|
| C2351 | 2113928N01 | CAP, 0.1uF |
| C2356 | 2113928N01 | CAP, 0.1uF |
| C2357 | 2113928N01 | CAP, 0.1uF |
| C2400 | 2113928N01 | CAP, 0.1uF |
| C2401 | 2113947H01 | CAP, 0.1uF |
| C2402 | 2113928N01 | CAP, 0.1uF |
| C3000 | 2113928C12 | CAP, 10uF |
| C3001 | 2113928C12 | CAP, 10uF |
| C3002 | 2113928N01 | CAP, 0.1uF |
| C301DNP | 2113743N02 | CAP, 0.75pF |
| C3050 | 2113928C12 | CAP, 10uF |
| C3051 | 2113928C12 | CAP, 10uF |
| C3052 | 2113928N01 | CAP, 0.1uF |
| C3053 | 2113928N01 | CAP, 0.1uF |
| C3100 | 2113928C12 | CAP, 10uF |
| C3101 | 2113928C12 | CAP, 10uF |
| C3150 | 2113928C04 | CAP, 4.7uF |
| C3151DNP | 2113743N38 | CAP, 33pF |
| C3200 | 2113928C12 | CAP, 10uF |
| C3201 | 2113928C12 | CAP, 10uF |
| C3220 | 2113928C12 | CAP, 10uF |
| C3221 | 2113743L17 | CAP, 1000pF |
| C3222 | 2113743N35 | CAP, 24pF |
| C3224 | 2113928C12 | CAP, 10uF |
| C3225 | 2113928C12 | CAP, 10uF |
| C3226 | 2113928C12 | CAP, 10uF |
| C3228 | 2113743N38 | CAP, 33pF |
| C3229 | 2113743N38 | CAP, 33pF |
| C3227DNP | 2113743N38 | CAP, 33pF |
| C3250 | 2113928C04 | CAP, 4.7uF |
| C3300 | 2113928C04 | CAP, 4.7uF |
| C3350 | 2113928C12 | CAP, 10uF |
| C339DNP | 2113743N50 | CAP, 100pF |
| C3400 | 2113928C12 | CAP, 10uF |
| C3401 | 2113928C12 | CAP, 10uF |
| C3402 | 2113743M24 | CAP, 0.1uF |
| C3450 | 2113928C04 | CAP, 4.7uF |
| C345DNP | 2113743L17 | CAP, 1000pF |
| C3500 | 2113928C12 | CAP, 10uF |
| C3501 | 2113928C12 | CAP, 10uF |
| C3502 | 2113743M24 | CAP, 0.1uF |
| C3550 | 2113928C04 | CAP, 4.7uF |
| C3555 | 2113743N35 | CAP, 24pF |
| C3560 | 2113928C12 | CAP, 10uF |

Electrical Parts List

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|-------------|
| C3561 | 2113928C12 | CAP, 10uF |
| C3562 | 2113743M24 | CAP, 0.1uF |
| C3600 | 2113928C12 | CAP, 10uF |
| C3602 | 2113743N40 | CAP, 39pF |
| C3601DNP | 2113743N40 | CAP, 39pF |
| C3650 | 2113928C04 | CAP, 4.7uF |
| C3651DNP | 2113947B05 | CAP, 33pF |
| C3801 | 2113928C04 | CAP, 4.7uF |
| C3850 | 2113928C04 | CAP, 4.7uF |
| C3851 | 2113928C04 | CAP, 4.7uF |
| C3852 | 2113928N01 | CAP, 0.1uF |
| C3900 | 2113928C04 | CAP, 4.7uF |
| C3903 | 2113743N38 | CAP, 33pF |
| C3904 | 2113743N38 | CAP, 33pF |
| C3906 | 2113743N50 | CAP, 100pF |
| C3901DNP | 2113947B05 | CAP, 33pF |
| C3902DNP | 2113743N38 | CAP, 33pF |
| C3910 | 2113928C12 | CAP, 10uF |
| C3911 | 2113928C12 | CAP, 10uF |
| C3912 | 2113928N01 | CAP, 0.1uF |
| C3914DNP | 2113743N26 | CAP, 10pF |
| C3950 | 2113928C04 | CAP, 4.7uF |
| C3951 | 2113743M24 | CAP, 0.1uF |
| C3961 | 2113928C12 | CAP, 10uF |
| C3962 | 2113743M24 | CAP, 0.1uF |
| C3963 | 2113928N01 | CAP, 0.1uF |
| C3964 | 2113928N01 | CAP, 0.1uF |
| C3965 | 2113928N01 | CAP, 0.1uF |
| C3966 | 2113743N38 | CAP, 33pF |
| C3967 | 2113743N38 | CAP, 33pF |
| C3960DNP | 2113743L35 | CAP, 5600pF |
| C3980 | 2113928C03 | CAP, 1.0uF |
| C3981 | 2113743N38 | CAP, 33pF |
| C3983 | 2113743N37 | CAP, 30pF |
| C3984 | 2113743N34 | CAP, 22pF |
| C3985 | 2113928C12 | CAP, 10uF |
| C3987 | 2113928C12 | CAP, 10uF |
| C3989 | 2113928P04 | CAP, 1.0uF |
| C3990 | 2113928C12 | CAP, 10uF |
| C3991 | 2113928C12 | CAP, 10uF |
| C3993 | 2113743L41 | CAP, .01uF |
| C3992DNP | 2113743L41 | CAP, .01uF |
| C3998DNP | 2113743L35 | CAP, 5600pF |
| C4000 | 2113928P04 | CAP, 1.0uF |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|-------------|
| C4002 | 2113743L13 | CAP, 680pF |
| C4003 | 2113947B05 | CAP, 33pF |
| C4008 | 2113947B05 | CAP, 33pF |
| C4100 | 2113928P04 | CAP, 1.0uF |
| C4110 | 2113743N38 | CAP, 33pF |
| C4112 | 2113928C04 | CAP, 4.7uF |
| C4113 | 2113743N26 | CAP, 10pF |
| C4114 | 2113743N38 | CAP, 33pF |
| C4160 | 2113743N38 | CAP, 33pF |
| C4198 | 2113947H01 | CAP, 0.1uF |
| C4200 | 2113743M24 | CAP, 0.1uF |
| C4202 | 2113743L13 | CAP, 680pF |
| C4203 | 2113947B05 | CAP, 33pF |
| C4207 | 2113947B05 | CAP, 33pF |
| C4210 | 2113928C04 | CAP, 4.7uF |
| C4213 | 2113743M24 | CAP, 0.1uF |
| C4301 | 2113743N38 | CAP, 33pF |
| C4302 | 2113743N38 | CAP, 33pF |
| C4303 | 2113743N38 | CAP, 33pF |
| C4304 | 2113947E01 | CAP, .01uF |
| C4306 | 2311049A89 | CAPP, 22uF |
| C4355 | 2113947B05 | CAP, 33pF |
| C4356 | 2311049A89 | CAPP, 22uF |
| C4380DNP | 2113928C04 | CAP, 4.7uF |
| C4390 | 2113743M24 | CAP, 0.1uF |
| C4392 | 2113743N38 | CAP, 33pF |
| C4393 | 2113743N38 | CAP, 33pF |
| C4394 | 2113743N38 | CAP, 33pF |
| C4395 | 2113743M24 | CAP, 0.1uF |
| C4400 | 2113928A01 | CAP, 1.0uF |
| C4401 | 2113743M24 | CAP, 0.1uF |
| C4402 | 2113743N26 | CAP, 10pF |
| C441DNP | 2113743L41 | CAP, .01uF |
| C442DNP | 2113743N50 | CAP, 100pF |
| C443DNP | 2113743N50 | CAP, 100pF |
| C4500 | 2113743M24 | CAP, 0.1uF |
| C4501 | 2113743N38 | CAP, 33pF |
| C4502 | 2113928C04 | CAP, 4.7uF |
| C4503 | 2113743M24 | CAP, 0.1uF |
| C4504 | 2113928C04 | CAP, 4.7uF |
| C4550 | 2113743L25 | CAP, 2200pF |
| C4551 | 2113743L41 | CAP, .01uF |
| C5000 | 2113743M24 | CAP, 0.1uF |
| C5002 | 2113743N38 | CAP, 33pF |

Electrical Parts List

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|-------------|
| C5003 | 2113743N38 | CAP, 33pF |
| C5010 | 2113743L41 | CAP, .01uF |
| C5050 | 2113743M24 | CAP, 0.1uF |
| C5053 | 2113928A01 | CAP, 1.0uF |
| C508DNP | 2113743N28 | CAP, 12pF |
| C5100 | 2113743L41 | CAP, .01uF |
| C5101 | 2113743L41 | CAP, .01uF |
| C5102 | 2113743L41 | CAP, .01uF |
| C5103 | 2113743L41 | CAP, .01uF |
| C5104 | 2113743L41 | CAP, .01uF |
| C5105 | 2113743L41 | CAP, .01uF |
| C5106 | 2113743L41 | CAP, .01uF |
| C5107 | 2113743L41 | CAP, .01uF |
| C5200 | 2113947B05 | CAP, 33pF |
| C5202 | 2113947B05 | CAP, 33pF |
| C5204 | 2113947B05 | CAP, 33pF |
| C5206 | 2113947B05 | CAP, 33pF |
| C5208 | 2113947B05 | CAP, 33pF |
| C5210 | 2113947B05 | CAP, 33pF |
| C5212 | 2113743N38 | CAP, 33pF |
| C5213 | 2113743N38 | CAP, 33pF |
| C5214 | 2113947B05 | CAP, 33pF |
| C5218 | 2113947B05 | CAP, 33pF |
| C5220 | 2113947B05 | CAP, 33pF |
| C5222 | 2113947B05 | CAP, 33pF |
| C5224 | 2113947B05 | CAP, 33pF |
| C5226 | 2113743N38 | CAP, 33pF |
| C5227 | 2113743N38 | CAP, 33pF |
| C5228 | 2113947B05 | CAP, 33pF |
| C5229 | 2113743L25 | CAP, 2200pF |
| C5230 | 2113743L25 | CAP, 2200pF |
| C534DNP | 2113743N34 | CAP, 22pF |
| C5400 | 2113928C12 | CAP, 10uF |
| C5401 | 2113743N22 | CAP, 6.8pF |
| C5402 | 2113743M24 | CAP, 0.1uF |
| C5403 | 2113743N38 | CAP, 33pF |
| C5404 | 2113743N38 | CAP, 33pF |
| C5405 | 2113743N38 | CAP, 33pF |
| C5407 | 2113743L41 | CAP, .01uF |
| C5410 | 2113928C12 | CAP, 10uF |
| C5411 | 2113928N01 | CAP, 0.1uF |
| C5412 | 2113928N01 | CAP, 0.1uF |
| C5413 | 2113928P04 | CAP, 1.0uF |
| C5501 | 2113743N38 | CAP, 33pF |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|-------------|
| C5503 | 2113743N38 | CAP, 33pF |
| C5504 | 2113743N38 | CAP, 33pF |
| C5505 | 2113743N38 | CAP, 33pF |
| C5506 | 2113928N01 | CAP, 0.1uF |
| C5507 | 2113743N38 | CAP, 33pF |
| C5508 | 2113928N01 | CAP, 0.1uF |
| C5509DNP | 2113928N01 | CAP, 0.1uF |
| C5600 | 2113743M24 | CAP, 0.1uF |
| C5604 | 2113743M24 | CAP, 0.1uF |
| C5607 | 2113743N09 | CAP, 2pF |
| C5608 | 2113743L23 | CAP, 1800pF |
| C5605DNP | 2113743N03 | CAP, 1pF |
| C5611 | 2113743N52 | CAP, 120pF |
| C5612 | 2113743L41 | CAP, .01uF |
| C5613 | 2113743L01 | CAP, 220pF |
| C5614 | 2113743L07 | CAP, 390pF |
| C5615 | 2113743L37 | CAP, 6800pF |
| C5616 | 2113743M24 | CAP, 0.1uF |
| C5617 | 2113743L41 | CAP, .01uF |
| C5618 | 2113743N26 | CAP, 10pF |
| C5620 | 2113743N26 | CAP, 10pF |
| C5621 | 2113743N26 | CAP, 10pF |
| C5622 | 2113928N01 | CAP, 0.1uF |
| C5623 | 2113928N01 | CAP, 0.1uF |
| C5624 | 2113928N01 | CAP, 0.1uF |
| C5649DNP | 2113743N26 | CAP, 10pF |
| C5650 | 2113743N03 | CAP, 1pF |
| C5651 | 2113743N01 | CAP, 0.5pF |
| C5670 | 2113928N01 | CAP, 0.1uF |
| C5671 | 2113743L17 | CAP, 1000pF |
| C5700 | 2113743N38 | CAP, 33pF |
| C6000 | 2113743F18 | CAP, 2.2uF |
| C6001 | 2113743M24 | CAP, 0.1uF |
| C6002 | 2113743M24 | CAP, 0.1uF |
| C6003 | 2113743M24 | CAP, 0.1uF |
| C6004 | 2113947H01 | CAP, 0.1uF |
| C6005 | 2113743N38 | CAP, 33pF |
| C6007 | 2113743M24 | CAP, 0.1uF |
| C6008 | 2113743N38 | CAP, 33pF |
| C6009 | 2113743M24 | CAP, 0.1uF |
| C6010 | 2113743L41 | CAP, .01uF |
| C6011 | 2113928C12 | CAP, 10uF |
| C6012 | 2113743L01 | CAP, 220pF |
| C6014 | 2113928N01 | CAP, 0.1uF |

Electrical Parts List

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|-------------|
| C6019 | 2113928P04 | CAP, 1.0uF |
| C6050 | 2113743N32 | CAP, 18pF |
| C6051 | 2113743L09 | CAP, 470pF |
| C6052 | 2113743N52 | CAP, 120pF |
| C6053 | 2113743N09 | CAP, 2pF |
| C6055 | 2113743N12 | CAP, 2.7pF |
| C6057 | 2113743L09 | CAP, 470pF |
| C6058 | 2113743M24 | CAP, 0.1uF |
| C6059 | 2113743M24 | CAP, 0.1uF |
| C6056DNP | 2113743N03 | CAP, 1pF |
| C6060 | 2113743N42 | CAP, 47pF |
| C6061 | 2113743L13 | CAP, 680pF |
| C6062 | 2113743L41 | CAP, .01uF |
| C6063 | 2113743M24 | CAP, 0.1uF |
| C6064 | 2113743M24 | CAP, 0.1uF |
| C6065 | 2113743M24 | CAP, 0.1uF |
| C6066 | 2113743M24 | CAP, 0.1uF |
| C6067 | 2113743N05 | CAP, 1.2pF |
| C6069 | 2113743L17 | CAP, 1000pF |
| C6070 | 2113743N26 | CAP, 10pF |
| C6080 | 2113743N32 | CAP, 18pF |
| C6082 | 2187893N01 | CAP, 1.0uF |
| C6083 | 2187893N01 | CAP, 1.0uF |
| C6084 | 2113743N52 | CAP, 120pF |
| C6090DNP | 2113743N09 | CAP, 2pF |
| C6091DNP | 2113743N03 | CAP, 1pF |
| C6500 | 2113928P04 | CAP, 1.0uF |
| C6501 | 2113928C12 | CAP, 10uF |
| C6502 | 2113743N38 | CAP, 33pF |
| C6503 | 2113743N38 | CAP, 33pF |
| C6504 | 2113743N38 | CAP, 33pF |
| C6510DNP | 2113743N38 | CAP, 33pF |
| C6511DNP | 2113743N38 | CAP, 33pF |
| C706DNP | 2113743N03 | CAP, 1pF |
| C7610 | 2113743N38 | CAP, 33pF |
| C7611 | 2113743N38 | CAP, 33pF |
| C7612 | 2113947B05 | CAP, 33pF |
| C7613 | 2113743N38 | CAP, 33pF |
| C7615 | 2113946D02 | CAP, 1.0uF |
| C7616 | 2113946D02 | CAP, 1.0uF |
| C7617 | 2113946D02 | CAP, 1.0uF |
| C7618 | 2113928N01 | CAP, 0.1uF |
| C7620 | 2113743N30 | CAP, 15pF |
| C7621 | 2113743L09 | CAP, 470pF |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|---------------|--------------|
| C7630 | 2113928N01 | CAP, 0.1uF |
| C7631 | 2113928N01 | CAP, 0.1uF |
| C7632 | 2113928N01 | CAP, 0.1uF |
| C7633 | 2113928N01 | CAP, 0.1uF |
| C7634 | 2113928N01 | CAP, 0.1uF |
| C7640 | 2113743L17 | CAP, 1000pF |
| C7641 | 2113743L41 | CAP, .01uF |
| C7642 | 2113743L17 | CAP, 1000pF |
| C7643 | 2113743M24 | CAP, 0.1uF |
| C7644 | 2113743M24 | CAP, 0.1uF |
| C7726 | 2113743N38 | CAP, 33pF |
| C7729 | 2113743N38 | CAP, 33pF |
| C7721DNP | 2113743N38 | CAP, 33pF |
| C7730 | 2113743N38 | CAP, 33pF |
| C7731 | 2113743M24 | CAP, 0.1uF |
| C813DNP | 2113743N38 | CAP, 33pF |
| C901DNP | 2113743M24 | CAP, 0.1uF |
| CR200 | 4809877C32 | SMV1763 |
| CR201 | 4809877C32 | SMV1763 |
| CR330 | 4809877C32 | SMV1763 |
| CR331 | 4809877C32 | SMV1763 |
| CR1300 | 4809924D18 | RB520S-30 |
| CR3000 | 4809924D18 | RB520S-30 |
| CR3050 | 4809653F02 | MBRM120T3 |
| CR3100 | 4809924D18 | RB520S-30 |
| CR3960 | 4809653F02 | MBRM120T3 |
| CR3961 | 4809653F02 | MBRM120T3 |
| CR5005 | 4809948D42 | RB751V40 |
| D5101 | 4809788E17 | EDZ68B |
| D5110 | 4809788E17 | EDZ68B |
| D5300 | 4809118D02 | LNJ115W8P0MT |
| E100 | SHORT_RES0402 | SHORT |
| E108 | SHORT_RES0402 | SHORT |
| E109 | SHORT_RES0402 | SHORT |
| E110 | SHORT_RES0402 | SHORT |
| E111 | SHORT_RES0402 | SHORT |
| E528 | SHORT_RES0402 | SHORT |
| E529 | SHORT_RES0402 | SHORT |
| E530 | SHORT_RES0402 | SHORT |
| E975 | SHORT_RES0402 | SHORT |
| E976 | SHORT_RES0402 | SHORT |
| E977 | SHORT_RES0402 | SHORT |
| E2013 | SHORT_RES0402 | SHORT |
| E2320 | SHORT_RES0402 | SHORT |

Electrical Parts List

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description | |
|------------------|---------------|--------------|------------|
| E3003 | SHORT_RES0402 | SHORT | |
| E3050 | SHORT_RES0402 | SHORT | |
| E3103 | SHORT_RES0402 | SHORT | |
| E3153 | SHORT_RES0402 | SHORT | |
| E3203 | SHORT_RES0402 | SHORT | |
| E3251 | SHORT_RES0402 | SHORT | |
| E3352 | SHORT_RES0402 | SHORT | |
| E3402 | SHORT_RES0402 | SHORT | |
| E3403 | SHORT_RES0402 | SHORT | |
| E3451 | SHORT_RES0402 | SHORT | |
| E3503 | SHORT_RES0402 | SHORT | |
| E3552 | SHORT_RES0402 | SHORT | |
| E3601 | SHORT_RES0402 | SHORT | |
| E3900 | SHORT_RES0402 | SHORT | |
| E3916 | SHORT_RES0402 | SHORT | |
| E3951 | SHORT_RES0402 | SHORT | |
| E3965 | SHORT_RES0402 | SHORT | |
| E6001 | SHORT_BAR0_61 | SHORTING_BAR | |
| E6002 | SHORT_BAR0_61 | SHORTING_BAR | |
| E6003 | SHORT_BAR0_61 | SHORTING_BAR | |
| E6006 | SHORT_RES0402 | SHORT | |
| E6009 | SHORT_RES0402 | SHORT | |
| E6062 | SHORT_RES0402 | SHORT | |
| FL001 | 4889695L12 | ASM3201B | |
| FL010 | 9109674L20 | S0351 | |
| FL020 | 9109674L22 | 74L22 | |
| FL030 | 9109674L18 | S0350 | |
| FL150 | 5885949K03 | LDD15A | |
| FL201 | 9109405J17 | SAFCD380 | |
| FL300 | 9109239M28 | fl | SAF2G14KB0 |
| FL310 | 9109674L14 | | LFSG20N25 |
| FL320 | 9109405J16 | FLTR | |
| FL410 | 9109239M16 | fl | SAF1G95KB0 |
| FL460 | 5888234M01 | | 34M01 |
| FL500 | 9188695K04 | bg | 95K04 |
| FL510 | 4887925N01 | | FLTR |
| FL4300 | 4889526L04 | bg | FLTR |
| FL5601 | 9109239M23 | | LE65A |
| FL6050 | 9109239M26 | | 855969 |
| FL6055 | 9185223E01 | | DFM2R1575 |
| J001 | 0788468M03 | | CONTACT |
| J3900 | 0988365M02 | c | CONN_J |
| J4100DNP | 5085600J01 | | SPKR |
| J4200DNP | 2888328M01 | | CONN_P |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|---------------|---------------|
| J4300 | 0904136G01 | CONN_J |
| J5000 | 0987636K05 | c CONN_J |
| J5200 | 0987817K05 | c CONN_J |
| J5400 | 3987522K03 | CONTACT |
| J5500 | 3909426M05 | BM050406 |
| J7600 | 0987817K04 | c CONN_J |
| J7700 | 0987817K04 | c CONN_J |
| L003 | 2462587P55 | IDCTR, 82nH |
| L005 | 2409154M14 | IDCTR, 12.0nH |
| L010 | 2409154M59 | IDCTR, 4.7nH |
| L150 | 2409154M79 | IDCTR, 1.8nH |
| L152 | 2409154M81 | IDCTR, 2.7nH |
| L153 | SHORT_RES0402 | SHORT |
| L200 | 0660076S01 | RES, 0 |
| L201 | 2485793G04 | IDCTR, 10nH |
| L223 | 2485793G04 | IDCTR, 10nH |
| L240 | 2409377M16 | IDCTR, 82nH |
| L241 | 2409377M16 | IDCTR, 82nH |
| L242 | 2488289M24 | IDCTR, 82nH |
| L243 | 2488289M25 | IDCTR, 100nH |
| L280 | 2409154M09 | IDCTR, 4.7nH |
| L281 | 2409154M09 | IDCTR, 4.7nH |
| L297 | 2409377M16 | IDCTR, 82nH |
| L298 | 2409377M16 | IDCTR, 82nH |
| L302DNP | 2409154M07 | IDCTR, 3.3nH |
| L313 | 2409154M56 | IDCTR, 2.7nH |
| L314 | 2409154M73 | IDCTR, 68.0nH |
| L315 | 2113743N02 | CAP, 0.75pF |
| L316 | 2113743N26 | CAP, 10pF |
| L320 | 2409646M86 | IDCTR, 27nH |
| L321 | 2409646M86 | IDCTR, 27nH |
| L324 | 2485793G15 | IDCTR, 82nH |
| L325 | 2485793G15 | IDCTR, 82nH |
| L330 | 2409377M08 | IDCTR, 22nH |
| L610 | 2409154M11 | IDCTR, 6.8nH |
| L701 | 2409154M70 | IDCTR, 39.0nH |
| L703 | 2409154M47 | IDCTR, 82.0nH |
| L710 | 2113743N12 | CAP, 2.7pF |
| L713 | 2409154M65 | IDCTR, 15.0nH |
| L810 | 2409154M09 | IDCTR, 4.7nH |
| L821 | 2409154M61 | IDCTR, 6.8nH |
| L825 | 2409154M52 | IDCTR, 1.2nH |
| L832 | 2409154M09 | IDCTR, 4.7nH |
| L3000 | 2588866L14 | IDCTR, 47uH |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|-----------------|
| L3050 | 2588866L14 | IDCTR, 47uH |
| L3100 | 2487659M11 | IDCTR, 47uH |
| L3220 | 2588866L05 | IDCTR, 2.2uH |
| L3560 | 2487996L04 | EXCML16 |
| L4399 | 2409646M13 | IDCTR, 39nH |
| L4400 | 2409154M71 | IDCTR, 47.0nH |
| L4401 | 2409154M71 | IDCTR, 47.0nH |
| L5600 | 2409154M08 | IDCTR, 3.9nH |
| L5601 | 2409154M08 | IDCTR, 3.9nH |
| L5602 | 2409154M08 | IDCTR, 3.9nH |
| L5604 | 2409154M03 | IDCTR, 1.5nH |
| L6000 | 0662057M01 | RES, 0 |
| L6050 | 2409154M11 | IDCTR, 6.8nH |
| L6051 | 2409154M11 | IDCTR, 6.8nH |
| L6053 | 2409154M12 | IDCTR, 8.2nH |
| L6080 | 2409704K43 | IDCTR, 33nH |
| L7600 | 2462587Q46 | IDCTR, 820nH |
| L7640 | 2462587Q59 | IDCTR, 10uH |
| L831DNP | 2409154M65 | IDCTR, 15.0nH |
| M001 | 0987378K01 | SWITCH |
| M5700 | 5909382K09 | MOTOR |
| M6050 | 0987378K01 | SWITCH |
| Q130 | 4809579E24 | 2SJ347 |
| Q420 | 4809608E03 | DTA114YE |
| Q510 | 4862830F01 | bga SI8401DB |
| Q700 | 4809579E16 | TN0200T |
| Q901 | 4809579E58 | FDG6332C |
| Q902 | 4809579E48 | FDC6306P |
| Q906 | 4809939C34 | EMB10 |
| Q3220 | 4809579E43 | FDG6303N |
| Q3222 | 4809579E02 | 2SK1830 |
| Q3403 | 4809607E04 | 2SB1132 |
| Q3502 | 4809607E04 | 2SB1132 |
| Q3610 | 4809607E04 | 2SB1132 |
| Q3960 | 4862830F01 | bga SI8401DB |
| Q3963 | 4862830F01 | bga SI8401DB |
| Q3964 | 4862830F01 | bga SI8401DB |
| Q3966 | 4862830F01 | bga SI8401DB |
| Q3967 | 4809939C39 | EMD9 |
| Q3980 | 4809579E49 | SI6467DQ |
| Q3981 | 4862830F01 | bga SI8401DB |
| Q4300 | 4809940E03 | DTC114TE |
| Q5000 | 4809579E58 | FDG6332C |
| Q5600 | 5109572E39 | AS179_92 |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|---------------|-------------|
| Q6050 | 4809579E50 | SI1905 |
| Q6051 | 4809579E24 | 2SJ347 |
| R009 | 0662057M01 | RES, 0 |
| R1003DNP | 0662057M01 | RES, 0 |
| R1004DNP | 0662057M01 | RES, 0 |
| R1006DNP | 0662057N15 | RES, 47K |
| R1060DNP | 0662057M01 | RES, 0 |
| R1100DNP | 0662057M98 | RES, 10K |
| R1102DNP | 0662057N23 | RES, 100K |
| R1104DNP | 0662057M01 | RES, 0 |
| R1122DNP | 0662057M98 | RES, 10K |
| R1150DNP | 0662057M98 | RES, 10K |
| R1200DNP | 0662057M01 | RES, 0 |
| R130 | 0662057M74 | RES, 1K |
| R131 | 0662057N09 | RES, 27K |
| R132 | 0662057N09 | RES, 27K |
| R133 | 0662057M01 | RES, 0 |
| R134 | 0662057N39 | RES, 470K |
| R1000 | 0662057M01 | RES, 0 |
| R1001 | 0662057M01 | RES, 0 |
| R1002 | 0662057M01 | RES, 0 |
| R1061 | 0662057M01 | RES, 0 |
| R1101 | 0662057N23 | RES, 100K |
| R1103 | 0662057N23 | RES, 100K |
| R1105 | 0662057M01 | RES, 0 |
| R1127 | 0662057M74 | RES, 1K |
| R1300 | 0662057M98 | RES, 10K |
| R1303 | 0662057M01 | RES, 0 |
| R1304 | 0662057M01 | RES, 0 |
| R1301DNP | 0662057M98 | RES, 10K |
| R135DNP | 0662057M01 | RES, 0 |
| R140 | 0662057M70 | RES, 680 |
| R141 | 0662057M94 | RES, 6.8K |
| R146 | 0662057M36 | RES, 27 |
| R147 | 0609591M17 | RESNET, 220 |
| R1401DNP | 0662057M01 | RES, 0 |
| R150 | 0662057M50 | RES, 100 |
| R151 | SHORT_RES0402 | SHORT |
| R200 | 0662057N15 | RES, 47K |
| R201 | 0662057M98 | RES, 10K |
| R203 | SHORT_RES0402 | SHORT |
| R205 | 0662057M43 | RES, 51 |
| R2009DNP | 0662057B27 | RES, 1.6MEG |
| R213 | 0609591M37 | RESNET, 10K |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|---------------|-------------|
| R215 | 0662057V02 | RES, 10K |
| R230 | 0662057N15 | RES, 47K |
| R231 | SHORT_RES0402 | SHORT |
| R232 | SHORT_RES0402 | SHORT |
| R240 | 0662057M26 | RES, 10 |
| R250 | 0609591M01 | RESNET, 10 |
| R252 | 0609591M01 | RESNET, 10 |
| R270 | 0662057M50 | RES, 100 |
| R290 | SHORT_RES0402 | SHORT |
| R291 | SHORT_RES0402 | SHORT |
| R292 | SHORT_RES0402 | SHORT |
| R293 | 0662057M01 | RES, 0 |
| R294 | 0662057M01 | RES, 0 |
| R295 | 0662057M01 | RES, 0 |
| R296 | SHORT_RES0402 | SHORT |
| R301 | 0662057M85 | RES, 3K |
| R304 | 0662057M50 | RES, 100 |
| R305 | 0662057M26 | RES, 10 |
| R315 | 0662057M26 | RES, 10 |
| R319 | 0662057M26 | RES, 10 |
| R320 | 2113743N22 | CAP, 6.8pF |
| R321 | 0662057M26 | RES, 10 |
| R325 | 0662057M70 | RES, 680 |
| R330 | 0662057M01 | RES, 0 |
| R331 | 0662057M98 | RES, 10K |
| R332 | 0609591M37 | RESNET, 10K |
| R335 | 0662057M01 | RES, 0 |
| R336 | 0662057M01 | RES, 0 |
| R337 | 0662057M01 | RES, 0 |
| R338 | 0662057M01 | RES, 0 |
| R339 | 0662057M01 | RES, 0 |
| R341 | 0662057M01 | RES, 0 |
| R342 | 0662057M01 | RES, 0 |
| R344 | 0662057M74 | RES, 1K |
| R346 | 0662057N15 | RES, 47K |
| R347 | SHORT_RES0402 | SHORT |
| R348 | 0662057M26 | RES, 10 |
| R349 | 0662057M26 | RES, 10 |
| R360 | SHORT_RES0402 | SHORT |
| R361 | SHORT_RES0402 | SHORT |
| R410 | 0662057M90 | RES, 4.7K |
| R411 | 0662057M70 | RES, 680 |
| R412 | 0662057M70 | RES, 680 |
| R420 | 0662057M01 | RES, 0 |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|---------------|-------------|
| R431 | SHORT_RES0402 | SHORT |
| R432 | SHORT_RES0402 | SHORT |
| R450 | 0662057M95 | RES, 7.5K |
| R451 | 0662057M90 | RES, 4.7K |
| R452 | 0662057M98 | RES, 10K |
| R453 | 0662057N20 | RES, 75K |
| R454 | SHORT_RES0402 | SHORT |
| R455 | SHORT_RES0402 | SHORT |
| R456 | 0662057M90 | RES, 4.7K |
| R457 | 0662057N11 | RES, 33K |
| R503 | 0662057M83 | RES, 2.4K |
| R504 | 0662057M74 | RES, 1K |
| R506 | 0662057N19 | RES, 68K |
| R508 | 0662057M01 | RES, 0 |
| R511 | 0662057N21 | RES, 82K |
| R536 | SHORT_RES0402 | SHORT |
| R537 | 0662057M98 | RES, 10K |
| R554 | 0662057N19 | RES, 68K |
| R556 | 0662057N30 | RES, 200K |
| R576 | 0662057N15 | RES, 47K |
| R577 | 0662057M96 | RES, 8.2K |
| R610 | SHORT_RES0402 | SHORT |
| R611 | 0662057N30 | RES, 200K |
| R612 | 0662057M58 | RES, 220 |
| R615 | 0662057M01 | RES, 0 |
| R700 | 0662057M28 | RES, 12 |
| R701 | 0662057M38 | RES, 33 |
| R704 | 0662057M64 | RES, 390 |
| R705 | 0662057M76 | RES, 1.2K |
| R707 | 0662057M56 | RES, 180 |
| R807 | 0662057M39 | RES, 36 |
| R810 | 0662057U95 | RES, 5.6K |
| R812 | 0662057V02 | RES, 10K |
| R813 | 0662057V02 | RES, 10K |
| R814 | 0662057M43 | RES, 51 |
| R815 | 0662057U98 | RES, 7.5K |
| R816 | 0662057U60 | RES, 220 |
| R822 | 0662057M01 | RES, 0 |
| R900 | 0662057M98 | RES, 10K |
| R901 | 0662057M98 | RES, 10K |
| R902 | 0662057M98 | RES, 10K |
| R903 | 0662057N15 | RES, 47K |
| R904 | 0662057M01 | RES, 0 |
| R912 | 0662057N15 | RES, 47K |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|-------------|
| R1400 | 0662057M01 | RES, 0 |
| R1402 | 0662057M01 | RES, 0 |
| R2002 | 0662057M98 | RES, 10K |
| R2003 | 0662057M98 | RES, 10K |
| R2006 | 0662057M98 | RES, 10K |
| R2011 | 0662057M01 | RES, 0 |
| R2012 | 0662057M01 | RES, 0 |
| R2014 | 0662057N11 | RES, 33K |
| R2026 | 0609591M37 | RESNET, 10K |
| R2027 | 0662057N23 | RES, 100K |
| R2028 | 0662057M50 | RES, 100 |
| R2029 | 0662057M50 | RES, 100 |
| R2030 | 0662057M98 | RES, 10K |
| R2040 | 0662057N23 | RES, 100K |
| R2041 | 0662057M35 | RES, 24 |
| R2042 | 0662057M35 | RES, 24 |
| R2043 | 0662057N03 | RES, 15K |
| R2044 | 0662057N03 | RES, 15K |
| R2045 | 0662057N23 | RES, 100K |
| R2050 | 0662057M82 | RES, 2.2K |
| R2051 | 0662057M01 | RES, 0 |
| R2055 | 0662057M98 | RES, 10K |
| R2059 | 0662057M98 | RES, 10K |
| R2056DNP | 0662057M98 | RES, 10K |
| R2070 | 0662057M50 | RES, 100 |
| R2097 | 0662057M26 | RES, 10 |
| R2098 | 0662057M01 | RES, 0 |
| R2304 | 0662057M01 | RES, 0 |
| R2350 | 0662057M01 | RES, 0 |
| R2400 | 0662057M01 | RES, 0 |
| R2401 | 0662057M01 | RES, 0 |
| R2402 | 0662057N23 | RES, 100K |
| R2403 | 0662057V35 | RES, 200K |
| R2404 | 0662057M01 | RES, 0 |
| R2430 | 0662057V35 | RES, 200K |
| R2431 | 0662057V35 | RES, 200K |
| R3004 | 0687874L02 | RES, 0.1 |
| R3051 | 0687874L02 | RES, 0.1 |
| R3055 | 0662057U85 | RES, 2.2K |
| R3056 | 0662057V13 | RES, 27K |
| R3057 | 0662057M01 | RES, 0 |
| R3104 | 0687874L02 | RES, 0.1 |
| R3205DNP | 0662057M01 | RES, 0 |
| R3221 | 0662057N23 | RES, 100K |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|---------------|-------------|
| R3222 | 0662057N01 | RES, 12K |
| R3223 | 0662057N35 | RES, 330K |
| R3224 | 0662057V32 | RES, 150K |
| R3225 | 0662057V32 | RES, 150K |
| R3228 | 0662057N47 | RES, 1MEG |
| R3400 | 0687874L02 | RES, 0.1 |
| R3504 | 0687874L02 | RES, 0.1 |
| R350DNP | 0662057M01 | RES, 0 |
| R3553 | 0662057M50 | RES, 100 |
| R3561 | 0687874L02 | RES, 0.1 |
| R3650 | 0662057M78 | RES, 1.5K |
| R3651 | 0662057M37 | RES, 30 |
| R3652 | 0662057M37 | RES, 30 |
| R3850 | SHORT_RES0402 | SHORT |
| R3902 | 0662057M50 | RES, 100 |
| R3904 | 0662057M50 | RES, 100 |
| R3910 | 0662057U98 | RES, 7.5K |
| R3911 | 0662057V02 | RES, 10K |
| R3912 | 0662057N23 | RES, 100K |
| R3961 | 0687874L01 | RES, 0.24 |
| R3963 | 0662057V35 | RES, 200K |
| R3990 | 0662057V35 | RES, 200K |
| R3995 | 0662057N23 | RES, 100K |
| R3997 | 0662057N23 | RES, 100K |
| R3998 | 0662057V35 | RES, 200K |
| R3999 | 0662057M01 | RES, 0 |
| R3994DNP | 0662057M01 | RES, 0 |
| R4004 | 0609591M05 | RESNET, 22 |
| R4103 | 0662057M90 | RES, 4.7K |
| R4200 | 0662057N03 | RES, 15K |
| R4201 | 0662057N06 | RES, 20K |
| R421DNP | 0662057M98 | RES, 10K |
| R4305 | 0662057N47 | RES, 1MEG |
| R4306 | 0662057N39 | RES, 470K |
| R4393 | 0662057M98 | RES, 10K |
| R4395 | 0662057M98 | RES, 10K |
| R4396 | 0662057M90 | RES, 4.7K |
| R4397 | 0662057N39 | RES, 470K |
| R4398 | 0662057M68 | RES, 560 |
| R4400 | 0662057M50 | RES, 100 |
| R4401 | 0662057M74 | RES, 1K |
| R4550 | 0662057N06 | RES, 20K |
| R5000 | 0662057N23 | RES, 100K |
| R5001 | 0662057N15 | RES, 47K |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|--------------|
| R5002 | 0662057M98 | RES, 10K |
| R5003 | 0662057N13 | RES, 39K |
| R5004 | 0662057N23 | RES, 100K |
| R5005 | 0662057N15 | RES, 47K |
| R5006 | 0609591M49 | RESNET, 100K |
| R5009 | 0662057N39 | RES, 470K |
| R5007DNP | 0662057N23 | RES, 100K |
| R5008DNP | 0662057M01 | RES, 0 |
| R5050 | 0662057N15 | RES, 47K |
| R5052 | 0662057N33 | RES, 270K |
| R5053 | 0662057M86 | RES, 3.3K |
| R5100 | 0662057M98 | RES, 10K |
| R5101 | 0609591M37 | RESNET, 10K |
| R5102 | 0609591M37 | RESNET, 10K |
| R5113 | 0662057M26 | RES, 10 |
| R5114 | 0662057M50 | RES, 100 |
| R5115 | 0662057M50 | RES, 100 |
| R5116 | 0662057M50 | RES, 100 |
| R5117 | 0662057M50 | RES, 100 |
| R5118 | 0662057M50 | RES, 100 |
| R5119 | 0662057M50 | RES, 100 |
| R5120 | 0662057M50 | RES, 100 |
| R5121 | 0662057M50 | RES, 100 |
| R5200 | 0662057M98 | RES, 10K |
| R526DNP | 0662057M98 | RES, 10K |
| R5300 | 0662057M34 | RES, 22 |
| R5301 | 0662057M34 | RES, 22 |
| R5401 | 0662057M90 | RES, 4.7K |
| R5480 | 0662057M80 | RES, 1.8K |
| R5481 | 0662057V11 | RES, 22K |
| R5482 | 0662057V43 | RES, 330K |
| R5483 | 0662057V02 | RES, 10K |
| R5485 | 0662057M50 | RES, 100 |
| R5500 | 0662057M01 | RES, 0 |
| R5501 | 0662057M92 | RES, 5.6K |
| R5502 | 0662057M01 | RES, 0 |
| R5503 | 0662057M01 | RES, 0 |
| R5603 | 0662057M78 | RES, 1.5K |
| R5604 | 0662057N08 | RES, 24K |
| R5605 | 0662057M96 | RES, 8.2K |
| R5606 | 0655086C39 | RES, 2870 |
| R5607 | 0662057M80 | RES, 1.8K |
| R5608 | 0662057M80 | RES, 1.8K |
| R5613 | 0662057M96 | RES, 8.2K |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|--------------|
| R5619 | 0662057M98 | RES, 10K |
| R5610DNP | 0662057M98 | RES, 10K |
| R5623 | 0662057M98 | RES, 10K |
| R5624 | 0662057M98 | RES, 10K |
| R5675 | 0662057N39 | RES, 470K |
| R5683 | 0662057N47 | RES, 1MEG |
| R6000 | 0662057V19 | RES, 47K |
| R6001 | 0609591M45 | RESNET, 47K |
| R6002 | 0609591M45 | RESNET, 47K |
| R6003 | 0609591M45 | RESNET, 47K |
| R6004 | 0609591M45 | RESNET, 47K |
| R6005 | 0662057N23 | RES, 100K |
| R6006 | 0662057M01 | RES, 0 |
| R6008 | 0662057M82 | RES, 2.2K |
| R6007DNP | 0662057M01 | RES, 0 |
| R6010 | 0662057V32 | RES, 150K |
| R6011 | 0662057V35 | RES, 200K |
| R6059 | 0662057M01 | RES, 0 |
| R6060 | 0662057M94 | RES, 6.8K |
| R6061 | 0662057M01 | RES, 0 |
| R6063 | 0662057M46 | RES, 68 |
| R7610 | 0662057M50 | RES, 100 |
| R7611 | 0662057M50 | RES, 100 |
| R7612 | 0662057M50 | RES, 100 |
| R7613 | 0662057N23 | RES, 100K |
| R7615 | 0662057M01 | RES, 0 |
| R7614DNP | 0662057M01 | RES, 0 |
| R7616DNP | 0662057M01 | RES, 0 |
| R7620 | 0662057M50 | RES, 100 |
| R7630 | 0662057M82 | RES, 2.2K |
| R7631 | 0662057M82 | RES, 2.2K |
| R7632 | 0609591M29 | RESNET, 2.2K |
| R7635 | 0662057M46 | RES, 68 |
| R7637 | 0662057M98 | RES, 10K |
| R7638 | 0609591M37 | RESNET, 10K |
| R7641 | 0662057M78 | RES, 1.5K |
| R7642 | 0662057M92 | RES, 5.6K |
| R7643 | 0662057M98 | RES, 10K |
| R7644 | 0662057N23 | RES, 100K |
| R7645 | 0662057N23 | RES, 100K |
| R7646 | 0662057N23 | RES, 100K |
| R7654 | 0662057N39 | RES, 470K |
| R7650DNP | 0662057M01 | RES, 0 |
| S2070 | 4085805H02 | SWITCH |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|---------------|
| S5100 | 4087635K01 | SWITCH |
| S5101 | 4087635K01 | SWITCH |
| S5102 | 4087635K01 | SWITCH |
| S5103 | 4087635K01 | SWITCH |
| SH130 | 2688976N01 | SHIELD |
| SH140 | 2687472N03 | SHIELD |
| SH150 | 2687476N03 | SHIELD |
| SH200 | 2687475N03 | SHIELD |
| SH310 | 2687473N03 | SHIELD |
| SH330 | 2687474N03 | SHIELD |
| SH400 | 2687471N03 | SHIELD |
| SH500 | 2688037M01 | SHIELD |
| SH700 | 2688036M01 | SHIELD |
| SH800 | 2688035M03 | SHIELD |
| SH1000 | 2688975N01 | SHIELD |
| SH2000 | 2688974N02 | SHIELD |
| SH3000 | 2688727M02 | SHIELD |
| SH5600 | 2688038M01 | SHIELD |
| SH6000 | 2688033M01 | SHIELD |
| SH6100 | 2688031M01 | SHIELD |
| SH6200 | 2688034M01 | SHIELD |
| SH7600 | 2688089M02 | SHIELD |
| T100 | 5887510M01 | HHM1520 |
| T650 | 5885949K08 | x HHM1409 |
| T660 | 5885949K09 | x HHM1410 |
| T670 | 5885949K05 | x HHM1525 |
| U101 | 5188450M07 | bg 50M07 |
| U130 | 5187634N01 | KM4110 |
| U140 | 4809283D73 | MQL304 |
| U150 | 5109940K32 | UPC8151TB |
| U200 | 5109817F71 | q MAX2363 |
| U310 | 5109944C53 | q MC13770 |
| U330 | 5109817F69 | q MAX2309 |
| U410 | 5187970L05 | m AV122 |
| U420 | 5109908K55 | PA2001_5W |
| U440 | 5109768D08 | LM20 |
| U450 | 5187970L13 | DD02-92 |
| U500 | 5188450M05 | 50M05 |
| U510 | 5109522E63 | NC7WZ04 |
| U600 | 5109940K41 | bg LIFE_30PIN |
| U6004DNP | 5182159Y04 | MAX6381 |
| U630 | 5109512F47 | LP3985 |
| U700 | 4809283D97 | 83D97 |
| U710 | 5887694L17 | EXB24ATE |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|-------------|-------------------|
| U800 | 5109908K74 | 08K74 |
| U810 | 5885811G11 | q DD05-EN722 |
| U908 | 5109522E83 | NC7SZ11 |
| U1000 | 5199134J02 | bga1 8 DSPIO |
| U1110 | 5109522E53 | s NC7SZ125 |
| U1120 | 5109522E60 | TC7SZ08FU |
| U1140 | 5109522E53 | s NC7SZ125 |
| U1150 | 5162852A59 | MAX4599EXT |
| U1300 | 5199144J01 | b 44J01 |
| U1310 | 5199144J01 | b 44J01 |
| U1400 | 5109509A55 | bg K4M64163 |
| U2000 | 5189251L05 | bg OMAP1510 |
| U2020 | 5109522E60 | TC7SZ08FU |
| U2023 | 5109522E53 | s NC7SZ125 |
| U2040 | 5109522E25 | TC7SH02FU |
| U2070 | 5109522E16 | TC7W74FU |
| U2071 | 5109522E60 | TC7SZ08FU |
| U2300 | 5199121J01 | bga 5 28F128K18 |
| U2380 | 5199139J01 | bga 5 GE28F256K18 |
| U2400 | 5109509A45 | bga K4S56163LC |
| U3000 | 5188450M06 | b 50M06 |
| U3220 | 5187324N01 | LTC3411 |
| U3910 | 5109512F46 | ILC7081 |
| U3911 | 5164751E01 | MC74VHC1GT50 |
| U3980 | 5187344N01 | bga LP3983 |
| U5000 | 5109817F58 | 17F58 |
| U5001 | 4889526L02 | bga 0 CSPEMI-307 |
| U5002 | 5109522E82 | mi NC7SB3157 |
| U5003 | 4889526L01 | bga 0 CSPEMI-306 |
| U5004 | 5109522E82 | mi NC7SB3157 |
| U5005 | 5109522E82 | mi NC7SB3157 |
| U5600 | 5189316L01 | BCM2033A |
| U5623 | 5109522E82 | mi NC7SB3157 |
| U5670 | 5109522E60 | TC7SZ08FU |
| U6000 | 5109841C70 | bga1 30 GSP2E |
| U6001 | 5199342A01 | bga GT28F800B |
| U6002 | 5186311J23 | mi NC7SZ126 |
| U6003 | 5186311J23 | mi NC7SZ126 |
| U6010 | 5109512F46 | ILC7081 |
| U6050 | 5187970L16 | GRF2I_LP |
| U6051 | 5105739X12 | BGA428 |
| U6075 | 5109522E17 | TC7S00FU |
| U6500 | 5162852A33 | I HSDL3202 |
| U7600 | 5189251L01 | CX1164621 |

Table 10. Electrical Parts List - cont'd

| Reference Number | Part Number | Description |
|------------------|--------------|---------------|
| U7601 | 5109817F66 | TLE4913 |
| U7602 | 5109522E16 | TC7W74FU |
| U7603 | 5109522E82 | NC7SB3157 |
| U7605 | 5186311J23 | mi |
| U7640 | 5109522E16 | NC7SZ126 |
| U7701 | 4889526L01 | bga |
| U7702 | 0 CSPEMI-306 | 4889526L01 |
| U7703 | 0 CSPEMI-306 | bga |
| U7704 | 0662057M50 | RES, 100 |
| U7705 | 2409154M66 | IDCTR, 18.0nH |
| VR800 | 5109522E82 | NC7SB3157 |
| VR3912 | 4809788E17 | EDZ68B |
| VR3914 | 4809788E17 | EDZ68B |
| VR5500 | 4809948D44 | EDZ68B |
| VS1001 | 4809948D44 | CSPESD304 |
| VS1002 | 4809948D44 | CSPESD304 |
| VS4200 | 4809788E06 | CSPESD304 |
| VS4201 | 4809788E06 | UDZTE-176.8B |
| VS4392 | 4809788E08 | UDZTE-176.8B |
| VS5000 | 4809788E08 | UDZTE-176.8B |
| VS5001 | 4813830C29 | MMSZ5246B |
| VS5002 | 4809788E06 | MMSZ5246B |
| VS5003 | 4809788E06 | UDZTE-176.8B |
| VS5004 | 4813830C29 | UDZTE-176.8B |
| VS5200 | 4809948D44 | MMSZ5246B |
| VS5400 | 4809948D44 | UDZTE-176.8B |
| VS5401 | 4809948D44 | UDZTE-176.8B |
| VS5402 | 4809948D44 | UDZTE-176.8B |
| VS7600 | 4809948D44 | UDZTE-176.8B |
| VS7602 | 4809948D44 | UDZTE-176.8B |
| VS7603 | 4809948D44 | UDZTE-176.8B |
| VS7604 | 4809948D44 | UDZTE-176.8B |
| VS7605 | 4809948D44 | UDZTE-176.8B |
| VS7601DNP | 4809948D44 | UDZTE-176.8B |
| VS7730 | 4809948D44 | UDZTE-176.8B |
| VS7731 | 4809948D44 | UDZTE-176.8B |
| Y130 | 4809718L14 | EDZ68B |
| Y500 | 4809612J43 | EDZ68B |
| Y2000 | 4809612J45 | EDZ68B |
| Y3982 | 4809995L13 | NT5032SA |
| Y6050 | 4885169E03 | XTAL |
| | | CX-91F |
| | | CC5V |
| | | TX2949 |