

SIXTY

QUICK START GUIDE



SAGEMCOM

Dear customer,

You have just acquired a new generation Sagemcom telephone and thank you for placing your confidence in us.

This device has been manufactured with the utmost care. If you should have difficulties in operating it, we recommend that you consult this quick start guide.

This product follows a strategy of continuous development. We reserve the right to make changes without notice, modifications and improvements to the products described in this quick start guide.

You can also find the user guide on the following site: <http://www.sagemcom.com/sixty>

To operate the device safely and easily, please read carefully the paragraph "Recommendations and safety instructions", page 3.



The CE label confirms that the product complies with the 1999/5/EC regulations of the European Union Parliament regarding wireless systems and telecommunications.

The declaration of compliance may be looked up on the www.sagemcom.com website section «support», or can be obtained from the following address :

Sagemcom Broadband SAS

250, route de l'Empereur - 92848 Rueil-Malmaison Cedex - France

Copyright © Sagemcom Broadband SAS
All rights reserved
Sagemcom is a registered trademark



RECOMMENDATIONS AND SAFETY INSTRUCTIONS



Do not install your DECT telephone in a damp environment, such as a bathroom, washroom, kitchen etc, and not within 1.50 metres of a source of water or outside. This device is designed for use in temperatures of between 5 °C and 45 °C.



Do not attempt to remove screws or open the appliance. It does not contain any user-replaceable parts.



Only use the power unit supplied and connect it to the electricity mains in accordance with the installation instructions in this user manual and the details on the sticker regarding voltage, electrical current and frequency. As a precaution if there is a risk of danger, the power plug can be pulled out to disconnect the 230 volt power supply. Therefore the sockets should be near the device and easily accessible.



This device is designed to be used for connecting to the public telephone network. If problems should arise, contact your nearest specialist dealer. Only use the telephone cable supplied.



For safety reasons, never put the handset in the base station without the battery inserted or without the lid on the battery compartment as this could cause an electric shock.

To avoid damaging your handset/base, only use certified rechargeable batteries NiMH 1.2 V 450 mAh, never use non rechargeable batteries. Insert the batteries in the handset/base battery compartment respecting polarity.



The used battery must be disposed of in line with the recycling regulations in this user manual.



Your DECT telephone has a range of approx. 50 metres indoors and up to 300 metres outdoors. The range can be affected by the proximity of metal objects, such as a television and electrical devices.

Zones without reception may appear owing to elements in the building. This can cause brief interruptions in the conversation, caused by faulty transmission.



Certain medical equipment and highly-sensitive machines or security systems may be affected by the transmission power of the telephone. In these cases we recommend adhering to the safety information.



In regions greatly affected by electrical storms we recommend that you protect your telephone circuit with a special fixture for excess voltage.



Your SIXTY has anti-skid pads that should leave no traces on your furniture and ensure stability. However, given the wide variety of finishes used by furniture manufacturers, traces may appear on surfaces in contact with the parts of your SIXTY. Sagemcom Broadband SAS decline all responsibility in any such cases of damage.

UNPACKING

Place the box in front of you, open it and make sure it contains the following items: one base SIXTY, one handset with its batteries, one telephone line cord, one equipped power adapter and this quick start guide.

PHONE DESCRIPTION

Your base



- Short press: find handsets (Paging)
- Press and hold : handset registration

* Keyway: indicates the position of the handset earpiece


** Press and hold the key ①:

- If the answering machine is turned off: access to voice messaging service.
- If the answering machine is turned on: access to your messages on the answering machine.



Indicator light operation:


- *Fast flashing: handset registration.*
- *Slow flashing: handset on line or new events.*

Make sure that when the handset is on the charger, the  icon is animated.

Your handset

SIXTY's particularity is that it has a wireless handset.

The single button on the handset allows the user to hang up or answer an incoming call. It should be noted that the handset is provided with a buzzer that sounds on receiving an incoming call with the handset not on its base.



The handset batteries are charged when the handset is placed on its base.

Control panel

Your SIXTY has a touch keys for access to configuration and settings functions. The screen tells you about the state (date and time, unread message, etc..).



Using the touch buttons


The screen includes six touch keys around its periphery. Simply touch the tactile area for the function to be taken into account:

Key	Function(s)
▲	Scroll up /Go to the menu list.
•	Context key 1: Access a menu / Validate the selection.
*	Asterisk key.

Key	Function(s)
▼	Browse down / Go to the menu list.
••	Context key 2: Delete an entry / Return to the previous menu.
#	# key.

Display screen

During use or on standby, the screen of your SIXTY tells you about the state of your telephone by showing icons, and in particular:



- * The low emission icon (ECO mode): Your telephone is provided with an automatic power management system. As soon as the handset is near its base, the power required is reduced to the minimum. Radio transmissions are also cut off when the handset is placed on the base, and the low emission icon is then displayed.




If a second handset is paired with the base, the "low emission" icon is no longer displayed.

PHONE INSTALLATION

CONNECTING THE BASE



Before making any connections, please refer to the safety instructions presented at the beginning of this quick start guide. Never force the plugs: they are in different shapes to avoid connection mistakes.



1. On the underside of the base, click the phone jack into its socket and connect the other end of the cord to the telephone wall outlet.
2. Connect the end of the power supply cord on the underside of the base and connect the power adapter to the mains socket. The phone display is turned on.
3. An information screen presents the current language used.
4. Select the language using ▲ and ▼ keys.
5. Press **Valid..**
6. An information screen asks you to choose the country where you will use your telephone.
7. Select the country using ▲ and ▼ keys.
8. Press **Valid..**



If you have made a mistake while choosing the language or the country, you have the possibility to change them later. In order to modify the language or the country, refer-to the user guide available on our web site: www.sagemcom.com/Sixty.

SETTING UP THE HANDSET

The batteries are already inserted in the handset. To put the handset into use, simply remove the tab by pulling on it firmly in the direction of the arrow.

The handset emits a double beep to indicate that it has started and then a second beep to indicate that the handset is synchronized with the base. From then on, your handset becomes operative and you can use it to make calls.



On leaving the factory, the handset is already registered in the base.


If your handset is not recognized by the base, refer-to the user guide available on our web site: www.sagemcom.com/Sixty.

You can now use your telephone to make and receive calls.

CHARGING BATTERIES

Place the handset on its base and fully charge the batteries.

An audio signal is emitted and a light flashes when the handset is placed correctly on the base.

The battery charge icon  is animated to indicate that the battery is being charged and stops to indicate that the batteries are fully charged.



The handset batteries charging time is 10 hours. During charging, the batteries may heat up. This is quite normal and perfectly safe.

NAVIGATING IN THE MENU

With your SIXTY you can create your own telephone directory, display the list of calls etc. To do this, use the touch keys.

With the touch keys **▲** and **▼** you can choose a menu, a sub-menu or a precise setting.


The key **●** allows you to enter the sub-menus of the chosen function and select the setting to modify. With the key **●●** you can return to the previous function or cancel the current choice.

The keys ***** and **#** are used when you use the answering machine.

See the menu structure to familiarise yourself with what your phone can do.

Menu structure

To access one of your phone's menus, use key **▲** or **▼**.



Browsing through the menus

Use the browsing keys ▲ or ▼ to select the desired menu. Press **Valid**. To confirm your selection.

Select the desired function by pressing the browsing keys ▲ or ▼ and then press the **Valid**. key.

- To return to the previous menu, press **Return**.
- To save the settings, press **Valid**.

Example:

To access the menu **SETTINGS /DATE/TIME**:

1. Use ▲ or ▼ to access the menu list.
2. Select **SETTINGS** using ▲ or ▼. Press **Valid**.
3. Select **DATE/TIME** using ▲ or ▼. Press **Valid**.

You are now under the DATE/TIME menu.



PHONE USE

CALLING




Receiving a call

- When a call is received, the phone rings.
- The caller's phone number is displayed on the screen if you have subscribed to the "Caller ID" service. The caller's name may also be displayed if it is included in your phonebook.

Accepting a call in handset mode




- Pick up the phone handset. You do not need to press the handset's button.
- Make sure to identify the handset direction by the dot which identifies the earpiece end. The call time counter is displayed on the screen.
- To end the call, hang up the handset or press the handset button.
- A visual and audible signal confirms that the handset is hung up correctly.
- If the handset is not on the base, you have to press the handset button to take the call.

Accepting a call in speakerphone mode

- Press  to speak in speakerphone mode (without holding the handset). The  symbol and the call time counter are displayed on the screen.
- To end the call, press  again.



Toggle between handset mode and speakerphone mode

- If you are in handset mode, press and hold the  key and then hang up the handset to toggle to speakerphone mode.
- If you are in speakerphone mode:
 - If the handset is hung up on the base, lift the phone handset to toggle to handset mode.
 - If the handset is not hung up on the base, press the dial tone button  to toggle to handset mode.
- To end the call, hang up the handset on the base or press .




Use the ▲ and ▼ keys to vary the earphone volume or speakerphone volume. The handset earphone volume or speakerphone volume can vary from 1 to 5.




Making a call

The call can be made in two ways:


Making a call in handset mode

- Pick up the handset.
- The icon  is displayed on the screen. Dial your number on the keypad. The call time counter is displayed on the screen.


Making a call in speakerphone mode

- Press  to obtain a dial tone prompt on the screen. Dial your number on the keypad. The  and  icons are displayed on the screen. The call time counter is displayed on the screen.





*You can also dial a number in pre-dialling mode, whether in handset or speakerphone mode: dial the number on the keypad and then lift the handset or press . If necessary, you can correct the number entered by pressing **BACK**.*

Ending a call



When you have finished your call, press  or hang up the handset on the base.

Hands-free/speakerphone mode


If you want to phone in speakerphone mode, do not lift the handset, but press the base  key; the  icon is displayed on your phone's screen.


The caller can then be heard through the loudspeaker and you speak into the base microphone.

To end the call, press the key again .

If you want to toggle to speakerphone mode during a call in handset mode, press the  key; the  icon is displayed on your phone's screen.

The caller can then be heard through the base loudspeaker and the handset earphone and you speak into the handset microphone. In this mode the base microphone is inactive.

You can return to speakerphone mode by holding down the  key and then replacing the handset.

To end the call, replace the handset or press the key .


ANSWERING MACHINE

Your phone's answering machine provides the following features:

- *Active answering machine mode with pre-recorded messages,*
- *Call filtering,*
- *Remote querying.*


ENABLING / DISABLING THE ANSWERING MACHINE

- Go to **ANS. MACH / ON/OFF**.
- Press **Valid..**
- A screen displays the current status of the answering machine (On or Off).
 - To keep the displayed status, press **Valid..**
 - To change the status, press **▲** or **▼**:
 - To activate the answering machine, select **ACTIVATE**.
 - To turn off the answering machine, select **OFF**.
 - Press **Valid..**
- **OK** is displayed on the screen.
- Press **Return** to go back to the previous menu.



PLAYING MESSAGES

If you have new messages (unread), these messages are read first. Afterwards, the messages that have already been taken are played back in chronological order (from the oldest messages to the most recent messages).

- Go to **ANS. MACH / MESSAGES / PLAY**.
- Press **Valid..**
- The messages are played through the loudspeaker.
- Depending on your service provider and your subscription, the name and number of your contact will be displayed on the screen (except for a confidential call).
- During playback, you can use the touch-sensitive keys to perform the following actions:
 - * : go back to the beginning of the message.
 - * x 2: return to the previous message.
 - # : go to the next message.
 - **Pause/PLAY** (context key 1): pause/resume playback.
 - **DELETE** (context key 2): delete the message being played.
 -  : exit playback of messages.

ENVIRONMENT

Environmental protection and sustainable development is an important priority for SAGEMCOM. SAGEMCOM has a policy of using environmentally- friendly systems and makes environmental protection an essential part of the life-cycle of its products – from the manufacturing, to the installation, operation and disposal.

PACKAGING



The logo (green point) on the packaging means that a fee is paid to an authorised national organisation to improve packaging recycling and the recycling infrastructure. Follow the local sorting regulations for this type of waste product in order to improve recycling.

BATTERIES AND RECHARGEABLE BATTERIES

If your product contains batteries or rechargeable batteries, these must be disposed of at designated collecting centers.

THE PRODUCT



The crossed out dustbin displayed on the product signifies that it belongs to the electrical and electronic equipment group. The European regulations request you to carry out your own selective recycling collection at:

- the sales outlet when you buy a similar new device.
- the collection points available in your area (recycling centres, sorting points, etc).

This means you participate in the recycling and valorisation of used electric and electronic goods which would otherwise have a negative impact on the environment and health.



GUARANTEE

TERMS AND CONDITIONS FOR UNITED KINGDOM & IRELAND ONLY

In order to apply the guarantee, you should contact the SAGEMCOM Helpdesk or the retailer where you purchased the equipment. Proof of purchase will be required in either case.

Please make sure that you use your equipment only for the purpose for which it was designed and under normal usage conditions.

SAGEMCOM do not accept any liability for the equipment if used outside the frame of its original designed purpose or any consequence that may arise from this usage.

Should any malfunction arise, the SAGEMCOM Helpdesk or your retailer will advise you how to proceed.

A) General Guarantee conditions

SAGEMCOM undertakes to remedy by repair or exchange at its own convenience, free of charge for labour and replacement parts, any defects in the equipment during the guarantee period of 12 (twelve) months or 3 (three) months for accessories, from the date of original invoice of the Equipment, where those defects are a result of faulty workmanship.

Unless the customer has concluded with SAGEMCOM a maintenance contract in respect of the equipment which specifically provides for repairs to be carried out at the customer's premises, the repairs will not be carried out on the equipment at the customer premises.

The customer must however return the defective equipment at his/her own expense, to the address supplied by the SAGEMCOM Helpdesk or by the retailer.

In the case that a product needs to be sent in for a repair, it must always be accompanied by a proof of purchase (which is not altered, written on or in any way made illegible) showing that the product is still under guarantee. In the case that no proof of purchase is enclosed, the SAGEMCOM repair centre will use the production date as its reference for establishing the guarantee status of the product.

Apart from all legal obligatory rules, SAGEMCOM, do not give any Guarantee, either implicit or explicit which is not set force in the present section, and can not be held responsible for any direct or indirect, material or immaterial damage, either in or out of the frame of the present guarantee.

If any provision of this guarantee shall be held to be in whole or in part invalid or illegal due to an obligatory rule applicable to consumers pursuant to their national legislation, such invalidity or illegality shall not impair or affect the remaining provisions or parts of this guarantee.

This guarantee does not affect the Customer statutory rights.

B) Exclusions From Guarantee

SAGEMCOM shall have no liability under the guarantee in respect of:

- Damage, defects, breakdown or malfunction due to one or more of the following:
 - Failure to properly follow the installation process and instructions for use
 - An external cause to the equipment (including but not limited to: lightning, fire, shock, vandalism, inappropriate conditions of electrical network or water damage of any nature)
 - Modifications made without the written approval of SAGEMCOM
 - Unsuitable operating conditions, particularly of temperature and humidity
 - Repair or maintenance of the equipment by persons not authorised by SAGEMCOM
- Wear and tear from normal daily use of the equipment and its accessories
- Damage due to insufficient or bad packaging of equipment when returned to SAGEMCOM
- Usage of new versions of software without the previous approval of SAGEMCOM
- Work on any equipment or software modified or added without the prior written consent of SAGEMCOM
- Malfunctions not resulting from the Equipment or from software installed in user workstations for the purpose of use of the equipment.

Communication problems related to an unsuitable environment including:

- Problems related to access and/or connection to the Internet such as interruptions by access networks or malfunction of the line used by the subscriber or his correspondent
- Transmission faults (for example poor geographical coverage by radio and TV transmitters, interference or poor line quality)
- Local network faults (wiring, servers, workstations) or the failure of the transmission network (such as but not limited to interferences, fault or poor quality of the network)
- Modification of the parameters of the cellular or broadcast network carried out after the sale of the Product
- Normal servicing (as defined in the user guide supplied with the equipment) as well as malfunctioning due to servicing not being carried out. Servicing costs are in any event always borne by the customer.
- Malfunctions resulting from the usage of products, consumables or accessories not compatible with the equipment.

C) Out of Guarantee Repairs

In the cases set forth in B) as well as after expiry of the guarantee period, the customer must ask the Authorised SAGEMCOM Repair Centre for a cost estimation prior to work being carried out.

In such cases, the repair and delivery costs will be invoiced to the customer.

The foregoing shall apply unless otherwise agreed in writing with the customer and only for the United Kingdom and Ireland.

TERMS AND CONDITIONS FOR OTHER COUNTRIES

If, despite our best efforts, your product presents any defects, you should refer to your retailer and present the proof of purchase that they gave you on the day of purchase.

Should any malfunctioning arise, the retailer will advise you what to do.

For the warranty to apply, you should ensure that the product was used in accordance with the instructions for use and the purpose for use, and that you have at your disposal the sales invoice or receipt stating the date of purchase, the name of the retailer, the reference and the serial number of the product.

No coverage shall be given under this warranty if the following conditions are applicable:

- The required documents have been modified or altered in order to take advantage of the warranty.
- The manufacturing numbers, product brands or labels have been altered or made illegible.
- Interventions on the product have been made by an unauthorized person.
- The product has been subjected to abnormal or improper use.
- The product has been damaged by external factors such as lightning, over-voltage, moisture, accidental damage, improper care as well as all Acts of God.

This present warranty does not affect the consumer rights that you may have under the laws in effect in your country.

Important:

Should you return the product to the after-sales department, please ensure that you return as well all the elements and accessories originally supplied with the product.

Note:



Note:





SIXTY by **SAGEMCOM**

Sagemcom Broadband SAS

250, route de l'Empereur - 92848 Rueil-Malmaison - France

Tél. +33(0)1 57 61 10 00 - Fax : +33(0)1 57 61 10 01

www.sagemcom.com

All rights reserved. Sagemcom Broadband SAS reserves the right to change the technical characteristics of its products and services or to stop marketing them at any time. The information and specifications included are subject to change without prior notice. Sagemcom Broadband SAS tries to ensure that all information in this document is correct, but does not accept liability for error or omission. Non contractual document. All trademarks are registered by their respective owners. Simplified joint stock company - Capital 35 703 000 € - 518 250 360 RCS Nanterre.