

# bel canto

**e.One™ series**



## USER'S GUIDE

# PRE3vB™

Two Channel Analog  
Pre-Amplifier

## TABLE OF CONTENTS

Safety Information	2
Certifications/Standards	3
Warranty	4
Unpacking	4
Power Connection	4
Setup and Placement	5
Design Features	5
Single Knob Control Functions and Display	6
Remote Control	7
Connecting the LNS1	8
Rear Panel Connections	9
Specifications	9
Declaration of Conformity	10

Copyright © 2012 Bel Canto Design Ltd.  
Bel Canto Design Limited  
221 North 1<sup>st</sup> Street  
Minneapolis, MN 55401  
United States

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of the publisher. The content of this manual is furnished for information use only, is subject to change without notice, and should not be construed as a commitment by Bel Canto Design Limited. Bel Canto Design Limited assumes no responsibility or liability for any errors or inaccuracies that may appear in this manual. Trademarks used in this publication: Bel Canto and the Bel Canto logo are registered trademarks of Bel Canto Design Limited. PRE3vB is a trademark of Bel Canto Design Limited. Bel Canto Design Limited disclaims any proprietary interest in trademarks and trade names other than its own. Printed in the United States.

# Important Safety Instructions

Explanation of symbols used in this manual or on the rear/underside of the apparatus:



The Lightning Flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product enclosure that may be of sufficient magnitude to constitute a risk of shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

- Read, keep and follow these instructions.
- Heed all warnings.
- Do not use the apparatus near water, ie near a bathtub, kitchen sink, laundry tub, in a wet basement, near a swimming pool etc.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the Manufacturer's instructions. Site the apparatus so that its location or position does not interfere with its proper ventilation. For example, the apparatus should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings, or placed in a built in installation such as a bookcase or cabinet that may impede the flow of air through the ventilation openings.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- Do not defeat the safety purpose of the polarized or grounding type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong is provided for your safety. If the provided plug does not fit into your outlet; consult an electrician for replacement of the obsolete outlet.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and at the point where they exit from the apparatus.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug has been damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Mains plug: Use the mains plug to disconnect the apparatus from the mains supply. The mains plug must be accessible at all times. Use the mains switch (if applicable) when the apparatus is not in use.
- Objects and liquid entry: Do not let objects or liquids fall into the apparatus. Do not expose the apparatus to dripping or splashing. Do not place a vessel containing liquid on top of the apparatus.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- The apparatus has been designed for use in moderate and tropical climates.

TO COMPLETELY DISCONNECT THIS APPARATUS FROM THE AC MAINS, DISCONNECT THE POWER SUPPLY CORD PLUG FROM THE AC RECEPTACLE.

THE MAINS PLUG OF THE POWER SUPPLY CORD SHALL REMAIN READILY ACCESSIBLE.

Disconnect supply cord before changing fuse. Refer servicing to qualified service personnel.

**WARNING:** TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE AND OBJECTS FILLED WITH LIQUIDS, SUCH AS VASES, SHOULD NOT BE PLACED ON THIS APPARATUS.

# In The U.K.

## Fuse replacement:

This appliance is fitted with a non-rewireable 10 amp mains plug. The plug contains a 10 amp fuse. If the fuse has blown it can be replaced as follows:

- a) Pull out the black fuse cover/carrier.
- b) Remove and dispose of the blown fuse.
- c) Fit a new 10 amp BS1362 approved fuse into the carrier and push the carrier back into the plug.

Always ensure the fuse cover is fitted. If the fuse cover is missing do not use the plug. Contact your Bel Canto retailer to obtain a replacement fuse cover. Fuses are for fire protection and do not protect against electric shock.



**WARNING: THIS APPLIANCE MUST BE GROUNDED.**

## FCC NOTICE

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does

cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### Green By Design

All Bel Canto products make use of compact and efficient design principles. Our products use less resources per unit to produce better performance than ever before. Everything from reduced packaging volume, to less weight in transport helps to reduce the overall environmental impact of bringing our products into the market.

Our products make very efficient use of electricity. Low energy usage and compact size ensure that the physical and environmental footprints of all Bel Canto products are minimized. Quality and performance play into this approach as all of our products are designed to remain vital and valid performers for many years. Should you want to upgrade to one of our new products, we even offer trade-in value for your old Bel Canto product to ensure that it is recycled in the most efficient and responsible manner.

### RoHS and WEEE

All of our current products are designed and produced to RoHS standards, ensuring that dangerous materials do not enter the waste stream. Lead free electronics assemblies and environmentally safe finishing and production methods are utilized to ensure that our products and processes are environmentally safe.

### Bel Canto Recycles

Bel Canto has always been a forward thinking company. In the same way that we are focused on the development of high-end audio products, we are also conscious of what we leave behind. For many years we have implemented environmentally sound measures to make the most efficient use of resources and keep our impact at a minimum.

We reuse or recycle more than 99% of the packing materials for our incoming parts shipments. Each year we divert massive amounts of cardboard, paper, plastic film, and Styrofoam from landfills. Our plastic and Styrofoam is delivered directly to local facilities that process it on site for use in their manufacturing. Steel, aluminum, and other metal waste products are delivered to local metal scrap yards for recycling back into the production stream.

We also participate in Waste Management's e-Cycling program. All electronic waste is processed in the US, with hazardous material being separated from non-hazardous, at ISO 9001 and ISO 14001 certified regional processing centers.

Our commitment to responsible production processes ensures that the absolute minimum of material used in the making of our products enters the waste stream.

## Warranty Information

Bel Canto products are automatically covered by a 90 day factory warranty that covers all internal parts and labor. Register online ([http://www.belcantodesign.com/Belcanto\\_Warranty.html](http://www.belcantodesign.com/Belcanto_Warranty.html)) within 30 days of purchase from an authorized dealer to automatically extend your warranty for 2 years starting from the date of purchase. If you do not have web access, please contact your dealer for assistance. Upon fully completing registration, within 5 business days you will receive an email that officially validates your warranty. Your information will be used for internal use only and will not be sold or released outside Bel Canto. Your comments and suggestions are appreciated and help us continually improve our products and services.

The warranty is only valid to the original owner and is non-transferable. Damage caused by unauthorized modification, abuse, or neglect of product will void your warranty. Any cost associated with return of product is the sole responsibility of the owner. All returns require a return authorization number issued after completing the RMA form in the support section of our website. If you have any questions, please feel free to contact us online at [info@belcantodesign.com](mailto:info@belcantodesign.com).

## Unpacking Your PRE3vB

PRE3vB box contents include the following:

- 1 (one) – PRE3vB Preamplifier
- 1 (one) – PRE3vB User's Guide
- 1 (one) – VB Power Cable
- 1 (one) – Remote Control

Carefully unpack each piece and check for shipping damage. If there is any damage, or if anything is missing, please contact your dealer, distributor or Bel Canto Design.

**IMPORTANT:** Save all packing materials as they are specially designed to protect the unit during transportation or shipping. If the packing becomes lost or damaged, please contact your dealer, distributor or Bel Canto before attempting to transport your unit.

## Power Connection

The power supply on the PRE3vB is preset for the proper power voltage. The power cable should have the correct plug for your local power system. If you believe this to not be true, please contact your dealer immediately.

This product, like any electrical component, can be dangerous and cause injury unless correct handling procedures are observed and used. Before powering this product, it is necessary to read and follow proper setup and procedures.



### **WARNING!**

Do not connect power to this product yet!

## Setup & Placement

Because the PRE3vB runs cool, it can be placed in many system locations without compromise. We do not recommend placing weights or other objects directly on the PRE3vB. This may scratch or mar the chassis finish. Do not use harsh chemicals when cleaning the outside of your PRE3vB.

Single Ended RCA and Balanced XLR connectors are available. XLR jacks allow balanced hookup using the standard North American pin configuration:

Pin 1 Ground  
Pin 2 Signal +  
Pin 3 Signal -



### **IMPORTANT!**

Make all connections before powering your unit!

## Design Features

The Bel Canto PRE3vB represents a powerful statement in high performance audio control preamplifiers. Its superb audio performance and transparency renders it a modern standard in control preamplifier design:

- All analog, low noise, low distortion architecture for controlling up to six (6) 2-channel inputs including 1 balanced input
- Fully balanced XLR outputs for optimum interface with the power amplifier
- 4-layer PC board design for superior signal routing, grounding and power supply routing
- Latest generation of low-noise, low-distortion high speed audio buffers, level controls and output drivers provide superb measured and subjective audio quality
- Independent digital and analog transformers with multi-stage power supplies for precise power to the sensitive analog circuitry
- Precision audio grade resistors and no capacitors in the audio signal path
- Ultra low noise second stage regulation for the analog amplifier sections
- Home Theater Bypass mode on Input 5
- Digitally controlled analog volume control for optimum signal architecture
- New Single-Knob user interface provides Simple, intuitive control function

### **CONDITIONING**

The sonic performance of the PRE3vB will begin to stabilize after 100 hours of continuous power up.

# Single Knob Control Functions & Display

## Front Panel Control Knob:

The control knob is a continuously rotating control with a push-switch function.

## Volume Control Mode:

The PRE3vB default operating mode allows you to change volume level by rotating the knob. The volume down function (counter-clockwise rotation) is very rapid and allows quick changes in the volume level. Volume up (clockwise rotation) functions rapidly up to a displayed volume level of 50.0. There is a pause at 50.0 until the display dims then the volume up function continues more slowly to a displayed value of 60.0 and then slower yet above 60.0. This operation makes it difficult to accidentally set a volume level that is too high.

## Input Selection Mode:

Pressing the control knob in briefly will toggle into the input selection mode. The selected input will be displayed for 5 seconds. During this time you can rotate the control knob to scroll to the desired input. Pressing the knob again will select the indicated input. The volume level will automatically ramp down and up during this selection process. If the control knob is not pressed for 5 seconds, the indicated input will automatically be selected and the PRE3vB will return to the default volume control mode.

## Home Theater Bypass Operation:

Input 5 can be set to a home theater bypass mode (htb) that is used to pass the front left/right outputs from a multichannel processor output through the PRE3vB to the main L/R power amplifiers. ***This mode must be used with a preamp output which has volume control function as the PRE3vB volume and mute controls will not function while the PRE3vB remains in the htb unity gain setting.*** When in the Input Selection Mode, Input 5 can be toggled between the normal operating mode (In 5) and the bypass mode for (htb5) by pressing the control knob 2 times. You will note that the Input display will toggle between htb5 and In 5. The display simply reads htb (home theater bypass) when the bypass mode is active.

## Pre In:

This is used to scroll through the inputs, when initially pressed it will indicate the currently selected input.

# Remote Control

The PRE3vB Remote Control has a comprehensive set of control features that are not available on the front panel.

To access **all PRE3vB control features** press the button marked **PRE** on the remote control. The Main CD controls will still operate in the DAC, PRE and Tuner modes.

**PGM:** Used for programmable functions.

**Display:** Toggles through display modes. When in OFF mode, the Display will come on momentarily when operating the front panel or remote control.

**Mute:** When in variable output mode this will toggle the analog outputs from Soft to Hard Mute and Un-muted modes. Soft mute is indicated by two decimal points in the far right of the display . . and Hard mute is indicated by 4 decimals on the display . . . .

**VOL>:** Increases the volume setting in Variable Output mode. This will Punch Through to any Bel Canto unit in Variable Output mode. The display will show the volume level while changing.

**<VOL:** Decreases the volume setting in Variable Output mode. This will Punch Through to any Bel Canto unit in Variable Output mode. The display will show the volume level while changing.

**CH/SCAN+:** This will toggle the input selection up in number and wrap around. Note that the first press of this control will show the active input selection.


**CH/SCAN-:** This will toggle the input selection down in number and wrap around. Note that the first press of this control will show the active input selection.

**Number Buttons:** These will directly select the inputs numbered from 1-5 and Balanced IN (6).






# Connecting The LNS1



- The PRE3vB must be powered by either the VBS1 or the LNS1. If using the VBS1, please refer to the VBS1 User's Guide for connectivity. If using the LNS1, please read the following
- The LNS1 is designed to power Bel Canto VB equipped products only. Use of any cable other than the supplied power interconnect may damage either the LNS1 or VB equipped unit and will void any warranty. Certain non-VB equipped units can be factory upgraded. To begin the upgrade process, fill out the RMA form in the Support Section of our website
- When connecting your VB unit to the LNS1, be careful to observe the alignment notches on both units power receptacles and the power interconnect cable
- When inserting the power interconnect cable, align the notch on the cable end and the alignment teeth on the outer sleeve to the 12 o'clock position. This will allow the interconnect cable to fully seat and ensure that the plug mates correctly with the power receptacle
- Once the power interconnect cable is fully seated in the receptacle, lock in the power interconnect cable by turning the outer sleeve clockwise one quarter turn. Proper seating of the LNS1 cable will ensure safe and secure operation of the LNS1 and all connected components
- The LNS1 has been designed to run on non-regulated, non-filtered AC Mains. Usage of any additional isolation or filtration from the AC Mains supply may compromise LNS1 performance

## Rear Panel Connections



- VB power interconnect jack to interface with either the VBS1 or LNS1 power supplies
- XLR Balanced line outputs
- XLR Balanced line inputs
- RCA Line out
- RCA Record out
- RCA Inputs

## Specifications

Bandwidth:	DC-200KHz
Volume setting for unity gain:	80.0
Signal to Noise Ratio @ 2 Volt RMS:	>105 dB A weighted, 20Hz-20kHz
Distortion @ 2 Volt RMS/1kHz:	<0.001%
Dynamic Range:	120 dB
Input overload:	10 V RMS
Output Impedance:	500 Ohms Single Ended, 200 Ohms Balanced
Input Impedance:	10K Ohms Single Ended, 20K Ohms Balanced
Maximum Gain:	20dB/10X
Maximum Output Level:	9.5 V RMS
Idle power draw:	<10 Watts
Power Requirements:	100-120 VAC 50-60 Hz or 220-240 VAC 50-60 Hz
Dimensions:	8.5" W x 12.5" D x 3.5" H (216 mm x 318 mm x 75 mm)
Weight:	10lbs. (4.5 kg)

# Declaration Of Conformity

**Application of Council Directive(s):**

2004/108/EC and 2006/95/EC, as amended

**Standard(s) to Which Conformity Is Declared:**

EN 55013:2001 + A1:2003 + A2:2006

EN 55020:2007

EN 61000-3-2:2006

EN 61000-3-3:1995 + A1:2001 + A2:2005

EN 60065:2002/A12:2011

**Manufacturer:**

Bel Canto Design, Ltd.

221 1<sup>st</sup> Street North

Minneapolis, MN 55401 USA

The equipment identified here conforms to the Directive(s) and Standard(s) specified above.

**Type of Equipment:** Audio Preamplifier

**Models:** PRE3vB

**Date:** January, 2012

**Bel Canto Design, Ltd.**

**221 1<sup>st</sup> Street North**

**Minneapolis, MN 55401 USA**

**Tel: 612-317-4550**

**Fax: 612-359-9358**

Bel Canto Design, LTD

221 First Street North, Suite 300  
Minneapolis, MN 55401

Phone : 612.317.4550 Fax : 612.359.9358

[www.belcantodesign.com](http://www.belcantodesign.com)

[info@belcantodesign.com](mailto:info@belcantodesign.com)

©2012 Bel Canto Design, LTD

e.One™ is a trademark of Bel Canto Design, LTD

version 3.0