

# **Installation & Operation Guide**

Version 10.5 Published: January 22, 2014





# **Table of Contents**

NOTICES	4
Trademarks	4
Copyright	
Contacting Support	
Chapter 1: Introduction	5
Overview	5
Features:	6
Broadcast-Quality Conversion	6
lo XT/4K Audio	7
AJA Software	7
System Requirements	7
What's In The Box?	7
In This Manual	8
Chanter 2. Installation	9
Installation Overview	<b>ر</b>
Connecting to your Computer	10
Cable Connections	10
Connector Descriptions	10
Installing to XT/AK Software	17
Macintosh Software Installation	12
Windows Software Installation	17
Re-Installation & Renair	17
Chantor 7: Anoration	
	•• 22
Using Io XT/4K with Professional Video /Audio Software	22
Using lo XT/4K with Professional Video /Audio Software	22
Using lo XT/4K with Professional Video /Audio Software	· · 22 23 23
Using lo XT/4K with Professional Video /Audio Software	· · 22 23 23 24
Using lo XT/4K with Professional Video /Audio Software	22 23 23 24 28
Using Io XT/4K with Professional Video /Audio Software	· · 22 23 23 24 28 28 28
Using lo XT/4K with Professional Video /Audio Software	22 23 23 24 28 28 30
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview . Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen. Format Screen . Input Select Screen .	22 23 23 24 28 28 30 33
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview . Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen. Format Screen . Input Select Screen . SDI Out Screen .	22 23 23 24 28 28 30 33 34
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen. Format Screen. Input Select Screen . SDI Out Screen . HDMI Screen . Angles Out Screen .	22 23 23 24 28 28 30 33 34 36
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview . Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen. Format Screen . Input Select Screen . SDI Out Screen . HDMI Screen . Analog Out Screen (lo XT Only).	22 23 23 24 28 30 33 34 36 37
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview . Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen . Format Screen . Input Select Screen . SDI Out Screen . HDMI Screen . Analog Out Screen (Io XT Only). Video Setup Screen .	22 23 23 24 28 30 33 34 36 37 38
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview . Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen. Format Screen . Input Select Screen . SDI Out Screen . HDMI Screen . Analog Out Screen (lo XT Only). Video Setup Screen (lo XT Only). Conversion Screen (Mac OS only).	22 23 23 24 28 30 33 34 36 37 38 39
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview . Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen. Format Screen . Input Select Screen . SDI Out Screen . HDMI Screen . Analog Out Screen (lo XT Only). Video Setup Screen (lo XT Only). Conversion Screen (Mac OS only). DS Kaure Screen	22 23 23 24 28 30 33 34 36 37 38 39 40
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview . Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen. Format Screen . Input Select Screen . SDI Out Screen . HDMI Screen . Analog Out Screen (lo XT Only). Video Setup Screen (lo XT Only). Conversion Screen (Mac OS only). DS Keyer Screen . Timecode Screen .	22 23 23 24 28 28 30 33 34 36 37 38 39 40 42
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview . Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen . Format Screen . Input Select Screen . SDI Out Screen . HDMI Screen . Analog Out Screen (lo XT Only). Video Setup Screen (lo XT Only). Conversion Screen (Mac OS only). DS Keyer Screen . Timecode Screen . Dresets Screen .	22 23 23 24 28 28 30 33 34 36 37 38 39 40 42 43
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview . Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen . Format Screen . Input Select Screen . SDI Out Screen . HDMI Screen . Analog Out Screen (lo XT Only). Video Setup Screen (lo XT Only). Video Setup Screen (lo XT Only). Conversion Screen (Mac OS only). DS Keyer Screen . Timecode Screen . Presets Screen . Eimwara Screen .	22 23 23 24 28 28 30 33 34 36 37 38 39 40 42 43 45
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview . Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen . Format Screen . Input Select Screen . SDI Out Screen . HDMI Screen . Analog Out Screen (lo XT Only). Video Setup Screen (lo XT Only). Video Setup Screen (Mac OS only). DS Keyer Screen . Timecode Screen . Presets Screen . Firmware Screen . Input Screen . Input Screen . Firmware Screen . Input Screen . Input Screen . Based Screen . Firmware Screen . Input Screen . Input Screen . State Screen . Sta	22 23 23 24 28 30 33 34 36 37 38 39 40 42 43 45 46
Using Io XT/4K with Professional Video /Audio Software. AJA Control Panel Overview. Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen. Format Screen. Input Select Screen SDI Out Screen . HDMI Screen . Analog Out Screen (Io XT Only). Video Setup Screen (Io XT Only). Video Setup Screen (Io XT Only). Conversion Screen (Mac OS only). DS Keyer Screen . Timecode Screen . Presets Screen . Firmware Screen . Info Screen .	22 22 23 23 23 23 23 23 23 23 30 30 30 30 30 30 31 36 37 38 39 40 42 43 45 46 47
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview . Single-user & Network Settings. Block Diagram Screen . Control Panel Operation. Control Screen . Format Screen . Input Select Screen . SDI Out Screen . HDMI Screen . Analog Out Screen (lo XT Only). Video Setup Screen (lo XT Only). Video Setup Screen . Audio Setup Screen (Mac OS only). DS Keyer Screen . Timecode Screen . Presets Screen . Firmware Screen . Info Screen . Using Io 4K for UHD/4K. Configuring Ouad SDI I/O	22 22 23 23 24 28 28 30 33 34 36 37 38 39 40 42 43 45 46 47 47 47
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview . Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen. Format Screen. Input Select Screen SDI Out Screen . HDMI Screen . Analog Out Screen (lo XT Only). Video Setup Screen (lo XT Only). Video Setup Screen (Mac OS only). DS Keyer Screen . Timecode Screen . Presets Screen . Firmware Screen . Info Screen . Using Io 4K for UHD/4K. Configuring Quad SDI I/O. Input Select Screen in 4K Mode	22 22 23 24 28 28 30 33 34 36 37 38 39 40 42 43 45 46 47 47 48 47
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview . Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen. Format Screen . Input Select Screen . SDI Out Screen . HDMI Screen . Analog Out Screen (lo XT Only). Video Setup Screen (lo XT Only). Video Setup Screen (Mac OS only). DS Keyer Screen . Timecode Screen . Presets Screen . Firmware Screen . Info Screen . Using lo 4K for UHD/4K. Configuring Quad SDI I/O Input Select Screen in 4K Mode. SDI Output Screen in 4K Mode.	22 23 23 24 28 28 30 33 34 36 37 38 39 40 42 43 45 46 47 47 48 49 49
Using lo XT/4K with Professional Video /Audio Software. AJA Control Panel Overview. Single-user & Network Settings. Block Diagram Screen. Control Panel Operation. Control Screen. Format Screen. Input Select Screen . SDI Out Screen . HDMI Screen . Analog Out Screen (lo XT Only). Video Setup Screen (lo XT Only). Video Setup Screen (lo XT Only). Conversion Screen (Mac OS only). DS Keyer Screen . Timecode Screen . Presets Screen . Firmware Screen . Info Screen . Info Screen . Using Io 4K for UHD/4K. Configuring Quad SDI I/O. Input Select Screen in 4K Mode . BDI Output Screen in 4K Mode . HDMI Screen in 4K Mode . HDMI Screen in 4K Mode . HDMI Screen in 4K Mode .	22 23 24 28 28 28 30 33 34 36 37 38 39 40 42 43 45 45 46 47 48 49 50 50

Video Setup Screen in 4K.       5         Downstream Keyer Screen in 4K Mode       5	51 51
Chapter 4: Troubleshooting	52
If You Run Into Problems	52
Updating Software	53
Support	53
Annendix A: Specifications 5	: <b>Л</b>
In XT Specifications	54
Video Formats	54
Video Input	54
Video Output Digital	54
Video Output Analog	54
Audio Input Digital	55
Audio Output Digital	55
Audio Output Analog	55
Downstream Keyer	55
Up-Conversion	55
Down-conversion5	55
Cross-conversion	55
SD to SD aspect ratio conversion5	55
Reference Input or LTC Input5	56
lo 4K Specifications5	56
Video Formats	56
Video Inputs5	56
Video Outputs	56
Audio Inputs Digital5	57
Audio Output Digital	57
Audio Output Analog	57
Downstream Keyer	57
4K to HD Down-Conversion	/כ 
Reference input or LTC input	/כ רק
Physical	)/ 57
	57
Appendix B: Safety and Compliance5	8
Federal Communications Commission (FCC) Compliance Notices	58
Class A Interference Statement	58
FCC Caution	58
Canadian ICES Statement	28c
European Union and European Free Trade Association (EFTA)	- 0
Regulatory Compliance	59 50
Verson Compliance Statement	39 60
Taiwan Compliance Statement	50
Jananoso Compliance Statement	50
Translated caution statements, warning conventions and warning messages	ר ג1
Refore operating your AIA unit, read the instructions in this document	51
warranty and Liability Information	19
Limited Warranty	59 70
	10
Index	1′

# **Chapter 1: Introduction**



#### **Overview**

AJA's lo XT and lo 4K provide professional-grade I/O for high-end computers. Io XT and 4K are the ideal companion for lightning-fast video capture, playback and up/down/ cross conversion. Designed for today's workflows, lo XT/4K provides a new interface for video Pro's working with 10-bit uncompressed, Apple ProRes 422, Apple ProRes 422 (HQ), XDCAM HD, DVCPRO HD, stereoscopic 3D workflows, and more. Io 4K provides additional support for Ultra HD (UHD) and 4K.

Io XT and Io 4K connect with a single Thunderbolt cable and provide a second Thunderbolt connector for storage, making them perfect for on set, or in the edit suite.

Based on the KONA 3G hardware, these lo products provide 3G/Dual-link/HD/SD-SDI, Component Analog, and HDMI connectivity.

lo XT's 10-bit hardware conversion capability paired with a Thunderbolt RAID System creates a super-fast editing system, portable enough to fit in a backpack—with desktop level power.

4K Workflows: Io 4K is the evolution of AJA's popular devices for professional video I/O, now updated and customized for Thunderbolt<sup>™</sup> 2 technology and 4K workflows. Io 4K connects to any Thunderbolt<sup>™</sup> 2-enabled device, and offers an additional Thunderbolt<sup>™</sup> 2 port for daisychaining other peripherals such as high-resolution displays and high-capacity storage.

Io 4K offers a broad range of video and audio connectivity, supporting the latest 4K and UltraHD devices. AJA's proven conversion technology allows realtime high-quality scaling of 4K and UltraHD to HD.

#### **Features:**

The following table provides a comparison of Io 4K and Io XT features.

#### Table 1. Io 4K/XT Feature Comparison

Feature	lo 4K	lo XT
Two Thunderbolt ports (supports pass-through/"daisy-chaining")	Х	Х
Supports Thunderbolt 2 connectivity	Х	-
Two SD-SDI, HD-SDI, and 3G HD-SDI inputs and outputs	Х	Х
Single link SDI 4:2:2 or 4:4:4; Dual-link SDI 4:4:4	Х	Х
Bidirectional SDI BNCs configurable for four 4K inputs or outputs	Х	-
HDMI Input and Output	Х	Х
Analog component/composite output, 10-bit		Х
Broadcast quality hardware-based 10-bit up-conversion		Х
Broadcast quality hardware-based 10-bit down-conversion		Х
Broadcast quality hardware-based 10-bit cross-conversion (1080 to 720 and 720 to1080)		Х
Dedicated realtime 4K to HD down-conversion output (SDI 5 BNC)	Х	
DVCProHD hardware scaling acceleration	Х	Х
HDV hardware scaling acceleration	Х	Х
Broadcast quality hardware-based 10-bit SD aspect ratio conversion (anamorphic to letterbox, etc.)	Х	Х
16-Channel Embedded SDI audio	Х	Х
Eight channels analog audio output (Tascam-style DB25-type cable)	Х	Х
Front panel LED VU meters and Headphone output w/level control	Х	Х
Reference In/LTC In (selectable)	Х	Х
LTC Output	Х	Х
RS-422 control via 9-pin	Х	Х
Rugged Chassis, Small Size	Х	Х
12V DC, 4-pin XLR Power (AC adapter included)	Х	Х

# Broadcast-Quality Conversion

lo XT features hardware-based full 10-bit broadcast quality motion adaptive SD to HD up-conversion, HD to SD down-conversion and HD to HD cross-conversion.

The quality of the conversion features found in the Io XT is virtually identical to AJA's award winning stand-alone converter products used throughout the post production market. The Io XT built-in up converter uses a a full 10-bit path, fully motion adaptive de-interlacing, and large multi-point digital interpolators. Down-conversion uses large multi-point digital interpolators, anti-alias filtering and interpolation.

Cross-conversion is high-quality hardware-based and offers true broadcast picture quality in realtime. Because these functions are in hardware, they are available full time, all the time—with no CPU load. Such conversions are useful for cost effective monitoring, making standard definition dubs of an HD project, or up-converting from a standard definition project to an HD deliverable.

Video Formats	For a complete list of supported video formats, see " <i>Appendix A: Specifications on page 54</i> ".
lo XT/4K Audio	lo XT and Io 4K provide up to 16 channels of SDI embedded audio. The front panels have a mini TRS headphone output with a lockable level control knob.
	For analog audio output monitoring, lo XT and 4K provide a DB25 connector with eight channels of audio to be used with industry standard Tascam-style audio breakout cables. The front panel has an eight-channel VU meter display to monitor output levels.
HDMI Audio:	Both Io XT and Io 4K also support HDMI Audio, 2 or 8 channels.
AJA Software	AJA's Io XT/4K software and hardware were developed for powerful integrated video/ audio capture, editing, and production with a variety of 3rd-party software. With an Io XT/4K and qualified Thunderbolt-enabled computer, you have the ultimate system for standard and high definition production, post-production, broadcast, and streaming work. AJA software is available for download at the AJA website.
	<ul> <li>AJA device drivers for tightly integrated hardware/software operation.</li> <li>AJA Control Panel for source selection and controlling lo XT/4K within either Mac or Windows environment, Input Pass through, and more. AJA Control Panel uses a block diagram to show visually what is happening inside lo XT/4K.</li> </ul>
	• AJA ControlRoom—a unified cross-platform software application for ingest, playback and output with AJA products.
	<ul> <li>AJA-provided plugins for popular 3rd-party Professional Video Applications from Adobe, Avid, Apple, Telestream, and more.</li> </ul>
NOTE:	For a complete software compatibility list, see the AJA website link:
	http://www.aja.com/en/category/edit/compatibility

#### **System Requirements**

NOTE: See the vendor of your system software for requirements/recommendations of GPU and additional hardware requirements.

For best performance AJA recommends:

- OS 10.7.5 or later
- Windows 7/8 with all updates
- 2.5GHz dual core i5 or better
- 2.0 GHz quad core i7 or better
- 4GB RAM Minimum, 8GB Recommended

As you unpack the shipping box(es), carefully examine the contents. Ensure you received everything and that nothing was damaged during shipment. If you find any damage, immediately notify the shipping service and supply them with a complete description of the damage. AJA will repair or replace damaged items. If you find shipping damage, contact your AJA dealer or distributor for details on how to have your Io XT/4K repaired or replaced. Save packing materials and the shipping box. If you ever require service or move your system—use the packaging materials and box for safe shipment.



Figure 1. Io XT/4K Shipping Box Contents (Io 4K shown)

When you unpack your AJA Io XT/4K, you'll find the following components:

- Io XT or Io 4K
- 12V power adapter and power cord
- Read Me First Notice—Contains late-breaking news and/or errata related to the product and it's documentation.
- Registration Sheet—allows you to register your Io XT/4K by mail or online (details provided).

#### **In This Manual**

- **Chapter 2** Provides complete instructions for installing and configuring the AJA lo XT/4K. The user is guided through unpacking, cabling the lo XT/4K, installing AJA & third-party support software, then getting it up and running. Important configuration information is also provided on video settings and use of genlock/external reference.
- **Chapter 3** Discusses operational aspects of lo XT/4K and how to work with 3rd-party software.
- **Chapter 4** Discusses troubleshooting problems with your system and what to do when there's a problem you can't solve.
- **Appendix A** Presents a list of technical specifications for the product.
- **Appendix B** Provides important Safety and Compliance information.

The balance of the book provides Warranty information and an Index.

# **Chapter 2: Installation**



#### **Installation Overview**

The installation and set up of an Io XT and Io 4K is very simple. A functional description of each connector is provided in this chapter. The steps of installation and configuration are outlined here and each of these steps are explained in greater detail on the remaining pages of this chapter:

- 1. If not previously installed on your Thunderbolt equipped computer, ensure that appropriate application software is installed as detailed in its user documentation.
- 2. For latest System Compatibility and Software Version information for Io XT or Io 4K visit the AJA website.

For lo XT, visit:

http://www.aja.com/en/products/io-xt/#/overview

For lo 4K visit:

www.aja.com/en/products/io-4k#overview

3. Install the latest AJA software on your computer from the AJA website. For Io XT, visit:

http://www.aja.com/en/products/io-xt/#support

For lo 4K visit:

www.aja.com/en/products/io-4k#support

4. First install the Io XT or Io 4K driver package (includes the AJA Control Panel) and then finally install any AJA plug-ins for 3rd-party software.

#### **Connecting to your Computer**

- 1. With your **computer off,** connect a Thunderbolt cable between the computer and the lo XT/4K.
- 2. Power the unit (AC supply or battery) and if it is Io XT, turn it on using the power button on the front. Io 4K does not have a power button.
- 3. Cable the system audio and video sources, VTR, audio monitor, and video monitor.
- 4. When you run the AJA Control Panel, you'll notice that the lo XT/4K is autodiscovered as long as it is properly cabled and powered up.
- 5. Please read "*Chapter 3: Operation on page 22*". (The latest version of the manual can be downloaded from the AJA support page provided above.)

#### **Cable Connections**

Io XT and Io 4K connections are made directly to the unit's rear connector plate. Both have a Tascam-style DB25 connector providing 8 audio output channels.

#### Figure 2. Io XT Connectors





Connector Descriptions	<ul> <li>The following section describes the connectors offered on the lo XT and lo 4K chassis in the following order:</li> <li>Connectors common to both models</li> <li>Io XT connectors</li> <li>Io 4K connectors</li> </ul>
Connectors Common to Both Models	
HDMI Input and Output:	Two HDMI connectors on the Io XT/4K provide input and output of HDMI video and multi-channel embedded audio.
	<ul> <li>Io XT has HDMI v1.3a capability at 30 bits per pixel allows full support of the latest 10- bit monitors.</li> </ul>
	<ul> <li>Io 4K has HDMI 1.4 capability, supporting Ultra HD and 4K resolutions at up to 30 frames per second.</li> </ul>
	<ul> <li>Both Io XT and Io 4K support 2 or 8 channel HDMI audio input and output.</li> </ul>
	HDCP is not supported on either input or output. Io XT/4K HDMI output does not have HDCP, and input sources having HDCP are not supported. The HDMI input is designed to support long cable runs—up to 100 ft. when using 22 or 24AWG HDMI cable, or up to 50 ft. using 28 or 30AWG HDMI cable. The HDMI output supports standard HDMI cables only.
RS422 Machine Control:	A female DE-9 connector on lo XT/4K provides connection for VTRs, camcorders, disk media servers, and other devices using RS422 SMPTE (Sony) protocol. (Connector pinout is listed in Appendix A, see <i>"Machine Control" on page 57</i> .)
Reference Video and LTC Input:	Two BNC connectors on Io XT/4K provide reference Input and Output. The Reference Video input can also be used for LTC input. The selection of Reference (sync) or LTC is set using the AJA Control Panel ( <i>"Input Select Screen" on page 33</i> ).
	In Video Pass-through mode, these connectors are effectively loop-through. Supplying reference signal to the Reference input allows you to synchronize lo XT/4K outputs to your house analog reference video signal (or black burst). If you have a sync generator or central piece of video equipment to use for synchronizing other video equipment in your studio, then connect its analog composite output here. When lo XT/4K outputs video, it uses this reference signal for locking. When connecting a reference video source, the locking signal should be the same format as the Primary format selected in the AJA Control Panel. It is possible in some circumstances to use an alternate format video signal as long as the basic frame rate is compatible.
Balanced Analog Audio Output:	A 25-pin DB connector provides 8-channel, 24-bit D/A analog audio, 48kHz sample rate, balanced via 8x XLR on DB-25 breakout cable. (Cable not supplied.)
12V Power Connector:	A standard 4-pin XLR type connector is provided for either battery or line source power using the supplied AC power adapter.
Io XT Connectors	These connectors are used only on the Io XT model.
Thunderbolt ports:	Two Thunderbolt ports are provided as describe in the figure above. These are first generation Thunderbolt connections.
HD/SD SDI Input and Output:	BNC connectors are provided on Io XT for two HD/SD-SDI inputs and two HD/SD-SDI outputs. The input and output support video and embedded 24-bit digital audio. Use SDI wherever possible for the best quality 10-bit uncompressed video input, capture and

	output. If peripheral equipment has a variety of inputs/outputs, look to see if it has SDI I/ O, and use it where possible. Most high-end professional broadcast equipment supports SDI (VTRs, cameras, media storage servers, etc.).
Component Video Output:	lo XT features a group of 3 BNC connectors for output of component, composite and Y/C functions. The signals are labeled on the BNC connectors on the rear panel of Io XT.
A Note About YPbPr:	Component Video, or YPbPr, has been given several names over time. YUV, Y/R-Y/B-Y, and YCbCr, are just some examples. Although these various formats have some differences in levels, they are all basically the same. Io XT uses the modern YPbPr terminology exclusively. Io XT supports three different types of YPbPr: SMPTE/EBU N10, Betacam (NTSC), and Betacam (NTSC Japan). These three formats differ in level only and are configured via the AJA Control Panel.
lo 4K Connectors	These connectors are offered only on the Io 4K model.
Thunderbolt 2:	The Io 4K provides the second-generation Thunderbolt ports to support UHD and 4K signals. Two ports are provided for "daisy-chained" network configurations.
Bi-directional SDI I/O:	Four bidirectional BNC connectors can be configured via the AJA Control Panel for: • HD/SD inputs (x2) and outputs (x2)
	<ul> <li>Or you can input or output 4 channels of video representing individual quadrants of the higher definition Ultra HD (3840x2160) and 4K (4096x2160) formats.</li> </ul>
NOTE:	The Io 4K can only be configured for either input or output of 4K at a time. It cannot support 4K input and output at the same time since both require four BNCs.
Dedicated SDI HD/SD Output:	One BNC connector is provided for full-time, real-time output of HD/SD video. 4K video is down-converted to 2K HD and UHD is down-converted to HD.

#### Installing Io XT/4K Software

Go to the AJA website and download the latest lo XT/4K driver software containing the
AJA Control Panel application. While there, also download any AJA plug-ins for 3rd-party
applications (such as Adobe and Avid). All of these software installers can be found here:
http://www.aja.com/en/support/downloads/

System software updates may occasionally become available to AJA lo XT/4K owners on our website (www.aja.com). We recommend checking occasionally for both software updates and additional product information.

NOTE: If your computer has previously had another video capture or multimedia device installed, ensure you uninstall any related software before installing to XT/4K This will prevent any hardware or software conflicts.

If you add Io XT/4K supported applications at a later date and have not previously installed the appropriate drivers, you must run the install program again selecting the appropriate application support software to be installed.

#### Macintosh Software Installation

NOTE: If you have trouble installing Io XT or Io 4K software, turn off any virus protection and security software that you may have installed on your computer and try again.

Mountain Lion OS and Gatekeeper: With the addition of Gatekeeper functionality in Mac OS Mountain Lion, you should go to System Preferences>Security & Privacy and choose to allow "*Mac App Store and identified developers*."

Figure 4. Mac Security & Privacy Gatekeeper Setting

00	Security & Privacy	
Show All		Q
	General FileVault Firewall P	rivacy
A login passwo	rd has been set for this user Change	Password
🗌 Require	password immediately : after sleep	o or screen saver begins
Show a r	nessage when the screen is locked	et Lock Message
Disable	automatic login	
Allow application	ans downloaded from:	
Mac Apr	Store	
Mac App	Store and identified developers	
Anywhe	re	

- 1. Locate the Io XT or Io 4K software downloaded from AJA.
- 2. Double-click the package to log on and begin software installation. Start by installing the lo XT/4K driver package with AJA Control Panel and then finally install any AJA plug-ins for 3rd-party software.
- NOTE: The system will respond by asking you to authenticate who you are as currently defined on your OS X user profile. Enter the proper name and password at the Authenticate prompt; if you have multiple users defined, ensure that you log on as a user with administrator-level authority.

#### Figure 5. Log On Authenticate Prompt

1	your password to allow this.
	Name: vid tech 1
	Password: ••••••

- 3. Click on the Install Software button after entering a valid user and password.
- 4. The installer will launch and you'll see a series of installer screens.

- 5. On the following pages, we show the series of screens you'll see when installing the lo XT/4K driver software package. The lo 4K installation uses a different package but is the same process.
- 6. When you launch the installer, you'll see a series of installer screens.

#### Figure 6. Initial Installer Screen



- 7. Click *Continue* to begin installation.
- 8. The next screen lets you know that the installer will check your Mac to ensure it has the hardware and software resources required (*"System Requirements" on page 7*).

#### Figure 7. System Check Installer Screen



9. Read and agree to the Software License Agreement.



Figure 8. Io XT/4K Software License Agreement Screen

10. At the next screen, select the "Io XT/4K Setups" checkbox. Check any Easy Setups that you want to use (or all of them) and then click the *Continue* button to place the software on the drive you previously selected. Some 3rd-party applications provide native setups so you can uncheck the "IoXT Setups" checkbox before clicking Continue.

	Custom Install on "Imac HD"		
<ul> <li>Introduction</li> <li>Read Me</li> <li>License</li> <li>Destination Select</li> <li>Installation Type</li> <li>Installation</li> <li>Summary</li> </ul>	Package Name ♥	Action Upgrade Upgrade	Size 100.1 MB 100.1 MB 30 KB 30 KB
VIDEO SYSTEMS Because it matters.	Space Required: 100.2 MB	Remaining: Go Back	518.27 GB

Figure 9. Installer Screen, Select Easy Setups to be Installed

11. The installer tells you how much room the installation will take and prompts you to click Install to begin (or go back). Click the *Install* button to proceed.

#### Figure 10. Installer Screen, Space Reminder

d Install on "Imac HD"
his will take 100.2 MB of space on your omputer. lick Install to perform a standard installation of his software for all users of this computer. All sers of this computer will be able to use this oftware.

12. Next, the system will display a reminder that you'll have to Restart the Mac after installation concludes. Click *Continue Installation*.

Figure 11. Installer Screen, Reminder about Restarting

000	😺 Install AJA Io4K Software 10.5	8
R	When this software finishes installing, you must restart your computer. Are you	Size
Introduct     Read Me     License     Destinati	Cancel Continue Installation	100.1 MB 30 KB
<ul> <li>Installation Type</li> <li>Installation</li> <li>Summary</li> </ul>		
	Space Required: 100.2 MB Remain	ing: 518.4 GB
lecause it matter	Standard Install Go Back	Install

13. The installer runs and puts all the necessary Io XT/4K drivers and software on the desired hard drive. When it has completed installation, a final screen will be displayed announcing that "software was successfully installed."

# Install A/A Io4K Software 10.5 Installation was completed successfully. Installation Select Installation Type Installation Summary VIDED SYSTEMS Recause it matters.

#### Figure 12. Installation Success and Restart Message

- 14. Click the Restart button to complete the installation procedure. The system will perform software restart.
- 15. After installing the lo XT or lo 4K system driver package, you will find the AJA Control Panel software installed in your applications.
- 16. Finally, install any AJA plug-ins required for 3rd-party software. You can download these from the AJA website:

#### http://www.aja.com/en/products/io-xt/#support

17. For example, if you wish to use the Io XT/4K with Adobe Premiere or Adobe After Effects, you would go the AJA website Io XT or Io 4K support page (URL above) and download the "AJA Adobe Plug-ins for Creative Cloud". These plug-ins come with complete documentation on how to use them.

#### Windows Software Installation

Locate the AJA Windows Software download file and follow the procedure below to install the required software on the host system.

NOTE: If you have trouble installing AJA Windows Software, turn off any virus protection and security software that you have installed on your computer and try again.

Open the AJA Windows Software download package.

## **Install Wizard** The AJA Windows Software installation program will launch and extract the necessary Io XT/4K drivers, AJA Control Panel Software, for installation on the desired hard drive.

NOTE: The Windows installation requires separate download and installation of application plugins for AVID, Adobe, Eyeon Fusion, and Telestream Wirecast plugins. (See the web-link above.)

Figure 13. Install Wizard Welcome



When you see the Welcome page, click "Next" to view the AJA Windows Software license agreement.

#### Figure 14. License Agreement

17	AJA Win Drivers 10.4.0-x64 Setup
-	End-User License Agreement Please read the following license agreement carefully VIDEO SYSTEMS
	AJA Video Systems KONA Software License
	Print Back Next Cancel

Read the Windows Software license agreement and click "Yes" to accept. You will be asked to choose the type of installation you would like to perform. Click on the Custom button to see the installation options.

The default selections include AJA Drivers for KONA cards, Io Express/XT/4K, and T-TAP. Software not installed is marked with a red X.

You may choose to perform a Custom installation to select the specific software necessary for your applications. If you use the entire collection, use the "Complete" installation.

NOTE: By default, AJA ASIO drivers are not installed. (If you will be using the Voice-over feature in Adobe Premiere Pro, you will need to click on the pulldown menu and include them in the installation. For more information on using ASIO drivers, refer to the AJA Adobe Plugins Installation and Operation Guide.

AJA Win Drivers 1	0.4.0-x64 Setup	x
etup way you want features to be instal	led.	15
AJA Drivers AJA Drivers Kona 3/LHi, IoExpress AJA ASIO Drivers AJA QuickTime 7.0 Codecs AVI Video For Windows	ASIO Drivers for Kona and Io products. This feature requires 0KB on your hard drive.	
Didutere	Browse	
	AJA Win Drivers 1 etup way you want features to be instal ons in the tree below to change the AJA Drivers AJA ASIO Drivers AJA ASIO Drivers AJA ASIO Drivers AJA QuickTime 7.0 Codecs AVI Video For Windows Disk Usage	AJA Win Drivers 10.4.0-x64 Setup

#### *Figure 15. Custom Installation Window*

The following screens depict the more elaborate Custom installation. Shown below are the pull-down options. Click (triangle) to expand or contract.

#### Figure 16. Installation Item Selection

-		AJA Win Drivers 1	0.4.0-x64 Set	tup	-
Custor Selec	m Setup t the way you	want features to be instal	ed.	V	
					VIDEO SYSTE
Click	the icons in the	tree below to change the	way features wil	ll be installed	i.
E	A)/A 	Orivers → Kona 3/LHi, IoExpress ASIO Drivers	ASIO Drive products.	ers for Kona	and Io
	💷 Wi	I be installed on local ha	ard drive		
	🗐 🖁 Ent	Entire feature will be installed on local hard drive			
	😰 Fea	Feature will be installed when required			
	× Ent	tire feature will be unava	ilable		
	-				_
					Browse
P	eset	Disk Usage	Back	Nevt	Cancel
I. I.	eset	Disk <u>U</u> sage	Dack	INCAL	Cancer

You may deselect any Item for installation by using the pulldown to make it unavailable.

Before clicking Next to install, you can verify your disk space availability by clicking the Disk Usage button.



AJA Win Drivers 10.4.0-x6	54 Setup	)
nents for the installation of the selected	features.	VIDEO SYSTEMS
not have enough disk space availa files from the highlighted volumes ves.	able for selected fea s, install fewer feat	atures. You ures, or select
Disk Size	Available	Required
231GB	176GB	164MB
931GB	164GB	ОКВ
		▶
	ments for the installation of the selected not have enough disk space availa files from the highlighted volumes ves. <u>Disk Size</u> 231GB 931GB	for the installation of the selected features. not have enough disk space available for selected features, files from the highlighted volumes, install fewer features. Disk Size Available 231GB 176GB 931GB 164GB

To return to the installation click OK. Then click Next to begin the installation.

Figure 18. Installation Progress Screen

1	AJA Win Drivers 10.4.0-x64 Setup
1	Installing AJA Win Drivers 10.4.0-x64
	Please wait while the Setup Wizard installs AJA Win Drivers 10.4.0-x64.
	Status:
	Back Naxt Cancel
5	Tank Tank

When the installer has completed copying the AJA Windows Software to disk, you will see a standard Windows Logo test warning. Click on the "Continue Anyway" button to finish the installation.

When the installation is completed, a final screen will be displayed announcing that "Setup has finished installing AJA Windows Software on your computer." Click on the Finish button after the installation is complete. Restart the computer after installation to activate the lo XT/4K.

# Re-Installation & Repair

If you have problems running your newly installed plugins or need to re-install for added applications, you can relaunch the install package and access the following window.

NOTE: Always uninstall AJA Windows Software before installing a new version.

Figure 19. Change, Repair, or Remove Installation Menu

17	AJA Win Drivers 10.4.0-x64 Setup	62
Chang Selec	t the operation you wish to perform.	
	Change Lets you change the way features are installed.	
.1	Repair Repairs errors in the most recent installation by fixing missing and corrupt	
	Remove	
	Removes AJA win Drivers 10.4.0-x64 from your computer.	
	Back Next Cancel	1

	The AJA Control Panel is a software application that provides a simple visual window showing how the lo XT/4K interface is currently configured, and that allows you to make changes. Settings—both those you changed and those you didn't—can be named and saved as a snapshot for recall at anytime. This lets you save settings associated with all your frequent tasks; then as you switch tasks you don't have to spend extra time resetting interface configurations—just load the previously saved settings for each task. If you work on multiple systems and want to carry your saved setup to another location, you can copy your saved Presets file on to movable storage and load it into any AJA-equipped system (see <i>"Presets Screen" on page 45</i> for more details).
Single-user &	The AJA Control Panel offers preference settings that support both:
Network Settings	• User Preferences— Preferences stored from the last Control Panel State to be used on next startup of AJA Control Panel.
	<ul> <li>Shared Preferences— Preferences saved by an Administrator for use as a default start state for AJA Control Panel.</li> </ul>
User Preferences:	This file exists to immediately, automatically, store preference changes made by a user on a particular AJA device. When any control is changed in the Control Panel, that change is recorded in the preferences file stored in a unique user preferences location dedicated to that particular device and serial number. Then, when AJA control panel is restarted for any reason, it will restart with the same preferences it used when it closed.
	However, if a user sets their preferences, and then replaces the AJA device with a different one, the Control Panel will either:
	<ul> <li>Start up with the factory defaults, or</li> </ul>
	<ul> <li>Start up with the "house defaults" dictated by the system administrator (if a Shared Preferences file exists).</li> </ul>
	The User Preferences File can be found in the following locations.
	On Mac: • /Users/ <user_name>/Library/Preferences/com.aja.devicesettings</user_name>
	On Windows 8:
	<ul> <li>C:\Users\<user_name>\AppData\Local\Aja\com.aja.devicesettings</user_name></li> </ul>
Shared Preferences:	An administrator can establish house standards for the AJA Control Panel by creating the user preferences file (described above) and placing it in a shared location where it will establish a standard default startup state for all users of a given computer system. These settings preempt the initial AJA default settings.
	To establish the <i>House Default</i> for every user on every system, a system or network administrator can move this default file to all systems on the network (manually or by pushing it out across the network). All users on the network will then open to the <i>House Defaults</i> when they launch the AJA control panel for the first time.
NOTE:	If the user makes changes to the control panel themselves, those changes will be saved in their user preferences, which will take priority over the house default dictated by the shared preferences file.
	The Shared Preferences file should be a file created at the User Preferences location described above, and placed by the System Administrator in the following locations.

#### On Mac:

//Users/Shared/Library/Preferences/com.aja.devicesettings

#### On Windows 8:

• C:\Users\All Users\Aja\com.aja.devicesettings

#### Block Diagram Screen

The AJA Control Panel represents a visual block diagram of the unit's configuration. The current status, input and output settings, and many other details are depicted in the color-coded block diagram.

The top area of the Control Panel is a visual representation of the processing, if any, that's currently occurring, including inputs/outputs, reference source, and system status. Lines between inputs, the framebuffer, and outputs, show a video path. Where there are no lines, there is no connection; this can be because an input or output isn't selected in the Input Select menu. The lines will also show whether the outputs are video or video + key.

Icon objects in the block diagram screen (input/output icons, frame buffer, etc.—indicate their status by color (described later). You can click any of the screen selection links in the left column to view its current settings or click on an icon to call up its related settings screen (for example, click an HDMI icon to call up the HDMI screen information). You can also right-click or Control-click to see context-sensitive information and choices. *Figure 20* & *Figure 21* show the IoXT and Io 4K Control screens.



#### Figure 20. AJA Control Panel, Block Diagram for IoXT



Figure 21. Io 4K, Block Diagram set for UHD Format

Framebuffer:

The framebuffer is the "memory" in lo XT/4K where your third-party applications interface with the hardware. The framebuffer has a format (called the "Primary Format" and color space that it follows, as defined in the linked menu screens or via external application software. It is important to realize that the computer can contain many applications that can use the lo XT/4K (as you switch from window to window) and it may not always be obvious which currently controls it.

#### Figure 22. Control Panel In Use Message (in red)



In the top right corner, the Control Panel displays the name of the application controlling the unit. In some cases, applications may not always properly "let go" of the I/O interface as another takes over—you'll be able to tell by looking at the Control Panel.

- *Color Meanings:* All items in the AJA Control Panel block diagram are color-coded to show what is happening in realtime. This applies to both icons and text. These colors have the following corresponding meanings:
  - Blue: video is same format as the Primary Format (framebuffer)
  - Red: the selected operation cannot be performed
  - Yellow: reference video (black burst or other reference source)
  - **Green:** indicates that Io XT/4K is performing an active change to the video making it different from the Primary Format (e.g., down-conversion).

# Primary & Secondary<br/>Video FormatsIn lo XT/4K operation, the Primary Format is the media format written to disk and used in<br/>your project. The Secondary Format is a selection for format conversion.

*Primary Format:* The video format currently assigned to lo XT/4K. This is the format that the framebuffer will use and is shown in the Control Panel using the color blue. It is the format that the third-party application software will either receive from the AJA hardware, or is giving to the hardware. All icons in blue are the same as the Primary Format used by the framebuffer. Also any text descriptions in the block diagram that appear in blue indicate that something is in the primary format. For example:

- If the input and output icons are blue, you know that the same format is used throughout the video path. No format conversion is being performed.
- If the input or output icon colors differ (blue input and green output icons for example), you know that a format conversion is being performed.
- Secondary Format: Any format other than the currently selected Primary Format, is a secondary format. As described previously, this means that either the Inputs or Outputs are somehow different from the framebuffer's assigned format—the Primary Format. A conversion is readily apparent because of the color change from blue. In the example below, a secondary format of 720p59.94 is selected on the Format screen and is then used for output at SDI 2.



#### Figure 23. Setting the Secondary Input Format

lo XT/4K v10.5

www.aja.com

- NOTE: In some cases the application you use with the Io XT/4K will automatically set the Primary Format, overriding the user's selected primary format in the AJA Control Panel.
- *Format Conversion:* Conversion allows selection of a format conversion between High-definition and Standard-definition. The choices offered depend on the AJA device present in your system and the Primary and Secondary format selected. Io XT supports up-, down-, and cross- conversion plus SD-to-SD aspect ratio conversions.

Conversion is performed based upon the Primary or Secondary Format settings. Io XT/4K can down-convert the input format (when designated as a Secondary Format) to the selected Primary Format. Or you can assign a Secondary Format for output that will be a conversion from the Primary (frame buffer) format.

- NOTE: When converting an Input to the Primary Format, select the Secondary Format option that has (I), for input only, appended to it. Conversely, when converting an Output from the Primary Format, you must select an output signal with (O) for output only.
- *Input/Output Icons:* The input and output icons are triangles that together with their color show all the input and outputs and their status (selected, not selected, input present or not, format, etc.). A complete video path is shown when inputs and outputs are connected with lines going to/from the framebuffer.

#### Figure 24. Input/Output Icon



*Conversion lcons:* When an input or output is a different standard than the framebuffer, the lo XT/4K may be up- down- or cross-converting the signal to the selected standard. This may be automatic, because it's detected an input signal that differs from the standard currently selected, or because you've explicitly told it to convert. In either case, the block diagram will show the conversion by displaying a conversion icon in between the input/output and the framebuffer.

#### Figure 25. Up, Down, and Cross-convert Icons



*Control Panel Screens:* The side area of the Io XT/4K Control Panel provides different information categorized by topics. Clicking on a topic—or a block diagram element—displays an information screen corresponding to that topic. Screens that can be selected are:

Control: configures lo XT/4K operation and output timing.
Format: select the framebuffer primary video format and any secondary formats for conversion of inputs/outputs
Input Select: view and edit input selections and how they are mapped
SDI Out: select output format
HDMI: configure the HDMI I/O
Analog Out: configure the component/composite analog output
Video Setup: configures Video such as composite black level and filtering specific video parameters for output.
Audio Setup: (Io XT only) configures Audio options such as analog audio monitor level.
Conversion: (available for Mac only) for applications that support selection of codec

options such as whether paused video appears as a full frame or a single field (jitter shown or not shown) and 24 to 30 fps padding patterns, RGB range, and Stereo 3D signal configuration (if applicable).

**DS Keyer:** setup and control the insertion of keyed video from the frame buffer or graphics files with alpha channel.

**Presets:** add or delete saved preset configurations (handy for setting up the lo XT/4K for certain workflows and then saving it as a canned configuration for easy later recall)

*Firmware:* enables installation of AJA card firmware.

*Info:* displays status information and firmware version # of the Io XT/4K and how it is installed in the host Macintosh. This information is generally intended for troubleshooting/support.

#### **Control Panel Operation**

In this section, Control Panel operation for Io 4K using Ultra-HD and 4K formats are described separately (see *"Configuring Quad SDI I/O" on page 48*). Standard SD, HD, and 2K operations are essentially the same for both Io XT and Io 4K and are illustrated using Io XT screen shots (exceptions are noted).

#### **Control Screen**

The lo XT/4K can be controlled by various software applications running on a host Mac. The Control screen is where you select how the lo XT/4K directs video and is used by application software. This screen also provides control for configuring output timing with regard to external reference video and horizontal/vertical delay.

At the top of the Control screen it will show the current Default Output and the application currently controlling the Io XT/4K.



Figure 26. AJA Control Panel, Control Screen

#### **Control Screen Settings**

**Default Output**—this is where you select what lo XT/4K will output as a default when no application has control of the board, such as when the Finder is active. Since lo XT/4K can be controlled by software applications as well as its own control panel, the output can change dynamically. When you select many video applications, they will grab control of the lo XT/4K inputs/outputs. These settings determine what happens when an application that doesn't grab the lo XT/4K inputs/outputs is active.

Default Output Choices and their meanings:

- *Input Pass through:* this selection directs Io XT/4K to route video from its selected input through the card for processing and output. When this selection is in effect, all Primary/Secondary Format selections are available for selection in controlling the output. This, in effect, makes the Io XT a converter when used in conjunction with the AJA Control Panel application and your computer. No applications other than the AJA Control Panel need to be open to convert audio and video from one format to another. For example, if an SD source tape needs to be dubbed to an HD tape, the signal might be routed from the SD VTR to the Io XT, configured for up-conversion in the AJA Control Panel and then passed through to the HD VTR for recording.
- NOTE: See "Configuring Quad SDI I/O" on page 48 for using this menu to input UHD/4K formats.
  - **Test** *Pattern***:** this selection directs lo XT to output a choice of preset pattern when no other application is using the lo XT. You can choose from:

Black, Color bars (75% or 100%), Ramp, Multiburst, Line Sweep, Multi Pattern, or Flat Field.

In addition to the preset test pattern choices, a "Load File..." selection at the bottom of the menu allows you to load any standard RGB graphics file (.tif,.psd, etc.) into the frame buffer for display.

While in Test Pattern mode, you can select RGB or YUV output via a pulldown menu.

NOTE: The graphic file will not be scaled to fit. If it's smaller than the current frame buffer format, Io XT/4K will center it in the frame. If it's larger than the current frame buffer format, it will be cropped on the right and bottom. Also some graphics formats and bit depths may not be supported. Once a graphic file is loaded into the frame buffer it will be retained until it is overwritten by another graphic or test pattern, or when power is turned off. Graphic file names are only "remembered" in the menu as long as the AJA Control Panel application is running.

**Hold Last Application:** this selection directs Io XT/4K to hold and output the last frame of video from the last application to control Io XT/4K. This can be helpful when operating in an environment where you're switching back and forth between multiple application windows.

Playback Timing: Use these controls to set Genlock and Timing adjustment.

Genlock (Freerun, Ref In, Video In)—selects how Io XT/4K will synchronize program video:

- *Freerun:* In this mode, Io XT/4K generates sync without an external reference source
- **Ref In:** Directs lo XT/4K to use the Ref Video source for sync (usually an analog black burst video signal)
- *Video In:* Directs lo XT/4K to use whichever video input source has been selected in the Inputs screen for sync

Timing (*Horiz* and *Vert*)—these two pull-downs allow output timing adjustment with reference to the Ref Video source selected. The Horizontal reference can be adjusted by selecting a number of pixels (clocks) to offset. Vertical can be adjusted by specifying a number of lines to offset.

#### Format Screen

The Formats screen shows the video format currently in use by the Io XT/4K framebuffer (called the *Primary Format*) and allows you to change it. All throughout the Control Panel, choices are always presented based on what Io XT/4K can do with the signals available and the inputs/outputs selected. For example, on the Format screen, if the output or inputs are a different format than the primary, then you'll see an additional information pane that allows you to view and edit the secondary format—including control over whether up/down/cross conversion is employed.



#### Figure 27. AJA Control Panel, Formats Screen

#### **Format Screen Settings**

Video Format (Primary and Secondary): These pull-down menus show the currently selected formats. If you select an alternate value in the Primary Format using the pull-down, it will change the format used by Io XT's framebuffer. When a change is made via the Video Format pull-down or by right-clicking or Control-clicking an icon and selecting a new format via a contextual menu, the block diagram will change to reflect the new format. In the case of a Secondary Format, the formats available can vary based on what the Primary Format is and the input signal (frame rates of input sources limits the to/from conversion choices). The "Secondary

Video Format" pull-down menu lists all compatible formats for selection (incompatible formats are not shown). This allows you to see what you've chosen, and also see those formats that are compatible with the selected Primary format.

For a complete list of Io XT/4K Formats see "Appendix A: Specifications on page 54".

- NOTE: The AJA Control Panel software uses the abbreviation "sf" instead of "psf" when referring to "progressive segmented frame" formats. In the manual and in other literature you may see either of these acronyms used interchangeably. Visually it is easier to discern at a glance if you are working with progressively segmented frame formats (sf in the AJA Control Panel) as compared to progressive frame formats which will show only "p."
- Pixel Format: Use this pulldown menu in Io 4K to choose: YUV-10, YUV-8, RGB-10, or ARGB-8
- *RGB Range:* The *RGB Range* pulldown menu allows you to select either Full range (0-1023) or SMPTE range (typically 64-940) for RGB color output.
- VANC Checkbox: When checked ON, the VANC checkbox tells the lo XT/4K to capture and process any ancillary data in the SDI stream. This can include Closed Captioning data, and other types of metadata. Applications such as Premiere Pro and Final Cut Pro will not capture or output this data through the lo XT/4K, if this box is not checked on.
- *Io XT Cross-conversion:* If you have an HD format as your primary and then select a secondary HD format with a different frame size, the Io XT will perform a cross-conversion where necessary (input or output) for *"like Hz"* formats. *"Like Hz"* means that 720P 59.94 may be converted to 1080i 29.97 (59.94Hz). Converting from disparate Hz is not supported on the Io XT for cross-conversions. The example below shows 1080i to 720p.
- *Io XT Up (Conversion):* The *Up* and *Down* pull-down menus are available when conversion has been selected for the video path to/from the framebuffer and like Hz formats are selected (the one exception is 1080PsF 23.98 which can be down-converted to 525i 29.97.) Different choices will be available depending on the type of conversion and formats being converted. SD to SD conversions are essentially aspect ratio conversions to accommodate transforming anamorphic images to letterbox or vice versa.

For up-conversion the following choices are available:

Anamorphic: full-screen "stretched" image

Pillar box 4:3: results in a 4:3 image in center of screen with black sidebars

*Zoom 14:9:* results in a 4:3 image zoomed slightly to fill a 14:9 image with black sidebars

Zoom Letterbox: results in image zoomed to fill full screen

**Zoom Wide:** results in a combination of zoom and horizontal stretch to fill a 16:9 screen; this setting can introduce a small aspect ratio change

- Io XT Down (Conversion): For down-conversion the following choices are available:
   Letterbox: image is reduced with black top and bottom added to image area with
   the aspect ratio preserved
   Crop: image is cropped to fit new screen size
   Anamorphic: full-screen "stretched" image
  - Io XT SD to SD: This pulldown is for SD to SD aspect ratio conversion.
     Letterbox: this transforms SD anamorphic material to a letterboxed image.
     H Crop: will produce a horizontally stretched effect on the image; transforms anamorphic SD to full frame SD

**Pillarbox:** will produce an image in the center of the screen with black borders on the left and right sides and an anamorphized image in the center

V Crop: will transform SD letterbox material to an anamorphic image

4K to HD Down-conversion: The Io 4K provides a dedicated SDI Monitor BNC that outputs a quarter-size image of a selected UHD/4K signal format. For details, see *"Using Io 4K for UHD/4K" on page 47*.



Figure 28. AJA Control Panel, Formats Screen, Example shows to XT cross-conversion

#### **Input Select Screen**

On the Inputs screen you can view the currently selected video and audio input sources and map audio sources to the channels supported by your editing application. Two information panes in the screen are provided: Video Input and Audio Input.

Figure 29. AJA Control Panel, Inputs Screen



#### **Input Select Settings**

Video Input:	The pulldown menu allows you to see and change what's currently selected and shows the video format that Io XT has detected (if any). The figure above shows that video is selected at the HDMI input and the format is 1080i with a frame rate of 29.97. Since this text is blue, you can tell that it matches the framebuffer's primary format selected in the "Format" screen. By looking at the input source, you can determine how the primary format should be set (unless you want to perform a conversion on the input.) If you wish to select a different input use the pulldown to select either SDI 1, 2 or Dual Link for two- wire 4:4:4 RGB, or Stereo 3D. For 3G single-link, choose the SDI Source used and select Stereo 3D from the SDI pulldown menu.
--------------	---

Use the LTC/Ref menu pulldown next to Video Input to select how the LTC BNC is used: selecting Reference means it's used a Reference standard; selecting LTC means it's used for linear time code (LTC) input.

- *System Genlock:* For video stability and proper system operation, you can genlock all equipment to house sync, however genlock is not required for lo XT/4K due to excellent freerun accuracy. To connect genlock, use a black burst generator output looped through the system. On the lo XT/4K house sync is connected to "LTC/Ref In".
  - NOTE: Be sure to set the Reference/LTC connection to Reference in the pulldown menu in the Video Input pane.

- Audio Input: This pulldown menu allows you to pick where the audio comes from. Io XT/4K supports up to 16 channels of embedded audio. Here you can also select which two channels from the 16 embedded would be mapped to your editing application if only two channels were selected in that application.
- **SDI Out Screen** The SDI Out screen shows the current settings for the SDI outputs. Because the outputs can be configured independently, one output may be the Primary format and the other output may be the Secondary format. If an input/output has no video, it will be indicated on the block diagram ("No Video").
  - **3D Stereoscopic Workflow** Through SDI, you can output Discrete Left and Right Eye feeds with a simple Stereo button choice in the AJA Control Panel. Additionally, muxed stereo output is possible using a single SDI output. AJA hardware and software works in close collaboration with CineForm's Neo3D software tools and CineForm codec to allow stereoscopic editorial and viewing when working with professional quality video editing applications.
    - NOTE: This feature works within applications that support the CineForm video delivery method.
  - **SDI Output 1 and 2** Configure SDI Out 1 and 2 via pulldowns:



#### Figure 30. AJA Control Panel, SDI Output Screen

#### **SDI Output Options**

- *Primary:* When selected, this indicates that the SDI output is set to the same format as the framebuffer. That value will be listed in blue.
- Secondary: When selected, this indicates that the SDI output is set to a format different from the framebuffer (Primary Format). That secondary format value will be listed in green. This shows that active processing of the video is taking place (format change and possibly even up/down-conversion).
- *Video+Key:* When selected, this indicates that the SDI 1 Output video is set to the same format as the framebuffer. SDI 2 Output is set to a video key signal associated with SDI 1 (the shape to be cut out from the video this will appear as a black and white image/matte). Using the second Io XT output as an Alpha Channel key, with the video output, may be useful for feeding production switchers, DVEs or other professional video equipment.

Figure 31. SDI Outputs Set for Video +Key



*Stereo:* When selected, this indicates that SDI 1 represents the left eye output and SDI 2 represents the right eye output of stereoscopic material. Io XT also offers single link 3Gb output of multiplexed Stereo 3D.

#### **Dual Stream Options**

Dual Link: Output (SMPTE 372M) using SDI 1 and SDI 1 in concert.

*3Gb:* Output (SMPTE 424M) using a single-link transport.

- *RGB SMPTE:* When selected, sets the output to RGB SMPTE range video for the SDI output.
  - *RGB Full:* When selected, sets the output to RGB full range video for the SDI output.

#### **HDMI Screen**

The lo XT/ 4K HDMI input and output are configured at this screen. For lo 4K UHD and 4K format setup, see "HDMI Screen in 4K Mode" on page 50.

#### Figure 32. AJA Io XT HDMI, HDMI Screen

000			IoXT	AJA ControlPa	nel		
Control Format Input Select SDI Out	1080129.97 SDI In 1	_		1080i29.97 YUV-10			29.97 Out 1
HDMI Analog Out Video Setup Audio Setup Conversion DS Keyer Timecode Presets Firmware	1080i29,97 SDI In 2 No Video HDMI In No Video Ref In	Genlock: Free	trun	Frame Buffer		1080 SDI 0 HDM1 Auto 1080 Analo Comp	29.97 Out 2 29.97 3D-SS Detect 29.97 og Out SMPTE
Info	HDMI Output	Primary		1080/29.97	Protocol	HDMI	
	Stereo 3D	Side by Side			Color Space	Auto Detect	
	Audio Ch	8 Channels			RGB Range	SMPTE	
	HDMI Input						

# HDMI Output Settings The Source pulldown menu allows you to select either the primary video format (framebuffer) or (if conversion is supported) a secondary one (up/down/cross-conversion). Pulldowns are also provided for configuring the video output range, color space and number of embedded audio channels (2 or 8) for the HDMI output. A Protocol pulldown allows you to choose either "HDMI" or "DVI" protocol—use DVI if you're outputting to a DVI monitor using an HDMI to DVI adapter. A pulldown menu for 3D output allows you to select either Side-by-Side or Top-Bottom (Stacked) output of left-eye and right-eye signals.

- NOTE: This selection must agree with format selection in the third-party CineForm Codec (**NOT** included with AJA Io XT) pulldown menu.
- *Audio Channels:* An Audio Channel pulldown allows you to select the number of embedded audio channels for the HDMI output.

# **HDMI Input Settings** The detected HDMI input video format is displayed and you're given a chance to configure the RGB range (SMPTE or FULL) and select any two embedded channel pairs from those supplied for stereo output (if applicable).

#### Analog Out Screen (Io XT Only)

Io XT provides a high-quality analog component or composite + Y/C output, generally used for monitoring. This screen shows the current settings for that analog output, and allows you to re-configure it when desired.

Figure 33. AJA Control Panel, Analog Out Screen



#### Analog Out Screen Settings

SettingsAnalog Output:Select Primary or Secondary (any conversion applied) for the analog output; if a<br/>conversion is applied, you'll see the conversion icon appear on the block diagram. Next,<br/>select the video format from the Format pulldown.Analog formats can be:<br/>Composite +Y/C (one composite output and a simultaneous Y/C [S-Video] output)<br/>Component (SMPTE/EBU N10)<br/>Component (Beta)<br/>Component (RGB)Audio Monitor:Here you select which two channels will be mapped to the analog audio stereo output<br/>(headphone jack).

#### **Video Setup Screen**

lo XT provides standard setup adjustments for analog component or composite output. This screen shows the current settings for that analog video output, and allows you to reconfigure it when desired.



#### Figure 34. AJA Control Panel, Video Setup Screen

#### **Setup Screen Settings**

Analog Black Level (in lo XT only):	<ul> <li>Choices available for Black Level are the two Composite analog formats. Choices presented are for US or Japan:</li> <li>7.5 IRE (NTSC US)</li> <li>0 IRE (NTSC Japan)</li> </ul>
Progressive Formats:	Radio buttons allow you to choose between <i>psf</i> (progressive segmented frames) and <i>p</i> (progressive frames) non-interlaced output.
QuickTime Video Output Filter (available on Mac OS only):	The QuickTime Video Output Display Filter is designed to help manage the comprehensive list of video outputs that may be available to applications.
	By selecting the checkbox next to specified parameters, the video outputs related to these specified parameters are enabled as possible video outputs for applications. For example, if the checkbox next to 25/50 is unchecked, 50Hz video outputs are deselected and would not be available to the user's editing application. To avoid confusion when working in a particular editorial environment, you might choose to leave 50Hz unchecked if working solely in a 60Hz editorial environment. The same might be true if you do not intend to work with true progressive 1080 material.

#### Audio Setup Screen (Io XT Only)

This screen shows the current settings for the analog audio output, allowing you to reconfigure it when desired.

000		lo	XT AJA ControlPanel		
Control	IoXT - 0	÷	1080/29.97		
Format Input Select SDI Out	1080i29.97 SDI In 1		YUV-10	-	1080i29.97 SDI Out 1
HDMI Analog Out	No Video SDI In 2	>		->	1080i29.97 SDI Out 2
Video Setup Audio Setup	No Video HDMI In			-	1080i29.97 HDMI 3D-TB Auto Detect
DS Keyer Timecode	00:00:00:00 LTC In	Genlock: Freen			1080i29.97 Analog Out Comp SMPTE
Presets			Frame Buffer		
Firmware Info	Audio Setup		Audio Setup		
	🗹 Lock Audio	Gain to Unity	Analog Monitor Level	+24 dBu FSD	÷

#### Figure 35. AJA Control Panel, Audio Setup Screen

#### **Audio Setup Screen Settings**

Lock Audio Gain To Unity: When set, the lo XT will ignore the third-party application's gain setting and set the audio gain at unity. When not set, this checkbox tells the lo XT to get the audio gain setting from the editing application (if supported).

Analog Audio Monitor Level: This selection determines the audio level that will appear at the analog audio outputs ("FSD" is full-scale-deflection reading as measured on a VU meter). Select +18 for Europe or +24 for USA.

#### Conversion Screen (Mac OS only)

This screen offers controls that determine how the card behaves with 3rd-party applications.

NOTE: This screen is present in the Mac version of AJA Control Panel only and not all applications support these functions.



Figure 36. AJA Control Panel, Conversion Screen

*Pause On:* These two choices determine what happens when the editing application is paused in stop mode:

Full Frame: both fields are displayed resulting in some jitter while paused.

*Single Field:* a single field is displayed, showing no flicker (useful when color correcting or whenever the flickering would be a distraction).

Software Conversion: The value selected in this pulldown is used whenever, due to format selection, you've chosen to do 24 frames-per-second to 30 conversion where extra fields will be added to pad the existing ones. Depending on video content, selection of different field patterns may be useful in reducing jitter due to the content of adjacent fields. The numbers in the pattern choices specify the frequency with which inserted fields will be repeated. For example, "2:3:2:3" means duplicate a field twice, then the next field three times, then the next twice, and then back to three times.

	Conversion
	Software Conversion
	3-2 Pulldown Pattern: ✓ 2:3:2:3 2:3:3:2 3-2 Pulldown Offset: 0
	YUV-RGB Conversion
	ColorSpace: Gamma: Auto ÷ Auto ÷ Enable Custom LUTs
YUV-RGB Conversion	These pulldowns select industry standard color space and gamma transfer functions for the YUV-RGB conversion, or allow you to direct lo XT to automatically determine it for you.
Colorspace:	Choose from:
	• Rec 601
	• Rec 709
	• Auto
Gamma:	Choose from the following:
	• Linear (1.8)
	• Rec 601 (2.20)
	• Rec 709 (2.22)
	• Auto
RGB Range:	The RGB Range pulldown menu allows you to select either Full range (0-1023) or SMPTE range (typically 64-940) for RGB color output.
Enable Custom LUTs:	This checkbox enables a custom color lookup table (LUT).

Figure 37. Conversion Screen Frame-padding Pattern Choices

#### DS Keyer Screen

The lo XT and lo 4K have a hardware-based downstream keyer that is ideal for putting logos, "bugs" or other video material with an alpha channel on top of video being played out or printed to tape.

NOTE: The Io 4K does not support Downstream Keying in UHD and 4K formats.

A typical application would be putting a television station's call letters or channel over program video content. Keyed video can be from the Io XT internal Frame Buffer (from storage, video In, etc.) or from a graphics file that has an alpha channel (PhotoShop etc.).

$\Theta \Theta \Theta$		104	K AJA Controll	Panel	
Control Format Input Select SDI Out	Io4K - 0 1080 29.97 SDI 1	*	1080i29.97 YUV-10 DS Kever	1	Disabled SDI 1
IDMI /ideo Setup	No Video SDI 2	>			Disabled SDI 2
Conversion OS Keyer Timecode	Disabled SDI 3	>			- 1080129.97 SDI 3 3Gb V+К
resets Irmware	Disabled SDI 4				1080129.97 SDI 4 3Gb V+K
nfo	No Video HDMI In				HDMI Out Auto Detect
	No Video Ref In	Genlock: Freerun	Frame Buffer		
		Do	wnstream I	Keyer	
	Mode	Graphic Over Matte	r +	Matte Color:	-
		Foreground pr	e-multiplied	Audio Out: 🤍	Frame Buffer Audio In
	Constant Pilo	Logo Alpha Key.ps	d ±	Opacity:	~

#### Figure 38. AJA Control Panel, Downstream Keyer Screen

Settings in the DS Keyer Screen provide control over how the keyer operates and whether it's turned on or off. Controls and their meanings in the screen are as follows:

#### Mode

Downstream Keyer Off:	When this pulldown menu item is selected the downstream keyer will be turned off
Frame Buffer over Matte:	Places the keyed video with alpha channel currently in the Frame Buffer over a fixed color matte determined by the "Matte Color" setting set separately.
Frame Buffer over Video In:	Places the keyed video currently in the Frame Buffer over the video input for playout or print-to-tape.
Graphic over Matte:	Places a graphics file having an alpha channel (chosen in "Graphic File" pulldown) over a fixed color matte determined by the "Matte Color" setting set separately.
Graphic over Video In:	Places a graphics file having an alpha channel (chosen in "Graphic File" pulldown) over the video input for playout or print-to-tape.
Graphic over Frame Buffer:	Places a graphics file having an alpha channel (chosen in "Graphic File" pulldown) over the current contents of the Io XT Frame Buffer (which might be from storage, video In, etc.).

Matte ColorOnly available when the pulldown "Frame Buffer over Matte" or "Graphic over Matte" are<br/>selected-pressing this button brings up a color selection dialog. The dialog provides a<br/>variety of ways to select a matte color including a color wheel, color picker (choose from<br/>a location anywhere on the computer screen), numeric sliders, swatches, "crayons", and<br/>spectrums. The matte chosen will be used as a video background under the keyed video.

**Foreground pre-multiplied** Use to avoid "matte lines" and improve the appearance of the foreground (key) being composited over the background.

#### **Audio Out**

*Frame Buffer:* Select audio out to be routed from the Frame Buffer.

Audio In: Select audio out to be routed from the Io XT's selected input(s).

**Graphic File** This pulldown allows you to choose from any recently accessed file or select a new file ("Load File..."), which then brings up a file dialogue. Remember that the file raster (pixel x pixel count) should match the primary format in the frame buffer or the secondary format if up-converting. Example: you wish to key a logo on top of your 1920x1080 footage, the still image with alpha channel that you load should be 1920x1080.

#### Timecode Screen

The Timecode input:

- Selects the timecode stream read for applications that use it (for example, AJA Control Room, when the timecode source is set to *"Use control panel setting,"* will read the selected stream)
- · Is used for monitoring the RP-188 timecode embedded in the digital data stream
- Is used for selecting a timecode offset (if required)

Figure 39. AJA Control Panel, Timecode Screen



lo XT/4K v10.5

www.aja.com

#### **Timecode Input Settings**

*RP-188 Timecode <n>:* In RP-188 timecode (SMPTE 12M-2) there can be multiple timecode types in the data stream. Use this pull-down to select the one you wish to monitor:

- RP188 LTC (Linear timecode)
- RP188 VITC 1 (Vertical Interval timecode)
- RP188 VITC 2
- LTC Port input

The selection will be displayed in the timecode value displayed to the right of the pulldown.

- User Bits: For monitoring a variable framerate (VFR) timecode (such as Varicam), you may wish to check the User-bits box. If you set this checkbox, Io XT/4K will detect and interpret the user-bits and display them next to the checkbox. You will see the original framerate (30 fps in the figure below) followed by the adjusted frame padding (two digits reporting discarded and retained frame padding).
  - NOTE: SMPTE 12M-2 is the updated name and specification for what was RP-188.

Figure 40. AJA Control Panel, Timecode Screen

pur					
	F	188 LTC +	01:07:37:27 0		
		VFR: 3	0 fps 0 0		
utput					
_	Use QT Timecode		Timecode Burn-In	Timecode	\$

#### **Timecode Output Settings**

Use QuickTime Timecode (Mac OS Only):	This feature is for Final Cut Pro 7 (or earlier), VTR Exchange, and AJA TV only. When checked, it directs lo XT/4K to output timecode from the QuickTime timecode track.
Timecode Burn-in:	This pulldown selects whether the timecode value is displayed in a "burned-in" window in video output. If set to "OFF", timecode will not be keyed over the video. If set to "Timecode", then the timecode value will be keyed over the output video for all of the Io XT/4K outputs. This can be useful for synchronizing, choosing edit points, dailies, and many other purposes.
Timecode Offset (entry field and FPS pull-down):	When QuickTime timecode in disabled, this text entry field allows you to generate a timecode based on the offset entry. You can select a framerate from the pulldown menu at the right side of the pane. Use that same value here as the source video to ensure the timecode is synchronized.
NOTE:	SMPTE RP 188 defines a standard for the transmission of time code and control code in the ancillary data space of a digital television data stream. Time code information is transmitted in the ancillary data space as defined in ANSI/SMPTE 291M. Multiple codes can be transmitted within a single digital video data stream. Other time information, such as real time clock, DTTR tape timer information, and other user-defined information, may also be carried in the ancillary time code packet instead of time code. The actual information transmitted through

the interface is identified by the coding of a distributed binary bit. Equipment manufacturers can use the meta data for different purposes.

#### **Presets Screen**

After configuring the AJA Control Panel screens, you can then save all your settings as a snapshot for later recall—called a *preset*. In this way, you can organize presets for all your typical tasks, eliminating time-robbing manual reconfiguration each time. To save a preset, simply go to the Presets screen and click "Save Preset". A dialog will be presented asking you for a name; enter a meaningful name and click "OK". Thereafter the preset will be available under the Control Panel "Presets" list.

#### Figure 41. Presets Screen

000		-	IoXT AJA ControlPanel	
Control	IoXT - 0	\$	1080129.97	
Format Input Select SDI Out	1080129.97 SDI In 1	-	YUV-10	1080i29.97 SDI Out 1
HDMI Analog Out	No Video SDI In 2	>		1080129.97 SDI Out 2
Video Setup Audio Setup	No Video HDMI In			1080i29.97 HDMI 3D-TB Auto Detect
DS Keyer Timecode	00:00:00:00 LTC In	Genlock: Fre	erun	1080i29.97 Analog Out Comp SMPTE
Presets			Frame Buffer	
Firmware Info			Presets	
	MyPreset			Save Preset
				Load Preset
				Delete
				Reset To Default
rom the Pre	esets screen yo	u can mana	age your collection of	presets easily. To Lo

*Transferring Saved Presets:* If you want to use a saved Preset on another workstation, you can simply copy the file on removable storage and install it at the new location. The Preset file is always stored at:

- ~/Library/Application Support/AJA/<device name> Presets/ [on Mac]
- c:\Users\<username>\AppData\Local\AJA\Control Panel\<device name> Presets\ [Windows 8]

*Reset to Default:* When you click the 'Reset to default' button the control panel will delete the User's preference file and do one of the following:

- A. If "Shared" preferences exist, they are reloaded and the device is set to this state.
- B. If the "Shared" preferences file does not exist, "factory defaults" are loaded and the device is set to this state.

For more information on Preset preferences see "Single-user & Network Settings" on page 23.

or

#### **Firmware Screen**

Use the Firmware screen to access the firmware install screen. Click install to erase current firmware and load the firmware version contained in your current driver installation. Note the Installation message shown below.

Figure 42. Firmware Update



You will be required to power-cycle your computer and Io XT/4K to finish the update.

#### Figure 43. Update Completed



#### **Info Screen**

This screen shows the Io XT/4K software files that have been installed on your system. This information may be needed if you talk to an AJA Customer Service representative to determine if files are missing or need updating.

Figure 44. Information Screen in Standard Mode



#### Using Io 4K for UHD/4K

In 4K Mode, you can input **or** output four channels of video representing individual quadrants of Ultra-HD (3840x2160) and 4K (4096x2160) formats. The lo 4K employs all four bi-directional SDI connectors for either input or output It cannot support the input and output at the same time.

Physical connections of the quadrants will be mapped to the Io 4K SDI connectors as shown in the following screens. For the HDMI, you can select just one of the quadrants for viewing (see "HDMI Screen in 4K Mode" on page 50 for quadrant selection).

#### Configuring Quad SDI I/O

This section describes the AJA Control Panel operations specific to UHD/4K Format selection.

Output Configuration: V

When you use the Control Panel Format screen to select a UHD or 4K format for the lo 4K output, you must also make sure the default output mode (Control screen setting) is set to "Test Pattern." Then the SDI connectors 1–4 will automatically configure as outputs (see *Figure 46*).



Default Output		Control
Video Output	Test Pattern	+
Test Pattern	Color Bars - 75%	\$

NOTE: When you select a UHD/4K format, the HDMI monitor output displays the Output Mode selection icon (see "HDMI Screen in 4K Mode" on page 50 for output options).





*Input Configuration:* To configure bi-directional SDI connectors for input, select *Pass-through* in the Default Output>Video Output menu (see *Figure 47 on page 49*).





#### Input Select Screen in 4K Mode

In 4K mode, on the Input Select Menu, the Source selection menu is not applicable. You can, however, still set input video format options (YUV, RGB, etc.) and set the LTC input usage and Audio Input settings. (Refer to *"Input Select Screen" on page 33*).

#### Figure 48. Input Select menus.

Video Input						
Source	SDI 1	¢	4Kp23.98	LTC/R	ef LTC	\$
SDI	YUV	\$				
Audio Input						
Select	Embedded Ch 1-16	\$	Map C	nannels	1-2 to 1-2	\$
				Rate	48000	\$

#### SDI Output Screen in 4K Mode

The SDI Output Screen allows you to select the Primary format or RGB for 4K output. Video+Key and Stereo 3D are available selections for SD, HD, or 2K formats only.

#### HDMI Screen in 4K Mode

The HDMI screen allows you to make the same selections previously described to XT when an SD, HD, or 2K format is selected (refer to *"HDMI Screen" on page 36*). Exclusive to UHD/4K formats, an HDMI monitor output Select menu is available to choose:

- Primary the full 4K or UHD format
- 4K Quarter a downconversion to 2K x 1080 for 4K format or 1920 x1080 for UHD
- A single Quadrant (1, 2, 3, or 4) of the 4K or UHD signal.

#### Figure 49. HDMI Output Screen with 4K Formatt



#### Figure 50. HDMI Output Format Select Menu

	HDMI		
t			
Primary	44-02:00	Sector 1	
Ouadrant 1	миргалав	Protocol	-
Quadrant 2		Color Space	
Quadrant 3		RGB Range	i.
	Primary V 4K Quarter Quadrant 1 Quadrant 2 Quadrant 3 Duadrant 4	Primary V 4K Quarter Quadrant 1 Quadrant 2 Quadrant 3 Duadrant 4	HDMI Primary V 4K Quarter Quadrant 1 Quadrant 2 Quadrant 3 Color Space RGB Range

#### Video Setup Screen in 4K

4K Mode adds the 4K Geometry selection (check box). Like other raster sizes, the Geometries checkbox for 4K needs to be enabled for the format to be presented and selectable in applications like AJA VTR Xchange and AJA TV.



#### Figure 51. QuickTime Video Output Filter 4K Geometry Checkbox

#### Downstream Keyer Screen in 4K Mode

The Downstream Keyer is not available for use in 4K Mode. If you select the screen and choose an active DSK mode from the menu, you will see:

"Keyer does not support 4K video formats."

#### If You Run Into Problems

One useful way to find the source of problems is to isolate your system to the smallest size where the problem still occurs and then note all the symptoms. This serves to eliminate areas not involved in the problem and makes finding the problem easier.

Once you've noted problem symptoms, look through the following table and see if any of the symptoms are listed. If so, check the items listed. If you later need to call for customer service, let them know all of the things you've tried and when and how the symptoms appeared.

Symptom	Check
Disk RAID cannot keep up (dropped frames etc.).	Ensure the disk system is providing at least 50 MB/second sustained transfer rate
Dropped frames during playback.	1. Virus checking software running in the background (disable it). 2. Scratch drive not set to the RAID.
Dropped frames during record.	<ol> <li>RAID cannot sustain the data rate of the capture preset codec.</li> <li>Virus checking software running in the background (disable it).</li> <li>Scratch drive not set to the RAID.</li> </ol>
Media is not being captured from desired external device.	Check the settings in the <i>Input</i> screen of the lo XT Control Panel application. Also check equipment cables.
Dropped frames during playback	Look for scroll bars in the viewer or canvas as a warning sign that the zoom setting exceeds the fit-t-window.
Video stutter during playback.	RAID cannot sustain data rate.
Red render bar occurs when placing a clip on a sequence.	The sequence setting does not match the clip setting.

Check on the AJA Video website for software updates.

For lo XT, visit:

http://www.aja.com/en/products/io-xt/#support

For lo 4K, visit:

www.aja.com/en/products/io-4k#support

If any are available, download the file and read any associated instructions prior to installing the software.

#### Support

When calling for support, first check over your system configuration and ensure everything is connected properly. Even if you cannot find the cause of the problem, having this information at hand will help when you call AJA Customer Support for help.

If the problem is unknown or you need general help, first contact the dealer where you purchased the product. AJA dealers offer product support for many service requirements.

If the problem is a 3rd-party software operational issue, Mac system issue, then call Apple Customer Support or the 3rd-party software manufacturer for help.

If the problem is an AJA Video Io XT issue, then contact AJA Video Customer Support, see *"Contacting Support" on page 4*.

# **Appendix A: Specifications**

### **Io XT Specifications**

Video Formats	<ul> <li>525i 29.97</li> <li>525i 23.98*</li> <li>625i 25</li> <li>720P 23.98*, 24 *, 25 *, 29.97*, 30 *, 50, 59.94, 60</li> <li>1080i 25, 29.97, 30</li> <li>1080PsF 23.98, 24, 25, 29.97, 30</li> <li>1080p 23.98, 24, 25, 29.97, 30, 50, 59.94, 60</li> <li>2Kx1080p 23.98, 24, 25</li> <li>2Kx1080PsF 23.98, 24, 25</li> </ul>
Software-dependent Formats:	* These formats are dependent on specific software functionality and are not normal 'over-the-wire' formats. 720P 23.98, 24, 25, 29.97, 30
Video Input	<ul> <li>3G/SD/HD SDI, SMPTE-259/292/296/424, 10-bits</li> <li>Single Link 4:2:2 or 4:4:4 (1 x 3G BNC)</li> <li>dual link HD 4:4:4, (2 x BNC)</li> <li>HDMI v1.3</li> <li>1D LUT Support (Mac and PC)</li> </ul>
Video Output Digital	<ul> <li>3G/SD/HD SDI, SMPTE-259/292/296/424</li> <li>Single link 4:2:2 or 4:4:4 (1 x BNC)</li> <li>Dual link HD 4:4:4, (2 x BNC)</li> <li>HDMI v1.4, 30/36 bits/pixel, RGB or YUV, 2.25Gbps</li> </ul>
Video Output Analog	<ul> <li>Composite/S-Video (Y/C) (1 x BNC/2x BNC+adapter)</li> <li>NTSC, NTSCJ, PAL</li> <li>Component (3 x BNC)</li> <li>HD: YPbPr, RGB</li> <li>SD: YPbPr, RGB (component mode)</li> <li>SMPTE/EBU N10, Betacam 525 line, Betacam 525J, RGB</li> <li>12-bit D/A, 8x oversampling</li> <li>+/2 dB to 5.0 MHz Y Frequency Response</li> <li>+/2 dB to 1 MHz C Frequency Response</li> <li>.5% 2T pulse response</li> <li>&lt;1% Diff Phase</li> <li>&lt;1% Diff Gain</li> <li>&lt;1 ns Y/C delay inequity</li> </ul>

Audio Input Digital	<ul> <li>16-channel, 24-bit SMPTE-259 SDI embedded audio, 48kHz sample rate, Synchronous</li> <li>8-channel, 24-bit HDMI embedded audio, 48kHz sample rate, Synchronous</li> </ul>
Audio Output Digital	<ul> <li>16-channel, 24-bit SMPTE-259 SDI embedded audio, 48kHz sample rate, Synchronous</li> <li>8-channel, 24-bit HDMI embedded audio, 48kHz sample rate, Synchronous</li> </ul>
Audio Output Analog	<ul> <li>8-channel, 24-bit D/A analog audio, 48kHz sample rate, balanced (via 8 x XLR on DB-25 breakout cable)</li> <li>+24dbu Full Scale Digital (0dbFS)</li> <li>+/- 0.2db 20 to 20kHz Frequency Response</li> </ul>
Downstream Keyer	• Supports graphics with alpha channel over video, matte or framebuffer, or framebuffer content over incoming video or matte.
Up-Conversion	Hardware 10-bit
-	Anamorphic: full-screen
	Pillar box 4:3: results in a 4:3 image in center of screen with black sidebars
	Zoom 14:9: results in a 4:3 image zoomed slightly to fill a 14:9 image with black side bars
	Zoom Letterbox: results in image zoomed to fill full screen
	Zoom Wide: results in a combination of zoom and horizontal stretch to fill a 16:9 screen; this setting can introduce a small aspect ratio change
Down-conversion	Hardware 10-bit
	Anamorphic: full-screen
	Letterbox: image is reduced with black top and bottom added to image area with the aspect ratio preserved
	Crop: image is cropped to fit new screen size
Cross-conversion	<ul> <li>Hardware 10-bit</li> <li>1080i to 720P</li> <li>720P to 1080i</li> <li>720P to 1080PsF</li> </ul>
SD to SD aspect	Letterbox: This transforms SD anamorphic material to a letterboxed image
ratio conversion	H Crop: Will produce a horizontally stretched effect on the image; transforms anamorphic SD to full frame
	SD Pillarbox: Will produce an image in the center of the screen with black borders on the left and right sides and an anamorphized image in the center
	V Crop: Will transform SD letterbox material to an anamorphic image

#### Reference Input or LTC Input

- 1 BNC assignable to Reference video or LTC input
- Reference:
  - Analog Color Black (1V) or Composite Sync (2 or 4V)
  - Non terminating

#### **Io 4K Specifications**

#### **Video Formats**

- **SD** 480p
  - 525i 29.97
  - 625i 25
- **HD** 720P 50, 59.94, 60
  - 1080i 50, 59.94, 60
  - 1080PsF 23.98, 24, 25, 29.97, 30
  - 1080p 23.98, 24, 25, 29.97, 30, 50, 59.94, 60
- **2K** 2048 x 1080p 23.98, 24, 25, 29.97, 30, 50, 59.94, 60
  - 2048 x 1080PsF 23.98, 24, 25, 29.97, 30
- **4K** 3840 x 2160P 23.98, 24, 25, 29.97, 30
  - 3840 x 2160PsF 23.98, 24, 25
  - 4096 x 2160P 23.98, 24, 25, 29.97, 30
  - 4096 x 2160PsF 23.98, 24, 25

#### **Video Inputs** • 3G/SD/HD SDI, SMPTE-259/292/296/424,

- 8 -or 10-bits
- Single Link 4:2:2 or 4:4:4 (1 x BNC)
- Dual Link HD 4:4:4 (2 x BNC)
- 2K HSDL (High Speed Data Link) 4:4:4, (2 x BNC)
- 4K/QuadHD 4:4:4 (4 x BNC)
- HDMI v1.4
  - 30/36 bits/pixel, RGB or YUV, 2.25Gbps.
  - SD, HD, 1080p-50/60, 4K, 2K and stereoscopic HD support

#### Video Outputs• 3G/SD/HD SDI, SMPTE-259/292/296/424, 8- or 10-bits

- Single Link 4:2:2 or 4:4:4 (1 x BNC)
- Dual Link HD 4:4:4 (2 x BNC)
- 2K HSDL (High Speed Data Link) 4:4:4, (2 x BNC)
- 4K/QuadHD 4:4:4 (4 x BNC)
- HDMI v1.4
  - 30/36 bits/pixel, RGB or YUV, 2.25Gbps.
  - SD, HD, 1080p-50/60, 4K, 2K and stereoscopic HD support

Audio Inputs Digital	<ul> <li>16-channel, 24-bit SDI embedded audio, 48kHz sample rate, Synchronous</li> <li>8-channel, 24-bit HDMI embedded audio, 48kHz sample rate, Synchronous</li> </ul>
Audio Output Digital	<ul> <li>• 16-channel, 24-bit SDI embedded audio, 48kHz sample rate, Synchronous</li> <li>• 8-channel, 24-bit HDMI embedded audio, 48kHz sample rate, Synchronous</li> </ul>
Audio Output Analog	<ul> <li>8-channel, 24-bit D/A analog audio, 48kHz sample rate, balanced (via 8x XLR on DB-25 breakout cable)</li> <li>+24 dBu Full Scale Digital (0 dBFS)</li> <li>+/- 0.2 bB 20Hz to 20kHz Frequency Response</li> </ul>
Downstream Keyer	<ul> <li>Supports graphics with alpha channel over video, matte or framebuffer content over incoming video or matte.</li> </ul>
4K to HD Down- Conversion	<ul> <li>Real time, always-on dedicated down-conversion output (1 x BNC)</li> <li>4K to 2K down-conversion</li> <li>UltraHD/QuadHD to HD down-conversion</li> </ul>
Reference Input or LTC Input	<ul> <li>1x BNC LTC Output</li> <li>1 x BNC assignable to Reference video or LTC input</li> </ul>
Reference:	<ul> <li>Analog Color Black (1V) or Composite Sync (2 or 4V)</li> <li>Non-terminating</li> </ul>
Physical	<ul> <li>Interface: Thunderbolt 2 (2 x)</li> <li>Power: 10-20V, 30-60W*</li> </ul>
NOTE:	Nominal power is 30W. However, multiple connected Thunderbolt devices may place additional power demands on Io 4K, which could increase the power draw to 60W.
Machine Control	
	••RS-422, Sony 9-pin protocol

- ••9-pin D-connector pinout is as follows:
- 1. GND
- 2. RX-
- 3. TX+
- 4. GND
- 5. No Connection
- 6. GND
- 7. RX+
- 8. TX-
- 9. GND
- Shell. GND

# Index

#### **Numerics**

24 frames-per-second to 30 conversion 40 3D output 36

#### A

alpha channel 42 alpha channel, Video + Key 35 analog audio 39 analog audio output 37 analog component 38 analog component output 37 analog composite 38 Analog Format 37, 38, 40 Analog Out Screen 37 Analog Out Screen Settings 37, 38 Anamorphic 31 anamorphic SD to full frame SD 31 aspect ratio conversion 31 Audio 7 Audio Input 34 audio input, pulldown menu 34 Audio Out 43

#### B

Betacam 12 Black 29 black borders 32 black burst 11 Black Level 38, 40 black Level pulldown menu 38 Blue 26 borders, black 32 Box 7

#### C

Cable Connections 10 camcorders 11 CineForm Codec 36 color matte 42 Color Meanings, Control Panel 26 color selection dialog 43 Colorspace choices 41 Component/Composite 12 composite 37 composite output 38 Configuration 12 Connector Descriptions 11 Connectors 11 Connectors 11 Control Panel, AJA Software 7 Control Panel, Tabbed Screens 27 Control Screen 42 Control Screen Settings 29 Conversion 6 Conversion Icons, Control Panel 27 conversion, YUV-RGB 41 Crop 31 crossconversion 6, 31 Custom LUTs 41 customer service 52

#### D

DE9 11 Default Kona Output 29 Device Drivers 7 Down (Conversion) 31 downconversion 6, 31 downstream keyer 42 DS Keyer 42

#### E

EBU N10 12

#### F

Foreground pre-multiplied (checkbox) 43 Format Screen Settings 30 format, primary 11 format, secondary 24 Formats Screen 30 Frame Buffer over Matte 42 Frame Buffer over Video In 42 Framebuffer 25 Freerun 29 Full Frame 40 full-screen 31

#### G

Gamma 41 Gatekeeper 13 Genlock and Your System 33 Getting Help 53 Graphic File 43 graphic file, test pattern output 29 Graphic over Frame Buffer 42 Graphic over Matte 42 Graphic over Video In 42 Green 26

#### Н

H Crop 31 HDMI audio output 36 HDMI output 36 Hold Last Application 29 Horizontal reference 30 horizontally stretched 31 house reference 11 house sync 33

#### 

Icons 27 Icons, Control Panel 27 Info Screen 47 Input Pass through 29 Input Screen 33 Input Screen Settings 33 Input/Output 27 Installation Overview 9 Installer Screen 14 Installing Io Software 12 Io 4K, Block Diagram 25 IRE 38

#### Κ

keyed video 42 KONA 3 Formats 31

#### L

Letterbox 31 letterbox 31 Linear 41 Load File 43 Log On Authenticate Prompt 13

#### Μ

Machine Control 11 Manual 8 Matte 42 Matte Color 43 Monitor Audio 37 monitoring, analog outputs 37 motion adaptive de-interlacing 6 Mountain Lion 13

#### 0

offset, video adjustment (timing) 30

#### Ρ

pattern, test 29 Pillar box 31 Pillarbox 32 Presets 45 Primary 35 Primary Format 25 Primary format 11 problem symptoms 52 problems, what to do if you encounter 52 progressive frame 31 progressive segmented frame 31 psf 31

#### R

Rec 601 41 Rec 709 41 Red 26 Ref In 29 Reference Video 11 Requirements, System 7 RP 188 definition 44 RP-188 Timecode 44 RS422 11

#### S

SD letterbox material to an anamorphic image 32 SD to SD aspect ratio conversion 31 Secondary 35 select audio 43 set up 9 Shipping Box Contents 8 sidebars 31 Single Field 40 SMPTE protocol 11 SMPTE RP 188 44 snapshot, Control Panel settings 45 Software 7 software files that have been installed 47 Software installation 12 Software License Agreement Screen 15 software updates 53 software, 3rd-party 22 Sony 11 Specifications 54 Support 53 support 53 Symptoms, problem 52 sync generator 11 synchronizing other video equipment 11 System software 12

#### T

Test Pattern 29 Timecode Offset 44 Timecode Screen 38, 43 Timecode Screen Settings 44 timing adjustment 30 Timing adjustment, Control Panel 30 troubleshooting 52

#### U

unpack 8

upconversion 31 upconverter 6 Updating Software 53 Use 46 user and password 13 User Bits, RP-188 44

#### V

V Crop 32 Vertical reference 30 Video Format 30 Video Input 33 video input source 29 video path 27 Video+Key 35 VTR RS-422 Control Port 11 VTRs, 11

#### Y

Y/C output 37 Y/R-Y/B-Y 12 Yellow 26 YPbPr 12 YUV 12 YUV-RGB Conversion 41

#### Ζ

Zoom 31 Zoom Letterbox 31 Zoom Wide 31