



i465

User's Guide

DECLARATION OF CONFORMITY

Per FCC CFR 47 Part 2 Section 2.1077(a)



Responsible Party Name: Motorola, Inc.

Address: 8000 West Sunrise Boulevard
Plantation, FL 33322 USA

Phone Number: 1 (800) 453-0920

Hereby declares that the product:

Product Name: i465

Model Number: H98XAH6JR7AN

FCC-ID: IHDT56KB1

Conforms to the following regulations:

FCC Part 15, subpart B, section 15.107(a), 15.107(d) and section 15.109(a)

FCC Notice to Users

The following statement applies to all products that have received FCC approval. Applicable products bear the FCC logo, and/or an FCC ID in the format FCC-ID: IHDT56KB1 on the product label.

Motorola has not approved any changes or modifications to this device by the user. Any changes or modifications could void the user's authority to operate the equipment. See 47 CFR Sec. 15.21.

Class B Digital Device

As a personal computer peripheral, this device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See 47 CFR Sec. 15.19(3).

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Motorola, Inc.
Consumer Advocacy Office
600 North US Highway 45
Libertyville, IL 60048

www.hellomoto.com

Note: Do not ship your phone to the above address. If you need to return your phone for repairs, replacement, or warranty service, please contact the Motorola Customer Support Center at:

1-800-453-0920 (United States)

1-877-483-2840 (TTY/TDD United States for hearing impaired)

Certain mobile phone features are dependent on the capabilities and settings of your service provider's network. Additionally, certain features may not be activated by your service provider, and/or the provider's network settings may limit the feature's functionality. Always contact your service provider about feature availability and functionality. All features, functionality, and other product specifications, as well as the information contained in this user's guide are based upon the latest available information and are believed to be accurate at the time of printing. Motorola reserves the right to change or modify any information or specifications without notice or obligation.


MOTOROLA and the Stylized M Logo are registered in the US Patent & Trademark Office. All other product or service names are the property of their respective owners. Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

© Motorola, Inc., 2009.


Manual Number: NNTN7762A

HELLOMOTO


Introducing your new Motorola i465 wireless phone. Here's a quick anatomy lesson.





check it out




turn it on & off

To turn on your phone, press and hold  for a few seconds or until the display turns on. If prompted, enter your four-digit unlock code.



To turn off your phone, press and hold  for two seconds.

Note: If you press the  for more than four seconds, the handset will power "On" in **Transmitters Off** mode. See "transmitters" on page 39.



















contents






| | | | | | |
|---|----------|---|-----------|--|-----------|
| check it out | 2 | call a stored phone number or private ID | 16 | features for the hearing impaired | 39 |
| turn it on & off | 2 | your phone number and private ID | 17 | TTY | 41 |
| menu map | 5 | messaging | 17 | security features | 41 |
| use and care | 7 | mms features | 18 | main attractions | 42 |
| essentials | 8 | inbox | 22 | media center | 42 |
| about this guide | 8 | outbox | 27 | video player | 43 |
| SIM card | 9 | sent items | 27 | camera | 43 |
| battery | 9 | customize messaging | 28 | PTX features | 45 |
| enable security | 13 | basics | 34 | one touch PTT | 52 |
| make a phone call | 13 | display | 34 | PT manager | 53 |
| answer a phone call | 13 | main menu | 35 | Bluetooth® | 54 |
| advanced calling | 14 | text entry | 35 | call features | 57 |
| make a private call | 14 | volume | 38 | turn off a call alert | 57 |
| answer a private call | 15 | navigation key | 38 | recent calls | 57 |
| store a phone number or private ID | 16 | handsfree speaker | 38 | redial | 58 |
| contacts | 16 | transmitters | 39 | caller ID | 58 |
| | | | | call forward | 58 |

| | | | | | |
|--|-----------|---|----|--|-----------|
| voice names | 59 | Caring for the Environment by Recycling | 71 | Information From the World Health Organization | 81 |
| emergency calls | 60 | Driving Precautions . . . | 71 | Product Registration . . | 82 |
| international calls | 60 | Operational Warnings . | 71 | Wireless: The New Recyclable | 82 |
| speed dial | 61 | Service and Repairs . . . | 73 | California Perchlorate Label | 82 |
| voicemail | 61 | Export Law Assurances | 74 | Patent and Trademark Information | 82 |
| customize. | 62 | Battery Use and Safety | 74 | Software Copyright Notice | 83 |
| ring tones | 62 | Battery Charging | 75 | Privacy and Data Security | 83 |
| backlight | 63 | Specific Absorption Rate | 75 | Smart Practices While Driving | 84 |
| LED indicators | 63 | AGPS and Emergency Calls | 76 | index. | 86 |
| wallpaper | 64 | Motorola Limited Warranty for the United States and Canada | 77 | | |
| datebook | 64 | Hearing Aid Compatibility With Mobile Phones | 80 | | |
| hide or show location information | 66 | | | | |
| Legal and Safety | 68 | | | | |
| Safety and General Information | 68 | | | | |
| Operational Precautions | 69 | | | | |
| RF Energy Interference/ Compatibility | 69 | | | | |
| Bluetooth | 70 | | | | |

menu map

main menu

-  **Net**
-  **Java Apps**
 - Java System
-  **Settings**
 - (see next page)
-  **VoiceRecord**
 - [New VoiceRec]
-  **Contacts**
 - [New Contact]
-  **Messages**
 - [Create Message]
 - Voice Mail
 - Inbox
 - Drafts
 - Outbox
 - Fax Mail
 - Net Alert
 - Sent Items
-  **Call Forward**
-  **Datebook**
-  **Memo**
-  **Call Timers**
 - Last Call
 - Phone Reset
 - Phone Lifetime
 - Prvt/Grp Reset
 - Prvt/Grp Life
- 
 - Kbytes Reset
-  **Recent Calls**
-  **Shortcuts**
 - [New Entry]
 - 1)Shortcuts
 - 2)Cntcs[New Contact]
 - 3)Recent Calls
 - 4)Contacts
 - 5)Datebook
 - 6)Messages
 - 7)VoiceRecord
 - 8)Net
 - 9)Call Forward
-  **My Info**
 - My Name
 - Line 1
 - Private ID
 - Group ID
 - Carrier IP
 - IP1 Address
 - IP2 Address
-  **Quick PTT**
-  **Profiles**
-  **Call Alert**
-  **GPS**
 - Position
 - Privacy
 - Interface

-  **Ring Tones**
 - Vibrate All: On/Off
 - Ringer
 - Vibrate
 - Silent
-  **Media Center**
-  **Camera**
-  **Bluetooth**
 - Hands Free
 - Link to Devices
 - Device History
 - Setup
 - Find Me
-  **PT Manager**
 - Quick PTT
 - Send Message
 - Send Picture
 - Send Event
 - Send My Info
 - Send Contact
 - Configure

This is the standard Main Menu layout.
Your phone's menu may be a little different.

settings menu

Display/Info

- Wallpaper
- Text Size
- Theme
- Home Icons
- Backlight
- Clock
- Menu View
- Large Dialing
- Language

Phone Calls

- Set Line
- Any Key Ans
- Auto Redial
- Call Waiting
- Auto Ans
- Minute Beep
- Call Duration
- TTY
- Hearing Aid
- Notifications
- DTMF Dialing
- Prepend

2-Way Radio

- One Touch PTT
- Alert Type
- PTT Quick Notes
- On/Off PTT
- Store Rcvd Info
- PTT Backlight

Personalize

- Menu Options
- Up Key
- Down Key
- Left Key
- Right Key
- Center Key
- Left Sftkey
- Right Sftkey
- Power Up

Volume

- Line 1
- Messages
- Earpiece
- Speaker
- Keypad
- Java Earpiece
- Java Spkr
- Data

Security

- Phone Lock
- Keypad Lock
- SIM PIN
- GPS PIN
- Change Passwds

Advanced

- Alert Timeout
- Headset/Spkr
- Connectivity
- Reset Defaults
- Return to Home
- Transmitters
- Phone Only
- Baud Rate

use and care

To care for your Motorola phone, please keep it away from:



liquids of any kind

Don't expose your phone to water, rain, extreme humidity, sweat, or other moisture. If it does get wet, don't try to accelerate drying with the use of an oven or dryer, as this may damage the phone.



dust and dirt

Don't expose your phone to dust, dirt, sand, food, or other inappropriate materials.



extreme heat or cold

Avoid temperatures below 0°C/32°F or above 45°C/113°F.



cleaning solutions

To clean your phone, use only a dry soft cloth. Don't use alcohol or other cleaning solutions.



microwaves

Don't try to dry your phone in a microwave oven.



the ground

Don't drop your phone.

essentials



Caution: Before using the phone for the first time, read the Important Safety and Legal information included in the gray-edged pages at the back of this guide.



about this guide

This guide shows how to locate a menu feature as follows:

Find it:  >  > **Phone Calls**

This means that, from the home screen:

- 1 Press the *menu key*  and then press the **Settings** menu option .

- 2 Press the *navigation keys*  to scroll to **Phone Calls**, and press the *center key*  to select it.

symbols




This means a feature is network or subscription dependent and may not be available in all areas, or might not be offered by your service provider. Contact customer service for more information.



This means a feature requires an optional accessory.

SIM card

insert the SIM card



Warning: To avoid loss or damage, do not remove your SIM card from your phone unless absolutely necessary.

battery



Battery Use & Battery Safety

- **Motorola recommends you always use Motorola-branded batteries and chargers.** The warranty does not cover damage caused by non-Motorola batteries and/or chargers.
Caution: Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard. Improper battery use, or use of a damaged battery, may result in a fire, explosion, or other hazard.
- Battery usage by children should be supervised.
- **Important:** Motorola mobile devices are designed to work best with qualified batteries. If you see a message on your display such as **Invalid**

Battery or Unable to Charge, take the following steps:

- Remove the battery and inspect it to confirm it bears a Motorola “Original Equipment” hologram;
- If there is no hologram, the battery is not a qualified battery;
- If there is a hologram, replace the battery and retry charging it;
- If the message remains, contact a Motorola Authorized Service Center.
- New batteries or batteries stored for a long time may take more time to charge.
- **Charging precautions:** When charging your battery, keep it near room temperature. Never expose batteries to temperatures below 0°C (32°F) or above 45°C (113°F) when charging.

Always take your mobile device with you when you leave your vehicle.

- When storing your battery, keep it in a cool, dry place.
- It is normal over time for battery life to decrease, and for the battery to exhibit shorter runtime between charges or require more frequent or longer charging times.
- **Avoid damage to battery and mobile device.** Do not disassemble, open, crush, bend, deform, puncture, shred, or submerge the battery or mobile device. Avoid dropping the battery or mobile device, especially on a hard surface. If your battery or mobile device has been subjected to such damage, take it to a Motorola Authorized Service Center before using. **Do not** attempt to dry it with an

appliance or heat source, such as a hair dryer or microwave oven.

- **Use care when handling a charged battery:** Particularly when placing it inside a pocket, purse, or other container with metal objects. Contact with metal objects (e.g., jewelry, keys, beaded chains) could complete an electrical circuit (short circuit), causing the battery to become very hot, which could cause damage or injury.


Promptly dispose of used batteries in accordance with local regulations. Contact your local recycling center for proper battery disposal.




Warning: Never dispose of batteries in a fire because they may explode.

battery installation

- 1 Pull out the connector cover. Slide the battery door downwards until it is released from the phone.



- 2** Remove the battery door.



- 3** Push the battery down until it snaps in place.



- 4** Replace the battery door and slide it up while pressing gently until you hear a click.




battery charging

New batteries are not fully charged.

charge using the charger

- 1** Pull out the connector cover, and insert the charger into the micro USB connector on your phone as shown.



charge from your computer




You can partially charge your phone's battery by connecting a Motorola-approved USB cable from your phone's micro-USB port to a high power USB connector on a




computer (not a low-power one, such as the USB connector on your keyboard or bus-powered USB hub). Typically, USB high-power connectors are located directly on your computer.


enable security

You must enable security the first time you power on your phone or within 10 days of first activation of your phone.




- 1 Press  under **Ok**.
- 2 You are prompted to enable security. Press  under **Yes**. A series of screens followed by the default home page displays.
- 3 Press  to return to the home screen.

make a phone call

Enter a phone number and press  or use a voice command. See “place a call using a voice name” on page 59.





To hang up press .

answer a phone call

- 1 If you want to answer the call on speaker phone, press the speaker key .
- 2 If you want to answer the call using the handset, press . To hang up press .
- 3 If you are using a Bluetooth headset, press the answer key on your headset. To hang up press the key again.

advanced calling




| feature | |
|-----------------------|---|
| call waiting | To accept the second call and put the active call on hold press  under Yes . To accept the second call and end the active call press  . |
| any key answer | To answer phone calls by pressing any key on the keypad press  >  > Phone Calls > Any Key Ans > On. |

make a private call

Your Private ID is the number at which you receive one-to-one Private calls.

Note: PTT means Push To Talk / Walkie-Talkie.

to make a Private call

- 1 Enter the Private ID you want to call.
- 2 Press and hold the PTT button. Begin talking after your phone emits a chirping sound.
- 3 Release the PTT button to listen.
To end the call press .


Note: A Private call ends automatically if there is no activity on the call for a few seconds.

send call alerts

Sending a call alert discretely lets the recipient know that you want to talk to him or her on a Private call.


When you send a call alert, the recipient's handset displays your name and emits a series of beeps or vibrations.

to send a call alert

- 1 Enter the Private ID you want to call as you would when making a Private call.
- 2 Press  under **Alert**.

When the message **Ready To Alert** appears on the display, press the PTT button until the message **Alert Successful** appears.

answer a private call

- 1 When your phone emits a chirping sound or vibrates to indicate you are receiving a Private call, wait for the caller to finish speaking.
- 2 Press and hold the PTT button and begin talking after your phone emits a chirping sound.
- 3 Release the PTT button to listen.
To end the call press .


answer a call alert


When you receive a call alert, you must:

| option |
|---|
| Answer: Begin a Private call with the sender. |
| Queue: Store the call alert to the call alert queue. |
| Clear: Dismiss and delete the call alert. |

You cannot receive phone calls or Private calls until you do.

to answer a call alert


- 1 Press the PTT button to start a Private call with the sender.
or
- 2 Queue the call alert by pressing  under **Queue**.
or

- 3 Clear the call alert by pressing  under **Clear**.








store a phone number or private ID

You can store a phone number or private ID in **Contacts**:

Find it:  >  > [New Contact]

- 1 Enter a name for the new entry. Each entry's name can contain 20 characters.
- 2 Select a specific **Ring Tone**.
- 3 Select a type for the entry (**Mobile, Private, Work1, Work2, Home, Email, Fax, Pager, IP** or **Other**). To store a private ID choose **Private**.
- 4 Enter the number for the entry and press  under **Save** when done.


contacts

| feature | |
|----------------------------------|---|
| edit/delete contact entry | Press  under Contcs . Select a contact and press  > Edit . Change the desired content and press  . Press  under Save . |
| set ringer ID | Press  under Contacts . Select a contact and press  > Edit . Select Ringer and chose your desired ring tone. Press  under Done . |

call a stored phone number or private ID

Find it:  > .

- 1 Scroll to the **Contacts** entry.

- 2 If the Contacts entry contains more than one number, scroll left or right until the type of the number you want to call is displayed (**Mobile**, **Private**, **Work1**, **Work2**, **Home**, etc.).
- 3 If you chose a phone number, press  to call the entry, or if you chose a Private ID press and hold the PTT button to call the number.

your phone number and private ID

Find it:  > My Info.





messaging

Your phone has the ability to use both MOSMS and Multimedia Messaging Service (MMS) messaging. The type of messaging your phone uses will be determined by your



service provider. If your service provider offers messaging through MOSMS, your phone sends and receive messages using MOSMS.

If your service provider offers MMS, your phone sends and receives messages using MMS. Additionally, MMS allows you to send and receive messages that may include text, pictures, videos, and audio files.

create and send messages



- 1 From the home screen press  under **Mesgs** > [**Create Message**].
- 2 Enter the phone number of the person you want to send the message to and press  or press  under **Search**. Select **Contacts** or **Recent Calls** to find the number you want.
- 3 Select **Mesg**: and enter the text of the message or to use a quick note press 

under **QNotes** and scroll to the quick note you want.

- 4 If you want to send the message, press  under **Send** or to delete the message without sending it, press  under **Cancel**.

quick notes

When you are filling in the **Message** and **Subject** fields, you can add ready-made words or short phrases called Quick Notes. After you add these words or phrases, you can edit them as you would any other text.

- 1 While you are creating a message, scroll to or select **Message** or **Subject**.
- 2 Press  under **QNotes**.
- 3 Select the quick note you want to insert into the message.
- 4 Press  under **Send**.

mms features

Note: The following features are available only when using MMS.


more message options

To view more message fields in a message you are creating, select **...More...**

The following options become available:

| option |
|---|
| Subject: Create or edit the subject line. |
| Attach: Attach a picture, audio file or voice record. |
| Cc: Send a copy of this message to someone else. |
| Auto Replies: Allows you to create a list of possible short answers for the recipient to choose when replying to your message. |
| Priority: Set priority Normal or High . |


option

Valid Until: Set a date after which attempts to deliver the message end, or press  under **No Date**.

insert a picture, video, and audio recording

You can insert one or more pictures, videos, and audio files from the media center into the body of the message. You can include text in the body of your message in addition to these items.


insert items

While you are filling in the **Mesg** field, press , select **Insert** and choose from **Add Picture**, **Insert Audio**, **Insert Video**, **Capture Video**, **Capture Picture** or **Record Voice**.

A list of available pictures, videos, or audio files appears. You can only insert one item at a time.

Select the picture, video, or audio recording you want to insert.

remove an inserted item

To remove an item from the message you are creating, highlight it and press  under **Delete**.

attach a picture, video, or audio recording

You can attach one or more pictures, audio or voice recordings from your phone into the body of the message. You can include text in the body of your message in addition to these items.


- 1 While you are filling in the **Attach** field, press **[New]** > and select from **Browse Pictures**,

Capture Picture, Browse Audio, Record Voice, Browse Video, or Record Video.

A list of available pictures, audio files, or voice recordings appears.

- 2 Select the picture, audio or voice record you want to attach.





If you want to attach more items, select **[New]**.

- 3 When finished, press  under **Done**.

Note: You can only attach audio files and pictures if they are not forward locked and if their DRM settings do not prevent you from sending.





Forward locked items are usually copyright protected, and you cannot share them with anyone, such as in Private calls or by uploading them from your phone.

take a new picture

- 1 While you are creating a message, scroll to any message field and press  or select **Attach > [New]**.
- 2 Select **Capture Picture**. This accesses the camera.
- 3 Take the picture. For instructions on how to take the picture see “camera” on page 43.
- 4 When you have captured the picture you want, press  under **Save**.
To discard the picture, press  under **Discard**. You can then take another picture.
- 5 When finished, press  under **Done**.
The picture is attached to the message and saved to the default storage location.


record a video



You can record a video to send with a message:

- 1 Select **Attach** > **[New]** > **Record Video**.
- 2 Record and adjust video.
To view the video without saving it, press  under **Review**.
- 3 To save the video, press  or press .
To discard the video without saving it, press  under **Discard**.
- 4 The video is attached to the message and saved to the media center in the default storage location.

create a new voice record


You can create a new voice record to send with a message:

- 1 Press  or select **Attach** > **[New]**.

- 2 Select **Record Voice**.
- 3 Say the message you want to record into the microphone.
- 4 When you are finished recording, press .
- 5 When finished, press  under **Done**.
- 6 The voice record is attached to the message and saved to the media center and the list of voice records.

remove an attachment

To remove an attachment in a message you are creating:

- 1 Select **Attach**.
- 2 Scroll to the attachment you want to remove.
- 3 Press  > **Unattach**.

use drafts



When you save a message as a draft, it is saved in the drafts folder.

Find it: Press  >  > **Drafts**.

- 1 Select the draft you want to edit.
- 2 To edit the fields you want to change, follow step 2 through step 4 in “create and send messages” above.

delete a draft



When you send a draft, it is removed from the Drafts folder.


- 1 To delete a message in the Drafts folder without sending it, scroll to the message you want to delete and press  under **Delete**.
- 2 Press  under **Yes** to confirm.

inbox

Find it: Press  >  > **Inbox**.


receive a message

- 1 To view the message press  under **Read**.
- 2 To dismiss the message notification press  under **Exit**.

While reading a text and numeric message that contains a phone number, you can press  to call that number.



threaded inbox

The threaded Inbox allows you to organize your messages by subject or sender.



- 1 From the Inbox, highlight a message.
- 2 Press  > **Threading**, and select from **None**, **Subject**, or **Sender**.

Note: Threading by subject is dependant upon your service provider.

read from the message center

- 1 From the home screen press  under **Mesgs > Inbox**.
- 2 Select the message you want to read.
- 3 To reply to the message, press  under **Reply**.

delete unread messages

- 1 Scroll to the message you want to delete.
- 2 Press  under **Delete** and  under **Yes** to confirm.


forward a message

- 1 Press  > **Forward**.

- 2 Create and send your message.
Embedded objects and attachments are included when you forward a message.

lock and unlock messages

Locked messages cannot be deleted until you unlock them.


- 1 View the message you want to lock or unlock.
- 2 Press  > **Lock Message** or **Unlock Message**.

call a number in a message

If a message you receive contains a phone number, Private ID in the **From** field, the **To** field, the **Cc** field, the **Subject** field, or the body of the message, you can call or send a call alert to that number.


send a call alert

- 1 View the message.



- 2 Highlight the Private ID you want to alert.
- 3 Press  > **Alert**.
- 4 Push the PTT button.

store message information to contacts

If a message you receive contains a phone number, Private ID or an email address in the **From** field, the **To** field, the **Cc** field, the **Subject** field, or the body of the message, you can store this information to **Contacts**.




- 1 View the message.
- 2 Highlight the number or email address you want to save.
- 3 Press  > **Save Number** or **Save Email**.
- 4 To store the number or email address as a new entry, select **[New Contact]**.

To store the number or email address to an existing entry, select the entry.

- 5 With the **Contacts** type field highlighted, press  left or right to display the **Contacts** type you want to assign the number or email address.
- 6 Press  under **Save**.

reply to a message

To reply to a message:


- 1 View the message you want to reply to.
- 2 To reply to the sender only, press  under **Reply** or press  under **Reply All** to reply to all recipients.
- 3 A list of short phrases appears. Select any of these phrases to add it to your messages or select **[Create Reply]**.
- 4 Edit any message fields you want to change.
- 5 Press  under **Send**.

use auto replies

If the message you are replying to was sent with auto replies, it contains a numbered list of possible replies for you to send. Press the number of the reply you want to send. The reply is sent immediately without further action.

go to a website

If a message contains one or more website URLs, you can go to that website.

- 1 View the message.
- 2 Highlight the website URL you want to go to.
- 3 Press  > **Go To Website**.


Note: The entire URL must appear in the message to allow you to open the website.

embedded objects and attachments

If a message contains pictures, videos, or audio files in the body of the message, highlight each picture, video, or audio recording to view or play it.

If a message contains a picture, video, or audio recording as an attachment, open the attachment to view the picture or play the video or audio recording.


open attachments

- 1 View the message.
- 2 Highlight the attachment you want to open. Attachments appear at the end of a message.
- 3 Press .

Attachments of an unknown type cannot be opened, but can be deleted.

save an embedded picture, video, or audio recording


To save a picture, video, or audio recording that is part of the body of a message you receive:

- 1 View the message.
- 2 Highlight the picture, video, or audio recording you want to save.
- 3 Press .
- 4 Select **Save Picture**, **Save Video**, or **Save Audio**.


The item will save in the default storage location.

delete an embedded picture, video, or audio recording

To delete a picture, video, or audio recording that is part of the body of a message you receive:



- 1 View the message.
- 2 Highlight the picture, video, or audio recording you want to delete and press .
- 3 Select **Delete Picture**, **Delete Video**, or **Delete Audio**.

save attachments

- 1 View the message.
- 2 Highlight the attachment you want to save.
- 3 Press  > **Save Attachment**.
Selected items save to the default storage location.

delete attachments

- 1 View the message.
- 2 Highlight the attachment you want to delete.


- 3 Press  > **Delete Attachment**.
- 4 Press  under **Yes** to confirm.

outbox


The Outbox holds all unsent messages.

Find it: Press  >  > **Outbox**.

resending failed messages from the outbox

- 1 Scroll to the message you want to resend or press the number of the message you want to resend.
- 2 Press  under **Resend**.

cancel an unsent message



- 1 Highlight the message you want to cancel.
- 2 Press .

- 3 Press  under **Cancel**.

sent items

The Sent Items box holds sent messages.

forward items from sent items



- 1 Scroll to the message you want to forward.
- 2 Press  > **Forward**.
- 3 Make edits if you wish, select the recipient and press  under **Send**.

check delivery status

If a message was successfully sent and you set the message to confirm delivery, you can check the delivery status:

- 1 Scroll to the message you want to view.
- 2 Press  > **Delivery Status**.

delete sent messages

- 1 Scroll to the message you want to delete.
- 2 Press  under **Delete**.
- 3 Press  under **Yes** to confirm.

delete all unlocked sent messages

- 1 Press  > **Delete All**.
- 2 Press  under **Yes** to confirm.

customize messaging

Find it:  >  >  > **Setup**.

This option is available from many context-sensitive menus.

The following options become available:

| option |
|---|
| Signature: Allows you to create a signature that is automatically inserted at the end of your messages. Signatures can be edited before sending the message. |
| Quick Notes: Lets you create new Quick Notes and edit or delete Quick Notes you created. |
| Cleanup: Controls how long messages remain in the Inbox and Sent Items before being deleted. |
| Delivery Rpt: Allows you to be automatically notified when your message is delivered. |
| Memory Size: Shows a report on used and free memory in your phone. |
| MMS Setup: opens a submenu to set MMS options. |
| Note: Available with MMS only. |

| option |
|---|
| Text Msg Setup: opens a submenu to set text messaging options. |
| Note: Available with MOSMS only. |

manage memory

Your text Inbox and Sent Items hold 200 messages each. The Outbox, and Drafts folder hold up to 30 messages each. If they are full, you cannot receive messages, send messages, or save drafts until you delete some items.

To view the amount of memory available in your text inbox:

Find it: Press  >  >  > Setup > Memory Size.

mms setup

Find it:  >  >  > Setup > MMS Setup.

This option is available from many context-sensitive menus when you are using MMS.

The following options become available:

| option |
|---|
| Friendly Name: Allows you to create a friendly name. Your friendly name is displayed in the From field on other iDEN handsets when your message is received. |
| Downloads: Controls whether your phone downloads new messages. Set this option to Automatic if you want your phone to download new messages automatically. Select Manual if you want your phone to prompt you before downloading new messages. |
| Replies: Lets you create or edit and delete reply phrases you created. |

text message setup

Find it:  >  >  > **Setup** > **Text Msg setup**.

This option is available from many context-sensitive menus when you are using MOSMS.


The following options become available:

| option |
|---|
| Srvc Cntr No: Allows you to enter a service center number. |
| Expire After: Allows you to set the number of days before a message expires. |

new quick notes and reply phrases


create quick notes or replies

- 1 From the Setup menu, select **Quick Notes**, or select **MMS Setup** > **Replies**.
- 2 Select **[New Quicknote]**, or **[New Reply]**.



- 3 Enter text from the keypad and press .

edit quick notes or replies



You can edit only Quick Note phrases you have created.

- 1 From the Setup menu, select **Quick Notes**, or select **MMS Setup** > **Replies**.
- 2 Select the quick note or reply you want to edit.
- 3 Edit the text and press .

delete quick notes or replies you have created

- 1 From the Setup menu, select **Quick Notes**, or select **MMS Setup** > **Replies**.
- 2 Scroll to the quick note you want to delete.
- 3 Press  under **Delete**.
- 4 Press  under **Yes** to confirm.

delete all quick notes or replies you have created

- 1 From the Setup menu, select **Quick Notes**, or select **MMS Setup > Replies**.
- 2 Press  > **Delete All**.
- 3 Press  under **Yes** to confirm.

cleanup options

The cleanup option controls how long messages remain in the Inbox and Sent Items before they are deleted. You set the cleanup option for the Inbox and Sent Items separately.

The clean up option deletes only read, unlocked messages and sent messages.



Find it:  >  >  > **Setup > Cleanup**.

- 1 Select **Inbox** or **Sent Items**.

- 2 Choose a clean up option from the following list:

| option |
|---|
| Off: Messages are never automatically deleted. |
| 5 Messages: If you have more than 5 messages, messages are deleted in the order they were received, starting with the oldest, until 5 are left. |
| 10 Messages: If you have more than 10 messages, messages are deleted in the order they were received, starting with the oldest, until 10 are left. |
| 1 Day: Messages are deleted if they are older than 1 day. |
| 3 Days: Messages are deleted if they are older than 3 days. |
| With these options, messages are deleted when you exit the message center after setting the option. |



| option |
|--|
| F-In F-Out: Messages are deleted as necessary on an FirstIn FirstOut basis. |
| Custom: Lets you create a clean-up option of up to 199 days for the inbox. |

- 3 Press  under **Yes** to automatically delete messages now or press  under **No** to delete messages later.

delete all messages

To delete all read, unlocked messages from the Inbox, all messages in the Drafts folder, or all successfully sent messages in the Outbox:

Find it:  > .

- 1 Select **Inbox**, **Drafts**, **Sent Items**, or **Outbox**.
- 2 Press  > **Delete All**.
- 3 Press  under **Yes** to confirm.

delete a thread

To delete a thread from the Inbox:

- 1 From the Inbox, select a thread.
- 2 Press  > **Delete Thread**.
- 3 Press  under **Yes** to confirm.

message notifications

When you receive a message, your phone notifies you with text on the display, a notification tone or vibration.

You can access the message or dismiss the notification.

If you dismiss the notification, the message is not deleted. It can be accessed through the message center.

If you are not on a phone call when you receive a message, your phone sounds a notification tone every 30 seconds until you access the message or dismiss the alert.

If you are on a call when you receive a message, your phone may sound a notification tone during the call or after you end the call, depending on how you set your notification options.

set notification options

To control whether your phone sounds message notification tones while you are on a phone call:

Find it:  >  > **Phone Calls > Notifications.**

Select from the following options:

| option |
|---|
| Receive All: Tones sound during calls for all types of messages. |
| Msg Mail Only: Tones sound during calls for mail messages; tones for all other types of messages are held until you end calls. |

| option |
|---|
| Delay All: Tones for all types of messages are held until you end calls. |
| Note: Delay All is the default setting. |


To set notification options during a call press

 > **Call Setup > Notifications.**


basics

See page 1 for a basic phone diagram.

display

The home screen shows when you turn on the phone. To dial a number from the home screen, press number keys and .


Note: Your home screen may look different.




Soft key labels show the current soft key functions. For soft key locations, see page 1.

status indicators

Status indicators are shown at the top of the home screen:



- 1 Signal Strength Indicator:** Vertical bars show the strength of the network connection. You can't make or receive calls when  shows.

- 2 **Active Phone Line:**  indicates phone line 1 is ready to make calls.
- 3 **Speaker On/Off:** Sounds associated with Private calls are set to come through the earpiece rather than through the speaker.
- 4 **Ringer Vibe/Off:** Your phone is set to not ring.
- 5 **Message Indicator:** Shows when you receive a text message. 
- 6 **Packet Data:** Your handset is ready to transfer packet data or is transferring packet data when it shows a blinking arrow.
- 7 **Battery Charge Indicator:** A fuller battery indicates a greater charge. Recharge the battery when your phone shows **Low Battery**.

main menu

All your phone's features can be accessed through the main menu. You can set the main menu to appear as **List View** or **Icon View**.


Find it:  >  > **Display/Info** > **Menu View**.

text Entry

Some features let you enter text.

Your phone provides convenient ways to enter words, letters, punctuation, and numbers whenever you are prompted to enter text (for example, when adding a Contacts entry or when using Text Messaging).

change the character input mode

- 1 When you see a screen where you can enter text, press  to change the character input mode.








2 Select one of the following options:

| entry method | |
|----------------------|---|
| Alpha | Press a key several times for different characters. |
| Word | Enter words using a predictive text entering system that lets you enter a word with fewer keypresses. |
| Text Settings | Selects the desired entry languages and Word Prediction features. |
| Insert | Selects a item to be inserted, such a picture, an audio/video clip or a voice recording. Note: available only when composing a message using MMS. |

word method

The Word text input method predicts the word you are typing by comparing the letters entered with dictionaries of words, and provides the most commonly-used word as you type. You may use up to two dictionaries, one for a primary language and another for a secondary language.

enter a word using “word” method character input

- 1 Select the **Word** character input method.
- 2 Press the corresponding keys to enter a word (for example, to enter the word **Bill**, press    ). (If you make a mistake, press  to erase a single character. Press and hold  to delete an entire entry.)
- 3 To accept a word and insert a space, press .

To accept a word completion (such as **Billion** when you entered **Bill**), press the navigation key to the right. To enter **Bill**, press the navigation key to the left.









If next word prediction is turned on, when you hit space, you will be presented with a predicted word option. For example, if you enter **Go**, you will be presented with a predicted word option such as **to**. Press the navigation key right to accept the predicted word.

If two or more word combinations result from the sequence of letters entered, a down arrow will be displayed. Press and hold the navigation key down to display a list of possible word choices.

When word completion is turned on, if you get a word you don't want, you can press the navigation key up or down to see more word choices.

alpha method

To enter characters by tapping the keypad:


- 1 Select the **Alpha** method.
- 2 Press the corresponding keys to enter a word. For example, to enter the word **Bill**, press    . If you make a mistake, press  to erase a single character. Press and hold  to erase an entire word.
- 3 To enter a symbol character, press  or  and the key for the symbol you wish to enter.

By default, the first letter of an entry is capitalized.

volume


Press the volume keys up or down to:

- turn off an incoming call alert
- change the earpiece volume during calls
- change the ringer volume from the home screen



Tip: You can quickly set your ringer to **Vibrate All** by holding the down volume key in the home screen.

navigation key

Press the *navigation key* up, down, left, or right to scroll to items in the display. When you highlight the desired item, press  to select it.



handsfree speaker

You can use your phone's handsfree speaker to make calls without holding the phone to your ear.

During a call, press  under **Spkr** to turn the handsfree speaker On.

The handsfree speaker stays on until you press  under **Spkr** again.

transmitters

Consult airline staff about the use of the *Transmitters Off* feature during flight. Turn off your phone whenever instructed to do so by airline staff.

Transmitters Off turns off your phone's calling and Bluetooth features in situations where wireless phone use is prohibited, but you can use the phone's other non-calling features when Transmitters is turned Off.

Find it:  >  > **Advanced** > **Transmitters** > **Off**.


features for the hearing impaired

using your phone with a hearing aid

For best results use the following optimization procedures and handset setting. They generally apply as well for users with cochlear implants:

optimize your handset position and orientation


While in a phone call slide your phone up and down, then left and right until best microphone coupling is obtained. You also may need to adjust your hearing aid (HA) volume setting.



If your HA has a telecoil, activate its switch, then also rotate the handset as illustrated to align the telecoils.

Note: Some automatically switched hearing aids may need an auxiliary switching magnet.

If you are unsure whether your HA is telecoil equipped or needs an auxiliary magnet, please refer to your HA user guide or contact a hearing aid professional or supplier.



choose your hearing aid setting

Find it: > > Phone Calls > Hearing Aid.

- 1 Set this option to **Microphone**. Microphone coupling is now optimized.
or
- 2 Set this option to **Telecoil**. Handset meets US federal requirements for telecoil coupling sound or set this option to **Off** (factory default). This is the setting for non HA users.

TTY



| feature | |
|--------------------------------------|---|
| turn On TTY feature | Press > > Phone Calls > TTY > Use TTY > On. |
| choose TTY mode | Press > > Phone Calls > TTY > Type. Select from TTY, VCO or HCO. |
| change the TTY baud rate | Press > > Phone Calls > TTY > Baud. Select 45.45 or 50.00. |
| change TTY mode during a call | While in the TTY call, press > In Call Setup > TTY > Type. Select from TTY, VCO or HCO. |

security features

| feature | |
|-----------------------|--|
| phone lock | To lock the phone press > > Security > Phone Lock > Lock Now or Auto Lock. |
| keypad lock | To lock the keypad press > > Security > Keypad Lock > Lock Now or Auto Lock. Shortcut: To lock the keypad press > . |
| enable SIM PIN | Press > > Security > SIM PIN > On. |
| change SIM PIN | Press > > Security > Change Passwords > SIM PIN. |

Note: You can make emergency calls on a locked phone (see page 60).

main attractions

media center

The media center lets you access pictures, audio recordings, and videos stored in your phone's memory.

The following audio recordings can be accessed through the media center:

- Voice records
- Musical ring tones in the list of ring tones
- Audio recordings saved from MMS messages received
- Audio recordings downloaded to your phone

Items in the media center can be sent in MMS messages and with Bluetooth. See "mms features" on page 18 and "Bluetooth®" on page 54.

Pictures in the media center can be sent in Private calls using Send via PTT. See "PTX features" on page 45.

Audio files supported by the Media Center include:

| Format | Sampling Rates/Bit Rates |
|---------------|---------------------------------|
| .au | 8 KHz/8 kbps |
| .midi | 8 KHz |
| .mp3 | 8 KHz/8 kbps |
| .wav | 8 KHz/64 kbps |
| .amr | 12kbps |


Image files supported by the Media Center include:

| Format | Max. Image Size (in pixels) |
|---------------|------------------------------------|
| .png | 128 x 160 |
| .gif | 128 x 160 |
| .jpg | 640 x 480 |
| .wbmp | 128 x 160 |

Video files supported by the Media Center include:

| Format | Frame Rate and Max. Image Size (in pixels) |
|---------------|---|
| AVI | 15fps 128 x 96 |
| H.263 | 15fps 128 x 96 |
| MPEG | 15fps 128 x 96 |

video player

- 1 From the Media Center, scroll left or right to Media: Video.
- 2 Select the video you wish to view, and it will begin to play.
- 3 To stop the video, press the navigation key down. To play the video again, press .

camera

You can save pictures taken with the integrated camera in your phone's memory, and can access them through the Media Center.


Pictures you take can be sent via Private Calls, Bluetooth, or MMS message. You can also set them as your phone's wallpaper.

access the camera

To access the camera, press .

To take pictures aim the camera lens and press  under **Capture** or press .

To save the picture, press .

To discard the picture without saving it, press  under **Discard**.

From the camera viewfinder, you can press  to enter **Menu Options**.

The following options become available:

| option |
|--|
| Media Center: Opens the Media Center application. |
| Record Video: To record a video |
| Zoom: To set the camera's zoom to 1x, 2x, or 4x. |


option

Lighting: Turn on the spotlight On before taking a picture in low light conditions. You can set it up to be **Normal** or **Low Light**.

Self Timer: Delay capturing the picture for a selected number of seconds. The values are: **Off** (default), **10 seconds**, **15 seconds**, and **20 seconds**.

To turn off the timer before the picture is captured, press  under **Cancel**.

Picture Quality: Adjust the picture quality to **Normal** or **Fine**.


Picture Size: Set up the picture size to **XL (640x480)**, **L (320x240)**, **M (160x120)**, **S (128x96)**, or **WP (128x160)**. You can also set picture size from the viewfinder by pressing  left and right.





Memory Usage: Shows the total amount of **Used**, **Free**, and total **Capacity** of the phone's memory.

option

Camera Setup: To access the camera set up screen.

access the media center

You can access the media center from the camera at any time by pressing  > **Media Center**, except when you are using the **Camera Setup** menu or viewing the memory screen.

The media center contains all your pictures, music files, and videos located on your phone's memory. Press  and  or  and  to filter your results.

customize the camera

Find it:  >  > **Camera Setup**

The following options become available:

option

Ask for Name: If this option is **On**, you are prompted to enter a name for each picture before saving. Otherwise, pictures are automatically saved with the date and a number as their names.

Shutter Sound: Set the default sound the camera makes when is taking a picture.

Default Size: Sets the default value for the **Picture Size** option.

Default Quality: Sets the default value for the quality of the picture.

PTX features



With *Push To View* features, your phone can send and receive the following items through Private calls with other phones that have this capability:

- Short text messages¹
- Pictures¹
- Datebook events
- My Info
- Contact information
- Location information¹

You can choose to send messages, pictures, events, **My Info**, **Contacts** or **Location** information to the Private ID you are engaged in a Private call with, Private IDs on the **Recent Calls** list, and Private IDs stored in **Contacts**.

When you make or receive a Private call, your phone automatically determines whether the phone you are engaged in a Private call with is able to receive each of these items. Your phone saves this information for as long as the Private ID is on your **Recent Calls** list or is

1. Additional charges may apply.

saved in your **Contacts**. Your phone updates the saved information each time you make or receive a call to or from that Private ID.

send messages



The Push to Send Messages feature lets you send short text messages through Private calls.


When you send a message, it appears on the display of the phone you are engaged in the Private call with.

begin a message and choose a recipient


You can begin a message during a Private call, from the **Contacts** list, the **Recent Calls** list, or from the **PT Manager**.

begin a message during a Private call

While in a Private call, press  > **Use PTT Feature** > **Send Message**.



Note: The first time you send a message, **Messaging Fees May Apply Continue?** appears and you are prompted to respond. Press  under **Yes** to acknowledge the message.

begin a message from the **Contacts** or the **Recent Calls** list

- 1 From the **Contacts** or the **Recent Calls** list, select the entry containing the Private ID you want to send the message to.
- 2 Press  > **Use PTT Feature** > **Send Message**.

begin a message from the **PT Manager**

The **PT Manager** lets you select the Private ID you want to send the message to from **Contacts** or the **Recent Calls** list.

Find it:  >  > **Send Contact** > **Browse**.

Then select **Contacts** or **Recent Calls** to see a list of entries from the **Contacts** or the **Recent Calls** list that can receive messages.

create messages

After you have begun a message and chosen a recipient, a screen appears that lets you create the text of the message you want to send. Your message may be up to 400 characters long.

You can choose from a list of ready-made words or short phrases called Quick Notes. You can use a Quick Note as it is or edit it before you send it. Editing a Quick Note changes the Quick Note for this message only and will not change the Quick Note on the list.


send a completed message

After you have completed your message, press the PTT button to send it.


receive messages

When you receive a message, a message notification appears on the display.

To view the message: Press  under **Read**.

To dismiss the message press  under **Dismiss**.

reply to a message

- 1 View the message.
- 2 Press  under **Reply**.
- 3 Create the message and press the PTT button to send it.

send pictures





You can send pictures stored in the **Media Center** through Private calls. The picture you send appears on the Private call recipient's display.

If the recipient accepts the picture, their phone saves the picture. The picture then appears in that phone's recent call list.

The first time you send a stored picture after turning the phone on, **Picture Fees May Apply Continue?** appears and you are prompted to respond.

Note: You cannot make or receive Private calls while transmitting or receiving a picture.


send a picture during a call


- 1 While in a Private call, press  under **Picture** or press  > **Use PTT Feature** > **Send Picture**.
A list of pictures that can be included in a Private call appears.
- 2 Select the picture you want to send.
- 3 Press the PTT button to send the picture.
- 4 Wait while the picture is transmitted. The Private call is temporarily interrupted while a picture is transmitted.

- 5 When prompted, press the PTT button to resume the Private call.

start a call by sending a picture

from the media center

Find it:  > **Media Center**

- 1 Scroll left or right to **Media: Pictures**.
- 2 Select the picture you want to send.
- 3 Press  > **Send Via...** > **Send Via PTT**.
- 4 Select **A Contact** or **A Recent Call**
A list of contacts that have Private IDs and are able to receive pictures appears.
- 5 Select the name of the person you want to send the picture to.
- 6 Press the PTT button to send the picture.
- 7 When prompted, press the PTT button to resume the Private call.

from the PT Manager:

Find it:  >  > **Send Picture**.

- 1 Select **A Contact** or **A Recent Call**
A list of contacts that have Private IDs and are able to receive pictures appears.
- 2 Select the name of the person you want to send the picture to.
- 3 Select **Browse Picture** or **Capture Picture**.
- 4 Press the PTT button to send the picture.
- 5 Once picture has been sent, when prompted press the PTT button to resume the call.


receive a picture

When someone sends you a picture, your phone emits a tone or vibrates and a message appears asking if you want to accept the picture.

Pictures you receive are saved to your phone's memory. They are accessible through the media center.

When you see a message asking if you want to accept the picture, press **Yes** to accept or **No** to decline.

clear a picture from the display

If you want to clear a picture from your phone's display while still on a call, press  > **Clear Screen**.

send a datebook event




to send a datebook event during a private call





- 1 While in a Private call press  > **Use PTT Feature** > **Send Event**.


Note: If these options do not appear on the menu, the Private ID you are engaged

in a private call with is not able to receive Datebook events.

- 2 If you want to create a new datebook event, press  under **New** and create the event in your datebook. If you want to chose an existing event do so.
- 3 If the event is a recurring event: Select **This Event Only** to send only the event selected. Select **Repeat Events** to send all occurrences of the event.
- 4 Push the PTT button to send the event.

send my info

- 1 While in a Private Call press  > **Send via PTT** > **Send My Info**, and push the PTT button to send.
or
- 2 From the home screen press  > **My Info** >  > **Send via PTT**. Enter a Private ID or press  under **Browse** to chose a


recipient from Contacts, Recent Calls or Memo, and press . Push the PTT button to send.

set my info sending option



You can control what portion of the information in **My Info** is sent and whether it is sent automatically in every call or only when you choose to send it.

Find it:  > **PT Manager** > **Configure** > **PTT My Info** > **Info to Send**

- 1 Select or remove the fields you want to send.
- 2 Press  under **Done**.

The information your phone sends always includes **My Name**, and **Private**. You may also send **Line 1**, and **Carrier IP**, depending on your sending options.


automatic sending



To control whether you send your information automatically:

Find it:  > **PT Manager** > **Configure** > **PTT My Info** > **Auto Send**

- 1 Select **On** or **Off**
- 2 When you make a call in which your information is sent automatically, the name you entered in the **My Name** field of **My Info** appears on the display of the recipient's phone, even if your name and Private ID are not stored in the recipient's Contacts.

send contact information



- 1 While in a Private Call press  > **Use PTT Feature**.
- 2 Select **Send Contact** and select the contact information you want to send.

- 3 Push the PTT button to send.
or
- 1 From the home screen press  > **PT Manager** > **Send Contact**.
- 2 Enter the Private ID number of the person you want to send the Contact information to or press  under **Browse**.
- 3 Select from **Recent Calls**, **Contacts**, or **Memo**.
- 4 Select the contact information you want to send and push the PTT button.

turn PTT features on and off



You can turn your phone's ability to send and receive messages, pictures, and Datebook events on and off.

You cannot turn your phone's ability to send and receive My Info and contact information on and off.


Find it:  >  > **2-Way Radio** > **On/Off PTT**.

- 1 Check or uncheck Messages, Pictures or Events.

one touch PTT

Find it:  >  > **2-Way Radio** > **One Touch PTT**.

One Touch PTT sets your phone to do any of the following each time you press the PTT button from the home screen:

| option |
|---|
| Off: Nothing happens when you press the PTT button from the home screen. |
| Quick PTT: Go to Quick PTT. See "quick PTT" on page 53. |
| Last Call: Call the most recent Private ID or Group on the recent calls list. |
| Assigned No.: Call a Private ID you assign. Enter the number using your keypad, or press  under Search . Select Contacts , Recent Calls , or Memo . |

| option |
|---|
| PT Manager: Go to PT Manager. See “PT manager” on page 53. |
| Send Message: Go to the first screen to send a message. |
| Send Picture: Go to the first screen to send pictures. See “send pictures” on page 48. |
| Send Event: Go to the first screen to send a Datebook event. |
| Send My Info: Go to the first screen to send My Info. See “send my info” on page 50. |
| Send Contact: Go to the first screen to send a contact. See “send contact information” on page 51. |






quick PTT



Quick PTT lets you quickly make a call, when accessing any Private IDs on your phone.

To view a list of Contacts with Private IDs in **Contacts**:

Find it:  > **Quick PTT**

To move between **Contacts**, **Recent Calls**, or **Memo**, use the  left or right, or press  and  or  and .

PT manager



The **PT Manager** lets you quickly access PTT features, and other Private call features, from the main menu.

Find it:  > **PT Manager**

- 1 Select **Quick PTT**, **Send Message**, **Send Picture**, **Send Event**, **Send My Info**, **Send Contact**, or **Configure**. After choosing what PTT item you are sending, select a contact and press the PTT button to send.

or

- 2 Select **Configure** to configure your **PTT Quick Notes**, **PTT My Info**, **One Touch PTT**, or **On/Off PTT**.

Bluetooth®

Find it:  > 

turn Bluetooth on or off

You can turn your phone's Bluetooth feature on or off. While Bluetooth power is on, your phone can communicate with other devices.

Find it:  >  > **Setup** > **Power**




- 1 Select **On** to power Bluetooth On.
- 2 Select **Name** if you wish to assign a name to your handset.
- 3 Select **Find Me Time** to determine the amount of time in which your handset can be found by other Bluetooth devices.

You can turn off Bluetooth if you want to prolong battery life or if you enter an area where Bluetooth is prohibited.

make a Bluetooth connection

connect your handset with a Bluetooth headset

Find it:  >  > **Hands Free** > **[Find Devices]**

- 1 Follow the instructions on your Bluetooth headset to set it up to be found.
- 2 Once your Bluetooth headset is set to be found press  on your handset. Your phone will scan for the Bluetooth headset until it finds it. Press  when you see the name of the Bluetooth headset on your screen.
- 3 Your handset requires that you create a bond in order to connect with a Bluetooth headset. Press  under **Yes** when you are prompted to bond with the headset.

4 Enter the Bluetooth pass key.

Some Bluetooth devices ship with Bluetooth PINs. Please refer to your Bluetooth device's user guide to locate this information.

If a device ships without a Bluetooth PIN, then you can enter any PIN for that device. To establish a connection to that device, enter the same PIN for both your phone and the device. For example, if you enter 1234 as the device's PIN, then enter 1234 as your phone's PIN.

5 Press under **Ok**.

This handset offers the Bluetooth auto pair feature with auto pair compatible Motorola devices. When bonded via Bluetooth with a certain device, the pin will not be required.

connect your handset with another Bluetooth device


Find it:  >  > **Link To Devices**

- 1 Select the device you want from the list of found devices on your screen.
- 2 Create a bond if you are prompted to do so.

If you have previously connected to a device, the device will be stored on your phone so you can connect with it easily.

use Bluetooth during a call

You can connect with available Bluetooth devices during a call.


- 1 While in a call, press  > **Use Bluetooth**.
- 2 Select the audio device you want to connect to from the list of **Hands Free Devices**.

If the **Audio Devices** list contains only one device, your phone will try to connect to it.


send information via Bluetooth

Your handset can transfer Contacts entries, Datebook events, audio files, pictures and videos to another Bluetooth device.

The receiving device must be within 32 feet (10 meters) of your phone in order to connect.

Note: Files sent or received may be up to 1 MB, depending on your service provider. 

sending information

- 1 From within Contacts, datebook, or Media Center, select the Contacts entry, Datebook event, audio file, video, or picture you want to send.
- 2 Press  > **Send Via...** > **Bluetooth**.
- 3 Select the device you want to transfer the contact information to, or search for the device by selecting [**Find Devices**].
- 4 If prompted, bond with the device.

Your phone connects with the devices and transfers the information.

call features

turn off a call alert

You can press the volume keys to turn off a call alert before answering the call.

recent calls



The recent calls list contains information associated with calls you have made and received and call alerts you have received.

When you send or receive Private calls, the recent call list contains the following PTX items with those calls:

- contact information received
- My Info received
- short text messages received

- pictures sent or received
- Datebook events received



The recent calls list displays up to 20 of the most recent calls and call alerts.

- 1** Press  > **Recent Calls**.
- 2** Scroll through the list.
- 3** To view more details of the item press .


store an item to contacts from recent calls

Phone calls, Private calls, My Info, Contacts or Location entries received from other phones can be stored to the Contacts list from the Recent Calls list.

Find it:  > Recent Calls.

- 1 Scroll to or select the item you want to store.
- 2 Press  under **Save** to store the information as a new entry in the Contacts list.
or
- 3 Select an existing contact and update the information.
- 4 Press  under **Done** to save your changes.

redial





To redial your last outgoing call, press and hold  or push the PTT button if it was a private call.

caller ID

Caller ID allows people to identify a caller before answering the phone by displaying the number of the incoming call. If you do not want your number displayed when you make a call, just follow these easy steps.

To block your phone number from being displayed for a specific outgoing call:



- 1 Press   .
- 2 Enter the number you want to call.
- 3 Press .

To permanently block your number, call your customer service provider.

call forward

Call forwarding sends calls to the phone numbers you specify. You can forward all calls to one number or forward missed calls to

different numbers depending on the reason you missed the call. You can forward phone lines 1 and 2 independently.

Find it:  > **Call Forward.**

1 To forward all calls select **All Calls** and select **To** to enter the phone number you want all your calls forwarded to.

or

2 You can specify a forwarding number for each type of missed call by selecting **Detailed** and choosing the following options:

If Busy: When your handset is on a call or transferring data.

If No Answer: When you do not answer on the first 4 rings.

If Unreachable: When your handset is out of coverage or powered off.

voice names



You can place calls by speaking commands to your phone if you have previously assigned a voice name to your contacts.

assign voice names to contacts


1 Press  under **Contacs** and select **[New Contact]**.

2 Assign a name, phone number and select **[Options]**.

3 Select **Voice Name** and follow the prompt to record the voice name.

4 Press  under **Back** and  under **Save**.

place a call using a voice name

1 Press the speaker key  until you are prompted to say the voice name.

The handset will automatically place the call.

emergency calls



Your service provider programs one or more emergency phone numbers that you can call under any circumstances. Emergency calls can be made without a SIM card, when your phone is locked, or when the SIM card is blocked.

Note: Emergency numbers vary by country. Your phone's preprogrammed emergency number(s) may not work in all locations, and sometimes an emergency call cannot be placed due to network, environmental, or interference issues.

Dial 911 or your local emergency number to be connected to an emergency response center. If you are on an active call, you must end it before making an emergency call.


When you make an emergency call, your phone's GPS Enabled feature can help emergency service personnel find you, if you

are in a location where your phone's GPS antenna has established a clear view of the open sky and your local emergency response center has the equipment to process location information. Because of the limitations of this feature, always provide your location, to the best of your knowledge, to the emergency response center when you make an emergency call.

Note: Emergency calls cannot be placed while the keypad is locked, or if your phone is displaying a **No Service** message on the screen. To unlock the keypad, press  .



international calls



If your phone service includes international dialing, press and hold  to insert your local international access code (indicated by +). Then, press the keypad keys to dial the country code and phone number.

speed dial

Each phone number stored in Contacts is assigned a Speed Dial number, which you can use to call that number.

- 1 From the home screen, use the keypad to enter the Speed Dial number assigned to the phone number you want to call.
- 2 Press .
- 3 Press .

turbo dial

The first nine entries in your contacts are set for turbo dial. They can be called by pressing and holding the speed dial number (1 through 9).

voicemail






To receive voice mail messages, you must first set up a voice mail account with your service provider.

receiving a message

When you receive a voice mail message, **New VoiceMail Message** appears on the display.

To call your service provider's voice mail system and listen to the message:

- 1 Press  under **Call**.
- 2 To dismiss the message notification:
 - Press  or **Back**.

If the caller leaves a message, this icon  appears on the display, reminding you that you have a new message.


customize

ring tones

To set the ring tone your phone makes when you receive phone calls, call alerts, message notifications, pictures sent using Send via PTT or Datebook reminders:

Find it:  > Ring Tones

- 1 Make sure **Vibrate All** is set to **Off**.
- 2 Scroll through the list of ring tones and select the one you want to assign.
Vibrate sets your phone to vibrate instead of making a sound. **Silent** sets your phone to neither vibrate nor make a sound.
- 3 Select the features you want to assign the ring tone to.

- 4 When you are finished, press  under **Done**.

Note: This icon  appears on the display if you set your phone to **Silent**. This icon  appears on the display if you set the phone to **Vibrate All**.

set your phone to vibrate

You can set your phone to vibrate instead of making a sound when you receive all phone calls, Private calls, call alerts, message notifications, pictures sent using Send via PTT, and Datebook reminders.

Find it:  > Ring Tones > Vibrate All

Set this option to **On** or **Locked**.

Setting this option to **On** lets you turn **Vibrate All** off by pressing the up volume control. Setting this option to **Locked** requires you to press and hold the up volume control to turn **Vibrate All** off. The **Locked** option helps prevent you from accidentally turning **Vibrate All** off.


To set **Vibrate All** to **On** or **Locked** using the volume controls:

Press the volume controls to turn down the volume as far as possible to set **Vibrate All** to **On**. Continue to hold the down volume control to set **Vibrate All** to **Locked**.

To set your phone to vibrate instead of making a sound for some features but not others:



Find it:  > Ring Tones

- 1 Make sure **Vibrate All** is set to **Off**.
- 2 Select **Vibrate** from the list of ring tones.
- 3 Select the features you want to set to make no sound.

- 4 When you are finished, press  under **Done**.



backlight

Set the amount of time that the display and Java apps. backlights remain on, or turn off the backlight feature to extend battery life.

Find it:  >  > Display/Info > Backlight



LED indicators


You can turn off the Bluetooth, messaging, and voicemail indicators.

Find it:  >  > Display/Info > Backlight > Bluetooth LED, Message LED, or VMail LED > Off

wallpaper







Set a previously saved photo or picture as a wallpaper (background) image in your phone's external display, internal screen or throughout all menu screens.



Find it:  >  > **Display/Info > Wallpaper**

- 1 Select **Wallpaper**.
- 2 Scroll through the list of pictures and press  to select a picture.

You can set the wallpapers to change automatically after a certain period of time by turning on the **Auto Cycle** feature located in the Wallpaper menu. You can select from **5 minutes, 15 minutes, 1 hour, 8 hours, Daily, or Startup**.

datebook

| feature | |
|-------------------------------|--|
| create datebook events | To create a new Datebook event press  > Datebook > [New Event] . |
| see datebook event | To see a calendar event press  > Datebook . Press  left or right to see the day and  up or down to see the events. |
| event reminder | When an event reminder occurs press  under View . Press  under Back to close the reminder. |

| feature | |
|--|--|
| receive datebook events via PTT | <p>To view the information while still in the Private call press .</p> <p>The 5 most recent events received from a Private ID are stored with that Private ID on the recent calls list.</p> <p>To store events to the Datebook press  under Save while viewing the event you want to store.</p> |

datebook setup

Find it:  > **Datebook** >  > **Setup**

You can view or change these options:

| options |
|---|
| <p>Start View: Sets Datebook to start in day view, week view, or month view when you access Datebook.</p> |
| <p>Daily Begin: Sets the beginning of your day. This is the earliest time of day displayed in week view, if you have a 12-hour day view.</p> |
| <p>Delete After: Sets the amount of time Datebook waits to delete an event after it occurs.</p> |
| <p>Time Shift: Lets you shift the times of all Datebook events. This is useful if you are traveling to a different time zone.</p> |
| <p>Alert Timeout: Sets the amount of time a tone continues to sound when you receive a Datebook reminder.</p> |

options

Clock: Controls whether the time and date appear on the home screen; sets time and date format; sets year.

hide or show location information




Your phone is equipped with a Location feature for use in connection with location-based services that may be available in the future.

Turning Location **On** will allow the network to detect your position using GPS technology, making some applications and services easier to use. Turning Location off will disable the GPS location function for all purposes except 911, but will not hide your general location based on the cell site serving your call. No application or service may use your location

without your request or permission. GPS-enhanced 911 is not available in all areas.

set your privacy options

Find it:  > GPS > Privacy

Select from the following options:

option

Restricted: No Java or similar software applications may view the location of your phone. However, location information may still be available to the phone's owner, fleet manager, or account administrator.



Unrestricted: All applications may view the location of your phone, without notifying you.

option

Ask Access: When an application attempts to view the location of your phone, you will be prompted to give permission. However, location information may still be available to the phone's owner, fleet manager, or account administrator.

change GPS PIN

When you receive your phone, your GPS PIN is 0000.

To change your GPS PIN press  >  > **Security** > **Change Passwords** > **GPS PIN**. Enter the current GPS PIN and enter the new four to eight digit GPS PIN. Re-enter the new four- to eight-digit GPS PIN to confirm.

Legal and Safety

Safety and General Information

This section contains important information on the safe and efficient operation of your mobile device. Read this information before using your integrated multi-service portable radio.*

Exposure to Radio Frequency (RF) Energy

Your mobile device contains a transmitter and receiver. When it is ON, it receives and transmits RF energy. When you communicate with your phone, the system handling your call controls the power level at which your phone transmits.

Your mobile device is designed to comply with local regulatory requirements in your country concerning exposure of human beings to RF energy.

Portable Radio Product Operation and EME Exposure

Your Motorola radio product is designed to comply with the following national and international standards and guidelines regarding exposure of human beings to radio frequency electromagnetic energy (EME):

- United States Federal Communications Commission, Code of Federal Regulations; 47 CFR part 2 sub-part J.
- American National Standards Institute (ANSI) / Institute of Electrical and Electronics Engineers (IEEE). C95. 1-1992.
- Institute of Electrical and Electronics Engineers (IEEE). C95. 1-2005 Edition.*
- International Commission on Non-Ionizing Radiation Protection (ICNIRP) 1998.
- Ministry of Health (Canada). Safety Code 6. Limits of Human Exposure to Radio frequency Electromagnetic Fields in the Frequency Range from 3 kHz to 300 GHz, 1999.
- Australian Communications Authority Radio communications (Electromagnetic Radiation - Human Exposure) Standard 2003.
- ANATEL, Brazil Regulatory Authority, Resolution 303 (July 2, 2002) "Regulation of the limitation of exposure to

* The information provided in this document supersedes the general safety information in user's guides published prior to May 1, 2006

electrical, magnetic, and electromagnetic fields in the radio frequency range between 9 kHz and 300 GHz.”
“Attachment to Resolution 303 from July 2, 2002.”

Operational Precautions

For optimal mobile device performance, and to be sure that human exposure to RF energy does not exceed the guidelines set forth in the relevant standards, always follow these instructions and precautions.

Phone Operation

When placing or receiving a phone call, hold your mobile phone as you would a landline telephone. **Speak directly into the microphone.**

Two-way radio operation

Your radio product has been designed and tested to comply with national and international standards and guidelines regarding human exposure to RF electromagnetic energy, when operated in the two-way mode (at the face, or at the abdomen when using an audio accessory) at usage factors of up to 50% talk/50% listen.

Transmit no more than the rated duty factor of 50% of the time. To transmit (talk), push the PTT button. To receive calls, release the PTT button. Transmitting 50% of the time or less, is important because this radio generates measurable RF energy only when transmitting (in terms of measuring for standards compliance).

When using your radio product as a traditional two-way radio, **hold the radio product in a vertical position with the microphone one to two inches (2.5 to 5 cm) away from the lips.**



If you wear the mobile device on your body, always place the mobile device in a Motorola approved clip, holder, holster, case or body harness. If you do not use a body-worn accessory supplied or approved by Motorola and are not using the mobile device in the intended use positions along side the head in the phone mode or in front of the face in the two-way radio mode, or if you hang your device from a lanyard around your neck, keep the device at least 2.5 centimeters (1 inch) from your body when transmitting.

Approved Accessories

For a list of approved Motorola accessories call 1-800-453-0920, or visit our website at www.motorola.com/iden.

RF Energy Interference/Compatibility

Nearly every electronic device is subject to RF energy interference from external sources if inadequately shielded, designed or otherwise configured for RF energy compatibility. In some circumstances your mobile device may cause interference with other devices.

Follow Instructions to Avoid Interference Problems

Turn OFF your mobile device in any location where posted notices instruct you to do so.

In an aircraft, turn off your mobile device whenever instructed to do so by airline staff. If your mobile device offers an airplane mode or similar feature, consult airline staff about using it in flight.

Implantable Medical Devices

If you have an implantable medical devices, such as a pacemaker or defibrillator, consult your physician before using this mobile device.

Persons with implantable medical devices should observe the following precautions:

- ALWAYS keep the mobile device more than 20 centimeters (8 inches) from the implantable medical device when the phone is turned ON.
- DO NOT carry the mobile device in the breast pocket;
- Use the ear opposite the implantable medical device to minimize the potential for interference.
- Turn OFF the mobile device immediately if you have any reason to suspect that interference is taking place.

Read and follow the directions from the manufacturer of your implantable medical device. If you have any questions about using

your mobile device with your implantable medical device, consult your health care provider.

Hearing Aids

Some phones may interfere with some hearing aids. In the event of such interference, you may want to consult your hearing aid manufacturer or physician to discuss alternatives.

Other Medical Devices and Health Care Facilities

If you use any other personal medical devices, consult your physician or the manufacturer or your device to determine if it is adequately shielded from RF energy. Turn off your radio product when instructed to do so in hospitals or health care facilities that may be using equipment that is sensitive to external RF energy.

Bluetooth

This device supports Bluetooth 1.2 including HSP, HFP, OPP, DUN, PBAP, and BPP. In order for Bluetooth devices to communicate with one another, they must utilize the same Bluetooth profile. To determine the profiles supported by other Motorola devices, visit www.hellomoto.com/bluetooth. For other devices, contact their respective manufacturer.

Certain Bluetooth features including those listed may not be supported by all compatible Bluetooth-enabled devices, and/or the functionality of such features may be limited in certain devices, or by certain wireless carriers. Contact your wireless carrier about feature availability and functionality.

Caring for the Environment by Recycling



This symbol on a Motorola product means the product should not be disposed of with household waste.

Disposal of your Mobile Device and Accessories

Please do not dispose of mobile devices or electrical accessories (such as chargers, headsets, or batteries) with your household waste. These items should be disposed of in accordance with the national collection and recycling schemes operated by your local or regional authority. Alternatively, you may return unwanted mobile devices and electrical accessories to any Motorola Approved Service Center in your region. Details of Motorola approved national recycling schemes, and further information on Motorola recycling activities can be found at: www.motorola.com/recycling

Disposal of your Mobile Device Packaging and User's Guide

Product packaging and user's guides should only be disposed of in accordance with national collection and recycling requirements. Please contact your regional authorities for more details.

Driving Precautions

The use of wireless phones while driving may cause distraction. Discontinue a call if you can't concentrate on driving.

Additionally, the use of wireless devices and their accessories may be prohibited or restricted in certain areas. Always obey the laws and regulations on the use of these products.

Responsible driving practices can be found in the "Smart Practices While Driving" section (see page 84).

Operational Warnings

Obey all posted signs when using Mobile devices in public areas.







Potentially Explosive Atmospheres

Areas with potentially explosive atmospheres are often but not always posted, and can include fueling areas such as below decks on boats, fuel or chemical transfer or storage facilities, or areas where the air contains chemicals or particles, such as grain, dust or metal powders.

When you are in such area, turn off your handset, and do not remove, install, or charge batteries unless it is a radio product type especially qualified for use in such areas as "Intrinsically Safe" (for example, Factory Mutual, CSA, or UL approved). In such areas, sparks can occur and cause an explosion or fire.

Symbol Key

Your battery, charger, or portable radio may contain symbols, defined as follows:

| Symbol | Definition |
|---|--|
|  | Important safety information follows. |
|  | Do not dispose of your battery or phone in a fire. |
|  | Your battery or phone may require recycling in accordance with local laws. Contact your local regulatory authorities for more information. |
|  | Do not throw your battery or phone in the trash. |
|  | Your phone contains an internal lithium ion battery. |
|  | Do not let your battery, charger, or phone get wet. |

| Symbol | Definition |
|---|---|
|  | Listening at full volume to music or voice through a headset may damage your hearing. |

Batteries and Chargers

Caution: Improper treatment or use of batteries may present a danger of fire, explosion, leakage, or other hazard. For more information, see the “Battery Use and Battery Safety” section in this user’s guide.

Keep Your Mobile Device and Its Accessories Away from Small Children

These products are not toys and may be hazardous to small children. For example:

- A choking hazard may exist for small, detachable parts.
- Improper use could result in loud sounds, possibly causing hearing injury.
- Improperly handled batteries could overheat and cause a burn.

Glass Parts

Some parts of your mobile device may be made of glass. This glass could break if the product is dropped on a hard surface or receives

a substantial impact. If glass breaks, do not touch or attempt to remove. Stop using your mobile device until the glass is replaced by a qualified service center.

Seizures/Blackouts

Some people may be susceptible to epileptic seizures or blackouts when exposed to flashing lights, such as when playing video games. These may occur even if a person has never had a previous seizure or blackout.

If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult with your physician before playing video games or enabling a flashing-lights feature (if available) on your mobile device.

Discontinue use and consult a physician if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. It is always a good idea to hold the screen away from your eyes, leave the lights on in the room, take a 15-minute break every hour, and stop use if you are very tired.

Caution About High Volume Usage

Warning: Warning: Exposure to loud noise from any source for extended periods of time may affect your hearing. The louder the volume sound level, the less time is required before your hearing could be affected. To protect your hearing:



- Limit the amount of time you use headsets or headphones at high volume.
- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you can't hear people speaking near you.

If you experience hearing discomfort, including the sensation of pressure or fullness in your ears, ringing in your ears, or muffled speech, you should stop listening to the device through your headset or headphones and have your hearing checked.

For more information about hearing, see our Web site at direct.motorola.com/hellomoto/nss/AcousticSafety.asp (in English only).

Repetitive Motion

When you repetitively perform actions such as pressing keys or entering finger-written characters, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. If you continue to have discomfort during or after such use, stop use and see a physician.

Service and Repairs

If you have questions or need assistance, we're here to help.

Go to www.motorola.com/support, where you can select from a number of customer care options. You can also contact the Motorola Customer Support Center at 1 (800) 453-0920 (United

States), 1 (877) 483-2840 (TTY, TDD United States for hearing impaired).

Export Law Assurances

This product is controlled under the export regulations of the United States of America and Canada. The Governments of the United States of America and Canada may restrict the exportation or re-exportation of this product to certain destinations. For further information contact the U.S. Department of Commerce or the Canadian Department of Foreign Affairs and International Trade.

Battery Use and Safety

Important: Handle and store batteries properly to avoid injury or damage. Most battery issues arise from improper handling of batteries, and particularly from the continued use of damaged batteries.

DON'Ts

- **Don't disassemble, crush, puncture, shred, or otherwise attempt to change the form of your battery.**
- **Don't let the phone or battery come in contact with water.** Water can get into the phone's circuits, leading to corrosion. If the phone and/or battery get wet, have them checked by your carrier or contact Motorola, even if they appear to be working properly.

- **Don't allow the battery to touch metal objects.** If metal objects, such as jewelry, stay in prolonged contact with the battery contact points, the battery could become very hot.
- **Don't place your battery near a heat source.** Excessive heat can damage the phone or the battery. High temperatures can cause the battery to swell, leak, or malfunction. Therefore:
- Do **not** dry a wet or damp battery with an appliance or heat source, such as a hair dryer or microwave oven.
- Avoid leaving your phone in your car in high temperatures.

DOs

- **Do avoid dropping the battery or phone.** Dropping these items, especially on a hard surface, can potentially cause damage.
- **Do contact your service provider or Motorola if your phone or battery has been damaged from dropping or high temperatures.**

Important: Use Motorola Original products for quality assurance and safeguards. To aid consumers in identifying authentic Motorola batteries from non-original or counterfeit batteries (that may not have adequate safety protection), Motorola provides holograms on its batteries. Consumers should confirm that any battery they purchase has a "Motorola Original" hologram.

Motorola recommends you always use Motorola-branded batteries and chargers. Motorola mobile devices are designed to work with Motorola batteries. If you see a message on your display such as **Invalid Battery** or **Unable to Charge**, take the following steps:

- Remove the battery and inspect it to confirm that it has a “Motorola Original” hologram;
- If there is no hologram, the battery is not a Motorola battery;
- If there is a hologram, replace the battery and retry charging it;
- If the message remains, contact a Motorola authorized service center.

Important: Motorola’s warranty does not cover damage to the phone caused by non-Motorola batteries and/or chargers.

Warning: Use of a non-Motorola battery or charger may present a risk of fire, explosion, leakage, or other hazard.

Proper and safe battery disposal and recycling: Proper battery disposal is not only important for safety, it benefits the environment. Consumers may recycle their used batteries in many retail or service provider locations. Additional information on proper disposal and recycling may be found on the Web:

- www.motorola.com/recycling
- www.rbrc.org/call2recycle/ (in English only)

Disposal: Promptly dispose of used batteries in accordance with local regulations. Contact your local recycling center or national recycling organizations for more information on how to dispose of batteries.

Warning: Never dispose of batteries in a fire because they may explode.

Battery Charging

Notes for charging your phone’s battery:

- When charging your battery, keep it near room temperature. Never expose batteries to temperatures below 0°C (32°F) or above 45°C (113°F) when charging.
- New batteries are not fully charged.
- New batteries or batteries stored for a long time may take more time to charge.
- Motorola batteries and charging systems have circuitry that protects the battery from damage from overcharging.

Specific Absorption Rate

Your model wireless phone meets international guidelines for exposure to radio waves.

Your mobile device is a radio transmitter and receiver. It is designed to not exceed the limits for exposure to radio waves recommended by international guidelines. These

guidelines were developed by the independent scientific organization ICNIRP and include safety margins designed to assure the protection of all persons, regardless of age and health, and to account for any variations in measurements.

The guidelines use a unit of measurement known as the Specific Absorption Rate (SAR). The ICNIRP SAR limit for mobile devices used by the general public is 2 watts per kilogram (W/kg), and the highest SAR value for this mobile device when tested at the ear is 1.17 W/kg. As mobile devices offer a range of functions, they can be used in other positions, such as on the body as described in this guide. In this case, the highest tested SAR value is 1.41 W/kg. The tests are carried out in accordance with international guidelines for testing. The SAR information includes the Motorola testing protocol, assessment procedure, and measurement uncertainty range for this product.

As SAR is measured utilizing the mobile device's highest transmitting power, the actual SAR of this mobile device while operating is typically below that indicated above. This is due to automatic changes to the power level of the mobile device to ensure it only uses the minimum level required to reach the network.

While there may be differences between the SAR levels of various mobile devices and at various positions, they meet the governmental requirements for safe exposure.

Please note that improvements to this product model could cause differences in the SAR value for later products; in all cases, products are designed to be within the guidelines.

The World Health Organization has stated that present scientific information does not indicate the need for any special precautions for the use of mobile devices. They note that if you want to reduce your exposure, then you can do so by limiting the length of calls or using a handsfree device to keep the mobile device away from the head and body.

Additional Information can be found on the Web sites of the World Health Organization (<http://www.who.int/emf>) or Motorola, Inc. (<http://www.motorola.com/rfhealth>).

AGPS and Emergency Calls

When you make an emergency call, your mobile device can use *Assisted Global Positioning System* (AGPS) satellite signals to tell the emergency response center your approximate location.

The AGPS feature has limitations, so always tell the emergency response center your best knowledge of your location. Remain on the phone for as long as the emergency response center instructs you.

AGPS **might not work** for emergency calls, if your local emergency response center does not process AGPS location information. For details, contact your local authorities.

If your mobile device cannot find strong AGPS satellite signals, the location of the nearest cell tower in contact with your mobile device is automatically provided to the emergency response center.

AGPS Performance Tips

- Go outside and away from underground locations, covered vehicles, structures with metal or concrete roofs, tall buildings, and foliage. Indoor performance might improve if you move closer to windows, but some window sun shielding films can block satellite signals.
- Move away from radios, entertainment equipment, and other electronic devices that might interfere with or block AGPS satellite signals.

AGPS uses satellites controlled by the U.S. government and subject to changes implemented in accordance with the Department of Defense AGPS user policy and the Federal Radio Navigation Plan. These changes might affect AGPS performance.

Motorola Limited Warranty for the United States and Canada

What Does this Warranty Cover?

Note: FOR IDEN SUBSCRIBER PRODUCTS, ACCESSORIES AND SOFTWARE PURCHASED IN THE UNITED STATES OR CANADA

Subject to the exclusions contained below, Motorola, Inc. warrants its Motorola iDEN Digital Mobile and Portable Handsets ("Products"), Motorola-branded or certified accessories sold for use with these Products ("Accessories") and Motorola software

contained on CD-Roms or other tangible media and sold for use with these Products ("Software") to be free from defects in materials and workmanship under normal consumer usage for the period(s) outlined below. **This limited warranty is a consumer's exclusive remedy, and applies as follows to new Products, Accessories and Software purchased by consumers in the United States or Canada, which are accompanied by this written warranty:**

| Products Covered | Length of Coverage |
|---|--|
| Products as defined above. | Ninety (90) days from the date of purchase by the first consumer purchaser of the product. |
| Accessories as defined above. | Ninety (90) days from the date of purchase by the first consumer purchaser of the product. |
| Products or Accessories that are Repaired or Replaced. | The balance of the original warranty or for ninety (90) days from the date returned to the consumer, whichever is longer. |
| Software as defined above. Applies only to physical defects in the media that embodies the copy of the software (e.g. CD-ROM, or floppy disk). | Ninety (90) days from the date of purchase. |

What is not covered? (Exclusions)

Normal Wear and Tear. Periodic maintenance, repair and replacement of parts due to normal wear and tear are excluded from coverage.

Ornamental Decorations. Ornamental decorations such as emblems, graphics, rhinestones, jewels, gemstones and their settings, and other decorative elements, are excluded from coverage.

Batteries. Only batteries whose fully charged capacity falls below 80% of their rated capacity and batteries that leak are covered by this limited warranty.

Abuse & Misuse. Defects or damage that result from: (a) improper operation, storage, misuse or abuse, accident or neglect, such as physical damage (cracks, scratches, etc.) to the surface of the product resulting from misuse; (b) contact with liquid, water, rain, extreme humidity or heavy perspiration, sand, dirt or the like, extreme heat, or food; (c) use of the Products or Accessories for commercial purposes or subjecting the Product or Accessory to abnormal usage or conditions; or (d) other acts which are not the fault of Motorola, are excluded from coverage.

Use of Non-Motorola Products and Accessories. Defects or damage that result from the use of Non-Motorola branded or certified Products, Accessories, Software or other peripheral equipment are excluded from coverage.

Unauthorized Service or Modification. Defects or damages resulting from service, testing, adjustment, installation, maintenance, alteration, including without limitation, software

changes, or modification in any way by someone other than Motorola, or its authorized service centers, are excluded from coverage.

Altered Products. Products or Accessories with (a) serial numbers or date tags that have been removed, altered or obliterated; (b) broken seals or that show evidence of tampering; (c) mismatched board serial numbers; or (d) nonconforming or non-Motorola housings, antennas, or parts, are excluded from coverage.

Communication Services. Defects, damages, or the failure of Products, Accessories or Software due to any communication service or signal you may subscribe to or use with the Products, Accessories or Software is excluded from coverage.

Software Embodied in Physical Media. No warranty is made that the software will meet your requirements or will work in combination with any hardware or software applications provided by third parties, that the operation of the software products will be uninterrupted or error free, or that all defects in the software products will be corrected.

Software NOT Embodied in Physical Media. Software that is not embodied in physical media (e.g. software that is downloaded from the internet), is provided "as is" and without warranty.

Who is covered? This warranty extends only to the first consumer purchaser, and is not transferable.

What will Motorola Do? Motorola, at its option, will at no charge repair, replace or refund the purchase price of any Products, Accessories or Software that does not conform to this warranty.

We may use functionally equivalent reconditioned/refurbished/pre-owned or new Products, Accessories or parts. No data, software or applications added to your Product, Accessory or Software, including but not limited to personal contacts, games and ringer tones, will be reinstalled. To avoid losing such data, software and applications please create a back up prior to requesting service.

How to Obtain Warranty Service or Other Information? To obtain service or information, please call:

Motorola iDEN Customer Services 1-800-453-0920 or
954-723-4910

TTY-877-483-2840

Or visit us online at <http://www.motorola.com/iden>

You will receive instructions on how to ship the Products, Accessories or Software, at your expense, to a Motorola Authorized Repair Center. To obtain service, you must include: (a) a copy of your receipt, bill of sale or other comparable proof of purchase; (b) a written description of the problem; (c) the name of your service provider, if applicable; (d) the name and location of the installation facility (if applicable) and, most importantly; (e) your address and telephone number.

What Other Limitations Are There? ANY IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY, OTHERWISE THE REPAIR, REPLACEMENT, OR REFUND AS PROVIDED UNDER THIS EXPRESS

LIMITED WARRANTY IS THE EXCLUSIVE REMEDY OF THE CONSUMER, AND IS PROVIDED IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED. IN NO EVENT SHALL MOTOROLA BE LIABLE, WHETHER IN CONTRACT OR TORT (INCLUDING NEGLIGENCE) FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT, ACCESSORY OR SOFTWARE, OR FOR ANY INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR LOSS OF REVENUE OR PROFITS, LOSS OF BUSINESS, LOSS OF INFORMATION OR DATA, SOFTWARE OR APPLICATIONS OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE ABILITY OR INABILITY TO USE THE PRODUCTS, ACCESSORIES OR SOFTWARE TO THE FULL EXTENT THESE DAMAGES MAY BE DISCLAIMED BY LAW.

Some states and jurisdictions do not allow the limitation or exclusion of incidental or consequential damages, or limitation on the length of an implied warranty, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or from one jurisdiction to another.

Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted Motorola software such as the exclusive rights to reproduce and distribute copies of the Motorola software. Motorola software may only be copied into, used in, and redistributed with, the Products associated with such Motorola software. No other use, including without limitation disassembly of such Motorola software or exercise of the exclusive rights reserved for Motorola, is permitted

Patent and Software Provisions:

MOTOROLA will defend, at its own expense, any suit brought against the end user purchaser to the extent that it is based on a claim that the Product or parts infringe a patent, and Motorola will pay those costs and damages finally awarded against the end user purchaser in any such suit which are attributable to any such claim, but such defense and payments are conditioned on the following:

- That MOTOROLA will be notified promptly in writing by such purchaser of any notice of such claim;
- That MOTOROLA will have sole control of the defense of such suit and all negotiations for its settlement or compromise; and
- Should the Product or parts become, or in MOTOROLA'S opinion be likely to become, the subject of a claim of infringement of a patent, that such purchaser will permit MOTOROLA, at its option and expense, either to procure for such purchaser the right to continue using the Product or parts or to replace or modify the same so that it becomes non infringing or to grant such purchaser a credit for the Product or parts as depreciated and accept its return. The depreciation will be an equal amount per year over the lifetime of the Product or parts as established by MOTOROLA.

MOTOROLA will have no liability with respect to any claim of patent infringement which is based upon the combination of the Product or parts furnished hereunder with software, apparatus or

devices not furnished by MOTOROLA, nor will MOTOROLA have any liability for the use of ancillary equipment or software not furnished by MOTOROLA which is attached to or sued in connection with the Product or any parts thereof. In no event shall MOTOROLA be liable for any incidental, special or consequential damages arising from any claim of patent infringement or alleged infringement.

Laws in the United States and other countries preserve for MOTOROLA certain exclusive rights for copyrighted MOTOROLA software, such as the exclusive rights to reproduce in copies and distribute copies of such MOTOROLA software. MOTOROLA software may be used in only the Product in which the software was originally embodied and such software in such Product may not be replaced, copied, distributed, modified in any way, or used to produce any derivative thereof. No other use including, without limitation, alteration, modification, reproduction, distribution, or reverse engineering of such MOTOROLA software or exercise or rights in such MOTOROLA software is permitted. No license is granted by implication, estoppel or otherwise under MOTOROLA patent rights or copyrights.

Hearing Aid Compatibility With Mobile Phones

Some Motorola phones are measured for compatibility with hearing aids. If the box for your particular model has "Rated for Hearing Aids" printed on it, the following explanation applies.

When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed ratings for some of their mobile phones, to assist hearing device users in finding phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their box or a label on the box.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.

T-Ratings: Phones rated T3 or T4 meet FCC requirements and are likely to be more usable with a hearing device's telecoil ("T Switch" or "Telephone Switch") than unrated phones. T4 is the better/higher of the two ratings. (Note that not all hearing devices have telecoils in them.)

Hearing devices may also be measured for immunity to this type of interference. Your hearing device manufacturer or hearing health

professional may help you find results for your hearing device. The more immune your hearing aid is, the less likely you are to experience interference noise from mobile phones.

Information From the World Health Organization

Present scientific information does not indicate the need for any special precautions for the use of mobile phones. If you are concerned, you may want to limit your own or your children's RF exposure by limiting the length of calls or by using hands-free devices to keep mobile phones away from your head and body.

Source: WHO Fact Sheet 193

Further information: <http://www.who.int/peh-emf>.

Product Registration

Online Product Registration:

www.motorola.com/us/productregistration

Product registration is an important step toward enjoying your new Motorola product. Registering permits us to contact you for product or software updates and allows you to subscribe to updates on new products or special promotions. Registration is not required for warranty coverage.

Please retain your original dated sales receipt for your records. For warranty service of your Motorola Personal Communications Product you will need to provide a copy of your dated sales receipt to confirm warranty status.

Thank you for choosing a Motorola product.

Wireless: The New Recyclable

Your wireless phone can be recycled. Recycling your phone reduces the amount of waste disposed in landfills and allows recycled materials to be incorporated into new products.

The Cellular Telecommunications Industry Association (CTIA) and its members encourage consumers to recycle their phones and have taken steps to promote the collection and environmentally sound recycling of end-of-life devices.

As a phone user, you have an important role in ensuring that this device is recycled properly. When it comes time to give this phone up or trade it in for a new one, please remember that the phone,

the charger, and many of its accessories can be recycled. It's easy. To learn more about CTIA's Recycling Program for Used Wireless Devices, please visit us at:

<http://recycling.motorola.young-america.com/index.html>

California Perchlorate Label

Some mobile phones use an internal, permanent backup battery on the printed circuit board that may contain very small amounts of perchlorate. In such cases, California law requires the following label:

Perchlorate Material - special handling may apply. See **www.dtsc.ca.gov/hazardouswaste/perchlorate**.

There is no special handling required by consumers.

Patent and Trademark Information

MOTOROLA, the Stylized M Logo and all other trademarks indicated as such herein are trademarks of Motorola, Inc. ® Reg. U.S. Pat. & Tm. Off. © 2009 Motorola, Inc. All rights reserved.

Microsoft and Microsoft Internet Explorer are registered trademarks of Microsoft Corporation.

T9 is a trademark owned by Tegic Communications.

T9® Text Input Patent and Trademark Information.

This product is covered by U.S. Pat. 5,818,437, U.S. Pat. 5,953,541, U.S. Pat. 6,011,554 and other patents pending.

Java and all other Java-based marks are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

All other product names or services mentioned in this manual are the property of their respective trademark owners.

Software Copyright Notice

Motorola products may include copyrighted Motorola and third party software stored in semiconductor memories or other media. Laws in the United States and other countries preserve for Motorola and third party software providers certain exclusive rights for copyrighted software, such as the exclusive rights to distribute or reproduce the copyrighted software. Accordingly, any copyrighted software contained in the Motorola products may not be modified, reverse-engineered, distributed, or reproduced in any manner to the extent allowed by law. Furthermore, the purchase of Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents, or patent applications of Motorola or any third party software provider, except for the normal, non-exclusive, royalty-free license to use that arises by operation of law in the sale of a product.

Privacy and Data Security

Motorola understands that privacy and data security are important to everyone. Because some features of your mobile device may

affect your privacy or data security, please follow these recommendations to enhance protection of your information:

- **Monitor access**—Keep your mobile device with you and do not leave it where others may have unmonitored access. Lock your device's keypad where this feature is available.
- **Keep software up to date**—If Motorola or a software/application vendor releases a patch or software fix for your mobile device that updates the device's security, install it as soon as possible.
- **Erase before recycling**—Delete personal information or data from your mobile device prior to disposing of it or turning it in for recycling. For instructions on how to delete all personal information from your device, please contact your local service provider.
- **Understanding AGPS**—To provide location information for emergency calls, certain Motorola mobile devices incorporate Assisted Global Positioning System (AGPS) technology. AGPS technology also can be used in non-emergency applications to track and monitor a user's location—for example, to provide driving directions. Users who prefer not to permit such tracking and monitoring should avoid using such applications.

If you have further questions regarding how the use of your mobile device may impact your privacy or data security, please contact Motorola at privacy@motorola.com, or contact your service provider.

Smart Practices While Driving

Drive Safe, Call SmartSM

Check the laws and regulations on the use of phones and their accessories in the areas where you drive. Always obey them. The use of these devices may be prohibited or restricted in certain areas—for example handsfree use only. Go to www.motorola.com/callsmart (in English only) for more information.

Your mobile device lets you communicate by voice and data—almost anywhere, anytime, wherever wireless service is available and safe conditions allow. When driving a car, driving is your first responsibility. If you choose to use your phone while driving, remember the following tips:

- **Get to know your Motorola mobile device and its features such as speed dial and redial.** If available, these features help you to place your call without taking your attention off the road.
- **When available, use a handsfree device.** If possible, add an additional layer of convenience to your phone with one of the many Motorola Original handsfree accessories available today.
- **Position your mobile device within easy reach.** Be able to access your phone without removing your eyes from the road. If you receive an incoming call at an



inconvenient time, if possible, let your voice mail answer it for you.

- **Let the person you are speaking with know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.** Rain, sleet, snow, ice, and even heavy traffic can be hazardous.
- **Do not take notes or look up phone numbers while driving.** Jotting down a “to do” list or going through your address book takes attention away from your primary responsibility, driving safely.
- **Dial sensibly and assess the traffic; if possible, place calls when your car is not moving or before pulling into traffic.** If you must make a call while moving, dial only a few numbers, check the road and your mirrors, then continue.
- **Do not engage in stressful or emotional conversations that may be distracting.** Make people you are talking with aware you are driving and suspend conversations that can divert your attention away from the road.
- **Use your mobile device to call for help.** Dial 911 or other local emergency number in the case of fire, traffic accident, or medical emergencies (wherever wireless phone service is available).
- **Use your mobile device to help others in emergencies.** If you see an auto accident, crime in progress, or other serious emergency where lives are in

danger, call 911 or other local emergency number (wherever wireless phone service is available), as you would want others to do for you.

- **Call roadside assistance or a special non-emergency wireless assistance number when necessary.** If you see a broken-down vehicle posing no serious hazard, a broken traffic signal, a minor traffic accident where no one appears injured, or a vehicle you know to be stolen, call roadside assistance or other special non-emergency wireless number (wherever wireless phone service is available).

index

A

- accessories 8
- active phone line 35
- advanced calling 14
 - call waiting 14
- alert
 - set 38, 62
 - turn off 38, 57
- answer a call 13
- audio formats 42
- auto replies 25

B

- backlight 63
- battery charging 12
- battery indicator 35
- battery installation 11

- Bluetooth 54
 - connect 55
 - send information 56
 - setting your phone 54
 - turning on or off 54

C

- call
 - answer 13
 - any key answer 14
 - end 13
 - make 13
- call forward 58
- caller ID 58
- camera 43
 - media center 44
 - self-timer 44
- center key 38

- center select key 8
- contacts 64
 - edit/delete 16
 - set ringer ID 16

D

- datebook 64
 - create events 64
 - receive events via PTT 65
 - setup 65
 - view reminders 64
 - dial a phone number 13
 - diald calls 57
 - display 34
 - drafts
 - see also text messages,
drafts
- 22

- E**
earpiece volume 38
emergency number 60
end a call 13
end key 13
- F**
frequently asked questions
 service and repairs 73
- G**
GPS enabled
 emergency calls 60
GPS, see GPS enabled
- H**
handsfree speaker 38
hearing aid 39
Hearing Aid Compatibility 80
home screen 34
- I**
image formats 43
international calls 60
- L**
low battery message 35
- M**
main menu 35
make a call 13
media center 42
message center
 text messages 23
message indicator 35
messaging 17
- N**
navigation key 8, 38
- O**
one touch PTT 52
optional accessory 8
optional feature 8
- P**
packet data 35
phone number 17
power key 2
private calls
 answer 15
 call alerts 14
 make 14
 receive a call alert 15
PT Manager 53
PTX features 45
- R**
radio frequency 68
received calls 57
recent calls 57

- recycling 82
- redial 58
- ring style indicator 35
- ring style, setting 38
- ring tones
 - off 62
 - setting 62
 - vibrate 62, 63
- ring tones, setting 62
- ringer volume 38

S

- safety
 - radio frequency 68
 - RF energy interference 69
- safety information 68
- safety tips 84
- security 41
- send key 13
- signal strength indicator 34

- SIM card 9
 - change SIM PIN 41
 - enable SIM PIN 41
- soft keys 34
- speaker 35
- speed dial 61
- store your number 17

T

- text entry 35
 - alpha method 37
 - word method 36
- text messages 17
 - creating 17
 - deleting 28
 - drafts 22
 - memory 29
 - message center 23
 - receiving
 - resend messages 27
 - sending 17
 - sent messages 28

V

- video formats 43
- voice names 59
- voicemail 61
 - message indicator 61
 - receiving 61
 - setting up 61
- volume 38

W

- wallpaper 64
- WHO information 81

Y

- your phone number 17

www.motorola.com



NNTN7762A