

Cat. No. 43-931

OWNER'S MANUAL

Please read before using this equipment.



System 931

**79-Memory Caller ID
with Dial Back**



RadioShack®

WARNING: To reduce the risk of fire or shock hazard, do not expose this product to rain or moisture.

	CAUTION RISK OF ELECTRIC SHOCK. DO NOT OPEN.	
CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER OR BACK. NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED PERSONNEL.		



This symbol is intended to alert you to the presence of un-insulated dangerous voltage within the product's enclosure that might be of sufficient magnitude to constitute a risk of electric shock. Do not open the product's case.



This symbol is intended to inform you that important operating and maintenance instructions are included in the literature accompanying this product.

**© 1998 Tandy Corporation.
All Rights Reserved.
RadioShack is a registered trademark used by Tandy Corporation.**

FEATURES

Your RadioShack System 931 79-Memory Caller ID with Dial Back is the latest in telephone technology. The system displays the caller's telephone number (and name, if available in your area) and the current date and time, as provided by your local phone company to Caller ID service subscribers. (The date and time are set when your Caller ID receives its first call.)

The System 931 stores and displays up to 79 multiple (name and number) Caller ID records, and includes these features:

Easy Installation — the system easily connects to your telephone line so you can quickly begin using it.

Call Summary — displays the number of new calls, total number of calls you received, the phone number, date and time you received and the caller's name.

Note: Check with your local phone company regarding name service availability.

New Call Indicator — flashes when you have new calls to review.

VIP Call List — lets you save up to 20 important call records so they will not be deleted when you delete other calls from the system's memory.

Dial Back — lets you redial a telephone number stored in the Caller ID call record memory.

Record Scrolling — lets you easily look through all call records in Caller ID memory.

Trilingual Operation — lets you set the system to display messages in English, French, or Spanish.

Liquid Crystal Display — makes it easy to see caller information and the current time and date.

Contrast Control — lets you adjust the display contrast for the best readability.

Time and Date Display — displays the current time and date as provided to Caller ID service subscribers by your local telephone company.

Mounting Options — you can place the system on a desk, shelf, or table, or mount it on a wall.

Note: Your system requires four AAA batteries (not supplied) to protect its memory during a power outage.



This system has been tested and found to comply with all applicable ETL and FCC standards.

We recommend you record the system's serial number here. The number is on the system's bottom panel.

Serial Number: _____

Important Information:

- To use this system, you must be in an area where Caller ID service is available, and you must subscribe to the service.
- Where Caller ID is offered, one or more of the following options are generally available:
 - Caller's number only
 - Caller's name only
 - Caller's name and number

Your system displays the caller's name only if that option is available in your area.

- The actual number of Caller ID records your system will store depends on the amount of Caller ID information sent by the phone company.

FCC INFORMATION

We have designed your system to conform to federal regulations, and you can connect it to most telephone lines. However, each system (and each device, such as a telephone or answering machine) that you connect to the telephone line draws power from the telephone line. We refer to this power draw as the device's *ringer equivalence number*, or REN. The REN is on the bottom of the system.

If you use more than one telephone or other device on the line, add up all of the RENs. If the total is more than five, your telephone might not ring. In rural areas, a total REN of three might impair ringer operation. If ringer operation is impaired, remove a device from the line.

Your system complies with Part 68 of *FCC Rules*. You must, upon request, provide the FCC registration number and the REN to your telephone company. Both numbers are on the bottom of the system.

Note: You must not connect your system to:

- Coin-operated systems
- Party-line systems
- Most electronic key telephone systems


In the unlikely event that your system causes problems on the phone line, the phone company can temporarily disconnect your service. If this happens, the phone company attempts to notify you in advance. If advance notice is not practical, the phone company notifies you as soon as possible and advises you of your right to file a complaint with the FCC.

Also, the phone company can make changes to its lines, equipment, operations, or procedures that could affect the operation of this system. The telephone company notifies you of these changes in advance, so you can take the necessary steps to prevent interruption of your telephone service.

This equipment complies with the limits for a Class B digital device as specified in Part 15 of *FCC Rules*. These limits provide reasonable protection against radio and TV interference in a residential area. However, your equipment might cause TV or radio interference even when it is operating properly. To eliminate interference, you can try one or more of the following corrective measures:

- Reorient or relocate the TV or radio's receiving antenna
- Increase the distance between the equipment and the radio or TV
- Use outlets on different electrical circuits for the equipment and the radio or TV




Consult your local RadioShack store if the problem continues.



CONTENTS



Pls add the contents



PREPARATION

INSTALLING BATTERIES

You need four AAA batteries (not supplied) to protect the system's memory during a power failure. For the longest operation and best performance, we recommend alkaline batteries, such as RadioShack Cat. No. 23-558.

Cautions:

- Always use fresh batteries of the required size and recommended type.
- Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.

Follow these steps to install batteries.

Notes:

- When you replace the batteries, do not press any buttons on the system after you remove the old batteries. Doing so could erase all stored information.
- When replacing the batteries, have fresh ones on hand before you begin. If you do not install the new batteries within about 2 minutes after removing the old ones, you will lose all the information stored in the system.

1. Make sure the system is unplugged from the telephone line.
2. If you are *replacing* the batteries, unplug both modular line cords from the back of the system.
3. Use a Phillips screwdriver to remove the screw in the battery compartment cover.
4. Slide the battery compartment cover in the direction of the arrow, then lift open the cover.

(illus)

Caution: The battery compartment cover is attached to the system. Do not try to remove it completely.

5. Put four fresh AAA batteries into the compartment as indicated by the polarity symbols (+ and -) marked inside.
6. Close the cover and secure it with the screw. If you are replacing the batteries, reconnect the phone line and the phone.

(illus)

When **BATT** appears or the display dims, replace the batteries.

Cautions:

- Always remove old or weak batteries. Batteries can leak chemicals that can damage your system.
- Dispose of dead batteries promptly and properly. Do not bury or burn them.

CONNECTING THE SYSTEM

The System 931 connects to any modular phone jack and your phone. You can also connect it to an answering machine.

Cautions:

- Never install telephone wiring during a lightning storm.
- Never touch uninsulated telephone wires or terminal, unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.

Connecting to a Single-Line Phone

(illus)

1. Disconnect the telephone line cord from the phone and plug it into the system's **LINE** jack.
2. Plug one end of the supplied line cord into the system's **PHONE** jack.
3. Plug the other end of the cord into the phone's jack.

Connecting to a Two-Line Phone

To record information about calls received on a two-line phone, you can connect two System 931s using a triplex adapter such as Cat. No. 279-402 (not supplied). Each system only records information about calls received on the line to which it is connected.

Follow these steps to connect two System 931s to a two-line phone.

(illus)

1. Disconnect the telephone line cord from the modular phone jack (on the wall) and plug it into **L1 + L2** on the triplex adapter.
2. Plug the triplex adapter into the modular phone jack.
3. Plug one end of the supplied line cord into the **LINE** jack on one of the systems.
4. Plug the other end of the cord into either **L1** or **L2** on the triplex adapter.
5. Repeat Steps 3 and 4 to connect another system to the remaining open jack (**L1** or **L2**) on the triplex adapter.

Connecting to an Answering Machine

(illus)

1. Plug a telephone line cord into the modular jack and plug it into the system's **LINE** jack.
2. Plug one end of the supplied line cord into the system's **PHONE** jack and plug the cord's other end into the answering machine's jack.
3. Plug a third telephone line cord into the answering machine and the phone.
4. Set your answering machine to answer after two or more rings. This gives the System 931 time to record the call information that the phone company sends between the first and second rings.

MOUNTING THE SYSTEM

You can place the system directly on a desk, shelf, or table by itself or attach the supplied mounting bracket if you want the system to sit up at an angle. Or, you can use the bracket to mount the system on a wall.

Attaching the Mounting Bracket

(illus)

1. Align the keyhole slots on the bottom of the system with the hooks on the mounting bracket.
2. Gently push the system down on the bracket to secure it.

If you are placing the system on a desk, shelf, or table, pull out the stand on the back of the bracket until it clicks.


To remove the system from the bracket, press up from the bottom of the system until it snaps off the bracket.

Mounting on a Wall

To mount the system on the wall, you need two screws (not supplied) with heads larger than the keyhole slots on the back of the mounting bracket.


Follow these steps to mount the system on a wall.

1. Using the keyholes in the supplied mounting bracket as a template, mark the mounting screw locations on the wall.
2. Drill a hole in the wall at each marked location.




3. Thread a screw through each hole, letting the head extend $\frac{1}{8}$ inch from the wall.
4. Attach the mounting bracket to the system (see "Attaching the Mounting Bracket" on Page x).
5. Route the phone line cords through the slots on the back of the bracket.

(illus)



6. Line up the keyhole slots on the bracket with the screws in the wall, then slide the system down onto the screws until it is secure.

(illus)



ADJUSTING THE DISPLAY CONTRAST

To lighten or darken the display, press **ERASE** and **REVIEW** ◀ buttons until **CONTRAST ADJUST** appears in the display. To scroll through the contrast setting, press the **REVIEW** ▶ button.

CHOOSING A LANGUAGE

Your System 931 is programmed to display messages in English, but you can change it to display in French or Spanish. Follow these steps to change the language.

1. Hold down ◀**REVIEW** and **CALL BACK** buttons for about 3 seconds until the current language (**ENGLISH**, **ESPANOL** for Spanish, or **FRANCAIS** for French) appears.
2. Press **REVIEW** ▶ until the language you want appears.
3. When you release the **REVIEW** button, new language is set.

Note: If you don't press any button within 10 seconds, the unit will go to time calendar.

SETTING LOCAL AREA CODE

Before receiving calls, you should enter your local area code.

1. Hold down both **REVIEW** buttons until **LOCAL AREA CODE** appears.
2. To change the first digit, press **REVIEW ►** until the desired digit appears, then press **DELETE** button to confirm.
3. Repeat Step 2 for setting the second and third digit.
4. Leave the system alone without pressing any button, or press **◀REVIEW** to the idle mode.

OPERATION

RECEIVING AND STORING CALLS

Caller ID is a service provided by your telephone company. When you subscribe to this service, the telephone company sends the caller's telephone number (and name, if available) and the call's date and time between the first and second rings. The system receives and displays this information for each call and updates the display with the current date and time. Your system saves up to 79 call records, then replaces the oldest call record with each new one.

During an incoming call, the red new call indicator flashes, the display lights, and **NEW** and **TOTAL** number of calls appear.

REVIEWING CALL RECORDS

Each time you receive a call, the system saves a call record in memory that you can see while you are on the phone or review later.

Each call record includes the time and date of the call, the call number (order the call is received), the caller's telephone number, and the caller's name (if available).

(illus)



To scroll through the call records, repeatedly press (or hold down) ◀**REVIEW** or **REVIEW** ▶ .

Notes:

- If no call information is stored, **-NO CALL-** appears when you press ◀**REVIEW** or **REVIEW** ▶ .
- If you do not press a button within about 10 seconds, the system automatically returns to the time and date display.
- After you review all calls, **-END OF LIST-** appears. Simply press ◀**REVIEW** to view the calls again.

REDIALING FROM CALL RECORD MEMORY

To redial a telephone number stored in the Caller ID call record memory, press either **REVIEW** button to view the desired call record.

1. Lift the handset of your touchtone telephone and confirm the presence of dial tone.
2. Press the **CALL BACK** button to redial the telephone number observed in the display.
3. If the number to be redialed is out of your area code, dial "1" on your telephone before pressing the **CALL BACK** button.

Displayed Call Information

The system can display the following information.

Display (English, French, Spanish)	Description
REPT	Appears with a number if you have received a call from the same phone number more than once.
LONG DISTANCE LONGUE DISTANCE LARGA DISTANCIA	Appears along with LDC (long distance call) if your phone company sends information indicating that the incoming call is long distance.
-UNKNOWN NAME- -NOM INCONNU- -NOM DESCONOCIDO	The incoming call is from an area that does not send Caller ID name information.
UNKNOWN NUMBER NUMERO INCONNU NUM DESCONOCIDO	The incoming call is from an area that does not send Caller ID number information.
UNKNOWN CALLER APPELER INCONNU DESCONOCIDO	The incoming call is from an area that does not send any Caller ID information.
-BLOCKED NAME- -NOM BLOQUE- -NOMBRE PRIVADO	The caller has blocked the Caller ID name information from being sent.

Display (English, French, Spanish)	Description
BLOCKED NUMBER -NUMERO BLOQUE- NUMERO PRIVADO	The caller has blocked the Caller ID number information from being sent.
BLOCKED CALL APPEL BLOQUE LLAMADA PRIVADA	The caller has blocked any Caller ID information from being sent.
-SERVICE ERROR- ERREUR DE LIGNE ERROR EN LINEA	Call information was distorted before reaching the system. Normal static on the telephone can cause this message. If it happens often, contact your phone company.
BATT	Appears when battery level is low.
-NO CALL- -PAS D APPEL- -NO LLAMADA-	No call information is stored in the system.
NEW NOUV NUEVO	The system has received incoming calls that have not been reviewed.
TOTAL TOT. TOTAL	The total number of incoming calls (not included VIP calls).

Display (English, French, Spanish)	Description
#NEW	Indicates it is a new call that has not been reviewed.
-RECORD STORED- -MEMORISE- -MEMORIZADO-	The caller ID record is stored in VIP memory.
VIP	VIP memory is active.
-VIP MEMO FULL-- -VIP PLEIN- -VIP LLENO-	Appears when no new VIP number can be entered.
DELETE ALL? EFFALER TOUT? BORRAR TODD?	Delete all numbers from memory.
-NO DATA SENT- -PAS DE DONNEES -NO ENVIADO-	Call information was not sent by the phone company.

DELETING CALLS

Deleting a Single Call

1. Repeatedly press (or hold down) either **REVIEW** key until you see the call record you want to delete.
2. Press **DELETE** button. The system deletes that record and automatically renumbers the remaining call records. After 10 seconds, the time and date reappears.

(illus)

Deleting All Calls

1. While the system displays the time and date, press either **REVIEW** key.
2. Hold down **DELETE** until the system displays **DELETE ALL?**
3. While **DELETE ALL?** appears, press **DELETE** again. **NO CALL-** appears.

Or, to cancel deletion, do not press any button. After about 10 seconds, **DELETE ALL?** disappears.

VIP CALL LIST

Your system lets you save up to 20 call records in its VIP call list so they will not be deleted if you delete all calls from the system's memory. This lets you save a list of important callers.

Follow these steps to store call records in the VIP call list.


1. Repeatedly press either **REVIEW** key until you see the call record you want to store as a VIP call.
2. Hold down **VIP** button until **VIP** flashes and **-RECORD STORED-** appears. The system stores the call record as a VIP call record.

(illus)

Note: If the system's memory is full (20 VIP call records are already stored), **-VIP MEMO FULL-** appears when you press **VIP** button. To store another VIP call record, you must first delete an existing one.




To review VIP call records, repeatedly press either **REVIEW** key.

- To delete a VIP call record, select the call record you want to delete, then press **DELETE**.



To delete all entries from the VIP call list, hold down **DELETE** until **DELETE ALL?** appears. Press **DELETE** to confirm.

Or, to cancel deletion, do not press any button. After about 10 seconds, **DELETE ALL?** disappears.



TROUBLESHOOTING

If your system is not working as it should, these suggestions might help you eliminate the problem.

Problem	Solution
Blank screen	The System 931 is not receiving power. Make sure the batteries are installed.
	Adjust the contrast as described in "Adjusting the Display Contrast" on Page x.
	Check if you have ordered caller ID service from your local telephone company.
No dial tone on the phone attached to the caller ID unit	Check all cabling to make sure that all connections are secure.
	Check installation.
	Disconnect the caller ID unit and reconnect phone to find out if the phone works without the caller ID unit.

Problem	Solution
You have an incoming call, but do not receive any Caller ID information.	You answered the call before the System 931 received the call information. Wait until your phone rings at least 2 times before answering a call.
Problem	Solution
Alarm time can be set, but there is no alarm action.	The system has no alarm action.

If you see a message that you do not understand, see "Displayed Call Information" on Page x.

CARE AND MAINTENANCE

Your RadioShack System 931 79-Memory Caller ID with Dial Back is an example of superior design and craftsmanship. The following suggestions will help you care for your system so you can enjoy it for years.



Keep the system dry. If it gets wet, wipe it dry immediately. Liquids might contain minerals that can corrode the electronic circuits.



Use and store the system only in normal temperature environments. Temperature extremes can shorten the life of electronic devices and distort or melt plastic parts.



Keep the system away from dust and dirt, which can cause premature wear of parts.



Handle the system gently and carefully. Dropping it can damage circuit boards and cases and can cause the system to work improperly.





Wipe the system with a damp cloth occasionally to keep it looking new. Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the system.

Modifying or tampering with the system's internal components can cause a malfunction and might invalidate your system's warranty and void your FCC authorization to operate it. If your system is not performing as it should, take it to your local RadioShack store for assistance. If the trouble is affecting the telephone lines, the phone company can ask you to disconnect your system until you have resolved the problem.


LIGHTNING

Your system has built-in protection circuits to reduce the risk of damage from surges in phone line or power line current. These protection circuits meet or exceed FCC requirements. However, lightning striking the phone line can damage your system.

Lightning damage is not common. However, if you live in an area that has severe electrical storms, we suggest you unplug your system during storms to reduce the possibility of damage.




Pls add one year warranty



RadioShack
A Division of Tandy Corporation
Fort Worth, Texas 76102

Printed in China



12A8

