

Where Do I Find Everything I Need for Process Measurement and Control? OMEGA...Of Course!

TEMPERATURE

- ✓ Thermocouple, RTD & Thermistor Probes, Connectors, Panels & Assemblies
- ✓ Wire: Thermocouple, RTD & Thermistor
- ✓ Calibrators & Ice Point References
- ✓ Recorders, Controllers & Process Monitors
- ✓ Infrared Pyrometers

PRESSURE, STRAIN AND FORCE

- ✓ Transducers & Strain Gauges
- ✓ Load Cells & Pressure Gauges
- ✓ Displacement Transducers
- ✓ Instrumentation & Accessories

FLOW/LEVEL

- ✓ Rotameters, Gas Mass Flowmeters & Flow Computers
- ✓ Air Velocity Indicators
- ✓ Turbine/Paddlewheel Meters
- ✓ Totalizers & Batch Controllers

pH/CONDUCTIVITY

- ✓ pH Electrodes, Testers & Accessories
- ✓ Benchtop/Laboratory Meters
- ✓ Controllers, Calibrators, Simulators & Pumps
- ✓ Industrial pH & Conductivity Equipment

DATA ACQUISITION

- ✓ Data Acquisition & Engineering Software
- ✓ Communications-Based Acquisition Systems
- ✓ Plug-in Cards for Apple, IBM & Compatibles
- ✓ Datalogging Systems
- ✓ Recorders, Printers & Plotters

HEATERS

- ✓ Heating Cable
- ✓ Cartridge & Strip Heaters
- ✓ Immersion & Band Heaters
- ✓ Flexible Heaters
- ✓ Laboratory Heaters

ENVIRONMENTAL MONITORING AND CONTROL

- ✓ Metering & Control Instrumentation
- ✓ Refractometers
- ✓ Pumps & Tubing
- ✓ Air, Soil & Water Monitors
- ✓ Industrial Water & Wastewater Treatment
- ✓ pH, Conductivity & Dissolved Oxygen Instruments

M-4047 / 0304

User's Guide



<http://www.omega.com>
e-mail: info@omega.com

LVH-200 Series Horizontal Mini-Float Level Switch

SPECIFICATIONS

Step One


Specifications:

- Accuracy: ± 5 mm in water
- Repeatability: ± 2 mm in water
- Extreme orientation: ± 20° from horizontal
- Specific gravity: 0.55 minimum
- Reed type: Dry contact SPST
- Reed voltage: 120/240, 0-30 VDC @ 20 VA
(CE: 30 Vrms and 42.2 V peak or 60 Vdc)
- Reed output: Selectable NO or NC
- Temperature rating: F: -40° to 225°
C: -40° to 107.2°
- Pressure rating: 100 psi
- Probe material: Polypropylene (PP)
- Mounting threads: 1/2" NPT
- Cable length: 2 ft. (61 cm), 2-wire, 22 AWG
- CE Compliance: EN 60730

Switch Ratings - Maximum Resistive Load -

VA	Volts	Amps AC	Amps DC
20	0-30	0.4	0.3
	120	0.17	0.13
	240	0.08	0.06

Dimensions: LVH-200 series



WARNING: These products are not designed for use in, and should not be used for, patient connected applications. The information contained in this document is believed to be correct but OMEGA Engineering, Inc. accepts no liability for any errors it contains, and reserves the right to alter specifications without notice. This information is provided for informational purposes only. OMEGA will add the CE mark to every appropriate device upon certification.

It is the policy of OMEGA to comply with all worldwide safety and EMC/EMI regulations that apply. OMEGA is constantly pursuing certification of its products to the European New Approach Directives. OMEGA will add the CE mark to every product that complies with these requirements.

USA and Canada: Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA
Customer Service: 1-800-822-9436 / 1-800-USA-OMEGA
TELE FAX: 996404 EASYLINK: 62968994 CABLE: OMEGA
TEL: (95) 800-TC-OMEGA
En Español: (203) 359-1660 ext: 2203 e-mail: espanol@omega.com

Mexico and Latin America: En Español: (203) 359-1660 ext: 2203 e-mail: espanol@omega.com

Benelux: Postbus 8034, 1180 LA Amsterdam, The Netherlands
Tel: (31) 20 641805
Tel: (31) 20 643443
e-mail: nl@omega.com

Czech Republic: Opatavská 767, 733 01 Karvina
Tel: (49) 6311899
e-mail: cz@omega.com

France: 9 rue Denis Papin, 78190 Trappes
Tel: (33) 138-621-800
Tel: (33) 130-699-120
e-mail: france@omega.com

Germany/Austria: Daimlerstrasse 26, D-75392 Deckenbrunn, Germany
Tel: (49) 07056) 3017
Tel: (49) 07056) 8540
e-mail: germany@omega.com

United Kingdom: 25 Swannington Road, Brougham Ashley, Leicestershire, LE9 6TU, England
Tel: 44 (1455) 283520
Tel: 44 (161) 777-6611
Tel: 44 (161) 777-6622
FAX: 44 (161) 777-6622
Toll Free in England: (800) 488-488
e-mail: uk@omega.com

USA: One Omega Drive, Box 4047
Stamford, CT 06907-0047
Tel: (203) 359-1660
e-mail: info@omega.com

Canada: 976 Bognar
Laval (Quebec) H7L 5A1
Tel: (514) 856-6928
FAX: (514) 856-6886
e-mail: canada@omega.com

For immediate technical or application assistance:
Sales Service: 1-800-826-6342 / 1-800-TC-OMEGA
Customer Service: 1-800-822-9436 / 1-800-USA-OMEGA
TELE FAX: 996404 EASYLINK: 62968994 CABLE: OMEGA
TEL: (95) 800-TC-OMEGA
En Español: (203) 359-1660 ext: 2203 e-mail: espanol@omega.com

Service North America:
Tel: (203) 359-1660
Tel: (203) 359-7700
FAX: (203) 359-7700
e-mail: info@omega.com

OMEGA.net - On-Line Service
<http://www.omega.com>

Internet e-mail
info@omega.com

RETURN REQUESTS / INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence to the purchaser.

FOR NON-WARRANTY RETURNS, please have the following information available BEFORE contacting OMEGA:

1. P.O. number under which the product was PURCHASED.
2. Model and serial number of the product.
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.
© Copyright 1996 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated or reprinted in any electronic medium or machine-readable form, in whole or in part, without prior written consent of OMEGA ENGINEERING, INC.

WARRANTY/DISCLAIMER

OMEGA warrants this unit to be free of defects in materials and workmanship for a period of 13 months from date of purchase. OMEGA Warranty adds an additional one (1) month grace period to the standard one (1) year product warranty to cover handling and shipping time. This ensures that OMEGA's customers receive maximum coverage on each product.

OMEGA's WARRANTY does not apply to defects resulting from any action of the purchaser, including but not limited to misapplication, misuse or other operating conditions outside of OMEGA's control. Components which wear are not warranted, including but not limited to contact points, fuses, and trace.

OMEGA is pleased to offer suggestions on the use of its various products. However, OMEGA neither assumes responsibility for any omissions or errors nor assumes liability for any damages that result from the use of its products with hardware not provided by OMEGA, either verbal or written.

OMEGA warrants only that the parts manufactured by it will be as specified and free of defects. OMEGA MAKES NO OTHER WARRANTIES OR REPRESENTATIONS OF ANY KIND WHATSOEVER, EXCEPTED OR IMPLIED, EXCEPT THAT OF TITLE, AND ALL IMPLIED WARRANTIES INCLUDING ANY CLAIMED LIMITATION OF LIABILITY, THE REMEDIES OF PURCHASER set forth herein are excluded and the total liability of OMEGA with respect to this order, whether based on contract, warranty, negligence, indemnification, strict liability or otherwise, shall not exceed the purchase price of the component upon which liability is based. In no event shall OMEGA be liable for consequential, incidental or special damages.

CONDITIONS: Equipment sold by OMEGA is not intended to be used, nor shall it be used, (1) as a "basic component" under 19 CFR 21 (NRC), used in or with any nuclear installation or activity, or medical application or used on humans. Should any Product(s) be used in or with any nuclear installation or activity, OMEGA assumes no responsibility as set forth in our basic WARRANTY/DISCLAIMER language, and additionally, purchaser will indemnify OMEGA and hold OMEGA harmless from any liability or damage whatsoever arising out of the use of the Product(s) in such a manner.

RETURN REQUESTS / INQUIRIES

Direct all warranty and repair requests/inquiries to the OMEGA Customer Service Department. BEFORE RETURNING ANY PRODUCT(S) TO OMEGA, PURCHASER MUST OBTAIN AN AUTHORIZED RETURN (AR) NUMBER FROM OMEGA'S CUSTOMER SERVICE DEPARTMENT (IN ORDER TO AVOID PROCESSING DELAYS). The assigned AR number should then be marked on the outside of the return package and on any correspondence to the purchaser.

FOR NON-WARRANTY RETURNS, please have the following information available BEFORE contacting OMEGA:

1. P.O. number under which the product was PURCHASED.
2. Model and serial number of the product.
3. Repair instructions and/or specific problems relative to the product.

OMEGA's policy is to make running changes, not model changes, whenever an improvement is possible. This affords our customers the latest in technology and engineering.

OMEGA is a registered trademark of OMEGA ENGINEERING, INC.
© Copyright 1996 OMEGA ENGINEERING, INC. All rights reserved. This document may not be copied, photocopied, reproduced, translated or reprinted in any electronic medium or machine-readable form, in whole or in part, without prior written consent of OMEGA ENGINEERING, INC.

SAFETY PRECAUTIONS

Step Two

⚠ About this Manual:

PLEASE READ THE ENTIRE MANUAL PRIOR TO INSTALLING OR USING THIS PRODUCT. This manual includes information on all models of horizontal mini-float level switches from OMEGA ENGINEERING, LVH-200 series. Please refer to the part number located on the switch label to verify the exact model which you have purchased.

⚠ User's Responsibility for Safety:

OMEGA ENGINEERING manufactures a wide range of liquid level sensors and technologies. While each of these sensors is designed to operate in a wide variety of applications, it is the user's responsibility to select a sensor model that is appropriate for the application, install it properly, perform tests of the installed system, and maintain all components. The failure to do so could result in property damage or serious injury.

⚠ Proper Installation and Handling:

Because this is an electrically operated device, only properly trained staff should install and/or repair this product. Use a proper sealant with all installations. Never overtighten the sensor within the fitting, beyond being hand tight. Always check for leaks prior to system startup.

⚠ Material Compatibility:

The LVH-200 series switch is available in one wetted material. Models LVH-200 series are made of Polypropylene (PP). Make sure that the model you have selected is compatible with the application liquid. To determine the chemical compatibility between the sensor and its application liquids, refer to an industry reference such as the Compass Corrosion Guide (available from Compass Publications, phone 858-589-9636).

⚠ Temperature and Pressure:

The LVH-200 series switch is designed for use in application temperatures up to 107.2 °C, and for use at pressures up to 100 psi.

⚠ Wiring and Electrical:

The supply voltage used for the LVH-200 series should never exceed 120/240 volts AC / 30 volts DC @ 20 VA. CE mark versions should never exceed 30 Vrms and 42.2 Vpeak or 60 VDC. Electrical wiring of the sensor should be performed in accordance with all applicable national, state, and local codes.

⚠ Flammable, Explosive and Hazardous Applications:

The LVH-200 series should not be used within flammable or explosive applications. In hazardous applications, use redundant measurement and control points, each having a different sensing technology. Refer to the National Electric Code (NEC) for all applicable installation requirements in hazardous locations.

⚠ WARNING ⚠

Orientation of the switch is critical. Make sure the switch is positioned correctly.


Avoid installing the LVH-200 series switch in ferromagnetic tanks. Doing so will activate the internal reed switch.

INSTALLATION

Step Three

Through Wall Installation:

OMEGA ENGINEERING's LVH-200 series sensors may be installed through the side wall of a tank. The LVH-200 series has dual male 1/2" NPT threads for installation from the outside of the tank in or the inside of the tank out. If the LVH-200 series is installed in the Outside-In method, then the outer threads may be used for connection



to conduit.

Maintenance:

The LVH-200 series sensor itself requires no periodic maintenance except cleaning as required. It is the responsibility of the user to determine the appropriate maintenance schedule, based on the specific characteristics of the application liquids.

Cleaning Procedure:


- 1. Power:** Make Sure that all power to the sensor, controller and/or power supply is completely disconnected.
- 2. Sensor Removal:** In all through-wall installations, make sure that the tank is drained well below the sensor prior to removal. Carefully, remove the sensor from the installation.
- 3. Cleaning the Sensor:** Use a soft bristle brush and mild detergent, carefully wash the LVH-200 series sensor. Do not use harsh abrasives such as steel wool or sandpaper, which might damage the surface sensor. Do not use incompatible solvents which may damage the sensor's Polypropylene plastic body.
- 4. Sensor Installation:** Follow the appropriate steps of installation as outlined in the installation section of this manual.

ELECTRICAL


Step Four

Signal Outputs (Reed Switch):


Normally Open Operation: Orientate the switch such that float swings down when the switch is dry. In the dry state, the float rests in the lowest position and the circuit is open.




As the switch becomes wet, the float becomes buoyant and circuit closes.



Normally Closed Operation: Orientate the switch such that float rests on top of the switch when the switch is dry. In the dry state, the float rests on the switch and the circuit is closed.



As the switch becomes wet, the float becomes buoyant and circuit opens.




Contact Protection (Reed Switch):


When current is interrupted, the inductance of the load generates a high frequency voltage, which appears across the switch contacts. If the voltage is large enough, it can cause arcing. Arcing can cause the contacts to weld to each other resulting in unreliable switching performance. It is essential to protect the circuit, by suppressing the voltage to prevent arcing.

This can be accomplished through the use of a diode for DC circuits and a resistor-capacitor network for AC circuits.

DC Contact Protection:



AC Contact Protection:




WIRING

Step Five


Wiring to a OMEGA ENGINEERING Controller:

OMEGA ENGINEERING controllers have a built-in 13.5 VDC power supply which provides power to all of OMEGA ENGINEERING's level switches. Alternative controllers and power supplies may also be used with the LVH-200 series switch.

LVCN-100 Series Controller



LVCN-120/-130/-140 Series Controller



Note: The above wiring is for NO operation. For NC operation, rotate the switch 180 degrees.