




**Model: NB447**

## Sport Ear Buds with Modular Cord System



### Using Your New Balance Sport Ear Buds with Foldable Head Band

Your New Balance Ear Buds feature a foldable headband for compact storage. Unfold the headband completely, place it over your head and insert the "L" ear bud in your left ear and the "R" ear bud in your right ear. Adjust the length of the headband for the most comfortable and secure fit.


Your New Balance Sport Ear Buds were designed with a modular cord system. We have provided a 15" iPod/iPhone control cable that is suitable if your music player will be worn in an armband or clipped to your clothing at chest level. We have also provided a 36" cable that is suitable if your music player will be clipped to your belt, placed in your pocket or carried in a fanny-pack. You may connect both cables together in case you want to control your iPod or iPhone and the 15" cable is not long enough.



Connect the male headphone plug of the ear buds to the female headphone jack of either the 15" or 36" headphone cable depending on your wearing preference. Then connect the male headphone plug of the 15" or 36" cable to the headphone jack of your music player. Be sure that the plugs are fully inserted into the jacks. If the plug is not fully inserted you may only hear sound from one earpiece.

### Using the iPod/iPhone Control Cable

Connect the 15" iPod/iPhone cable between your headphones and your iPod/iPhone to perform the following operations with the remote controller mounted on the cable:




To Do This	Action Required
Activate voice control* Answer or end a call	Depress the Master Control for 2 seconds Press the Master Control once to answer call Press the Master Control again to end call
Ignore an incoming call	Depress the Master Control for 2 seconds
Answer a second incoming call and place original call on hold	Press the Master Control once to answer second call Press the Master Control again to return to first call
Answer a second incoming call, and end original call	Depress the Master Control for 2 seconds 2 low tones will confirm end of original call.
Switch between two calls	Press the Master Control once to switch between calls
Play or Pause	Press Master Control once to Play, again to Pause
Skip Track or Chapter Forward	Press Master Control 2 times quickly
Skip Track or Chapter Back	Press Master Control 3 times quickly
Increase Volume Decrease Volume	Press the "+" button Press the "-" button
Activate VoiceOver**	Press and hold the Master Control to hear title and artist of currently playing song
Navigate Playlists using VoiceOver**	Press and hold the Master Control until tone is heard, then release. When the name of the desired playlist is heard, press the Master Control once to select it.

### Using the Accessory Cord Winder Clip


Your New Balance Ear Buds are also supplied with a cord winder clip that may be used to eliminate excess slack in the 36" cable if necessary. If you find that that the 36" cable is too long you can store up to 24" of cable in the cord winder and then clip the cord winder to your clothing.

**1**


open the cord winder using the small tab under the clip

**2**


pass the plug down and through the cover

**3**


pull the cord back up and over the spool

**4**

wrap cord clockwise around the spool to reach desired length

**5**

close the cord winder

**6**

clip it on and go!



## Using the Water Resistant Connection Cover

Your New Balance Ear Buds are also supplied with a silicon sleeve that can be used to cover the connection between the male headphone plug on the Ear Buds and the female headphone jack on the 15" or 36" cable. Use this connection cover if you routinely use your Ear Buds in extremely wet or damp conditions.

Stretch the connection cover over the plug of the Ear Buds as shown. After connecting the male plug of the Ear Buds to the female jack on the 15" or 36" cable. Slide the connection cover down so that it completely covers the plug and jack connection point to seal out excess moisture.

## Safety Information

To protect your hearing, always start listening with the Volume Control of your music player set to a low level and gradually increase the volume to a comfortable listening level.

**IMPORTANT!** Listening at high volume for long periods of time can result in long-term hearing damage. For your safety, do not use headphones if they would prevent you from hearing warning sounds, such as while driving a car or motorcycle, riding a bike, etc.

**NOTE:** In extremely cold or dry air conditions you may notice a slight 'tingling' feeling in your ears when using in-ear headphones. This is the result of the build-up of static electricity in your body. This is normal and not an indication of any problem with your headphones.

