

TABLE OF CONTENT

<u>1. INSTALLATION GUIDE</u>

2. FUNCTION KEYS

2.1 FUNCTIONS OF FRONT PANEL

2.2 FUNCTIONS OF REMOTE CONTROL

<u>3. TROUBLE SHOOTING</u>

3.1 NO POWER

3.2 REMOTE CONTROL NOT FUNCTIONING

3.3 NO DISPLAY OR PICTURE NOT CLEAR

4. ACCESSORIES

5. SPECIFICATIONS

<u>1. INSTALLATION GUIDE</u>

1. On a towel or soft cloth, gently place the monitor unit "facedown" on a stable work surface.

2. Locate the pigtail with the DIN connector.

3. Connect the DIN connector to the interface cable provided.

4. Connect the RED wire to the positive (+) battery terminal.

5. Connect the Black wire to a chassis electrical ground point.

6. Connect the cable with YELLOW RCA jack to Video Input sources for your Video Program material.

7. Connect the cable with RED and WHITE RCA jacks to Audio sources for your Audio Program material.

8. Dome Light Circuit: (NOT SHOWN IN PICTURE) Connect the Black to Ground. Connect one red lead to the dome light circuit that is positive (+) when the door is open. Connect the other red lead to a constant positive (+).



2. FUNCTION KEYS

2.1 FRONT PANEL FUNCTIONS



- POWER: 1. Press the "POWER" button once, it will be "POWER ON." Press it again, it will be "POWER OFF."
- MENU: 1. Pop up the OSD menus. Press the "Menu" button again to enter the OSD menus. When in sub-menu, press. "EXIT" to go back to the main menu.
- UP/DN: 1. Press the "UP/DOWN" key to increase or decrease value 2. Make item selection in OSD menus to increase or decrease parameters as well..



nent
hods
puts.

Press the "Menu key", to display a crosswise bar with digits. Use the INC/DEC keys to adjust the value, and then press the "Menu key" to confirm the adjustment. To have the crosswise bar and digits disappear; press "Exit" to leave the OSD function directly.

<u>3. TROUBLE SHOOTING</u>

3.1 NO POWER

- 1. Make sure the power cable has been pluged in.
- 2. Make sure the plug has 12V~14V, may use another electrical appliance to test it.

3.2 NO FUNCTION OF REMOTE CONTROL

- 1. Make sure the batteries are in good condition and installed properly.
- 2. Make sure the remote control is aiming at the receiver, and there are no obstacles in between.
- 3. Perhaps, it is too far away from the receiver. Normal distance is within 7 meters.

3.2 NO DISPLAY OR NOT CLEAR

- 1. Check the video signal wires if they are connected properly.
- 2. Check the antenna or adjust it.
- 3. Make sure the TV/Video being in proper position.

4. ACCESSORIES

PS2/CAR CABLE INSTALLATION BRACKET USER MANUAL SCREW PACK REMOTE CONTROL

5. SPECIFICATIONS

ITEM	DESCRIPTION
LCD Panel	14.1" TFT
Active Area:	285.7 (W) x 214.3 (H) mm
Resolution:	1024(H) x 3(RGB) x 768(V)
Display Colors:	262,144 colors
Pixel Pitch (mm):	0.279 (H) x 0.279 (V) mm
Backlight Unit:	CCFL Side-light type (four lamp)
Contrast Ratio:	300 : 1
Brightness (cd/m2):	300
Viewing Angle:	Horizontal:63 ^o (typ.,Lift side), 63 ^o (typ.,right
	side)
	Vertical: 45 [°] (typ.,up side), 30 [°] (typ.,down side)
Power Supply:	$DC12V \pm 10\%$ less than 2A
IR Transmitter:	Yes
Power management:	24W power consumption (typ.), less than 3W
	when in backlight sleep mode.
User's Control:	Power on/off, OSD control
System:	1. Auto detection between NTSC/PAL
	2. Sceam is available
Dimensional Outline (mm):	338.0mm (W) x 340.2mm (H) x 52mm (D)
Weight	3.8 kg
Safety Certifications:	UL, FCC, CE, TUV
	Operation Temp.:0~50 degree C
Environmental Condition:	Storage Temp.: -20~60 degree C
	Humidity: 10~90%

* Recommend for use with PYLE'S PLVWH1 wireless headphones.