

# DI 8610

# CHDI 8610

Cooker Hood

Operating and Installation Instructions

---

# Contents

<b>Safety warnings</b>	<b>56</b>
For the User	56
For the Installer	56
<b>Description of the Appliance</b>	<b>58</b>
Extractor version	58
Recirculation Version	58
<b>Hood Operation</b>	<b>59</b>
Control device for grease and charcoal filters	60
Grease filter LED (D)	60
Charcoal filter LED (E)	60
Resetting the saturation indicator	60
<b>Maintenance and care</b>	<b>61</b>
Cleaning the hood	61
Metal grease filter	61
Removing the metal grease filter	61
Charcoal filter	62
Changing the light bulb	63
<b>What to do if</b>	<b>64</b>
<b>Special accessories</b>	<b>65</b>
<b>Technical assistance service</b>	<b>65</b>
<b>Technical Specifications</b>	<b>66</b>
Mounting accessories included	66
<b>Electrical connection</b>	<b>67</b>
Safety warnings for the electrician	67
Installation	68



# Safety warnings

## For the User

- The cooker hood is designed to extract unpleasant odours from the kitchen, it will not extract steam.
- Always cover lighted elements, to prevent excess heat from damaging the appliance. In the case of oil, gas and coal fired cookers it is essential to avoid open flames.
- Also, when frying, keep the deep frying pan on the cooker top/cooker under careful control.
- The hot oil in the frying pan might ignite due to overheating.
- The risk of self-ignition increases when the oil being used is dirty.
- It is extremely important to note that overheating can cause a fire.
- **Never carry out any flambé cooking under the hood.**
- **Always disconnect the unit from the power supply before carrying out any work on the hood, including replacing the light bulb** (take the cartridge fuse out of the fuse holder or switch off the automatic circuit breaker).
- **It is very important to clean the hood and replace the filter at the recommended intervals. Failure to do so could cause grease deposits to build up, resulting in a fire hazard.**

## For the Installer

- When used as an extractor unit, the hood must be fitted with a 150mm diameter hose. Should there already be a pipe of diameter 125 mm that ducts to the outside through the walls or roof, it is possible to use the 150/125 mm reduction flange provided. In this case the hood will be slightly noisier.
- **When installing the hood, make sure you respect the following minimum distance from the top edge of the cooking hob/ring surfaces:**

electric cookers	600 mm
gas cookers	650 mm
coal and oil cookers	700 mm min.
- The national Standard on fuel-burning systems specifies a maximum depression of 0.04 mbar in such rooms.
- The air outlet must not be connected to chimney flues or combustion gas ducts. The air outlet must under no circumstances be connected to ventilation ducts for rooms in which fuel-burning appliances are installed.
- The air outlet installation must comply with the regulations laid down by the relevant authorities.
- When the unit is used in its extractor version, a sufficiently large ventilation hole must be provided, with dimensions that are approximately the same as the outlet hole.
- National and regional building regulations impose a number of restrictions on using hoods and fuel-burning appliances connected to a chimney, such as coal or oil room-

---

heaters and gas fires, in the same room.

- Hoods can only be used safely with appliances connected to a chimney if the room and/or flat (air/environment combination) is ventilated from outside using a suitable ventilation hole approximately 500-600 cm<sup>2</sup> large to avoid the possibility of a depression being created during operation of the hood.
- If you have any doubts, contact the relevant controlling authority or building inspector's office.
- Since the rule for rooms with fuel burning appliances is "outlet hole of the same size as the ventilation hole", a hole of 500-600 cm<sup>2</sup>, which is to say a larger hole, could reduce the performance of the extractor hood.
- If the hood is used in its filtering function, it will operate simply and safely in the above conditions without the need for any of the aforementioned measures.
- When the hood is used in its extractor function, the following rules must be followed to obtain optimal operation:
  - short and straight outlet hose
  - keep bends in outlet hose to a minimum
  - never install the hoses with an acute angle, they must always follow a gentle curve.
  - keep the hose as large as possible (preferably the same diameter as the outlet hole).
- Failure to observe these basic instructions will drastically reduce the performance and increase the noise levels of the extractor hood.

# Description of the Appliance


- The hood is supplied as an extractor unit and can also be used with a filtering function by fitting one charcoal filter (special accessory).
- You will need an original AEG charcoal filter for this function (Available from your local AEG Service Force Centre).

## Extractor version

- The air is discharged to the outside through a pipe, which must be fitted to connection flange **A**. **Fig. 1**.
- In order to obtain the best performance the hose should have a diameter equal to the outlet hole.

For the extractor version this pipe must have a diameter of 150 mm.


Should there already be a pipe of diameter 125 mm that ducts to the outside through the walls or roof, it is possible to use the 150/125 mm reduction flange provided. In this case the hood will be slightly noisier.



**Fig. 1**

## Recirculation Version

- The air is filtered through an activated charcoal filter and returned to the kitchen through the top grill of the outlet pipe.
- You will need an original AEG charcoal filter for the recirculation function. (Available from your local Service Force Centre).
- Fix the deflector using 4 screws  $\text{Ø } 3.5 \times 6.5 \text{ mm}$ . **Fig. 2**.




**Fig. 2**

# Hood Operation

- Best results are obtained by using a low speed for normal conditions and a high speed when odours are more concentrated.  
Turn the hood on a few minutes before you start cooking, you will then get an under pressure in the kitchen. The hood should be left on after cooking for about 15 minutes or until all the odours have disappeared.  
The control switches are located on the unit's front panel:

- A - Main switch, hood off.
- B - Start and choice of motor speed 1-2-3-1-2.....
- C - Indicates speed 1 (LED).
- D - Indicates speed 2 and saturation of the grease filter (LED)
- E - Indicates speed 3 and saturation of the charcoal filter (LED) (flashing LED)
- F - Indicates Intensive speed (LED).
- G - Intensive speed on/off. The Intensive speed runs for 5 minutes:  
If the hood is on when the Intensive speed is activated, the hood reverts to previous speed after 5 minutes.  
If the hood is off when the Intensive speed is activated, the hood will be turned off after 5 minutes.  
To interrupt the Intensive speed, press button A or B.
- H - Light OFF
- I - Light ON



Should the hood or the controls fail to operate: disconnect the power supply for at least 5 seconds, then turn the hood back on again.

## Correct ventilation

If the cooker hood is to work correctly there must be an under pressure in the kitchen. It is important to keep the kitchen windows closed and have a window in an adjacent room open.

## Important

This is not applicable for recirculation. Great care must be taken if the hood is used at the same time as a burner or fireplace (e.g. gas, diesel, coal or wood heaters, water heaters, etc.), as the hood will expel air which is required by these other appliances. In this situation, ensure that a window is open. The negative pressure in the room must not exceed 0,04 mbar to prevent fumes being drawn back into the room by the cooker hood.

## **Control device for grease and charcoal filters**

This hood is fitted with a device that signals when it is necessary to clean the grease filter or the charcoal filter (in the case of recirculation version with charcoal filter).

On delivery, the hood is not supplied with an charcoal filter, so the saturation indicator will be disabled.

If the hood is to be used with a charcoal filter, the saturation indicator light must be enabled as follows:

Press buttons B and G simultaneously and hold them for 3 seconds. At first only the grease filter LED D will light up, but when the charcoal filter LED E lights up the saturation indicator will be enabled.

To disable it: Press buttons B and G again simultaneously and hold them for 3 seconds, until the charcoal filter LED goes out.

### **Grease filter LED (D)**

LED D will start to flash when it is time to clean the grease filter.

Cleaning will be necessary after 40 working hours. Always comply with the maintenance instructions for the grease filter.

### **Charcoal filter LED (E)**

The charcoal filter LED E will start to flash when the charcoal filter needs to be replaced.

This operation is necessary after approximately 160 working hours.

### **Resetting the saturation indicator**

After cleaning or replacing the filters, press button A for 3 seconds until the grease filter LED D or the charcoal filter LED E stops flashing.

# Maintenance and care

- The hood must always be disconnected from the electricity supply before beginning any maintenance work.

## Cleaning the hood

- Clean the outside of the hood using a damp cloth and a mild detergent.
- Never use corrosive, abrasive or flammable cleaning products.
- Never insert pointed objects in the motor's protective grid.
- Wash the outside surfaces using a delicate detergent solution. Never use caustic detergents or abrasive brushes or powders.
- Only ever clean the switch panel and filter grille using a damp cloth and delicate detergents.
- It is extremely important to clean the unit and change the filters at the recommended intervals. Failure to do so will cause grease deposits to build up that could constitute a fire hazard.

## Metal grease filter

- The purpose of the grease filters is to absorb grease particles which form during cooking and it **must** always be used, either in the external extraction or internal recycling function.  
Attention: the metal grease filters must be removed and washed, either by hand or in the dishwasher, every four weeks.




Fig. 3

## Removing the metal grease filter

- First, push the metal grease filter stop backwards, then extract the filter, pulling downwards. Fig. 3.

### Hand washing

- Soak grease filters for about one hour in hot water with a grease-loosening cleaner, then rinse off thoroughly with hot water. Repeat the process if necessary. Refit the grease filters when they are dry.

### Dishwasher

- Place grease filters in the dishwasher. Select the most powerful washing programme and highest temperature, at least 65°C. Repeat the process. Refit the grease filters when they are dry.  
When washing the metal grease filter in the dishwasher a slight discolouration of the filter can occur, this does not have any impact on its performance.

## Charcoal filter

- The charcoal filter should only be used if you want to use the hood in the recirculation function.
- To do this you will need an original AEG charcoal filter (available from your local Service Force Centre).
- **Cleaning/replacing the charcoal filter for UK**  
The charcoal filters cannot be cleaned, we recommend that they should be replaced approximately every three months or more often if the hood is used for more than three hours per day.
- **Cleaning/replacing the carbon filter not for UK**  
Unlike other carbon filters, the LONGLIFE carbon filter can be cleaned and reactivated. At normal use the filter should be cleaned every second month (when using the hood 2,5 hours per day, in average). The best way to clean the filter is in the dishwasher. Use normal detergent and choose the highest temperature (65° C). Wash the filter separately so that no food parts gets stuck on the filter and later causes bad odours. To reactivate the carbon, the filter should be dried in an oven for 10 minutes with a temperature of maximum 100° C.  
After approximately three years of use, the carbon filter should be replaced with a new, as the odour reduction capacity will be reduced.
- **Fitting**  
Remove the frame **i** which supports the filter **h** by unscrewing it from the hood **g** (Fig. 4). Insert the charcoal filter inside the frame and put all parts back in their place.
- **To remove** proceed in the reverse order.
- Always specify the hood model code number and serial number when ordering replacement filters. This information is shown on the registration plate located on the inside of the unit.
- The charcoal filter can be ordered from your local AEG Service Force Centre.




Fig. 4




## Warning

- Failure to observe the instructions on cleaning the unit and changing the filters could cause a fire hazard. You are therefore strongly recommended to follow these instructions.
- The manufacturer declines all responsibility for any damage to the motor or any fire damage linked to inappropriate maintenance or failure to observe the above safety recommendations.

## Changing the light bulb

- Disconnect the cooker hood from the mains supply.
- Remove the lamp cover, use a screw driver as a lever. **Fig. 5.**
- Replace the old bulb with a new one of the same type.
- Refit the lamp cover.
- If the light does not come on, make sure the bulb has been inserted in correctly before contacting your local AEG Service Force Centre.



**Fig. 5**

## What to do if

If your appliance fails to work properly please carry out the following checks.

Symptom	Solution
The cooker hood will not start...	Check that: The hood is connected to the electricity supply. Check that a fan speed has been selected
The cooker hood is not working effectively..	Check that: The fan speed is set high enough for the task. The grease filters are clean. The kitchen is adequately vented to allow the entry of fresh air. If set up for recirculation, check that the charcoal filter is still effective. If set up for extraction, check that the ducting and outlets are not blocked.
The cooker hood has switched off during operation...	The safety cut-out device has been tripped. Turn off the hob and then wait for the device to reset. If the hood has been installed below the heights indicated in the installation instructions the motor will cut-out frequently which will damage the hood.

If after all these checks, the problem persists, contact your local Service Force Centre, quoting the model and serial number.

Please note that it will be necessary to provide proof of purchase for any in-guarantee service calls.

In-guarantee customers should ensure that the above checks have been made as the engineer will make a charge if the fault is not a mechanical or electrical breakdown.

# Special accessories\*

Charcoal filter KF20

E-Nr. 942 120 600

\* Not available in UK, please contact your local Service Force Centre.

## Technical assistance service (not for UK)

You are welcome to telephone our technical assistance service (see list of technical assistance centres) whenever you need information or in the unlikely event of a fault.

When calling, please be ready to specify:

1. **The model code number**
2. **The serial number (E-Nr.)**
3. **The manufacturing number (F-Nr.)**

**This information is shown on the registration plate inside the unit behind the grease filter.**

We reserve the right to change specifications and colours as a result of our policy of continuing technological development.

## Service and spare parts for UK

In the event of your appliance requiring service, or if you wish to purchase spare parts, contact your local AEG Service Force Centre by telephoning: **08705 929 929**

Your call will be automatically routed to the Service Centre covering your post code area. For the address of your local Service Force Centre and further information about Service Force, please visit the website at [www.serviceforce.co.uk](http://www.serviceforce.co.uk)

Please ensure that you have read the section „What to do if....“ as the engineer will make a charge if the fault is not a mechanical or electrical breakdown even the appliance is under warranty. **Please note that proof of purchase is required for in-guarantee service calls.**

### Help us to help you

Please determine your type of enquiry before writing or telephoning.

When you contact us we need to know:

- Your name
- Address and post code
- Telephone number
- Clear and concise details of the fault
- Name and model of the appliance\*
- E number\*

\* This information can be found on the rating plate, which can be seen when the grease filters are removed.

# Technical Specifications

## Dimensions:

Height x Width x Depth (in cm)	80-106,5 x 100 x 65
--------------------------------	---------------------

Maximum absorbed power:	250 W
-------------------------	-------

Motor absorption:	1 x 170 W
-------------------	-----------

Lighting:	4 x 20 W
-----------	----------

Length of the cable:	150 cm
----------------------	--------

## Mounting accessories included

1 Reduction flange Ø 150-125

1 Deflector

6 Wood-screws 6 x 70 mm

6 Wall plugs Ø 10 mm

10 Nuts

8 Metal-screw 3 x 9 mm

14 Metal-screw 4 x 8 mm

10 Metal-screw 4 x 7 mm

---

# Electrical connection (not for UK)

## Safety warnings for the electrician

Before connecting the appliance to the power supply, check that the voltage indicated on the rating plate corresponds to the mains power supply available. Appliances fitted with a plug can be connected to any standard power socket within easy access. Should it be necessary to provide a fixed connection, the hood must only be installed by an electrician authorised by the local electricity board. When installing, an omnipolar disconnector with a distance of at least 3 mm between contacts must be provided.

### Electrical connection

220-240 V – by means of fixed power cable with plug.

(Fixed connection of the appliance must only be carried out by an authorised electrician.)

# Electrical connection for UK only

## Safety warnings for the electrician

The electric outlet should be placed on the wall inside the chimney. The hood has a power cable, 150 cm, with earth connection and the rated voltage is 220 - 240 V.

Connect the hood to the mains supply via a double pole switch which has 3 mm minimum separation between the contacts.

The switch must be accessible at all times.

The following is valid in the United Kingdom only:

- the wire which is coloured green and yellow must be connected to the terminal which is marked with the letter E or by the earth symbol (  $\perp$  ), or coloured green or green and yellow;
- the wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black, -
- the wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

## Installation - Fig. 6-7-8

Expansion plugs are provided to secure the hood to most types of ceilings. However, a qualified technician must verify suitability of the materials in accordance with the type of ceiling. The ceiling must be strong enough to take the weight of the hood.

During electrical connection ensure the power supply is disconnected at the domestic mains switch.

- Adjust extension of the hood support structure, as the final height of the hood depends on this, and remember that with installation completed the hood must be at least 60 cm above the hob top for electric cookers and 75 cm for gas or mixed fuel cookers.
- Fix the two sections of the structure using 8 screws (2).
- Place the ceiling hole diagram directly above the hob top (3 - the centre of the diagram must match the centre of the hob top and the edges must be parallel to the sides of the hob top – the side of the diagram with the wording FRONT corresponds to the control panel side). Prepare the electrical connection.
- Drill as shown (6 holes for 6 wall plugs – 4 plugs for fixture), screw the outer screws leaving a space of about 1 cm. between the screw head and the ceiling (4).
- Fit an exhaust pipe inside the support (5) and connect it to the motor compartment connection ring (exhaust pipe and fixing brackets are not supplied).
- Hook the frame onto the 4 screws (6 - see also step 4).

CAUTION! The side of the support with connection box corresponds to the side of the control panel with hood assembled.

- Tighten the 4 screws (7).
- Insert and tighten another 2 screws in the remaining free holes (8) for secure fixing.
- Carry out the electrical connection (9) to the mains power supply, only turn on the power supply upon completion of assembly.
- Hook the hood onto the support (10) , ensuring it fits properly – to hook the hood onto the support partially tighten 4 screws (see also step 12).
- Secure the hood to the support using two screws (11); this will also help centre the two sections.
- Tighten the 4 screws securing the support to the hood (12).




Fig. 6

- For extractor versions (13A), connect the other end of the exhaust pipe to the flue. For filter versions (13F), fit deflector F to the support and secure it to the bracket supplied using 4 screws, then connect the exhaust pipe to the connection ring located on the deflector.
- Fit the nuts with fixing hooks (14) supplied inside the top and bottom sections of the flues at the rectangular slots. A total of 10 nuts must be fitted.
- Join the two top sections of the flue to cover the support (15) so that one of the slots on the sections is situated on the same side of the control panel and the other on the opposite side. Screw the two sections together with 4 screws (2 each side- see the plan diagram for joining the two sections).
- Fix the top flue assembly to the support, near the ceiling, with two screws (16 - one each side).
- Carry out electrical connection of control panel and bulbs (17).
- Join the two bottom sections of the flue covering the support (18) using 6 screws (3 each side, see the plan diagram for joining the two sections).
- Insert the bottom section of the flue in its seat so that it completely covers the motor compartment and electrical connection box, then ensure it from inside the hood using two screws (19).
- Apply the 2 tabs (20 - supplied) to cover the fixing points of the bottom flue (CAUTION! THE BOTTOM FLUE TABS ARE THE NARROWER AND SHALLOWER ONES).  
The wider and deeper tabs are those used for the top flue, and must be cut to size.
- Turn the mains power on again at the central electrical panel and check for correct hood operation.




Fig. 7



**AEG Hausgeräte GmbH  
Postfach 1036  
D-90327 Nürnberg**

**<http://www.aeg.hausgeraete.de>  
<http://www.aeg.co.uk>**

**© Copyright by AEG**

**LI1R5C**