

GE863-GPS Software User Guide

GE863-GPS Software User Guide
1v0300724 Rev. 2 - 24/01/07



3.5.2	IRA character set	64
3.5.3	Writing a New SMS to storage.....	66
3.5.4	Sending an SMS previously stored.....	67
3.5.5	Sending a new SMS without storing it	68
3.5.6	Deleting an SMS.....	69
3.5.7	Reading an SMS	70
3.5.8	Listing a group of SMSs.....	72
3.6	Using General Purpose Input/Output pins.....	74
3.6.1	GPIO pin setup	74
3.6.2	GPIO pin use	76
3.7	Clock/Alarm function.....	81
3.7.1	Clock date/time.....	81
3.7.2	Alarm function.....	83
4	GPRS operations	88
4.1	Introduction	88
5	GPS operations	91
5.1	Introduction	91
5.2	GE863-GPS Serial Ports	91
5.2.1	GPS SERIAL PORT A (SIRF BINARY)	91
5.2.2	GPS SERIAL PORT B (NMEA).....	91
5.3	WGS 84.....	92
5.4	NMEA 0183.....	93
5.4.1	GGA - Global Positioning System Fixed Data.....	94
5.4.2	GLL - Geographic Position - Latitude/Longitude	95
5.4.3	GSA - GNSS DOP and Active Satellites.....	96
5.4.4	GSV - GNSS Satellites in View	97
5.4.5	RMC - Recommended Minimum Specific GNSS Data	98
5.4.6	VTG - Course Over Ground and Ground Speed	99
5.5	Checking GPS device functionality.....	100
5.5.1	Controlled mode	100
5.6	CONTROLLING GPS RECEIVER.....	101
5.6.1	POWER CONTROL OF GPS RECEIVER	101
5.6.2	GPS RESET.....	102
5.6.3	GPS ANTENNA MANAGEMENT.....	103
5.6.4	GPS PARAMETERS SAVE.....	104
5.6.5	RESTORE GPS PARAMETERS.....	104
5.6.6	READ ACQUIRED GPS POSITION	104
6	Service and firmware update	106
6.1	Step-by-Step upgrade procedure	106
7	Document Change Log	109



1 Overview

The purpose of this document is the description of some common AT command procedures that may be used with the **Telit GE863-GPS module**.

In this document, all the basic functions of a mobile phone will be taken into account and for each one of them, a proper command sequence will be suggested.

In the Advanced operation section the more useful services and features of the GSM network supported by the **Telit GE863-GPS module** is taken into account and some command sequence and usage are provided for each one of them.

This document and its suggested command sequences shall not be considered mandatory; instead, the information given shall be used as a guide for properly using the **Telit module**. For further commands and features that may not be explained in this document refer to the GE863-GPS Product Description document where all the supported AT commands are reported.

NOTE

The information presented in this document is believed to be accurate and reliable. However, Telit Communications S.p.A. assumes no responsibility for its use, nor any infringement of patents or other rights of third parties, which may result from its use. No license is granted by implication or otherwise under any patent rights of Telit Communications S.p.A. other than for circuitry embodied in Telit products. This document is subject to change without notice.



2 Basic Operations

2.1 Command Syntax

In the next paragraphs the following notations are used:

- <cr> represents the Carriage Return Character (13)
- <lf> represents the Line Feed Character (10)
- <xx> represents a parameter whatever name is in place of the xx. (< and > characters are only for delimiting the parameter and **must not** be issued to the terminal).
- [<xx>] represents an optional parameter whatever name is in place of the xx. ([and] characters are only for delimiting the optional parameter and **must not** be issued to the terminal).

2.1.1 Interface Style

The GE863-GPS module is using an AT interface that is defined in the document 80000ST10025a (AT Commands Reference Guide). The specification defines 3 possible AT interfaces:

- 0 - AT command interface of the products, to the GM862-GSM and GM862-GPRS interface style
- 1 – AT interface of the products, to the GM862-PCS, PYTHON, QUAD-PY, TRIZIUM and GE863-QUAD, PY interface style
- 2 - switches the AT command interface style of the product, to the new products like GE864, GC864 and the GPS products

The default interface for the GE863-GPS product is 2.

The switch between the different interfaces could also be performed with the **#SELINT** AT command. Refer to the AT Commands Reference Guide for the full command description.

All the AT commands described in this specification is related to SELINT 2



2.2 Command Response Timeout

Every command issued to the Telit GE863-GPS returns a result response if response codes are enabled (default) (see command ATQn). The time needed to process the given command and return the response varies from command to command and may depend also from the network on which the command may interact. As a result every command is provided with a proper timeout time, if this time elapses without any result from the operation, then the ERROR response is reported as if the operation was not successful.

The timeout time is quite short for commands that imply only internal set up commands, but may be very long for command that interact with the network (or even Networks).



NOTE: In case no response is received after the timeout time has been elapsed, then try repeating the last command and if still no response is received until the timeout time, then an Unconditional Shutdown MUST be issued and then the device shall be powered ON again.


In the table below are listed all the commands whose timeout differs from the default **100 ms** and their effective timeout is reported:

Command	Time-Out (Seconds)
+CBST	0.2
+CR	0.2
+CRC	0.2
+CRLP	0.2
+CSCS	0.2
+CEER	5
+CGMI	5
+CGMM	5
+CGMR	5
+CGSN	20
+CIMI	20
+CNUM	20
+CREG	5
+COPS	180
+CLCK	180
@CLCK	180
+CPWD	180
+CLIP	180
+CLIR	180
+CCFC	180
+CCWA	20
+CHLD	20
+CUSD	180
+CAOC	20
+CSSN	20



2.3 Turning ON the GE863-GPS

To turn on the GE863-GPS the pin ON# must be tied low for at least 1 second and then released.
A simple circuit to do it is:



NOTE: don't use any pull up resistor on the ON# line. Using pull up resistor may bring to latch up problems on the GE863-GPS power regulator and improper power off of the module. The line ON# must be connected only in open collector configuration.



TIP: To check if power has raised it is possible to monitor the PWRMON line, when this line goes high the module is powered on, but before it remains on the device needs other 900 ms for software startup. Hence check the PWRMON line and 900 ms after its transition to high it is possible to release the ON# pin.

When turning on the module, both devices (GSM and GPS) will be started.
The GPS antenna will be supplied and the receiver will start the scanning activity to achieve the Fix.



2.4 Turning OFF the GE863-GPS

The turning off of the device can be done in two ways:

- by software command
- by hardware shutdown

When the device is shut down by software command or by hardware shutdown, it issues to the network a detach request that informs the network that the device will not be reachable any more.

2.4.1.1 Software shutdown

- Send command **AT#SHDN<cr>**
- wait for **OK** response

The device shuts down with the following sequence of activities:

- Detach from the network
- Module Shutdown

In the case of Network unavailability the detach will be attempted few seconds (typical 6secs). After this timeout the module will be shut down.

2.4.1.2 Hardware shutdown

To turn OFF the GE863-GPS the pin ON# must be tied low for at least 2 second and then released. The same circuitry for the power on can be used. The device shuts down after the release of the ON# pin.




TIP: To check if the device has powered off, the hardware line PWRMON should be monitored. When it goes low, the device has powered off.



2.4.1.3 Hardware Unconditional SHUTDOWN

To unconditionally SHUTDOWN the GE863-GPS the pin RESET# must be tied low for at least 200 milliseconds and then released.

A simple circuit to do it is:



NOTE: don't use any pull up resistor on the RESET# line nor any totem pole digital output. Using pull up resistor may bring to latch up problems on the GE863-GPS power regulator and improper functioning of the module. The line RESET# must be connected only in open collector configuration.



TIP: The unconditional hardware RESET should be always implemented on the boards and software should use it as an emergency exit procedure.



2.5.2 SIM presence checking

After autobauding the first thing to check is the SIM presence and PIN code insertion, this can be done with the following commands:

2.5.2.1 Enable the Extended error result codes

- send command **AT+CMEE=1<cr>**
 - wait for **OK** response
- or if you prefer the verbose format instead of the numerical format then:
- send command **AT+CMEE=2<cr>**
 - wait for **OK** response

2.5.2.2 Query SIM presence and status

- send command **AT+CPIN?<cr>**
- wait for response:

Response	Reason	Action
+CPIN: SIM PIN	SIM is present and PIN is required to continue operations	Proceed to par. 2.5.2.3
+CPIN: SIM PUK	SIM is present and 3 attempts to give SIM PIN have failed, so SIM PUK is required	Send command AT+CPIN=<SIM PUK>
+CPIN: READY	SIM is present and no PIN code is required to proceed	Proceed ahead
+CME ERROR: 10	SIM not present	Insert SIM or require SIM insertion and repeat from par. 2.5.2.2
+CME ERROR: 13	SIM defect	Check SIM insertion or require a new SIM not defected and repeat from par. 2.5.2.2
+CME ERROR: 14	SIM is busy	retry later
+CME ERROR: 15	SIM is wrong type	Check SIM, it must be a GSM SIM.



2.5.3.2 Network operator identification

Once the mobile has registered on some network (or even if it has returned +CREG:x,3), it is possible to query the mobile for network identifications codes and names:

- send command **AT+COPS=?<cr>**
- wait for response in the format:
+COPS: [list of supported (<stat> ,<oper (in <format>=0)>),<oper (in <format>=2)>]s[,(list of supported <mode>s), (list of supported<format>s)]

where:

<stat> - operator availability

- 0 - unknown
- 1 - available
- 2 - current
- 3 - forbidden

<format>

- 0 - alphanumeric long form (max length 16 digits)
- 2 - numeric 5 digits [country code (3) + network code (2)]

<oper>: network operator in format defined by **<format>** parameter.

NOTE: since with this command a network scan is done, this command may require some seconds before the output is given.

For example:

command:

AT+COPS=?<cr>

Answer:

+COPS: (2,"I WIND",,"22288"),(1,"SI MOBITEL GSM",,"29341"),(1,"vodafone IT",,"2210"),(1,"SI.MOBIL",,"29340"),(3,"I TIM",,"22201"),(0-4),(0,2)

OK

In this case the mobile is registered on the network "I TIM" which is a network from Italy Nation code :222 and Network ID: 01. There is also another network available for registration:

"SI.MOBIL" which is a network from Slovenia Nation Code:293 and Network ID: 40.

The other networks are not available for registration and are:

"I-OMNITEL" from Italy Nation code :222 and Network ID: 10 - FORBIDDEN

"SI-GSM " from Slovenia Nation Code:293 and Network ID: 41 - UNKNOWN



TIP: In this case a "I TIM" logo might be reproduced on the MMI to give the user the information that is registered on that network.



NOTE: this command issues a network request and it may require a quite long time to respond, since the device has to wait the answer from the network (it can be as long as 60 seconds). Hence don't use it if not needed.



command:


`AT#MONI?<cr>`

Answer:

`#MONI: Cc: 010 Nc: 03 BSIC:23 RxQual:7 LAC:0001 Id:0001 ARFCN: 60 PWR: -83 dBm TA:0`

OK

In this case the mobile is registered on the network whose Country code is 010 and Network operator code is 03, the signal strength is -83dBm (MMI may indicate 4 antenna bars as reported on the table 5). The other information received is strictly technical and should not be given to the user. The values reported are random and have no meaning they are used only to explain command usage.

 **NOTE:** This command should be used only to gather information on network name and signal strength, to check if mobile is registered or is looking for a suitable network to register to, use always the +CREG command. This is due to the fact that if the network signal is too weak and mobile loses the registration, until a new network is found the #MONI command reports the last measured valid values and not the real ones.
The TA (timing advance parameter) is valid only during a call.

 **TIP:** To properly use this feature, check network registration with command +CREG as seen on par. 2.5.3.1 and when mobile is registered query the mobile for network operator name and signal strength with #MONI command.



For example:

1 - Let's assume that the desired audio path is always the internal MT

Command:
AT#CAP=2<cr>
Answer:
OK

2 - Let's assume that the desired audio path has to be determined by HARDWARE pin AXE

Command:
AT#CAP=0<cr>
Answer:
OK

Now set the hardware pin AXE in the desired status.

2.6.1.3 Set the desired volume on the active audio path speaker output

This setting is not strictly necessary; it is also possible to keep the default volume setting.


- Send command **AT+CLVL=<vol><cr>**

where:

<vol> is a number between 0 and 10 representing the volume setting:

- 0 – minimum volume
- 10 - maximum volume

- wait for **OK** response

 **NOTE:** The volume setting refers to the ACTIVE path ear line and is stored each time. When changing audio path the volume setting will be reset to the previously stored value for that audio path.

2.6.1.4 Check for microphone mute setting

The microphone of the active path can be muted with an AT command; to be sure that it is not muted, it is suggested to check it with this command:

- Send command **AT+CMUT?<cr>**

- wait for response in the format:

+CMUT: <mute>

OK

where:

<mute> is the muting setting for the microphone:

- 0 - microphone active



2.6.3 Closing the voice call

2.6.3.1 Hang up the voice call

- Send command **ATH<cr>**
- wait for response **OK**



TIP: during the voice call the device remains in command mode, so the escape sequence (+++) must not be issued before sending commands.



AT+CBST==2, 0, 0	V.22	1200	transparent
AT+CBST==3, 0, 0	V.23	1200/75	transparent
AT+CBST==4, 0, 0	V.22Bis	2400	transparent
AT+CBST==6, 0, 0	V.32	4800	transparent
AT+CBST==7, 0, 0	V.32	9600	transparent
AT+CBST==65, 0, 0	V.110	300	transparent
AT+CBST==66, 0, 0	V.110	1200	transparent
AT+CBST==68, 0, 0	V.110 / X.31	2400	transparent
AT+CBST==70, 0, 0	V.110 / X.31	4800	transparent
AT+CBST==71, 0, 0	V.110 / X.31	9600	transparent

Once selected the appropriate <mod> and <ce> parameters from the table:

- Send command **AT+CBST=<mod>,0,<ce><cr>**
- wait for **OK** response

2.7.2 Phone number dialing (data call)

2.7.2.1 Dial a given phone number

- Send command **ATD <PhoneNumber><cr>**
where:
<PhoneNumber> is the phone number to be dialed

- wait for response:

Response	Reason	Action
CONNECT 9600	The called modem is now on line.	exchange data..
BUSY	The line called is busy	retry later
NO ANSWER	The receiver did not answer the call	retry later
NO CARRIER	The modem handshaking has not been successful	check for mobile registration and signal strength and eventually retry.



TIP: The response to the ATD command is returned after the modem handshaking, this takes about 30 seconds, so allow this time before doing anything.



TIP: When the device is doing the handshake the issue of any character closes the handshake and aborts the call.



For example:

1- Let's assume you have to call the national number 040 - 4192111,

command:

ATD 0404192111<cr>

response

CONNECT 9600

2- Let's assume you have to call the national number but in international format +39-40-4192111,

command:

ATD +39404192111<cr>

response

CONNECT 9600

3- Let's assume you have to call the international number +386-40-4192111,

command:

ATD +386404192111<cr>

response

CONNECT 9600

2.7.3 Closing the Data call

2.7.3.1 Exit the data mode and enter the command mode

- Send escape sequence **+++**
- wait the escape sequence pause time (see S12 parameter)
- wait for response **OK**



NOTE: After the Escape sequence and during the call the only command that is accepted by the GE863-GPS is the ATH. All the other commands are not supported during a call.



TIP: during the escape sequence pause time S12 no further characters should be sent to the device in order to enter the command mode.



+CME ERROR: 17	PIN2 is required to continue operations, since FD facility is not enabled.	SIM. Enable FD facility with +CLCK (see par.3.1.1.2) and retry.
----------------	--	--



NOTE: After power up & PIN authentication the device reads all the SIM for a backup, hence SIM access is inhibited (SIM is busy after the issue of the PIN or after power up if PIN request is disabled) for a time varying from few seconds to about a minute, depending on the percentage of written records in the SIM phonebook. If Phonebook commands are issued during this time the device returns an error message. If this happens, retry the operations later.



NOTE: Due to the particular features of the FD storage, when selecting the FD storage, the PIN2 must have been inserted or the FD facility must have been enabled. If +CPBS command reports +CME ERROR: 17 then enable the facility with command +CLCK (see par. 3.1.1.2)

For example:

1- Let's assume you want to select the "SM" normal phonebook for operations,

command:

AT+CPBS="SM"<cr>

response

OK

2- Let's assume you want to select the "MC" missed calls list for operations,

command:

AT+CPBS="MC"<cr>

response

OK

3.1.1.2 Enable Fixed Dialing Phonebook facility (only for FD PB)

- Send command **AT+CLCK=FD,1,<PIN2><cr>**

where:

<PIN2> is the PIN2 code of the SIM.

- wait for response:

Response	Reason	Action
OK	FD facility is now enabled	Return to select PB (see par. 3.1.1.1)
ERROR	some error occurred	Enable extended result codes (see par. 2.5.2.1), check if the PIN2 is correct



		and retry.
+CME ERROR: 16	the inserted PIN2 is wrong	Check PIN2 code and retry.

NOTE: When receiving the **ERROR** or **+CME ERROR** message, repeat Query SIM presence and status since after 3 failed attempts SIM PIN2 is not anymore requested, but SIM PUK2 is requested instead, hence you may need to go through procedure 2.5.2.4 (but insert PUK2 instead of PUK1)

3.1.2 Phonebook entry search by Name

As first thing, you must select the "SM" storage as active (see par.3.1.1.1).

- send command **AT+CPBF=<Name><cr>**

where:

<Name> is the desired string to be found in the name field of the PB record.

- wait for response in the format:

+CPBF= <index>,"<number>",<type>,"<name>"
OK

where:

<index> is the record number on the PB;

<Number> is the phone number;

<type> is the type of number:

145 – international numbering scheme

129 – national numbering scheme

<Name> is the alphanumeric name associated with the number.

or in the case no corresponding entries are found:

+CME ERROR: 22 or simply **ERROR.**

NOTE: The search for **<name>** string is not case sensitive and the string may or may not be included in double brackets.

For example:

1- Let's assume you want to select the "SM" normal phonebook for operations,

command:

AT+CPBS="SM"<cr>

response

OK

- Now you might want to look for the entries with the name starting with: "FA"



3.2 Distinguish Calls

3.2.1 Identify the Call type

The GE863-GPS is able to identify the call type before answering it, it is so possible to have different ring indications (unsolicited codes) depending on the call type:

Unsolicited code	Reason
RING	The extended format of incoming call indication is disabled and a call (voice or data) is incoming.
+CRING: VOICE	The extended format of incoming call indication is enabled and a voice call is incoming.
+CRING: ASYNC	The extended format of incoming call indication is enabled and an asynchronous transparent data call is incoming.
+CRING: SYNC	The extended format of incoming call indication is enabled and a synchronous transparent data call is incoming.
+CRING: REL ASYNC	The extended format of incoming call indication is enabled and an asynchronous not transparent data call is incoming.
+CRING: REL SYNC	The extended format of incoming call indication is enabled and a synchronous not transparent data call is incoming.
+CRING: FAX	The extended format of incoming call indication is enabled and a fax call is incoming.

In order to use this feature you must enable the extended format of incoming calls



3.2.1.1 Set the extended incoming call indication

- Send command **AT+CRC=<n><cr>**

where:

<n> is the operation mode selected:

- 0 – extended results Disabled (device reports RING only)
- 1 – extended results Enabled (device reports +CRING: <type> indication)

- wait for **OK** response

3.2.2 Identify the Caller

The GE863-GPS is able to identify the caller number and give indication of it before the call is answered.

The calling number is presented after each RING or +CRING indication in the format:

+CLIP: "<number>",<type>["<subaddress>",<satype>["<alpha>"],["<CLI validity>"]]]

OK

where:

<Number> is the phone number;

<type> is the type of number:

- 145 – international numbering scheme
- 129 – national numbering scheme

<subaddress> is the subaddress of the calling party

<satype> is the type of subaddress

<alpha> is an optional string type alphanumeric representation of <number> corresponding to the entry found in phonebook;

<CLI validity> is the validity status of CLI presentation:

- 0 CLI valid.
- 1 CLI has been withheld by the originator.
- 2 CLI is not available due to interworking problems or limitation or originating network.

In order to use this feature you must enable the caller ID indication presentation, if feature is disabled then no CLI indication is given after the RING or +CRING code.



3.2.2.1 Set Caller line ID indication presentation

- Send command **AT+CLIP=<n><cr>**

where:

<n> is the operation mode selected:

- 0 – Calling Line Indication Presentation Disabled
 - 1 – Calling Line Indication Presentation Enabled
- wait for **OK** response

For example:

1- Let's assume you receive a call from the national number 1234567890 and extended incoming calls indication is disabled while CLIP is enabled, you'll see:

ring indication:
RING

+CLIP: "1234567890",129

2- Let's assume you receive a call from the international number +391234567890 and extended incoming calls indication is disabled while CLIP is enabled, you'll see:

ring indication:
RING

+CLIP: "+391234567890",145

NOTE: this does not mean that the incoming call is an international one, it simply means that the numbering scheme used to identify the caller is the international one.

3.2.3 Restricting Calling Line Indication

The GE863-GPS is able to send the calling line indication (CLI) to the other party through the network when an outgoing call is made. This indication can be restricted (CLIR) in various ways:

- CLI sent always
- CLI never sent
- CLI temporary sent (normally not sent)
- CLI temporary not sent (normally sent)



3.2.3.1 CLIR Service status query

- send command **AT+CLIR?<cr>**
- wait for response in the format:
+CLIR: <n>,<m>
OK


where:

<n> is the facility status on the Mobile

- 0 – CLIR facility according to CLIR service network status
- 1 – CLIR facility active (CLI not sent)
- 2 – CLIR facility not active (CLI sent)

<m> is the facility status on the Network

- 0 - CLIR service not provisioned (service unavailable)
- 1 - CLIR service provisioned (service available)
- 2 - unknown (e.g. no network present, etc.)
- 3 - CLI temporary mode presentation restricted
- 4 - CLI temporary mode presentation allowed

 **NOTE: The <m> parameter reports the status of the service at network level. If the CLIR service is not provisioned, then it is not possible to use this service and changing the first parameter <n> will not change the CLI presentation to the other party behavior of the network.**

For example:

1- Let's assume you want to check your CLIR settings:

command:

AT+CLIR? <cr>

response:

+CLIR: 2,4

In this case the CLIR service is temporary mode allowed on the network and the mobile sends the CLI when calling. (CLI Restriction not active).



3.2.3.2 Restrict/Allow Caller line ID indication

- Send command **AT+CLIR=<n><cr>**

where:

<n> is the operation mode selected:

- 0 – Calling Line Indication to the other party According to Network service status.
- 1 – Calling Line Indication Restriction Enabled (CLI not sent)
- 2 – Calling Line Indication Restriction Disabled (CLI sent)

- wait for **OK** response

For example:

1- Let's assume you want to disable the CLI presentation to the other party permanently:

command:

AT+CLIR=1<cr>

response:

OK

3.2.4 Call Barring Control

The call Barring is a GSM service that allows the user to block certain types of calls:

- Barring All Outgoing Calls
- Barring Outgoing International Calls
- Barring Outgoing International Calls except to Home Country
- Barring All Incoming Calls
- Barring Incoming Calls when Roaming outside the home country
- All Barring services (applicable only for disabling command)
- All Outgoing barring services (applicable only for disabling command)
- All Incoming barring services (applicable only for disabling command)

The service can be queried, enabled and disabled.

NOTE: *The call Barring service is handled by the network, hence all the relative commands issue a network request and it may take several seconds to have the response from the network.*

Furthermore, all the Call Barring service commands must be issued when the mobile is Registered on some Network, else an error code is returned (no network service).



2- Let's assume you want to check whether the Outgoing (originated) international calls are barred or not:

command:
AT+CLCK=OI,2<cr>
response:
+CLCK: 1

In this case, the outgoing international calls ARE BARRED.

3.2.4.2 Barring/Unbarring All Incoming Calls

- Send command **AT+CLCK=AI,<en>,<pwd><cr>**

where:

<en> is the operation selected:

- 0 – Call Barring Disable (Unbarring)
- 1 – Call Barring Enable (Barring)

<pwd> is the network password required to change facility status

- wait for response:

Response	Reason	Action
OK	Barring is now enabled/disabled	all incoming calls will be barred/unbarred
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 2.5.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let's assume you want to bar all the incoming calls and the network password of your operator is 0000:

command:
AT+CLCK=AI,1,0000<cr>
response:
OK



- wait for response:

Response	Reason	Action
OK	Barring is now enabled/disabled	all outgoing calls will be barred/unbarred
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 2.5.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let's assume you want to bar all the outgoing calls (originated by mobile) and the network password of your operator is 0000:

command:

`AT+CLCK=AO,1,0000<cr>`

response:

OK

3.2.4.5 Barring/Unbarring All Outgoing International Calls

- Send command **AT+CLCK=OI,<en>,<pwd><cr>**

where:

<en> is the operation selected:

0 – Call Barring Disable (Unbarring)

1 – Call Barring Enable (Barring)

<pwd> is the network password required to change facility status

- wait for response:

Response	Reason	Action
OK	Barring is now enabled/disabled	all outgoing international calls will be barred/unbarred
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax



+CME ERROR: 30	no network service	Check for registration (see par. 2.5.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let's assume you want to bar all the outgoing international calls (originated by mobile and to a number outside the home country of the mobile) and the network password of your operator is 1234:

command:

AT+CLCK=OI,1,1234<cr>

response:

OK

3.2.4.6 Barring/Unbarring All Outgoing International Calls except to Home Country

- Send command **AT+CLCK=OX,<en>,<pwd><cr>**

where:

<en> is the operation selected:

0 – Call Barring Disable (Unbarring)

1 – Call Barring Enable (Barring)

<pwd> is the network password required to change facility status

- wait for response:

Response	Reason	Action
OK	Barring is now enabled/disabled	all outgoing international calls except to Home Country will be barred/unbarred
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 2.5.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let's assume you want to bar all the outgoing international calls except the ones towards the Home Country and the network password of your operator is 1234:

command:



`AT+CLCK=OX,1,1234<cr>`
response:
 OK

3.2.4.7 Unbarring all the Calls

- Send command **AT+CLCK=AB,0,<pwd><cr>**

where:

<pwd> is the network password required to change facility status

- wait for response:

Response	Reason	Action
OK	Barring is now disabled	all calls will be allowed (unbarred)
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CME ERROR: 4	operation not supported, the service required is not available	Check command syntax
+CME ERROR: 30	no network service	Check for registration (see par. 2.5.3.1) and signal strength.
+CME ERROR: 16	wrong network password	check network password and retry

For example:

1- Let's assume you want to disable all the barring services you might have previously activated and the network password of your operator is 0000:

command:

`AT+CLCK=AB,0,0000<cr>`

response:

OK



3.3 DTMF tones

DTMF tones are managed by specific AT commands. These tones are generated with AT commands only during voice calls. The minimum duration of a DTMF tone can be set on 10 ms but it should be considered that this value can vary with the limitations on network.

Group low	Group high		
	1209 Hz	1336 Hz	1477 Hz
697 Hz	1	2	3
770 Hz	4	5	6
852 Hz	7	8	9
941 Hz	*	0	#

NOTE: The GSM system architecture defines that the audio signal of the DTMF tones is inserted by the network switches on commands sent by the Mobile Station (MS). Thus, the default duration parameters may vary from network to network. In case that the devices to be controlled by DTMF are sensitive related to the duration of the tones and timing of the sequences, dedicated investigations on the parameter settings have to be made.



3.5 SMS handling

The Telit GE863-GPS supports the Short Message Service, it is possible to store, delete, write, send and receive a SMS, which is a short text message up to 160 characters long.

3.5.1 SMS device setup

Before accessing the Short Message Service, the device has to be properly set up.

3.5.1.1 Select SMS format type.

The GE863-GPS supports SMS in two different formats:

- PDU
- Text

The difference is that in the PDU mode the device returns and receives SMS encoded in the format ready to be sent to the network; in TEXT mode the device converts automatically the read PDU into text and viceversa. By using TEXT mode the PDU data encoding knowledge is not needed and operations are easier. For this reason, we will use the TEXT mode to explain how to operate with SMS. If you are familiar with PDU encoding then you can operate with PDU by selecting that format and using appropriate command syntax.

- Send command **AT+CMGF=<mode><cr>**

where:

<mode> is the SMS format type:

- 0 – PDU
- 1 – Text

- wait for response **OK**



TIP: This setting is stored and remains until the device is turned off. Hence, there's no need to issue it more than one time. For TEXT mode use <mode>=1.

For example:

1- Let's assume you want to set TEXT format for the SMS:

command:

AT+CMGF=1<cr>

response:

OK



The GE863-GPS allows the user to select a different storage for the read-delete, write-send, and reception-saving SMS operations.

- send command **AT+CPMS=<memr>,<memw>,<mems><cr>**

where:

<memr>: memory storage for Read and Delete commands
 - "SM"
 - "ME" (No Delete operations allowed)
<memw>: memory storage for Write and Send commands
<mems>: memory storage for new incoming message saving
 - "SM" only

- wait for response in the format:

+CPMS:<usedr>,<totalr>,<usedw>,<totalw>,<useds>,<totals>

OK

where

<usedr> - number of SMS stored into **<memr>**
<totalr> - max number of SMS that **<memr>** can contain
<usedw> - number of SMS stored into **<memw>**
<totalw> max number of SMS that **<memw>** can contain
<useds> - number of SMS stored into **<mems>**
<totals> max number of SMS that **<mems>** can contain

From this response you can check if the selected storage has room for new SMSs, the free positions in the storage X (where X can be r,w,s) are **<totalX> -<usedX>**.

3.5.2 IRA character set

The character set used in SMS text mode is the IRA.

This set defines each char as a 7-bit value, hence from 0x00 to 0x7F. The table below reports all the chars supported and their hexadecimal code. To obtain the code for a char in the table remember that in the row it is reported the least significant nibble (4 bits) and in the column the most significant nibble. The empty cells correspond to reserved combinations.

		Most Significant Nibble							
		0x	1x	2x	3x	4x	5x	6x	7x
Least Significant Nibble	x0			SP ¹	0	@	P		p
	x1			!	1	A	Q	a	q
	x2			"	2	B	R	b	r
	x3			#	3	C	S	c	s
	x4			\$	4	D	T	d	t
	x5			%	5	E	U	e	u
	x6			&	6	F	V	f	v



x7			'	7	G	W	g	w
x8			(8	H	X	h	x
x9)	9	I	Y	i	y
xA	LF ²		*	:	J	Z	j	z
xB			+	;	K		k	
xC			,	<	L		l	
xD	CR ³		-	=	M		m	
xE			.	>	N		n	
xF			/	?	O	£	o	

- ¹ - SP stands for space character
- ² - LF stands for Line Feed character
- ³ - CR stands for Carriage Return character

For example:

1- Let's assume you want to find the IRA code for the character '&':

From the table you find:

- most significant Nibble: 2
- least significant Nibble: 6

Hence the IRA code for the '&' character is the hexadecimal 0x26.

2- Let's assume you have the IRA code 0x6B and you want to find the corresponding character:

From the table you find at the position

- most significant Nibble: 6
- least significant Nibble: B

Hence, the character corresponding to the 0x6B IRA code is 'k'.

TIP: With the command AT+CSGS is possible to select the character set; the available types are:

“IRA” - ITU-T.50

”8859-1” - ISO 8859 Latin 1

”PCCP437” - PC character set Code Page 437.

”UCS2” - 16-bit universal multiple-octet coded character set (ISO/IEC10646)

Please refer to the AT command specification for the full command description



For example:

1- Let's assume you want to send a SMS that was written to the storage index position number 3. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

command:
AT+CMSS=3
response:
+CMSS: 1

OK

In this case, the SMS was successfully sent to the destination and its network message reference number is 1.

3.5.5 Sending a new SMS without storing it

A new SMS can be sent directly to the network without storing it.

- send command **AT+CMGS="<da>"<cr>**

where:

<da>: destination address

- wait for prompt ">"
- send SMS text (MAX 160 characters)
- end command with CTRL-Z character (0x1A hexadecimal) or abort command with ESC character (0x1B hexadecimal)
- wait for response:

Response	Reason	Action
+CMGS: <mr> OK	Message has been successfully sent. <mr> represents the message reference number.	proceed ahead
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CMS ERROR: 330	SMSC address unknown	Insert SMSC address (see par. 3.5.1.3)
+CMS ERROR: 41	"Temporary Failure", may be that the device is not registered on any network	Check for signal strength and network registration
+CMS ERROR: 331	No network service	Check for signal strength and network registration
+CMS ERROR: 1	Unassigned number	The destination address number does not exist. Check it and repeat command.



Response	Reason	Action
OK	Message has been successfully deleted.	proceed ahead
ERROR	some error occurred	Enable the extended error codes report (see par.2.5.2.1) and retry.
+CMS ERROR: 321	Invalid memory index e.g. the given record was already empty	Check the <index> number and retry.

For example:

1- Let's assume you want to delete a previously written SMS that was written to the storage index position number 3. We suppose you already have set up the device for text SMS mode as described on the previous paragraphs:

command:
AT+CMGD=3
response:
OK

In this case, the SMS was successfully deleted.

2- Let's assume you want to delete a received SMS that was stored to the index position number 7:

command:
AT+CMGD=7
response:
OK

3.5.7 Reading an SMS

A new SMS can be read with the command:

- send command **AT+CMGR=<index><cr>**

where:

<index>: SMS location index

- wait for response in the format:

Output format for received messages (the information written in italics will be present depending on +CSDH last setting):

+CMGR: <stat>,<oa>,<alpha>,<scts>[,<toa>,<fo>,<pid>,<dc>,<sca>,<tosca>,<length>]<CR><LF><data>

Output format for sent messages:



In this case, the GPIO4 pin was successfully put in input direction.

3.6.2 GPIO pin use

After having set-up the GPIO pin direction you can query the input status of an INPUT pin or set the output status of an OUTPUT pin.

3.6.2.1 Querying GPIO pin status

To query for the pin status:

- Send command **AT#GPIO=<pin>,2<cr>**

where:

<pin> is the GPIO pin number at which the command applies:

1 – GPIO1	10 – GPIO10
2 – GPIO2	11 – GPIO11
3 – GPIO3	12 – GPIO12
4 – GPIO4	13 – GPIO13
5 – GPIO5	14 – GPIO14
6 – GPIO6	15 – GPIO15
7 – GPIO7	16 – GPIO16
8 – GPIO8	17 – GPIO17
9 – GPIO9	18 – GPIO18

- wait for response in the format:

#GPIO: <dir>,<stat>

OK

where:


<dir> - GPIO<pin> direction setting

<stat> - status of the pin

0 - LOW

1 - HIGH

 **NOTE:** In case the GPIO pin direction is set to ALTERNATE FUNCTION (2), then the reported <stat> has no meaning and shall not be kept as valid, but shall be threaten as a dummy value.

 **TIP:** The query reports depending on the pin direction:

- the read pin status in case the direction is input;
- the previously set pin status in case the direction is output.

In any case, you can know if the pin at the query moment is high or low and the pin direction.

For example:

1- Let's assume you want to query the GPIO3 pin for its status:

command:



```
AT#GPIO=3,2<cr>
response:
#GPIO: 0,1
OK
```

In this case, the GPIO3 pin was set in input direction and its status has been measured to be HIGH.

2- Let's assume you want to query the GPIO4 pin for its status:

```
command:
AT#GPIO=4,2<cr>
response:
#GPIO: 1,0
OK
```

In this case, the GPIO4 pin was set in output direction and its status is LOW.

3- Let's assume you want to query the GPIO6 pin for its status:

```
command:
AT#GPIO=6,2<cr>
response:
#GPIO: 2,0
OK
```

In this case, the GPIO6 pin was set in "alternate function" direction and therefore works as alarm output. The reported status = LOW has no meaning.

3.6.2.2 Setting GPIO pin output status

To set the pin status (when pin is set as OUTPUT):

- Send command **AT#GPIO=<pin>,<value>,1<cr>**

where:

<pin> is the GPIO pin number at which the command applies:

1 – GPIO1	10 – GPIO10
2 – GPIO2	11 – GPIO11
3 – GPIO3	12 – GPIO12
4 – GPIO4	13 – GPIO13
5 – GPIO5	14 – GPIO14
6 – GPIO6	15 – GPIO15
7 – GPIO7	16 – GPIO16
8 – GPIO8	17 – GPIO17
9 – GPIO9	18 – GPIO18

<value> is the pin value to be set and can be:

- 0 – LOW
- 1 – HIGH

- wait for response **OK**



<value> is a dummy value can be either:

- 0 – dummy value
- 1 – dummy value

- wait for response **OK**



TIP: Remember that the alternate function places the GPIO6 pin always in OUTPUT direction and since the GPIO6 pin value is controlled by the internal software, the corresponding function (+CALA) must be setup properly.



NOTE: The #GPIO6 direction setting is saved and will be kept after a power off.

For example:

1- Let's assume you want to set GPIO6 pin as ALARM OUTPUT:

command:

AT#GPIO=6,0,2<cr>

response:

OK

In this case, the GPIO6 pin was successfully put in alarm output direction.

3.6.2.5 Using GPIO7 pin as BUZZER OUTPUT (alternate function)

When you set the GPIO7 pin as buzzer output function, the pin will output a waveform suitable to drive a Buzzer, provided a simple external mosfet driver is developed and that the #SRP settings are adequate. To set the pin in alternate function you must specify also a dummy value for the pin state:

- Send command **AT#GPIO=7,<dummy_value>,2<cr>**

where:

<value> is a dummy value can be either:

- 0 – dummy value
- 1 – dummy value

- wait for response **OK**



TIP: Remember that the alternate function places the GPIO7 pin always in OUTPUT direction and since the GPIO7 pin value is controlled by the internal software, the corresponding function (#SRP) must be setup properly.



NOTE: The #GPIO7 direction setting is saved and will be kept after a power off.

For example:

1- Let's assume you want to set GPIO7 pin as BUZZER OUTPUT:

command:



3.7 Clock/Alarm function

The **Telit GE863-GPS** provides a Real Time Clock and Alarm embedded in the product; it is therefore possible to set-up the proper time, check the actual time, set-up an alarm time at which the alarm will be triggered with various behavior depending on the +CALA setting.

The only requirement is that the power input to the **Telit GE863-GPS** has to be guaranteed without interruptions, the **Telit GE863-GPS** has no backup battery; therefore it will lose the time setting if its power supply is interrupted.

On Alarm trigger the **Telit GE863-GPS** can:

- automatically Wake-up fully operative from shutdown as if the ON/OFF
- automatically Wake-up from shutdown in a special status namely "alarm status" where it will not look for or try to register into any network, as if it would be off, except from the fact that it proceeds with the alarm action and it can receive commands to return completely operative or shutdown immediately.
- If already ON at alarm trigger time, simply proceed with the Alarm action

Once Woken-up the **Telit GE863-GPS** proceeds with the chosen action that can be

- issue an unsolicited code "+ALARM: <user_text>" on the serial port until a 90s timeout expires or a special Wake-up command is received
- play an Alarm tone until a 90s timeout expires or a special Wake-up command is received
- rise the pin GPIO6 until a 90s timeout expires or a special Wake-up command is received
- any combination of these actions

With these features, the **Telit GE863-GPS** for example can:

- Wake-up itself and its controlling hardware by using the GPIO6 pin at the desired time, so timely surveys can be programmed without the need to keep the any hardware on and therefore reducing power consumption to a minimum.
- Activate some special hardware on time trigger event with the GPIO6 pin.
- Alert the controlling application that the alarm time has come with the unsolicited code "+ALARM:<user_text>"
- Alert the user with the alarm tone played

3.7.1 Clock date/time

Before using the Alarm feature, you must regulate the internal clock.



3.7.1.1 Regulate the Clock

- Send command **AT+CCLK="<time>"<cr>**

where:

<time> - current time as quoted string in the format : "yy/MM/dd,hh:mm:ss±zz"

yy - year (two last digits are mandatory), range is 00..99

MM - month (two last digits are mandatory), range is 01..12

dd - day (two last digits are mandatory), range is 01..31 (if the month MM has less than 31 days, the clock will be set for the next month)

hh - hour (two last digits are mandatory), range is 00..23

mm - minute (two last digits are mandatory), range is 00..59

ss - seconds (two last digits are mandatory), range is 00..59

±zz - time zone (indicates the difference, expressed in quarter of an hour, between the local time and GMT; two last digits are mandatory), range is -47..+48

NOTE: If the parameter is omitted the behavior of Set command is the same as Read command.

- wait for response **OK**



TIP: Remember that the string time has to be encapsulated in double brackets.



NOTE: The time will start immediately after the time setting command.

For example:

1- Let's assume you want to regulate your clock to 7 November 2002 at 12h 24m 30s for the time zone +01h central Europe:

command:

`AT+CCLK="02/11/07,12:24:30+04"<cr>`

response:

OK

In this case, the time was successfully set.

3.7.1.2 Read the current date/time

- Send command **AT+CCLK?<cr>**

- wait for response in the format:

+CCLK: <time>

OK


NOTE: the three last characters of **<time>** are not returned by **+CCLK?** because the **ME** doesn't support time zone information.





- 3 - the MODULE wakes up in "alarm mode" if at the alarm time it was off, otherwise it remains fully operative. In both cases the MODULE starts playing the alarm tone on the selected path for the ringer (see command **#SRP**)
The device keeps on playing the alarm tone until a **#WAKE** or **#SHDN** command is received or a 90s timeout occurs. If the device is in "alarm mode" and it does not receive the **#WAKE** command within 90s then it shuts down.
- 4 - the MODULE wakes up in "alarm mode" if at the alarm time it was off, otherwise it remains fully operative. In both cases the MODULE brings the pin **GPIO6** high, provided its **<direction>** has been set to alarm output, and keeps it in this state until a **#WAKE** or **#SHDN** command is received or a 90s timeout occurs. If the device is in "alarm mode" and it does not receive the **#WAKE** command within 90s then it shuts down.
- 5 - the MODULE will make both the actions as for **<type>=2** and **<type>=3**.
- 6 - the MODULE will make both the actions as for **<type>=2** and **<type>=4**.
- 7 - the MODULE will make both the actions as for **<type>=3** and **<type>=4**.

<text> - unsolicited alarm code text string. It has meaning only if **<type>** is equal to 2 or 5 or 6.

- wait for response **OK**

 **TIP: Remember that the string time has to be encapsulated in double brackets, furthermore the Alarm time will not be computed for different timezone, therefore the alarm time will always refer to the same timezone as the clock setting regardless the timezone set in the +CALA command.**

 **NOTE: if you use the GPIO6 pin as ALARM OUTPUT, then you MUST set its direction to "alternate function" (see par. 3.6.2.4) otherwise the pin will not respond to the alarm settings. In case the alarm mode is equal to 1,3,7 then a dummy empty text shall be inserted "".**

 **NOTE: if you use the unsolicited codes +ALARM: <text>, then you must fix the port speed rate (see par. 2.5.1) and store it in the active profile (see command &W), in order to make the Telit GE863-GPS boot with the desired port speed, otherwise at the alarm wakeup, the module will start with the default port speed that may differ from yours.**

3.7.2.2 Stop the Alarm activity

When the alarm time expires, the module starts the alarm activity according to the alarm behavior parameter **<type>** selected.

To stop the Alarm activity there are three ways, you can either decide to exit from alarm and shutdown the device or exit from alarm and entering the normal operational status; otherwise you can leave the alarm go on until the 90s timeout is reached.



3.7.2.2.1 Exit from the alarm status and shutdown

- Send command **AT#SHDN<cr>**
- wait for response **OK**

At the OK result code, the device will end alarm activity and shutdown.

3.7.2.2.2 Exit from the alarm status and enter the normal operating mode

- Send command **AT#WAKE=0<cr>**
- wait for response **OK**

At the OK result code, the device will end alarm activity and enter normal operating mode. If the device was already in normal operating mode (alarm has started when the module was already ON), then with the command only the alarm activity is terminated.

3.7.2.3 Querying the Alarm status

When the device awakes by means of an alarm time expire, the module starts the alarm activity but not the network activity, permitting some operations to be done by the controlling application without registering the mobile in the network.

To check if the mobile is in the "alarm status" and therefore no network activity is done or if the device is in the normal operating status:

- Send command **AT#WAKE?<cr>**
- wait for response in the format:
+WAKE: <status>
OK

where:

<status> is the operating mode:

0 - normal operating mode


1 - alarm mode



NOTE: if the device is in the alarm mode no network activity is done, therefore the only commands that are accepted are the #WAKE and #SHDN ones.

When in the alarm mode, no operation is allowed towards the network, therefore it is not possible to receive or send calls, SMS and whatever GSM/GPRS services.






CSD interconnectivity

In GPRS operations instead, the connection is made directly towards internet as if the GPRS modem was a network IP socket interface. There's no data path reserved for the data exchange between the two peers, instead the resources are allocated dynamically on demand and the data exchanged is organized into packets typically TCP/IP, furthermore the maximum transfer speed can be much faster than GSM CSD.

An example of GPRS connection is shown in the following picture, where the GPRS connection is between the GPRS modem and the internet as if all the devices inside the dashed line are not present:



GPRS interconnectivity



Due to this kind of connection, when activating the GPRS connection you must provide the network parameters to enter through the internet point of the GPRS network ISP (Internet Service Provider) and not the phone number to be dialed; therefore it is not possible to establish a direct point to point GPRS connection between two modems as in CSD case, instead an internet tunneling must be done to achieve a point to point connection between two peers.

This approach as the immediate advantage of projecting the controlling application of the GPRS modem directly on the internet, ready to be accessed virtually from anywhere in the world at the same cost on the GPRS; actually the billing of the GPRS connection is based on the amount of data exchanged (number of packets transferred) independently from the time the connection is active or where these packet must be delivered. Therefore, it is possible to leave the controlling application always connected and ready to receive/send data on demand, while paying only for the data really exchanged.

The drawback of the GPRS connection is that the controlling application must have its own TCP/IP protocol stack embedded to decode the packets that arrive from GPRS and encode the ones to be sent through the internet.

There are few considerations than must be done on the GPRS connections:

- the GPRS connection speed with a GPRS class 10 multislots device is asymmetrical, 3 time slots in reception (43200 bps max) and 2 time slot in sending (28800 bps max) or 4 time slots in reception (57600 bps max) and 1 time slot in sending (14400 bps max).
- The controlling application of the module must have a TCP/IP - PPP software stack to interface with the GPRS modems.
- The controlling application must rely on some ISP that may be the Network Operator of the SIM to gain access to the internet through the GPRS connection.
- Because of the point before, the receiving application must have internet access either.
- Since the communication is based upon TCP/IP packets, then it is possible to talk contemporarily with more than one peer.
- When required, the data security in internet shall be guaranteed by security protocols over the TCP/IP that must be managed by the controlling application.

NOTE: For more detailed information about GPRS connections and practical examples please refer to the Easy GPRS User Guide



5 GPS operations

5.1 Introduction

The GE863-GPS module is equipped with a SiRFStar III GPS receiver that is controllable by the GSM modem using a set of AT commands or dedicated NMEA sentences.

5.2 GE863-GPS Serial Ports

4 serial ports are available on the module:

- MODEM SERIAL PORT
- MODEM SERIAL PORT 2 (GPS CONTROL PORT)
- GPS SERIAL PORT A (SIRF BINARY)
- GPS SERIAL PORT B (NMEA)

5.2.1 GPS SERIAL PORT A (SIRF BINARY)

This port is carrying out the GPS navigation data in SIRF BINARY format.

The default configuration is 57600 bps, 8, n, 1

It is available on the following pins:

PIN #	NAME	DESCRIPTION	TYPE
78	RX_GPS_BIN	GPS RX Data (Sif Binary)	CMOS 2.8V
80	TX_GPS_BIN	GPS TX Data (Sif Binary)	CMOS 2.8V

The typical integration requires connecting this pins to MODEM serial port 2.

5.2.2 GPS SERIAL PORT B (NMEA)

This port is carrying out the GPS navigation data in NMEA 0183 format.

The default configuration is 4800 bps, 8, n, 1

It is available on the following pins:

PIN #	NAME	DESCRIPTION	TYPE
68	TX_GPS	GPS TX Data (NMEA)	CMOS 2.8V
73	RX_GPS	GPS RX Data (NMEA)	CMOS 2.8V



The typical application that permits also to control the GPS part by the GSM modem is the following:

PIN #	NAME		NAME	PIN#
25	TX_TRACE	←→	RX_GPS_BIN	78
26	RX_TRACE	←→	TX_GPS_BIN	80

This configuration is also settable on the EVK board.
This configuration is defined as "Controlled Mode".

5.3 WGS 84

GPS receivers perform initial position and velocity calculations using an earth-centered earth-fixed (ECEF) coordinate system. Results may be converted to an earth model (geoid) defined by the selected datum. For GE863-GPS the default datum is WGS 84 (World Geodetic System 1984) which provides a worldwide common grid system that may be translated into local coordinate systems or map datums. (Local map datums are a best fit to the local shape of the earth and not valid worldwide).



5.4 NMEA 0183

The NMEA 0183 is a specification created by the National Marine Electronics Association (NMEA) that defines the interface between other marine electronic equipment.

The standard permits marine electronics to send information to computers and to other marine equipment.

GPS receiver communication is defined within this specification.

The actually supported version is 2.2

The provided NMEA sentences are :

GGA	Time, position and fix type data.
GLL	Latitude, longitude, UTC time of position fix and status.
GSA	GPS receiver operating mode, satellites used in the position solution, and DOP values.
GSV	The number of GPS satellites in view satellite ID numbers, elevation, azimuth, and SNR values.
VTG	Course and speed information relative to the ground.
RMC	Time, date, position, course and speed data.



5.4.2 GLL - Geographic Position - Latitude/Longitude

This sentence provides latitude and longitude of vessel position, time of position fix and status

Table C contains the values for the following example:

```
$GPGLL,3723.2475,N,12158.3416,W,161229.487,A,A*41
```

Table C

Name	Example	Units	Description
Message ID	\$GPGLL		GLL protocol header
Latitude	3723.2475		ddmm.mmmm
N/S Indicator	N		N=north or S=south
Longitude	12158.3416		dddmm.mmmm
E/W Indicator	W		E=east or W=west
UTC Time	161229.487		hhmmss.sss
Status	A		A=data valid or V=data not valid
Mode	A		A=Autonomous, D=DGPS, E=DR (Only present in NMEA version 3.00)
Checksum	*41		
<CR> <LF>			End of message termination



5.4.3 GSA - GNSS DOP and Active Satellites

This sentence reports the GPS receiver's operating mode, satellites used in the navigation solution reported by the GGA sentence and DOP values.

Table D contains the values for the following example:

\$GPGSA,A,3,07,02,26,27,09,04,15, , , , , 1.8,1.0,1.5*33

Table D: GSA Data Format

Name	Example	Units	Description
Message ID	\$GPGSA		GSA protocol header
Mode 1	A		See Table E
Mode 2	3		See Table F
Satellite Used1. Satellite used in solution.1	07		Sv on Channel 1
Satellite Used1	02		Sv on Channel 2
....			
Satellite Used1			
PDOP	1.8		
HDOP	1.0		
VDOP	1.5		
Checksum	*33		
<CR> <LF>			End of message termination

Table E: Mode 1

Value	Description
M	Manual—forced to operate in 2D or 3D mode
A	2D Automatic—allowed to automatically switch 2D/3D

Table F: Mode 2

Value	Description
1	Fix not available
2	2D (<4 SVs used)
3	3D (>3 SVs used)



5.4.4 GSV - GNSS Satellites in View

This sentence reports the number of satellites (SV) in view, satellite ID numbers, elevation, azimuth and SNR value.

There could be four satellites information per transmission so, if the number of satellites in view is bigger, separated GSV sentences will be generated. The number of sentence in transmission and the total to be transmitted is shown in the first 2 fields of the sentence.

Table G contains the values for the following example:

```
$GPGSV,2,1,07,07,79,048,42,02,51,062,43,26,36,256,42,27,27,138,42*71
```

```
$GPGSV,2,2,07,09,23,313,42,04,19,159,41,15,12,041,42*41
```

Table G: GSV Data Format

Name	Example	Units	Description
Message ID	\$GPGSV		GSV protocol header
Number of Messages	2		Range 1 to 3
Message Number1	1		Range 1 to 3
Satellites in View	07		
Satellite ID	07		Channel 1 (Range 1 to 32)
Elevation	79	degrees	
Azimuth	048	degrees	
SNR (C/No)	42	dBHz	
....	
Satellite ID	27		Channel 4 (Range 1 to 32)
Elevation	27	degrees	Channel 4 (Maximum 90)
Azimuth	138	degrees	Channel 4 (True, Range 0 to 359)
SNR (C/No)	42	dBHz	Range 0 to 99, null when not tracking
Checksum	*71		
<CR> <LF>			End of message termination



5.4.6 VTG - Course Over Ground and Ground Speed

This sentence reports the actual course and speed relative to the ground.

Table I contains the values for the following example:

\$GPVTG,309.62,T, ,M,0.13,N,0.2,K,A*23

Table I: VTG Data Format

Name	Example	Units	Description
Message ID	\$GPVTG		VTG protocol header
Course	309.62		Measured heading
Reference	T		True
Course		degrees	Measured heading
Reference	M		Magnetic
Speed	0.13	knots	Measured horizontal speed
Units	N	Knots	
Speed	0.2	km/hr	Measured horizontal speed
Units	K		Kilometers per hour
Mode	A		<i>A=Autonomous, D=DGPS, E=DR</i>
Checksum	*23		
<CR> <LF>			End of message termination



NOTE: SiRF Technology Inc. does not support magnetic declination. All “course over ground” data are geodetic WGS84 directions.



5.5 Checking GPS device functionality

After a proper power on the device is ready to receive AT commands on the MODEM serial port. The GPS receiver also will be automatically powered on and it will start the scan of the available GPS signals.

On the NMEA serial port (default 4800 bps, 8, n, 1) there must be presence of the NMEA sentences.

5.5.1 Controlled mode

The GE863-GPS is by factory default set to controlled mode.

With the command **AT\$GPSD=<device type>** is possible to set this configuration.

Parameter:

<device type>

0 - none; the serial port is not connected to GPS device

2 - serial port connected to GPS serial port: controlled mode (default)



5.6.2 GPS RESET

With the command **AT\$GPSR=<reset type>** is possible to reset the GPS module.

Parameter:

<reset type>

- 0 - Hardware reset: the GPS receiver is reset and restarts by using the values stored in the internal memory of the GPS receiver.
- 1 - Coldstart (No Almanac, No Ephemeris): this option clears all data that is currently stored in the internal memory of the GPS receiver including position, almanac, ephemeris, and time. The stored clock drift however, is retained. It is available in controlled mode only.
- 2 - Warmstart (No ephemeris): this option clears all initialization data in the GPS receiver and subsequently reloads the data that is currently displayed in the Receiver Initialization Setup screen. The almanac is retained but the ephemeris is cleared. It is available in controlled mode only.
- 3 - Hotstart (with stored Almanac and Ephemeris): the GPS receiver restarts by using the values stored in the internal memory of the GPS receiver; validated ephemeris and almanac. It is available in controlled mode only.

Example :

Let's suppose to perform a cold start of the GPS receiver.

```
AT$GPSR=1<cr>
```

OK

The Receiver will clear all the parameters in its memory and it will start a new scanning of the available satellites.



5.6.4 GPS PARAMETERS SAVE

This command allows saving the set parameters in the module's memory

Syntax of the command :

AT\$GPSSAV

After this command restart the module to update the modifications.

5.6.5 RESTORE GPS PARAMETERS

This command allows restoring the factory default parameters for the GPS module

Syntax of the command :

AT\$GPSRST

After this command restart the module to update the modifications.

5.6.6 READ ACQUIRED GPS POSITION

This command allows reading the acquired position of the GPS receiver

Syntax of the command :

AT\$GPSACP

The response syntax is:

\$GPSACP:<UTC>,<latitude>,<longitude>,<hdop>,<altitude>,<fix>,<cog>,
<spkm>,<spkn>,<date>,<nsat>

The fields contain the following information:

<UTC>: (referred to GGA sentence)
hhmmss UTC of Position

Values:

hh (hour) 00 to 23
mm (minutes) 00 to 59
ss (seconds) 00 to 59

<latitude>: (referred to GGA sentence)
ddmm.mmmm N/S

Values:

dd (degrees) 00 to 90
mm.mmmm (minutes) 00,0000 to 59.9999
N/S: North / South



6 Service and firmware update

The Telit GE863 modules firmware can be updated through the same serial interface, which is used normally for the AT commands. Since the software group is continuously working, in order to improve the overall performances and introduce new features on the product, we suggest, in order to keep updated the module's firmware, to foreseen an external access to that interface with level converters to RS232, which allows connecting a Windows-based PC, since it is normally not possible to disconnect a GE863 module already soldered on the PCB of the application. It shall be possible to start the update procedure at POWER OFF condition of the module and then switch it ON to continue.

During the application development or evaluation phase of the GE863 module, the RS232 interface with the level converters or the USB port implemented on the **Telit Evaluation Kit EVK2** can be used to connect to a Windows-based PC on which the specific program for updating the Software (TFI) can be run.

6.1 Step-by-Step upgrade procedure

The firmware update can be done with a specific software tool provided by Telit that runs on Windows based PCs.


First the program will erase the content of flash memory, then the program will write on the flash memory. To update the firmware of the module, we suggest the following procedure:

1. Collect information about the Hardware and implemented version of Software by the command
 - AT+CGMR<enter>, which returns the Software version information;
 - AT+CGMM<enter>, which returns the Model Identification.
2. Switch OFF the module.
3. Run the file *TFI_xxxx.exe*. The following window should be displayed, Select the language preferred by pressing the correspondent button.




4. The End User License Agreement will appear. Please, read it and accept the terms if you are going to proceed.






5. Press OK to the initial message.




NOTE: In connection with the GE863 modules, charged battery has to be understood that the power supply must not be disconnected during the firmware update.

6. Select the right COM port and speed. Note that to go faster than 115200 you need a special hardware on the PC. Then Press the Download button and within 5 seconds power-on the GE863.





Wait for the end of programming green message OK



The **Telit GE863 module** is now programmed with the new firmware.

NOTE: the above pictures show how the application dialogs appear for the GM862 product. The GE863 TFI application will look similar.



