

MAGNAVOX

AQ 6570 Radio Cassette Player



Owner's Manual



Operating Instructions

General Information

POWER SUPPLY

Batteries

- Insert two alkaline batteries (R6, UM3 or AA) as indicated.
- Remove dead batteries or batteries that will not be used for a long time.

RADIO RECEPTION

- Set TAPE/RADIO to RADIO.
- Connect the headphones to H .
- Set FM-AM to FM or AM.
- Tune to the desired radio station using TUNING.
 - The headphone cord will function as the FM antenna.
 - For AM the unit is provided with a built-in antenna. The antenna can be directed by turning the whole unit.
- Adjust the sound with VOLUME and DBB (Dynamic Bass Boost).
- The unit is off when TAPE/RADIO is in TAPE position and no cassette player button is pressed.

CASSETTE PLAYBACK

- Set TAPE/RADIO to TAPE.
- Connect the headphones to H .
- Open the cassette holder and insert a cassette with the open part facing the buttons and the full reel on your right.
- To start playback, press \blacktriangleright .

MAINTENANCE

- Clean the magnetic head after every 50 hours of use or, on average, once a month by playing a cleaning cassette.
- Do not expose the unit and cassettes to rain, moisture, sand, or excessive heat from heating equipment or vehicles parked in the sunlight.
- Use a soft, slightly dampened chamois leather to clean the housing. Do not use any strong or corrosive cleaning agents such as thinner, benzene, etc. as these will damage your unit.

ENVIRONMENTAL NOTE

1. All excessive packaging material has been omitted. The packaging may be separated into three materials:
 - cardboard (box)
 - expandable polystyrene (buffer)
 - polyethylene (bags, protective foam sheet).
 Please observe the local regulations regarding the disposal of these packaging materials.
2. Your unit consists of materials which can be recycled and reused if disassembled by a specialized company. Ask about local regulations on recycling your unit.
3. Do not dispose of dead batteries with your household waste. Dispose of batteries according to local regulations.


Operating Instructions

Troubleshooting

English



Meet Magnavox at the Internet
<http://www.magnavox.com>



2 x R6/UM3/AA-cells

- Adjust the sound with VOLUME and DBB (Dynamic Bass Boost).
- To stop playback, press \blacksquare .
 - The unit is switched off.
- At the end of the tape, the \blacktriangleright button is automatically released and the unit is switched off.
- For fast winding, press $\blacktriangleright\blacktriangleright$.
 - To stop, press \blacksquare .

General Information

ACCESSORIES (included)

- Stereo Headphones
- Belt clip

USE YOUR HEAD WHEN USING HEADPHONES

- **Hearing safety:** Do not play your headphones at a high volume. Hearing experts advise that continuous use at high volume can permanently damage hearing.
- **Traffic safety:** Do not use headphones while driving a vehicle. It may create a traffic hazard, and it's illegal in many countries. You should use extreme caution or temporarily discontinue use in potentially hazardous situations. Even if your headphones are an open-air type designed to let you hear outside sounds, do not turn up the volume so high that you cannot hear what is going on around you.

If a problem occurs, check the points listed below before taking the unit for repair. If you are unable to solve a problem by following these suggestions, consult your dealer or service center.

Warning: Never try to repair the unit yourself, as this would invalidate your warranty.

PROBLEM

- CAUSE
 - SOLUTION
- #### No power
- Wrong battery polarity.
 - Insert batteries correctly.
 - Dead batteries.
 - Replace batteries.

No sound

- Volume is not turned up.
- Turn up volume.
- Headphones are not connected.
- Connect headphones plug to headphones jack (H).

Poor sound/sound from one channel only

- Headphones plug is not inserted fully.
- Insert plug fully.

Severe radio hum or noise

- FM antenna (headphones cord) is not extended fully.
- Extend FM antenna (headphones cord) fully.
- Unit is too close to TV, VCR or computer.
- Move unit away from TV, VCR, or computer.

Poor cassette sound quality

- Tape head dirty.
- Clean tape head (See 'Maintenance').

The model number is located at the bottom of the unit.
 The serial number is located in the battery compartment.
 The set complies with the FCC-Rules, Part 15

SAFETY INSTRUCTIONS

Read before operating equipment

This product was designed and manufactured to meet strict quality and safety standards.

There are, however, some installation and operation precautions which you should be particularly aware of.

- 1. Read Instructions** - All of the safety and operating instructions should be read before the appliance is operated.
- 2. Keep Instructions** - The safety and operating instructions should be kept for future reference.
- 3. Heed Warnings** - All warnings on the appliance and in the operating instructions should be heeded.
- 4. Follow Instructions** - All operating instructions should be followed.
- 5. Water and Moisture** - The appliance should not be used near water - for example, near a bathtub, washbowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool, etc.
- 6. Heat** - The appliance should be kept away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
- 7. Cleaning** - The appliance should be cleaned only as recommended by the manufacturer.
- 8. Object and Liquid Entry** - Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.

LIMITED WARRANTY

PORTABLE AUDIO 90 Days Free Exchange

This product must be carried in for an exchange.

WHO IS COVERED?

You must have proof of purchase to exchange the product. A sales receipt or other document showing that you purchased the product is considered proof of purchase. Attach it to this owner's manual and keep both nearby.

WHAT IS COVERED?

Warranty coverage begins the day you buy your product. **For 90 days thereafter**, a defective or inoperative product will be replaced with a new, renewed or comparable product at no charge to you. A replacement product is covered only for the original warranty period. When the warranty on the original product expires, the warranty on the replacement product also expires.

WHAT IS EXCLUDED?

Your warranty does not cover:

- labor charges for installation or setup of the product, adjustment of customer controls on the product, and installation or repair of antenna systems outside of the product.
- product repair and/or part replacement because of misuse, accident, unauthorized repair or other cause not within the control of Philips Consumer Electronics Company.
- reception problems caused by signal conditions or cable or antenna systems outside the unit.
- a product that requires modification or adaptation to enable it to operate in any country other than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications.

(In U.S.A., Puerto Rico and U.S. Virgin Islands, all implied warranties, including implied warranties of merchantability and fitness for a particular purpose, are limited in duration to the duration of this express warranty. But, because some states do not allow limitations on how long an implied warranty may last, this limitation may not apply to you.)

EXCHANGING A PRODUCT IN CANADA

Contact your dealer to arrange an exchange. Or, ship the product, insured and freight prepaid, and with proof of purchase enclosed, to one of the Philips consumer service centers listed below.

Philips Electronics Ltd.

601 Milner Avenue, Scarborough,
Ontario, M1B 1M8 - ☎ (416) 292-5161
4977 Levy Street, St. Laurent, (Montréal),
Québec, H4R 2N9 - ☎ (514) 956-0120
3695 Grandview Highway, Vancouver,
B.C., V5M 2G7 - ☎ (604) 435-4411

(In Canada, this warranty is given in lieu of all other warranties. No other warranties are expressed or implied, including any implied warranties of merchantability or fitness for a particular purpose. Philips is not liable under any circumstances for any direct, indirect, special, incidental or consequential damages, howsoever incurred, even if notified of the possibility of such damages.)

NOTES

- 9. Damage Requiring Service** - The appliance should be serviced by qualified service personnel when:
 - A.** Objects have fallen, or liquid has spilled into the appliance; or
 - B.** The appliance has been exposed to rain; or
 - C.** The appliance does not appear to operate normally or exhibits a marked change in performance; or
 - D.** The appliance has been dropped, or the enclosure has been damaged.
- 10. Servicing** - Do not attempt to service the appliance beyond that described in the operating instructions. All other servicing should be referred to qualified service personnel.

- incidental or consequential damages resulting from the product. (Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you. This includes, but is not limited to, prerecorded material, whether copyrighted or not copyrighted.)

WHERE IS EXCHANGE AVAILABLE?

You may exchange the product in all countries where the product is officially distributed by Philips Consumer Electronics Company. In countries where Philips Consumer Electronics Company does not distribute the product, the local Philips service organization will attempt to provide a replacement product (although there may be a delay if the appropriate product is not readily available).

BEFORE REQUESTING EXCHANGE...

Please check your owner's manual before requesting an exchange. Adjustments of the controls discussed there may save you a trip.

EXCHANGING A PRODUCT IN U.S.A., PUERTO RICO OR U.S. VIRGIN ISLANDS

Contact your dealer to arrange an exchange. Or, ship the product, insured and freight prepaid, and with proof of purchase enclosed, to the address listed below.

**Small Product Service Center
Philips Service Company**
907 Snapps Ferry Road, Plant 2, Building 6
Greeneville, TN 37743

TO GET OUT-OF-WARRANTY EXCHANGE

In U.S.A., Puerto Rico or U.S. Virgin Islands, contact Philips Service Company at ☎ (800) 851-8885 to obtain the cost of out-of-warranty exchange. Then carefully pack the product and ship it to the Small Product Service Center (address listed above).

In Canada, contact the nearest Philips consumer service center (phone number and address listed above) to obtain the cost of out-of-warranty exchange. Then carefully pack the product and ship it to that service center.

REMEMBER

Please record the model and serial numbers below. Also, please fill out and mail your warranty registration card promptly. It will be easier for us to notify you if it is necessary.

Model # _____

Serial # _____

This warranty gives you specific legal rights.

You may have other rights which vary from state to state.

Philips Service Company
P.O. Box 555
Jefferson City, Tennessee 37760 - ☎ (423) 475-8869

For Customer Use:

Enter below the Serial No. which is located in the battery compartment. Keep this information for future reference.

Model No. **AQ 6570**

Serial No. _____