

Congratulations on your purchase of a high-quality Insignia product. Your NS-WBRDVD2, NS-WBRDVD2-CA, NS-BRDVD4, and NS-BRDVD4-CA represents the state of the art in Blu-ray disc player design and is designed for reliable and trouble-free performance.

Package contents


- Blu-ray disc player
- AAA batteries (2)
- Remote control
- User Guide
- Quick Setup Guide

Installing remote control batteries

- 1 Remove the battery compartment cover.



- 2 Insert two AAA batteries into the battery compartment. Make sure that the + and – symbols on the batteries match the + and – symbols in the battery compartment.




- 3 Replace the battery compartment cover.




For the most updated *User Guide*, please visit www.insigniaproducts.com

Connecting a TV Using HDMI (best)




Digital connection (optical or coaxial)

NOTE: To select the digital audio output mode, see page 15 of the *User Guide*.



Using composite (good)


NOTE: Composite connections do not provide HD quality video.



To connect to a home theater, see your *User Guide*.

Using Quick Setup

- Press ▲ or ▼ to select **Quick Setup**, then press **ENTER**. The *Quick Setup* menu opens. Follow the guide to set the most important settings for your player.




Connecting to your home network


This player can be connected to your wired network using the Ethernet port on the back of your player or using a wireless network. Using a wired network provides the best performance, because the attached devices connect directly to the network and are not subject to radio frequency interference.

Connecting to the Internet with a wireless network (NS-WBRDVD2 and NS-WBRDVD2-CA only):

- 1 Set up your access point or wireless router (if not already set up).




- 2 Turn on your player and your TV.
- 3 Press ▲ or ▼ to select **Settings**, then press **ENTER**. The *Settings* menu opens.
- 4 Press ▲ or ▼ to select **Network**, then press **ENTER**.



Note: The screen shot is only for wireless players.

- 5 Press ▲ or ▼ to select **Network List**, then press **ENTER**. The *Network List* screen opens, showing a list of available wireless networks.



- 6 Press ▲ or ▼ to select the wireless network you want your player to connect to. A *Network Setup* screen opens with the following options: *Password*, *Connect*, *Delete*, or *Cancel*.
- 7 If your network does not use encryption, press ▲ or ▼ to select **Connect**, then press **ENTER**. If the wireless network is working you should see a checkmark and a connected message on the TV. If the message does not appear, repeat the steps above.

OR


If your network uses encryption:

- a Press ▲ or ▼ to select the **Password** field, then press **ENTER**. An on-screen keyboard opens.
- b Press ▲, ▼, ◀, or ▶ to select the first letter in the password, then press **ENTER**. Repeat this step to enter the rest of the password. If you make a mistake, use backspace key to delete the character.
- c After you enter the password, select the red "DONE" in the upper left-hand corner of the keyboard, then press **ENTER** to close the keyboard.
- d Press ▲ or ▼ to select **Connect**, then press **ENTER**. A connection message will appear. Select **Close**, then press **ENTER**. If the connection is not successful, repeat the steps above.


For information on connecting to a wireless network using Wi-Fi Protected Setup (WPS), see your *User Guide*.

Connecting to the Internet with a wired network:

- 1 Connect a network cable to the ETHERNET jack on the back of your player and into a wired router using an Ethernet cable (Cat 5 or better, with RJ45 connectors).



- 2 Press **▲** or **▼** to select **Settings**, then press **ENTER**. The *Settings* menu opens.




Note: The screen shot is only for wired players.

- 3 Press **▲** or **▼** to select **Network**, then press **ENTER**. The *IP Settings* screen opens.
- 4 Press **▲** or **▼** to select **IP Mode**, then press **ENTER**.
- 5 Press **▲** or **▼** to select an IP Mode, then press **ENTER**. You can select **Dynamic** - Uses DHCP to automatically obtain an IP address **Manual** - Lets you manually configure network settings. (See your *User Guide* to set up your connection manually.)
- 6 Press **▲**, **▼**, **◀**, or **▶** to select **Apply**, then press **ENTER**. A Network Test automatically runs.
- 7 If the connection is established, select **OK**, then press **ENTER** to close the screen.

Advanced users only: To make changes to your network connection, see your *User Guide*.

Testing your network connection

- 1 Press **▲** or **▼** to select **Settings**, then press **ENTER**. The *Settings* menu opens.



- 2 Press **▲** or **▼** to select **Network**, then press **ENTER**.
- 3 Press **▲** or **▼** to select **Network Test**, then press **ENTER**. A dialog box opens, showing the progress of the network test. The test results appear shortly.

The Network Test will begin and run three tests:

- 1 **Local Network Test.** If this test fails, you need to check your connection to your home network.

- **If you have a wired connection:**

- * Make sure your network cable is securely attached to your router and your player.
- * Make sure your router is connected to your cable or DSL modem correctly.

- **If you have a wireless connection:**

- * Make sure your router is connected to your cable or DSL modem correctly.
- * Make sure your player is within the range of your router.
- * Make sure the desired WIFI network is selected.
- * If you have a security password, be sure you have entered the password correctly.
- * If further help is need for setting up security and obtaining your security password, contact your router manufacturer and/or cable or DSL modem manufacturer.

- 2 **DNS Sever Test.** If this test fails, there may be an issue with your Internet service provider.

- Make sure your router is connected to your cable or DSL modem correctly.
- Contact your Internet service provider for more help.

- 3 **Internet Connection Test.** If this test fails, there may be an issue with your Internet service provider.

- Make sure your router is connected to your cable or DSL modem correctly.
- Contact your Internet service provider for more help.

Using connected applications (U.S. market)

Note: Instructions and support numbers for the connected applications apply to the US market only.

You can watch movies over the Internet (for example, from Netflix or CinemaNow), or to listen to Pandora Internet radio. Before being able to use these Internet services, you must first:

- 1 Have connected the player to the Internet, and passed the Network Test, above.
- 2 Have a valid account to these services.

Watching movies with Netflix

- 1 Press **▲** or **▼** to select **Netflix**, then press **ENTER** to register your player with your Netflix account. Follow the directions on the screen. You will be provided with an activation code.
- 2 If you already have an existing Netflix account, log in to your account on your PC. Click on the **Your Account & Help** link in the upper right corner of the screen.
- 3 In the **WATCHING INSTANTLY ON YOUR TV OR COMPUTER** section, click **Activate a Netflix Ready Device** and enter the activation code from Step 1. - OR -

If you do not have an existing Netflix account, go to <http://www.netflix.com/insignia> to start your free trial and enter the activation code from Step 1 into the **Insignia code** field on screen.

- 4 After setting up your account and activating your Blu-ray player, browse to **Instant** under the **Your Queue** tab and add movies to queue.
- 5 To exit Netflix, press **Home/Setup**.

Watching movies with CinemaNow

- 1 First set up your CinemaNow account through your PC. Go to www.cinemanow.com/activate to get an activation PIN.
- 2 Click **Activate a New Device** and sign in with your user name/password.
- 3 Enter any name in the **Name Your Device** section, then click **Continue**. You have been provided with a valid activation number to enter into the activation field within the CinemaNow application on your Blu-ray player.
- 4 Once you have successfully established an Internet connection on your Blu-ray player, select the **CinemaNow** application using your remote control, then press **ENTER**.

- 5 Select the **Settings** tab at the bottom of the screen, then press **ENTER**.
- 6 Select **Activate** and enter your activation code. You can now rent movies using CinemaNow.
- 7 To exit CinemaNow, press **Home/Setup**.

Listening to music with Pandora

To use an existing Pandora account:

- 1 Press **▲** or **▼** to select **Pandora**, then press **ENTER**.
- 2 Select **I have a Pandora account** from the options, then sign in with your account information.

To create a new Pandora account on your player:

- 1 Press **▲** or **▼** to select **Pandora**, then press **ENTER**.
- 2 Select **I am new to Pandora** from the options. You will receive an activation code.
- 3 On your PC, go to www.pandora.com/insignia and enter the activation code from Step 2, then click **Activate**.

- 4 Click **Create a Pandora Account** and follow the on-screen instructions.

- 5 To exit Pandora, press **Home/Setup**.

To create a new Pandora account using a PC:

- Go to <http://www.pandora.com/> to create a new account.

Contact the partner company (not Insignia) if you experience an issue using one of these applications.

Note: Support numbers for the connected applications apply to the US market only.

Netflix:

www.netflix.com/help

1-866-579-7113

CinemaNow:

www.cinemanow.com/support

Pandora:

<http://blog.pandora.com/faq/>

Using connected applications (Canada market)

To stay up-to-date on future service options, visit www.insigniaproducts.com.

Netflix:

<http://ca.netflix.com/contactus>

1-866-716-0414

One-year limited warranty

Visit www.insigniaproducts.com for details.

Contact Insignia:

For customer service, call 1-877-467-4289 (US and Canada markets)

www.insigniaproducts.com