Unpack the MultiPASS C545

• Carefully remove all items from the box.

Remove these items from the documentation package: this Quick Start Guide, the MultiPASS C545 Installer CD packet, MultiPASS C545 User's Manual, Registration card, and Warranty card.

Remove these hardware items from the top tray:



Lift out the MultiPASS unit from the bottom.



Important! Save the box and shipping materials. You may need them later if you have to transport the MultiPASS.

2 Remove all pieces of shipping tape.

Remove all pieces of shipping tape from the outside of the printer. Be sure to remove the tape from the back of the printer also.

Remove the protective plastic piece from the sheet feeder.



Note that tape may not be in the exact locations shown.

Open the document tray.

Remove the protective sheet covering the operation panel.



Open the operation panel.

Use both hands to grip the operation panel, and gently pull it toward you until it opens partially.

Remove the soft styrofoam sheet from the unit's Automatic Document Feeder (ADF).



Press the operation panel closed until it clicks into place.

6 Open the printer cover.





holds documents to be faxed, copied or scanned

Set Up the MultiPASS

Place the main unit of the MultiPASS on a level surface with plenty of room to work.

• Attach the sending document support.

Fit the tabs on the sending document support into the ADF slots above the ADF. Make sure the support curves toward the back of the unit.

2 Connect the phone line.

T

L

The MultiPASS unit has three telephone jacks (located on the left side of the unit) that will accept standard line connections.

Use the bottom L jack to connect the wall Jacks on MultiPASS jack to the MultiPASS with the supplied line cord (unless connected with Caller ID). The other two jacks are pass-through ports to connect other devices to the MultiPASS and your telephone service. Select from the S options in the diagram below to configure your telephone device to work in conjunction with your MultiPASS.

If you have only one telephone line and plan to use the MultiPASS for receiving both faxes and voice calls, you must attach a telephone and/or answering machine to the unit.







MultiPASS, PC Modem, Answering Machine and Telephone



③ Connect the USB—to—Parallel cable and power cord.

Make sure the computer is turned off.



Connect the power cord to the MultiPASS and to a wall outlet. The MultiPASS has no power switch. The power is on as long as the system is plugged in.



The MultiPASS is equipped with a 3-prong, grounding-type plug. This plug will only fit into a grounding-type outlet. This is a safety feature. Do not defeat the safety purpose of this plug. Make sure the socket-outlet is located near the MultiPASS and is easily accessible.



3 Install the Canon BJ[®] Cartridge

Spilled ink can stain any surface. Open BJ cartridges and ink tanks very carefully. See your User's Manual for complete details on BJ cartridge and ink tank maintenance.

Make sure the MultiPASS is plugged in. The LCD reads:

PUT IN CARTRIDGE

• Open the ADF.

Grasp both the document guides and lift up.



When you plug in the MultiPASS for the first time, the cartridge holder moves to the center of the unit so you can install the BJ cartridge. If the cartridge holder is not in the center, press the cartridge button inside the unit.

Do not touch the ribbon cable, the small circuit board, the guide rail, or the round shaft. Touching these parts may adversely affect operation of the unit and/or cause print quality deterioration.



2 Remove the cap and tape from the BC-21e Color BJ Cartridge.

Peel the clear plastic from the BJ cartridge's protective packaging and remove the cartridge.

Hold the BJ cartridge on the sides only. Do not touch the silver plate on the bottom of the cartridge, or the silver metal or circuit area on the side.

Make sure the BJ cartridge's print head is facing away from you. Carefully remove the orange cap and then pull the orange tape from the print head.



Discard the cap and tape immediately. Never attempt to re-attach the cap or tape to the print head; this may adversely affect the ink flow or quality of the ink color.

③ Insert the BJ cartridge.

Raise the blue lock lever (on the right side of the cartridge holder) to the up position. Lock Lever

Make sure the cartridge label faces you and the print head is down. Carefully set the BJ cartridge straight down into the cartridge holder.

Install the MultiPASS C545 Software

Your MultiPASS C545 comes with a Setup program that makes installing the MultiPASS software easy and fast. You install the MultiPASS C545 software from the MultiPASS C545 Installer CD.

Important! The MultiPASS must be plugged in and connected to your Macintosh. If you have a previous version of the MultiPASS Desktop Manager software installed, you must remove it. See your online MultiPASS Desktop Manager Software Guide for details.

Standalone Fax Users: If you plan to use the MultiPASS C545 as a standalone fax machine, you do not need to install the MultiPASS Desktop Manager software. However, you do need to program your name and fax number into the unit so that this information prints on faxes you send. You can also select a Receive Mode for faxes you receive.

Start up your system in this order:

- 1. Make sure your computer is turned off.
- 2. Be sure the MultiPASS is plugged in and connected to the computer.
- 3. Now turn on the computer.

When you see the Macintosh desktop, follow these steps.



Insert the MultiPASS Canon Creative CD into your CD drive. (This CD contains all the device software for your MultiPASS.)

- 2. The MultiPASS Canon Creative screen should appear automatically. (If not, doubleclick the **MultiPASS C545** icon that appears in the CD window on your desktop. This will launch the MultiPASS Canon Creative screen.)
- 3. Click the Install/Uninstall button on the MultiPASS Canon Creative screen.
- 4. On the new screen that appears, click the Install MultiPASS Software button. This will install the MultiPASS Desktop Manager software package. Follow the instructions on screen. (You must accept the license agreement in order for installation to proceed.)
- 5. When installation is complete, you will be

- 8. On the Receive Fax tab, select one of four Receive Modes to determine how faxes are received. For more information about these Receive Modes, see Chapter 3, Using the Fax Setup Utility in your Desktop Manager Software Guide (click the Manuals/Supplies/Help button on the Canon Creative screen, or double-click the Desktop Software Guide icon in the Desktop Manager folder on your hard drive).
- 9. Installation and setup of the MultiPASS Desktop Manager software is now complete.
- To install Canon Photo and TextBridge Pro:
- 1. Make sure the MultiPASS Canon Creative CD is inserted into your CD drive. (Double-click the MultiPASS C545 icon if the MultiPASS Canon Creative screen does not appear automatically.)
- 2. Click the Install/Uninstall button on the MultiPASS Canon Creative screen.
- 3. Click the Install Canon Photo button. Follow the instructions that appear on the screen.
- 4. When installation is complete, click the Install TextBridge Pro button.
- 5. After you finish installing Canon Photo and TextBridge Pro, click the Plug-In Setup button.

MultiPASS Software

The MultiPASS comes with the following software: MultiPASS Toolbar, MultiPASS Printer Driver, ScanTastic[™] for MultiPASS, and Canon Creative for MultiPASS.

Your Canon Creative for MultiPASS software includes:

OfficeReady[™] **CC**

Now you can enhance your image and boost your performance with professionally designed Microsoft® Office templates – for business and personal use.

- 250 templates integrated for Word[®], Excel[®], and PowerPoint[®]
- Perfect for business and personal applications
- Customized templates create professional documents in seconds
- Integrated tools simplify advanced office-document functions

You must have Microsoft Office installed on your system to use OfficeReady CC.

Canon Photo

With Canon Photo, you can digitally enhance and retouch your photographs, share them with friends over the Internet, explore special effects and create wonderful photo projects:

- Organize and enhance your digital pictures easily
- Add pictures, movies, and sound to your e-mail
- Create photo projects from over 250 ready-made templates
- Canon Photo is backed by Canon's photographic expertise and leadership

TextBridge[®] Pro

The powerful, easy way to scan documents into your personal computer for editing as text:

- Turn paper into PC documents without retyping. TextBridge Pro is a full-featured, highly accurate and easy-to-use document recognition package.
- TextBridge Pro offers increased accuracy and improved duplication of page layout including pictures and tables.
- Edit scanned documents with a word processor, spreadsheet, or HTML editor



For printing or receiving faxes, the MultiPASS uses paper from the sheet feeder.

The sheet feeder is ADF Sheet Feeder (holds documents to be faxed, copied, (holds blank paper the larger capacity for printing or tray behind or scanned) receiving faxes) the ADF. • Pull the paper rest up until it stops. Move the paper guide to Sheet Feeder the left to match the size of your paper.

Fan a stack of paper. Fan the edge that will feed into the MultiPASS first; then tap the stack on a flat surface to even its edges.

2 Insert the stack of paper.

Make sure the print-side of the paper is face-up. Align the right edge of the stack with the right side of the sheet feeder.



Note Do not fill the sheet feeder above the limit mark (\triangleright]). The sheet feeder holds up to 100 sheets of plain paper (20 lb or 75 g/m²).

Adjust the paper guide snugly against the side of the stack of paper.

C What's Next?

After using this *Quick Start Guide* to unpack and set up your new MultiPASS unit, you'll want to look at the rest of your documentation. All the online manuals in Adobe Acrobat format are located on the MultiPASS Installer CD and in the MultiPASS Desktop Manager folder on your hard drive.

MultiPASS C545 User's Manual (in Adobe® Acrobat® PDF format)

This manual describes how to use the MultiPASS as a monochromatic or color printer and covers the basics on how to send and receive faxes. It also includes maintenance, troubleshooting, and specifications.

MultiPASS Desktop Manager Software Guide (in Adobe[®] Acrobat[®] PDF format)

Use the online *Software Guide* to find out how to use the MultiPASS C545 Printer Driver, ScanTastic scanning software, MultiPASS Fax Setup Utility and the MultiPASS Toolbar.

Standalone Fax Manual (in Adobe[®] Acrobat[®] PDF format)

If you are NOT going to connect the MultiPASS to your computer, use this manual to find out how you use the operation panel on the MultiPASS to control all your faxing and receiving functions.

PAGE 6 (BACKS 5)

PAGE 7 (BACKS 4)

CANON/MPC530\560 Q.S.G: Pages 6 & 7 - File: 560QS6-7.eps Wendi Swanlund UPDATE4/FINAL> December 26, 1999

Printing an Image or Document

To print an image or a document, make sure you have paper loaded in the multi-purpose tray. Start the application that you used to create the image or document. Make sure the Canon MultiPASS C545 printer is selected as your default printer in the Chooser. In the application, choose Print or Page Setup from the File menu. Specify any special printing options, then click **Print** to start the print job. See your online MultiPASS Desktop Manager Software Guide for details.

Faxing or Scanning an Image or Document

For faxing, you load the document face-down in the Automatic Document Feeder (ADF), dial the number you are faxing to, and then press the **Start/Scan** button on the MultiPASS.

To scan, load the image or document in the Automatic Document Feeder (ADF). Scan the document in the following ways.

Scanning With the MultiPASS Toolbar

Use the MultiPASS Toolbar to scan a document directly into an application.

If you installed Canon Photo and TextBridge Pro, or if PictureViewer and SimpleText are on your system, just click any of the application buttons to scan directly into that application.

To customize the default settings associated with a Toolbar button, click and hold the button. To add an application to the Toolbar, drag the application icon onto the Toolbar.

The Toolbar appears automatically. If you quit the Toolbar, relaunch it by selecting MultiPASS Toolbar from the Apple menu.



Scanning With ScanTastic or Other Applications

To set more detailed scan options, click the ScanTastic Central button on the Toolbar, or select ScanTastic Central from the Apple menu. You can also use ScanTastic as a plug-in, to scan directly to applications that support the Adobe Photoshop plug-in standard.

Scanning With the Start/Scan Button

You can insert a document into the ADF and press the Start/Scan button on the operator panel on the front of the MultiPASS. The factory default setting for this button is to scan into Canon Photo, if you have it installed. To customize the scan settings and scan destination, click and hold the Start/Scan button on the Toolbar.



See your online MultiPASS Desktop Manager Software Guide for complete details on using the Toolbar and ScanTastic.

Copying an Image or Document

To copy an image or a document, make sure you have paper loaded in the sheet feeder. Next, place the image or document you want to copy face-down in the ADF. On the operation panel, press the Copy button and then press the Start/Scan button. (To make multiple copies, press Copy, enter the number of copies with the numeric buttons, and then press Start/Scan. To make one color copy, press Color so the light comes on, press Copy, and then press Start/Scan. See your online *MultiPASS C545 User's Manual* for details.)





©2000 Canon Computer Systems, Inc. BCI, BJ, Bubble Jet and MultiPASS are trademarks of Canon Inc. Print Planet is a service mark of Canon Computer Systems, Inc. Mac and the Mac logo are trademarks of Apple Computer, Inc., registered in the U.S. and other countries. All other products and brand names are trademarks of their respective owner



Canon

1

QUICK START GUIDE

Mac

A Universe of Creative Projects



www.canonprintplanet.com



IMPORTANT

Follow the steps in this Quick Start Guide to unpack and set up your new MultiPASS C545 multifunction printer.

30-32236-0100