

HINTS

For Best Overall Toy Function

- Keep background noise low, or for best results play with Wise-Crackin' Shrek in a quiet room.
- Wise-Crackin' Shrek performs best when you sit between 12 and 18 inches away from the toy, facing it directly.
- Talk in a normal tone of voice, the way that you would talk to a friend. Pronounce all the syllables of each word clearly.
- Shouting or speaking very loudly does not improve speech recognition.
- Wait until Shrek has finished speaking before giving him another speech cue.
- If Shrek gets dirty, wipe him clean with a soft, damp cloth. NEVER IMMERSER WISE CRACKIN' SHREK IN WATER!
- Keep Shrek's Cue Card handy, and remember that the toy will respond only to the exact commands on the card. You can always hear speech cues by squeezing, holding for three seconds, and releasing Shrek's tummy.
- If Shrek's speech begins to slow down, or if he begins to talk constantly, try moving toy to a quiet room or change the batteries.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including any interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.



Shrek is a registered trademark of DreamWorks L.L.C.
Shrek 2 and Shrek Ear Design™ and © 2004
DreamWorks L.L.C.
®* and/or ™* & © 2003 Hasbro. All Rights Reserved.
© denotes Reg. U.S. Pat. & TM Office.

05667/05697 Asst.
P/N 6305970000



Questions? Call: 1-800-327-8264

AGES 5+

SHREK 2

05667/05697 Asst.

Wise-Crackin' Shrek®

Thank you for choosing
this Shrek 2 friend!

Squeeze Shrek's tummy
and the fun begins!



You have received Shrek in DEMO MODE..
See inside for operating instructions.

For best play keep background noise low, or
play with Wise-Crackin' Shrek in a quiet room.

TO PLAY

NOTICE: SWITCH TOY FROM “DEMO” TO “PLAY” BEFORE CONTINUING



Save Shrek's Cue Card (located on the hang tag attached) to remind you of Shrek's speech cues.

NOTE: Shrek responds only to cues spoken exactly as they appear on his cue card

1. Squeeze Shrek's tummy and he will respond with “That tickles!” to let you know that he's awake.
2. Once he's awake, refer to the cue card and say one of Shrek's speech cues. Shrek will listen to you and respond.
3. Shrek has two different modes: “I love you” and “wise-crackin'” mode. When he's in “I love you” mode, he responds to cues with a unique set of phrases. When he's in wise-crackin' mode, he responds with another unique set of phrases. Say “I love you” or “Onions!” to change his mode at any time.



* Shrek responds with several phrases. This is one example.

4. There are several cues you can say to Shrek to which he will respond. Also, Shrek may ask questions that you can respond to with “Yes” or “No”. His next response will differ depending on your answer.

You Can Say

**I love you!
Onions!
Tell me a joke!
Are you hungry?
Sing a song!
Are you sleepy?
Are we there yet?
You're my friend.
Hello, Shrek!
See you later!**



Shrek May Ask

**Are we there yet?
Am I your favorite toy?
Are you thinking what I'm thinking?**

If you need a reminder of Shrek's speech cues, squeeze and hold Shrek's tummy for 3 seconds, then release. He will recite all of the cues that you can say to him to make him talk!

TURNING Shrek OFF


There are three ways to turn Shrek off:

- Say, “See you later!”
- Manually turn him off by squeezing his tummy once.
- Shrek will shut off automatically after 3 minutes of inactivity.

Note: After a 3 minute “shut off”, you'll need to re-squeeze his tummy to turn Shrek back on.

TO REPLACE BATTERIES

When the batteries need replacement, open the fabric fasteners on Shrek's back, and pull the fabric open enough to access his battery door. Use a Phillips/cross head screwdriver to loosen the screw in battery compartment door, and remove door (screw remains attached to door). Remove exhausted batteries and insert 2 fresh “AA” or R6 size batteries. Alkaline batteries recommended. Replace the door, tighten screw, and close fabric fasteners.



⚠ CAUTION: TO AVOID BATTERY LEAKAGE

1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturer's instructions.
2. Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
3. Always remove weak or dead batteries from the product.

IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference.

Batteries should be replaced by an adult.

⚠ CAUTION:

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and - polarity markings.
2. Do not mix old batteries and new batteries, or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short-circuit the supply terminals.
6. Should this product cause, or be affected by, local electrical interference, move it away from the other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
7. **RECHARGEABLE BATTERIES:** Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision. **DO NOT RECHARGE OTHER TYPES OF BATTERIES.**