



*Owner's
Guide*

VISION  FITNESS®

X6150 AND X6250HRT
INCLINE ELLIPTICAL TRAINERS

Congratulations on choosing a VISION FITNESS Incline Elliptical Trainer. You've taken an important step in developing and sustaining an exercise program! Your Incline Elliptical Trainer is a tremendously effective tool for achieving your personal fitness goals. Regular use of your Incline Elliptical Trainer can improve the quality of your life in so many ways...

Here are just a few of the health benefits of aerobic exercise:

- Weight Loss
- A Healthier Heart
- Improved Muscle Tone
- Increased Daily Energy Levels
- Reduced Stress
- Help in Countering Anxiety and Depression
- An Improved Self Image

The key to reaping these benefits is to develop the exercise habit. Your new Incline Elliptical Trainer will help you eliminate the obstacles that prevent you from getting in your exercise time. Snow and rain and darkness won't interfere with your workout when you have your Incline Elliptical Trainer in the comfort of your home. This Owner's Guide provides you with basic information on starting an exercise program. A more complete knowledge of your new Incline Elliptical Trainer will assist you in realizing your goal of a healthy lifestyle.

Please contact your authorized VISION FITNESS retailer should service be required. If a question or problem arises which cannot be handled by your VISION FITNESS retailer, please contact us:

VISION FITNESS
500 South CP Avenue
P.O. Box 280
Lake Mills, WI 53551
Ph: 1.800.335.4348
Fax: 1.920.648.3373
www.visionfitness.com

Table of Contents

ALL MODELS

SAFETY INSTRUCTIONS	4
POWER REQUIREMENTS	5
ASSEMBLY & MOVING	6
PLACEMENT, STABILIZING, & POWER	7
CONTACT HEART RATE, INCLINE RAMP	8

X6250HRT CONSOLE

CONSOLE OVERVIEW	10
CONSOLE DESCRIPTIONS	11
ON/OFF SWITCH	13
PROGRAM OVERVIEWS	14
PROGRAM OPTIONS	17
USING THE PROGRAMS	18
USING THE SPRINT 8 PROGRAM ...	20
USING HEART RATE TRAINING	21
USING THE HEART RATE CHEST STRAP	22
ALL HRT® PROGRAMS	23
USING CUSTOM PROGRAMS	25
ENGINEERING MODE	26

X6150 CONSOLE

CONSOLE OVERVIEW	28
CONSOLE DESCRIPTIONS	29
PROGRAM OVERVIEWS	31
USING THE PROGRAMS	33
USING THE SPRINT 8 PROGRAM ...	35
ENGINEERING MODE	36

GENERAL


PREVENTATIVE MAINTENANCE	37
TROUBLESHOOTING	38
TROUBLESHOOTING HEART RATE CHEST STRAP	39
HOME WARRANTY	40
CORPORATE WARRANTY	42
DEVELOPING A FITNESS PROGRAM .	44
EXERCISE GUIDELINES	45
TARGET HEART RATE	46
RATE OF PERCEIVED EXERTION	47
BALANCED FITNESS	48
STRETCHING	49
WEEKLY WORKOUT LOGS	52
MONTHLY WORKOUT LOGS	54

ALL MODELS

X6250HRT

X6150

GENERAL



X6250HRT

X6150

X6150 **X6250HRT**
INCLINE ELLIPTICAL TRAINERS

IMPORTANT SAFETY INSTRUCTIONS SAVE THESE INSTRUCTIONS

When using an electrical product, basic precautions should always be followed, including the following:

Read all instructions before using this exercise product.

WARNING! To reduce the risk of burns, fire, electrical shock or injury to persons:

- Use this exercise product for its intended use as described in this Owner's Guide. Only use attachments recommended by the manufacturer.
- Never drop or insert any object into any opening.
- Do not remove the Incline Elliptical Trainer sidecovers. Service should be performed only by an authorized VISION FITNESS retailer.
- Never operate this Incline Elliptical Trainer if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or immersed in water. Please contact your authorized VISION FITNESS retailer for service.
- Keep the cord away from heated surfaces.
- Do not use outdoors.
- To disconnect, turn the switch to the OFF position, then remove plug from outlet.
- Only use the power cord provided with your VISION FITNESS Incline Elliptical Trainer.
- Never place the power cord under carpeting or place any object on top of the power cord that may pinch and damage it.
- Unplug your Incline Elliptical Trainer when not in use and before moving it.

CHILDREN

- Keep children off your Incline Elliptical Trainer at all times.
- When the Incline Elliptical Trainer is in use, young children and pets should be kept at least 10 feet away.

OTHER SAFETY TIPS FOR YOUR VISION FITNESS INCLINE ELLIPTICAL TRAINER

CAUTION! If you experience chest pains, nausea, dizziness or shortness of breath, stop exercising immediately and consult your physician before continuing.


- Do not wear loose clothing that might catch on any part of the Incline Elliptical Trainer.
- Read this Owner's Guide before operating this Incline Elliptical Trainer.

CLEANING

- Clean only with soap and a slightly damp cloth; never use solvents.

POWER REQUIREMENTS

This product is for use on a nominal 120-volt circuit, and has a grounding plug that looks like the plug illustrated below. An improper connection of the equipment grounding conductor can result in a risk of an electrical shock. Do not modify the plug that was provided with this product. If this plug does not fit into your outlet, have a qualified electrician install the proper outlet. Adapters, extension cords and surge protectors should not be used with this product.



ASSEMBLY

It is recommended, when possible, that an authorized VISION FITNESS retailer assemble your Incline Elliptical Trainer. If you have elected to assemble this product yourself, for your safety, please read and follow each of the steps in the enclosed assembly instructions. If you have any questions regarding any component or function of your Incline Elliptical Trainer, contact your retailer.

MOVING

Your VISION FITNESS Incline Elliptical Trainer has transport wheels included for ease of mobility. To move, firmly grasp the rear of the frame assembly. Carefully lift and roll on the transport wheels.




CAUTION: Our Incline Elliptical Trainers are well-built and heavy, weighing up to 340 pounds! Use care and additional help if necessary.

PLACEMENT IN YOUR HOME

Please follow the safety instructions to place the Incline Elliptical Trainer in the location where it will best be used. It is important that you place your Incline Elliptical Trainer in a comfortable and inviting room. Avoid putting your Incline Elliptical Trainer in an unfinished basement or undesirable setting. Exercise adherence will be achieved only if you exercise in an attractive setting.


STABILIZING THE INCLINE ELLIPTICAL TRAINER

After positioning the Incline Elliptical Trainer in its intended location, check the unit's stability. Rocking or wobbling indicates that your Incline Elliptical Trainer needs to be leveled. Determine which leveler is not resting completely on the floor. Loosen the nut at the base of the leveler to allow the leveler to rotate. Now rotate the leveler to the left or right until the Incline Elliptical Trainer is stable. Lock the adjustment by tightening the nut against the rear foot support.



TURNING THE UNIT ON AND OFF


Use the power switch on the front of the unit to turn the machine ON and OFF. It is recommended to turn the machine off when not in use.



CONTACT HEART RATE

HAND PULSE HEART RATE SENSORS


The Contact Hand Pulse Sensors are included on each product to monitor your heart rate. To use, grasp both of the sensors with a comfortable grip during your workout. The console will display your heart rate. It may take the system a few seconds to zero in on your actual heart rate.



INCLINE RAMP

Press the INCLINE UP or DOWN arrows to adjust the ramp incline from 1 to 16. This incline setting represents a ramp angle from 4° through 21°. There is not a one-to-one relationship between the ramp setting and the degree of incline.

Ramp changes are not immediate. They will take time to get to the target incline angle.




IMPORTANT: The ramp incline changes only occur when the foot pedals are in motion.

X6250HRT

X6250HRT CONSOLE

DISPLAY CONSOLE OVERVIEW

The computerized display allows the user to select a workout that meets their desired fitness goals. It also allows the user to monitor the progress and feedback of each workout so they can track improvements in overall fitness over time.



X6250HRT CONSOLE DESCRIPTIONS

A. START/HOLD TO RESET

Press the START key to begin a MANUAL workout immediately without having to set individual information. When the program begins, you have the ability to adjust resistance levels with the ARROW keys. Feedback information will be calculated using default settings.

PAUSE: If you need to PAUSE your program during a workout, pressing the START key will PAUSE your program for five minutes. Pressing START will return you to your workout.

RESET: If you need to RESET the console during your workout, you can do so by holding down the START key for three seconds or until the display resets.

B. ENTER/HOLD TO SCAN

This key is used after entering each piece of information in setup such as age, weight, or level.

SCAN: When exercising in a program, pressing the ENTER key will allow you to SCAN the feedback display views. If you hold down the ENTER key for three seconds during your workout, the SCAN function will automatically alternate feedback display views.

C. ARROW KEYS

These keys are used to change values in setup mode prior to your workout. During your workout, they are used to change workout levels. In HRT® programs, they are used to change your target heart rate.

D. PROGRAM KEYS

These keys provide quick access to your favorite workouts. There is no need to scroll through the programs to find the one you want. Simply press the program key and begin user setup.

X6250HRT CONSOLE DESCRIPTIONS (continued)**E. PROFILE DISPLAY**

This window provides a dot matrix profile of the workout segments you are about to complete, as well as those you have already completed, and the level of resistance for each segment.

F. MESSAGE/FEEDBACK WINDOWS

These windows provide step-by-step instructions in the setup mode, instructions, feedback and motivational messages during your workout.

FEEDBACK:

During your workout, these windows display exercise feedback about your workout, including:

TIME: the time elapsed or the time remaining in your workout.

DISTANCE: the total distance traveled in miles or kilometers since the start of your workout.

STRIDES/MIN: your stride rate or strides per minute.

WATTS: a measurement of workload; one watt is equal to six kilogram-meters per minute.

CALORIES: an estimate of calories burned since the beginning of the workout.

RESISTANCE: the current resistance level of your workout.


INCLINE: the level of ramp incline. There are 16 levels that run between 4° and 21° of elevation.

METS: a measurement of oxygen consumption; one MET equals the approximate amount of oxygen consumed per minute by a person at rest.

G. HEART RATE/HRT FEEDBACK WINDOW

This window provides feedback on your current heart rate and the percent of your predicted maximum heart rate (% Heart Rate). It also includes your target heart rate when using one of the HRT® programs on this product.

ON/OFF SWITCH Turn your Incline Elliptical Trainer off if you will not use it for an extended period of time.



X6250HRT

THE X6250HRT PROGRAMS

PROGRAM OVERVIEWS




MANUAL is a user-controlled program in which the resistance remains at a set level unless you decide to change it.



INTERVAL is an efficient workout that strengthens your cardiovascular system by alternating work intervals and recovery intervals. Be sure to challenge yourself with intense work intervals.




FAT BURN is a program designed to target your stored body fat. This program is generally used at a slightly lower resistance level but runs for longer durations than other programs.




SPRINT 8 is an anaerobically-based interval program. It is effective in recruiting fast twitch muscle fibers and improving athletic performance.



GLUTE BURN is a challenging program designed to tone the lower half of the body. This program includes incline changes and user prompts for maximum effectiveness.



SUMMIT HIKE is a variable ramp incline program that adds variety and targets your muscles from different angles.



X6250HRT


HRT CARDIO is a high-intensity program that keeps you at the upper range of your predicted maximum heart rate and promotes cardiovascular endurance and maximum calorie burning. The user must grasp the hand pulse sensors or wear a telemetric heart rate chest strap during use. The program will automatically adjust resistance to keep you at 80% of your predicted maximum heart rate.

HRT WEIGHT LOSS is a lower intensity workout that will help your body burn a higher percentage of calories from your body's fat reserves. The user must grasp the hand pulse sensors or wear a telemetric heart rate chest strap during use. The program will automatically adjust resistance to keep you at 65% of your predicted maximum heart rate.

HRT INTERVAL alternates between effort intervals of 80% and 70% of your predicted maximum heart rate. This program is designed to increase your cardiovascular fitness capacity. The user must grasp the hand pulse sensors or wear a telemetric heart rate chest strap during use.

HRT HILL increases your intensity level from 65%, to 70%, to 75%, to 80% of your predicted maximum heart rate to promote cardiovascular strength and endurance. The user must grasp the hand pulse sensors or wear a telemetric heart rate chest strap during use.

X6250HRT



CUSTOM allows you to preset up to four workout programs by setting the resistance and profile of each segment in the program. You have the ability to save or change the workouts whenever you wish.

PROGRAM OPTIONS

PROGRAM	PRESET INCLINE	PRESET RESISTANCE	INSTRUCTIONAL MESSAGE PROMPTS	FIXED TIME	HEART RATE CONTROLLED
MANUAL		•			
INTERVAL		•			
FAT BURN		•			
SPRINT 8		•	•	•	
GLUTE BURN	•				
SUMMIT HIKE	•				
HRT® PROGRAMS		•			•
CUSTOM		•			


NOTE: The incline profile will be displayed during the GLUTE BURN and SUMMIT HIKE programs. The resistance profile will be displayed briefly if you change your resistance level. All other programs will display the resistance level and only display the inline level briefly when you change the incline level.

X6250HRT

USING THE PROGRAMS


SELECTING EASY START

The easiest way to begin exercising is to simply press the START key. You will begin exercising in a MANUAL resistance program in which you can change the resistance levels to meet your goals. Current default settings will be used to determine exercise feedback.




SELECTING A PROGRAM

Each program has its own program key. Press the key of the program you would like to use. You can also use the arrow keys to scroll through the program options and see the exercise profiles for each of the programs.




ENTERING AGE

When prompted by the message center to enter your age, use the UP ▲ arrow or DOWN ▼ arrow to adjust displayed age to the correct value. This information is necessary for the HRT® programs and will affect your “% Heart Rate” feedback.




ENTERING TIME

When prompted by the message center to enter a time, use the UP ▲ arrow and DOWN ▼ arrow to adjust the displayed exercise time to a desired value.




ENTERING WEIGHT

When prompted by the message center to enter weight, use the UP ▲ arrow and DOWN ▼ arrow to adjust the displayed weight to equal your current body weight. This information is necessary to give accurate exercise feedback for calorie and MET calculations.



ENTERING LEVEL

When prompted by the message center to enter level, use the UP ▲ arrow and DOWN ▼ arrow to adjust the displayed resistance level. There are 16 levels of resistance to choose from in each program. The maximum resistance level varies by program.



The HRT® programs will set your target heart rate in the place of resistance level. The console will display your target heart rate and give you the opportunity to adjust this value if you wish.

X6250HRT

USING THE SPRINT 8 PROGRAM

The Sprint 8 program is an anaerobic interval program designed to build muscle, improve speed, and naturally increase the release of Human Growth Hormone (HGH) in your body. Producing HGH through exercise and a proper diet has been shown as an effective way to burn fat and build lean muscle mass according to Phil Campbell, author of *Ready, Set, Go! Synergy Fitness*. Please go to Mr. Campbell's website www.readysetgofitness.com for more details about this radical new approach to fitness.

The SPRINT 8 program features intense sprint intervals followed by recovery intervals. The program includes the following phases:

1. **WARM-UP** should gradually increase your heart rate and increase respiration and blood flow to working muscles. The warm-up is controlled by the user to meet your specific needs.
2. **INTERVAL TRAINING** starts immediately after the warm-up with a 30-second Sprint interval. Seven Recovery Intervals of 90 seconds will alternate with the eight 30-second Sprint Intervals. The message display will prompt you to increase your stride rate during the Sprint Interval and decrease stride rate during the Recovery Interval. A difference of 40 to 60 Strides Per Minute between Sprint Interval and Recovery Interval is recommended.
3. **COOL-DOWN** helps return your body's systems to resting levels. Less demand is placed on your heart during recovery if an appropriate cool-down is used following the exercise.

Due to the fact that this is a specialized training program, total workout time is not displayed during the program. The interval time is displayed in the time window instead. It takes only 20 minutes to complete the SPRINT 8 workout.

USING HEART RATE TRAINING

WHAT IS HEART RATE TRAINING?


Heart Rate Training means exercising at an intensity that keeps you in your ideal heart rate zone. Your personal heart rate training zone depends on your fitness goal, such as weight loss, cardiovascular endurance, or strength building. Refer to page 46 for more information on heart rate training zones. VISION FITNESS HRT® programs are set up to keep you at an ideal heart rate based on your fitness goal. These programs automatically adjust resistance based on your heart rate readings.

The X6250HRT console features four programs (HRT Weight Loss, HRT Cardio, HRT Interval, and HRT Hill) that offer the benefits of Heart Rate Training.

- *These programs use the predicted maximum heart rate formula (220 minus age) to determine your predicted maximum heart rate. Some individuals have higher or lower maximum heart rates than determined by this formula. The programs allow you to modify your Target Heart Rate to achieve your personal goals.*

HAND PULSE HEART RATE SENSORS


The Contact Hand Pulse Sensors are included on each product to monitor your heart rate. To use, grasp the sensors with a comfortable grip during your workout. The console will display your heart rate. Although your signal will be displayed immediately, it may take the system a few seconds to zero in on your actual heart rate.



NOTE: The Contact Hand Pulse Sensors will work for the HRT® programs, but it is recommended to use the telemetric chest strap for an uninterrupted signal and ease of use.


TELEMETRIC HEART RATE CHEST STRAP (AVAILABLE ON X6250HRT ONLY)

The wireless Telemetric Chest Strap uses a pair of electrodes on the underside of the strap to send your heart rate signal to the console. Prior to wearing the chest strap, moisten the two rubber electrode pads with several drops of water. These electrodes must remain wet to provide an accurate signal. We advise using the chest strap against your skin, but it also functions through a thin layer of wet clothing.



STRAP PLACEMENT

Center the transmitter strap just below the breast or pectoral muscles, directly over your sternum with the VISION FITNESS logo facing out. Adjust the elastic strap so it is snug but comfortable enough for proper breathing.




ALL HRT PROGRAMS

During the workout, the user will grasp the hand pulse sensors or wear the telemetric chest strap to send their heart rate signal to a receiver in the console. The console will continuously monitor the heart rate, adjusting the resistance level of the Incline Elliptical Trainer to keep your heart rate within several beats of your Target Heart Rate. By using the SCAN key, the heart rate feedback window conveniently displays your Heart Rate, % Heart Rate, and your Target Heart Rate to keep you informed about your current heart rate. Each program will begin with a two-minute warm-up. When the workout time has been completed, the console will begin a five-minute cool-down. The user will be responsible for adjusting resistance to meet their needs during the warm-up and cool-down.

ADJUSTING TARGET HEART RATE

While exercising in one of the HRT® programs, after the two-minute warm-up, you may decide the Target Heart Rate needs to be adjusted. To adjust your Target Heart Rate, use the UP ▲ or DOWN ▼ arrow keys. Push ENTER to select.



HRT CARDIO

The HRT CARDIO program is designed to maintain your heart rate at 80% of your predicted maximum heart rate. It is intended to improve efficiency and endurance of your cardiovascular system by working your heart, lungs and circulatory systems. This is a great workout for anyone, but beginners may want to start lower and build their way up to 80% of their predicted maximum heart rate.

HRT WEIGHT LOSS

The HRT WEIGHT LOSS program is designed to maintain your heart rate at 65% of your predicted maximum heart rate. The goal of this program is to burn calories by using your body's fat reserves as the primary fuel during exercise and to improve the efficiency of your workout by eliminating over-training or under-training. This is a great workout for beginners.

HRT INTERVAL

The HRT INTERVAL program is designed to increase aerobic endurance and your overall fitness level, increase endurance of muscle fibers, and increase the amount of calories burned in your exercise session. This program consists of alternating effort and recovery intervals. The Target Heart Rate for your effort interval will be 80% of your predicted maximum heart rate, while the Target Heart Rate for your recovery intervals will be 70% of your predicted maximum heart rate. The two-minute effort interval begins when you reach your Target Heart Rate for that particular interval. The recovery interval duration depends on the amount of time it takes to get to your recovery heart rate.


HRT HILL

The HRT HILL program uses four different Target Heart Rates to build cardiovascular strength and endurance. The resistance will adjust until your rate reaches the Target Heart Rate for four separate hills. The hills will be set at 65%, 70%, 75%, and 80% of your predicted maximum heart rate. The program will keep you at each heart rate level for one minute from the time the Target Heart Rate is reached. The program will repeat the series of hills until the workout time is complete.

USING CUSTOM PROGRAMS

The CUSTOM programs allow for four separate workout choices to be set and then stored for future use.

Setup for the CUSTOM programs begins just as any other program. The user will push the CUSTOM program button, set age, set time, and set weight. At this point, the console will ask the user to select one of four CUSTOM programs. If the programs have not yet been set, the user can follow these setup instructions:



1. Use the arrows to select one of four CUSTOM programs.
2. Press ENTER to select.
3. The dot on the bottom left corner of the dot matrix will now be flashing. Use the UP ▲ or DOWN ▼ arrow to adjust the resistance of the first segment to your desired setting.
4. Push ENTER to select.
5. Continue setting each segment until all 16 segments have been set.
6. When you have pressed ENTER after the final segment, the program will automatically begin.

Each program will remain saved in the console's memory and can be used over again.

If the CUSTOM programs have already been saved, you have two options:

1. Press START to begin the program as it has been set.
2. Press ENTER to begin resetting each segment for a new program.

X6250HRT

X6250HRT ENGINEERING MODE

Engineering consists of optional settings and information used by service technicians to assure your product is working in proper order. There are also several default settings that allow you to customize the incline elliptical trainer to fit your needs.

ENTERING AND USING ENGINEERING MODE

- Press and hold the UP ▲ and DOWN ▼ RESISTANCE ARROW keys simultaneously for three seconds.
- The console will beep and bring you into engineering mode. Use the UP ▲ and DOWN ▼ RESISTANCE ARROW keys to scroll through the various engineering options.
- Press the ENTER key to select the appropriate engineering option.
- Use the UP ▲ and DOWN ▼ RESISTANCE ARROW keys within each setting to modify the setting.
- Press the ENTER key to save the setting.
- To exit engineering mode, press and hold the START key for three seconds.

ENGINEERING OPTIONS INCLUDE:


SETTING	DESCRIPTION
HARDWARE TEST	TEST USED BY SERVICE TECHNICIANS TO TEST ECB SYSTEM
LED TEST	TEST USED BY SERVICE TECHNICIANS TO TEST LED DISPLAY
DEF TIME SET	SET THE DEFAULT WORKOUT TIME
DEF LEVEL SET	SET THE DEFAULT RESISTANCE LEVEL
DEF AGE SET	SET THE DEFAULT USER AGE
BEEPER MODE	TURN THE BEEPER ON OR OFF
SPEED MODE	SET THE FEEDBACK INFO TO ENGLISH (MILES) OR METRIC (KILOMETERS)
MACHINE MODE	SET TO BIKE, ELLIPTICAL TRAINER, OR INCLINE ELLIPTICAL TRAINER
DOT DISP MODE	SET DOT MATRIX DISPLAY WHEN NOT IN USE
ACC TIME	MEASURES TOTAL TIME IN HOURS OF USE
ACC DIST	MEASURES TOTAL DISTANCE TRAVELED ON THE UNIT
INCLINE TEST	TESTS AT ZERO, MIN., AND MAX.
AUTO-CALIBRATE	AUTO-CALIBRATION OF ELEVATION MOTOR TO SET MIN, MAX AND ZERO POSITIONS

X6150

X6150 SERIES CONSOLE

DISPLAY CONSOLE OVERVIEW

The computerized display allows the user to select a workout that meets their desired fitness goals. It also allows the user to monitor the progress and feedback of each workout, so they can track improvements in overall fitness over time.



X6150 CONSOLE DESCRIPTIONS

A. POWER SWITCH

Turn off power to your console if your Incline Elliptical Trainer will not be used for an extended period of time.

B. MILES/KILOMETER SWITCH

Changes your exercise feedback to the English or Metric system.

C. BIKE OR ELLIPTICAL SWITCH

This console can be used on both products, so make sure the switch is set to ELLIPTICAL mode.

D. PROFILE DISPLAY

This window provides an 8x12 block profile of the workout segments you are about to complete or have completed and the level of resistance for each segment. Each column represents 1/12 of your total workout time. Each row represents two resistance levels or two incline levels.

E. MESSAGE WINDOW

This window provides step-by-step instructions in the setup mode, feedback or motivational messages during your workout and at the end of your workout.

F. FEEDBACK DISPLAY

During your workout, this window displays exercise feedback about your workout, including:

TIME: the time elapsed or the time remaining in your workout.

DISTANCE: the total distance traveled in miles or kilometers since the start of your workout.

STRIDES/MIN: the stride rate or Strides Per Minute (SPM).

WATTS: measurement of workload; one watt is equal to six kilogram-meters per minute.

CALORIES: an estimate of calories burned since the start of the workout

LEVEL: the current resistance level of your workout.

HEART RATE: displays your heart rate in beats per minute when using the hand pulse grips.

INCLINE: the level of ramp incline. There are 16 levels that run between 4° and 21° of elevation.

X6150 CONSOLE DESCRIPTIONS (continued)**G. START/PAUSE/HOLD TO RESET KEY**

Press the START key to begin exercising at the set default time. Press START when instructed to by the scrolling LCD message center to begin a program. When exercising, press the START key to pause your workout.

H. UP ▲ KEY

Use this key in setup mode to change display values. During your workout, use this key to increase resistance.

I. DOWN ▼ KEY

Use this key in setup mode to change display values. During your workout, use this key to decrease resistance.

J. ENTER KEY

Use this key in setup mode to select your personal settings prior to your workout. During your workout, use this key to toggle between Watts feedback and Level feedback.

THE X6150 PROGRAMS

PROGRAM OVERVIEWS

EASY START

The quickest way to begin exercising. Simply press **START** and you will skip the setup of specific workouts and begin exercising at a **MANUAL** constant level workout. The resistance levels do not change automatically, but you can adjust the resistance with the arrows as you choose.

NOTE: Because you did not go through setup mode, the computer will use default values to calculate your feedback information.

X6150

MANUAL is a workout in which the resistance level does not change unless you change it.



INTERVAL is an efficient workout that strengthens your cardiovascular system by alternating work intervals with recovery intervals. Be sure to challenge yourself with intense work intervals.



GLUTE BURN is a challenging program designed to tone the lower half of the body. This program includes incline changes and user prompts for maximum effectiveness.



SUMMIT HIKE is a variable ramp incline program that adds variety and targets your muscles from different angles.




SPRINT 8™ is an anaerobically-based interval program. It is effective in recruiting fast twitch muscle fibers and improving athletic performance.



USING THE PROGRAMS


CHOOSING EASY START

Easy Start is the fastest way to begin exercising, as it allows you to bypass the setup steps required for the preset programs. Simply press START and you will begin a MANUAL, constant resistance level workout. The resistance and incline levels will not change automatically, but you can adjust them by using the arrow keys.




CHOOSING A PROGRAM

Press the UP ▲ or DOWN ▼ keys to scroll through the program selections (Manual, Interval, Sprint 8, Glute Burn, or Summit Hike). When you arrive at your chosen workout, press the ENTER key.



CHOOSING DURATION


The LCD message board will scroll instructions for setting TIME. The default time will be flashing in the TIME window. Set the TIME using the UP ▲ and DOWN ▼ keys. When you arrive at your chosen workout duration, press the ENTER key.



X6150

CHOOSING WEIGHT


Your current body weight is required to give more accurate calorie feedback as you exercise. The LCD message board will scroll instructions for setting WEIGHT. The default weight will be flashing in the calories window. Set WEIGHT using the UP ▲ and DOWN ▼ keys. When you arrive at your current body weight, press the ENTER key.



CHOOSING RESISTANCE LEVEL


The LCD message board will scroll instructions for setting LEVEL. The default level will be flashing in the LEVEL window. Set the LEVEL using the UP ▲ and DOWN ▼ keys. When you arrive at your chosen intensity level, press the ENTER key.

NOTE: The Glute Burn program will ask you to set INCLINE LEVEL in place of the RESISTANCE LEVEL.



STARTING

Press START to begin your workout.



USING THE SPRINT 8 PROGRAM

The Sprint 8 program is an anaerobic interval program designed to build muscle, improve speed, and naturally increase the release of Human Growth Hormone (HGH) in your body. Producing HGH through exercise and a proper diet has been shown as an effective way to burn fat and build lean muscle mass according to Phil Campbell, author of *Ready, Set, Go! Synergy Fitness*. Please go to Mr. Campbell's website www.readysetgofitness.com for more details about this radical new approach to fitness.

The SPRINT 8 program features intense sprint intervals followed by recovery intervals. The program includes the following phases:

1. **WARM-UP** should gradually increase your heart rate and increase respiration and blood flow to working muscles. The warm-up is controlled by the user to meet your specific needs.
2. **INTERVAL TRAINING** starts immediately after the warm-up with a 30-second Sprint interval. Seven Recovery Intervals of 90 seconds will alternate with the eight 30-second Sprint Intervals. The message display will prompt you to increase your stride rate during the Sprint Interval and decrease stride rate during the Recovery Interval. A difference of 40 to 60 Strides Per Minute between Sprint Interval and Recovery Interval is recommended.
3. **COOL-DOWN** helps return your body's systems to resting levels. Less demand is placed on your heart during recovery if an appropriate cool-down is used following the exercise.

Due to the fact that this is a specialized training program, total workout time is not displayed during the program. The interval time is displayed in the time window instead. It takes only 20 minutes to complete the SPRINT 8 workout.

X6150 ENGINEERING MODE

Use the User Set option in Engineering Mode to adjust the Default Weight and Default Level for you console.

ENTERING ENGINEERING MODE

- Press and hold the UP ▲ and DOWN ▼ RESISTANCE ARROW keys simultaneously for three seconds.
- The console will beep and bring you into engineering mode. Use the UP ▲ and DOWN ▼ RESISTANCE ARROW keys to scroll through the various engineering options.
- Press the ENTER key to select the appropriate engineering option.
- Use the UP ▲ and DOWN ▼ RESISTANCE ARROW keys within each setting to modify the setting
- Press the ENTER key to save the setting.
- To exit the engineering option you are in press and hold the START key for three seconds.
- To exit engineering mode, press and hold the START key for three seconds.

ENGINEERING OPTIONS INCLUDE:

SETTING	DESCRIPTION
DISP TEST	LCD TEST
USER SET	SET DEFAULT LEVEL AND DEFAULT TIME
ACC TIME	DISPLAY ACCUMULATED TIME
ACC DIST	DISPLAY ACCUMULATED DISTANCE
HW TEST	TEST USED BY SERVICE TECHNICIANS TO TEST ECB SYSTEM
INCL CAL	AUTO-CALIBRATION OF ELEVATION MOTOR TO SET MIN, MAX AND ZERO
INCL SET	VIEW AND/OR ADJUST INCLINE ADC ZERO, MIN AND MAX VALUES (SET AFTER AUTO-CALIBRATION)

SERVICE AND TROUBLESHOOTING

PREVENTATIVE MAINTENANCE TIPS

- Locate Incline Elliptical Trainer in a cool, dry place.
- Make sure all bolts and fasteners are kept tight.
- Keep the display console free from fingerprints and salt build-up caused by sweat.
- Use a cotton cloth with water and a mild cleaning product to clean the Incline Elliptical Trainer. Other fabrics, including paper towels, may scratch the surface. Do not use ammonia or acid-based cleaners.
- Clean the housing thoroughly on a regular basis.
- VISION FITNESS recommends you clean the roller wheels and ramp before each use with a soft, damp cloth to remove any dust or dirt that might affect the smooth operation of the product.

PREVENTATIVE MAINTENANCE SCHEDULE

Follow the schedule below to ensure proper operation of the product.

ITEM	DAILY	MONTHLY	BI-ANNUALLY	ANNUALLY
DISPLAY CONSOLE		CLEAN		
ALL BOLTS AND HARDWARE			INSPECT	
FRAME		CLEAN		INSPECT
HANDLEBARS		CLEAN		
GUIDE RAILS	CLEAN			
ROLLER WHEELS	CLEAN		INSPECT	
PLASTIC COVERS		CLEAN		
FOOTPLATES		CLEAN		
POWER CORD				INSPECT

TROUBLESHOOTING

Our Incline Elliptical Trainers are designed to be reliable and easy to use. If, however, you have a problem, these troubleshooting steps may reveal the cause.

PROBLEM: The console does not light up.

SOLUTION: Check to make sure the power switch located on the backside of the console is turned on.

SOLUTION: Make sure the power cord is plugged into the base of the Incline Elliptical Trainer, and the power switch located near the plug is on.

SOLUTION: Make sure the wire harness is plugged into the back of the console.

PROBLEM: You feel a thump or hitch in the stride motion.

SOLUTION: Check assembly and tightness of all hardware.

SOLUTION: Wipe off the roller wheels. They could have taken on debris that is causing the thump.

SOLUTION: Check the bolts and the bracket under the footplate. At times, these can be over-tightened which cause friction to the pivoting footplate and may lead to a thump or hitch.

NOTE: If the above steps fail to remedy the problem, discontinue use, turn the power off and contact your retailer.

TROUBLESHOOTING YOUR HEART RATE MONITOR CHEST STRAP

X6250HRT ONLY

PROBLEM: No pulse reading appears.

SOLUTION: There may be a poor connection between the contact pads and skin. Remoisten the contact pads.

SOLUTION: Transmitter is not properly positioned; reposition the chest strap.

SOLUTION: Verify that the distance between the transmitter and receiver is not beyond the recommended range of 36 inches.

PROBLEM: There is an erratic pulse rate.

SOLUTION: Chest strap is too loose; readjust according to directions.

NOTE: It is possible that heart rate monitors will not function properly on some people for a variety of reasons. It may be necessary to experiment with the fit and position of the chest strap. Outside interference sources such as computers, motors, electric dog fences, home security systems, remote controls, CD players, fluorescent lights, etc., may cause problems for heart rate monitors.

LIMITED HOME USE WARRANTY

VISION FITNESS extends the following exclusive, limited warranty, which shall apply only to the use of the device in the home, for residential, non-commercial purposes only. Any other use of the device shall void this warranty.

VISION FITNESS hereby extends the following limited warranties for the following components of the device, for the time period indicated:

FRAME - LIFETIME VISION FITNESS warrants the Frame against defects in workmanship and materials for the life of the product, so long as it remains in the possession of the original owner.

ECB-PLUS™ BRAKE - LIFETIME VISION FITNESS warrants the ECB-PLUS™ Magnetic Brake against defects in workmanship and materials for the life of the product, so long as it remains in the possession of the original owner. Only the Brake and Magnet assembly, and no other ancillary components or parts, are covered by this lifetime warranty.

ELECTRONICS & PARTS - THREE YEARS VISION FITNESS warrants the Electronic components and all original Parts (other than the ECB-PLUS™ Magnetic Brake) against defects in workmanship and materials for a period of three years from the date of original purchase, so long as the device remains in the possession of the original owner.

LABOR - ONE YEAR VISION FITNESS shall cover the Labor cost for the repair of the device for a period of one year from the date of original purchase, so long as the device remains in the possession of the original owner.

LIMITED HOME USE WARRANTY (continued)

EXCLUSIVE REMEDY

The exclusive remedy for any of the above warranties shall be repair or replacement of defective Parts, or the supply of Labor to cure any defect, provided that Labor shall be limited to one year. All Labor shall be supplied by the local Retailer who sold the Product, and the Product must be located within that Retailer's service area. Products located outside the Retailer's service area will not be covered by the Labor warranty.

EXCLUSIONS AND LIMITATIONS

This warranty applies only to the original owner and is not transferable. This warranty is expressly limited to the repair or replacement of a defective Frame, ECB-PLUS™ Magnetic Brake, Electronic component, or defective Part and is the sole remedy of the warranty. The warranty does not cover normal wear and tear, improper assembly or maintenance, or installation of parts or accessories not originally intended or compatible with the Fitness Product as sold. The warranty does not apply to damage or failure due to accident, abuse, corrosion, discoloration of paint or plastic, or neglect. VISION FITNESS shall not be responsible for incidental or consequential damages. Parts and Electronic components reconditioned to As New Condition by VISION FITNESS or its vendors may sometimes be supplied as warranty replacement parts and constitute fulfillment of warranty terms. Any warranty replacement parts shall be warranted for the remainder of the original warranty term.

VISION FITNESS expressly disclaims all other warranties, express or implied, including but not limited to all warranties of fitness for a particular purpose or of merchantability. This warranty gives you specific legal rights, and your rights may vary from state to state.

WARRANTY REGISTRATION

Your warranty card must be completed and sent to VISION FITNESS before a warranty claim can be processed. You may also register via our website at www.visionfitness.com. Inside the enclosed warranty card, you will find a customer survey. Your care in completing the survey will be of value to us in serving you in the future. Comments and suggestions are always welcome. We are certain you will enjoy your new Incline Elliptical Trainer. Thank you for selecting a VISION FITNESS product.

LIMITED CORPORATE WARRANTY

Up to 3 hours use per day

CORPORATE USES DEFINED VISION FITNESS warrants model X6250HRT for use in corporate facilities including: Hotels; Resorts; Police & Fire Stations; Apartment Complexes; Corporate Fitness Centers; Hospitals; Rehabilitation and Sports Medicine Clinics, where average use is up to three hours per day. Not warranted for private Health Clubs, YMCA's or Schools.

FRAME, ECB-PLUS™ BRAKE, ELECTRONICS & PARTS - ONE YEAR

VISION FITNESS warrants the Frame, ECB-PLUS™ Magnetic Brake, Electronic components and all original Parts against defects in workmanship and materials for a period of one year from the date of original purchase, so long as the device remains in the possession of the original owner.

LABOR - ONE YEAR VISION FITNESS shall cover the Labor cost for the repair of the device for a period of one year from the date of original purchase, so long as the device remains in the possession of the original owner.

EXCLUSIVE REMEDY

The exclusive remedy for any of the above warranties shall be repair or replacement of defective Parts, or the supply of Labor to cure any defect, provided that Labor shall be limited to one year. All Labor shall be supplied by the local Retailer who sold the Product, and the Product must be located within that Retailer's service area. Products located outside the Retailer's service area will not be covered by the Labor warranty.

LIMITED CORPORATE WARRANTY (continued)

Up to 3 hours use per day

EXCLUSIONS AND LIMITATIONS

This warranty applies only to the original owner and is not transferable. This warranty is expressly limited to the repair or replacement of a defective Frame, ECB-PLUS™ Magnetic Brake, Electronic component, or defective Part and is the sole remedy of the warranty. The warranty does not cover normal wear and tear, improper assembly or maintenance, or installation of parts or accessories not originally intended or compatible with the Fitness Product as sold. The warranty does not apply to damage or failure due to accident, abuse, corrosion, discoloration of paint or plastic, or neglect. VISION FITNESS shall not be responsible for incidental or consequential damages. Parts and Electronic components reconditioned to As New Condition by VISION FITNESS or its vendors may sometimes be supplied as warranty replacement parts and constitute fulfillment of warranty terms. Any warranty replacement parts shall be warranted for the remainder of the original warranty term.

VISION FITNESS expressly disclaims all other warranties, express or implied, including but not limited to all warranties of fitness for a particular purpose or of merchantability. This warranty gives you specific legal rights, and your rights may vary from state to state.

WARRANTY REGISTRATION

Your warranty card must be completed and sent to VISION FITNESS before a warranty claim can be processed. You may also register via our website at www.visionfitness.com. Inside the enclosed warranty card, you will find a customer survey. Your care in completing the survey will be of value to us in serving you in the future. Comments and suggestions are always welcome. We are certain you will enjoy your new Incline Elliptical Trainer. Thank you for selecting a VISION FITNESS product.

DEVELOPING A FITNESS PROGRAM

By purchasing this piece of VISION FITNESS exercise equipment, you have made a commitment to exercise and now have the convenience of exercising in your own home. Your new equipment offers the flexibility to exercise at whatever time suits you best. It will be easier to maintain a consistent exercise program that will help you achieve your fitness goals.

ACHIEVING YOUR FITNESS GOALS

An important step in developing a long-term fitness program is to determine your goals. Is your primary goal to lose weight? Improve muscle tone? Relieve stress? Prepare for the spring racing schedule? Knowing what your goals are will help you develop a more successful exercise program. If possible, try to define your personal goals in precise, measurable terms over specific periods of time. Examples of these goals might include:

- Decrease your waistline by two inches over the next two months.
- Run the local 5K race this summer.
- Get 30 minutes of cardiovascular exercise at least five days per week.
- Improve your race time by two minutes over the next year.
- Move from walking a mile to jogging a mile within the next three months.

The more specific the goal, the easier it will be to track your progress. If your goals are long-term, divide them into monthly and weekly segments. Long-term goals can lose some of the motivational benefits. Short-term goals are easier to achieve and will allow you to see the progress you are making. Every time you reach a goal, it is important to set a new goal. This will lead to a healthier lifestyle and will provide the motivation that you will need to move forward.

TRACK YOUR PROGRESS

Now that you have set your exercise goals, it is time to write them down and make an exercise schedule that will help you achieve them. By keeping a fitness diary, you will stay motivated and know where you are in terms of reaching your goals. As time goes on, you will be able to look back with pride to see how far you've come. For your convenience, we have included exercise log sheets at the end of this manual.

EXERCISE GUIDELINES

EXERCISE DURATION

A common question asked is, “how much exercise do I need?” We recommend following the guidelines set up by the American College of Sports Medicine (ACSM) for healthy aerobic activity.

- Exercise three to five days per week.
- Warm up for five to 10 minutes before aerobic activity.
- Maintain your exercise activity for 30 to 45 minutes.
- Gradually decrease the intensity of your workout, then stretch to cool down during the last five to 10 minutes.


If weight loss is a major goal, participate in your aerobic activity at least 30 minutes for five days each week.

EXERCISE INTENSITY

The next question asked is, “how hard do I need to workout?” To reap the most cardiovascular benefits from your workout, it is necessary to exercise within a recommended intensity range. We recommend using one of two methods to measure exercise intensity. These two methods are performed by monitoring your exercise heart rate or by using the Rate of Perceived Exertion (RPE).

TARGET HEART RATE

Target Heart Rate is a percentage of your maximum heart rate. Target Heart Rate will vary for each individual depending on age, current level of conditioning, and personal fitness goals. Exercise heart rate should range from 55% to 85% of your maximum heart rate. As a point of reference, we use the predicted maximum heart rate formula of (220 minus age) to determine your heart rate training zone. Please use the following chart to determine your predicted Target Heart Rate.



EXAMPLE:

If you are a 30-year-old, your predicted maximum heart rate is 190 based on the (220 minus age) formula.

$$220 - 30 = 190$$

Based on the chart above, your heart rate training zone is 104 to 161, which is 55%–85% of 190.

RATE OF PERCEIVED EXERTION

Rate of Perceived Exertion (RPE) is one of the easiest ways to monitor exercise intensity. By becoming familiar with the RPE scale, you can continually assess your level of intensity and insure a level of exertion that is comfortable. An increase in exercise intensity is directly related to elevation in exercise heart rate. Consequently, RPE can be used alone or together with heart rate when monitoring exercise intensity.

RPE SCALE

0	Nothing at all
.5	Very, very weak
1	Very weak
2	Weak
3	Moderate
4	Somewhat strong
5	Strong
6	
7	Very strong
8	
9	
10	Very, very, strong
	Maximal

The recommended RPE range during exercise for most people is between 3 (moderate) and 5 (strong). The RPE should be independent of your pace.

BALANCED FITNESS

While cardiovascular exercise has been the primary method of fitness for many programs over the years, it should not be the only method. Strength Training and Flexibility Training have become more popular as exercise has developed. Incorporating Strength and Flexibility Training into your current exercise program will give you the balance you need to improve your athletic performance, reduce susceptibility to injury, increase metabolic rate, increase bone density, and reach your goals faster.

STRENGTH TRAINING

Strength Training was once known as an activity performed by young males only. That has changed with the advances in scientific research on Strength Training over the last 20 years or so. Research has proven that, after age 30, we begin to lose muscle mass if we do not incorporate Strength Training into our exercise program. With this decrease in muscle mass, our ability to burn calories decreases, our physical ability to do work decreases and our susceptibility to injuries increases. The good news is that, with a proper Strength Training program, we can maintain or even build muscle as we age. A proper Strength Training program will work the muscle groups of the upper and lower body. There are now many options available for Strength Training including: yoga, Pilates, selectorized machines, free weights, stability balls or medicine balls, exercise tubing and body weight exercises, just to name a few.

Recommendations for a minimum Strength Training program include:

FREQUENCY: Two to three days per week

VOLUME: One to three sets consisting of eight to 12 repetitions.

STRETCHING


Flexibility Training is not associated with fitness as often as cardiovascular exercise or Strength Training, even though it is just as important. A good stretching program will help to maintain flexibility of the hips and lower back. A flexible person will be less likely to injure themselves in common activities, such as reaching, twisting and turning, or in uncommon activities such as the annual softball tournament.

Before stretching, take a few minutes to warmup the muscles because stretching a cold muscle can cause injury. Start your stretch slowly, exhaling as you gently stretch the muscle. Try to hold each stretch 15 to 30 seconds. Don't bounce when you stretch. Holding a stretch offers less chance of injury. Don't strain or push a muscle too far. If it hurts, ease up. Here are a few stretches you can incorporate into your exercise program:

GENERAL


SEATED TOE TOUCH

Sit on the floor with your legs together and straight out in front of you. Do not lock your knees. Extend your fingers toward your toes, exhaling as you go. Hold for 15 to 30 seconds. Return to the start position, and repeat as necessary.




STANDING QUADRICEPS STRETCH

Using a wall to provide balance, grasp your left ankle with your left hand and hold to stretch. Your knee should be pointing toward the floor. Hold the stretch for 15 to 30 seconds. Repeat with your right leg, and continue to alternate as necessary.



STANDING CALF STRETCH

Standing about three to four feet from the wall, take one step forward with your right foot. Place your hands on the wall in front of you. Bend your right leg slowly, using your movement to control the amount of stretch in the left calf. Your left heel should remain on the ground. Slowly bring yourself back to the starting position and switch legs. Repeat as necessary.



GENERAL

51

Week #

Weekly Goals: _____

Scheduled Workout Time: _____

Reward: _____

Day	Date	Workload Level	Exercise Time	Distance	Comments
Sunday					
Monday					
Tuesday					
Wednesday					
Thursday					
Friday					
Saturday					
Totals			<input type="text"/>	<input type="text"/>	

Week #

Weekly Goals: _____

Scheduled Workout Time: _____

Reward: _____

Day	Date	Workload Level	Exercise Time	Distance	Comments
Sunday					
Monday					
Tuesday					
Wednesday					
Thursday					
Friday					
Saturday					
Totals			<input type="text"/>	<input type="text"/>	

Week #

Weekly Goals: _____

Scheduled Workout Time: _____

Reward: _____

Day	Date	Workload Level	Exercise Time	Distance	Comments
Sunday					
Monday					
Tuesday					
Wednesday					
Thursday					
Friday					
Saturday					
Totals			<input type="text"/>	<input type="text"/>	

GENERAL

Week #

Weekly Goals: _____

Scheduled Workout Time: _____

Reward: _____

Day	Date	Workload Level	Exercise Time	Distance	Comments
Sunday					
Monday					
Tuesday					
Wednesday					
Thursday					
Friday					
Saturday					
Totals			<input type="text"/>	<input type="text"/>	

January		
Week	Minutes	Distance
1		
2		
3		
4		
5		
Totals	<input type="text"/>	<input type="text"/>
Reward	<input type="text"/>	

February		
Week	Minutes	Distance
1		
2		
3		
4		
5		
Totals	<input type="text"/>	<input type="text"/>
Reward	<input type="text"/>	

March		
Week	Minutes	Distance
1		
2		
3		
4		
5		
Totals	<input type="text"/>	<input type="text"/>
Reward	<input type="text"/>	

April		
Week	Minutes	Distance
1		
2		
3		
4		
5		
Totals	<input type="text"/>	<input type="text"/>
Reward	<input type="text"/>	

May		
Week	Minutes	Distance
1		
2		
3		
4		
5		
Totals	<input type="text"/>	<input type="text"/>
Reward	<input type="text"/>	

June		
Week	Minutes	Distance
1		
2		
3		
4		
5		
Totals	<input type="text"/>	<input type="text"/>
Reward	<input type="text"/>	

July		
Week	Minutes	Distance
1		
2		
3		
4		
5		
Totals	<input type="text"/>	<input type="text"/>
Reward	<input type="text"/>	

August		
Week	Minutes	Distance
1		
2		
3		
4		
5		
Totals	<input type="text"/>	<input type="text"/>
Reward	<input type="text"/>	

September		
Week	Minutes	Distance
1		
2		
3		
4		
5		
Totals	<input type="text"/>	<input type="text"/>
Reward	<input type="text"/>	

October		
Week	Minutes	Distance
1		
2		
3		
4		
5		
Totals	<input type="text"/>	<input type="text"/>
Reward	<input type="text"/>	

November		
Week	Minutes	Distance
1		
2		
3		
4		
5		
Totals	<input type="text"/>	<input type="text"/>
Reward	<input type="text"/>	

December		
Week	Minutes	Distance
1		
2		
3		
4		
5		
Totals	<input type="text"/>	<input type="text"/>
Reward	<input type="text"/>	

GENERAL

*it all
starts
with a
v i s i o n*



500 South CP Avenue • P.O. Box 280
Lake Mills, WI 53551
toll free 800.335.4348 • phone 920.648.4090
fax 920.648.3373
www.visionfitness.com

©2007 Vision Fitness. All Rights Reserved.
HRT is a Trademark of Vision Fitness.
1.07
OM18.54PRD
REV1