

CTL120-3 Remote Control

This IR remote (Extron part #70-371-01) is to be used with the SWP123 Presentation Switcher.

Switching input devices

To switch to a new input group and input device using the CTL120-3 remote control:

1. Press and release the **SWP SWITCHER** button.
2. Press and release the numeric button (1, 2, 3, or 4) on the remote control unit that corresponds to the desired input group (VGA, S-video, Video, or Audio, respectively).
3. Press and release the numeric button (1, 2, 3, or 4) on the remote control unit that corresponds to the desired input device within the selected group that you want to connect to the output.
4. Press and release the **ENT (ENTER)** button to execute the switch.

68-940-01, Rev. A
12 04



Extron Electronics, USA
1230 South Lewis Street
Anaheim, CA 92805
USA
714.491.1500
Fax 714.491.1517

Extron Electronics, Europe
Beeldschermweg 6C
3821 AH Amersfoort
The Netherlands
+31.33.453.4040
Fax +31.33.453.4050

Extron Electronics, Asia
135 Joo Seng Road, #04-01
PM Industrial Building
Singapore 368363
+65.6383.4400
Fax +65.6383.4664

Extron Electronics, Japan
Kyodo Building
16 Ichibancho
Chiyoda-ku, Tokyo 102-0082 Japan
+81.3.3511.7655
Fax +81.3.3511.7656

Other CTL120-3 functions

The following button functions are also included for the SWP123.*

- **MIC** — + (increase) and – (decrease) microphone volume adjustment
- **VOL** — + (increase) and – (decrease) Master Audio output adjustment
- **Talk Over** — activate the microphone mixer for microphone talk over
- **Mute** — mute/unmute Master Audio output
- **Blank** — suppress the video/audio input to the selected A/V group

* *The remaining buttons do not apply to the SWP123 operation.*

Resetting the component code

If, for any reason, the component device code is erased, reset the code with the following instructions:

1. Press and release the **S** (set) button.
2. Press and release the **SWP SWITCHER** button.
3. Enter the component's three digit code number using the numeric buttons: **001**.
4. Press and release the **ENT (ENTER)** button to store the code.