



Operating Instructions



For Sony 4K Ultra HDTV XBR-84X900

US

4K Media Player
FMP-X1

Sony Customer Support

<http://www.sony.com/4ksupport/>
1-855-476-6945 (1-855-4Sony4K)
Please Call Before Returning the Product to the Store



*The screen design is subject to change without notice.

Overview


You can watch content that is already stored in the player. Some content are paid. You need an account of the 4K video content service to purchase content. Some content are downloaded via the internet connection in the background. Therefore, you may need to limit the Internet connection bandwidth of the player wherever necessary in accordance with your internet usage environment. This player is only compatible with the Sony 4K Ultra HDTV XBR-84X900 and Sony Xperia Tablet S and Z series.

- 1 Make sure the tablet device is wirelessly connected to a router and the 4K application is installed on the tablet device.
If the tablet device does not have the 4K application installed, go to "Play Store" on the tablet device, and obtain the "4K Ultra HD Remote" application to install. Registering "Google Accounts" is necessary to obtain the application from "Play Store."
- 2 Connect the player to the router the tablet device is connected to.
- 3 Connect the player to the HDMI IN 2 jack on the side panel of the TV with an HDMI cable*.
If you connect the player to an audio system (optional) with an HDMI cable*, you can enjoy surround sound (LPCM 5.1ch). In this case, after completing the setup, you need to configure the HDMI OUT 2 (for AUDIO) jack using the 4K application on the tablet device.
* A Sony HDMI cable is recommended.
- 4 Connect the AC adapter to the player, connect the AC power cord to the AC adapter, and then insert the power plug into an AC outlet.
- 5 Turn on the player and TV, and switch the TV input to HDMI2.
The PIN number screen automatically appears on the TV. It may take some time for the screen to appear (the power indicator blinks while the player is starting up and lights when it has turned on).
If the player has successfully connected to the network, the NETWORK indicator lights green.
- 6 Click the icon on the tablet device to start up the 4K application. Confirm the Legal Terms screen which automatically appears on the tablet device.
- 7 Wait for the PIN number screen to appear on the tablet device, and then enter the PIN number as shown on the TV screen in step 5.
- 8 Start pairing using the tablet device by following the instructions displayed on the tablet screen.
After pairing is successfully completed, the Home screen appears on the tablet device.

To create an account

You need an account to purchase content. Follow the on-screen instructions to create an SEN (Sony Entertainment Network) account.

Types of indicators



Power indicator

White

Blink: Starting up
Light: Power on
Light out: Power off

HDD

Green

Light: Writing to the hard disk (downloading or moving content, etc.)

NETWORK (status when power indicator lights)

Light out: Unconnected with the LAN cable

Green

Blink: Retrieving IP address or trying to connect to the internet

Light: Successfully connected to the internet

Red

Blink: Failed to retrieve IP address

Light: Failed to connect to the internet

Power indicator/NETWORK/HDD

Orange*

Simultaneously blink or light: Updating the software

Red*


Simultaneously blink: System error

* The power indicator blinks or lights white.

Optional Usage

To connect an external hard disk to the player

This function will be available by firmware upgrade. Please refer to the following website about the firmware availability.
www.sony.com/4ksupport/
You can move content between an external hard disk (25 GB - 4 TB, Hi-Speed USB and faster) and the internal hard disk.



To the USB jack
of the external hard disk


Notes

- When you connect an external hard disk to the player for the first time, the hard disk may be formatted exclusively for the player and all of the data on the hard disk will be erased.
- Before disconnecting the external hard disk, check that all of the indicators on the front of the player are off and wait for about five minutes. Also check that the player is not accessing to the external hard disk.


When using the jack cover

Make sure to detach the jack cover before connecting or disconnecting the cables.

When connecting the cables



When disconnecting the cables



Troubleshooting

The power does not turn on.

- Check that the AC adapter is connected securely to the DC IN jack on the rear of the player.
- Check that the AC power cord is connected securely to the AC outlet.

There is no picture.

- Re-connect all connecting cables securely.
- One of the connecting cables may be damaged.

There is no sound.

- Re-connect all connecting cables securely.
- One of the connecting cables may be damaged.
- You can also output audio signals to the HDMI OUT 2 (for AUDIO) jack through a connected audio system. Configure the HDMI OUT 2 (for AUDIO) jack using the 4K application on the tablet device.
- The audio system input may be automatically changed to the input that is connected to the TV. Switch the audio system input so that it outputs audio signals from the player.
- Make sure that the muting function of the TV or the audio system is not turned on.

The player cannot connect to the internet/network.

- Check the network connection and the network settings.
- The router must be DHCP server compatible.
- After making sure that the tablet device is connected to the internet, turn the player off and on again.
- If the player requires proxy settings for internet access, the settings are synchronized with the tablet device settings. Check the tablet device settings.

The player cannot pair with the tablet device.

- Make sure you are not using a tablet device other than Sony Xperia Tablet S or Z series.
- Make sure that the player and the tablet device are connected to the same router, or check the status of the network connection (See "Types of indicators").
- The player may be connected to a TV other than a Sony 4K Ultra HDTV XBR-84X900.
- The player may not be connected to the HDMI IN 2 jack of the TV.

The player does not detect the USB device connected to the player. (This function is not available in some areas.)

- Make sure that the USB device is connected securely to the EXTRA HDD jack.
- Check if the USB device or a cable is damaged.
- Check that the USB device is turned on.
- If the USB device is connected via a USB hub, connect the USB device directly to the player.