NISSAN CERTIFIED PRE-OWNED **VEHICLE INSPECTION FORM**

Certi	fication Number: NCPOX12B 0005 Stock number			
VIN r	number Dealer Code			
	er Name Date			
Repa	ir Order Number Model Year			
	el	ģ	þ	
	Odometer reading	ts	lace	air /
	Original In-Service Date	Meets Standard	Replaced	Repair Adjust
Pre-	Inspection:			
1	Basic Appearance meets Nissan Standards			
2	Vehicle Originally Imported by Nissan Canada for Sale in Canada Check Canadian Certification Label.			
3	Routine Maintenance is current or brought up to current level with appropriate inspection for age and mileage.			
4	Odometer has not been tampered with and the kilometers are known.			
5	No indication of significant body repair or frame damage			
6	No aftermarket accessories.			
7	No suspension, emission-system or exhaust system modifications other than NISMO Street Accessories			
VIN	Inspection			
8	VIN numbers match other VINs stamped on vehicle and on paperwork (Check Dash, Door Pillar and stamp as per service manual)			
9	Check to ensure all bulletins, campaigns and recall updates have been performed on the vehicle			
10	Check for any trouble codes (past or present) ATTACH Consult Printouts to repair order			
FXT	ERIOR			
	y Exterior			
12	Inspect for damage, dings, dents, alignment, mismatched paint - (Repair as Needed)			
13	Paint - Repair any cracks, dents, or surface scratches larger than 20mm			
14	Paint - Repair any chips larger than 5mm, dings or dents larger than 10 mm and any scratches which penetrate to the base metal			
15	Paint - Repair any surface corrosion or significant etching, stains or fallout.			
16	Doors/Hood/Trunk/Tailgate operation - Check release mechanisms manual/automatic, hinges, alignment and proper attaching devices.			
17	Bumpers - Repair any surface scratches greater than 50mm or any damage which penetrates to the base material.			
	s/Mirror/Wiper and Washer Condition			
18	Windshield (Replace if cracked, scratched or broken; Repair if chipped) Minor Pitting acceptable			
19	Side and Rear Glass - No cracks, scratches, chips larger than 5mm or significant pitting (Repair or Replace as Needed)			
20	Mirrors - Check Condition, Hinge, Operation, Heater, Power Adjusters (Repair or Replace as Needed)			
21	Wiper Blades and Operation - Check Condition of mechanism/blade, speeds/delay (Repair or Replace as Needed)			
-	Washer Front/Rear - Check Fluid Level/Spray Pattern (Refill, Repair or Replace as Needed)			
	roof/Moonroof/Convertible Top			
23	Sunroof/Moonroof - Check Operation - (Repair or Replace as Needed)			
24	Sunroof/Moonroof Sunshade - Check Operation, Check if Worn, Ripped, Cracked, or faded - (Clean, Repair or Replace as Needed)			
	dow/Door Locks Operation:			
25	Door Locks/Controls - Check Manual/Automatic Operation (Repair or Replace as Needed)			
26	Child Safety Locks - Check Operation (Repair or Replace as Needed)			
27	Windows/Controls & Window Lock - Check Operation (Repair or Replace as Needed)			
28	Key/Remote/Intelligent Key - Check Operation (Replace Battery in Remote as Needed)			
Exte	rior Lights			
29	Headlights, High/Low Beams - Check Alignment, Lens Condition, Operation (Replace Broken Lens or Non-Operational Bulbs/ Transformers)			
30	Tail Lights/Brake Lights/High Mounted Brake Light - Check Lens Condition and Operation (Replace as Needed)			
31	Turn Signal/Marker Lights - Check Lens Condition and Operation (Replace as Needed)			
32	Hazard & Reverse Lights - Check Lens Condition and Operation (Replace as Needed)			
33	License Plate Lights - Check Lens Condition and Operation (Replace as Needed)			

34 Fog/Driving Lights - Check Lens Condition and Operation (Replace as Needed)

35 Daytime Running Lights (DLR) - Check Lens Condition and Operation (Replace as Needed)

The Nissan names, logos and trademarks are owned by or licensed to Nissan Motor Co. Ltd. and/or its North American subsidiaries. © 2008 Nissan Canada Inc. All rights reserved.



Visually inspect for

NISSAN CERTIFIED PRE-OWNED

VEHICLE INSPECTION FORM

repairs, damage, abnormal tire wear. Note: Overall vehicle inspection should take place at this point for rust and
e natural disaster (flood etc.). Look under carpet in trunk, interior and under dash for flood/body damage repair.

36	36 damage due to some natural disaster (flood etc.). Look under carpet in trunk, interior and under dash for flood/body damage repair.		
	Any vehicle with flood, fire or significant frame damage should be excluded from Certification.		
RO	ROAD TEST		

37	Check Start-up Cold/Hot		
38	Check Engine Idle Quality		
39	Engine Performance/Smooth Acceleration - Check general drivability.		
40	Engine Noise - Check both Cold/Hot and High/Low Speeds		
41	Automatic Transmission/Transaxle (Cold/Hot) - Check Overall Operation, Slippage, Shift Points, Shift Interlock and Noise		

42 Shift Interlock - Check Operation (Repair or Replace as Needed) 43 Manual Transmission - Check Overall Operation, i.e. Smoothness, Noise and Synchronizers (Repair or Replace as Needed) 44 Clutch Operation - Check Overall Operation, Smoothness, Engagement, Slippage or Chatter (Repair, Adjust or Replace as Needed)

45 Clutch Interlock - Check Overall Operation (Repair, Adjust or Replace as Needed) 46 Drive Axle and Transfer Case - Check Bearings, Gear Noise or Vibration (Repair, Adjust or Replace as Needed)

47 Steering Performance - Check Free Play, Centering, Tracking and Smoothness - (Repair, Adjust or Replace as Needed) 48 Brakes/ABS - Check Effectiveness, Overall Operation, Noise, Pulling or Pulsating - (Repair, Adjust or Replace as Needed)

49 Cruise control - Check Operation Including Resume - (Repair, Adjust or Replace as Needed) Gauges (Speedometer/Tachometer/Odometer/Oil Pressure/Charging/Water Temp.) - Check Operation (Repair or Replace as

51 Wind Noise - Check for Excessive or Unusual Noise (Repair, Adjust or Replace Seals or Trim, Roof Rack etc., as Needed)

52 Body/Suspension - Check Performance, Noise, Vibration Utilize Rough Road Test (Repair, Adjust or Replace as Needed)

53	Navi System - Check Operation, Ensure DVD in System, Erase Addresses and Destinations - (Repair or Replace as Needed)			
54	Nissan DVD Entertainment System - Check Operation, Sound and Picture Quality - (Repair or Replace as Needed)			
55	Clock - Check Condition/Operation (Repair or Replace as Needed)			
56	Horn - Check Operation (Repair or Replace as Needed)			
57	Lighter/Power outlets - Check Condition/Operation (Repair or Replace as Needed)			

58 Glove Box/Glove Box Light/ Centre Armrest/Console - Check Condition/Operation (Repair or Replace as Needed) 59 Tilt and/or Telescope Steering Wheel - Check Operation (Repair or Replace as Needed)

60 Steering Wheel Lock - Operation (Repair or Replace as Needed) 61 Rear View Mirror - Check Condition/Operation (Repair or Replace as Needed)

62 Rear View Monitor - Condition/Operation/Picture Quality (Repair or Replace as Needed)

63 Instrument Panel/Lights and Warning Lights - Check Condition/Operation (Repair or Replace as Needed) 64 Warning Chimes - Check Operation (Repair or Replace as Needed)

65 Interior Courtesy/Dome/Map Lights - Check Operation (Repair or Replace as Needed)

66 Fuel Filler Door Release - Check Operation (Repair or Replace as Needed)

67 Odors - Check for Objectional Odours from Damp, Mould, Smoke, Perfume, Pets. etc. (Clean or Deodorize as Needed)

68 Carpet - Check if Worn, Ripped, Cracked, or Significantly Stained or Faded - (Clean, Repair or Replace as Needed) 69 Floor Mats - Check if Worn Ripped, Cracked, or Significantly Stained or Faded - (Clean or Replace as Needed)

70 Parcel Shelf - Check if Worn, Loose, Ripped, Cracked, or Significantly Faded - (Clean, Repair, Re-attach or Replace as Needed)

Dashboard/Door Trim/Panels/Dashboard - Check if Worn, Loose, Ripped, Cracked, or Significantly Faded - (Clean, Repair, Re-attach or 72 Headliner - Check if Worn, Ripped, Loose, Cracked, or Significantly Faded - (Clean, Repair or Replace as Needed)

Sun Visors, including mirror and light - Check Worn, Ripped, Cracked, or Significantly Stained or Faded - (Clean, Repair or Replace as

Part # 99999-NCPOE

uggage Compartment - Check Trim, Carpet and Cargo Net - Check if Worn, Ripped, Cracked or Soiled (Clean, Repair or Replace as	
eeded)	
uggage Compartment Light - Check Operation (Repair or Replace as Needed)	

76 Jack/Tools - (Check Operation/Condition)

77 Emergency Trunk Release - Check Operation



NISSAN CERTIFIED PRE-OWNED VEHICLE INSPECTION FORM

78 Seat Upholstery - Check if Worn, Ripped, Cracked, or Significantly Stained or Faded - (Clean, Repair or Replace as Needed)

81 Audio System - Check Radio, Cassette, CD, Speakers Condition and Operation (Repair or Replace Components as Needed)

85 Air Conditioning System - Check Overall Operation, Cooling, Compressor, Hoses, Leaks (Repair or Replace Components as Needed)

79 | Seat/Headrest Adjustments - Check Operation Manual/Automatic Operation (Repair or Replace as Needed)

84 Automatic Climate Control System - Check Overall Operation (Repair or Replace Components as Needed)

86 Heating System Operation - Check Overall Operation, Leaks (Repair or Replace Components as Needed)

90 Check for Oil in Air Cleaner (can indicate excessive blow by or faulty PCV system) - (Repair as Needed)

96 Belts - Check for Overall Condition, Cracks, Glazed, Frayed, Adjustment (Adjust or Replace as Needed)

98 Engine Mounts - Check for Cracking or Dryness - If electronic, check operation. (Replace as Needed)

101 Coolant - Check Condition, Level, Leaks and Record Freeze point . (Replace as Needed)

104 Cooling Fans/Fan clutch/Fan Motor - Check Condition, Operation (Repair or Replace as Needed)

100 Turbocharger/Supercharger - Check operation, belts and for excessive noise - (Repair or Replace as Needed)

107 Recovery Tank/Antifreeze Overflow Bottle - Check for Cracks or Leaks - Top up Fluid Level - (Replace Tank as Needed)

117 Alternator Charging - Check Voltage and Amperage Output - Attach Test printouts to work order (Repair or Replace as Needed)

91 Check the underside of the oil filler cap for water - (If water in oil, refuse vehicle for certification)

93 Cylinder power balance - run diagnostics (if error code/s present, compression check is required)

94 Engine Oil - Check Condition (could be an indicator or other issues) and Level (Change Oil)

92 Timing Chain - Check for Abnormal Noise (Repair, Adjust or Replace as Needed)

97 Wiring - Check for Damage or Tampering (Repair or Replace as Needed)

102 Coolant Hoses - Check for Cracking or Dryness (Replace as Needed)

105 Water Pump - Check for Noise or Leaks (Repair or Replace as Needed)

108 Check Operation of Block Heater (Repair or Replace as Needed)

111 Fuel Filter - Check Condition (Replace per Maintenance Schedule)

115 Perform Emission Control Tests and Record Readings on Work Order

116 Starter Operation - Check Draw and Amperage (Repair or Replace as Needed)

119 Battery Cables - Check Cables and Mounts (Repair or Replace as Needed)

112 Air Filter - Check Condition (Replace per Maintenance Schedule)

103 Radiator - Check Condition, Tubes and Fins (Repair or Replace as Needed).

106 Pressure Test Cooling System and Cap (Repair or Replace If Pressure Drop)

109 Fuel Pump - Check for Abnormal Noise/Leakage (Repair or replace as Needed)

110 Fuel Lines/Hoses - Check Condition or Signs of Leakage - Repair or Replace as Needed

114 Catalytic Converter(s) and Heat Shield(s) - Check Condition and Noise (Replace as Needed)

118 Ignition System Operation - Check Operation as per Service Manual (Repair as Needed)

120 Battery Condition - Check for Corrosion, Check Voltage, Perform Load Test (Replace as Needed)

113 Entire Exhaust System - Check Condition, Leaks, Hangers, Damage, Noise (Repair or Replace as Needed)

99 Hoses - Check for Cracking or Dryness - (Replace as Needed)

87 Rear Defogger/Defroster - Check Overall Operation (Repair or Replace Components as Needed) 88 Front Defogger/Defroster - Check Overall Operation (Repair or Replace Components as Needed)

80 Heated and/or Cooled Seats - Check Operation - (Repair or Replace as Needed)

82 Antenna - Check Condition and Operation (Repair or Replace as Needed) 83 Alarm/Theft Deterrent System - Check Operation (Repair or Replace as Needed)

89 Fluid Leakage - Record where and what is leaking

95 Oil change/scheduled maintenance performed. Date:

NISSAN CERTIFIED PRE-OWNED **VEHICLE INSPECTION FORM**

	$^{\prime}$					
122	Manual Transmission/Drive Axle/Transfer Case Fluids - Check Condition, Level, Leaks (Fill or Change Oil as Needed)					
123	23 Transmission Mounts - Check for Cracks or Broken (Replace as Needed)					
Tran	smission/Differential/Transaxle (Continued):					
124	Universal Joints/CV Joints/Boots - Check Overall Condition, Cracks, Dryness, Oil Soaked, Damage - (Repair or Replace as Needed)					
125	Differential/Drive Axles - Check Overall Condition, Leaks, Damage (Repair or Replace as Needed)					
126	AWD System - Check Operation, Overall Condition, Leaks, Damage (Repair or Replace as Needed)					
127	4WD System - Check Operation, Overall Condition, Leaks, Damage (Repair or Replace as Needed)					
128	Clutch - Check Operation, Slippage and Freeplay (Adjust, Replace or Repair as Needed)					
129	Clutch Hydraulic System - Check for Leakage and Proper Operation (Adjust or Replace as Needed)					
Susp	pension/Steering:					
130	Rack and Pinion - Check Overall Condition, Leaks, Boots, noise (Repair or Replace as Needed)					
131	Steering System Linkage front (and rear), Control Arms/Ball Joints/Bushings - Check if Damaged, Check Boots (Repair or Replace as					
	Needed)			_		
132	Power Steering Pump and Hoses - Check Overall Condition, Leaks, Fluid Level, Noise (Repair or Replace as Needed)					

33	Sway Bars/Links/Bushings - Check Overall Condition (Repair or Replace as Needed)			
34	Springs - Check Overall Condition and Ride Height (Repair or Replace as Needed)			
35	Struts/Shocks - Check for Leakage and Perform Bounce Test (Replace as Needed)			
Brak	rakes:			

121 Automatic Transmission/Transaxle Fluids - Check Condition, Level, Leaks (Fill or Change Fluid and Filters as Needed)

6	Calipers/Cylinders - Check Operation, Condition, Leaks (Adjust or Replace as Needed)	
7	Brake Fluid - Check and Condition (Top Up or Replace Fluid as Needed)	
8	Pads/Shoes (If less than 40 percent Replace)	
9	Rotors - Check Overall Condition, Wear (Machine or replace as Needed)	
0	Brake System - Lines, Hoses and Fittings for Wear, Leaks, Corrosion or Damage. (Repair, Replace as Needed)	
1	Anti-Lock Braking System - Check Overall Operation, excessive noise (Repair, Replace Components as Needed)	
2	Parking Brake - Check Operation (Adjust, Repair or Replace as Needed)	

145	Driver & Front Passenger Active Head Restraints - Check Condition and Operation. (Repair or Replace Components as Needed)			
	Driver & Front Passenger Supplemental Air Bags - Check Exterior Condition, Consult Codes, Dash Light Operation Note: When			
146	inspecting the air bag system, look carefully at the steering wheel for abnormal wear. Wear could indicate vehicle has been repaired			
	and a used steering wheel/used air bag installed. (Repair or Replace as Needed)			
147	Front Seat Side Supplemental Air Bags - Check appearance, Consult Codes, Dash Light Operation (Repair or Replace as Needed)			
148	Side Curtain Supplemental Air Bags - Check appearance Consult Codes Dash Light Operation (Repair or Replace as Needed)			

170	Olde Ourtain Ouppiementai 7 iii Dago	Oricon appearance, Consult Codes, Bash Light Operation (repair of replace as recode
\ \ / / l	ada and Time	

149	OEM Size Correct - Replace if not original size
150	Tires - Ensure OEM speed rating, same brand and model all around (Replace as Needed)
151	Tire Tread Depth (Replace if below 50 percent)

143 Master Cylinder and Booster - Check Operation and Leaks (Repair or Replace as Needed)

144 Seat Belts - Check Overall Condition and Operation (Repair or Replace as Needed)

152	Tire Condition/Abnormal Wear	- Check Sidewalls,	Vibration, Alignment I	Problems - (Replace as l'
153	Pressure - Set Tire Pressure to	OEM Specification	(Ensure Tire Pressur	e Monitoring system is w

154	Spare Tire, Retaining Cable and Mechanism - Check Condition, Tread, Pressure (Repair or Replace as Needed)

155	Wheels	 Check for visual runout, 	curb damage, marks	s, scratches, gouges	corrosion or pitting	(Repair or Replace	e if damage is larger then 5mm)	

Technician Final Acceptance	Signature
Service Manager Final Acceptance	Signature
Used Car Manager Final Acceptance	Signature