



PARTS AND SERVICE DEPARTMENT
Lebanon, Tennessee
615-889-8900 / Fax: 615-547-1000
www.Lochinvar.com

WARRANTY INFORMATION BY SERIAL NUMBER

Warranty Code Explanation

1. Water heater tanks for residential use have a six (6) year limited warranty effective 60 days from date of manufacture as determined by the serial number.
2. Water heater tanks for commercial use have a three (3) year limited warranty effective 60 days from date of manufacture as determined by the serial number.
3. Storage Tanks have a five (5) year limited warranty effective 60 days from date of manufacture as determined by the serial number.
4. Heat exchangers on copper-tube water heater models (IW, PF, CF, CW) have a five (5) year limited warranty effective 60 days from the date of manufacture as determined by the serial number.
5. Heat exchangers on copper-tube water heater models (EW, RW, CW 90-500) have a three (3) year limited warranty effective 60 days from the date of manufacture as determined by the serial number.
6. Heat exchangers on copper-tube boiler models (IB, PB, CH, CB & EB) have a ten (10) year limited warranty effective 60 days from the date of manufacture as determined by the serial number.
7. Heat Exchangers on stainless tube boiler models (KB 80-285, WB) have a twelve (12) year limited warranty effective 60 days from the date of manufacture as determined by the serial number.
8. Heat Exchangers on stainless tube boiler models (KB 399-800) have a ten (10) year limited warranty effective 60 days from the date of manufacture as determined by the serial number.
9. Heat Exchangers on stainless tube water heater models (AW) have a five (5) year limited warranty effective 60 days from the date of manufacture as determined by the serial number.
10. Heat exchangers on copper-tube boiler models (RB, CB 45-260) have a twenty (20) year limited warranty effective 60 days from the date of manufacture as determined by the serial number.
11. All residential tank-type water heater parts have a six (6) year warranty from the date of purchase.
12. All residential non-tank-type parts and all commercial parts have a one (1) year warranty from the date of purchase.
13. All shipping charges must be prepaid for any warranted item returned to Lochinvar at either Detroit, Michigan or Lebanon, Tennessee.

THIS OUTLINE IS NOT A WARRANTY.
FOR COMPLETE INFORMATION, CONSULT THE WRITTEN LIMITED
WARRANTY OR LOCHINVAR'S CONSUMER PRODUCTS DIVISION.

RESIDENTIAL TANK TYPE	ALL YEARS
GAS, ELECTRIC & SOLAR	ALL YEARS
COMMERCIAL TANK TYPE GAS	ALL YEARS
LIGHT DUTY COMMERCIAL ELECTRIC	ALL YEARS
EXPLOSION RESISTANT ELECTRIC	ALL YEARS
JACKETED TANKS (RJS & RJA)	1986-Present
STANDARD HI-POWERS (HS&HC)	1997-Present
COMPACT ASME HI-POWER	1997-Present
OIL FIRED	1992-2006

The above series has a two letter, six or seven number system, which is used to distinguish the warranty date.

Example: KJ-1000130...Built in September of 1993

The first letter signifies the year produced.
The second letter signifies the month produced.
The remaining numbers are production codes.

1 ST LETTER	2 ND LETTER
A = 2004	A = January
B = 2005	B = February
C = 2006	C = March
D = 2007	D = April
E = 2008	E = May
F = 2009	F = June
G = 2010	G = July
H = 1991	H = August
J = 1992	J = September
K = 1993	K = October
L = 1994	L = November
M = 1995	M = December
N = 1996	
P = 1997	
S = 1998	
T = 1999	
W = 2000	
X = 2001	
Y = 2002	
Z = 2003	

DATA PLATE LOCATION:

- Commercial Tank Type Gas, Oil Fired:**
Approximately half-way down the jacket on the front of the heater.
- Residential Tank Type Gas, Electric and Solar, Light Duty Commercial and Explosion Resistant Electric, Jacketed Tanks:**
Below the Lochinvar logo, approximately in the middle of the tank.
- Standard Hi-Power & Compact ASME Hi-Power:**
The upper right side of the jacket on the front of the heater.

Note: Residential products prior to serial number prefix SA have a five (5) year limited warranty.
Products starting with serial number prefix SA have a six (6) year limited warranty.

ELECTRIC BOOSTERS (SB) (1978-Present)

Booster serial numbers have ten numbers.
The first six numbers are production related.
The seventh & eighth number indicates year produced.
The final ninth or tenth numbers equal month produced.

Example: 1234569708...Built in August of 1997

7TH AND 8TH NUMBER 9TH AND 10TH NUMBER

99 = 1999	01 = January
00 = 2000	02 = February
01 = 2001	03 = March
02 = 2002	04 = April
03 = 2003	05 = May
04 = 2004	06 = June
05 = 2005	07 = July
06 = 2006	08 = August
07 = 2007	09 = September
08 = 2008	10 = October
09 = 2009	11 = November
10 = 2010	12 = December

DATA PLATE LOCATION:

On the lower right corner of the jacket, from the front view.

NOTE: RJA120 tanks manufactured after 2004 are listed in the warranty table on page 3.

CUSTOM HI-POWER (CHP)	1978-Present
JACKETED TANKS (TV* & R*A)	1979-Present
COPPER-FIN (CW & CB)	1981-Present
POOL HEATERS (ER, CS & CP)	1981-Present
POWER-FIN (PF & PB)	1986-Present
MINI-FIN (RW & RB)	1989-Present
COPPER-FIN II (CF & CH)	1991-Present
EFFICIENCY+ (EW & EB)	1997-Present
INTELLI-FIN (IW & IB)	2000-Present
SOLUTION (CB)	2004-Present
KNIGHT (KB)	2005-Present
ARMOR (AW)	2007-Present

* indicates G, N or J

The above models will have either a 7 place or a 12 place serial code.

Examples: J-930001...Built in September of 1993
A07H00123456 Built in January of 2007

First letter indicates month produced.

Next two numbers indicate year produced.

The remaining numbers are production codes.

1ST LETTER	1ST & 2ND NUMBER
A = January	91 = 1991
B = February	92 = 1992
C = March	93 = 1993
D = April	94 = 1994
E = May	95 = 1995
F = June	96 = 1996
G = July	97 = 1997
H = August	98 = 1998
I = September	99 = 1999
J = October	00 = 2000
K = November	01 = 2001
L = December	02 = 2002
	03 = 2003
	04 = 2004
	05 = 2005
	06 = 2006
	07 = 2007
	08 = 2008
	09 = 2009
	10 = 2010

DATA PLATE LOCATION:

A. Copper-Fin, Copper-Fin II, Efficiency+, Mini-Fin, Solution & Pool Heaters

On bottom right corner of the heater from the water connection side.

B. Power-Fin, Intelli-Fin

On upper back side of heater from the water connection side.

C. Custom Hi-Power, Jacketed Tanks

On outside door panel approximately at eye level.

STANDARD HI-POWER	1974-Apr. 1997
OIL FIRED (BRE SERIES)	1984-1992

NOTE: This chart is for reference only. See chart on page 2 for current standard Hi-Power and Oil-Fired serial numbers.

The above models have one letter, followed by six numbers, and one final letter on Hi-Powers.

Note: The fourth digit on oil heaters will be a letter.

Example: J93-1030F...Built in September of 1993

First letter indicates month produced.

Next two numbers indicate year produced.

1ST LETTER	1ST & 2ND NUMBER
A = January	82 = 1982
B = February	83 = 1983
C = March	84 = 1984
D = April	85 = 1985
E = May	86 = 1986
F = June	87 = 1987
G = July	88 = 1988
H = August	89 = 1989
J = September	90 = 1990
K = October	91 = 1991
L = November	92 = 1992
M = December	93 = 1993
	94 = 1994
	95 = 1995
	96 = 1996
	97 = 1997

DATA PLATE LOCATION:

A. Standard Hi-Power

The upper right side of jacket on the front of the heater.

B. Oil Heaters

Approximately halfway down the jacket on the front of the heater.

NOTE: All charts on this page are reference only.

HI-FIRE COMMERCIAL GAS (HF) thru 1986
OIL FIRED (G-O SERIES) thru 1986
POWER GAS (PG) thru 1986

A) 1965-1983 models coded with one letter, followed by five numbers.

Example: M78013...Built in December of 1978

First letter indicates month produced.
The next two numbers indicate year produced.
The remaining three numbers are production codes.

1 ST LETTER	1 ST TWO NUMBERS
------------------------	-----------------------------

A	= January	75	= 1975
B	= February	76	= 1976
C	= March	77	= 1977
D	= April	78	= 1978
E	= May	79	= 1979
F	= June	80	= 1980
G	= July	81	= 1981
H	= August	82	= 1982
J	= September	83	= 1983
K	= October	84	= 1984
L	= November	85	= 1985
M	= December	86	= 1986

1984-Present models coded with eight numbers.

Example: 85040000...April, 1985

First two numbers indicate year produced.
The third and fourth numbers indicate the month produced.
The final four numbers are production codes.

DATA PLATE LOCATION:

A. Hi-Fire

Left of the gas valve.

B. Power Gas

Left of the gas valve.

C. Oil-Fired (G-O Series)

On the front of the jacket, at the top.

COPPER-FIN® WATER HEATERS (CFW) 1968-1981
COPPER-FIN BOILERS (CFB) 1968-1981

The Copper-Fin heaters have a number followed by a letter(s) then three numbers.

Example: 5Y013...Built in May 1978

First number indicates month produced.
Next letter(s) indicates year produced.
Final three numbers are production codes.

1 ST NUMBER	1 ST LETTER
------------------------	------------------------

1	= January	P	= 1970
2	= February	R	= 1971
3	= March	S	= 1972
4	= April	T	= 1973
5	= May	U	= 1974
6	= June	V	= 1975
7	= July	W	= 1976
8	= August	X	= 1977
9	= September	Y	= 1978
10	= October	Z	= 1979
11	= November	AA	= 1980
12	= December	BB	= 1981

DATA PLATE LOCATION:

On the top left corner of Copper-Fin, from the front controls.

MOD-U-POWER (MUP) 1978-1984

The Mod-U-Power has a single letter, six number serial code.

Example: J-930001...Built in September of 1993

First letter indicates month produced.
Next two numbers indicate year produced.
The remaining numbers are production codes.

1 ST LETTER	1 ST & 2 ND NUMBER
------------------------	--

A	= January	78	= 1978
B	= February	79	= 1979
C	= March	80	= 1980
D	= April	81	= 1981
E	= May	82	= 1982
F	= June	83	= 1983
G	= July	84	= 1984
H	= August		
I	= September		
J	= October		
K	= November		
L	= December		