Ransburg

SERVICE INSTRUCTION SI-08-09.1 Replaces (SI-08-09)

SERVICE INSTRUCTION

PULSETRACK II START-UP REQUIREMENTS

Inspector's Initials	For Ransburg Technical Service Call: (800) 233-3366		
Before Start-Up (Site Inspection)			
	PulseTrack installed in a convenient area, located in a suitable environment (see manual for more details) .		
	Make sure the customer's main disconnect that supplies power to the PulseTrack is off.		
	Verify the incoming voltage at the disconnect.	Model #	Service Manual
	Remove fuses in the PulseTrack.		
	Check incoming voltage wiring inside the control panel for correct termination point.	A11515	LN-9248-05
	Check all I/O terminations for proper connections.	Reference www.ransburg.com for service manual information	
	Grounding checked to a known earth ground (flat braid and conventional).		
	Verify and document all dip switch settings for all cards.		
	Check all pneumatic tubing connections for tightness.		
	Required air available. 100 psi max. filtered to 40 Microns.		
	All cards seated properly.		
	Atomization to bearing air interlocks in place (if applicable).		
	_Start-Up Requirements		
	Turn on the customer's main disconnect.		
	Verify incoming voltage to the PulseTrack.		
	Turn off the customer's main disconnect.		
	Replace PulseTrack fuses.		
	Turn on the customer's main disconnect.		
	Follow normal start-up/operation procedures per applicator.		
NOTE:	Additional information regarding applicator and/or its capability can be found in the corresponding service manual.		
	For "Spare Part Information" reference the applicator service manual.		
	Always use genuine Ransburg replacement parts to assure maximum uptime with applicator.		
Facility Repre	sentative: Date:		
Ransburg Re	presentative: Date:		

Manufacturing 1910 North Wayne Street Angola, Indiana 46703-9100 Telephone: 260/665-8800 Fax: 260/665-8516 www.ransburg.com

Technical/Service Assistance Telephone: 800/ 233-3366 Fax: 419/ 470-2071

Technical Support Representative will direct you to the appropriate telephone number for ordering Spare Parts.



