



## Halogen Bulb replacement instructions:

**If your halogen bulbs need replacement, please follow these instructions below. You will need a 1" wide suction cup, available thru Faber or local hardware store.**

**Step 1:** Purchase a new MR-11 or MR-16 (Pellicano), 12 volt, 20 watt halogen bulb with a glass lens cover.

**Step 2:** Using the suction cup gently push against the bulb in the hood making a seal around the bulb.

**Step 3:** Pull down on the bulb with the suction cup, to remove the bulb from the hood

**Step 4:** Place the new bulb into the hood, lining up the bulb prongs with the holes inside the hood.

For more information please call Faber at 508-358-5353 or email [info@faberonline.com](mailto:info@faberonline.com)



**Step 1**



**Step 2**



**Step 3**



**Step 4**